



An Oshkosh Corporation Company



www.Discount-Equipment.com

---

# ***Service and Maintenance Manual***

## **Model**

### **530LRT**

**Prior to SN E200000675,  
Including  
1200027648 through 1200027657**

**P/N - 3121708**

November 8, 2018 - Rev D

**ANSI**



**CE**

**AS/NZS**





## SECTION A. MAINTENANCE SAFETY PRECAUTIONS

### GENERAL

This section contains the general safety precautions which must be observed during maintenance of the aerial platform. It is of utmost importance that maintenance personnel pay strict attention to these warnings and precautions to avoid possible injury to themselves or others, or damage to the equipment. A maintenance program must be followed to ensure that the machine is safe to operate.

#### **⚠ WARNING**

**MODIFICATION OF THE MACHINE WITHOUT APPROVAL BY JLG INDUSTRIES INC. IS A SAFETY VIOLATION.**

The specific precautions to be observed during maintenance are inserted at the appropriate point in the manual. These precautions are, for the most part, those that apply when servicing hydraulic and larger machine component parts.

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

#### **⚠ WARNING**

**SINCE THE MACHINE MANUFACTURER HAS NO DIRECT CONTROL OVER THE FIELD INSPECTION AND MAINTENANCE, SAFETY IN THIS AREA RESPONSIBILITY OF THE OWNER/OPERATOR.**

### HYDRAULIC SYSTEM SAFETY

It should be noted that the machines hydraulic systems operate at extremely high potentially dangerous pressures. Every effort should be made to relieve any system pressure prior to disconnecting or removing any portion of the system.



Relieve system pressure by cycling the applicable control several times with the engine stopped and ignition on, to direct any line pressure back into the reservoir. Pressure feed lines to system components can then be disconnected with minimal fluid loss.

### MAINTENANCE

#### **⚠ WARNING**

**FAILURE TO COMPLY WITH SAFETY PRECAUTIONS LISTED IN THIS SECTION MAY RESULT IN MACHINE DAMAGE, PERSONNEL INJURY OR DEATH AND IS A SAFETY VIOLATION.**

- No smoking is mandatory. never refuel during electrical storms. ensure that fuel cap is closed and secure at all other times.
- Remove all rings, watches and jewelry when performing any maintenance.
- Do not wear long hair unrestrained, or loose-fitting clothing and neckties which are apt to become caught on or entangled in equipment.
- Observe and obey all warnings and cautions on machine and in service manual.
- Keep oil, grease, water, etc. wiped from standing surfaces and hand holds.
- Use caution when checking a hot, pressurized coolant system.
- Never work under an elevated scissor until platform has been safely restrained from any movement by blocking or overhead sling, or boom safety prop has been engaged.
- Before making adjustments, lubricating or performing any other maintenance, shut off all power controls.
- Battery should always be disconnected during replacement of electrical components.
- Keep all support equipment and attachments stowed in their proper place.
- Use only approved, nonflammable cleaning solvents.

**REVISION LOG**

Original Issue - A .....April 11, 2016  
Revised - B ..... July 13, 2016  
Revised - C ..... January 30, 2018  
Revised - D .....November 8, 2018

Go to [Discount-Equipment.com](http://Discount-Equipment.com) to order your parts



TABLE OF CONTENTS

SUBJECT - SECTION, PARAGRAPH	PAGE NO.
<b>SECTION 1 - SPECIFICATIONS</b>	
1.1 Specifications .....	1-1
Operating Specifications .....	1-1
Dimensional Data .....	1-1
Capacities .....	1-1
Tires .....	1-2
Critical Stability Weights .....	1-2
Major Component Weights .....	1-2
1.2 Engine Specifications .....	1-2
Kubota (D1305-E4B - T4F - Diesel) .....	1-2
Kubota (D1305-E3B - T4i - Diesel) .....	1-2
Kubota (WG972-GL-E4F -T3 - Dual Fuel) .....	1-3
1.3 Hydraulic Pressure Settings .....	1-3
1.4 Hydraulic Cylinder Specifications .....	1-3
1.5 Serial Number Locations .....	1-3
1.6 Elevation/Tilt Limit Settings .....	1-4
1.7 Lubrication .....	1-4
1.8 Torque Charts .....	1-7
SAE Fasteners .....	1-7
Metric Fasteners .....	1-10
<b>SECTION 2 - GENERAL</b>	
2.1 Machine Preparation, Inspection, and Maintenance .....	2-1
General .....	2-1
Preparation, Inspection, and Maintenance .....	2-1
Pre-Start Inspection .....	2-1
Pre-Delivery Inspection and Frequent Inspection .....	2-1
Annual Machine Inspection .....	2-1
Preventative Maintenance .....	2-1
2.2 Preventive Maintenance and Inspection Schedule .....	2-2
Footnotes and Performance Codes .....	2-2
Schedule .....	2-3
2.3 Service and Guidelines .....	2-5
General .....	2-5
Safety and Workmanship .....	2-5
Cleanliness .....	2-5
Components Removal and Installation .....	2-5
Component Disassembly and Reassembly .....	2-5
Pressure-Fit Parts .....	2-5
Bearings .....	2-5
Gaskets .....	2-5
Bolt Usage and Torque Application .....	2-6
Hydraulic Lines and Electrical Wiring .....	2-6
Hydraulic System .....	2-6
Lubrication .....	2-6
Battery .....	2-6
Lubrication and Servicing .....	2-6
2.4 Lubrication and Information .....	2-6
Hydraulic System .....	2-6
Hydraulic Oil .....	2-6

## TABLE OF CONTENTS

---

	Changing Hydraulic Oil .....	2-7
	Lubrication Specifications .....	2-7
2.5	Service Maintenance Components .....	2-7
	Setting Scissor Arm Safety Prop .....	2-7
	General Maintenance Tips .....	2-8
	Fuel Tank .....	2-9
	Drive Hub .....	2-9
	Scissor Arms - Sliding Wear Pads .....	2-9
	Hydraulic Oil Tank .....	2-9
	Engine - Oil Change w/Filter - Kubota - (WG972-GL-E4F -T3) Dual Fuel .....	2-9
	Engine - Oil Change w/Filter - Kubota (D1305-E4B - T4F - Diesel) and (D1305-E3B - T4 - Diesel) .....	2-10
	Fuel/Water Separator Filter (Diesel) - Kubota .....	2-10
	Hydraulic Charge Filter (Diesel) - Kubota .....	2-10
	Fuel Strainer (Diesel) - Kubota .....	2-10
	Fuel Filter (Gas) - Kubota .....	2-11
	Air Filter .....	2-11
2.6	Cylinder Drift Test .....	2-11
	Platform Drift .....	2-11
	Cylinder Drift .....	2-11
2.7	Pins and Composite Bearing Repair Guidelines .....	2-12
<b>SECTION 3 - CHASSIS, PLATFORM &amp; SCISSOR ARMS</b>		
3.1	Operating Characteristics .....	3-1
	Leveling Jacks .....	3-1
	Generator .....	3-1
	Lift .....	3-1
	Drive .....	3-1
3.2	Tires, Wheels, & Drive Assembly .....	3-1
	Tire Inflation .....	3-1
	Tire Damage .....	3-1
	Tire Replacement .....	3-1
	Wheel Replacement .....	3-2
	Wheel Installation .....	3-2
	Drive Assembly .....	3-3
3.3	Drive Hub (Fairfield) .....	3-4
	Roll and Leak Testing .....	3-4
	Tightening and Torquing Bolts .....	3-4
	Oil Information .....	3-4
	Main Disassembly for Drive Hub .....	3-8
	Hub-Spindle Disassembly .....	3-8
	Cover Disassembly .....	3-8
	Carrier Disassembly .....	3-9
	Assembly of the Carrier .....	3-9
	Cover Sub-Assembly .....	3-11
	Hub-Spindle Sub-Assembly .....	3-12
	Main Assembly .....	3-14
	Tool List .....	3-19
	Re-Aligning Torque Hub Input Coupling .....	3-19
3.4	Drive Motor (Sauer) .....	3-20
	Description .....	3-20
	Shaft Seal Replacement .....	3-20
	Loop Flushing Valve .....	3-21

	Troubleshooting .....	3-22
	Disassembly .....	3-23
	Inspection .....	3-26
	Assembly .....	3-29
	Initial Start-Up Procedures .....	3-34
3.5	Front Axle .....	3-35
	Front Axle Assembly (Fixed) .....	3-35
	Front Axle Assembly (Oscillating) .....	3-36
	Steering Assembly .....	3-37
	Axle Lockout Cylinder .....	3-38
3.6	Leveling Jacks .....	3-39
	Cylinder Removal .....	3-39
	Assembly Removal .....	3-40
3.7	Platform .....	3-41
	Platform Control Station .....	3-42
	Joystick Controller .....	3-43
3.8	Scissor Arms .....	3-44
	Lift Cylinder Removal .....	3-44
	Scissor Arms Removal .....	3-44
	Scissor Arm Assembly Removal .....	3-44
3.9	Side Compartment Covers .....	3-48
	Engine Compartment (Left Side) .....	3-48
	Hydraulic/Fuel Compartment (Right Side) .....	3-49
	Cover Removal .....	3-50
	Cover Installation .....	3-50
3.10	Ground Control Station .....	3-50
	Control Station Removal .....	3-50
	Ground Control Station Components .....	3-51
	Options Control Module .....	3-52
3.11	Battery .....	3-53
3.12	Fuel Tank .....	3-54
3.13	Hydraulic Tank .....	3-55
3.14	Kubota Engine .....	3-56
	Engine Tray - Swing Out .....	3-56
	Generator (If Equipped) .....	3-57
	Exhaust System .....	3-58
	Air Cleaner System .....	3-59
	Radiator .....	3-60
	Engine Electrical Component Locations .....	3-61
	Hydraulic Pumps .....	3-63
	Pump Coupling Assembly .....	3-64
	Engine Removal .....	3-65
3.15	Dual Fuel/LPG System .....	3-66
	Changing From Gasoline to LP Gas .....	3-66
	Changing From LP Gas to Gasoline .....	3-66
	Using Liquid Petroleum (LP) Gas .....	3-66
	Propane Fuel System Pressure Relief .....	3-66
	Propane Fuel System Leak Test .....	3-66

**SECTION 4 - HYDRAULICS**

4.1	Cylinders - Theory of Operation .....	4-1
4.2	Valves - Theory of Operation .....	4-1
	Solenoid Control Valves (Bang-Bang) .....	4-1
	Relief Valves .....	4-1

## TABLE OF CONTENTS

---

	Crossover Relief Valves .....	4-1
4.3	Cylinder Checking Procedure .....	4-1
	Cylinders Without Counterbalance Valves .....	4-1
	Cylinders With Single Counterbalance Valve .....	4-2
4.4	Oscillating Axle - Lockout Cylinder Test (if equipped) .....	4-2
	Left Side Wheel Test .....	4-2
	Right Side Wheel Test .....	4-3
4.5	Drive Pump Start-up Procedure .....	4-3
4.6	Hydraulic Component Start-Up Procedures & Recommendations .....	4-4
4.7	Hydraulic Valves .....	4-6
	Main Hydraulic Valve .....	4-7
	Flow Divider Valve .....	4-9
	Leveling Jack Directional Valve .....	4-10
	Leveling Jack Valves .....	4-11
	Pressure Relief Valve - Setting Procedures .....	4-12
4.8	Gear Pumps .....	4-13
	Gear Pump Priming .....	4-13
	All Diesel Engines/Dual Fuel Engines Prior to SN E200000368 .....	4-13
	Dual Fuel Engines (SN E200000369 through E200000675) .....	4-14
4.9	Axial HI 45 Pump .....	4-15
	General Repair Instructions .....	4-17
	Start-Up Procedure .....	4-17
	Removing the pump .....	4-18
	Electric Control Module .....	4-19
	Control Solenoids .....	4-19
	Shaft Seal, Roller Bearing & Shaft Replacement .....	4-20
	Charge Pump .....	4-20
	Charge Check/HPRV .....	4-22
	Charge Pressure Relief Valve .....	4-22
	Pressure Limiter Valve Replacement .....	4-23
4.10	Charge Pump Filter .....	4-23
4.11	Cylinder Repair .....	4-24
	Disassembly .....	4-24
	Cleaning and Inspection .....	4-25
	Assembly .....	4-26
4.12	Cylinder Assemblies .....	4-30
	Oscillating Axle Cylinder Bleeding Procedure .....	4-37

## SECTION 5 - JLG CONTROL SYSTEM

5.1	Hand Held Analyzer .....	5-1
	To Connect the Hand Held Analyzer .....	5-1
	Using the Analyzer .....	5-2
	Changing the Access Level of the Hand Held Analyzer .....	5-3
	Adjusting Parameters Using the Hand Held Analyzer .....	5-4
	Machine Setup .....	5-4
	Analyzer Menu Flow Charts .....	5-6
5.2	Diagnostic Troubleshooting codes (DTC's) and Flash Codes Description .....	5-10
5.3	Tilt Sensor Installation .....	5-19
5.4	Sensor Location and Calibration .....	5-20
	Rotary Angle (Elevation) Sensor Calibration .....	5-20
	Arm Stack Angle Sensor Calibration .....	5-21
	Oscillating Axle Tilt Sensor .....	5-21
	Tilt Sensor Calibration .....	5-21
	Leveling Jack Pressure Set Calibration .....	5-22

	Drive Minimum Calibration.....	5-23
	Reset Personality Calibration.....	5-23
5.5	Machine Setup (Configuration) and Calibration Procedure.....	5-24
5.6	Machine Configuration And Programming Settings.....	5-25
	Machine Tilt Configuration.....	5-26
	Machine Model Personality Adjustment.....	5-27

**SECTION 6 - GENERAL ELECTRICAL INFORMATION & SCHEMATICS**

6.1	General.....	6-1
6.2	Multimeter Basics.....	6-1
	Grounding.....	6-1
	Backprobing.....	6-1
	Min/Max.....	6-1
	Polarity.....	6-1
	Scale.....	6-1
	Voltage Measurement.....	6-2
	Resistance Measurement.....	6-2
	Continuity Measurement.....	6-3
	Current Measurement.....	6-3
	Continuity Measurement Over Long Distances.....	6-4
	Requirements:.....	6-4
	Procedure.....	6-4
6.3	Applying Silicone Dielectric Compound To Amp Connectors.....	6-5
	Assembly.....	6-6
	Disassembly.....	6-7
	Wedge Lock.....	6-7
	Service - Voltage Reading.....	6-8
6.4	Working With Deutsch Connectors.....	6-9
	DT/DTP Series Assembly.....	6-9
	DT/DTP Series Disassembly.....	6-9
	HD30/HDP20 Series Assembly.....	6-9
	HD30/HDP20 Series Disassembly.....	6-9
6.5	Switches.....	6-10
	Basic check.....	6-10
	Limit Switches.....	6-10
	Automatic Switches.....	6-11
	Switch Wiring - Low Side, High Side.....	6-11
6.6	Electrical Schematic.....	6-12
	Ground Controls.....	6-12
	Chassis, Arm Stack, and Options.....	6-13
	Platform Controls.....	6-14
	Platform Control Box.....	6-15
	Kubota Diesel Engine.....	6-16
	Kubota Dual Fuel Engine Chassis.....	6-17
	Kubota Dual Fuel Engine.....	6-18
	Generator and Light Options.....	6-19
6.7	Hydraulic Schematics.....	6-20
	Oscillating Axle Valve.....	6-21

**LIST OF FIGURES**

<b>FIGURE NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
1-1.	Hydraulic Oil Operating Temperature Specifications . . . . .	1-5
1-2.	Engine Oil Operating Temperature Specifications - Kubota (Dual Fuel Engine) . . . . .	1-5
1-3.	Engine Oil Operating Temperature Specifications - Kubota (Diesel Engine) . . . . .	1-6
2-1.	Scissor Arm - Safety Prop Assembly . . . . .	2-7
2-2.	Safety Prop Actuator Rod . . . . .	2-8
2-3.	Service Maintenance Components . . . . .	2-8
3-1.	Drive Hub . . . . .	3-5
3-2.	Drive Hub (Cross-Section) . . . . .	3-7
3-3.	Cluster Gear Punch Marks . . . . .	3-16
3-4.	Drive Motor Cross Section . . . . .	3-20
3-5.	Removing the Shaft Seal . . . . .	3-20
3-6.	Loop Flushing Spool . . . . .	3-23
3-7.	Plugs, Fittings, and Speed Sensor . . . . .	3-23
3-8.	End Cap . . . . .	3-24
3-9.	Valve Plate & Rear Shaft Bearing . . . . .	3-24
3-10.	Cylinder Kit . . . . .	3-25
3-11.	Shaft Seal . . . . .	3-25
3-12.	Shaft & Front Bearing . . . . .	3-25
3-13.	Swash Plate & Servo Piston . . . . .	3-25
3-14.	Cylinder Kit Disassembly . . . . .	3-26
3-15.	Servo Piston . . . . .	3-29
3-16.	Cylinder Kit Assembly . . . . .	3-30
3-17.	Swash Plate and Journal Bearing . . . . .	3-30
3-18.	Shaft and Front Bearing . . . . .	3-31
3-19.	Cylinder Kit Installation . . . . .	3-31
3-20.	Servo Spring and Minimum Angle Stop . . . . .	3-31
3-21.	Valve Plate and Rear Bearing . . . . .	3-32
3-22.	End Cap . . . . .	3-32
3-23.	Shaft Seal . . . . .	3-33
3-24.	Plugs and Fittings Installation . . . . .	3-33
3-25.	Loop Flushing Spool . . . . .	3-34
3-26.	Joystick Controller . . . . .	3-43
3-27.	Scissor Arm - Hose and Wiring Routing . . . . .	3-45
3-28.	Scissor Arm Component Assembly 1 of 2 . . . . .	3-46
3-29.	Scissor Arm Component Assembly 2 of 2 . . . . .	3-47
3-30.	Dual Fuel Engine - Control Module Location . . . . .	3-61
3-31.	Dual Fuel Engine Compartment - Electrical Component Locations . . . . .	3-61
3-32.	Diesel Engine Compartment - Electrical Component Locations (T4F and CE) . . . . .	3-62
4-1.	Hydraulic Compartment Control Valves . . . . .	4-6
4-2.	Main Valve Port Identification . . . . .	4-7
4-3.	Flow Divider Valve . . . . .	4-9
4-4.	Leveling Jack Directional Valve . . . . .	4-10
4-5.	Leveling Jack Valves . . . . .	4-11
4-6.	Axial HI 45 Pump . . . . .	4-15
4-7.	Axial HI 45 Pump - Cross Section View . . . . .	4-16
4-8.	Charge Pump Filter . . . . .	4-23
4-9.	Lift Cylinder Holding Valve and Fitting Removal . . . . .	4-24
4-10.	Cylinder Barrel Support . . . . .	4-24
4-11.	Lift Cylinder Cap Screw Removal . . . . .	4-24
4-12.	Cylinder Rod Support . . . . .	4-25
4-13.	Tapered Bushing Removal . . . . .	4-25
4-14.	Bushing Installation . . . . .	4-26
4-15.	Rod Seal Installation . . . . .	4-26
4-16.	Poly-Pak Piston Seal Installation . . . . .	4-26

4-17.	Wiper Seal Installation .....	4-27
4-18.	Installation of Head Seal Kit .....	4-27
4-19.	Piston Seal Kit Installation .....	4-27
4-20.	Tapered Bushing Installation.....	4-28
4-21.	Seating the Tapered Bearing.....	4-28
4-22.	Rod Assembly Installation .....	4-28
4-23.	Steer Cylinder .....	4-30
4-24.	Lift Cylinder (Lower) .....	4-31
4-25.	Lift Cylinder (Upper) .....	4-32
4-26.	Lift Cylinder Valve Cartridge Torque Values.....	4-33
4-27.	Oscillating Axle Cylinder .....	4-34
4-27.	Leveling Jack Cylinder .....	4-35
4-28.	Leveling Jack Torques .....	4-36
4-29.	Oscillating Axle Cylinder Bleeding.....	4-37
5-1.	Analyzer Menu Flow Chart (Version P2.1) - Sheet 1 of 4 .....	5-6
5-2.	Analyzer Menu Flow Chart (Version p2.1) - Sheet 2 of 4 .....	5-7
5-3.	Analyzer Menu Flow Chart (Version P2.1) - Sheet 3 of 4 .....	5-8
5-4.	Analyzer Menu Flow Chart (Version P2.1) - Sheet 4 of 4 .....	5-9
5-5.	Tilt Sensor Location .....	5-19
5-6.	Tilt Sensor Removal .....	5-19
6-1.	AMP Connector .....	6-5
6-2.	Connector Assembly (1 of 4) .....	6-6
6-3.	Connector Assembly (2 of 4) .....	6-6
6-4.	Connector Assembly (3 of 4) .....	6-6
6-5.	Connector Assembly (4 of 4) .....	6-6
6-6.	Connector Disassembly.....	6-7
6-7.	Connector Installation .....	6-8
6-8.	DT/DTP Contact Installation .....	6-9
6-9.	DT/DTP Contact Removal.....	6-9
6-10.	HD/HDP Contact Installation.....	6-9
6-11.	HD/HDP Locking Contacts Into Position .....	6-9
6-12.	HD/HDP Contact Removal .....	6-9
6-13.	HD/HDP Unlocking Contacts.....	6-9

**LIST OF TABLES**

<b>TABLE NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
1-1	Maximum Cutout Height .....	1-4
1-2	Tilt Cutout Settings.....	1-4
1-3	Lubrication Specifications .....	1-4
2-1	Inspection and Maintenance.....	2-2
3-1	Wheel Torque Chart .....	3-2
3-2	Drive Hub Part Description .....	3-6
3-3	Excessive Noise and/or Vibration.....	3-22
3-4	System Operating Hot.....	3-22
3-5	Won't Shift or Slow to Start .....	3-22
3-6	Displacement Identifiers.....	3-25
3-7	Slipper Foot Thickness & End Play.....	3-27
3-8	Cylinder Block Measurements .....	3-27
3-9	Joystick Specifications.....	3-43
3-10	Joystick Plug Loading Chart .....	3-43
3-11	AC Generator Specifications .....	3-57
4-1	Main Valve Port Identification.....	4-8
4-2	Main Valve Torque Specs .....	4-8
4-3	Main Valve Porting Specs .....	4-8
4-4	Leveling Jack Directional Valve Torque Specs.....	4-11
4-5	Leveling Jack Valves Torque Specs .....	4-11
4-6	Axial HI 45 Pump Specs .....	4-15
4-7	Holding Valve Torque Specifications .....	4-28
5-1	DTC and Flash Code Descriptions .....	5-10
5-2	Tilt Sensor Harness (SN3) .....	5-19

Go to Discount-Equipment.com to order your part.



# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

**Search Manuals**

Enter your information to search for manuals and parts.

\* Brand:

\* Model:

\* Serial:

\* Part Number:

SEARCH

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

**Parts Order Form**

Please fill in the following information:

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Part Name:

Part Description:

Part Location:

Part Condition:

Part Status:

Part Price:

Part Weight:

Part Dimensions:

Part Material:

Part Color:

Part Finish:

Part Notes:

Part Images:

Part Attachments:

Part Specifications:

Part Certifications:

Part Compliance:

Part Safety:

Part Environmental:

Part Performance:

Part Reliability:

Part Durability:

Part Efficiency:

Part Accuracy:

Part Precision:

Part Consistency:

Part Quality:

Part Value:

Part Cost:

Part Profit:

Part Margin:

Part Return:

Part Warranty:

Part Support:

Part Training:

Part Documentation:

Part Compliance:

Part Safety:

Part Environmental:

Part Performance:

Part Reliability:

Part Durability:

Part Efficiency:

Part Accuracy:

Part Precision:

Part Consistency:

Part Quality:

Part Value:

Part Cost:

Part Profit:

Part Margin:

Part Return:

Part Warranty:

Part Support:

Part Training:

Part Documentation:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

## SECTION 1. SPECIFICATIONS

## 1.1 SPECIFICATIONS

## Operating Specifications

Model	530LRT
Maximum Occupants	6
Maximum Workload (Capacity): Main Platform: Max. on Extension (Each):	1500 lb (680 kg) 500 lb (227 kg)
Maximum Stowed Travel Grade - Gradeability:	40% (22°)
Maximum Stowed Travel Grade - Sideslope:	5°
Maximum Platform Working Height	53 ft (16.14 m)
Maximum Drive Height	32 ft (9.8 m)
Maximum Drive Speed Platform Lowered: High Mid Low (> 14 ft) Platform Elevated:	3.5 mph (5.6 kph) 2.0 mph (3.21 kph) 1.0 mph (1.61 kph) 0.5 mph (0.8 kph)
Lift Up Speed (No Load) (Stowed to Full Height)	65 seconds
Lift Down Speed (No Load) (Full Height to Stowed)	60 seconds
Maximum Wind Speed	28 mph (12.5 m/s)
Maximum Horizontal Manual Side Force: ANSI/ANSI EXPORT: CE:	300 lb force (1335 N) 90 lb force (400 N)
Maximum Tire Load (Each)	5500 lb (2500 kg)
Ground Bearing Pressure w/Standard tires	26.5 psi (1.86 kg/cm <sup>2</sup> )
Leveling Jack Bearing Pressure	70 psi (4.92 kg/cm <sup>2</sup> )
Hydraulic System Pressure Main Relief: Lift Up Relief: Steer Relief: Leveling Jack Relief:	3000 psi (207 bar) 2700 psi (186 bar) 2500 psi (193 bar) 2000 psi (138 bar)
Electrical System Voltage	12V
Inside Turning Radius	109.7 in (2.79 m)

Model	530LRT
Outside Turning Radius	19.76 ft (6.023 m)
Gross Vehicle Weight Dual Fuel/Diesel - ANSI/ANSI Export/CSA/CE w/ One Extension: w/Two Extensions: w/Mega Deck:	17,000 lb (7711 kg) 17,300 lb (7847 kg) 17,800 lb (8074 kg)
<i>Note: Certain options or country standards increase weight.</i>	

## Dimensional Data

	530LRT
Wheelbase	117 in (297 cm)
Ground Clearance (center/platform stowed)	12 in (32 cm)
Machine Height (top of rails/platform stowed)	93 in (236.2 cm)
Machine Width	90.8 in (230 cm)
Machine Length (leveling jack to leveling jack)	192.2 in (488.3 cm)

## Capacities

Fuel Tank Capacity	Diesel: Gasoline: LP Tank:	22 gal (83.3 L) 22 gal (83.3 L) 43.5 lb (20 kg)
Hydraulic Tank		32.3 gal (122.2 L)

## SECTION 1 - SPECIFICATIONS

### Tires

Size	Ply Rating	Foam Fill Tire Assembly Rating	Wheel Nut Torque
12x16.5 Foam Filled (Non-Marking)	10	90 PSI@ 8,000 lb (3700 Kg) - Static Load	170 ft.lb. (230 Nm)
12x16.5 Foam Filled	10	90 PSI@ 8,000 lb (3700 Kg) - Static Load	170 ft.lb. (230 Nm)
IN395/45/D20 Foam Filled (Non-Marking)	14	90 PSI@ 14,740 lb (6700 Kg) - Static Load	170 ft.lb. (230 Nm)
IN395/45/D20 Foam Filled	14	90 PSI@ 14,740 lb (6700 Kg) - Static Load	170 ft.lb. (230 Nm)

### Critical Stability Weights

#### WARNING

**DO NOT REPLACE ITEMS CRITICAL TO STABILITY WITH ITEMS OF DIFFERENT WEIGHT OR SPECIFICATION (FOR EXAMPLE: FILLED TIRES, ENGINE) DO NOT MODIFY UNIT IN ANY WAY TO AFFECT STABILITY.**

Component	530LRT
Wheel and Tire (each) 12x16.5 - Foam Filled 395/45/D20 - Foam Filled	328 lb (149 kg) 381 lb (173 kg)
Engine Only (Kubota - Diesel)	209 lb (95.1 kg)
Engine Only (Kubota - Gas/LP)	158 lb (71.4 kg)
Battery	66 lb (30 kg)

### Major Component Weights

Component	Weight
Platform Single Ext: Dual Ext: Mega:	890 lb (404 kg) 890 lb (404 kg) 1,080 lb (490 kg)
Platform Extension (each)	290 lb (132 kg)
Arm Assembly- (Includes Lift Cylinders):	6,760 lb (3066 kg)
Chassis:	6,863 lb (3113 kg)
Chassis Counterweight:	1,005 lb (456 kg)
Chassis with Foam Filled Tires:	8,755 lb (3,971 kg)

## 1.2 ENGINE SPECIFICATIONS

### Kubota (D1305-E4B - T4F - Diesel)

Emissions	EPA - Tier 4 Final
Fuel Type:	Diesel: - Low Sulfur (<500 ppm) - Ultra Low Sulfur (15 ppm) (Recommended) - up to 5% biodiesel
No. of Cylinders	3
Oil Pan Capacity	1.51 Gal. (5.7 L)
Engine RPM Control	Mechanical
Low RPM Set	1200 RPM
High RPM Set	2600 RPM
Alternator	40 Amp, 12V, Belt Drive
Battery	112 Amp-Hour, 950 Cold Cranking Amps, 12VDC
Fuel Consumption:	Low RPM 0.41 GPH (1.5 lph) High RPM 2.0 GPH (7.6 lph)
Displacement	1.261 L (77 cu. in.)
Horsepower	24.8 Hp (18.5 Kw) @ 2600 RPM
Torque Rating	59.1 Ft. lb. (80.1 Nm) @ 1700 rpm

### Kubota (D1305-E3B - T4i - Diesel)

Emissions	CARB/EPA - Tier 4 - 2014
Fuel Type:	Diesel: - Low Sulfur (<500 ppm) - Ultra Low Sulfur (15 ppm) (Recommended) - up to 5% biodiesel
No. of Cylinders	3
Oil Pan Capacity	1.51 Gal. (5.7 L)
Engine RPM Control	Mechanical
Low RPM Set	1200 RPM
High RPM Set	3000 RPM
Alternator	40 Amp, 12V, Belt Drive
Battery	112 Amp-Hour, 950 Cold Cranking Amps, 12VDC
Fuel Consumption:	Low RPM 0.41 GPH (1.5 lph) High RPM 2.0 GPH (7.6 lph)
Displacement	1.261 L (77 cu. in.)
Horsepower	29.1 Hp (21.7 Kw) @ 3000 RPM
Torque Rating	59.1 Ft. lb. (80.1 Nm) @ 2000 rpm

**Kubota (WG972-GL-E4F -T3 - Dual Fuel)**

Emissions	CARB/EPA - LSI - Tier 3	
Fuel Type:	Gasoline - 87 Octane minimum - Ethanol/Gas Mix- 10% max. - Methanol/Gas Mix- 5% max. LP - Liquid Petroleum	
No. of Cylinders	3	
Oil Pan Capacity	0.90 Gal. (3.4 L)	
Engine RPM Control	Electronic - ECM	
Low RPM Set	1200 RPM	
High RPM Set	3000 RPM	
Alternator	40 Amp, 12V, Belt Drive	
Battery	112 Amp-Hour, 950 Cold Cranking Amps, 12 VDC	
Fuel Consumption:	Gas -	LP -
Low RPM	0.38 gal/hr (1.45 L/hr)	2.07 lb/hr (0.94 kg/hr)
High RPM	1.76 gal/hr (6.66 L/hr)	9.77 lb/hr (4.43 kg/hr)
Displacement	2.9L - 2925 cm <sup>3</sup> (179 cu. in.)	
Horsepower	GAS - 32.5 Hp (24.2 Kw) @ 3500 RPM LP - 31 Hp (23.1 Kw) @ 3500 RPM	
Torque Rating (max.)	58 Ft. lb. @ 2100 rpm	

**1.3 HYDRAULIC PRESSURE SETTINGS**


Description	530LRT
Main Relief	3000 psi (206 bar)
Steer Relief	2500 psi (193 bar)
Lift Up Relief	2700 psi (186 bar)
Leveling Jack Retract Relief	2000 psi (138 bar)

**1.4 HYDRAULIC CYLINDER SPECIFICATIONS**

Description	Bore	Stroke	Rod Dia
Lift Cylinders Upper:	3.90 in (99 mm)	84.125 in (2136 mm)	3.30 in (84 mm)
Lower:	4.70 in (119 mm)	84.125 in (2136 mm)	3.5 in (90 mm)
Leveling Jack Cylinder	2.5 in (63.5 mm)	27 in (686 mm)	2 in (51 mm)
RAM Lockout Cylinder (Oscillating Axle)	3.62 in (92 mm)	4 in (101.6 mm)	3.5 in (88.9 mm)
Steer Cylinder	2.75 in (70 mm)	8.94 in (227.1 mm)	1.97 in (50 mm)

**1.5 SERIAL NUMBER LOCATIONS**

For machine identification, a serial number plate is affixed to the machine. The plate is located at the rear of the machine on the center of the axle. In addition, should the serial number plate be damaged or missing, the machine serial number is stamped onto the lip of the rear axle.



- 1. Serial Number Plate
- 2. Stamped Serial Number

### 1.6 ELEVATION/TILT LIMIT SETTINGS

The machine is equipped with the following limit switches:

**Elevation Switch/Rotary Position Sensor** - High drive speed is cut out when platform is raised above the preset heights listed in Table 1-1, Maximum Cutout Height.

**Table 1-1. Maximum Cutout Height**

Model	High Drive Cutout
530LRT	14 ft (4.26 m)

**Tilt Alarm** - An alarm sounds and a warning light is illuminated when the machine is operated on a slope that exceeds the values in Table 1-2, Tilt Cutout Settings. The lift and drive functions will cut out at these set heights.

**NOTE:** Alarm only sounds when above elevation. If the machine is operated beyond the specified slope, with the platform completely lowered, only the warning light is illuminated.

**Table 1-2. Tilt Cutout Settings**

Model 530LRT	Front to Back	Side to Side
ANSI, ANSI EXPORT	5° to 32 ft (9.75 m) 1.5° to 53 ft (16 m)	4° to 32 ft (9.75 m) 1.5° to 53 ft (16 m)
CSA	3° to 32 ft (9.75 m) 1.5° to 53 ft (16 m)	3° to 32 ft (9.75 m) 1.5° to 53 ft (16 m)
CE, AUS	5° to 32 ft (9.75 m) 1.3° to 45 ft (13.7 m) <sup>(1)</sup> 1.5° to 53 ft (16 m) <sup>(2)</sup>	3° to 32 ft (9.75 m) 1.3° to 45 ft (13.7 m) <sup>(1)</sup> 1.5° to 53 ft (16 m) <sup>(2)</sup>
(1) - Leveling Jacks not set (2) - Leveling Jacks set		

### 1.7 LUBRICATION


**NOTE:** Hydraulic oils must have anti-wear qualities at least to API Service Classification GL-3, and sufficient chemical stability for mobile hydraulic system service. JLG Industries recommends Mobilfluid 424 hydraulic oil, which has an SAE viscosity index of 145.

When temperatures remain below 20° F (-7° C), JLG Industries recommends the use of Mobil DTE13.

Aside from JLG recommendations, it is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities.


**Table 1-3. Lubrication Specifications**

KEY	SPECIFICATIONS
MPG	Multipurpose Grease - Having a minimum dripping point of 350° F. Excellent water resistance and adhesive qualities, and being of extreme pressure type. (Timken OK 40 pounds minimum.)
EPGL	Extreme Pressure Gear Lube (oil) - Meeting API service classification GL-5 or MIL-Spec MIL-L-2105.
EO	Engine Oil (crankcase) - See Oil Change w/Filter (engine) and; Figure 1-2., Engine Oil Operating Specification, or; OEM Engine Manual supplied with machine
HO	Hydraulic Oil - See Figure 1-1., Hydraulic Oil, Operating Temperature Specifications



4150740\_B\_Hydraulic

Figure 1-1. Hydraulic Oil Operating Temperature Specifications



1001204714\_A\_Dual Fuel

Figure 1-2. Engine Oil Operating Temperature Specifications - Kubota (Dual Fuel Engine)




Figure 1-3. Engine Oil Operating Temperature Specifications - Kubota (Diesel Engine)



1.8 TORQUE CHARTS

SAE Fasteners

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)															
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	SAE GRADE 5 BOLTS & GRADE 2 NUTS				SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS*						
					Torque (Dry)	Torque Lubricated	Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140)	Torque (Loctite® 262™ or TITE™ 131)	Clamp Load	Torque (Dry or Loctite® 263) K=0.20	Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140)	Torque (Loctite® 262™ or TITE™ 131) K=0.15			
		In	Sq In	LB	IN-LB	IN-LB	IN-LB	IN-LB	IN-LB	FT-LB	FT-LB	FT-LB	FT-LB	FT-LB	FT-LB
4	40	0.1120	0.00604	380	8	0.9	6	0.7							
	48	0.1120	0.00661	420	9	1.0	7	0.8							
6	32	0.1380	0.00909	580	16	1.8	12	1.4							
	40	0.1380	0.01015	610	18	2.0	13	1.5							
8	32	0.1640	0.01400	900	30	3.4	22	2.5							
	36	0.1640	0.01474	940	31	3.5	23	2.6							
10	24	0.1900	0.01750	1120	43	4.8	32	3.5							
	32	0.1900	0.02000	1285	49	5.5	36	4							
1/4	20	0.2500	0.0318	2020	96	10.8	75	9	105	12					
	28	0.2500	0.0364	2320	120	13.5	86	10	135	15					
		In	Sq In	LB	FT-LB	FT-LB	FT-LB	FT-LB	FT-LB	FT-LB	FT-LB	FT-LB	FT-LB	FT-LB	FT-LB
5/16	18	0.3125	0.0524	3340	17	23	13	18	26	16	22	22	25	20	25
	24	0.3125	0.0580	3700	19	26	14	19	29	17	23	23	25	20	26
3/8	16	0.3750	0.0775	4940	30	41	23	31	48	28	38	38	45	35	50
	24	0.3750	0.0878	5800	35	47	25	34	54	32	43	43	50	40	55
7/16	14	0.4375	0.1063	6800	50	68	35	47	75	45	61	61	70	55	70
	20	0.4375	0.1187	7550	55	75	40	54	82	50	68	68	80	65	90
1/2	13	0.5000	0.1419	9050	75	102	55	75	85	55	75	75	95	80	100
	20	0.5000	0.1599	10700	90	122	65	88	100	68	92	92	110	95	130
9/16	12	0.5625	0.1820	11600	110	149	80	108	120	80	108	108	130	110	150
	18	0.5625	0.2030	12950	120	163	90	122	135	84	109	109	140	120	175
5/8	11	0.6250	0.2260	14400	150	203	110	149	165	102	148	148	185	155	210
	18	0.6250	0.2560	16300	170	230	130	176	190	116	163	163	210	180	250
3/4	10	0.7500	0.3340	21300	260	363	200	285	258	153	207	207	285	240	330
	16	0.7500	0.3730	23800	300	407	220	298	330	168	228	228	310	260	360
7/8	9	0.8750	0.4620	29400	430	583	320	434	475	186	266	266	363	310	420
	14	0.8750	0.5090	32400	470	637	350	475	520	207	292	292	390	340	460
1	8	1.0000	0.6060	38600	640	868	480	651	719	238	335	335	440	380	510
	12	1.0000	0.6630	42200	700	949	530	719	735	258	363	363	470	410	550
1 1/8	7	1.1250	0.7630	48300	800	1085	600	813	840	288	393	393	510	450	600
	12	1.1250	0.8560	47500	880	1193	660	895	925	318	433	433	560	500	660
1 1/4	7	1.2500	0.9690	53900	1120	1518	840	1139	1175	358	493	493	630	570	750
	12	1.2500	1.0730	59600	1240	1681	920	1247	1300	398	543	543	700	640	840
1 3/8	6	1.3750	1.1550	64100	1460	1979	1100	1491	1525	448	613	613	780	720	950
	12	1.3750	1.3150	73000	1680	2278	1260	1708	1750	508	693	693	880	820	1080
1 1/2	6	1.5000	1.4050	78000	1940	2630	1460	1979	2025	578	793	793	1000	940	1240
	12	1.5000	1.5800	87700	2200	2983	1640	2224	2300	648	883	883	1110	1050	1390

NO. 5000059 REV. K

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS  
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%  
 3. \* ASSEMBLY USES HARDENED WASHER



Values for Magni Coating Fasteners (Ref 4150701)																		
SAE GRADE 5 BOLTS & GRADE 2 NUTS						SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS*												
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry) K=0.17	Torque (Locitite® 242™ or 271™ OR Vibra-TITE™ K=0.16		Torque (Locitite® 262™ or TITE™ 131) K=0.15		Clamp Load	Torque (Dry or Locitite® 263) K=0.17		Torque (Locitite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K=16		Torque (Locitite® 262™ or Vibra-TITE™ 131) K=0.15			
						IN-LB	IN-LB	IN-LB	IN-LB		IN-LB	IN-LB	IN-LB	IN-LB	IN-LB	IN-LB	IN-LB	IN-LB
4	40	0.1120	0.00604	380	7	0.8												
	48	0.1120	0.00661	420	8	0.9												
6	32	0.1380	0.00909	580	14	1.5												
	40	0.1380	0.01015	610	14	1.6												
8	32	0.1640	0.01400	900	25	2.8												
	36	0.1640	0.01474	940	26	2.9				1320	37	4						
10	24	0.1900	0.01750	1120	36	4.1				1580	51	6						
	32	0.1900	0.02000	1285	42	4.7				1800	58	7						
1/4	20	0.2500	0.0318	2020	86	9.7	9			2860	122	14	114	13				
	28	0.2500	0.0364	2320	99	11.1	11			3280	139	16	131	15				
		In	Sq In	LB	IN-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	3340	15	20	14	19	15	20	4720	20	25	20	25	20	25	25
	24	0.3125	0.0580	3700	15	20	15	21	15	20	5220	25	35	20	25	20	25	25
3/8	16	0.3750	0.0775	4940	25	35	25	34	25	34	7000	35	50	35	50	35	50	50
	24	0.3750	0.0878	5600	30	40	28	40	25	34	7900	40	55	40	55	35	50	50
7/16	14	0.4375	0.1063	6800	40	55	40	54	35	40	9550	60	80	55	75	50	70	70
	20	0.4375	0.1187	7550	45	60	44	60	40	54	10700	65	90	60	80	60	80	80
1/2	13	0.5000	0.1419	9050	65	90	60	82	55	75	12750	90	120	85	115	80	110	110
	20	0.5000	0.1589	10700	75	100	71	97	65	88	14400	100	135	95	130	90	120	120
9/16	12	0.5625	0.1820	11600	90	120	87	118	80	109	16400	130	175	125	170	115	155	155
	18	0.5625	0.2030	12950	105	145	97	132	90	122	18250	145	195	135	185	130	175	175
5/8	11	0.6250	0.2260	14400	130	175	120	163	115	156	20350	180	245	170	230	160	220	220
	18	0.6250	0.2560	16300	145	195	136	185	125	170	23000	205	280	190	260	180	245	245
3/4	10	0.7500	0.3340	21300	225	305	213	290	200	272	30100	320	435	300	410	280	380	380
	16	0.7500	0.3730	23800	255	345	238	324	225	306	33600	355	485	335	455	315	430	430
7/8	9	0.8750	0.4620	29400	365	495	343	466	320	435	41600	515	700	485	660	455	620	620
	14	0.8750	0.5090	32400	400	545	378	514	355	483	45800	570	775	535	730	500	680	680
1	8	1.0000	0.6060	38600	545	740	515	700	480	653	51500	730	995	685	930	645	875	875
	12	1.0000	0.6630	42200	600	815	563	765	530	721	59700	845	1150	795	1080	745	1015	1015
1 1/8	7	1.1250	0.7630	42300	675	920	635	863	595	809	68700	1095	1490	1030	1400	965	1310	1310
	12	1.1250	0.8560	47500	755	1025	713	969	670	911	77000	1225	1665	1155	1570	1085	1475	1475
1 1/4	7	1.2500	0.9690	53800	955	1300	897	1219	840	1142	87200	1545	2100	1455	1980	1365	1855	1855
	12	1.2500	1.0730	59600	1055	1435	993	1351	930	1265	96600	1710	2325	1610	2190	1510	2055	2055
1 3/8	6	1.3750	1.1550	64100	1250	1700	1175	1598	1100	1496	104000	2025	2755	1905	2590	1785	2430	2430
	12	1.3750	1.3150	73000	1420	1930	1338	1820	1255	1707	118100	2300	3130	2165	2945	2030	2760	2760
1 1/2	6	1.5000	1.4050	78000	1650	2260	1560	2122	1465	1992	126500	2690	3660	2530	3440	2370	3225	3225
	12	1.5000	1.5800	87700	1865	2535	1754	2385	1645	2237	142200	3020	4105	2845	3870	2685	3625	3625

NO. 5000059 REV. K

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS  
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%  
 3. \* ASSEMBLY USES HARDENED WASHER

SOCKET HEAD CAP SCREWS

Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load See Note 4	Magni Coating (Ref 4150701)*				Zinc Yellow Chromate Fasteners (Ref 4150707)*				
					Torque (Dry) K = .17	Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140 OR Precoat 85®) K=0.16	Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	Clamp Load See Note 4	Torque (Dry) K = .20	Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140 OR Precoat 85®) K=0.18	Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15		
		In	Sq In	LB	IN-LB [N.m]	FT-LB [N.m]	IN-LB [N.m]	FT-LB [N.m]	LB	IN-LB [N.m]	FT-LB [N.m]	IN-LB [N.m]	FT-LB [N.m]
4	40	0.1120	0.00604										
	48	0.1120	0.00661										
6	32	0.1380	0.00909										
	40	0.1380	0.01015										
8	32	0.1640	0.01400										
	36	0.1640	0.01474										
10	24	0.1900	0.01750										
	32	0.1900	0.02000										
1/4	20	0.2500	0.0318	2860	122	14	114	13	2860	143	16	129	15
	28	0.2500	0.0364		139	16	131	15	3280	164	19	148	17
		In	Sq In	LB	FT-LB [N.m]		FT-LB [N.m]		LB	FT-LB [N.m]		FT-LB [N.m]	
5/16	18	0.3125	0.0624	4720	20	25	20	25	4720	25	35	20	25
	24	0.3125	0.0680		25	35	20	25	5220	25	35	25	25
3/8	16	0.3750	0.0775	7000	35	50	35	50	7000	45	60	40	55
	24	0.3750	0.0878	7900	40	55	40	55	7900	50	70	45	60
7/16	14	0.4375	0.1063	9550	60	80	55	70	9550	70	95	65	90
	20	0.4375	0.1187	10700	65	90	60	80	10700	80	110	70	95
1/2	13	0.5000	0.1419	12750	90	120	85	115	12750	105	145	95	130
	20	0.5000	0.1599	14400	100	135	95	130	14400	120	165	110	150
9/16	12	0.5625	0.1820	16400	130	175	125	170	16400	155	210	140	190
	18	0.5625	0.2030	18250	145	195	135	185	18250	170	230	155	210
5/8	11	0.6250	0.2260	20350	180	245	170	230	20350	210	285	190	260
	18	0.6250	0.2560	23000	205	280	190	260	23000	240	325	215	280
3/4	10	0.7500	0.3340	30100	320	435	300	380	30100	375	510	340	460
	16	0.7500	0.3730	33600	355	485	335	455	33600	420	570	380	515
7/8	9	0.8750	0.4620	41600	515	700	485	660	41600	605	825	545	740
	14	0.8750	0.5090	45800	570	775	535	730	45800	670	910	600	815
1	8	1.0000	0.6060	51500	730	995	685	930	51500	860	1170	775	1055
	12	1.0000	0.6630	59700	845	1160	795	1080	59700	995	1365	895	1215
1 1/8	7	1.1250	0.7630	68700	1095	1490	1030	1400	68700	1290	1765	1160	1580
	12	1.1250	0.8560	77000	1225	1665	1155	1570	77000	1445	1965	1300	1770
1 1/4	7	1.2500	0.9690	87200	1545	2100	1465	1980	87200	1815	2470	1635	2225
	12	1.2500	1.0730	96600	1710	2325	1610	2130	96600	2015	2740	1810	2460
1 3/8	6	1.3750	1.1550	104000	2025	2755	1905	2590	104000	2365	3245	2145	2915
	12	1.3750	1.3150	118100	2300	3130	2165	2945	118100	2705	3680	2435	3310
1 1/2	6	1.5000	1.4050	126500	2690	3660	2530	3440	126500	3165	4305	2845	3870
	12	1.5000	1.5800	142200	3020	4105	2845	3870	142200	3555	4835	3200	4350

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS  
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = +10%  
 \*3. ASSEMBLY USES HARDENED WASHER OR FASTENER IS PLACED AGAINST PLATED STEEL OR RAW ALUMINUM  
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

NO. 5000059 REV. K

Metric Fasteners

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)											
CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS					CLASS 10.9 METRIC (HEX HEAD) BOLTS CLASS 10 METRIC NUTS CLASS 12.9 SOCKET HEAD CAP SCREWS M3 - M5*						
Size	PITCH	Tensile Stress Area	Clamp Load	Torque (Dry or Loctite® 263™)	Torque (Lub)	Torque (Loctite® 262™ OR Vibra-TITE™ 131)	Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140)	Clamp Load	Torque (Dry or Loctite® 263™) K= 0.20	Torque (Lub OR Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K= 0.18	Torque (Loctite® 262™ OR Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]	[N.m]	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	2.19	1.3	1.0	1.2	1.4	3.13			
3.5	0.6	6.78	2.95	2.1	1.6	1.9	2.3	4.22			
4	0.7	8.78	3.82	3.1	2.3	2.8	3.4	5.47			
5	0.8	14.20	6.18	6.2	4.6	5.6	6.8	8.85			
6	1	20.10	8.74	11	7.9	9.4	12	12.5			
7	1	28.90	12.6	18	13	16	19	18.0	25	23	19
8	1.25	36.60	15.9	26	19	23	28	22.8	37	33	27
10	1.5	58.00	25.2	50	38	45	55	36.1	70	65	55
12	1.75	84.30	36.7	88	66	79	97	52.5	125	115	95
14	2	115	50.0	140	105	126	154	71.6	200	180	150
16	2	157	68.3	219	164	197	241	97.8	315	280	235
18	2.5	192	83.5	301	226	271	331	119.5	430	385	325
20	2.5	245	106.5	426	320	383	469	152.5	610	550	460
22	2.5	303	132.0	581	436	523	639	189.0	830	750	625
24	3	353	153.5	737	553	663	811	222.0	1065	960	800
27	3	459	199.5	1080	810	970	1130	286.0	1545	1390	1160
30	3.5	561	244.0	1460	1100	1320	1530	349.5	2095	1885	1575
33	3.5	694	302.0	1990	1490	1790	2090	432.5	2855	2570	2140
36	4	817	355.5	2560	1920	2300	2690	509.0	3665	3300	2750
42	4.5	1120	487.0	4090	3070	3680	4290	698.0	5865	5275	4395

NO. 5000059 REV. K

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS  
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%  
 \*3. ASSEMBLY USES HARDENED WASHER OR FASTENER IS PLACED AGAINST PLATED STEEL OR RAW ALUMINUM  
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

Values for Magni Coated Fasteners (Ref 4150701)										
CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS					CLASS 10.9 METRIC (HEX HEAD) BOLTS CLASS 10 METRIC NUTS CLASS 12.9 SOCKET HEAD CAP SCREWS M6 AND ABOVE*					
Size	PITCH	Tensile Stress Area	Clamp Load	Torque (Dry or Loctite® 263™) K=0.17	Torque (Loctite® 262™ OR Vibra-TITE™ 131) K=0.16	Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K=0.15	Clamp Load	Torque (Dry or Loctite® 263™) K = 0.17	Torque (Lub OR Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K= 0.16	Torque (Loctite® 262™ OR Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	2.19	1.1	1.1	1.0	3.13			
3.5	0.6	6.78	2.95	1.8	1.7	1.5	4.22			
4	0.7	8.78	3.82	2.6	2.4	2.3	5.47			
5	0.8	14.20	6.18	5.3	4.9	4.6	8.85			
6	1	20.10	8.74	9	8.4	7.9	12.5	13	12	11
7	1	28.90	12.6	15	14	13	18.0	21	20	19
8	1.25	36.60	15.9	22	20	19	22.8	31	29	27
10	1.5	58.00	25.2	43	40	38	36.1	61	58	55
12	1.75	84.30	36.7	75	70	66	52.5	105	100	95
14	2	115	50.0	119	110	105	71.6	170	160	150
16	2	157	68.3	186	175	165	97.8	265	250	235
18	2.5	192	83.5	256	240	225	119.5	365	345	325
20	2.5	245	106.5	362	340	320	152.5	520	490	460
22	2.5	303	132.0	494	465	435	189.0	705	665	625
24	3	353	153.5	627	590	555	222.0	905	850	800
27	3	459	199.5	916	860	810	286.0	1315	1235	1160
30	3.5	561	244.0	1245	1170	1100	349.5	1780	1680	1575
33	3.5	694	302.0	1694	1595	1495	432.5	2425	2285	2140
36	4	817	355.5	2176	2050	1920	509.0	3115	2930	2750
42	4.5	1120	487.0	3477	3275	3070	698.0	4985	4690	4395

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS

2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%

\*3. ASSEMBLY USES HARDENED WASHER OR FASTENER IS PLACED AGAINST PLATED STEEL OR RAW ALUMINUM

4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

NO. 500059 REV. K

# PARTS FINDER

Search Website  
by Part Number



Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote

Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

## SECTION 2. GENERAL

### 2.1 MACHINE PREPARATION, INSPECTION, AND MAINTENANCE

#### General

This section provides the necessary information needed by those personnel that are responsible to place the machine in operation readiness and maintain its safe operating condition. For maximum service life and safe operation, ensure that all the necessary inspections and maintenance have been completed before placing the machine into service. With proper care, maintenance, and inspections performed per JLG's recommendations with any and all discrepancies corrected, this product will be fit for continued use.

#### Preparation, Inspection, and Maintenance

It is important to establish and conform to a comprehensive inspection and preventive maintenance program. The following table outlines the periodic machine inspections and maintenance recommended by JLG Industries, Inc. Consult your national, regional, or local regulations for further requirements for aerial work platforms. The frequency of inspections and maintenance must be increased as environment, severity and frequency of usage requires.

#### Pre-Start Inspection

It is the User's or Operator's primary responsibility to perform a Pre-Start Inspection of the machine prior to use daily or at each change of operator. Reference the Operator's and Safety Manual for completion procedures for the Pre-Start Inspection. The Operator and Safety Manual must be read in its entirety and understood prior to performing the Pre-Start Inspection.

#### Pre-Delivery Inspection and Frequent Inspection

The Pre-Delivery Inspection and Frequent Inspection shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

The Pre-Delivery Inspection and Frequent Inspection procedures are performed in the same manner, but at different times. The Pre-Delivery Inspection shall be performed prior to each sale, lease, or rental delivery. The Frequent Inspection shall be accomplished for each machine in service for 3 months or 150 hours (whichever comes first); out of service for a period of more than

3 months; or when purchased used. The frequency of this inspection must be increased as environment, severity and frequency of usage requires.

Reference the JLG Pre-Delivery and Frequent Inspection Form and the Inspection and Preventative Maintenance Schedule for items requiring inspection during the performance of these inspections. Reference the appropriate areas of this manual for servicing and maintenance procedures.

#### Annual Machine Inspection

JLG recommends that an annual machine inspection be performed by a Factory-Certified Service Technician on an annual basis, no later than thirteen (13) months from the date of the prior Annual Machine Inspection. JLG Industries, Inc. recognizes a Factory-Certified Service Technician as a person who has successfully completed the JLG Service Training School for the subject JLG product model. Reference the machine Service and Maintenance Manual and appropriate JLG inspection form for performance of this inspection.

Reference the JLG Annual Machine Inspection Form and the Inspection and Preventative Maintenance Schedule for items requiring inspection during the performance of this inspection. Reference the appropriate areas of this manual for servicing and maintenance procedures.

For the purpose of receiving safety-related bulletins, it is important that JLG Industries, Inc. has updated ownership information for each machine. When performing each Annual Machine Inspection, notify JLG Industries, Inc. of the current machine ownership.

#### Preventative Maintenance

In conjunction with the specified inspections, maintenance shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

Reference the Preventative Maintenance Schedule and the appropriate areas of this manual for servicing and maintenance procedures. The frequency of service and maintenance must be increased as environment, severity and frequency of usage requires.



**Table 2-1. Inspection and Maintenance**

Type	Frequency	Primary Responsibility	Service Qualification	Reference
Pre-Start Inspection	Prior to use each day; or At each Operator change.	User or Operator	User or Operator	Operator and Safety Manual
Pre-Delivery Inspection	Prior to each sale, lease, or rental delivery.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form.
Frequent Inspection	In service for 3 months or 150 hours, whichever comes first; or Out of service for a period of more than 3 months; or Purchased used.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form.
Annual Machine Inspection	Annually, no later than 13 months from the date of the prior inspection.	Owner, Dealer, or User	Factory-Certified Service Technician or a Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form.
Preventative Maintenance	At intervals as specified in the Service and Maintenance Manual.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual

**2.2 PREVENTIVE MAINTENANCE AND INSPECTION SCHEDULE**

The preventive maintenance and inspection checks are listed and defined in the following table. This table is divided into two basic parts, the "AREA" to be inspected and the "INTERVAL" at which the inspection is to take place. Under the "AREA" portion of the table, the various systems along with the components that make up that system are listed. The "INTERVAL" portion of the table is divided into two columns representing the various inspection time periods. The numbers listed within the interval column represent the applicable inspection code for which that component is to be checked.

The checks and services listed in this schedule are not intended to replace any local or regional regulations that may pertain to this type of equipment nor should the lists be considered as all inclusive. Variances in interval times may occur due to climate and/or conditions and depending on the location and use of the machine.

JLG Industries requires that a complete annual inspection be performed in accordance with the "Annual Machine Inspection Report" form. Forms are supplied with each new machine and are also available from JLG Customer Service. Form must be completed and returned to JLG Industries.

**NOTICE**

**JLG INDUSTRIES REQUIRES THAT A COMPLETE ANNUAL INSPECTION BE PERFORMED IN ACCORDANCE WITH THE "ANNUAL MACHINE INSPECTION REPORT" FORM.**

**NOTE:** This machine requires periodic safety and maintenance inspections by a JLG Dealer. A decal located on the frame affords a place to record (stamp) inspection dates. Notify dealer if inspection is overdue.

**Footnotes and Performance Codes**

<p><b>Footnotes:</b></p> <p><sup>1</sup> Prior to each sale, lease, or delivery</p> <p><sup>2</sup> In service for 3 months; Out of service for 3 months or more; Purchased used</p> <p><sup>3</sup> Annually, no later than 13 months from the date of the prior inspection, Includes all daily and quarterly inspections, mandated by regulating body</p> <p><sup>4</sup> Replace every 12 years or 7,000 hours</p> <p><sup>50</sup> Indicates a 50 hour interval required to perform task after initial use of machine. This only occurs once in machine life.</p> <p><sup>250</sup> Indicates a 250 hour interval required to perform task after initial use of machine. This only occurs once in machine life.</p> <p>** Refer to Operation Manual for machine specific instructions.</p>
<p><b>Performance Codes:</b></p> <p>1 - Check for proper and secure: installation, adjustment, or torque</p> <p>2 - Visual inspection for damage: (cracks, corrosion, abrasions, distortion, excessive wear, broken welds, gouges, chafing and threads showing)</p> <p>3 - Proper operation</p> <p>4 - Check for proper sealing, signs of leakage and fluid level</p> <p>5 - Clean and free of debris</p> <p>6 - Decals installed and legible</p> <p>7 - Check for proper tolerances, routing, and lubrication</p> <p>8 - Fully Charged</p> <p>9 - Verify/Perform</p> <p>a - Drain, Clean</p> <p>b - Refill/Replace</p> <p>c - Lubricate</p>

## Schedule

AREA	Inspections	
	Pre-Delivery <sup>1</sup> or Frequent <sup>2</sup> Inspection (Quarterly)	Annual <sup>3</sup> (Yearly) Inspection
<b>Scissor Arms</b>		
Scissor Arms	1,2	1,2
Safety Prop	1,3	1,3
Nuts, Bolts, Shafts, Shields, Bearings and Locking Devices	1,2	1,2
Cylinder/Pivot Pins and Attaching Hardware	1,2	1,2
<b>Platform Assembly</b>		
<b>Platform</b>	1	1
Mandril Chain/Gate, Bar and Latches	1,3	1,3
Extend Deck and Locks	1,3	1,3
Guard Rails and Floor	1,2	1,2
Platform Roll Pins and Fold Down Rails	1	1
Lanyard Anchorage Point	1,2,6	1,2,6
<b>Chassis Assembly</b>		
Wheel Rim Nuts	1 <sup>50</sup>	1 <sup>50</sup>
Tires	1,2	1,2
Oscillating Axle and Lock Nut	3	3
Steer, Drive, and Axle Components	1,2,3	1,2,3
Leveling Jacks and Stabilizers	3	3
Hydraulic Tray, Battery, Engine Compartment Covers	1,3	1,3
Static Strap	1	1
Pothole Protection System	1,2,3	1,2,3
Side-Compartment Door Installation	1,3,5	1,3,5
Drive Motors	1,4,5	1,4,5
Platform Ladder	1,5	1,5
Drive Brakes	1,5	1,5
Drive Hubs	1,5	1,5
Engine Mounts	1	1
Engine Oil	3	3
Exhaust System	1,3	1,3
Sliding Wear Pads **	1,2,5,7	1,2,5,7
Fuel Tank	1,4	1,4
<b>Functions/Controls</b>		
Control Levers, Switches, Gauges and Instruments	3,5	3,5
Detents Properly Lock, Control Enclosure and Protective Boots/Guards	1,3	1,3
Emergency Stop Switches at Ground and Platform	3	3
Lift, Drive and Speed Cut-outs	3	3
Auxiliary Power System	3	3
Function Enable System	3	3
Brakes	1,3,9	1,3,9
Machine Functions	3	3
Joystick/Toggle Return to Neutral/Off When Released	1,3	1,3



**SECTION 2 - GENERAL**

AREA	Inspections	
	Pre-Delivery <sup>1</sup> or Frequent <sup>2</sup> Inspection (Quarterly)	Annual <sup>3</sup> (Yearly) Inspection
<b>Power System</b>		
Engine Idle, Throttle, and RPM	1,3,7	1,3,7
Engine Fluids: Oil	4	4
Engine Fluids: Coolant	1,4,7	1,4,7
Air Filter	1,5	1,5
Fuel Filter(s)	1,5	1,5
Exhaust System	1,3	1,3
Batteries	1,4	1,4
Battery Fluid	4	4
Battery Charger		3
<b>Hydraulic/Electric System</b>		
Hydraulic Cylinders	2,4,5	2,4,5
Pumps, Oil Lines, and Reservoir	1,2,4	1,2,3,4
Hydraulic Filter	4,5,7	4,5,7
Hydraulic Tank, Cap, Breather, and Vent	3,4,5	3,4,5
Hydraulic Fittings	1,4	1,4
Electrical Connections	1,2	1,2
Switches, Gauges, Horn, and Lights	3	3
Switches and Controls	1,3	1,3
All Hydraulic Pressures	3	3
Hydraulic Fluid	4	4
<b>General</b>		
No Unauthorized Modification or Additions	9	9
Paint and Overall Appearance	5	5
Operation and Safety Manual	9	9
General Structural Condition and Welds	2	2
Grease and Lubrication Specification	9	9
Function Test of All Systems	9	9
Notify JLG of Change in Machine Ownership		9
ANSI and AEM Handbook	9	9
Capacity Decals	9	9
All Decals/Placards	9	9
Annual Machine Inspection		9
Safety Publication	9	9
All Fasteners, Pins, Shields and Covers	1,2	1,2

## 2.3 SERVICE AND GUIDELINES

### General

The following information is provided to assist you in the use and application of servicing and maintenance procedures contained in this book.

### Safety and Workmanship

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

### Cleanliness

1. The most important single item in preserving the long service life of a machine is to keep dirt and foreign materials out of the vital components. Precautions have been taken to safeguard against this. Shields, covers, seals, and filters are provided to keep air, fuel, and oil supplies clean; however, these items must be maintained on a scheduled basis in order to function properly.
2. At any time when air, fuel, or oil lines are disconnected, clear adjacent areas as well as the openings and fittings themselves. As soon as a line or component is disconnected, cap or cover all openings to prevent entry of foreign matter.
3. Clean and inspect all parts during servicing or maintenance, and assure that all passages and openings are unobstructed. Cover all parts to keep them clean. Be sure all parts are clean before they are installed. New parts should remain in their containers until they are ready to be used.

### Components Removal and Installation

4. Use adjustable lifting devices, whenever possible, if mechanical assistance is required. All slings (chains, cables, etc.) should be parallel to each other and as near perpendicular as possible to top of part being lifted.
5. Should it be necessary to remove a component on an angle, keep in mind that the capacity of an eyebolt or similar bracket lessens, as the angle between the supporting structure and the component becomes less than 90°.
6. If a part resists removal, check to see whether all nuts, bolts, cables, brackets, wiring, etc., have been removed and that no adjacent parts are interfering.

### Component Disassembly and Reassembly

When disassembling or reassembling a component, complete the procedural steps in sequence. Do not partially disassemble or assemble one part, then start on another. Always recheck your work to assure that nothing has been overlooked. Do not make any adjustments, other than those recommended, without obtaining proper approval.

### Pressure-Fit Parts

When assembling pressure-fit parts, use an anti-seize or molybdenum disulfide base compound to lubricate the mating surface.

### Bearings

1. When a bearing is removed, cover it to keep out dirt and abrasives. Clean bearings in nonflammable cleaning solvent and allow to drip dry. Compressed air can be used but do not spin the bearing.
2. Discard bearings if the races and balls (or rollers) are pitted, scored, or burned.
3. If bearing is found to be serviceable, apply a light coat of oil and wrap it in clean (waxed) paper. Do not unwrap reusable or new bearings until they are ready to install.
4. Lubricate new or used serviceable bearings before installation. When pressing a bearing into a retainer or bore, apply pressure to the outer race. If the bearing is to be installed on a shaft, apply pressure to the inner race.

### Gaskets

Check that holes in gaskets align with openings in the mating parts. If it becomes necessary to hand-fabricate a gasket, use gasket material or stock of equivalent material and thickness. Be sure to cut holes in the right location, as blank gaskets can cause serious system damage.

## Bolt Usage and Torque Application

1. Use bolts of proper length. A bolt which is too long will bottom before the head is tight against its related part. If a bolt is too short, there will not be enough thread area to engage and hold the part properly. When replacing bolts, use only those having the same specifications of the original, or one which is equivalent.
2. Unless specific torque requirements are given within the text, standard torque values should be used on heat-treated bolts, studs, and steel nuts, in accordance with recommended shop practices. (See Torque Chart Section 1.)

## Hydraulic Lines and Electrical Wiring

Clearly mark or tag hydraulic lines and electrical wiring, as well as their receptacles, when disconnecting or removing them from the unit. This will assure that they are correctly reinstalled.

## Hydraulic System

1. Keep the system clean. If evidence of metal or rubber particles are found in the hydraulic system, drain and flush the entire system.
2. Disassemble and reassemble parts on clean work surface. Clean all metal parts with non-flammable cleaning solvent. Lubricate components, as required, to aid assembly.

## Lubrication

Service applicable components with the amount, type, and grade of lubricant recommended in this manual, at the specified intervals. When recommended lubricants are not available, consult your local supplier for an equivalent that meets or exceeds the specifications listed.

## Battery

Clean battery, using a non-metallic brush and a solution of baking soda and water. Rinse with clean water. After cleaning, thoroughly dry battery and coat terminals with an anti corrosion compound.

## Lubrication and Servicing

Components and assemblies requiring lubrication and servicing are shown in the Lubrication Chart in Section 1.

## 2.4 LUBRICATION AND INFORMATION

### Hydraulic System

1. The primary enemy of a hydraulic system is contamination. Contaminants enter the system by various means, e.g., using inadequate hydraulic oil, allowing moisture, grease, filings, sealing components, sand, etc., to enter when performing maintenance, or by permitting the pump to cavitate due to insufficient system warm-up or leaks in the pump supply (suction) lines.
2. The design and manufacturing tolerances of the component working parts are very close, therefore, even the smallest amount of dirt or foreign matter entering a system can cause wear or damage to the components and generally results in faulty operation. Every precaution must be taken to keep hydraulic oil clean, including reserve oil in storage. Hydraulic system filters should be checked, cleaned, and/or replaced as necessary, at the specified intervals required in the Lubrication Chart in Section 1. Always examine filters for evidence of metal particles.
3. Cloudy oils indicate a high moisture content which permits organic growth, resulting in oxidation or corrosion. If this condition occurs, the system must be drained, flushed, and refilled with clean oil.
4. It is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. Good grade mineral oils, with viscosities suited to the ambient temperatures in which the machine is operating, are recommended for use.

**NOTE:** *Metal particles may appear in the oil or filters of new machines due to the wear-in of meshing components.*

### Hydraulic Oil

1. Refer to Section 1 for recommendations for viscosity ranges.
2. JLG recommends Mobilfluid 424 hydraulic oil, which has an SAE viscosity of 10W-30 and a viscosity index of 152.

**NOTE:** *Start-up of hydraulic system with oil temperatures below -15°F (-26°C) is not recommended. If it is necessary to start the system in a sub-zero environment, it will be necessary to heat the oil with a low density, 100VAC heater to a minimum temperature of -15°F (-26°C).*

3. The only exception to the above is to drain and fill the system with Mobil DTE 13 oil or its equivalent. This will allow start up at temperatures down to -20°F (-29°C). However, use of this oil will give poor perfor-

mance at temperatures above 120°F (49°C). Systems using DTE 13 oil should not be operated at temperatures above 200°F (94°C) under any condition.

### Changing Hydraulic Oil

1. Use of any of the recommended hydraulic oils eliminates the need for changing the oil on a regular basis. However, filter elements must be changed after the first 50 hours of operation and every 300 hours thereafter. If it is necessary to change the oil, use only those oils meeting or exceeding the specifications appearing in this manual. If unable to obtain the same type of oil supplied with the machine, consult local supplier for assistance in selecting the proper equivalent. Avoid mixing petroleum and synthetic base oils. JLG Industries recommends changing the hydraulic oil annually.
2. Use every precaution to keep the hydraulic oil clean. If the oil must be poured from the original container into another, be sure to clean all possible contaminants from the service container. Always clean the mesh element of the filter and replace the cartridge any time the system oil is changed.
3. While the unit is shut down, a good preventive maintenance measure is to make a thorough inspection of all hydraulic components, lines, fittings, etc., as well as a functional check of each system, before placing the machine back in service.

### Lubrication Specifications

Specified lubricants, as recommended by the component manufacturers, are always the best choice, however, multi-purpose greases usually have the qualities which meet a variety of single purpose grease requirements. Should any question arise, regarding the use of greases in maintenance stock, consult your local supplier for evaluation. Refer to Section 1 for an explanation of the lubricant key designations appearing in the Lubrication Chart.

## 2.5 SERVICE MAINTENANCE COMPONENTS


### Setting Scissor Arm Safety Prop

#### **⚠ CAUTION**

**THE SAFETY PROP MUST BE USED WHENEVER MAINTENANCE PERFORMED ON THE MACHINE REQUIRES THE SCISSOR ARMS TO BE RAISED.**

1. To engage the safety props, raise the unloaded platform high enough to allow the safety props to rotate vertically into position. (See Figure 2-1.)
2. Rotate the rod keeper plate and release the safety prop actuator rod at the front of the machine. (See Figure 2-2.)
3. Lift the actuator rod (flat) up out of the slot in the keeper plate bracket and pull the actuator rod to align the safety props vertically with the scissor arm center pins above and below the safety prop mounting pins.
4. Set the actuator rod (flat at the set position) into the slot on the keeper plate bracket and rotate the keeper plate to lock the actuator rod in this position.
5. Lower the platform arms until the safety prop rests on the scissor arm center pin mounts above and below the safety prop.

Maintenance can now begin.




**Figure 2-1. Scissor Arm - Safety Prop Assembly**

1. Actuator Rod/Rod Keeper Plate.
2. Safety Prop in set position.
3. Safety Prop in stowed position.

To store the safety prop, raise the platform, release the actuator rod from the keeper plate bracket, push the safety prop rod so that the safety props are restored back to its stowed position. Lock the actuator rod in place with the keeper plate till next use.

**⚠ WARNING**

**TO AVOID PERSONAL INJURY, USE SAFETY PROP FOR ALL MAINTENANCE REQUIRING PLATFORM TO BE ELEVATED.**



**Figure 2-2. Safety Prop Actuator Rod**

- 1. Safety Prop Actuator Rod
- 2. Notch Flats on Rod
- 3. Rod Keeper Plate


**General Maintenance Tips**

**NOTE:** Be sure to lubricate like items on each side of machine.

**NOTE:** Recommended lubricating intervals are based on machine operations under normal conditions. For machines used in multi-shift operations and/or exposed to hostile environments or conditions, lubrication frequencies must be increased accordingly.

Operate hydraulic functions through one complete cycle before checking hydraulic oil level in tank. Oil should be visible in ADD sight window on hydraulic tank. If oil is not visible, add oil until oil is visible in both ADD and FULL sight windows on tank. Do not overfill tank.

Any time the pump coupling is removed, coat splines of coupling with Texaco Code 1912 grease prior to assembly.




- 1. Fuel Tank - (Gasoline or Diesel)
- 2. Fuel Tank w/Shut-Off Valve - (LP Only)
- 3. Hydraulic Oil Tank
- 4. Drive Hubs
- 5. Scissor Arm - Sliding Wear Pads
- 6. Oil Change w/Filter - Kubota
- 7. Fuel/Water Separator Filter - Kubota- Diesel
- 8. Hydraulic Charge Filter - Kubota - Diesel
- 9. Fuel Filter/Fuel Pump - Kubota- Gasoline
- 10. Air Filter

**Figure 2-3. Service Maintenance Components**

**NOTE:** Platform ladders removed for illustrative purposes only.



## Fuel Tank



- Fuel - Diesel or Gasoline (Per Engine Type - Reference Decal on Machine)
- Capacity - 22 gal (83.2 l)

## Drive Hub




- Lube Points - Fill P (lugs (4))
- Capacity - 24 oz (0.8 L)
- Lube - EPGL
- Interval - Every 2 years or 1200 hours

## Scissor Arms - Sliding Wear Pads


- Lube Points - 8 Sliding Wear Pads
- Lube - MPG
- Interval - Every month or 50 hours.

## Hydraulic Oil Tank



- Lube Point - Fill Cap/Fill Level
- Capacity - 32.3 gal (122.3 L) total tank capacity  
27.3 gal (103.3 L) full level capacity
- Lube - HO - API service classification GL-3, Reference - Figure 1-1., Hydraulic Oil Operating Temperature Specifications
- Interval - Check oil every 10 hours of operation; change oil every 2 years or 1200 hours of operation.


## Engine - Oil Change w/Filter - Kubota - (WG972-GL-E4F -T3) Dual Fuel



**NOTE:** Exhaust system shown removed for illustrative purposes only.


- Lube Point(s) - Fill Cap/Spin-on Element
- Capacity - 0.9 Gal. (3.4 L) engine only
- Lube - EO - Minimum API SN, Viscosity - See Figure 1-2., Engine Oil Operating Temperature Specifications - Kubota (Dual Fuel Engine)
- Interval - Every Year or 200 hours of operation
- Check oil level daily, maintain within marked level (1)/Change in accordance with engine manual.

**Engine - Oil Change w/Filter - Kubota (D1305-E4B - T4F - Diesel) and (D1305-E3B - T4 - Diesel)**




- Lube Point(s) - Fill Cap/Spin-on Element
- Capacity - 1.51 gal. (5.7 L) Engine Oil
- Lube - EO - Minimum API CI-4 - Viscosity, See Figure 1-3., Engine Oil Operating Temperature Specifications - Kubota (Diesel Engine)
- Interval - Every Year or 200 hours of operation
- Check oil level daily, maintain within marked level (1)/Change in accordance with engine manual.

**Hydraulic Charge Filter (Diesel) - Kubota**



- Lube Point(s) - Replaceable Element
- Interval - Change after first 50 hours and after every six months or 300 hours


**Fuel/Water Separator Filter (Diesel) - Kubota**



**NOTE:** Mounted inside engine cabinet on right-rear cabinet wall behind battery and exhaust pipe.

- Lube Point(s) - Replaceable Element - Pre-Filter with pressure sensor next to fuel tank
- Interval - Every Year or 600 hours of operation


**Fuel Strainer (Diesel) - Kubota**



**NOTE:** Mounted inside fuel/hydraulic cabinet on left-rear cabinet wall behind fuel tank.

- Lube Point(s) - Replaceable Element
- Interval - Every Year or 600 hours of operation


## Fuel Filter (Gas) - Kubota



**NOTE:** Mounted inside fuel/hydraulic cabinet on left-rear cabinet wall behind fuel tank.

- Lube Point(s) - Replaceable Element
- Interval - Every 6 months or 300 hours of operation

## Air Filter



- Lube Point(s) - Replaceable Primary Filter Element (1) (Dry Type)
- Interval - Every 6 months or 300 hours of operation. Under severe operating conditions (such as a very dusty work area) check condition of filter more often.
- Once a week check the evacuator valve (2) on bottom of air cleaner assembly, squeeze it open to allow any collected debris to fall out of the air cleaner.

## 2.6 CYLINDER DRIFT TEST

Maximum acceptable cylinder drift is to be measured using the following methods.

### Platform Drift

Measure the drift of the platform to the ground. Fully extend the scissor arms from stowed position with the rated load in the platform and power off. Maximum allowable drift is 2 in (5 cm) in 10 minutes. If the machine does not pass this test, proceed with the following.

### Cylinder Drift

CYLINDER BORE DIAMETER		MAX. ACCEPTABLE DRIFT IN 10 MINUTES	
inches	mm	inches	mm
3	76.2	0.026	0.66
3.5	89	0.019	0.48
4	101.6	0.015	0.38
5	127	0.009	0.22
6	152.4	0.006	0.15
7	177.8	0.005	0.13

Drift is to be measured at the cylinder rod with a calibrated dial indicator. The cylinder oil must be at ambient temperature and temperature stabilized.

The cylinder must have the normal load, which is the normal platform load applied.

If the cylinder passes this test, it is acceptable.

**NOTE:** This information is based on 6 drops per minute cylinder leakage.



## 2.7 PINS AND COMPOSITE BEARING REPAIR GUIDELINES

Filament wound bearings.

1. Pinned joints should be disassembled and inspected if the following occurs:
  - a. Excessive sloppiness in joints.
  - b. Noise originating from the joint during operation.
2. Filament wound bearings should be replaced if any of the following is observed:
  - a. Frayed or separated fibers on the liner surface.
  - b. Cracked or damaged liner backing.
  - c. Bearings that have moved or spun in their housing.
  - d. Debris embedded in liner surface.
3. Pins should be replaced if any of the following is observed (pin should be properly cleaned prior to inspection):
  - a. Detectable wear in the bearing area.
  - b. Flaking, peeling, scoring, or scratches on the pin surface.
  - c. Rusting of the pin in the bearing area.
4. Re-assembly of pinned joints using filament wound bearings.
  - a. Housing should be blown out to remove all dirt and debris...bearings and bearing housings must be free of all contamination.
  - b. Bearing / pins should be cleaned with a solvent to remove all grease and oil...filament wound bearing are a dry joint and should not be lubricated.
  - c. Pins should be inspected to ensure it is free of burrs, nicks, and scratches which would damage the bearing during installation and operation.

# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

A screenshot of the "Search Manuals" form on the website. It includes fields for "Brand", "Model", "Serial", "Part Number", and "Category", along with a "Search" button at the bottom.

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

A screenshot of the "Parts Order Form" on the website. It is a structured form with multiple rows and columns for entering detailed information about the part and the request.

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

## SECTION 3. CHASSIS, PLATFORM & SCISSOR ARMS

### 3.1 OPERATING CHARACTERISTICS

#### Leveling Jacks

The machine is equipped with auto leveling jacks. These leveling jacks are operated through one switch unlike the traditional four switch system. The leveling jacks are operated by a bang-bang valve.

**NOTE:** *The engine speed will drop when the leveling jacks are in contact with the ground.*

1. Activate the leveling jack button located on the platform control box.
2. Extend the jacks by moving the joystick forward.

**NOTE:** *Once all four jacks make contact with the ground the system will go from set mode into level mode. At this point the engine will return to idle.*

3. The tilt indicator will go out once the machine is level.

**NOTE:** *If the machine is not level it will not lift. If you hit the end of stroke on any of the cylinders you cannot lift the machine.*

**NOTE:** *There is a limit switch on each cylinder that senses when the cylinder is fully retracted when all four are fully retracted, the stowed light in the platform control box will light.*

*If you receive a 2/5 flash code through the system fault light at the platform control station the machine is unable to level. You must reposition and try again.*

The jacks are operational (extend or retract) if the machine is in the stowed position. The proximity sensor and rotary sensor together must sense that the machine is stowed. A failure of either sensor will prevent the jacks from being activated.

#### Generator

When the generator switch is activated, the engine RPM will increase to high idle.

When a function is selected for operation, which requires a higher engine speed than the generator, the generator will automatically shut off during the operation of the function. Once the function has stopped, the generator will be active again.

#### Lift

There is a flow control valve which controls both the lift up and lift down speeds.

Anytime you abruptly change lift directions, there is a three second delay between lift up and lift down.

#### Drive

If driving at high drive up a grade and you hit an 8° incline, the drive function will cut back to mid drive speed. The drive pump will shift back into high drive once the incline decreases to 5°. There will be a 2 second delay before the machine goes back into high drive.

### 3.2 TIRES, WHEELS, & DRIVE ASSEMBLY

#### Tire Inflation

The air pressure for pneumatic tires must be equal to the air pressure that is stenciled on the side of the JLG product or rim decal for safe and proper operational characteristics.

#### Tire Damage

For pneumatic tires, JLG Industries, Inc. recommends that when any cut, rip, or tear is discovered that exposes sidewall or tread area cords in the tire, measures must be taken to remove the JLG product from service immediately. Arrangements must be made for replacement of the tire or tire assembly.

For polyurethane foam filled tires, JLG Industries, Inc. recommends that when any of the following are discovered, measures must be taken to remove the JLG product from service immediately and arrangements must be made for replacement of the tire or tire assembly.

- a smooth, even cut through the cord plies which exceeds 3 inches (7.5 cm) in total length
- any tears or rips (ragged edges) in the cord plies which exceeds 1 inch (2.5 cm) in any direction
- any punctures which exceed 1 inch in diameter
- any damage to the bead area cords of the tire

If a tire is damaged but is within the above noted criteria, the tire must be inspected on a daily basis to ensure the damage has not propagated beyond the allowable criteria.

#### Tire Replacement

JLG recommends a replacement tire be the same size, ply and brand as originally installed on the machine. Please refer to the JLG Parts Manual for the part number

of the approved tires for a particular machine model. If not using a JLG approved replacement tire, we recommend that replacement tires have the following characteristics:

- Equal or greater ply/load rating and size of original
- Tire tread contact width equal or greater than original
- Wheel diameter, width, and offset dimensions equal to the original
- Approved for the application by the tire manufacturer (including inflation pressure and maximum tire load)

Unless specifically approved by JLG Industries Inc., do not replace a foam filled or ballast filled tire assembly with a pneumatic tire. When selecting and installing a replacement tire, ensure that all tires are inflated to the pressure recommended by JLG. Due to size variations between tire brands, both tires on the same axle should be the same.

**Wheel Replacement**

The rims installed on each product model have been designed for stability requirements which consist of track width, tire pressure, and load capacity. Size changes such as rim width, center piece location, larger or smaller diameter, etc., without written factory recommendations, may result in an unsafe condition regarding stability.

**Wheel Installation**


It is extremely important to apply and maintain proper wheel mounting torque.

**⚠ WARNING**

**WHEEL NUTS MUST BE INSTALLED AND MAINTAINED AT THE PROPER TORQUE TO PREVENT LOOSE WHEELS, BROKEN STUDS, AND POSSIBLE DANGEROUS SEPARATION OF WHEEL FROM THE AXLE. BE SURE TO USE ONLY THE NUTS MATCHED TO THE CONE ANGLE OF THE WHEEL.**

Tighten the lug nuts to the proper torque to prevent wheels from coming loose. Use a torque wrench to tighten the fasteners. If you do not have a torque wrench, tighten the fasteners with a lug wrench, then immediately have a service garage or dealer tighten the lug nuts to the proper torque. Over-tightening will result in breaking the studs or permanently deforming the mounting stud holes in the wheels. The proper procedure for attaching wheels is as follows:

1. Start all nuts by hand to prevent cross threading. DO NOT use a lubricant on threads or nuts.
2. Tighten nuts in the following sequence:




3. The tightening of the nuts should be done in stages. Following the recommended sequence, tighten nuts per wheel torque chart.

**Table 3-1. Wheel Torque Chart**

TORQUE SEQUENCE (DRY)		
1st Stage	2nd Stage	3rd Stage
40-50-ft. lb. (60-70 Nm)	90-105 lb-ft (125-150 Nm)	170 lb-ft (230 Nm)

4. Wheel nuts should be torqued after first 50 hours of operation and after each wheel removal. Check torque every 3 months or 150 hours of operation.

## Drive Assembly



1. Tire & Rim
2. Lugnuts
3. Drive Hub (Fairfield)
4. Bolt, 5/8"-11NC x 1 3/4"
5. Hardened Washer, 5/8"
6. Drive Motor (Sauer)
7. Nut, 1/2"-13NC
8. Hardened Washer, 1/2"

**NOTE:** Rear Axle Shown

## REMOVAL

**⚠ WARNING**

**SHUT MACHINE OFF, BRACE AXLES AND CHALK WHEELS TO PREVENT MACHINE FROM MOVING DURING REPAIRS.**

1. Disconnect, cap and label all hydraulic lines attached to Drive Motor (6). If applicable, disconnect all electrical wiring.
2. With axle raised and supported, remove the Tires (1) from the Drive Hub (3) by removing the 9 Lugnuts (2).
3. Remove the Drive Hub (3) and Drive Motor (6) from the axle by removing the 6 Bolts (4) and Washers (5).
4. The Drive Motor (6) can be removed from the Drive Hub (3) by removing the 2 Nuts (7) and Washers (8).

## INSTALLATION

1. Follow "Removal" procedures in reverse order.

2. Refer to Table 3-1, Wheel Torque Chart when torquing Lugnuts (2).

**NOTE:** For detailed information on the Drive Hub and Drive Motor, refer to Section 3.3, Drive Hub (Fairfield) and Section 3.4, Drive Motor (Sauer).

### 3.3 DRIVE HUB (FAIRFIELD)

#### Roll and Leak Testing

Always roll and leak test Drive-Hubs after assembly to make sure that the unit's gears and sealants are working properly. The following information briefly outlines what to look for when performing these tests.


##### THE ROLL TEST

The purpose of a roll test is to determine if the unit's gears are rotating freely and properly. You should be able to rotate the gears in your unit by applying a constant force to the roll checker. If you feel more drag in the gears only at certain points, then the gears are not rolling freely and you should examine them for improper installation or defects. Some gear packages roll with more difficulty than others. Do not be concerned if the gears in your unit seem to roll hard as long as they roll with consistency.

##### THE LEAK TEST

The purpose of a leak test is to make sure the unit is air tight. You can tell if your unit has a leak if the pressure gauge reading on your air checker starts to fall once you have pressurized the unit. Leaks will most likely occur at the main seal or wherever o-rings or gaskets are located. Usually you can detect the exact location of a leak by brushing a soap and water solution around the main seal and where o-rings or gaskets meet the exterior of the unit, then checking for air bubbles. If you detect a leak in a seal, o-ring, or gasket, replace the part immediately.

#### Tightening and Torquing Bolts



If you use an air impact wrench to tighten bolts, take extreme care to ensure that you do NOT tighten the bolts beyond their indicated torque specification. Never use an impact wrench to tighten shoulder bolts. Always tighten all shoulder bolts by hand.

The following steps describe the proper procedure for tightening and torquing bolts or socket head **cap screws** in a bolt circle.

1. Tighten (but do not torque) bolt "A" until snug.
2. Go to the opposite side of the bolt circle and tighten bolt "B" until equally snug.
3. Continue around the bolt circle and tighten the remaining bolts.
4. Now use a torque wrench to apply the specified torque to bolt "A".
5. Continue around the bolt circle and apply an equal torque to the remaining bolts.

#### Oil Information

1. TYPE – EP90  
On normal applications, use EP90. On applications where the lubricant must meet special requirements, the O.E.M. should be able to recommend a suitable substitute.
2. OIL TEMPERATURE  
Continuous – 160°F [70°C] Intermittent – 200°F [95°C]
3. OIL CHANGE  
Initial – After 50 hours or 50,000 revolutions of operation. Subsequent – After 1000 hours or (1) year, whichever comes first.

**NOTE:** Higher temperatures make it necessary to change oil more frequently.

4. OIL FILL LEVEL AND VOLUME  
Unit mounted horizontal – half full  
Approximate volume - 17 oz. (0.5 ltr)
5. REAR BRAKES  
Rear brakes require 2.7 oz. (0.08 ltr) of DTE 13M hydraulic fluid each to function properly.






Figure 3-1. Drive Hub



## SECTION 3 - CHASSIS, PLATFORM & SCISSOR ARMS


**NOTE:** Refer to Figure 3-1., Drive Hub.

**Table 3-2. Drive Hub Part Description**

Item #	Description
1	Spindle/Housing Assembly
1A	Spindle
1B	Seal
1C	Bearing Cone
1D	Bearing Cup
1E	Bearing Cup
1F	Bearing Cone
1G	Housing/Ring Gear
1H	Thrust Washer
1I	Retaining Ring
1J	Wheel Stud
2	Internal Gear
3	Carrier Assembly
3A	Carrier
3B	Retaining Ring
3C	Needle Bearing
3D	Thrust Washer
3E	Planet Shaft
3F	Planet Gear
3G	Rollpin
4	Ring Gear
5	O-Ring
5A	O-Ring
6	Cover Assembly
6A	Thrust Spacer
6B	Cover Plate
6C	O-Ring
6D	Disconnect Rod
6E	Disengage Cap
6F	Bolt 1/2"-20NC x 1/2"
6G	Pipe Plug
6H	Rivet
6I	ID Plate
7	Input Shaft Assembly
7A	Shaft
7B	Retaining Ring
7C	Spring
7D	Thrust Spacer

**Table 3-2. Drive Hub Part Description**

Item #	Description
8	Sun Gear
9	Thrust Washer
10	Bolt
11	Dowell Pin
12	Coupling
13	Input Spacer
14	Input Spacer
15	Brake Assembly
16	O-Ring
17	Threaded Rod
18	Nut 1/2"-13NC
BRAKE ASSEMBLY	
19	Shaft
20	Housing
21	Friction Plate
22	Pressure Plate
23	Gasket
24	Outer Plate
25	Gasket
26	Cylinder
27	Piston
28	Ball Bearing
29	Retaining Ring
30	Shaft Seal
31	Capscrew
32	Lockwasher
33	O-Ring
34	Back-up Ring
35	O-Ring
36	Back-up Ring
37	Dowel Pin
38	Plug
39	Plug
40	Spring Kit (Natural)
41	Spring Kit (Blue)



- |                             |                         |                             |                   |
|-----------------------------|-------------------------|-----------------------------|-------------------|
| 1. Hub-Spindle Sub-Assembly | 2. Internal Gear        | A. Cover                    | C. Spring         |
| A. Spindle                  | 3. Carrier Sub-Assembly | B. Cover Cap                | D. Spacer         |
| B. Seal                     | A. Carrier Housing      | C. Bolt                     | 8. Input Gear     |
| C. Bearing Cup              | B. Thrust Washer        | D. Disconnect Cap           | 9. Thrust Spacer  |
| D. Bearing Cone             | C. Needle Roller        | E. Disconnect Rod           | 10. Thrust Spacer |
| E. Bearing Cup              | D. Spacer               | F. O Ring                   | 11. Bolt          |
| F. Bearing Cone             | E. Planet Shaft         | G. O Ring                   | 12. Shoulder Bolt |
| G. Hub                      | F. Cluster Gear         | H. Pipe Plug                | 13. Coupling      |
| H. Spacer                   | G. Roll Pin             | I. ID Plate                 | 14. Flat Washer   |
| I. Retaining Ring           | 4. Ring Gear            | 7. Input Shaft Sub Assembly |                   |
| J. Pipe Plug                | 5. O Ring               | A. Seal                     |                   |
| K. Stud                     | 6. Cover Sub-Assembly   | B. Retaining Ring           |                   |

Figure 3-2. Drive Hub (Cross-Section)

## Main Disassembly for Drive Hub

**NOTE:** Refer to Figure 3-2. for part location and listing.

1. Turn hub (1G) over onto its side. Remove coupling (14) from the wide end of spindle (1A).
2. Mark location of shoulder bolt holes on outside of ring gear and hub for easy re-alignment when rebuilding. Remove the four shoulder bolts (13) and twelve bolts (12) from cover (6).
3. Remove the sixteen flat washers (16) from cover (6).
4. Lift cover sub-assembly (6) off of ring gear (4), and set cover on table, interior side facing up.

### ⚠ CAUTION

**CAUTION: BEWARE OF SHARP EDGES IN THE COUNTERBORE WHEN YOU REMOVE THE O-RING.**

5. Remove o-ring (5) from the counterbore around the edge of cover (6A). Discard the o-ring.

**NOTE:** If o-ring is not in the cover counter-bore, it is in the ring gear counterbore. Remove it from the hub and discard it.

6. Remove thrust washer (11) from the counter-bore in top of carrier (3A).
7. Remove input gear (8) from the middle of carrier sub-assembly (3).
8. Lift ring gear (4) off of hub (1G).
9. Lift carrier sub-assembly (3) out of hub (1G).
10. Remove thrust spacer (9) from input shaft (7) in the middle of spindle (1A).
11. Lift input shaft sub-assembly (7) out of middle of spindle (1A), and stand input shaft (7A) on its splined end.

### ⚠ CAUTION

**WEAR SAFETY GLASSES DURING THIS STEP, AND BE AWARE THAT SPRING AND SPACERS COMPRESSED BY RETAINING RING MAY POP SUDDENLY OFF SHAFT WHEN YOU REMOVE THE RETAINING RING.**

12. Using retaining ring pliers, remove retaining ring (7B) from the groove on input shaft (7A).
13. Remove one spacer (7D), one spring (7C), and other spacer (7D) from input shaft (7A).
14. Remove thrust washer (11) from around spindle (1A).
15. Lift internal gear (2) out of hub (1G).

### ⚠ CAUTION

**BEWARE OF SHARP EDGES IN COUNTERBORE WHEN YOU REMOVE THE O-RING.**

16. Remove o-ring (5) from the counterbore in hub (1G). Discard the o-ring.

17. At this point the main disassembly for drive hub is complete.

## Hub-Spindle Disassembly

**NOTE:** Start with large end of hub facing up, large end of spindle facing down.

### ⚠ CAUTION

**WEAR SAFETY GLASSES DURING THIS STEP.**

1. Remove retaining ring (1I) from around spindle (1A) in hub (1G).
2. Remove spacer (1H) from around spindle (1A) in hub (1G).
3. Set hub (1G), small end/spindle facing down, up on something that will support the hub's flange while it lifts hub up so spindle is not resting on anything. Carefully press or hammer spindle (1A) down and out of hub (1G).

**NOTE:** If seal (1B) and bearing cone (1D) come out of hub and rest on spindle, remove these parts from the spindle and set them aside. Discard the seal.

4. If seal and bearing cone did not come out of the small end of hub (1G) when spindle is pressed out of hub, remove seal (1B) and bearing cone (1D) from the small end of hub. Discard the seal.
5. Bearing cone (1F) should be lying loose in wide end of hub (1G). Remove bearing cone (1F) from inside hub.

**NOTE:** If you use a punch and hammer, make sure you do not strike the counterbore with the punch when you remove the bearing cup.

6. Remove bearing cup (1C) from the counterbore in the small end of hub (1G).

**NOTE:** If using a punch and hammer, make sure to not strike the counterbore with the punch when removing the bearing cup.

7. Turn hub (1G) over and lift it out of the flange-support. Remove bearing cup (1E) from the counterbore in the wide end of hub.
8. Turn hub (1G) over onto its small end. Remove two pipe plugs (1J) from the two pipe plug holes in the side of hub.

**NOTE:** If the unit does not have studs, skip this step:

9. Press the nine studs (1N) out of the stud holes in hub (1G).
10. At this point the hub-spindle disassembly is complete.

## Cover Disassembly

1. Remove the two bolts (6C) holding disconnect cap (6D) to cover (6A).

2. Remove disconnect cap (6D) from top of cover cap (6B) and cover (6A).
3. Remove the two bolts (6C) attaching cover cap (6B) to cover (6A).
4. Remove cover cap (6B) from cover (6A).
5. Remove disconnect rod (6K) from cover cap (6B).
6. Pry o-ring (6F) out of the groove inside cover cap (6B). Discard the o-ring.
7. Remove o-ring (6G) from the flange of cover cap (6B). Discard the o-ring.
8. Remove pipe plug (6H) from cover (6A).
9. At this point the cover disassembly is complete.

### Carrier Disassembly

**NOTE:** When removing the needle rollers from the cluster gears, discard the old needle rollers and use new ones during re-assembly.


1. Using a punch and hammer, drive roll pin (3G) into planet shaft (3E).

**NOTE:** Be sure to drive the roll pin all the way into the planet shaft. Failure to do so could result in damage to the carrier when removing the planet shaft from the carrier.

2. Using a punch and hammer, drive the planet shaft (3E) out of the planet shaft hole in the carrier housing (3A).
3. When removing the planet shaft (3E) from the carrier housing, one thrust washer (38), one cluster gear (3F), and one more thrust washer will come off of the planet shaft and come to rest inside the carrier. Remove these parts from inside the carrier.
4. Remove 16 needle rollers (3C) from inside one end of cluster gear (3F). Discard the needle rollers.
5. Remove one spacer (3D) from inside cluster gear (3F).
6. Remove the remaining 16 needle rollers (3C) from the other side of cluster gear (3F). Discard the needle rollers.
7. Repeat steps 1-6 to remove and disassemble the two remaining cluster gears.
8. At this point the carrier disassembly is complete.

### Assembly of the Carrier


1. Apply grease to the inside of one cluster gear (3F) and line one half of cluster gear with 16 needle rollers (3C).



2. Place one spacer (3D) inside cluster gear (3F) so that it rests on top of the needle rollers.




3. Line the remaining half of cluster gear (3F) with 16 needle rollers.





### SECTION 3 - CHASSIS, PLATFORM & SCISSOR ARMS

4. Set carrier housing (3A) sideways on a table. Insert a planet shaft (3E), roll pin hole last, into one of the planet shaft holes from roll-pin-holed side of carrier housing.



5. Place one thrust washer (3B) onto the end of planet shaft (3E) inside carrier. Fit tang of thrust washer into the slot on the inside edge of the planet shaft hole.




6. Following the thrust washer, place the cluster gear (3F), large end toward roll pin hole in carrier housing, onto the planet shaft (3E).




7. Following the cluster gear, place one more thrust washer (3B) onto planet shaft (3E) through the opposite planet shaft hole in carrier housing (3A).



8. Use an alignment punch or similar tool to align the roll pin holes in carrier housing (3A) and planet shaft (3E).




9. Drive roll pin (3G) down into the aligned roll pin holes in carrier housing (3A) and planet shaft (3E).




10. Repeat steps 1 thru 9 to assemble and install the two remaining cluster gears.
11. At this point the carrier sub-assembly is complete.

**Cover Sub-Assembly**

1. Using the disconnect rod, push o-ring (6F) into the groove inside the cover cap (6B).



2. Place the o-ring (6G) onto the cover cap (6B) so that it rests against the flange of the cover cap.



3. Insert disconnect rod (6E) into cover cap (6B).




4. Set cover (6A) on table, exterior side up. Place cover cap (6B) onto cover (6A), aligning the pipe plug hole in the cover cap over the pipe plug hole in the cover.



5. Place two of the cover cap bolts (6C) into any two bolt holes that are 180° apart on the cover cap (6B) and tighten bolts.



**Using a torque wrench, apply 2.95 to 3.69 ft. lbs. (4 to 5 Nm) of torque to both bolts (6C).**




6. With the large end down, place the disconnect cap (6D) onto the cover cap (6B), aligning the pipe plug hole in the disconnect cap over the pipe plug hole in the cover cap.



7. Place the two remaining bolts (6C) into the bolt holes in the disconnect cap (6D), and tighten the bolts.



8. Using a torque wrench, apply 2.95 to 3.69 ft. lbs. (4 to 5 Nm) of torque to both bolts (6C).




9. Apply a light coat of "Never-Seize" to pipe plug (6H) and tighten it into the pipe plug hole in the cover (6A).




### **Hub-Spindle Sub-Assembly**

**NOTE:** Make sure the cup sits square with the counterbore before pressing.

1. Set hub (1G) onto its large end. Press bearing cup (1C) into the counterbore in the small end of the hub (1G).




2. Press the nine studs (1N) into the stud holes in hub (1G).






3. Apply a light coat of "Never-Seize" to two pipe plugs (1J) and tighten them into the two pipe plug holes in the side of the hub (1G).



**NOTE:** Make sure the cup sits square with the counterbore before pressing.

4. Turn hub (1G) over onto its small end. Press bearing cup (1E) down into the counterbore in the deep end of the hub (1G).



5. Set hub (1G) onto its large end. Place bearing cone (1D) into bearing cup (1C).




6. Press seal (1B) into the small end of hub (1G).




7. Oil spindle, then lower hub (1G), small end down, onto spindle (1A).



8. Press bearing cone (1F) onto spindle (1A) in hub (1G).



9. Place spacer (1H) onto spindle (1A) in hub (1G).



**NOTE:** Make sure the retaining ring is securely seated in the groove.

10. Place retaining ring (1I) over the spacer onto spindle (1A) in hub (1G).



11. At this point the hub-spindle sub-assembly is complete.

## Main Assembly

### WARNING


**BEWARE OF SHARP EDGES IN COUNTERBORE WHEN INSTALLING THE O-RING**

1. Grease o-ring (5) and place it into the counterbore in hub (1G).


**NOTE:** O-ring may be stretched or pinched together to make it fit the counterbore exactly.



2. Oil all exposed surfaces inside hub (1G).



3. Place internal gear (2) into hub (1G) so that its internal splines mesh with the external splines of spindle (1A). Oil internal gear (2).



4. Place thrust washer (11) around spindle (1A) so it rests on the bottom of the internal gear (2).



7. Place other spacer (7D) onto the smooth end of input shaft (7A).




5. Stand input shaft (7A) on its splined end. Place one spacer (7D) onto the smooth end of input shaft (7A).



**⚠ WARNING**

**WEAR SAFETY GLASSES DURING THIS STEP, AND BE AWARE THAT SPRING AND SPACERS, COMPRESSED BY RETAINING RING, MAY POP SUDDENLY OFF SHAFT IF THE RING IS RELEASED BEFORE IT IS PROPERLY IN PLACE.**


8. Using retaining ring pliers, insert retaining ring (7B) into the groove on input shaft (7A) by compressing the spring and spacers together.



6. Place one spring (7C) onto the smooth end of input shaft (7A).




9. With large splined end down, place input shaft sub-assembly (7) into spindle (1A).






10. Place thrust spacer (9) onto input shaft (7).




11. Set carrier sub-assembly (3) on a flat work surface so the large ends of cluster gears (3F) face up. Locate the punch marks on the face of each cluster gear (3F) and position them at 12 o'clock.



**Figure 3-3. Cluster Gear Punch Marks**

12. With "X" marked side facing up, place the ring gear (4) around cluster gears (3F).

**NOTE:** This will hold the punch marks in position while installing the carrier into the hub.



13. Place the carrier sub assembly (3) and ring gear (4) together into mesh with internal gear (2), aligning the "X" marked shoulder bolt hole in the ring gear (4) over one of the shoulder bolt holes in the hub. Mark the location of shoulder bolt holes on the outside of ring gear and hub.


**NOTE:** You may lift the ring gear off the hub to align the shoulder bolt holes. The ring gear and carrier are installed together only to keep the punch marks on the carrier in place.



14. With the internal splines facing up (counterbore end facing down), place input gear (8) into mesh with carrier sub-assembly (3).



15. Oil all exposed surfaces inside the hub (1G). Place thrust washer (11) into the counterbore in top of the carrier.



**⚠ WARNING**

**BEWARE OF SHARP EDGES IN THE COUNTERBORE WHEN YOU INSTALL THE O-RING.**

16. Set the cover (6A) on table, interior side up. Grease o-ring (5) and place it into the counterbore around the edge of cover (6A).

**NOTE:** The o-ring may be stretched or pinched together to make it fit the counterbore exactly.




17. Place cover sub-assembly (6) onto ring gear (4), aligning the pipe plug holes according to the alignment prior to disassembly.




18. Place four flatwashers (16) on top of the bolt holes in the cover sub-assembly.



19. Place shoulder bolts (13) into the four shoulder bolt holes in cover (6) and tighten by hand.



20. Place the remaining 12 flatwashers (16) onto the remaining bolt holes in cover (6).




21. Place the 12 bolts into the remaining bolt holes in cover (6) and tighten.




### SECTION 3 - CHASSIS, PLATFORM & SCISSOR ARMS

---


22. Torque the shoulder bolts (13) 18 to 25 ft. lbs. (25 to 34 Nm). Torque bolts (12) 18 to 25 ft. lbs. (25 to 34 Nm).



23. Turn hub (1G) over onto its side. Insert coupling (14) into the end of the spindle (1A).




24. Roll test the unit in both clockwise and counterclockwise directions. Perform the same number of turns in each direction as the ratio of the unit. The ratio is the last two digits of the model number on the unit's ID tag.



25. Leak test the unit at a pressure of 5 psi (0.34 bar) for 2 to 3 minutes.



26. At this point the main assembly is complete.




**Tool List**


The following specialized tools are used to assemble this unit. The tool diagrams included in this manual are intended for the customer who may wish to have a tool made. All tools exist as one piece and must be made from mild steel. All dimensions are given in inches.

**NOTE:** In order to improve tool life, tools may be carburized and hardened. If this is done, however, the tools must be ground on all surfaces labeled with a "G" on the tool diagram.


1. T-118126 SEAL PRESSING TOOL for SEAL (1B).




2. T-138903 ASSEMBLY PRESSING TOOL for CUP (1C)



3. T-140433 ASSEMBLY PRESSING TOOL for CUP (1E)



4. T-109691 ASSEMBLY PRESSING TOOL for CONE (1F)



\* These tools are for specific seals, cups or cones. There is a specific tool for each cup and cone.

**Re-Aligning Torque Hub Input Coupling**

The following procedure applies to torque hubs with integral brakes.

**EQUIPMENT REQUIRED**

1. Hydraulic power supply (hand pump) capable of producing 200 psi (13.8 bar).
2. Hydraulic fittings to adapt hydraulic supply to brake release port on hub.

**PROCEDURE**

1. Using appropriate fittings, connect a line from the hydraulic power supply to the brake port.
2. Pressurize the brake release port 155 to 200 psi (10.6 to 13.8 bar) to release the brake.
3. Verify that the brake is released by rotating the input coupling or hub spindle.
4. Once the brake is released, the input coupling will be free to re-align with the drive motor.
5. Install the drive motor on the hub, then release the hydraulic pressure at the brake release port. The coupling will remain in position.
6. Disconnect the hydraulic power supply and reconnect the line going into the brake release port.



### 3.4 DRIVE MOTOR (SAUER)

#### Description

The drive motors are low to medium power, two-position axial piston motors incorporating an integral servo piston. They are designed for operation in both open and closed circuit applications. The standard control is a direct acting single line hydraulic control. The integral servo piston controls motor displacement.

The motors are spring biased to maximum displacement and hydraulically shifted to minimum displacement. Minimum and maximum displacement can be set with fixed internal stops. The large diameter servo piston allows smooth acceleration and deceleration with relatively large circuit orificing.





Figure 3-4. Drive Motor Cross Section

### Shaft Seal Replacement

#### REMOVAL

1. Remove the snap ring (1) retaining the shaft seal and support washer.



1. Snap Ring
2. Support Washer
3. Shaft Seal

Figure 3-5. Removing the Shaft Seal

2. Remove the support washer (2).
3. Carefully pry out the shaft seal (3).

To avoid damaging the shaft during removal, install a large sheet metal screw into the chuck of a slide hammer. Drive the screw into the seal surface and use the slide hammer to pull the seal.

4. Discard the seal.

**INSPECT THE COMPONENTS**

Inspect the new seal, the motor housing seal bore, and the sealing area on the shaft for rust, wear, and contamination. Polish the shaft and clean the housing if necessary.


**INSTALLATION**

1. Cover the shaft splines with an installation sleeve to protect the shaft seal during installation.
2. Install a new shaft seal with the cupped side facing the motor. Press seal into housing until it bottoms out. Press evenly to avoid binding and damaging the seal.
3. Install seal support washer.
4. Install snap ring.
5. Remove the installation sleeve.

**Loop Flushing Valve**

**REMOVAL**

1. Using a 11/16 in internal hex wrench, remove plug (1) and (2).



- |           |            |                    |
|-----------|------------|--------------------|
| 1. Plug   | 6. O-ring  | 11. Washer         |
| 2. Plug   | 7. Spring  | 12. Shift Spool    |
| 3. Plug   | 8. Spring  | 13. Orifice Poppet |
| 4. O-ring | 9. Spring  |                    |
| 5. O-ring | 10. Washer |                    |

2. Using a 1/4 in hex wrench, remove plug (3).
3. Remove O-rings (4, 5, and 6).
4. Using pliers, remove centering springs (7, 8, and 9).

5. Remove spring retaining washers (10 and 11).
6. Remove shift spool (12).
7. Remove orifice poppet (13).

**INSPECT THE COMPONENTS**

Inspect new O-rings and the sealing area for rust, wear, or contamination. Also check springs and poppet for wear.

**INSTALLATION**

1. Install orifice poppet (13).
2. Install shift spool (12).
3. Install spring retaining washers onto springs (10 and 11).
4. Carefully install centering springs (7, 8, and 9).
5. Install new O-rings (6, 4, and 5).
6. Using a 1/4 in hex wrench, torque plug (3) to 20 ft. lbs. (27 Nm).
7. Using a 11/16 in internal hex, torque plugs (2 and 1) to 27 ft. lbs. (37 Nm).

**Troubleshooting**

**Table 3-3. Excessive Noise and/or Vibration**

Item	Description	Action
Check oil level in reservoir and oil supply to the motor.	Insufficient hydraulic fluid could lead to cavitation that would cause system noise.	Fill the reservoir to the proper level and ensure that oil supply to the motor is adequate and the lines are unobstructed.
Check for air in the system.	Air trapped within the system lines, or the motor itself, could result in cavitation that would cause system noise.	Ensure that all of the system lines and components are purged of air.
Inspect the output shaft couplings.	A loose or incorrect shaft coupling will produce vibrations that could result in system noise.	Ensure that the correct coupling is used and that it fits properly onto the shaft.
Inspect the output shaft alignment.	Misaligned shafts create excessive frictional vibration that could result in system noise.	Ensure that the shafts are properly aligned.
Hydraulic oil viscosity above limits.	Viscosity above acceptable limits will result in cavitation that would lead to system noise.	Replace hydraulic oil with appropriate fluid for operating conditions.

**Table 3-4. System Operating Hot**

Item	Description	Action
Check oil level in reservoir and oil supply to the pump.	Insufficient amount of hydraulic fluid will not meet the cooling demands of the system.	Fill the reservoir to the proper level.
Inspect the heat exchanger, (if so equipped).	If the heat exchanger fails, or becomes obstructed, it may not meet the cooling demands of the system.	Ensure that heat exchanger is receiving adequate air flow and that the heat exchanger is in good operating condition. Repair or replace as necessary.
Check the system relief valves.	If a system relief valve becomes unseated for an extended period of time or fails for any other reason, the system could become overheated.	Repair or replace any malfunctioning relief valves as applicable and verify that the loads on the machine are not excessive.

**Table 3-5. Won't Shift or Slow to Start**

Item	Description	Action
Check the signal line to the servo control port.	Obstructed or restricted flow through the servo control signal lines could result in slow shift or no shift conditions within the motor.	Ensure that the signal lines are not obstructed or restricted and that signal pressure is adequate to shift the motor.
Check that the correct supply and drain orifices are properly installed, and are not obstructed.	Supply and drain orifices determine the shift rate of the motor. The smaller the orifice, the longer the time it takes to shift the motor. Obstruction will also increase shift times.	Ensure that the proper control orifices are installed in the motor and verify that they are not obstructed. Clean or replace as necessary.


## Disassembly

**NOTE:** Removal of the endcap voids warranty.

During assembly, coat all moving parts with a film of clean hydraulic oil. This assures that these parts will be lubricated during start-up.

Replace all O-Rings and gaskets.


It is recommended that all O-rings be replaced. Lightly lubricate all O-rings with clean petroleum jelly prior to assembly.



- |           |           |            |                    |
|-----------|-----------|------------|--------------------|
| 1. Plug   | 5. O-ring | 9. Spring  | 12. Shift Spool    |
| 2. Plug   | 6. O-ring | 10. Washer | 13. Orifice Poppet |
| 3. Plug   | 7. Spring | 11. Washer |                    |
| 4. O-ring | 8. Spring |            |                    |

**Figure 3-6. Loop Flushing Spool**


1. Using a 11/16 in wrench, remove plug (1) and (2).
2. Using a 5/8 in hex wrench, remove plug (3).
3. Remove O-rings (4, 5, and 6).
4. Using pliers, remove centering springs (7, 8, and 9).
5. Remove spring retaining washers (10 and 11).
6. Remove shift spool (12).
7. Remove orifice poppet (13).



- |                       |                    |
|-----------------------|--------------------|
| 14. Lock Nut          | 18. Cavity Plug    |
| 15. O-ring Plug       | 19. Drain Plug     |
| 16. Control Line Plug | 20. Drain Plug     |
| 17. Control Line Plug | 21. Work Port Plug |

**Figure 3-7. Plugs, Fittings, and Speed Sensor**

8. Remove all fittings from the unit. Discard any O-rings on the fittings.
9. Using an 11/16 in hex wrench, loosen the speed sensor lock nut (14) if equipped. Then remove the speed sensor using a 1/2 inch hex wrench. Units without speed sensor have an O-ring plug (15) installed in that location; remove it with a 1/4 inch internal hex wrench.
10. Using a 1/4 in internal hex wrench, remove control line plugs (16, 17). Discard O-rings. Using a 3 mm hex wrench, remove cavity plug (18, if equipped with two-line control) from X2 cavity.
11. Using a 5/16 in internal hex wrench, remove drain plugs (19, 20). Discard O-rings.
12. Using a 9/16 in internal hex wrench, remove work port plugs (21, if equipped with axial ports). Discard O-rings.




- 22. Screw
- 23. End Cap
- 24. O-ring

**Figure 3-8. End Cap**

13. Using an 8 mm internal hex wrench, remove the end-cap screws (22).
14. Remove the endcap (23). Remove O-ring (24) from the housing or endcap.

When the endcap screws are removed, pressure from the servo spring will cause the endcap to bind on the shaft. Press down on the portion of the endcap covering the servo piston and hold the endcap level while removing.



- 25. Valve Plate
- 26. End Cap
- 27. O-ring
- 28. Rear Shaft Bearing
- 29. Minimum Angle Stop
- 30. Servo Spring

**Figure 3-9. Valve Plate & Rear Shaft Bearing**

**CAUTION**

**TAKE CARE NOT TO SCRATCH THE SURFACE OF THE VALVE PLATE.**


15. Remove the valve plate (25) and timing pin (26) from the endcap.

Each displacement has a unique valve plate. For identification, the last two digits of the valve plate part number are stamped on its surface.

16. Remove and discard the O-rings (27).
17. Remove the rear shaft bearing (28) from the endcap with a bearing puller.

The bearing may be difficult to remove with a puller. Try this as an alternative: Pack the bearing cavity with heavy grease. After the shaft is removed, insert it into the bearing cavity and tap lightly with a soft mallet on the splined end. The grease will force the bearing out. Use caution not to drive the bearing past the rear shaft journal as the bearing may become trapped on the shaft and damaged.

18. Remove minimum angle stop (29) and servo spring (30) from the housing.



31. Cylinder Kit Assembly


**Figure 3-10. Cylinder Kit**

- Turn the housing on its side and remove the cylinder kit assembly (31). Set the assembly aside, being careful not to scratch the running surface.

**NOTE:** Grooves on the surface of the cylinder kit identify its displacement:

**Table 3-6. Displacement Identifiers**

# of Grooves	Frame L	Frame K
1	25	38
2	30	45
3	35	--




- 32. Snap Ring
- 33. Support Washer
- 34. Shaft Seal

**Figure 3-11. Shaft Seal**

- Turn the housing over and remove the snap ring (32) retaining the shaft seal and support washer. Remove the support washer (33) and carefully pry out the shaft seal (34). Discard the seal.

To avoid damaging the shaft during seal removal,


install a large sheet metal screw into the chuck of a slide hammer. Drive the screw into the seal surface and use the slide hammer to pull the seal.



- 35. Inner Snap Ring
- 36. Snap Ring
- 37. Bearing
- 38. Shaft

**Figure 3-12. Shaft & Front Bearing**

- Remove the inner snap ring (35) and the shaft / bearing assembly.
- Remove the snap-ring (36) retaining the shaft front bearing. Pull the bearing (37) off of the shaft (38).




- 39. Swashplate
- 40. Servo Piston
- 41. Piston Seal
- 42. O-ring
- 43. Journal Bearings

**Figure 3-13. Swash Plate & Servo Piston**



23. Turn housing over and remove the swashplate (39) by lifting on the end opposite the servo lever.
24. Remove the servo piston (40). Remove the piston seal (41) and O-ring (42) from the servo piston. Discard the seal and O-ring.
25. Remove the journal bearings (43) from the housing. If the bearings are to be reused, note the location and orientation of each bearing for reassembly.



- |                      |                               |
|----------------------|-------------------------------|
| 44. Piston           | 49. Retaining Ring            |
| 45. Slipper Retainer | 50. Block Spring Washer       |
| 46. Cylinder Block   | 51. Spiral Retaining Ring     |
| 47. Ball Guide       | 52. Block Spring              |
| 48. Holddown Pins    | 53. Inner Block Spring Washer |

**Figure 3-14. Cylinder Kit Disassembly**

26. Remove pistons (44) and slipper retainer (45) from the cylinder block (46).

The pistons are not selectively fitted, however units with high hourly usage may develop wear patterns. Number the pistons and bores for reassembly if they are to be reused.

27. Remove the ball guide (47), hold-down pins (48), and retaining ring (49) from the cylinder block.

**NOTE:** Most repairs do not require block spring removal. Perform this procedure only if you suspect problems with the block spring.

**⚠ WARNING**

**RISK OF PERSONAL INJURY: COMPRESSING THE BLOCK SPRING REQUIRES FORCE OF ABOUT 80 TO 90 LBF (350 TO 400 N). USE A PRESS SUFFICIENT TO MAINTAIN THIS FORCE WITH REASONABLE EFFORT. ENSURE THE SPRING IS SECURE BEFORE ATTEMPTING TO REMOVE THE SPIRAL RETAINING RING. RELEASE THE PRESSURE SLOWLY AFTER THE RETAINING RING IS REMOVED.**


28. Turn the block over. Using a press, apply pressure on the block spring washer (50) to compress the block spring. Compress the spring enough to safely remove the spiral retaining ring (51). While maintaining pressure, unwind the spiral retaining ring (51). Carefully release the pressure and remove the outer block spring washer (50), block spring (52), and inner block spring washer (53) from the cylinder block.

**Inspection**

After disassembly, wash all parts (including the end-cap and housing) thoroughly with clean solvent and allow to air dry. Blow out oil passages in the housing and end-cap with compressed air. Conduct inspection in a clean area and keep all parts free from contamination. Clean and dry parts again after any rework or resurfacing.

**PISTON**

Inspect the pistons for damage and discoloration. Discolored pistons may indicate excessive heat; do not reuse.



**SLIPPERS**

Inspect the running surface of the slippers. Replace any piston assemblies with scored or excessively rounded slipper edges. Measure the slipper foot thickness. Replace any piston assemblies with excessively worn slippers. Check the slipper axial end-play. Replace any piston assemblies with excessive end-play.

Minimum slipper foot thickness and maximum axial end-play are given in the table below.

**CYLINDER BLOCK**

Measure the cylinder block height. Replace blocks worn beyond the minimum height specification. Inspect the running surface of the cylinder block. Replace or resurface worn or scratched blocks. Blocks may be resurfaced


**Table 3-7. Slipper Foot Thickness & End Play**

Measurement		L Frame	K Frame
Slipper Foot Thickness	mm (in.)	2.71 (0.11)	4.07 (0.16)
Piston/Slipper End Play		0.15 (0.006)	

to the specifications shown in the drawing, provided resurfacing will not reduce the block height below the minimum specification. Table 3-8, Cylinder Block Measurements.


**Table 3-8. Cylinder Block Measurements**

Measurement		L25	L30	L35	K38	K45
Minimum Cylinder Block Height (A)	mm (in.)	50.8 (2.00)	50.8 (2.00)	50.8 (2.00)	54.4 (2.14)	54.4 (2.14)
Cylinder Block Surface Flatness		0.002 (0.0000079)	0.002 (0.0000079)	0.002 (0.0000079)	0.002 (0.0000079)	0.002 (0.0000079)




**BALL GUIDE AND SLIPPER RETAINER**

Inspect the ball guide and slipper retainer for damage, discoloration, or excessive wear. A discolored ball guide or slipper retainer indicates excessive heat. Do not reuse.



**VALVE PLATE**


The condition of the valve plate is critical to the efficiency of the motor. Inspect the valve plate surfaces carefully for excessive wear, grooves, or scratches. Replace or resurface grooved or scratched valve plates. Measure the valve plate thickness and replace if worn beyond the minimum specification. Valve plates may be resurfaced to the specifications shown in the drawing, provided resurfacing will not reduce the thickness below the minimum specification.



**SWASHPLATE AND JOURNAL BEARINGS**

Inspect the running face, servo ball-joint, and swashplate journal surfaces for damage or excessive wear. Some material transfer may appear on these surfaces and is acceptable providing the surface condition meets specifications shown. Measure the swashplate thickness from the journals to the running face. Replace swashplate if damaged or worn beyond minimum specifica-


tion. Replace swashplate if the difference in thickness from one side to the other exceeds specification.



Inspect the journal bearings for damage or excessive wear. Replace journal bearings if scratched, warped, or excessively worn. The polymer wear layer must be smooth and intact.

**SHAFT BEARINGS**

Inspect bearings for excessive wear or contamination. Rotate the bearings while feeling for uneven movement. Bearings should spin smoothly and freely. Replace bearings that appear worn or do not rotate smoothly.




**SHAFT**

Inspect the motor shaft. Look for damage or excessive wear on the output and block splines. Inspect the bearing surfaces and sealing surface. Replace shafts with damaged or excessively worn splines, bearing surfaces, or sealing surfaces.


**SERVO PISTON AND MINIMUM ANGLE STOP**

Inspect the minimum angle stop, servo piston head, and servo piston ball-socket for damage or excessive wear. Replace if necessary.



**LOOP FLUSHING SPOOL**


Inspect the loop flushing spool. Check for cracks or damage. Replace if necessary.



**Assembly**

1. Install new O-ring (1) and piston seal (2) to the servo piston (3). Install the piston seal over the O-ring.

Installing the piston seal stretches it, making it difficult to install the servo piston in its bore. Allow 30 minutes for the seal to relax after installation. To speed up seal relaxation, compress the seal by installing the piston head into the servo cavity in the end-cap and let it stand for at least five minutes.



1. O-ring
2. Piston Seal
3. Servo Piston

**Figure 3-15. Servo Piston**


2. After piston seal has relaxed, lubricate and install servo piston into the housing bore. Align the piston with the ball socket facing the inside of the housing.

**⚠ WARNING**

**RISK OF PERSONAL INJURY: COMPRESSING THE BLOCK SPRING REQUIRES ABOUT 80 TO 90 LBF (350 TO 400 N) OF FORCE. USE A PRESS SUFFICIENT TO MAINTAIN THIS FORCE WITH REASONABLE EFFORT. ENSURE THE SPRING IS SECURE BEFORE ATTEMPTING TO INSTALL THE SPIRAL RETAINING RING. RELEASE THE PRESSURE SLOWLY AFTER THE RETAINING RING IS INSTALLED.**

3. Install the inner block spring washer (4), block spring (5), and outer washer (6) into the cylinder block. Using a press, compress the block spring enough to

expose the retaining ring groove. Wind the spiral retaining ring (7) into the groove in the cylinder block.




- |                          |                      |
|--------------------------|----------------------|
| 4. Block Spring Washer   | 9. Holddown Pins     |
| 5. Block Spring          | 10. Ball Guide       |
| 6. Outer Washer          | 11. Piston           |
| 7. Spiral Retaining Ring | 12. Slipper Retainer |
| 8. Retaining Ring        |                      |

**Figure 3-16. Cylinder Kit Assembly**

- Turn the block over and install the retaining ring (8), hold-down pins (9), and ball guide (10) to the cylinder block.
- Install the pistons (11) to the slipper retainer (12). Install the piston/retainer assembly into the cylinder block. Ensure the concave surface of the retainer seats on the ball guide. If you're reusing the pistons, install them to the original block bores. Lubricate the pistons, slippers, retainer, and ball guide before assembly. Set the cylinder kit aside on a clean surface until needed.

- Install the journal bearings (13) into the housing seats. Use assembly grease to keep the bearings seated during assembly. Ensure the locating nubs drop into the cavities in the seats. If you're reusing the bearings, install them in the original location and orientation. Lubricate the journal bearings.




- 13. Journal Bearings
- 14. Swash Plate

**Figure 3-17. Swash Plate and Journal Bearings**

- Install the swashplate (14) into the housing. Tilt the swashplate and guide the servo lever ball into its socket in the servo piston rod. Ensure the swashplate seats into the journal bearings and moves freely. Lubricate the running surface of the swashplate.

- Press front shaft bearing (15) onto shaft (16). Press bearing onto shaft with lettering facing out. Lubricate bearing rollers. Install snap-ring (17) onto shaft.




- 15. Front Shaft Bearing
- 16. Shaft
- 17. Snap Ring
- 18. Snap Ring

**Figure 3-18. Shaft and Front Bearing**

- While holding the swashplate in place, turn the housing on its side. Install the install shaft/bearing assembly into housing from the flange end. Install the snap-ring (18).


- Verify swashplate and bearings are properly seated. Install the cylinder kit (19) onto the shaft. Install with the slippers facing the swashplate. Rock the shaft to align the block splines and slide the cylinder kit into place. Orient the motor with the shaft pointing downward and verify the cylinder kit, swashplate, journal bearings, and servo piston are all secure and properly installed.



19. CylinderKit

**Figure 3-19. Cylinder Kit Installation**

- Lubricate and install the servo spring (20), and minimum angle stop (21) into the housing bore.




- 20. Servo Spring
- 21. Minimum Angle Stop

**Figure 3-20. Servo Spring and Minimum Angle Stop**

- Press the rear shaft bearing (22) into the endcap. Install the bearing with letters facing out. Press until



bearing surface is  $0.08 \pm 0.01$  in ( $2 \pm 0.25$  mm) above endcap surface.




- 22. Rear Shaft Bearing
- 23. Timing Pin
- 24. Valve Plate

**Figure 3-21. Valve Plate and Rear Bearing**

13. Install timing pin (23) into its bore in the endcap. Install the pin with its groove facing toward or away from the shaft. Press the pin until the end protrudes  $0.12 \pm 0.01$  in ( $3 \pm 0.25$  mm) above endcap surface.
14. Install the valve plate (24) onto the endcap. Install the valve plate with the yellow surface toward the cylinder block. Align the slot in the valve plate with the timing pin. Apply a liberal coat of assembly grease to the endcap side of the valve plate to keep it in place during installation.

15. Install the endcap (25) onto the housing with the endcap screws (26). Check to ensure the endcap will properly seat onto the housing without interference. Improper assembly of the internal components may prevent the endcap from seating properly. Ensure the O-rings seat properly when installing the endcap.




- 25. End Cap
- 26. Screw

**Figure 3-22. End Cap**

16. Using an 8 mm internal hex wrench, tighten the endcap screws. Tighten the screws in opposite corners slowly and evenly to compress the servo spring and properly seat the endcap. Torque endcap screws 35-45 lb-ft (47-61 Nm).
17. Before installing the shaft seal, ensure the shaft turns smoothly with less than 120 in.lbs. (13.5 Nm) of force. If the shaft does not turn smoothly within the specified maximum force, disassemble and check the unit.


18. Cover shaft splines with an installation sleeve. Install a new shaft seal (27) with the cup side facing the motor. Press seal into housing until it bottoms out. Press evenly to avoid binding and damaging the seal. Install seal support washer (28) and snap ring (29).



- 27. Shaft Seal
- 28. Seal Support Washer
- 29. Snap Ring


**Figure 3-23. Shaft Seal**

19. Install remaining plugs and fittings to the housing. Refer to the drawing below for wrench sizes and installation torques.



**Figure 3-24. Plugs and Fittings Installation**

20. Install orifice poppet (30).



- |                    |            |            |          |
|--------------------|------------|------------|----------|
| 30. Orifice Poppet | 34. Spring | 37. O-ring | 40. Plug |
| 31. Shift Spool    | 35. Spring | 38. O-ring | 41. Plug |
| 32. Spring         | 36. Spring | 39. O-ring | 42. Plug |
| 33. Spring         |            |            |          |

**Figure 3-25. Loop Flushing Spool**

21. Install shift spool (31).
22. Install spring retaining washers onto springs (32 and 33).
23. Carefully install centering springs (34, 35, and 36).
24. Install new O-rings (37, 38, and 39).
25. Using a 5/8 in wrench torque plug (40) to 20 lb-ft (27 Nm).
26. Using a 11/16 in wrench, torque plugs (41 and 42) to 27 lb-ft (37 Nm).

### Initial Start-Up Procedures


Follow this procedure when starting-up a new motor or when installing a motor that has been removed.

Prior to installing the motor, inspect for damage incurred during shipping. Make certain all system components (reservoir, hoses, valves, fittings, heat exchanger, etc.) are clean prior to filling with fluid.

1. Fill the reservoir with recommended hydraulic fluid. Always filter fluid through a 10 micron filter when pouring into the reservoir. Never reuse hydraulic fluid.
2. Fill the inlet line leading from the pump to the reservoir. Check the inlet line for properly tightened fittings and ensure it is free of restrictions and air leaks.
3. Fill the pump and motor housing with clean hydraulic fluid. Pour filtered oil directly into the upper most case drain port.
4. To ensure the pump and motor stay filled with oil, install case drain lines into the upper most case drain ports.
5. Install a 0 to 500 psi (0 to 35 bar) gauge in the charge pressure gauge port of the pump to monitor system pressure during start up.
6. While watching the pressure gauge, run the engine at the lowest possible speed until system pressure builds to normal levels [minimum 160 psi (11 bar)]. Once system pressure is established, increase to full operating speed. If system pressure is not maintained, shut down the prime mover, determine cause, and take corrective action.
7. Operate the hydraulic system for at least fifteen minutes under light load conditions.
8. Check and adjust control settings as necessary after installation.
9. Shut down the prime mover and remove the pressure gauge. Replace plug at the charge pressure gauge port.
10. Check the fluid level in the reservoir; add clean filtered fluid if necessary. The motor is now ready for operation.

## 3.5 FRONT AXLE

## Front Axle Assembly (Fixed)



- |                      |                         |                           |                    |
|----------------------|-------------------------|---------------------------|--------------------|
| 1. Front Axle        | 5. Pin Keeper and Screw | 8. Stop Block Pad Bracket | 11. Nuts           |
| 2. Pivot Pin         | 6. Stop Block Pad       | 9. Hex Head Screws        | 12. Wear Pad       |
| 3. Pivot Pin Bushing | 7. Stop Block Shims     | 10. Washers               | 13. Wear Pad Shims |
| 4. Thrust Washer     |                         |                           |                    |

## REMOVAL

**⚠ CAUTION**

**SUPPORT THE FRAME AND AXLE BEFORE ATTEMPTING ANY REMOVAL AND/OR ASSEMBLY PROCEDURES.**


1. Disable machine operation. Remove wheel and drive assemblies.
2. Remove the bolt and pin keeper (5).
3. Push the axle pivot pin (1) out and remove the thrust washer (4) and bearings (3).
4. Axle (1) can now be moved away from the frame.

## ASSEMBLY

1. When installing the axle assembly, follow Removal Steps in reverse.
2. Shim both the stop block pad and the wear pad to achieve a maximum gap of 1/16 in. (1.5mm) between the pad and the axle machined surface.

**NOTE:** Apply Loctite® #242 to bolts (5) and bolts (9) attaching stop block pad (6), and wear pad (12).

**Front Axle Assembly (Oscillating)**



- |                      |                         |                                  |                                 |
|----------------------|-------------------------|----------------------------------|---------------------------------|
| 1. Front Axle        | 5. Pin Keeper and Screw | 8. Hex Head Screws               | 11. Spacers                     |
| 2. Pivot Pin         | 6. Wear Pad             | 9. Osc. Axle Tilt Sensor Bracket | 12. Mounting Bolts/Washers/Nuts |
| 3. Pivot Pin Bushing | 7. Wear Pad Shims       | 10. Osc. Axle Tilt Sensor        |                                 |
| 4. Thrust Washer     |                         |                                  |                                 |

**REMOVAL**

**CAUTION**

**SUPPORT THE FRAME AND AXLE BEFORE ATTEMPTING ANY REMOVAL AND/OR ASSEMBLY PROCEDURES.**

1. Disable machine operation. Remove wheel and drive assemblies.
2. Unplug the axle tilt sensor electrical connection.
3. Remove the bolt and pin keeper (5).
4. Push the axle pivot pin (1) out and remove the thrust washer (4) and bearings (3).
5. Axle (1) can now be moved away from the frame.


**ASSEMBLY**

1. When installing the axle assembly, follow Removal Steps in reverse.
2. If removed, shim the wear pad to achieve a maximum gap of 1/16 in. (1.5mm) between the pad and the axle machined surface.

**NOTE:** Apply Loctite® #242 to bolts (8) attaching wear pad (6) to the frame.

- **Oscillating Axle Tilt Sensor - (item 10)** If this sensor is not wired correctly or if you have the wrong part number you will get CANBUS FAILURE - OSCILLATING AXLE TILT SENSOR.

## Steering Assembly



- |                            |                       |                         |
|----------------------------|-----------------------|-------------------------|
| 1. Steer Cylinder Assembly | 6. Cyl. Attach Screws | 11. Hex Flange Bolt     |
| 2. Tie-Rod Link            | 7. Washer             | 12. Tapered Kingpin Pin |
| 3. Pivot Pins              | 8. Spindle Assembly   | 13. Hex Nut             |
| 4. Pin Keeper and Screw    | 9. Bushing Seal       | 14. Thrust Washer       |
| 5. Thrust Washer           | 10. Spindle Bushing   |                         |

**STEER CYLINDER REMOVAL**

1. Disable machine operation and block all wheels. Disconnect, cap and label all hydraulic lines on steer cylinder (1).
2. Remove the screws and pin keeper (4), and pin (3) connecting cylinder rod to tie rod (2). Slide the tie rod out of the cylinder rod, capture the thrust washer (5) on bottom of tie rod.
3. Support steer cylinder. Remove 4 bolts (6) and washers (7) connecting cylinder to axle. Carefully remove cylinder.

**SPINDLE REMOVAL**

4. Remove wheel and drive assembly prior to spindle (8) removal.
5. Disconnect tie rod (2) from spindle by removing screw and pin keeper (4), and pin (3).
6. Support spindle. Remove spindle from axle by removing flange bolts (11), from nuts (13). Remove the 2 tapered king pins (12), from the tapered king-

pin bores on the axle, and thrust washer (14) from lower axle. Remove spindle from axle.


**ASSEMBLY**

1. When assembling steer cylinder and spindle, follow Removal Steps in reverse.

**NOTE:** Apply Loctite® #242 to bolts (4, 6, 11).  
Torque flange bolt (11) to 108 ft. lb. (147 Nm).  
Inspect spindle bushing seals (9), replace if damaged.  
Ensure large thrust washer (14) is installed between spindle (8) and bottom of axle.  
Be certain spindle nut (13) is aligned and seated in the machined groove on the axle before tightening.



## Axle Lockout Cylinder



1. Axle Lockout Cylinder

2. Bolt, M12 x 70mm (CLS 8.8)

3. Washers (12mm) (Hardened)

### REMOVAL

1. Disable machine operation.
2. Disconnect, cap and label hydraulic lines on the axle lockout cylinder (1).
3. Remove the four bolts (2) and washers (3) connecting the cylinder to the frame.
4. Carefully remove cylinder from the frame.

### INSTALLATION

1. Attach cylinder to frame using four bolts (2) and washers (3).

**NOTE:** Make sure the shoulder on the lockout cylinder is firmly against the bottom of the mounting plates on the frame before torquing bolts.

Apply Loctite® #242 and Loctite® Primer #7471 to bolts (2).

Torque bolts to


2. Uncap and reconnect hydraulic lines to cylinder.

**NOTE:** Refer to Section 4.14, Cylinder Assemblies for axle lockout cylinder breakdown and bleeding procedure.

3. Operate axle lockout cylinder function to ensure proper functioning.

## 3.6 LEVELING JACKS

## Cylinder Removal



1. Cover
2. Bolt, M6 x 20 LG
3. Flatwasher
4. Tinnerman Nut
5. Jack Cover Attach Bracket
6. Bolt, M12 x 100 LG
7. Nut/Washer
8. Leveling Jack Cylinder
9. Bolt, M10 x 220 LG
10. Nut/Washer

**REMOVAL**

1. Disable machine operation.
2. Remove the three bolts (2 and 9), flatwashers (3 and 10) and from cover (1). Carefully lift cover up and off of machine.
3. Disconnect, cap and label all hydraulic lines and wires connected to the leveling jack cylinder (8).
4. Support cylinder. Remove the four bolts (6) and nuts and washers (7) attaching cylinder to cylinder mount. Remove jack cover attach bracket (5).
5. Carefully remove cylinder from mount.

**INSTALLATION**


1. Follow Removal Steps in reverse.

**NOTE:** Refer to Figure 4-30., Leveling Jack Cylinder for cylinder breakdown.

2. Operate leveling jacks to ensure proper operation.

## Assembly Removal

**NOTE:** Applies to both front and rear of machine.



1. Leveling Jacks Assembly

2. Hydraulic Lines/Electrical Wiring

3. Bolt - M20 x 90 long

4. Washers (Hardened)

5. Nut - M20 x 2.5 long

6. Doubler Plate

### REMOVAL

#### **⚠ CAUTION**

**SUPPORT THE LEVELING JACKS ASSEMBLY BEFORE ATTEMPTING ANY REMOVAL AND/OR ASSEMBLY PROCEDURES.**

1. Disable machine operation and block all wheels.
2. Remove covers from leveling jack cylinders (refer to Section 3.6).
3. Disconnect, cap and label hydraulic lines (2) connected to leveling jack cylinders. Disconnect and label all electrical wiring attached to cylinder and switches. Remove hoses and wiring from the leveling jack tube assembly.
4. Remove the eight bolts (3), washers (4), nuts (5) and doubler plate (6) through the frame.
5. Carefully lower assembly from the frame.


### INSTALLATION

1. Follow Removal Steps in reverse.

**NOTE:** Mount doubler plate on outside of frame rail.

2. Insert hoses and wiring into the leveling jack tube assembly. Uncap and reconnect hydraulic lines and electrical wires to cylinders and switches.
3. Enable machine and unblock all wheels.
4. Operate leveling jacks to ensure proper operation.

## 3.7 PLATFORM



1. Platform
2. Scissor Arms
3. Slide Block
4. Bolt, (metric) 10 x 200
5. Locknut, (metric) M10 x 1.5
6. Pin
7. Spacer Tube
8. Bolt, 3/8"-16NC x 1 3/8"
9. Locknut
10. Pin Keeper
11. Pin

**⚠ CAUTION**

**NEVER WORK UNDER ELEVATED PLATFORM WITHOUT FIRST PROPERLY SUPPORTING THE PLATFORM AND BRACING/BLOCKING SCISSOR ARM ASSEMBLY.**

**REMOVAL**

1. Disable machine operation.
2. Place lifting straps at each end of the platform (1). Using an overhead crane lift platform.

**NOTE:** Use lifting straps and overhead crane capable of lifting at least 6000 lbs (2722 kg).

3. Disconnect, cap and label hydraulic lines on deck extension cylinders. Disconnect and label all electrical wires going to platform.
4. Detach the center attach link from the platform by removing the bolt (8), locknut (9) pin keeper (10) and pin (11).

5. With scissor arm assembly (2) braced, remove the slide block (3) at each corner of the platform by removing the bolt (4), locknut (5), pin (6) and spacer tube (7).

6. Lift platform away from the machine.


**INSTALLATION**

1. Follow Removal Steps in reverse.

**NOTICE**

**TIGHTEN BOLTS (4) AND LOCKNUTS (5) TO JUST MAKE CONTACT WITH THE SLIDE BLOCKS (3). DO NOT OVERTIGHTEN.**

Platform Control Station



- |                             |                              |   |                         |
|-----------------------------|------------------------------|---|-------------------------|
| 1. Mounting Bracket         | 5. Alarm Speaker             | 9. Select Switch/Guard                    | 13. Engine Start Switch |
| 2. Control Box Plate        | 6. Function Decal            | 10. Stop Switch                           | 14. Horn Switch         |
| 3. Joystick Controller      | 7. LED Indicator             | 11. Fuel Select or Glow Plug Switch/Guard | 15. Blank Plug          |
| 4. Wiring Harness Connector | 8. Leveling Jack Switch/LEDs | 12. Speed Select Switch                   | 16. Blank Plug          |

**DISASSEMBLY**

1. Disconnect the cable from the harness connector (4) on the underside of the platform control station.
2. Remove the control box plate (2) from the mounting bracket (1) by removing the three bolts and washers.
3. Once loaded control box plate is removed, switches, buttons and bulbs can be removed for replacement.
4. Remove the the four screws and nuts to remove the joystick controller (3).
5. The harness can be removed from the box by removing the harness connector terminal nut (4), and disconnecting all the wiring inside the control box.

**ASSEMBLY**

1. Follow Disassembly Procedures in reverse.
  2. Ensure electrical wires are properly and securely attached to switches, buttons and bulbs.
  - 3.
- NOTE:** Ensure wires are not pinched when installing the loaded control box plate back onto the mounting bracket.
4. Reattach wiring cable to harness connector (4) on underside of platform control station.
  5. Mount control station to platform rail.
  6. Operate functions with platform control console to ensure proper operation.

### Joystick Controller




Figure 3-26. Joystick Controller

Table 3-9. Joystick Specifications

Type	Single Axis (Y Axis Only)
Input Voltage	5V
Current Consumption	10mA@ 12VDC
Centered Output Voltage	2.50VDC
Reverse Voltage	4.0VDC
Forward Voltage	1.0VDC

Table 3-10. Joystick Plug Loading Chart

Terminal	Color	Function
1	RED	Handle COM
2	VIOLET	Trigger N.O.
3		Spare
4	YELLOW	Rocker Right
5	GREEN	Rocker Left
6		Spare
7	White/RED	+5VDC
8	White/BLACK	Ground
9	BROWN	SIG Output



## 3.8 SCISSOR ARMS

### Lift Cylinder Removal

#### REMOVAL

#### CAUTION

NEVER WORK UNDER ELEVATED SCISSOR ARMS WITHOUT FIRST PROPERLY BRACING/BLOCKING SCISSOR ARM ASSEMBLY.

1. Remove platform (refer to Section 3.7).
2. Elevate the scissor arm assembly enough to gain access to the upper and lower connection pins. Block/brace scissor arms and disable machine.
3. Disconnect, cap and label all hydraulic lines connected to the lift cylinder. Disconnect and label all electrical wires connected to lift cylinder.
4. Attach lifting straps to overhead crane and lift cylinder and support cylinder before attempting to remove from arm assembly.
5. Remove the cylinder upper pin by removing the bolt, nut and collar. Push pin out.
6. Remove the lower pin by removing the bolt and nut. Push pin out.
7. Carefully lift cylinder up and out of arm assembly.

#### INSTALLATION

1. Follow Removal Steps in reverse.
2. After assembly, operate lift cylinder to ensure proper operation.

**NOTE:** Refer to Figure 4-28., Lift Cylinder for cylinder breakdown.

### Scissor Arms Removal

#### CAUTION

NEVER WORK UNDER ELEVATED SCISSOR ARMS WITHOUT FIRST PROPERLY BRACING/BLOCKING SCISSOR ARM ASSEMBLY.

**NOTE:** Scissor arms can be removed individually or as an entire assembly.

#### ARM REMOVAL

1. Remove platform (refer to Section 3.7) and lift cylinder (refer to Figure 3-28.).
2. Disconnect, cap and label all hydraulic hoses and wiring attached to scissor arms.
3. Support the scissor arm(s) being removed.
4. Remove the pin from the scissor arm by removing the two bolts, nuts and collar.
5. Push pin and bearing out from scissor arms.
6. Repeat at each connecting pin.

#### INSTALLATION

1. Follow Removal Steps in reverse.

### Scissor Arm Assembly Removal

#### CAUTION

NEVER WORK UNDER ELEVATED SCISSOR ARMS WITHOUT FIRST PROPERLY BRACING/BLOCKING SCISSOR ARM ASSEMBLY.


#### REMOVAL

**NOTE:** Applies to all four corners.

1. Remove platform (refer to Section 3.7).
2. Disconnect, cap and label all hydraulic hoses and wiring attached to scissor arms and lift cylinder.
3. Support the scissor arm assembly with appropriate lifting straps and overhead crane.
4. Disconnect the scissor arm assembly from the four sliders by removing the bolts and nuts.
5. Push pins out.
6. Carefully lift arm assembly up and away from chassis.


#### INSTALLATION

Follow Removal Steps in reverse.




**NOTE:** See Figure 3-28. and Figure 3-29. for letter detail views. Route hoses/wiring through wire rod on arm, behind safety prop.

**Figure 3-27. Scissor Arm - Hose and Wiring Routing.**



**NOTE:** Detail H - Do not overtighten safety rod keeper plate, it must rotate freely.  
 Detail A, C, D, F, G, and H - Apply Loctite #242 to threads.

**Figure 3-28. Scissor Arm Component Assembly 1 of 2.**




**NOTE:** Coat all pins (Detail: B, J, K, L, M, and V) with moly paste lubricant (example: Loctite #51049) before assembly.

**Figure 3-29. Scissor Arm Component Assembly 2 of 2.**

### 3.9 SIDE COMPARTMENT COVERS

#### Engine Compartment (Left Side)




- 1. Engine Main Compartment Cover
- 2. Front Engine Door
- 3. Rear Engine Door

- 4. Ladder Assembly
- 5. Door Latch Assembly
- 6. Door Hinge Assembly

- 7. Engine Exhaust Tube
- 8. Generator Shield

Hydraulic/Fuel Compartment (Right Side)



1. Hydraulic/Fuel Main Compartment Cover  
2. Hydraulic Tank Door

3. Fuel Tank Door  
4. Ladder Assembly

5. Door Latch Assembly  
6. Door Hinge Assembly



**Cover Removal**

**NOTE:** Procedures apply to both left and right side compartment hoods.

1. Elevate the platform to a height where, when removed and lifted, the compartment covers clear the underside of the platform. Engage the arm safety prop and/or block the scissor arms to prevent lowering.
2. Disable machine operation.
3. If removing the main compartment cover, the hinged cover and any outer covers/doors must be removed first.
4. Attach lifting straps to each end of the large compartment cover and support with an overhead lifting device.
5. Remove the bolts on the hinges to remove the door from the cover.
6. Remove the bolts and washers, from the front covers or doors, remove and lay aside.
7. Remove the ladder from the support bracket by removing the bolts, washers and nuts.
8. Remove the bolts and washers, from the front, top and back of the large compartment cover.

**NOTE:** On engine side only, remove the exhaust pipe shield from the cover by removing the bolts, washers, and nuts.


9. Carefully lift the main compartment cover up and away from the machine.

**Cover Installation**

1. Follow Removal Steps in reverse.

**3.10 GROUND CONTROL STATION**

**Control Station Removal**



- |                       |                                     |
|-----------------------|-------------------------------------|
| 1. Ground Control Box | 3. Mounting Bolts, Nuts and Washers |
| 2. Control Box Mount  |                                     |


**REMOVAL**

1. Disconnect and label the harnesses from the ground control box (1).
2. Remove the ground control box from the control box mount (2) by removing the four lower and two upper bolts, nuts and washers (3).

**INSTALLATION**

1. Follow Removal Steps in reverse.

## Ground Control Station Components



- 1. Ground Control Box
- 2. Lid
- 3. Circuit Board

- 4. Tilt Sensor
- 5. Control Switches and Buttons
- 6. Machine Harness Connectors

### DISASSEMBLY

1. Disconnect the harnesses from the ground control box (1).
2. Open the lid (2) to gain access to components inside the ground control box.
3. Disconnect any wires and/or plugs from damaged components (3, 4, or 5).
4. Remove and replace components if necessary.


### ASSEMBLY

1. Reattach any wires and/or plugs.
2. Close lid (2) and secure.
3. Reattach machine harnesses to the ground control box (6).

**NOTE:** If tilt sensor or the ground control station box is removed and replaced, the tilt sensor must be calibrated (refer to Section 5.4, Sensor Location and Calibration).

## Options Control Module

The Options Control Module provides additional machine harness connections for additional machine components such as the Leveling Jacks and LSS control system. If determined faulty, this module is only replaceable and not serviceable.




- |                                       |                 |
|---------------------------------------|-----------------|
| 1. Option Control Module              | 6. J2-Connector |
| 2. Ground Control Station             | 7. J3-Connector |
| 3. Station/Module Mounting Plate      | 8. J4-Connector |
| 4. Module Mounting Bolts/Nuts/Washers | 9. J5-Connector |
| 5. J1-Connector                       |                 |

### REMOVAL

1. Tag and Disconnect the wiring harness(s) from the J-Connectors on the module.
2. Remove the four nuts and washers (4) from the mounting bolts.
3. Remove the module from the mounting plate.

### INSTALLATION

1. Mount new module to the mounting plate using the four bolts, nuts and washers (4)
2. Reconnect the J-Connector wiring harness(s).
3. Power up machine and operate functions to check proper operation.

**3.11 BATTERY**

- |                         |                                 |
|-------------------------|---------------------------------|
| 1. Battery              | 4. Bracket, Bolt, Nut & Washers |
| 2. Battery Terminal (-) | 5. Auxiliary Power Block        |
| 3. Battery Terminal (+) |                                 |


**REMOVAL**

1. Disconnect the red battery cable from the positive battery terminal (3).
2. Disconnect the black battery cable from the negative (2) battery terminal.
3. Remove the bolts, nuts, and washers to remove the hold-down bracket (4) securing the battery in place. Remove battery.
4. With the positive battery cable disconnected, if necessary, the auxiliary power block (5) can be removed by first disconnecting the cables from the block. Remove the bolts, washers and nuts securing the block to the machine compartment cover.

**INSTALLATION**

1. Place battery in the seat. Negative battery terminal (2) should be closest to outside of machine.
2. Secure battery in place with the hold-down bracket, bolt, nut and washers (4).
3. Reconnect red battery cable to positive battery terminal (3). Secure terminal cover in place over terminal.
4. Reconnect black battery cable to negative battery terminal (2).
5. If removed, secure auxiliary power block (5) to machine using two bolts, nuts and washers. Reconnect cables.

### 3.12 FUEL TANK



- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. Fuel Tank</li> <li>2. Tank Drain (on bottom of tank)</li> <li>3. Tank Sending Unit</li> </ol> | <ol style="list-style-type: none"> <li>4. Fuel Feed/Return and Vent Lines</li> <li>5. Tank Mounting Bolts/Nuts and Washers</li> </ol> |
|---|---|

#### REMOVAL

**NOTE:** Outer cabinet, ladder and door shown removed for illustrative clarity only.

1. Disable machine operation.
2. Drain fuel from the fuel tank (1, 2). Store fuel in appropriate receptacle.
3. Disconnect and cap the fuel and vent lines (4) attached to the fuel tank.
4. Remove the bolts, washers and nuts (5) from the bottom front and top rear of the fuel tank.
5. Remove the fuel tank from the hydraulic compartment.
6. If necessary, remove the tank sending unit (3) from the tank.

#### INSTALLATION

1. Follow Removal Steps in reverse.

**NOTE:** If removed, reuse or replace sending unit gasket, as necessary. Before reinstalling, apply Loctite #222 to threads of tank sending unit bolts.  
If removed, before reinstalling into tank insert apply pipe sealant (Loctite® #567) to fuel and vent line fittings on the fuel tank (1).  
Apply (Loctite 567 PST thread sealant) to threads of tank aluminum drain plug before installing. Do not over tighten.


2. Refill fuel tank with proper fuel.

#### NOTICE

**ENSURE PROPER FUEL LINES ARE ATTACHED TO PROPER FITTING ON FUEL TANK. FUEL TANK IS LABELED WITH RETURN LINE, SUPPLY LINE AND VENT LINE.**

3. Ensure there is no fuel leakage.

## 3.13 HYDRAULIC TANK



- 1. Hydraulic Tank
- 2. Tank Drain

- 3. Tank Mounting Bolts/Nuts and Washers

**REMOVAL**

**NOTE:** It is recommended to remove the side compartment cover before attempting to remove the hydraulic tank (refer to Section 3.9, Side Compartment Covers).

1. Disable machine operation.
2. Drain hydraulic fluid from hydraulic tank (1) by opening the drain plug (2). Store hydraulic fluid in appropriate receptacle.
3. Disconnect, cap and label all hoses connected to tank.
4. Remove the bolts, washers, and nuts (3) attaching the hydraulic tank to the machine. Remove tank from machine.

**NOTE:** Hydraulic tank has two lifting lugs on the top corners for lifting.  
Empty tank weighs approximately 105 lb (47.6 kg).

**INSTALLATION**


1. Follow Removal Steps in reverse.
2. Ensure drain plug (2) is tight. Refill hydraulic tank (1) with 34 gal (128.7 l) hydraulic fluid.




### 3.14 KUBOTA ENGINE

#### Engine Tray - Swing Out


**NOTE:** When servicing components on the back side of the engine, remove the tray (2) and ladder (3), bolts, nuts and washers to swing the engine tray out for better access (as shown below).



- 1. Tray Pivot Pin
- 2. Tray to Frame - Bolt, Nut and Washer
- 3. Ladder To Cabinet - Bolt, Nut, and Washer



**Generator (If Equipped)**



- 1. Generator
- 2. Belt Tensioner
- 3. Drive Belt

- 4. Drive Pulley
- 5. Upper Bracket Assembly
- 6. Lower Bracket Assembly

**CAUTION**

**ALLOW ENGINE AND COMPONENTS TO COOL DOWN BEFORE SERVICING.**

**REMOVAL**

1. Disable machine operation. Rotate engine tray to access back of engine.
2. Disconnect and label electrical wires attached to generator (1).
3. Remove drive belt tension using the belt tensioner and remove belt from generator pulley.
4. Remove the generator from the engine by removing the two upper bracket (5) bolts, nuts, and washers. And the lower pivot, belt tensioner bolt, nut, and washer.
5. Replace belt if damaged.

**INSTALLATION**

1. Follow Removal Steps in reverse. Ensure belt is tight before securing generator with the bolts.

**NOTE:** Apply Loctite® #242 to the threads of the generator mounting bolts.

**NOTE:** The generator control box is mounted on the rear wall of the Hydraulic/Fuel Tank cabinet just behind the ground control station.


**Table 3-11. AC Generator Specifications**

DESCRIPTION	7500 KW	4500 KW
Voltage	120/240V AC	120/240V AC - 60Hz 110/230V AC - 50Hz
Continuous	7.5 KW - 240V - 3 Phase 6.0 KW - 240V - 1 Phase 6.0 KW - 120V - 1 Phase	4.0 KW - 1 Phase
Peak	8.5 KW - 3 Phase 6.0 KW - 1 Phase	4.0 KW
Amps Peak	18.3 Amps - 3 Phase 26 Amps - 1 Phase 50 Amps - 1 Phase	20 Amps

*The platform junction box is mounted under the platform deck on the Hydraulic/Fuel Tank cabinet side of the machine.*


*See Section 6, Electrical Schematics generator electrical configuration.*

**Exhaust System**



**Dual Fuel - Gas/LPG**

- |              |                     |
|--------------|---------------------|
| 1. Tail Pipe | 5. Gasket           |
| 2. O2 Sensor | 6. Exhaust Pipe     |
| 3. Gasket    | 7. Gasket           |
| 4. Muffler   | 8. Mounting Bracket |



**Diesel**

- |                          |                     |
|--------------------------|---------------------|
| 1. Muffler               | 3. Mounting Bracket |
| 2. Catalyst/Exhaust Pipe |                     |

**DUAL FUEL - GAS/LPG**



**ALLOW ENGINE AND COMPONENTS TO COOL DOWN BEFORE SERVICING.**

**REMOVAL**

1. Disable machine operation.
2. Disconnect the O2 Sensor (2) wiring. Disassemble the tail pipe (1) from the muffler (4) by removing the two attaching bolts, washers, nuts, and gasket.
3. Disassemble the muffler (4) from the exhaust pipe (6) removing by the four attaching bolts, nuts, washers and gasket. Also remove the two bolts and washers attaching the muffler to the mounting bracket (8).
4. Disconnect the O2 Sensor (2) wiring. Disassemble the exhaust pipe (6) from the engine exhaust manifold by removing the four bolts, nuts, washers and gasket at the exhaust manifold.

**INSTALLATION**

1. Follow Removal Steps in reverse.

**NOTE:** Torque on O2 Sensors is 32 ft. lb. (44 Nm).

**DIESEL**



**ALLOW ENGINE AND COMPONENTS TO COOL DOWN BEFORE SERVICING.**


**REMOVAL**

1. Disable machine operation.
2. Disassemble the muffler (1) from the Catalyst/Exhaust Pipe (3), by removing the four bolts, nuts, washers, and gasket (2).
3. Unbolt the muffler (1) from the mounting bracket (5) by removing the bolts, nuts, and washers from the rubber isolating mounts.
4. Disassemble the Catalyst/Exhaust Pipe (3) from the exhaust manifold by removing the four bolts, washers, and gasket (4) attaching it to the manifold.

**INSTALLATION**

1. Follow Removal Steps in reverse.

## Air Cleaner System



Dual Fuel - Gas/LPG

- |                      |                |
|----------------------|----------------|
| 1. Inlet Hose        | 5. Intake Pipe |
| 2. Clamp             | 6. Clamp       |
| 3. Air Cleaner Assy. | 7. 90° Elbow   |
| 4. Clamp             | 8. Clamp       |

## DUAL FUEL - GAS/LPG

**⚠ CAUTION**

ALLOW ENGINE AND COMPONENTS TO COOL DOWN BEFORE SERVICING.


## REMOVAL

1. Disable machine operation. If necessary, swing engine tray out for better access to components.
2. Loosen the clamp (4) and (8) attaching the intake pipe to the air cleaner assembly (3) and engine intake manifold. Disconnect the intake pipe from the air cleaner assembly and remove the complete intake pipe from the engine assembly.
3. To remove the air cleaner assembly (3) from the air cleaner bracket clamp, Unscrew the main clamp screw on the clamp until the air cleaner is loose in the bracket. Release the latches on the end and remove the end cap from the air cleaner assembly. Slide the air cleaner assembly with inlet hose out of the bracket clamp.

**NOTE:** The filter element can be removed from the air cleaner by releasing the latches on the end of the air cleaner. Replace filter element as needed. See Section 1.8, Service Maintenance,

## INSTALLATION

1. Follow Removal Steps in reverse.



Diesel

- |                      |                |
|----------------------|----------------|
| 1. Inlet Hose        | 5. Intake Pipe |
| 2. Clamp             | 6. Clamp       |
| 3. Air Cleaner Assy. |                |
| 4. Clamp             |                |

## DIESEL

**⚠ CAUTION**

ALLOW ENGINE AND COMPONENTS TO COOL DOWN BEFORE SERVICING.

## REMOVAL


1. Disable machine operation. If necessary, swing engine tray out for better access to components.
2. Loosen the clamp (4) and (6) attaching the intake pipe to the air cleaner assembly (3) and engine intake manifold. Disconnect the intake pipe from the air cleaner assembly and remove the complete intake pipe from the engine assembly.
3. To remove the air cleaner assembly (3) from the air cleaner bracket clamp, Unscrew the main clamp screw on the clamp until the air cleaner is loose in the bracket. Release the latches on the end and remove the end cap from the air cleaner assembly. Slide the air cleaner assembly with inlet hose out of the bracket clamp.

**NOTE:** The filter element can be removed from the air cleaner by releasing the latches on the end of the air cleaner. Replace filter element as needed. See Section 1.8, Service Maintenance,

## INSTALLATION

1. Follow Removal Steps in reverse.

## Radiator



- |                                 |                              |
|---------------------------------|------------------------------|
| 1. Radiator Mounting Plate      | 4. Fan Shroud Assembly       |
| 2. Mounting Plate Lower Support | 5. Engine Tray               |
| 3. Radiator Assembly            | 6. Radiator Petcock Location |

### **⚠ WARNING**

**ALLOW RADIATOR TO COOL DOWN BEFORE SERVICING.**

#### REMOVAL

1. Disable machine operation. Swing engine tray out for better access to components.
2. Drain the coolant from the radiator into a suitable container by opening the petcock (6) on the bottom left corner of the radiator.
3. Disconnect the:
  - upper and lower radiator hoses from the radiator.
  - if necessary remove the air cleaner or disconnect the intake pipe hose connector at the radiator mounting plate
4. Support the radiator mounting plate assembly (1) and remove the four large bolts holding the mounting plate to the engine swivel tray (4), and the lower support bracket (2)
5. Re-check that all connections, hoses, etc. are disconnected and remove complete radiator mounting plate (1) assembly from the engine tray.

6. Disassemble the radiator shroud (3), and radiator assembly (2) from the radiator mounting plate assembly (1).

#### INSTALLATION

1. Follow Removal Steps in reverse.

**NOTE:** Refill with fresh clean coolant properly balanced.



Engine Electrical Component Locations




Figure 3-30. Dual Fuel Engine - Control Module Location




Figure 3-31. Dual Fuel Engine Compartment - Electrical Component Locations







Figure 3-32. Diesel Engine Compartment - Electrical Component Locations (T4F and CE)

## Hydraulic Pumps



1. Gear Pump
2. O-Ring
3. Axial Hi 45 Pump
4. Pump Coupling


**NOTE:** This gear pump applies to all machines equipped with a diesel engine and machines equipped with a dual fuel engine prior to SN E200000368.

### ⚠ CAUTION

**ALLOW ENGINE AND COMPONENTS TO COOL DOWN BEFORE SERVICING.**

#### REMOVAL

1. Disable machine operation. Disconnect, cap and label all hydraulic hoses connected to pumps (1, 3). Disconnect and label all wiring connected to pumps.
2. Remove the two bolts and washers attaching the gear pump (1) to the axial pump (3). Carefully remove the gear pump.
3. Remove and discard the o-ring (2).
4. Remove the two bolts and washers attaching the axial pump (3) to the coupling (4) of the motor. Carefully remove the axial pump.



1. Gear Pump
2. O-Ring
3. Axial Hi 45 Pump
4. Pump Coupling

**NOTE:** This gear pump applies to machines equipped with a dual fuel engine from SN E200000369 to E200000675 and 1200027648 through 1200027657

#### INSTALLATION

1. Follow Removal Steps in reverse.

**NOTE:** Apply grease to internal splines of pump coupling (1) and external splines of axial pump (5) shaft prior to installing pump.


Install a new o-ring (2) during installation.

Apply Loctite® #242 to bolts.

Torque mounting bolts to 50 ft. lbs. (70 Nm)

**NOTE:** Refer to Section 4.10, Gear Pump and Section 4.11, Axial HI 45 Pump for more information on pumps.

## Pump Coupling Assembly



- 1. Coupler Housing
- 2. Pump Coupler

- 3. Engine Flywheel/Coupler Mounting Plate
- 4. Starter Bolts

### **⚠ CAUTION**

**ALLOW ENGINE AND COMPONENTS TO COOL DOWN BEFORE SERVICING.**

#### **REMOVAL**


1. Disable machine operation. Disconnect the battery positive (+) terminal.
2. Remove exhaust system and pump assemblies, as necessary.
3. Remove the five bolts, washers and nuts, plus the two starter bolts holding the coupler housing (1) to the engine block plate. Support starter, do not hang by electrical wiring. Remove the coupler housing (1).
4. Remove the five pump coupler bolts to remove the pump coupling from the engine flywheel/mounting plate (3). Remove coupling plate (2).

#### **INSTALLATION**

1. Follow Removal Steps in reverse.

**NOTE:** Apply Loctite® #242 to bolts.  
Torque coupling to flywheel bolts to 50 lb-ft (68 Nm).

## Engine Removal



1. Kubota Engine
2. Engine Lifting Lugs
3. Left/Right Side Engine Mounting Brackets

4. Engine Isolator Mount
5. Swinging Engine Tray

### **CAUTION**

**ALLOW ENGINE AND COMPONENTS TO COOL DOWN BEFORE SERVICING.**

#### REMOVAL

1. Disable machine operation. Disconnect battery positive (+) terminal. Swing engine tray (5) out for access to both sides of engine.
2. Remove platform ladder and brackets, exhaust system, air cleaner system, hydraulic pumps and radiator cooling system, as necessary.
3. Disconnect, cap and label all hoses connected to engine (1). Disconnect and label all electrical wiring connected to engine.
4. Using the lifting lugs (2) at the front and rear corners of the engine, support engine (1) with lifting device capable of lifting 500 lbs (227 kg) (refer to engine manual for proper lifting information).

5. Remove the four large bolts, nuts, and washers securing the left/right side engine mounting brackets (3) to the isolator mounts (4) and tray.
6. Slowly lift the engine up and out of the engine compartment.

### **NOTICE**

**IF NOT REMOVED, BE CAREFUL NOT TO DAMAGE THE RADIATOR FAN ON THE RADIATOR HOUSING WHEN LIFTING THE ENGINE.**

#### INSTALLATION

1. Follow Removal Steps in reverse.

**NOTE:** Apply Loctite® #242 to the engine mount bolts.

### 3.15 DUAL FUEL/LPG SYSTEM

#### **⚠ CAUTION**

IT IS POSSIBLE TO SWITCH FROM ONE FUEL SOURCE TO THE OTHER WITHOUT ALLOWING THE ENGINE TO STOP. THE FOLLOWING INSTRUCTIONS MUST BE FOLLOWED.

#### Changing From Gasoline to LP Gas

**NOTE:** Before climbing onto the platform, open hand valve on LP gas supply tank by turning valve counterclockwise.

1. Start engine from platform control station.
2. While engine is operating, place the dual fuel switch at platform control station to the LPG position. Allow engine to operate, without load, until engine begins to "stumble" from lack of gasoline. At this time the machine is allowing the LP fuel to be sent to the fuel regulator.

#### Changing From LP Gas to Gasoline

1. With engine operating on LP under a no-load condition, throw LPG/GASOLINE switch at platform control station to GASOLINE position.
2. If engine "stumbles" because of lack of gasoline, place switch to LPG position until engine regains smoothness, then return switch to GASOLINE position.
3. Close hand valve on LP gas supply by turning clockwise.

#### Using Liquid Petroleum (LP) Gas

#### **⚠ WARNING**

CLOSE FUEL VALVE ON TANK WHEN PARKING SCISSOR LIFT MORE THAN MOMENTARILY.

WHEN REFUELING LPG POWERED SCISSOR LIFTS, ALWAYS FOLLOW MANUFACTURERS SPECIFICATIONS AND/OR APPLICABLE REGULATIONS.

1. If machine is to be left overnight or longer, it must be parked outside or the LPG tank removed and stored outside.
2. LPG is extremely flammable. No smoking.
3. Only trained and authorized personnel are permitted to operate filling equipment.
4. Fill LPG tanks outdoors. Stay at least 50 ft (15 m) from buildings, motor vehicles, electrical equipment or other ignition sources. Stay at least 15 ft (5 m) from LPG storage tanks.
5. During transfer of LPG, metal components can become very cold. Always wear gloves when refilling or changing tanks to prevent "freeze burns" to skin.

6. Do not store LPG tanks near heat or open flame. For complete instructions on the storage of LPG fuels, refer to ANSI/NFPA 58 & 505 or applicable standards.

#### **⚠ WARNING**

DO NOT USE AN LPG TANK THAT IS DAMAGED. A DAMAGED TANK MUST BE REMOVED FROM SERVICE. FROST ON THE SURFACE OF A TANK, VALVES, OR FITTINGS INDICATES LEAKAGE. A STRONG ODOR OF LPG FUEL CAN INDICATE A LEAK.

#### Propane Fuel System Pressure Relief

#### **⚠ CAUTION**

THE PROPANE FUEL SYSTEM OPERATES AT PRESSURES UP TO 312 PSI (21.5 BAR). TO MINIMIZE THE RISK OF FIRE AND PERSONAL INJURY, RELIEVE THE PROPANE FUEL SYSTEM PRESSURE (WHERE APPLICABLE) BEFORE SERVICING THE PROPANE FUEL SYSTEM COMPONENTS.

To relieve propane fuel system pressure:

1. Close the manual shut-off valve on the propane fuel tank.
2. Start and run the vehicle until the engine stalls.
3. Turn the ignition switch OFF.

#### **⚠ CAUTION**

RESIDUAL VAPOR PRESSURE WILL BE PRESENT IN THE FUEL SYSTEM. ENSURE THE WORK AREA IS WELL VENTILATED BEFORE DISCONNECTING ANY FUEL LINE.

#### Propane Fuel System Leak Test

#### **⚠ CAUTION**

NEVER USE AN OPEN FLAME OF ANY TYPE TO CHECK FOR PROPANE FUEL SYSTEM LEAKS.

Always inspect the propane fuel system for leaks after performing service. Check for leaks at the fittings of the serviced or replaced component. Use a commercially available liquid leak detector or an electronic leak detector. When using both methods, use the electronic leak detector first to avoid contamination by the liquid leak detector.





## SECTION 4. HYDRAULICS

### 4.1 CYLINDERS - THEORY OF OPERATION

Cylinders are of the double acting type. The steer system incorporates a double acting cylinder. A double acting cylinder is one that requires oil flow to operate the cylinder rod in both directions. Directing oil (by actuating the corresponding control valve to the piston side of the cylinder) forces the piston to travel toward the rod end of the barrel, extending the cylinder rod (piston attached to rod). When the oil flow is stopped, movement of the rod will stop. By directing oil to the rod side of the cylinder, the piston will be forced in the opposite direction and the cylinder rod will retract.

**NOTE:** *The lift cylinder is a single acting cylinder which takes hydraulic pressure to extend and gravity to retract.*

A holding valve is used in the lift circuit to prevent retraction of the cylinder rod should a hydraulic line rupture or a leak develop between the cylinder and its related control valve.

### 4.2 VALVES - THEORY OF OPERATION

#### Solenoid Control Valves (Bang-Bang)

Control valves used are four-way three-position solenoid valves of the sliding spool design. When a circuit is activated and the control valve solenoid energizes, the spool is shifted and the corresponding work port opens to permit oil flow to the component in the selected circuit, with the opposite work port opening to reservoir. Once the circuit is deactivated (control returned to neutral), the valve spool returns to neutral (center) and oil flow is then directed through the valve body and returns to reservoir. A typical control valve consists of the valve body, sliding spool, and two solenoid assemblies. The spool is machine fitted in the bore of the valve body. Lands on the spool divide the bore into various chambers, which, when the spool is shifted, align with corresponding ports in the valve body open to common flow. At the same time other ports would be blocked to flow. The spool is spring-loaded to center position, therefore when the control is released, the spool automatically returns to neutral, prohibiting any flow through the circuit.

#### Relief Valves

Main relief valves are installed at various points within the hydraulic system to protect associated systems and components against excessive pressure. Excessive pressure can be developed when a cylinder reaches its limit of travel and the flow of pressurized fluid continues from the system control. The relief valve provides an

alternate path for the continuing flow from the pump, thus preventing rupture of the cylinder, hydraulic line or fitting. Complete failure of the system pump is also avoided by relieving circuit pressure. The relief valve is installed in the circuit between the pump outlet (pressure line) and the cylinder of the circuit, generally as an integral part of the system valve bank. Relief pressures are set slightly higher than the load requirement, with the valve diverting excess pump delivery back to the reservoir when operating pressure of the component is reached.

#### Crossover Relief Valves

Crossover relief valves are used in circuits where the actuator requires an operating pressure lower than that supplied to the system. When the circuit is activated and the required pressure at the actuator is developed, the crossover relief diverts excess pump flow to the reservoir. Individual, integral relief's are provided for each side of the circuit.

### 4.3 CYLINDER CHECKING PROCEDURE

**NOTE:** *Cylinder check must be performed anytime a system component is replaced or when improper system operation is suspected.*

#### Cylinders Without Counterbalance Valves

1. Using all applicable safety precautions, activate engine and fully extend cylinder to be checked. Shut down engine.
2. Carefully disconnect hydraulic hoses from retract port of cylinder. There will be some initial weeping of hydraulic fluid which can be caught in a suitable container. After the initial discharge, there should be no further drainage from the retract port.
3. Activate engine and extend cylinder.
4. If cylinder retract port leakage is less than 6-8 drops per minute, carefully reconnect hose to port and retract cylinder. If leakage continues at a rate of 6-8 drops per minute or more, cylinder repair must be made.
5. With cylinder fully retracted, shut down engine and carefully disconnect hydraulic hose from cylinder extend port.
6. Activate engine and retract cylinder. Check extend port for leakage.
7. If extend port leakage is less than 6-8 drops per minute, carefully reconnect hose to extend port, than activate cylinder through one complete cycle and check for leaks. If leakage continues at a rate of 6-8

drops per minute or more, cylinder repairs must be made.

### Cylinders With Single Counterbalance Valve

#### **NOTICE**

OPERATE ALL FUNCTIONS FROM GROUND CONTROL STATION ONLY.

1. Using all applicable safety precautions, activate hydraulic system.
2. Shut down hydraulic system and allow machine to sit for 10-15 minutes. If machine is equipped with bang-bang or proportional control valves, turn ignition switch to on, move control switch or lever for applicable cylinder in each direction, then turn ignition switch to off. If machine is equipped with hydraulic control valves, move control lever for applicable cylinder in each direction. This is done to relieve pressure in the hydraulic lines.  
Carefully remove hydraulic hoses from appropriate cylinder port block.
3. There will be initial weeping of hydraulic fluid, which can be caught in a suitable container. After the initial discharge, there should be no further leakage from the ports. If leakage continues at a rate of 6-8 drops per minute or more, the counterbalance valve is defective and must be replaced.
4. To check piston seals, carefully remove the counterbalance valve from the retract port. After initial discharge, there should be no further leakage from the ports. If leakage occurs at a rate of 6-8 drops per minute or more, the piston seals are defective and must be replaced.
5. If no repairs are necessary or when repairs have been made, replace counterbalance valve and carefully connect hydraulic hoses to cylinder port block.
6. If used, remove lifting device supporting platform or release and stow safety prop, activate hydraulic system and run cylinder through one complete cycle to check for leaks.

### 4.4 OSCILLATING AXLE - LOCKOUT CYLINDER TEST (IF EQUIPPED)

#### **NOTICE**

LOCKOUT CYLINDER SYSTEM TEST MUST BE PERFORMED QUARTERLY, ANY TIME A SYSTEM COMPONENT IS REPLACED, OR WHEN IMPROPER SYSTEM OPERATION IS SUSPECTED.

**NOTE:** Ensure platform is fully lowered prior to beginning lockout cylinder test, and that the surface used to approach the ramp is flat and level.

#### Left Side Wheel Test

1. Place a 4 inch (10.16 cm) high block with ascension ramp in front of left wheel of the oscillating axle.
2. From platform control station, select LOW drive speed.
3. Set the DRIVE control switch into position and carefully drive the machine up ascension ramp until left oscillating axle wheel is on top of block.
4. Verify the axle oscillates to maintain contact with the ground/ramp. (All four wheels on the ground).
5. Raise machine platform above stowed position approximately 32 ft (9.75 m) on the 530LRT.
6. Carefully drive the machine back off the block and ramp.
7. Have an assistant check to see that the left oscillating axle wheel that was on the block is in position on the ground. The axle should oscillate so that all four wheels maintain contact with the ground.
8. In the current position (platform raised and all four tires on flat and level surface), carefully drive machine up the ramp block again.
9. Have an assistant check to verify that the axle did not oscillate and remained locked (one wheel is off of the ground).
10. Carefully drive the machine back off the block and ramp.
11. Lower the machine platform; the lockout cylinder should then release and allow wheel to rest on the ground. It may be necessary to activate DRIVE to release cylinders.
12. If the lockout cylinders do not function properly, have qualified personnel correct the malfunction prior to any further operation.

## Right Side Wheel Test

1. Place a 4 inch (10.16 cm) high block with ascension ramp in front of right wheel of the oscillating axle.
2. From platform control station, select LOW drive speed.
3. Set the DRIVE control switch into position and carefully drive the machine up ascension ramp until right oscillating axle wheel is on top of block.
4. Verify the axle oscillates to maintain contact with the ground/ramp. (All four wheels on the ground).
5. Raise machine platform above stowed position approximately 32 ft (9.75 m) on the 530LRT.
6. Carefully drive the machine back off the block and ramp.
7. Have an assistant check to see that the right oscillating axle wheel that was on the block is in position on the ground. The axle should oscillate so that all four wheels maintain contact with the ground.
8. In the current position (platform raised and all four tires on flat and level surface), carefully drive machine up the ramp block again.
9. Have an assistant check to verify that the axle did not oscillate and remained locked (one wheel is off of the ground).
10. Carefully drive the machine back off the block and ramp.
11. Lower the machine platform; the lockout cylinder should then release and allow the axle to oscillate. It may be necessary to activate DRIVE to release cylinders.
12. If the lockout cylinders do not function properly, have qualified personnel correct the malfunction prior to any further operation.

## 4.5 DRIVE PUMP START-UP PROCEDURE

### NOTICE

**THE FOLLOWING PROCEDURE SHOULD ALWAYS BE PERFORMED WHEN STARTING A NEW PUMP OR WHEN RESTARTING AN INSTALLATION IN WHICH EITHER THE PUMP OR MOTOR HAVE BEEN REMOVED FROM THE SYSTEM.**

**THE FOLLOWING PROCEDURE SHOULD ALWAYS BE PERFORMED WHEN STARTING A NEW PUMP OR WHEN RESTARTING AN INSTALLATION IN WHICH EITHER THE PUMP OR MOTOR HAVE BEEN REMOVED FROM THE SYSTEM.**

**THE FOLLOWING PROCEDURE MAY REQUIRE THE MACHINE TO BE DISABLED (WHEELS RAISED OFF THE GROUND, DRIVE FUNCTION DISCONNECTED, ETC.) WHILE PERFORMING THE PROCEDURE IN ORDER TO PREVENT INJURY TO TECHNICIAN AND OTHER PERSONNEL. TAKE NECESSARY SAFETY PRECAUTIONS BEFORE MOVING THE MACHINE.**

Prior to installing pump and/or motor, inspect unit(s) for damage incurred during shipping and handling. Make certain all system components (reservoir, hoses, valves, fittings, heat exchanger, etc.) are clean prior to filling with hydraulic fluid.

Fill reservoir with recommended hydraulic fluid, which should be passed through a 10 micron (nominal, no bypass) filter prior to entering the reservoir. The use of contaminated fluid will cause damage to components, which may result in unexpected machine movement.

The inlet line leading from the reservoir to the pump should be filled prior to start-up. Check inlet line for properly tightened fittings and make sure it is free of restrictions and air leaks.

Be certain to fill pump and/or motor housing with clean hydraulic fluid prior to start-up. Fill housing by pouring filtered oil into upper case drain port.

Install a 0 to 500 psi (0 to 35 bar) pressure gauge in the charge pressure gauge port to monitor charge pressure during start-up.

It is recommended that the external control input signal electrical connections be disconnected at the pump control until after initial start-up. This will allow the pump to remain in its neutral position.

“Jog” or slowly rotate prime mover until charge pressure starts to rise. Start prime mover and run at the lowest possible RPM until charge pressure has been established. Excess air may be bled from high pressure lines through high pressure gauge ports.

### **⚠ WARNING**

**DO NOT START PRIME MOVER UNLESS PUMP IS IN NEUTRAL POSITION (0 DEGREES SWASHPLATE ANGLE). TAKE PRECAUTIONS TO PREVENT MACHINE MOVEMENT IN CASE PUMP IS ACTUATED DURING INITIAL START-UP.**

Once charge pressure has been established, increase speed to normal operating RPM. Charge pressure should be approximately 220 psi (15.5 bar) minimum. If charge pressure is incorrect, shut down and determine cause for improper pressure.

### **⚠ WARNING**

**INADEQUATE CHARGE PRESSURE WILL AFFECT THE OPERATOR'S ABILITY TO CONTROL THE MACHINE.**

Shut down prime mover and connect external control input signal. Start prime mover, checking to ensure pump remains in neutral. With prime mover at normal operating speed, slowly check for forward and reverse machine operation.

Charge pressure should remain at 220 psi to 240 psi (15.5 bar to 16.9 bar) minimum during forward or reverse operation. Continue to cycle slowly between forward and reverse for at least five minutes.

Shut down prime mover, remove gauges, and plug ports. Check reservoir level and add fluid if necessary.

## 4.6 HYDRAULIC COMPONENT START-UP PROCEDURES & RECOMMENDATIONS

From a hydrostatic component standpoint, the goal at system start up is to put into functional operation, the hydrostatic system in such a way as to preserve the designed life span of the system. The following start-up procedure should be adhered to whenever a new pump or motor is initially installed into a machine, or a system is restarted after either a pump or motor has been removed and/or replaced.

### **⚠ WARNING**

**THE FOLLOWING PROCEDURE MAY REQUIRE THE MACHINE TO BE DISABLED (WHEELS RAISED OFF THE GROUND, WORK FUNCTIONS DISCONNECTED, ETC.) WHILE PERFORMING THE PROCEDURE IN ORDER TO PREVENT INJURY. TAKE NECESSARY SAFETY PRECAUTIONS BEFORE MOVING THE VEHICLE/MACHINE.**

Prior to installing the pump and/or motor, inspect the unit(s) for damage that may have been incurred during shipping and handling. Ensure all system components (reservoir, hoses, valves, fittings, heat exchanger, etc.) are clean prior to filling with fluid.

Fill the reservoir with recommended hydraulic fluid. This fluid should be passed through a 10 micron (nominal, no bypass) filter prior to entering the reservoir. The use of contaminated fluid will cause damage to the components, which may result in unexpected vehicle/machine movement.

**NOTE:** *If a pump or motor is being replaced due to internal damage, the remaining units (pump or motors) need to be inspected for damage and contamination, and the entire hydraulic system will need to be flushed and the fluid replaced. Failure to do so may cause considerable damage to the entire system.*

The inlet line leading from the reservoir to the pump must be filled prior to start-up. Check the inlet line for property tightened fittings and make sure it is free of restrictions and air leaks.

**NOTE:** *In most cases, the reservoir is above the pump inlet so that the pressure head created by the higher oil level helps to keep the inlet pressures within an acceptable range and prevent high vacuum levels. However, due to hose routing or low reservoir locations, there may be air trapped within this line. It is important to ensure that the air is bled from this line. This can be accomplished by loosening the hose at the fitting closest to the pump. When oil begins to flow, the line is full, the air has been purged, and the fitting can be retightened to its specified torque. If the tank needs to be pressurized in order to start the flow of oil, a vacuum reading should be taken at the inlet of the pump during operation in order to verify*

that the pump is not being asked to draw an inlet vacuum higher than it is capable of.

Be certain to fill the pump and/or motor housing with clean hydraulic fluid prior to start up. Fill the housing by pouring filtered oil into the upper case drain port.

**NOTE:** *It is highly recommended to use the highest possible case drain port, this ensures that the housing contains as much oil as possible and offers the greatest amount of lubrication to the internal components.*

*In initial start-up conditions, it may be convenient to fill the housing, just prior to installing the case drain line. Component, (especially motor), location may be such that access to the case drain port after installation is not realistic.*

*Make certain that the oil being used to fill the component housing is as clean as possible. Store the fill container in such a way as to prevent it from becoming contaminated.*

Install a 60 bar (or 1000 psi) pressure gauge in the charge pressure gauge port in order to monitor the charge pressure during start-up.

It is recommended that the external control input signal, (electrical connections for EDC), be disconnected at the pump control until after initial start-up. This will ensure that the pump remains in its neutral position.

### **⚠ WARNING**

**DO NOT START THE ENGINE UNLESS PUMP IS IN THE NEUTRAL POSITION (0 DEGREES SWASHPLATE ANGLE). TAKE PRECAUTIONS TO PREVENT MACHINE MOVEMENT IN CASE PUMP IS ACTUATED DURING INITIAL START-UP.**

"Jog" or slowly rotate the engine until charge pressure starts to rise. Start the engine and run at the lowest possible RPM until charge pressure has been established. Excess air should be bled from the system lines as close to the motors as possible.

**NOTE:** *With the engine on low idle, "crack", (loosen-don't remove), the system lines at the motor(s). Continue to run the engine at low idle and tighten the system lines as soon as oil is observed to leak from them. When oil is observed to "leak" at the motor, the line is full, the air has been purged, and the system hoses should be retightened to their specified torque.*

Once charge pressure has been established, increase speed to normal operating RPM. Charge pressure should be as indicated in the pump model code. If charge pressure is inadequate, shut down and determine the cause for improper pressure.

### **⚠ WARNING**

**INADEQUATE CHARGE PRESSURE WILL AFFECT THE OPERATOR'S ABILITY TO CONTROL THE MACHINE.**

Shut down the engine and connect the external control input signal. Also reconnect the machine function(s), if disconnected earlier. Start the engine, checking to be certain the pump remains in neutral. With the engine at normal operating RPM, slowly check for forward and reverse machine operation.


Charge pressure may slightly decrease during forward or reverse operation. Continue to cycle slowly between forward and reverse for at least five minutes.

Shut down engine, remove gauges, and plug ports. Check reservoir level and add filtered fluid if needed.

The machine is now ready for operation.



4.7 HYDRAULIC VALVES



- |                        |  |
|------------------------|--|
| 1. Main Valve          | 4. Oscillating Axle Lock-Out Valve (If Equipped) |
| 2. Flow Divider Valve  | 5. Hydraulic Tank                                |
| 3. Leveling Jack Valve |  |

Figure 4-1. Hydraulic Compartment Control Valves

**REMOVAL:**

1. Disconnect, cap and label all hydraulic hoses and any electrical harness connected to valves.
2. Remove the valve blocks from the hydraulic tray by removing the attaching bolts.

**INSTALLATION:**

1. Re-attach valve blocks to tray with bolts.
2. Re-connect all hydraulic lines and electrical harness.



Main Hydraulic Valve




Figure 4-2. Main Valve Port Identification  
See Table 4-2 on page 4-8

**Table 4-1. Main Valve Port Identification**

*See Figure 4-2. on page 4-7*

Port	Functionality	To Port
L1	To Lift Cylinder	Lift Cylinder
L2	To Lift Cylinder	Lift Cylinder
T4	Main RT Valve (Left Side)	T - Outrigger Valve
P1	Main RT Valve (Left Side)	Outlet - Tandem Gear Pump
S1	Main RT Valve (Left Side)	Steer Cylinder
S2	Main RT Valve (Left Side)	Steer Cylinder
G	Main RT Valve (Left Side) (Tee at Port)	P - Axle Lockout Valve M3 - Axial Pump
2S2	Main RT Valve (Left Side)	Union Tee
T2	Main RT Valve (Left Side)	Return to Tank
T3	Main RT Valve (Right Side)	12 - Flow Divider
P2	Main RT Valve (Right Side)	LP - Leveling Jack Valve
PS	Main RT Valve (Right Side)	Outlet - Tandem Gear Pump
MS	Main RT Valve (Right Side)	Diagnostic Port
MP1	Main RT Valve (Right Side)	Diagnostic Port

**Table 4-2. Main Valve Torque Specs**

*See Figure 4-2. on page 4-7*

Component	Functionality	Torque
CV3	Lift Cylinders Tank Port Check Valve	40 - 45 ft. lb.
EC1	Lift Cylinders Pressure Compensator Valve	30 ft. lb.
LS1	Steer Cylinder Shuttle Valve	19 - 21 ft. lb.
RV1	Lift Circuit Relief Valve	40 - 45 ft. lb.
RV2	Manifold Relief Valve	40 - 45 ft. lb.
RV3	Steer Cylinder Relief Valve	19 - 21 ft. lb.
RV4	Steer Pump Relief Valve	40 - 45 ft. lb.
SP1	Lift Down Proportional Valve	45 ft. lb.
SV1	Lift Up Valve	24 - 26 ft. lb.
SV2	Steer Valve	25 ft. lb.
SV3	Motors 2 Speed Control	40 ft. lb.
SV4	Hydraulic Brakes	40 ft. lb.
SV7	Lift Pump Unloader Valve (Dump)	35 - 40 ft. lb.

**Table 4-3. Main Valve Porting Specs**

Port	Size
L2, P1 & T1	SAE 10
L1	SAE 08
G, T4 & T2	SAE 06
All Others	SAE 04

**NOTE:** For internal hydraulic circuits, refer to Section 6.7, Hydraulic Schematics.

Flow Divider Valve




Figure 4-3. Flow Divider Valve

Leveling Jack Directional Valve





Figure 4-4. Leveling Jack Directional Valve

**NOTE:** For valve torque specs see Table 4-4 on page 4-11.  
For internal hydraulic circuits, refer to Section 6.7, Hydraulic Schematics.

**Table 4-4. Leveling Jack Directional Valve Torque Specs**  
 See Figure 4-4. on page 4-10

Component	Functionality	Torque
S1	Leveling Jack Cylinders Retract Valve	18.5 - 22 ft. lb. (25-30 Nm)
S2	Leveling Jack Cylinders Extend Tank Valve	28 - 33 ft. lb. (38-45 Nm)
S3	Leveling Jack Cylinders Extend Pressure Valve	7.75 ft. lb. (10.5 Nm)
	Leveling Jack Cylinders Thermal Relief	18.5 - 22 ft. lb. (25-30 Nm)
Coils S1-3		3 - 4.5 ft. lb. (4 Nm)

**Leveling Jack Valves**



**NOTE:** Applies to all four Leveling Jacks.

**Figure 4-5. Leveling Jack Valves**

**Table 4-5. Leveling Jack Valves Torque Specs**

Item	Torque
1	3 to 4.5 lb-ft (4.1 to 6.1 Nm)
2	18.5 to 22 lb-ft (25.1 to 29.8 Nm)
3	40 lb-ft (54.2 Nm)
4	32 lb-ft (43.4 Nm)

### Pressure Relief Valve - Setting Procedures

Cold temperatures have a significant impact on pressure readings. JLG Industries Inc. recommends operating the machine until the hydraulic system has warmed to normal operating temperatures prior to checking pressures. JLG Industries Inc. also recommends the use of a calibrated gauge. Pressure readings are acceptable if they are within  $\pm 5\%$  of specified pressures.

For main valve port identification, refer to Figure 4-2.

#### 1. Main Relief

- a. Locate the lift up solenoid valve (SV1). It is the middle solenoid on the main valve assembly.
- b. Remove the coil nut and coil from the cartridge. Do not remove the wire out of the coil plug.
- c. Install a pressure gauge, 3000 PSI or higher, at port MP1, located on the same face as the relief valves.
- d. Start the engine and activate lift up. The gauge should read 3000 PSI.
- e. The main relief (RV2) is located on the same face as port MP1, and is the top relief cartridge. Adjust clockwise to increase, counter-clockwise to decrease.
- f. Re-install the coil onto the lift up solenoid valve (SV1) and torque coil nut to 5 ft-lbs.

#### 2. Lift Up Relief Valve

- a. Install a pressure gauge, 3000 PSI or higher, at port MP1, located on the same face as the relief valves.
- b. Start the engine, activate lift up until the platform is fully extended, or remove the hose at port L1 of the main control valve and cap and plug. The gauge should read 2700 PSI.
- c. The lift up relief (RV1) is located on the same face as port MP1, and is second relief valve from the top. Adjust clockwise to increase, counter-clockwise to decrease.

#### 3. Steer Work Port Relief Valve

- a. Install a pressure gauge, 3000 PSI or higher, at port MS, located on the same face as the relief valves.
- b. Start the engine and activate steer right or left. The gauge should read 2500 PSI.
- c. The steer work port relief (RV3) is located on the same face as port MP1, and is the lowest relief valve. Adjust clockwise to increase, counter-clockwise to decrease.  
This one relief valve takes care of both right and left.

#### 4. Leveling Jack Retract Relief Valve;

- a. Install a pressure gauge, 3000 PSI or higher, at port MP1 of the main control valve.
- b. Start the engine and activate the auto level function, then proceed to full extension by using the rocker switch "trim" function.
- c. Next, fully retract leveling jacks. Repeat this cycle four more times to bleed all air from circuit.
- d. When the jacks are all retracted the gauge should read 2000 PSI.
- e. The relief valve is located on the jack valve, the same face as the solenoid valves. Adjust clockwise to increase, counter-clockwise to decrease.



## 4.8 GEAR PUMPS

### Gear Pump Priming


The gear pump is mounted with the suction hose up. Air trapped in this area can cause an air lock on start up. during this period, the pump is running dry, which can cause gear wear, which affects the volumetric efficiency of the pump.

To prime the pump:

1. Fill the hydraulic tank to the full mark.
2. Using a 2" wrench, loosen the suction hose fitting at the gear pump. The hose fitting does not need to be removed, just loosened enough to let the air escape.

When oil leaks at the hose end, re-torque the hose end to 115 lb-ft ( Nm). The pump is primed and the machine is ready to start.

### All Diesel Engines/Dual Fuel Engines Prior to SN E200000368




1. Inlet Port from Hydraulic Tank, 1-15/16-12 SAE STD THD - SAE #16 ORB

2. Outlet Ports, 7/8-14 SAE STD THD - SAE #10 ORB

Rotation (Viewing Drive End)		Clockwise
Displacement	Front:	14.4 cc/rev 13.3 GPM
	Rear:	3.9 cc/rev 3.6 GPM
Max Rated Speed (with max. fluid viscosity of 50mm <sup>2</sup> /sec.)		3500 rpm
Rated Pressure		3045 psi (210 bar)
Minimum Speed at Rated Pressure		1000 rev/min

**Dual Fuel Engines (SN E200000369 through E200000675)**


**NOTE:** This gear pump may also apply to machines equipped with a dual fuel engine with SN 1200027648 through 1200030222.



1. Inlet Port from Hydraulic Tank, 1-5/16-12 SAE STD THD - SAE #16 ORB      2. Outlet Ports, 7/8-14 SAE STD THD - SAE #10 ORB

Rotation (Viewing Drive End)		Clockwise
Displacement	Front:	8.4 cc/rev 8.9 GPM
	Rear:	2.62 cc/rev 2.77 GPM
Max Rated Speed (with max. fluid viscosity of 50mm <sup>2</sup> /sec)		4000 rpm
Rated Pressure		3046 psi (210 bar)
Minimum Speed at Rated Pressure		1000 rev/min

4.9 AXIAL HI 45 PUMP



- 1. Case Drain Port L2 (SAE#12)
- 2. Deutsch DT04-2P Connector
- 3. M5 Servo Gage Port (SAE#4)
- 4. Charge Pressure Filtration Port (from outlet on filter)
- 5. Charge Pressure Filtration Port (to inlet on filter)
- 6. MB Gage Port (SAE#6)
- 7. M3 Charge Gage Port (SAE#6)
- 8. M14 Gage Port (SAE#4)
- 9. Port A (SAE#16)
- 10. Charge Pump Suction Port (SAE#16)
- 11. Port B (SAE#16)
- 12. Case Drain Port L1 (SAE#12)


Figure 4-6. Axial HI 45 Pump

Table 4-6. Axial HI 45 Pump Specs

Rotation	Clockwise
Max Pressure	6525 psi (450 bar)
Displacement	2.75 in <sup>3</sup> (45 cm <sup>3</sup> )
Control Current	755 mA Threshold 1640 mA Max Displacement

Table 4-6. Axial HI 45 Pump Specs

12 CC Charge Pump Pressure	348 psi (24 bar)
Max Operating Speed	3500 rpm



- |                                  |                       |                  |
|----------------------------------|-----------------------|------------------|
| 1. Electric Displacement Control | 6. Shaft              | 11. Charge Pump  |
| 2. Swashplate Feedback Pin       | 7. Front Bearing      | 12. Rear Bearing |
| 3. Piston                        | 8. Swashplate Bearing | 13. Valve Plate  |
| 4. Slipper                       | 9. Swashplate         | 14. Servo Piston |
| 5. Shaft Seal                    | 10. Cylinder Block    |                  |

Figure 4-7. Axial HI 45 Pump - Cross Section View

## General Repair Instructions

### REMOVAL:

#### **⚠ CAUTION**

**PRIOR TO PERFORMING REPAIRS, REMOVE THE UNIT FROM THE MACHINE. CHOCK WHEELS ON THE MACHINE TO INHIBIT MOVEMENT. BE AWARE THAT HYDRAULIC FLUID MAY BE UNDER HIGH PRESSURE AND/OR HOT. INSPECT THE OUTSIDE OF THE PUMP AND FITTINGS FOR DAMAGE. CAP HOSES AFTER REMOVAL TO PREVENT CONTAMINATION.**

### KEEP IT CLEAN

Clean the outside of the pump thoroughly before disassembly. Take care not to contaminate system ports. Clean parts using a clean solvent wash and air dry.

#### **NOTICE**

**AS WITH ANY PRECISION EQUIPMENT, YOU MUST KEEP ALL PARTS FREE OF FOREIGN MATERIAL AND CHEMICALS. PROTECT ALL EXPOSED SEALING SURFACES AND CAVITIES FROM DAMAGE AND FOREIGN MATERIAL. IF LEFT UNATTENDED, COVER THE PUMP WITH A PROTECTIVE LAYER OF PLASTIC.**

### REPLACE ALL O-RINGS & GASKETS

Replace all o-rings and seals during service. Lightly lubricate o-rings with clean petroleum jelly prior to assembly.

### SECURE THE UNIT

Place the unit in a stable position with the shaft pointing downward. It will be necessary to secure the pump while removing and torquing fasteners and components.

#### **NOTICE**

**PERFORMING MINOR REPAIRS ACCORDING TO THIS SECTION WILL NOT AFFECT THE PUMP'S WARRANTY. MAJOR REPAIRS REQUIRING THE REMOVAL OF THE UNIT'S CENTER SECTION, SERVO SLEEVES, OR FRONT FLANGE VOIDS WARRANTY.**

## Start-Up Procedure

Follow this procedure when starting-up a new pump installation or when restarting an installation in which the pump has been removed and re-installed on the machine. Ensure pump has been thoroughly tested on a test stand before installing on a machine.

These pumps should never be dry started. The time it takes for the charge pump to create a vacuum to draw in the fluid, send it out through the charge pump filter and then back in to the pump may take 30-40 seconds. During this time the surface between the cylinder barrel and valve plate are running dry. This can affect the volumetric efficiency of the pump and cause premature failure of the pump. Pre-filling the case also reduces the time it takes for the pump to create a vacuum to draw fluid into the pump.

#### **⚠ WARNING**

**TO PROTECT AGAINST UNINTENDED MOVEMENT, SECURE THE MACHINE OR DISABLE/DISCONNECT THE MECHANISM WHILE SERVICING.**

**NOTE:** *Prior to installing the pump, inspect for damage that may have occurred during shipping.*

1. Ensure that the machine hydraulic oil and system components (reservoir, hoses, valves, fittings, and heat exchanger) are clean and free of any foreign material.
2. Install new system filter element(s) if necessary. Check that inlet line fittings are properly tightened and there are no air leaks.
3. Install the pump. Install a 1000 psi (50 bar) gauge in the charge pressure gauge port M3.
4. Fill the housing by adding filtered oil in the upper case drain port. If the control is installed on top, open the construction plug in the top of the control to assist in air bleed.
5. Fill the reservoir with hydraulic fluid of the recommended type and viscosity. Use a 10-micron filler filter. Fill inlet line from reservoir to pump. Ensure construction plug in control is closed after filling.
6. Disconnect the pump from all control input signals.
7. Close construction plug removed in step 4.

### NOTICE

**AFTER START-UP, THE FLUID LEVEL IN THE RESERVOIR MAY DROP DUE TO SYSTEM COMPONENTS FILLING. DAMAGE TO HYDRAULIC COMPONENTS MAY OCCUR IF THE FLUID SUPPLY RUNS OUT. ENSURE RESERVOIR REMAINS FULL OF FLUID DURING START-UP.**

**AIR ENTRAPMENT IN OIL UNDER HIGH PRESSURE MAY DAMAGE HYDRAULIC COMPONENTS. CHECK CAREFULLY FOR INLET LINE LEAKS. DO NOT RUN AT MAXIMUM PRESSURE UNTIL SYSTEM IS FREE OF AIR AND FLUID HAS BEEN THOROUGHLY FILTERED.**

8. Disable the engine to prevent it from starting. Crank the starter for several seconds. Do not exceed the engine manufacturer's recommendation. Wait 30 seconds and then crank the engine a second time as stated above. This operation helps remove air from the system lines. Refill the reservoir to recommended full oil level.
9. When the gauge begins to register charge pressure, enable and start engine. Let the engine run for a minimum of 30 seconds at low idle to allow the air to work itself out of the system. Check for leaks at all line connections and listen for cavitation. Check for proper fluid level in reservoir.
10. When adequate charge pressure is established (as shown in model code), increase engine speed to normal operating rpm to further purge residual air from the system.
11. Shut off engine. Connect pump control signal. Start engine, checking to be certain pump remains in neutral. Run engine at normal operating speed and carefully check for forward and reverse control operation.
12. Continue to cycle between forward and reverse for at least five minutes to bleed all air and flush system contaminants out of loop.

**NOTE:** Normal charge pressure fluctuation may occur during forward and reverse operation.

13. Check that the reservoir is full. Remove charge pressure gauge. The pump is now ready for operation.

### Removing the pump

### NOTICE

**CONTAMINATION CAN DAMAGE INTERNAL COMPONENTS AND VOID THE MANUFACTURER'S WARRANTY.**

**TAKE PRECAUTIONS TO ENSURE SYSTEM CLEANLINESS WHEN REMOVING AND INSTALLING SYSTEM LINES.**

#### DISASSEMBLY:

1. With the prime mover off, thoroughly clean all dirt and grime from the outside of the pump.
2. Tag, disconnect, and cap each hydraulic line connected to the pump. As hydraulic lines are discon-

nected, plug each open port, to ensure that dirt and contamination do not get into the pump.

3. Remove the pump and its auxiliary pump (if applicable) as a single unit.

**NOTE:** Be careful, do not damage solenoids and electrical connections when using straps or chains to support the pump.

#### INSPECTION:


1. Ensure the work surface and surrounding area are clean and free of contaminants such as dirt and grime.
2. Inspect the system for contamination.
3. Look at the hydraulic fluid for signs of system contamination, oil discoloration, foam in the oil, sludge, or metal particles.

#### REASSEMBLY:

1. Before replacing the pump, replace all filters and drain the hydraulic system. Flush the system lines and fill the reservoir with the correct, filtered hydraulic fluid.
2. Fill the pump with clean, filtered hydraulic fluid.
3. Attach the pump to the prime mover. Torque mounting screws according to the manufacturers recommendation.
4. Replace all hydraulic lines. Ensure the charge inlet line is filled with fluid.



## Electric Control Module

**REMOVAL:**

1. Using a 5 mm internal hex wrench, remove the six cap screws (D250).
2. Remove the control module and gasket (D150). Discard the gasket.
3. If necessary, remove orifices (F100) using a 3 mm internal hex wrench. Tag and number them for reinstallation.

**INSPECTION:**

1. Inspect the machined surfaces on the control and top of the pump. If you find any nicks or scratches, replace the component.

**REASSEMBLY:**

**NOTE:** Ensure you install dowel pins (D300) in housing before installing control.

1. Install a new gasket (D150).
2. If you removed screen (D084), install a new one. Install with the mesh facing outward (see drawing).
3. If previously removed, install orifices (F100) using a 3 mm internal hex wrench. Torque to 1.8 lb-ft (2.5 Nm).
4. Install the control module and six cap screws (D250).
5. Using a 5 mm internal hex wrench, torque the cap screws (D250) to 10 lb-ft (13.5 Nm).

**Control Solenoids****REMOVAL:**

1. Disconnect electrical connection and remove the three cap screws (D050) using a 4 mm internal hex wrench.
2. Remove the solenoid (D025) and O-ring (D025A). Discard the O-ring.
3. If necessary, remove the coil using a 12 point 26 mm socket.

**INSPECTION:**

1. Inspect the machined surface on the control. If you find any nicks or scratches, replace the component.

**REASSEMBLY:**


1. Lubricate new O-ring (D025A) using petroleum jelly and install.
2. Install solenoid with three cap screws (D050) using a 4 mm internal hex wrench. Torque screws to 5 Nm (4 lb-ft).
3. Install coil using a 12 point 26 mm socket. Torque coil nut to 3.7 lb-ft (5 Nm).
4. Reconnect electrical connections and test the pump for proper operation.

## Shaft Seal, Roller Bearing & Shaft Replacement

**NOTE:** The shaft assembly is serviceable without disassembling the pump. Orient the pump on the work surface so the shaft is pointing to the side.

### REMOVAL:

1. Unwind the spiral ring (J300) from the housing to release the shaft/seal/bearing subassembly.
2. Pry on the lip of the seal carrier (J275) to dislodge it from the pump. Remove the seal carrier. Remove and discard O-ring (J260). Press the seal (J250) out of the carrier and discard.
3. Pull the shaft (J100) with bearing (J150) out of the pump. If necessary, tap lightly on the shaft to dislodge it from the cylinder block.
4. Remove the retaining ring (J200) using retaining ring pliers. Press the bearing off the shaft.




### INSPECTION:

1. Inspect the shaft journals for wear, scratching, and pits. Check the splines for fretting; replace if damaged. Rotate the bearing, if it does not rotate smoothly, replace it.

### REASSEMBLY:

1. Press the bearing (J150) onto the shaft (J100) and replace the retaining ring (J200). Ensure the retaining ring diameter is less than 1.53 in (38.84 mm) when installed on the shaft.
2. Install the shaft/bearing assembly into the pump.
3. Lubricate and install a new O-ring (J260) onto seal carrier (J275). Press a new seal (J250) into the seal carrier. Press the seal until it is flush within 0.005 in

(+0.12mm ) or 0.0028 in (-0.72 mm) of the inside lip of the carrier: see illustration.



4. Cover the shaft with a protective sleeve while installing the seal carrier. Hand press the seal carrier into the housing. Ensure the seal carrier clears the spiral ring groove in the housing. Remove the protective sleeve.
5. Wind the spiral ring into the housing. Ensure the inside diameter of the spiral ring is greater than 2.677 in (68 mm) after installation.

## Charge Pump

If the pump has an auxiliary pump attached, remove the auxiliary pump and connecting shaft before removing the auxiliary pad.

### REMOVAL:

1. Position pump so end cover or auxiliary pad is on top.
2. If necessary, remove auxiliary pump (not shown), or shipping cover (K300) and pad seal (K250) as shown on following page.
3. Remove end cover/auxiliary pad screws (K400) using a 10 mm internal hex wrench.

**NOTE:** Alignment pins (G450) are in end cover. They may dislodge during disassembly.

4. Remove and discard gasket (K150).
5. Remove thrust washer (K500). Note thrust washer orientation.
6. Use a small hook to remove pressure balance plate (S200) and seal (S300). Note plate orientation. Discard seal.
7. Remove coupling (K200). Use a small hook if necessary.
8. Remove the charge pump outer ring (S150), and gearset (S100).
9. Remove valve plate (S250) with seal (S300). Discard seal



### INSPECTION:

1. Inspect the components for wear, scratches or pitting. Carefully inspect the valve and pressure-balance plates. Scratches on these components will

cause a loss of charge pressure. If any component shows signs of wear, scratching or pitting, replace it.

**REASSEMBLY:**

1. Install new seals (S300) in the valve (S250) and pressure-balance (S200) plates.
2. Install valve plate (S250) in the same orientation as removed.
3. Lubricate and install charge pump (S100) and outer ring (S150).
4. Install charge pump coupling (K200).
5. Install pressure balance plate (S200) in the same orientation as removed.
6. Install the thrust washer (K500). Coated side goes toward charge pump coupling (K200).
7. Install a new cover gasket. (K150). If removed, install guide pins (K450).
8. Install the auxiliary pad or charge pump cover and cap screws. Using a 10mm internal hex wrench, torque the cap screws (K400) to 68 lb-ft (92 Nm). Torque in sequence below.
9. Reinstall auxiliary pump or pad seal (K250) and shipping cover (K300).



Cover Screw K350

Cover Pad	Wrench Size; Torque
A	17 mm; 35 lb-ft (48 Nm)
B, C	19 mm; 58 lb-ft (77 Nm)

### Charge Check/HPRV

**REMOVAL:**


1. Using a 22 mm hex wrench, remove the HPRVs (L100/L200). Remove and discard the O-rings (L060) and backup rings (L068).

**INSPECTION:**

1. Inspect the sealing surfaces in the pump for nicks or scratches. Check the valves for damage. Replace any damaged components.

**REASSEMBLY:**

1. Lubricate and install new backup rings (L068) and O-rings (L060).
2. Install HPRVs. Torque to the value in the illustration below.
3. Operate the machine through full range of controls to ensure proper operation. Check for leaks.



### Charge Pressure Relief Valve

Replace the charge pressure relief valve (V10) as a complete unit. Do not attempt to repair the internal components of the valve. Torque to 38 lb-ft (52 Nm).

**REMOVAL:**


1. Using a 22 mm wrench, remove the charge pressure relief valve (V10). Discard seal (V024).

**INSPECTION:**

1. Inspect the sealing surfaces of the pump for nicks or scratches.

**REASSEMBLY:**

1. Lubricate and install new seal (V024).
2. Install the charge pressure relief valve. Torque to 38 lb-ft (52 Nm).
3. Operate machine through full range of controls to ensure proper operation.



## Pressure Limiter Valve Replacement

**NOTE:** Replace the pressure limiter valve as a complete unit. Do not attempt to repair individual components.

### REMOVAL:


- Using a 14 mm wrench, remove the pressure limiter valves (L300/L400). Discard O-rings.

### INSPECTION:


- Inspect the sealing surfaces of the pump for nicks or scratches.

### REASSEMBLY:

- Install new O-ring. Lubricate O-ring with petroleum jelly.
- Replace pressure limiter valves. Torque to 22 lb-ft (30 Nm).
- Operate pump at full range of controls to ensure proper machine operation.



## 4.10 CHARGE PUMP FILTER



- |                                    |  |
|------------------------------------|--|
| 1. Mounting Bracket                | 5. Inlet Hose from Port F (Out) - Axial Pump   |
| 2. Filter to Bracket Bolts/Washers | 6. Outlet Hose to Port E (Return) - Axial Pump |
| 3. Filter Assembly                 | 7. Rear Wall of Engine Compartment             |
| 4. Filter Bowl                     |  |

**Figure 4-8. Charge Pump Filter**

### REMOVAL:

- Disconnect and cap the hydraulic lines (5 and 6) on the filter assembly (3).
- Remove the four mounting bolts/washers (2) on top to remove the filter assembly from the bracket.

### INSTALLATION:

- Attach filter assembly (3) to mounting bracket (1) using the four mounting bolts (2).
- Uncap and reconnect the hydraulic lines (5 and 6) to the filter.

**NOTE:** If removed and reinstalled, filter bowl torque is 30 ft. lb. (40 Nm).

### 4.11 CYLINDER REPAIR

**NOTE:** The following are general procedures that apply to all cylinders on this machine. Procedures that apply to a specific cylinder will be so noted.

#### Disassembly

**NOTICE**


**DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.**

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

**WARNING**


**DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.**

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. If applicable, remove the cartridge-type holding valve and fittings from the cylinder port block. Discard o-rings.




**Figure 4-9. Lift Cylinder Holding Valve and Fitting Removal**

4. Place the cylinder barrel into a suitable holding fixture.



**Figure 4-10. Cylinder Barrel Support**




**Figure 4-11. Lift Cylinder Cap Screw Removal**

**NOTE:** Steps 6 and 7 apply only to the steer cylinder.

5. Using a spanner wrench, loosen the spanner nut retainer, and remove spanner nut from cylinder barrel.
6. Being careful not to mar the surface of the rod, use a punch or wooden dowel and hammer to drive the rod guide about one inch down into the cylinder bore. Using a screw driver, carefully push one end of the round retaining ring back towards the inside of the cylinder and then slip the screwdriver tip under that end. Pull the ring out of the groove toward the wall mouth. Once one end of the retaining ring is free from the groove, the remainder can be easily pried free using ones fingers or pliers.






- Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

### NOTICE

**EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.**

- With the barrel securely clamped, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.




**Figure 4-12. Cylinder Rod Support**

- Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.

**NOTE:** Step 11 applies only to the steer cylinder.

- Loosen and remove the nut which attaches the piston to the rod, and remove the piston.
- Loosen and remove the cap screw(s), if applicable, which attach the tapered bushing to the piston.
- Insert the cap screw(s) in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the cap screw(s) until the bushing is loose on the piston.

- Remove the bushing from the piston.



**Figure 4-13. Tapered Bushing Removal**

- Screw the piston counter-clockwise, by hand, and remove the piston from cylinder rod.
- Remove and discard the piston o-rings, seal rings, and backup rings.
- Remove piston spacer, if applicable, from the rod.
- Remove the rod from the holding fixture. Remove the cylinder head gland and retainer plate, if applicable. Discard the o-rings, back-up rings, rod seals, and wiper seals.


### Cleaning and Inspection

- Clean all parts thoroughly in an approved cleaning solvent.
- Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
- Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
- Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
- Inspect threaded portion of barrel for damage. Dress threads as necessary.
- Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
- Inspect threaded portion of piston for damage. Dress threads as necessary.
- Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
- Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.

## SECTION 4 - HYDRAULICS

10. Inspect threaded portion of head for damage. Dress threads as necessary.
11. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
12. Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
13. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
  - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
  - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
  - c. Lubricate inside of steel bushing with WD40 prior to bearing installation.
  - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

**NOTE:** Install pin into the Gar-Max bearing dry. Lubrication is not required with nickel plated pins and bearings.



**Figure 4-14. Bushing Installation**


14. Inspect travel limiting collar or spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
15. If applicable, inspect port block fittings and holding valve. Replace as necessary.
16. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
17. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

### Assembly

**NOTE:** Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




**Figure 4-15. Rod Seal Installation**

### NOTICE


**WHEN INSTALLING 'POLY-PAK' PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO WIPER SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.**

**WHEN INSTALLING THE WIPER SEAL ON THE LOWER (TOWER) LIFT CYLINDER, APPLY LOCTITE® #609 ON THE WIPER SEAL IN THREE EVENLY SPACED PLACES TO AID IN RETENTION OF THE SEAL.**

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland-groove.




**Figure 4-16. Poly-Pak Piston Seal Installation**



**Figure 4-17. Wiper Seal Installation**


- Place a new "o"ring and back-up seal in the applicable outside diameter groove of the cylinder head.



**Figure 4-18. Installation of Head Seal Kit**

- Install washer ring onto rod. Carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
- Carefully slide the piston spacer on the rod.
- If applicable, correctly place new o-ring in the inner piston diameter groove. (The backup ring side facing the O-ring is grooved.)
- If applicable, correctly place new seals and guide lock rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal.)

**NOTE:** The backup rings for the solid seal have a radius on one side. This side faces the solid seal. [See magnified insert in (See Figure 4-19.)] The split of seals and backup rings must be positioned so as not to be in alignment with each other.




**Figure 4-19. Piston Seal Kit Installation**

- Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
- Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and back-up rings are not damaged or dislodged.
- Thread piston onto rod until it abuts the spacer end and install the tapered bushing.


**NOTE:** When installing the tapered bushing, piston and mating end of rod must be free of oil.

- Assemble the tapered bushing loosely into the piston and insert JLG capscrews (not vendor capscrews) through the drilled holes in the bushing and into the tapped holes in the piston.



**Figure 4-20. Tapered Bushing Installation**

5. Tighten the capscrews evenly and progressively in rotation to the specified torque value.
6. After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows;
  - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
  - b. Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




**Figure 4-21. Seating the Tapered Bearing**

7. Re-torque the capscrews evenly and progressively in rotation to the specified torque value.
8. Remove the cylinder rod from the holding fixture.
9. Place new guide locks and seals in the applicable outside diameter grooves of the cylinder piston. (See Figure 4-19.)
10. Position the cylinder barrel in a suitable holding fixture.

**NOTICE**

**EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.**

11. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and seal ring are not damaged or dislodged.
12. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.
13. Secure the cylinder head gland using the washer ring and socket head bolts.



**Figure 4-22. Rod Assembly Installation**

14. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.
15. If applicable, install the cartridge-type holding valve and fittings in the rod port block, using new o-rings as applicable. (See Table 4-7, Holding Valve Torque Specifications).
16. Push the piston onto the rod until it abuts the spacer end and install the attaching nut.

**WARNING**

**WHEN REBUILDING THE CYLINDERS, APPLY LOCTITE® #242 TO PISTON NUT AND SETSCREW, THEN TORQUE PISTON NUT.**

**NOTE:** The Steer Cylinder uses snap rings to secure piston.

**Table 4-7. Holding Valve Torque Specifications**

Description	Torque Value
Sun - 7/8 hex M20 x 1.5 thds	30 - 35 lb-ft (41 - 48 Nm)
Sun - 1-1/8 hex 1 - 14 UNS thds	45 - 50 lb-ft (61 - 68 Nm)

**Table 4-7. Holding Valve Torque Specifications**

Description	Torque Value
Sun - 1-1/4 hex M36 x 2 thds	150-153 lb-ft (204-207 Nm)
Racine - 1-1/8 hex 1-1/16 - 12 thds	50-55 lb-ft (68-75 Nm)
Racine - 1-3/8 hex 1-3/16 - 12 thds	75-80 lb-ft (102-109 Nm)
Racine - 1-7/8 hex 1-5/8 - 12 thds	100-110 lb-ft (136-149 Nm)


17. Prior to setscrew installation spot drill rod before installing the setscrew(s) which secure the piston attaching nut to the diameter groove.
18. Remove the cylinder rod from the holding fixture.
19. Position the cylinder barrel in a suitable holding fixture.

**NOTICE**

**EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.**

20. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and seal ring are not damaged or dislodged.
21. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.
22. If applicable, secure the cylinder head retainer using a suitable chain wrench.
23. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.
24. If applicable, install the cartridge-type holding valve and fittings in the port block using new o-rings as applicable. Refer to Table 4-7, Holding Valve Torque Specifications.

4.12 CYLINDER ASSEMBLIES




- 1. Barrel
- 2. Rod
- 3. Head - Torque to 434 ft.lb. (588 Nm)
- 4. Wiper
- 5. Rod Seal
- 6. Back-up Ring
- 7. Dry Bearing
- 8. O-Ring
- 9. O-Ring
- 10. Piston Seal

Figure 4-23. Steer Cylinder




NOTE: SEE SCISSORS ARMS ASSEMBLY FOR CARTRIDGE VALVES LOCATED IN VALVE BLOCK. DO NOT PUT CYLINDER INTO SERVICE WITHOUT CARTRIDGE VALVES INSTALLED.



- 1. Barrel
- 2. Rod
- 3. Head - Torque to 332 ft. lb. (450 Nm)
- 4. Piston - Torque to 1003 ft. lb. (1360 Nm)
- 5. Screw - Torque to 7 ft. lb. (10 Nm)
- 6. Bearing
- 101. Wear Ring
- 102. O-Ring
- 103. Back-up Ring
- 104. Rod Seal
- 105. O-Ring
- 106. Wiper Ring
- 107. Wear Ring
- 108. Piston Seal
- 109. O-Ring
- 110. Back-Up Ring


Figure 4-24. Lift Cylinder (Lower)



NOTE: SEE SCISSORS ARMS ASSEMBLY FOR CARTRIDGE VALVES LOCATED IN VALVE BLOCK. DO NOT PUT CYLINDER INTO SERVICE WITHOUT CARTRIDGE VALVES INSTALLED.


- 1. Barrel
- 2. Rod
- 3. Head - Torque to 332 ft. lb. (450 Nm)
- 4. Piston - Torque to 575 ft. lb. (780 Nm)
- 5. Screw - Torque to 4 ft. lb. (5 Nm)
- 6. Bearing
- 7. LSS Transducers (If Equipped)
- 101. Wear Ring
- 102. O-Ring
- 103. Back-up Ring
- 104. Rod Seal
- 105. O-Ring
- 106. Wiper Ring
- 107. Wear Ring
- 108. Piston Seal
- 109. O-Ring
- 110. Back-Up Ring

Figure 4-25. Lift Cylinder (Upper)



Item	Torque
1	100 lb-ft (135.6 Nm)
2	100 lb-ft (135.6 Nm)
3	25 lb-ft (33.9 Nm)
4	10 - 12 lb-ft (13.6 - 16.3 Nm)
5	35 lb-ft (47.5 Nm)
6	5 lb-ft (6.8 Nm)
7	30 lb-ft (40.7 Nm)
8	33-37 lb-ft (33.9 Nm)
9	40 lb-ft (54.2 Nm)
10	40 lb-ft (54.2 Nm)
11	40 lb-ft (54.2 Nm)
12	60 lb-ft (81.3 Nm)

Figure 4-26. Lift Cylinder Valve Cartridge Torque Values




- 1. Barrel
- 2. Rod
- 3. Wiper Seal
- 4. Wear Ring
- 5. Rod Seal
- 6. Wear Ring
- 7. CounterBalance Valve
- 8. Bleeder Valve
- 9. Pilot Port
- 10. Valve Port

**NOTE:** Torque item #7 to 22 lb-ft (30 Nm)

**⚠ WARNING**

THE CYLINDER ROD CAN SLIDE OUT OF THE CYLINDER IF THE BLEEDER VALVE IS LOOSENED.

Figure 4-27. Oscillating Axle Cylinder




- 1. Head
- 2. Barrel
- 3. Rod
- 4. Jack Plate
- 5. Ring, Lock
- 6. Ring, Wear
- 7. Ring, Washer
- 8. Ring, Retaining
- 9. O-Ring
- 10. Screw
- 11. Capscrew
- 12. Seal
- 13. Wiper
- 14. Ring, Back-Up
- 15. T-Seal
- 16. Jack Pad

Figure 4-27. Leveling Jack Cylinder

**NOTE:** Apply a light coat of grease to the Cylinder Rod (3) before installing the Jack Pad (16).

Apply Loctite® #242 to Capscrews (11) and torque to 30 lb-ft ( 40.7 Nm).




Item	Description	Torque
1	Solenoid Directional Valve	40 lb-ft (54.2 Nm)
2	Straight Fitting	32 lb-ft (43.4 Nm)
3	Straight Fitting	40 lb-ft (54.2 Nm)

Figure 4-28. Leveling Jack Torques



## Oscillating Axle Cylinder Bleeding Procedure



1. Oscillating Axle Cylinder

2. Bleeder Valve

**Figure 4-29. Oscillating Axle Cylinder Bleeding**

1. Start the engine.
2. Raise the arms high enough so that the left axle cylinder bleeder valve can be accessed.
3. Let engine run at idle.
4. Position a suitable container [approximately 0.5 gal (1.9 l)] over the bleeder valve.
5. Using a 3/8" wrench, slowly open bleeder valve.
6. Keep the container close enough to the bleeder valve to catch the aerated oil.
7. Open the bleeder valve enough to get a fast stream of oil.

**NOTE:** A fast stream of oil will exhaust the air out of the hoses and cylinder better than a slow stream of oil.

8. Every 3-4 seconds, close the bleeder valve so that a slower stream of oil is being purged. When only oil and no air is being purged, close the bleeder valve.
9. A new system can take 10-15 seconds per cylinder to bleed.

### **NOTICE**

**ANYTIME EITHER OF THE HOSES PLUMBING TO THE CYLINDERS ARE BROKEN INTO, AIR HAS BEEN INTRODUCED INTO THE SYSTEM. THE CYLINDERS MUST BE BLED.**

# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

A screenshot of the "Search Manuals" form. The form has a title "Search Manuals" and a subtitle "Please provide information to help us locate the manual and/or parts you need." It includes fields for "Brand", "Model", "Serial", "Part Number", and "Quantity". There is a "Search" button at the bottom.

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

A screenshot of the "Parts Order Form". The form has a title "Parts Order Form" and a subtitle "Please fill in as much information as possible." It includes a table with columns for "Quantity", "Part Number", "Description", "Manufacturer", "Model", "Serial", "Part Number", "Quantity", "Date Received", "Order Code", "Phone", "Fax", "E-mail", and "Manufacturer".

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**


**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.


We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

## SECTION 5. JLG CONTROL SYSTEM


## 5.1 HAND HELD ANALYZER



## To Connect the Hand Held Analyzer



1. Ground Control Box - Analyzer Connector



2. Platform Control Box - Analyzer Connector

**NOTE:** The cable has a four pin connector at each end; the cable cannot be connected backwards.


1. Connect the four pin end of the cable supplied with the analyzer, to the four position connector (1) J6 on the PCB in the ground control station or at the platform control station connector (2) X32 as shown.

Connect the remaining end of the cable to the analyzer.

2. Power up the Control System by turning the lower key to the platform position and pulling out both emergency stop buttons.

## Using the Analyzer

With the machine power on and the analyzer connected properly, the analyzer will display the following:



### HELP:

PRESS ENTER


At this point, using the **RIGHT** and **LEFT** arrow keys, you can move between the top level menu items. To select a displayed menu item, press **ENTER**. To cancel a selected menu item, press **ESC**; then you will be able to scroll using the right and left arrow keys to select a different menu item.

The top level menus are as follows:

- ACCESS LEVEL
- PERSONALITIES
- MACHINE SETUP
- CALIBRATIONS
- ACTIVATE TESTS
- HELP
- DIAGNOSTICS

If you press **ENTER**, at the HELP:PRESS ENTER display, and a fault is present during power up, the analyzer display will scroll the fault across the screen. If there was no fault detected during power up, the display will read:  
 In platform mode, **HELP: EVERYTHING OK**,  
 In ground mode, **GROUND MODE OK**

If **ENTER** is pressed again, the display moves to the following display:



### LOGGED HELP

1: STARTUP (2/1): (Or last recorded fault)

At this point, the analyzer will display the current fault, if any are present. You may scroll through the fault logs to view what the last fifteen faults were. Use the right and left arrow keys to scroll through the fault logs. To return to the beginning, press **ESC** two times.


When a top level menu is selected, a new set of menu items may be offered; If for example you choose Personalities:

- DRIVE
- LIFT
- GROUND MODE

Pressing **ENTER** with any of the above displayed menus will display additional sub-menus within the selected menu. In some cases the next level is the parameter or information to be changed. Refer to the flow chart for what menus are available within the top level menus. You may only view the personality settings for selected menus while in access level 2. Remember, you may always cancel a selected menu item by pressing the **ESC** key.

## Changing the Access Level of the Hand Held Analyzer

When the analyzer is first connected, you will be in access level 2 which enables you to only view most configuration settings which cannot be changed until you enter a password to advance to a lower level. This ensures that a setting cannot be accidentally altered. To change the access level, the correct password must be entered. To enter the password, scroll to the **ACCESS LEVEL** menu. For example:



**MENU:**

ACCESS LEVEL 2

Press **ENTER** to select the **ACCESS LEVEL** menu.


Using the **UP** or **DOWN** arrow keys, enter the first digit of the password, 3.

Then using the **RIGHT** arrow key, position the cursor to the right one space to enter the second digit of the password.

Use the **UP** or **DOWN** arrow key to enter the second digit of the password which is 3.

Repeat this process until you have entered all five digits of the password which is **33271**.

Once the correct password is displayed, press **ENTER**. The access level should display the following, if the password was entered correctly:




**MENU:**

ACCESS LEVEL 1

Repeat the above steps if the correct access level is not displayed or you can not adjust the personality settings.

## Adjusting Parameters Using the Hand Held Analyzer

Once you have gained access to level 1, and a personality item is selected, press the UP or DOWN arrow keys to adjust its value, for example:



PERSONALITIES:  
DRIVE ACCEL 3.0s


There will be a minimum and maximum for the value to ensure efficient operation. The value will not increase if the **UP** arrow is pressed when at the maximum value nor will the value decrease if the **DOWN** arrow is pressed and the value is at the minimum value for any particular personality. If the value does not change when pressing the up and down arrows, check the access level to ensure you are at access level 1.

## Machine Setup

When a machine digit item is selected, press the **UP** or **DOWN** arrow keys to adjust its value, for example:

### **⚠ WARNING**

**FAILURE TO MAKE THE PROPER SETTINGS FOR THE PARTICULAR MACHINE CAN RESULT IN IMPROPER OPERATION.**



**GROUND ALARM:**  
1=DESCENT

The effect of the machine digit value is displayed along with its value. The above display would be selected if the machine was equipped with a ground alarm and you wanted it to sound when driving. There are certain settings allowed to install optional features or select the machine model.

When selecting the machine model to match the size of the machine, the personality settings will return to default settings.




**NOTE:** Refer to Section 5.6, Machine Configuration And Programming Settings for default settings.

Password 33271 will give you access to level 1, which will permit you to change all machine personalities and/or machine setup settings.

**⚠ WARNING**

**CHANGING THESE SETTINGS MAY ADVERSELY AFFECT THE PERFORMANCE OF YOUR MACHINE.**

The flash code is indicated on the face of the platform control box as shown:



**NOTE:** Flash codes are also displayed on the handheld analyzer. For descriptions see Table 5-1, Fault Code Listing.

**NOTICE**

**IT IS A GOOD PRACTICE TO AVOID PRESSURE-WASHING ELECTRICAL/ELECTRONIC COMPONENTS. SHOULD PRESSURE-WASHING BE UTILIZED TO WASH AREAS CONTAINING ELECTRICAL/ELECTRONIC COMPONENTS, JLG INDUSTRIES, INC. RECOMMENDS A MAXIMUM PRESSURE OF 750 PSI (52 BAR) AT A MINIMUM DISTANCE OF 12 INCHES (30.5 CM) AWAY FROM THESE COMPONENTS. IF ELECTRICAL/ELECTRONIC COMPONENTS ARE SPRAYED, SPRAYING MUST NOT BE DIRECT AND BE FOR BRIEF TIME PERIODS TO AVOID HEAVY SATURATION.**

Analyzer Menu Flow Charts




Figure 5-1. Analyzer Menu Flow Chart (Version P2.1) - Sheet 1 of 4




Figure 5-2. Analyzer Menu Flow Chart (Version p2.1) - Sheet 2 of 4






Figure 5-4. Analyzer Menu Flow Chart (Version P2.1) - Sheet 4 of 4

## 5.2 DIAGNOSTIC TROUBLESHOOTING CODES (DTC'S) AND FLASH CODES DESCRIPTION

Table 5-1. DTC and Flash Code Descriptions

DTC Code	Flash Code	Description	Item Check List
4	0 0	"Running At Cutback - Above Elevation"	<ul style="list-style-type: none"> <li>The platform is elevated and the machine is driving at creep speed.</li> <li>Fully stow the platform. Check that the Elevation Angle Sensor is securely mounted.</li> </ul>
5	0 0	"Drive & Lift Up Prevented - Tilted & Elevated"	<ul style="list-style-type: none"> <li>The platform is elevated and the chassis is not level. The control system prevents driving and lifting up.</li> <li>If the machine is tilted, lower the platform and reposition the machine to a level surface.</li> <li>The Chassis Tilt Sensor is located inside the left chassis cover. Check that the Chassis Tilt Sensor is securely mounted to the machine.</li> <li>The Elevation Angle Sensor is mounted on the centering link underneath the middle of the machine. Check that the Elevation Angle Sensor is securely mounted to the machine.</li> </ul>
9	0 0	"Drive Prevented - Elevated Above Drive Cutout Height"	<ul style="list-style-type: none"> <li>Attempting to drive with the platform elevated to over 32 feet. The control system prevents driving.</li> <li>Lower the platform to under 32 feet.</li> </ul>
23	0 0	"Function Selected But Trigger Switch Open"	<ul style="list-style-type: none"> <li>A function is commanded but the trigger is not closed.</li> <li>Squeeze the trigger.</li> <li>Check the Platform Trigger input J1-1 (should be high when trigger is squeezed).</li> </ul>
41	0 0	"Front Left Leveling Jack At End Of Stroke"	<ul style="list-style-type: none"> <li>Front Left Leveling Jack cylinder has reached end of stroke.</li> <li>Check if the cylinder is at end of stroke (normal operation).</li> <li>Check the wiring to the Front Left Leveling Jack end of stroke switch.</li> </ul>
42	0 0	"Front Right Leveling Jack At End Of Stroke"	<ul style="list-style-type: none"> <li>Front Right Leveling Jack cylinder has reached end of stroke.</li> <li>Check if the cylinder is at end of stroke (normal operation).</li> <li>Check the wiring to the Front Right Leveling Jack end of stroke switch.</li> </ul>
43	0 0	"Rear Left Leveling Jack At End Of Stroke"	<ul style="list-style-type: none"> <li>Rear Left Leveling Jack cylinder has reached end of stroke.</li> <li>Check if the cylinder is at end of stroke (normal operation).</li> <li>Check the wiring to the Rear Left Leveling Jack end of stroke switch.</li> </ul>
44	0 0	"Rear Right Leveling Jack At End Of Stroke"	<ul style="list-style-type: none"> <li>Rear Right Leveling Jack cylinder has reached end of stroke.</li> <li>Check if the cylinder is at end of stroke (normal operation).</li> <li>Check the wiring to the Rear Right Leveling Jack end of stroke switch.</li> </ul>
45	4 3	"Engine Shutdown Commanded - Check Engine Sensors"	<ul style="list-style-type: none"> <li>The engine coolant temperature is high or the oil pressure is low. The control system shuts down the engine.</li> <li>DIESEL - Check the engine oil pressure and engine coolant temperature sensors for damage.</li> <li>Check the engine oil pressure input J2-17 (should be low when not overheating).</li> <li>Check the engine coolant input J2-25 (resistive).</li> </ul>
212	2 1	"Keyswitch Faulty - Platform & Ground Active Together"	<ul style="list-style-type: none"> <li>The Platform and Ground mode switches are both high.</li> <li>Check the Ground Module inputs for Ground Mode (J4-4) and Platform Mode (J1-2).</li> </ul>
221	2 2	"Function Locked Out - Horn Switch Permanently Closed"	<ul style="list-style-type: none"> <li>The Platform horn input was closed at start up. The control system prevents any function selects.</li> <li>Check if the Platform horn switch is obstructed or jammed.</li> <li>Check Platform input J1-31 (should be low when horn is not pressed).</li> </ul>



Table 5-1. DTC and Flash Code Descriptions

223	2	2	"Function Locked Out - Drive & Lift Active Together"	<ul style="list-style-type: none"> <li>The Platform Drive and Lift inputs are both closed. The control system prevents any function selects.</li> <li>Check Platform inputs J1-3 (should be high in drive mode) and J1-4 (should be high in lift mode).</li> </ul>
224	2	2	"Function Locked Out - Steer Left Permanently Closed"	<ul style="list-style-type: none"> <li>The Platform Steer Left input was closed at start up. The control system prevents any function selects.</li> <li>Check if the Platform Steer left switch is obstructed or jammed.</li> <li>Check Platform input J6-5 (should be low when steer left is not pressed).</li> </ul>
225	2	2	"Function Locked Out - Steer Right Permanently Closed"	<ul style="list-style-type: none"> <li>The Platform Steer Right input was closed at start up. The control system prevents any function selects.</li> <li>Check if the Platform Steer right switch is obstructed or jammed.</li> <li>Check Platform input J6-6 (should be low when steer right is not pressed).</li> </ul>
228	2	2	"Function Locked Out - Joystick Not Centered"	<ul style="list-style-type: none"> <li>Function engaged but joystick not in center position. The control system prevents any function selects.</li> <li>Center joystick and re-attempt function.</li> <li>Check Platform joystick input J6-3 (should change from reverse to center to forward).</li> </ul>
229	2	2	"Trigger Switch Wiring Shorted High In Platform Cable"	<ul style="list-style-type: none"> <li>The Ground Module and Platform Module are reading the Trigger Switch differently.</li> <li>Check Platform Module input J1-1 and Ground Module input J1-3 for agreement.</li> </ul>
229	2	2	"Function Locked Out - Trigger Switch Permanently Closed"	<ul style="list-style-type: none"> <li>The Platform trigger input was closed at start up. The control system prevents any function selects.</li> <li>Check if the Platform trigger switch is obstructed or jammed.</li> <li>Check Platform input J1-1 (should be low when trigger is not pressed).</li> </ul>
232	2	3	"Ground Lift Up/down Active Together"	<ul style="list-style-type: none"> <li>Ground lift up and lift down inputs both closed. The control system prevents lifting and lowering.</li> <li>Check if the Ground lift switch is damaged, obstructed, or jammed.</li> <li>Check Ground input J4-7 (should be low when lift up is not selected).</li> <li>Check Ground input J4-8 (should be low when lift down is not selected).</li> </ul>
238	2	3	"Function Locked Out - Ground Aux Switch Permanently Closed"	
241	2	4	"Ambient Temperature Sensor - Out Of Range Low"	<ul style="list-style-type: none"> <li>The temperature is below the allowed minimum value. The control system prevents lift up. The control system limits driving to turtle speed if elevated.</li> <li>Check the wires to the Chassis Tilt Sensor.</li> <li>Replace the Chassis Tilt Sensor (also sends temperature).</li> </ul>
242	2	4	"Ambient Temperature Sensor - Out Of Range High"	<ul style="list-style-type: none"> <li>The temperature is above the allowed maximum value. The control system prevents lift up. The control system limits driving to turtle speed if elevated.</li> <li>Check the wires to the Chassis Tilt Sensor.</li> <li>Replace the Chassis Tilt Sensor (also sends temperature).</li> </ul>
243	2	5	"Front Left Leveling Jack Pressure Transducer Failure"	<ul style="list-style-type: none"> <li>Front Left Leveling Jack pressure transducer reading is outside of the allowed range.</li> <li>Check the wiring to the Front Left Leveling Jack pressure transducer.</li> </ul>
244	2	5	"Front Right Leveling Jack Pressure Transducer Failure"	<ul style="list-style-type: none"> <li>Front Right Leveling Jack pressure transducer reading is outside of the allowed range.</li> <li>Check the wiring to the Front Right Leveling Jack pressure transducer.</li> </ul>

## SECTION 5 - JLG CONTROL SYSTEM

**Table 5-1. DTC and Flash Code Descriptions**

245	2	5	"Rear Left Leveling Jack Pressure Transducer Failure"	<ul style="list-style-type: none"> <li>Rear Left Leveling Jack pressure transducer reading is outside of the allowed range.</li> <li>Check the wiring to the Rear Left Leveling Jack pressure transducer.</li> </ul>
246	2	5	"Rear Right Leveling Jack Pressure Transducer Failure"	<ul style="list-style-type: none"> <li>Rear Right Leveling Jack pressure transducer reading is outside of the allowed range.</li> <li>Check the wiring to the Rear Right Leveling Jack pressure transducer.</li> </ul>
247	2	5	"Front Left Leveling Jack Stow Switch Permanently Closed"	<ul style="list-style-type: none"> <li>Front Left Leveling Jack stowed switch is closed but pressure indicates all leveling jacks are set.</li> <li>Check the wiring to the Front Left Leveling Jack stowed switch.</li> </ul>
248	2	5	"Front Right Leveling Jack Stow Switch Permanently Closed"	<ul style="list-style-type: none"> <li>Front Right Leveling Jack stowed switch is closed but pressure indicates all leveling jacks are set.</li> <li>Check the wiring to the Front Right Leveling Jack stowed switch.</li> </ul>
249	2	5	"Rear Left Leveling Jack Stow Switch Permanently Closed"	<ul style="list-style-type: none"> <li>Rear Left Leveling Jack stowed switch is closed but pressure indicates all leveling jacks are set.</li> <li>Check the wiring to the Rear Left Leveling Jack stowed switch.</li> </ul>
251	2	5	"Elev Angle Sensor Faulty - Not Mounted Or Voltage Out Of Range"	<ul style="list-style-type: none"> <li>The Elevation Angle Sensor voltage is outside of the allowed range. The control system behaves elevated.</li> <li>The Elevation Angle Sensor is mounted on the centering link underneath the middle of the machine. Check that it is securely mounted to the machine.</li> </ul>
252	2	5	"Elev Angle Sensor Has Not Been Calibrated"	<ul style="list-style-type: none"> <li>The Elevation Angle Sensor calibrated values are invalid. The control system will prevent lift. The control system will prevent drive if the prox switch is open.</li> <li>The Elevation Angle Sensor is mounted on the centering link underneath the middle of the machine. Check that it is securely mounted to the machine.</li> <li>Calibrate the Elevation Angle Sensor using the CALIBRATIONS:SET STOW ELEV submenu to clear the message.</li> </ul>
257	2	5	"Elev Angle Sensor And Elev Prox Switch Disagree"	<ul style="list-style-type: none"> <li>The Elevation prox switch says the platform is stowed but the Elevation Angle Sensor says the platform is elevated. The control system will behave elevated.</li> <li>The Elevation Angle Sensor is mounted on the centering link underneath the middle of the machine. The Elevation Prox Switch is mounted on the slide channel towards the front of the machine from the left side chassis cover. Check that both sensors are securely mounted to the machine. Check that there are no metal shavings/dust on the Elevation Prox Switch.</li> </ul>
257	2	5	"Elevation Prox Switch Permanently Closed"	
2111	2	2	"Function Locked Out - Start Permanently Closed"	<ul style="list-style-type: none"> <li>The Platform start switch was closed during power up. The control system prevents any function selects.</li> <li>Check if the Platform start button is jammed.</li> <li>Check Platform Module input J1-14 (should be low when start is not pressed, and high when start is pressed).</li> </ul>
2210	2	2	"Trigger Closed Too Long While In Neutral"	<ul style="list-style-type: none"> <li>Trigger has been squeezed for 10 seconds while the joystick was in the center position.</li> <li>Check the Platform Trigger input J1-1 (should be high when trigger is squeezed).</li> </ul>
2232	2	2	"Function Locked Out - Drive & Lift Both Open"	<ul style="list-style-type: none"> <li>The Platform Drive and Lift inputs are both open. The control system prevents any function selects.</li> <li>Check Platform inputs J1-3 (should be high in drive mode) and J1-4 (should be high in lift mode).</li> </ul>

Table 5-1. DTC and Flash Code Descriptions

2234	2	2	"Function Locked Out - Drive Select Permanently Closed"	
2235	2	2	"Function Locked Out - Lift Select Permanently Closed"	
2237	2	2	"Joystick Faulty - Steer Switches Active Together"	<ul style="list-style-type: none"> <li>Platform steer left and steer right switch both high.</li> <li>Check if the Platform steer switch is damaged, obstructed, or jammed.</li> <li>Check Platform input J6-5 (should be low when steer left is not pressed).</li> <li>Check Platform input J6-6 (should be low when steer right is not pressed).</li> </ul>
2239	2	2	"Function Locked Out - Joystick Calibration Faulty"	<ul style="list-style-type: none"> <li>Joystick calibration is not valid. The control system prevents any function selects.</li> <li>Calibrate the Platform Joystick.</li> </ul>
2267	2	2	"Joystick Faulty - Wiper Out Of Range"	<ul style="list-style-type: none"> <li>Joystick Wiper is outside the acceptable voltage range.</li> <li>Check the wires to the joystick.</li> </ul>
2269	2	2	"Function Locked Out - High Speed & Creep Active Together"	<ul style="list-style-type: none"> <li>Rabbit and Turtle mode are both high. The control system prevents any function selects.</li> <li>Check platform inputs drive speed (J1-5) and engine speed (J1-6).</li> </ul>
2280	2	2	"Function Locked Out - Front Deck Select Permanently Closed"	
2281	2	2	"Function Locked Out - Rear Deck Select Permanently Closed"	
2282	2	2	"Function Locked Out - Generator Switch Permanently Closed"	<ul style="list-style-type: none"> <li>The Platform generator input was closed at start up. The control system prevents any function selects.</li> <li>Check if the Platform generator switch is obstructed or jammed.</li> <li>Check Platform input J7-9 (should be low when generator is not pressed).</li> </ul>
2283	2	2	"Function Locked Out - Autolevel Switch Permanently Closed"	<ul style="list-style-type: none"> <li>The Platform autolevel input was closed at start up. The control system prevents any function selects.</li> <li>Check if the Platform autolevel switch is obstructed or jammed.</li> <li>Check Platform input J1-2 (should be low when autolevel is not pressed).</li> </ul>
2284	2	2	"Trigger Switch Wiring Shorted Low In Platform Cable"	<ul style="list-style-type: none"> <li>The Ground Module and Platform Module are reading the Trigger Switch differently.</li> <li>Check Platform Module input J1-1 and Ground Module input J1-3 for agreement.</li> </ul>
23221	2	3	"Upper Lift Cylinder Lift Down Valve – Not Opening"	<ul style="list-style-type: none"> <li>Pressure Transducer 1 or 2 reads over 2400 PSI(3.25 Volts) while lifting down. Fault shall be retentive through Power Cycle.</li> <li>Check the wiring and hosing for lift down valve on the upper lift cylinder.</li> <li>Check LSS ANGLE SENSOR mounting and Calibration.</li> <li>The message can only be cleared with an Analyzer via the CALIBRATIONS &gt; PLTFM UNLOCK &gt; YES.</li> </ul>
23222	2	3	"Lower Lift Cylinder Lift Down Valve – Not Opening"	<ul style="list-style-type: none"> <li>Pressure Transducer 1 or 2 reads under 750 PSI(1.4 Volts) while lifting down. Fault shall be retentive through Power Cycle.</li> <li>Check the wiring and hosing for lift down valve on the lower lift cylinder.</li> <li>Check LSS ANGLE SENSOR mounting and Calibration.</li> <li>The message can only be cleared with an Analyzer via the CALIBRATIONS &gt; PLTFM UNLOCK &gt; YES.</li> </ul>

Table 5-1. DTC and Flash Code Descriptions

23223	2	3	"Upper Lift Cylinder - Leaking"	<ul style="list-style-type: none"> <li>• Pressure transducer 1 or 2 reads over 2400 PSI(3.25 Volts) while no lift action is being performed. Fault shall be retentive through Power Cycle.</li> <li>• Check Upper Lift Cylinder for leaks.</li> <li>• Check LSS ANGLE SENSOR mounting and Calibration.</li> <li>• The message can only be cleared with an Analyzer via the CALIBRATIONS &gt; PLTFM UNLOCK &gt; YES.</li> </ul>
23224	2	3	"Lower Lift Cylinder - Leaking"	<ul style="list-style-type: none"> <li>• Pressure transducer 1 or 2 reads under 750 PSI (1.4 Volts) while no lift action is being performed. Fault shall be retentive through Power Cycle.</li> <li>• Check Lower Lift Cylinder for leaks.</li> <li>• Check LSS ANGLE SENSOR mounting and Calibration.</li> <li>• The message can only be cleared with an Analyzer via the CALIBRATIONS &gt; PLTFM UNLOCK &gt; YES.</li> </ul>
2410	2	5	"Rear Right Leveling Jack Stow Switch Permanently Closed"	<ul style="list-style-type: none"> <li>• Rear Right Leveling Jack stowed switch is closed but pressure indicates all leveling jacks are set.</li> <li>• Check the wiring to the Rear Right Leveling Jack stowed switch.</li> </ul>
2512	2	5	"Elev Angle Sensor Not Detecting Change"	<ul style="list-style-type: none"> <li>• The Elevation Angle Sensor is not detecting any change during lifting. The control system will behave elevated. The control system will prevent drive if prox switch is open.</li> <li>• The Elevation Angle Sensor is mounted on the centering link underneath the middle of the machine. Check that it is securely mounted to the machine.</li> </ul>
2568	2	5	"Temperature Cutout Active - Ambient Temperature Too Low"	<ul style="list-style-type: none"> <li>• The temperature is too low. The control system may prevent lift up, drive, steer.</li> <li>• Check the wires to the Chassis Tilt Sensor.</li> <li>• Replace the Chassis Tilt Sensor (also sends temperature).</li> </ul>
2570	2	5	"Leveling Jack Set Prevented - Ecm Lost"	
2580	2	5	"Lift Up Prevented - Leveling Jacks Not Set"	<ul style="list-style-type: none"> <li>• Attempting to lift up with the platform elevated too high with out the leveling jacks set. The control system prevents lifting.</li> <li>• Lower the platform to stowed. Set the leveling jacks.</li> </ul>
2581	2	5	"Elev Angle Sensor And Elev Prox Switch Disagree"	<ul style="list-style-type: none"> <li>• The Elevation Angle Sensor and Elevation Prox Switch disagree detecting if the platform is stowed.</li> <li>• The Elevation Angle Sensor is mounted on the centering link underneath the middle of the machine. The Elevation Prox Switch is mounted on the slide channel towards the front of the machine from the left side chassis cover. Check that both sensors are securely mounted to the machine. Check that there are no metal shavings/dust on the Elevation Prox Switch.</li> </ul>
2582	2	5	"Arm Stack Tilt Sensor And Elev Prox Switch Disagree"	<ul style="list-style-type: none"> <li>• The Arm Stack Tilt Sensor and Elevation Prox Switch disagree detecting if the platform is stowed.</li> <li>• The Arm Stack Tilt Sensor is mounted on the lowest arm tube at the rear of the machine. The Elevation Prox Switch is mounted on the slide channel towards the front of the machine from the left side chassis cover. Check that both sensors are securely mounted to the machine. Check that there is no metal (shavings, dust) on the Elevation Prox Switch.</li> </ul>
23107	2	3	"Function Locked Out - Ground Lift Up Permanently Closed"	<ul style="list-style-type: none"> <li>• The Ground lift up input was closed at start up. The control system prevents any function selects.</li> <li>• Check if the Ground lift up switch is obstructed or jammed.</li> <li>• Check Ground input J4-7 (should be low when lift up is not pressed).</li> </ul>

Table 5-1. DTC and Flash Code Descriptions

23108	2	3	"Function Locked Out - Ground Lift Dn Permanently Closed"	<ul style="list-style-type: none"> <li>• The Ground lift down input was closed at start up. The control system prevents any function selects.</li> <li>• Check if the Ground lift down switch is obstructed or jammed.</li> <li>• Check Ground input J4-8 (should be low when lift down is not pressed).</li> </ul>
23147	2	3	"Function Locked Out - Ground Front Deck Ext Permanently Closed"	
23148	2	3	"Function Locked Out - Ground Front Deck Ret Permanently Closed"	
23149	2	3	"Function Locked Out - Ground Rear Deck Ext Permanently Closed"	
23150	2	3	"Function Locked Out - Ground Rear Deck Ret Permanently Closed"	
23151	2	3	"Ground Front Deck Extend/retract Active Together"	
23152	2	3	"Ground Rear Deck Extend/retract Active Together"	
23153	2	3	"Function Locked Out - Ground Start Switch Permanently Closed"	<ul style="list-style-type: none"> <li>• The Ground start switch was closed during power up. The control system prevents any function selects.</li> <li>• Check if the Ground start button is damaged, obstructed, or jammed.</li> <li>• Check Ground Module input J4-5 (should be low when start is not pressed, and high when start is pressed).</li> </ul>
23163	2	3	"Function Problem - Msso Permanently Selected"	<ul style="list-style-type: none"> <li>• The Ground MSSO switch was closed during power up. The control system prevents any function selects.</li> <li>• Check if the MSSO button is damaged, obstructed, or jammed.</li> <li>• Check Ground Module input J4-14 (should be low when MSSO is not pressed, and high when MSSO is pressed).</li> </ul>
3342	2	2	"Function Locked Out - Aux Power Switch Permanently Closed"	
3517	2	6	"Front Left Leveling Jack Short To Ground"	<ul style="list-style-type: none"> <li>• The Front Left Leveling Jack is shorted to ground.</li> <li>• Check the wiring to the Front Left Leveling Jack.</li> </ul>
3518	2	6	"Front Left Leveling Jack Short To Battery"	<ul style="list-style-type: none"> <li>• The Front Left Leveling Jack is shorted to battery.</li> <li>• Check the wiring to the Front Left Leveling Jack.</li> </ul>
3519	2	6	"Front Left Leveling Jack Open Circuit"	<ul style="list-style-type: none"> <li>• The Front Left Leveling Jack is open circuit.</li> <li>• Check the wiring to the Front Left Leveling Jack.</li> </ul>
3520	2	6	"Front Right Leveling Jack Short To Ground"	<ul style="list-style-type: none"> <li>• The Front Right Leveling Jack is shorted to ground.</li> <li>• Check the wiring to the Front Right Leveling Jack.</li> </ul>
3521	2	6	"Front Right Leveling Jack Short To Battery"	<ul style="list-style-type: none"> <li>• The Front Right Leveling Jack is shorted to battery.</li> <li>• Check the wiring to the Front Right Leveling Jack.</li> </ul>
3522	2	6	"Front Right Leveling Jack Open Circuit"	<ul style="list-style-type: none"> <li>• The Front Right Leveling Jack is open circuit.</li> <li>• Check the wiring to the Front Right Leveling Jack.</li> </ul>
3523	2	6	"Rear Left Leveling Jack Short To Ground"	<ul style="list-style-type: none"> <li>• The Rear Left Leveling Jack is shorted to ground.</li> <li>• Check the wiring to the Front Left Leveling Jack.</li> </ul>
3524	2	6	"Rear Left Leveling Jack Short To Battery"	<ul style="list-style-type: none"> <li>• The Rear Left Leveling Jack is shorted to battery.</li> <li>• Check the wiring to the Front Left Leveling Jack.</li> </ul>
3525	2	6	"Rear Left Leveling Jack Open Circuit"	<ul style="list-style-type: none"> <li>• The Rear Left Leveling Jack is open circuit.</li> <li>• Check the wiring to the Front Left Leveling Jack.</li> </ul>
3526	2	6	"Rear Right Leveling Jack Short To Ground"	<ul style="list-style-type: none"> <li>• The Rear Right Leveling Jack is shorted to ground.</li> <li>• Check the wiring to the Rear Right Leveling Jack.</li> </ul>
3527	2	6	"Rear Right Leveling Jack Short To Battery"	<ul style="list-style-type: none"> <li>• The Rear Right Leveling Jack is shorted to battery.</li> <li>• Check the wiring to the Rear Right Leveling Jack.</li> </ul>
3528	2	6	"Rear Right Leveling Jack Open Circuit"	<ul style="list-style-type: none"> <li>• The Rear Right Leveling Jack is open circuit.</li> <li>• Check the wiring to the Rear Right Leveling Jack.</li> </ul>
3529	2	6	"Leveling Jack Extend Valve Short To Ground"	<ul style="list-style-type: none"> <li>• The Leveling Jack extend valve is shorted to ground.</li> <li>• Check the wiring to the Leveling Jack extend valve.</li> </ul>

## SECTION 5 - JLG CONTROL SYSTEM

**Table 5-1. DTC and Flash Code Descriptions**

3530	2	6	"Leveling Jack Extend Valve Short To Battery"	<ul style="list-style-type: none"> <li>The Leveling Jack extend valve is shorted to battery.</li> <li>Check the wiring to the Leveling Jack extend valve.</li> </ul>
3531	2	6	"Leveling Jack Extend Valve Open Circuit"	<ul style="list-style-type: none"> <li>The Leveling Jack extend valve is open circuit.</li> <li>Check the wiring to the Leveling Jack extend valve.</li> </ul>
3532	2	6	"Leveling Jack Retract Valve Short To Ground"	<ul style="list-style-type: none"> <li>The Leveling Jack retract valve is shorted to ground.</li> <li>Check the wiring to the Leveling Jack retract valve.</li> </ul>
3533	2	6	"Leveling Jack Retract Valve Short To Battery"	<ul style="list-style-type: none"> <li>The Leveling Jack retract valve is shorted to battery.</li> <li>Check the wiring to the Leveling Jack retract valve.</li> </ul>
3534	2	6	"Leveling Jack Retract Valve Open Circuit"	<ul style="list-style-type: none"> <li>The Leveling Jack retract valve is open circuit.</li> <li>Check the wiring to the Leveling Jack retract valve.</li> </ul>
33132	3	3	"Throttle Actuator - Short To Battery"	<ul style="list-style-type: none"> <li>The control system is reading a high engine rpm when idle is commanded.</li> <li>Diesel Engines: Check J2-26 for short to battery positive.</li> </ul>
33280	2	2	"Function Locked Out - Glow Plug Switch Permanently Closed"	<ul style="list-style-type: none"> <li>The Platform glow plugs input was closed at start up. The control system prevents any function selects.</li> <li>Check if the Platform glow plugs switch is obstructed or jammed.</li> <li>Check Platform input J1-7 (should be low when glow plugs is not pressed).</li> </ul>
431	4	3	"Fuel Sensor Short To Battery"	<ul style="list-style-type: none"> <li>The fuel sensor value is over the maximum allowed value.</li> <li>Check the fuel sensor input J2-34 (resistive).</li> </ul>
431	4	3	"Fuel Sensor Disconnected"	<ul style="list-style-type: none"> <li>The fuel sensor value is over the maximum normal value.</li> <li>Check the fuel sensor input J2-34 (resistive).</li> </ul>
432	4	3	"Fuel Sensor Short To Ground"	<ul style="list-style-type: none"> <li>The fuel sensor value is under the minimum allowed value.</li> <li>Check the fuel sensor input J2-34 (resistive).</li> </ul>
433	4	3	"Oil Pressure Short To Battery"	<ul style="list-style-type: none"> <li>Engine oil pressure is high while the engine is not running for 30 seconds.</li> <li>Check the engine oil pressure input J2-17 (should be low when not overheating).</li> <li>Check the speed sensor wiring.</li> </ul>
434	4	3	"Oil Pressure Short To Ground"	
435	4	3	"Coolant Temperature Short To Ground"	
437	4	3	"Engine Trouble Code "	<ul style="list-style-type: none"> <li>Fault was reported by the engine controller.</li> <li>Check the engine.</li> </ul>
438	4	3	"Engine Temperature High "	<ul style="list-style-type: none"> <li>Engine temperature is over 110 degrees C.</li> </ul>
439	4	3	"Air Filter Bypassed"	
441	4	4	"Battery Too Low - System Shut Down"	<ul style="list-style-type: none"> <li>Battery voltage is under 9 Volts.</li> <li>Check the battery charge and cables.</li> </ul>
442	4	4	"Battery Too High - System Shut Down"	<ul style="list-style-type: none"> <li>Battery voltage is over 16 Volts.</li> <li>Check the battery charge and cables.</li> </ul>
4310	4	3	"No Alternator Output"	<ul style="list-style-type: none"> <li>The Alternator input is high after 15 seconds of engine running.</li> <li>Check alternator input J2-21 (should be low if engine is running).</li> </ul>
4311	4	3	"Oil Pressure Low"	<ul style="list-style-type: none"> <li>Engine oil pressure low after 10 seconds of running.</li> <li>Check engine oil pressure input J2-17 (should be high if engine is running).</li> </ul>
4312	4	3	"485 Communications Lost"	
4314	4	3	"Wrong Engine Selected - ECM Present"	<ul style="list-style-type: none"> <li>An engine is configured that does not have an engine controller but an engine controller was detected.</li> <li>Check the engine machine set up.</li> </ul>

Table 5-1. DTC and Flash Code Descriptions


4322	5	5	"Speed Input Lost"	<ul style="list-style-type: none"> <li>• Engine oil pressure is high with 0 rpm for 30 seconds.</li> <li>• Check the speed sensor wiring.</li> <li>• Check the engine oil pressure input J2-17 (should be low when not overheating).</li> </ul>
4323	5	5	"Speed Sensor Reading Invalid Speed"	<ul style="list-style-type: none"> <li>• The speed sensor reading is over the maximum allowed value.</li> <li>• Check the speed sensor wiring.</li> </ul>
4352	4	3	"Coolant Temp Sensor Out Of Range High"	<ul style="list-style-type: none"> <li>• Engine coolant temp value is over the maximum allowed value.</li> <li>• Check the engine coolant input J2-25 (resistive).</li> </ul>
4353	4	3	"Coolant Temp Sensor Out Of Range Low"	<ul style="list-style-type: none"> <li>• Engine coolant temp value is under the minimum allowed value.</li> <li>• Check the engine coolant input J2-25 (resistive).</li> </ul>
4430	4	4	"Battery Low"	<ul style="list-style-type: none"> <li>• Battery voltage is under 11 Volts.</li> <li>• Check the battery charge and cables.</li> </ul>
662	6	6	"Canbus Failure - Platform Module"	<ul style="list-style-type: none"> <li>• The control system failed to receive messages from the Platform Module. All data from Platform Module is marked invalid.</li> <li>• Check wiring to the Platform Module.</li> </ul>
666	2	5	"Generator Prevented - ECM Lost"	<ul style="list-style-type: none"> <li>• Dual Fuel - The control system failed to receive messages from the engine controller. The control system prevents enabling the generator.</li> <li>• Check the wiring to the engine controller.</li> </ul>
666	2	5	"Drive Prevented - ECM Lost"	<ul style="list-style-type: none"> <li>• Dual Fuel - The control system failed to receive messages from the engine controller. The control system prevents driving.</li> <li>• Check the wiring to the engine controller.</li> </ul>
666	6	6	"Engine Controller Can Communications Lost"	<ul style="list-style-type: none"> <li>• Dual Fuel - The control system failed to receive messages from the engine controller. Functions requiring high idle are prevented.</li> <li>• Check the wiring to the engine controller.</li> </ul>
671	0	0	"Accessory Fault"	<ul style="list-style-type: none"> <li>• The Accessory Module is requesting a fault.</li> </ul>
6635	6	6	"Canbus Failure - Chassis Tilt/temp Sensor"	<ul style="list-style-type: none"> <li>• The control system failed to receive messages from the Chassis Tilt Sensor. The control system behaves tilted.</li> <li>• The Chassis Tilt Sensor is located inside the left chassis cover. Check wiring to the Chassis Tilt Sensor.</li> </ul>
6650	6	6	"Canbus Failure - Axle Tilt Sensor"	<ul style="list-style-type: none"> <li>• The control system failed to receive messages from the Axle Tilt Sensor. The control system prevents lift up and prevents drive if the platform is elevated.</li> <li>• The Axle Stack Tilt Sensor is mounted to the middle of the front axle. Check wiring to the Axle Tilt Sensor.</li> </ul>
6660	6	6	"Canbus Failure - Leveling Jacks Module"	<ul style="list-style-type: none"> <li>• The control system failed to receive messages from the Leveling Jacks Module. All data from Leveling Jacks Module is marked invalid.</li> <li>• Check wiring to the Leveling Jacks Module.</li> </ul>
6661	6	6	"Canbus Failure - Arm Stack Tilt Sensor"	<ul style="list-style-type: none"> <li>• The control system failed to receive messages from the Arm Stack Tilt Sensor. The control system prevents lift up, behaves overloaded, activates Electronic Arm Guards.</li> <li>• The Arm Stack Tilt Sensor is mounted on the lowest arm tube at the rear of the machine. Check wiring to the Arm Stack Tilt Sensor.</li> </ul>
812	8	1	"No Signal From Tilt Sensor X Axis - Check Wiring"	
812	8	1	"No Signal From Tilt Sensor Y Axis - Check Wiring"	
814	8	1	"Chassis Tilt Sensor Out Of Range"	<ul style="list-style-type: none"> <li>• The Chassis Tilt Sensor angle is outside of the allowed minimum and maximum values. The control system behaves tilted.</li> <li>• The Chassis Tilt Sensor is located inside the left chassis cover. Check that the Chassis Tilt Sensor is securely mounted to the machine.</li> </ul>



**Table 5-1. DTC and Flash Code Descriptions**

825	9	3	"LSS Has Not Been Calibrated"	<ul style="list-style-type: none"> <li>The Load Sensing System has not been calibrated. The control system assumes that the platform is overloaded.</li> <li>Calibrate the LSS using the CALIBRATIONS:FULL LOAD submenu to clear the message.</li> </ul>
829	2	5	"Platform Overloaded"	<ul style="list-style-type: none"> <li>The load sensing system has measured an excessive platform load.</li> <li>Remove excess weight from the platform.</li> <li>Check that the platform is not caught on something preventing up or down movement.</li> </ul>
837	8	3	"Platform LSS Sensor 1 - Short To Battery"	<ul style="list-style-type: none"> <li>Pressure Transducer Number 1 is reading higher than 3360PSI.</li> <li>Check Sensor wiring.</li> </ul>
838	8	3	"Platform LSS Sensor 1 - Short To Ground Or Open Circuit"	<ul style="list-style-type: none"> <li>Pressure Transducer Number 1 is reading lower than 0 PSI.</li> <li>Check Sensor wiring.</li> </ul>
873	8	7	"Machine Safety System Override Occurred"	<ul style="list-style-type: none"> <li>The Platform was moved while overloaded using the MSSO button.</li> <li>Can be reset only with an Analyzer, via the CALIBRATIONS &gt; MSSO RESET &gt; MSSO RESET menu.</li> </ul>
8113	8	1	"Axle Tilt Sensor Has Not Been Calibrated"	<ul style="list-style-type: none"> <li>The Axle Tilt Sensor has not been calibrated. The control system prevents lift up and prevents drive if the platform is elevated.</li> <li>Calibrate the Axle Tilt Sensor using the CALIBRATIONS:AXLE TILT submenu to clear the message.</li> </ul>
8114	8	1	"Arm Stack Tilt Sensor Out Of Range"	<ul style="list-style-type: none"> <li>The Arm Stack Tilt Sensor angle is outside of the calibrated minimum and maximum values.</li> <li>The Arm Stack Tilt Sensor is mounted on the lowest arm tube at the rear of the machine. Check that the Arm Stack Tilt Sensor is securely mounted to the machine.</li> </ul>
8115	8	1	"Axle Tilt Sensor Out Of Range"	<ul style="list-style-type: none"> <li>The Axle Tilt Sensor angle is outside of the allowed minimum and maximum values. The control system prevents lift up and prevents drive if the platform is elevated.</li> <li>The Axle Stack Tilt Sensor is mounted to the middle of the front axle. Check that the Axle Stack Tilt Sensor is securely mounted to the machine.</li> </ul>
8212	8	2	"LSS Pressure Sensor Disagreement"	<ul style="list-style-type: none"> <li>Pressure Sensor 1 and Pressure Sensor 2 do not agree within 75 psi. The control system shall behave as overloaded.</li> <li>***Use R6-R10 check message.</li> </ul>
8216	8	2	"LSS Angle Sensor Has Not Been Calibrated"	<ul style="list-style-type: none"> <li>The LSS Angle Sensor has not been calibrated and the control system assumes that the platform is overloaded.</li> <li>Calibrate the LSS Angle Sensor using the CALIBRATIONS:LSS ANGLE SENSOR submenu to clear the message.</li> </ul>
8311	8	3	"Platform LSS Sensor 2 - Short To Battery"	<ul style="list-style-type: none"> <li>Pressure Transducer Number 2 is reading higher than 3360PSI.</li> <li>Check Sensor wiring.</li> </ul>
8312	8	3	"Platform LSS Sensor 2 - Short To Ground Or Open Circuit"	<ul style="list-style-type: none"> <li>Pressure Transducer Number 2 is reading lower than 0 PSI.</li> <li>Check Sensor wiring.</li> </ul>
998	9	9	"EEPROM Failure - Check All Settings"	<ul style="list-style-type: none"> <li>EEPROM checksum did not match saved checksum for a memory bank. Bank (personalities, machine configuration, calibrations, or fault log) reset to defaults.</li> <li>Replace controller.</li> </ul>
99188	9	9	"Two Platform Modules Detected"	<ul style="list-style-type: none"> <li>The control system received messages from two different platform modules.</li> <li>Check the CAN messages all the modules on the vehicle are sending.</li> </ul>

5.3 TILT SENSOR INSTALLATION



- 1. Ground Control Box
- 2. Tilt Sensor Assembly


Figure 5-5. Tilt Sensor Location

**NOTE:** Refer to Figure 5-6., Tilt Sensor Removal for numbers in parenthesis.

1. Disconnect the batteries.
2. Open the ground control box to gain access to the tilt sensor assembly.
3. Disconnect the tilt sensor wiring connector (SN3) from the (X03) harness connector on the side of the box.
4. Remove the four screws (3), lock washers (4), standoff insulators (5), and washers (6) to remove the tilt sensor (1) and sensor mount (2) from the ground control box.
5. The tilt sensor (1) can be removed from the sensor mount (2) by removing the two screws (7).

**NOTE:** Follow the above procedures in reverse order when installing the tilt sensor assembly. After installing, be sure to calibrate the tilt sensor (refer to Section 5.4, Sensor Location and Calibration).

**Chassis Tilt Sensor** - If this sensor is not wired correctly or if you have the wrong part number you will get CAN-BUS FAILURE - CHASSIS TILT SENSOR




- 1. Tilt Sensor
- 2. Sensor Mount
- 3. Mount Screws
- 4. Lockwashers
- 5. Stand-off Insulators
- 6. Washers
- 7. Sensor Screws
- 8. (SN3) (X03) Harness Connector

Figure 5-6. Tilt Sensor Removal

Table 5-2. Tilt Sensor Harness (SN3)

Wire Color	Function	Connector Pin
Red	VCC	1
Green	PWMX	2
White	PWMY	3
Black	Ground	4

## 5.4 SENSOR LOCATION AND CALIBRATION



1. Scissor Arm Stack Assembly (partly hidden for illustration)
2. Proximity (Elevation) Sensor (on frame inboard slide channel)
3. Rotary Angle (Elevation) Sensor (on scissor arm link at chassis)
4. Arm Stack Tilt Sensor for LSS (on bracket under crossmember)
5. Oscillating Axle Tilt Sensor (mounted to front oscillating axle)

### Rotary Angle (Elevation) Sensor Calibration

The sensor must be installed in the orientation shown. The sensor should be installed on the pin and then turned so that it can be attached to the bracket. You must be careful not to damage the spring return mechanism inside the sensor when turning it. Do not turn it in the wrong direction.

Using the Analyzer, in Access Level 1, go to MENU: CALIBRATION:

1. Set machine up on a firm level surface and set the leveling jacks and level the machine.
2. SET STOW ELEV;
  - a. Completely lower platform to stowed position.
  - b. Enter YES on the Analyzer.
  - c. COMPLETE will show on the analyzer when calibrated.
3. SET 32FT ELEV; (ANSI/ANSI EXPORT - LEVELING JACKS SET)
  - a. Raise platform to a height of 32 feet (measured deck to ground).
  - b. Enter YES on the Analyzer.

- c. COMPLETE will show on the analyzer when calibrated.
4. SET 45FT ELEV; (CE/AUSTRALIA ONLY - LEVELING JACKS SET)
  - a. Set leveling jacks and level machine.
  - b. Raise platform to a height of 45 feet (measured deck to ground).
  - c. Enter YES on the Analyzer.
  - d. COMPLETE will show on the analyzer when calibrated.

**NOTE:** Elevation Proximity Switch must be mounted and functioning properly to calibrate the Rotary Angle (Elevation) Sensor.

FOR MACHINE TO OPERATE TO CAPACITY, BE SURE TO CALIBRATE ELEVATION SENSOR AT ALL APPLICABLE POSITIONS.

### Arm Stack Angle Sensor Calibration

If this sensor is not wired correctly or if you have the wrong part number you will get CANBUS FAILURE - ARMSTACK TILT SENSOR

1. Set machine up on a firm level surface and set the leveling jacks and level the machine.
2. Perform an LSS ANGLE SENSOR calibration by navigating to CALIBRATIONS -> LSS ANGLE SENSOR. Follow the steps on the Analyzer. Then cycle power at maximum elevation before lowering the machine.
3. CYCLE POWER - This step is very important! Power must always be cycled between an LSS ANGLE SENSOR and a FULL LOAD CAL.
4. If the machine has a LOAD SENSING SYSTEM navigate to CALIBRATIONS -> FULL LOAD and follow the steps on the Analyzer. This calibration should be performed with 110% of rated load centered in the platform.

While lifting up the lift up button must not be released. While lifting down the lift down button must not be released.


1. After successful calibration of the load sensing system place 120% rated load in the platform and record the height at which LSS activates.
2. Lower the platform to stowed and remove the weight.
3. This completes machine setup/calibration.

### Oscillating Axle Tilt Sensor

If this sensor is not wired correctly or if you have the wrong part number you will get CANBUS FAILURE - OSCILLATING AXLE TILT SENSOR

### Tilt Sensor Calibration

1. Drive the machine onto a measured level surface ( $\pm 0.5^\circ$  for both x and y axis).
2. Using the Analyzer, go to MENU: CALIBRATION; TILT SENSOR. Press Enter. LEVEL VEHICLE will display. Press Enter again to calibrate.
3. Both axis' raw angles need to be within  $\pm 5.0^\circ$ , otherwise the machine is not level and the software will prohibit calibration. Should this occur, attempt to dissect the three areas of error to find the primary contributor:
  - a. Machine mounting and/or grade:  
With a digital level, measure the top of the Ground Control box for levelness. If unable to get a good reading, check the box's mounting surface for levelness.



1. Ground Control Box      2. Digital or Bubble Level

- b. Tilt sensor mounting on machine or wedged crooked in control box:  
If the machine mounting/grade appears acceptable, open the Ground Control box carefully. Observe whether the tilt sensor is properly seated.
- c. Tilt sensor has developed an offset shift:  
Remove the tilt sensor from the Ground Control box, but keep both the tilt sensor and Ground Control box electrically connected. Level one axis of the tilt sensor and observe the raw reading (should be within  $\pm 2.0^\circ$ ). Do the same for the other axis. If either axis is greater than  $\pm 2.0^\circ$ , replace the tilt sensor.

Some possible reasons that the tilt sensor will not calibrate are:

- a. The surface the machine is sitting on is off level by a few degrees (flat doesn't imply level; parking lots are often not level).
- b. The tilt sensor has failed one or both of the channels (X axis and Y axis).
- c. Tilt sensor has moisture intrusion that has shifted its output.
- d. Water and/or corrosion in the box has corrupted electrical connections or caused a tilt sensor or ground control board failure (observe any cracks in the box).
- e. The Ground Control Box, as mounted on the machine, does not allow the tilt sensor to be level.

For the following troubleshooting steps, a bubble level (smaller is better) will be needed and the machine must be on a level surface:

1. On the Analyzer, go to Diagnostics/System and read the tilt angle. If either angle reports  $+20.0^\circ$ , there is an electrical/electronic failure (tilt sensor, control board, electrical connections).
  - a. Open the Ground Control Box.
  - b. Disconnect the sensor and clean any corrosion off of the tilt sensor and control board connections.
  - c. Reassemble and test. If fault persists, replace tilt sensor.
2. If the Analyzer displays angles other than  $+20.0^\circ$ , attempt to calibrate. If machine will not calibrate, note the reason displayed on Analyzer:
  - a. SENSOR FAILURE – tilt sensor internal frequency is out of range (replace sensor).
  - b. NOT LEVEL - tilt sensor has either developed an offset or it is too unlevel as mounted on the machine.

### Leveling Jack Pressure Set Calibration

Perform this calibration procedure whenever the relief valve for the leveling jack retract circuit is checked or adjusted.

**NOTE:** Before beginning this calibration, ensure machine is parked on a firm, level surface and platform is stowed.

1. On the Analyzer, enter Access Level 1, then scroll to the CALIBRATIONS menu.
2. Scroll right to LEVELING JACK PRESSURE SET. Press Enter. Leveling jacks will retract at low engine RPM.
3. Procedure is complete when the Analyzer displays COMPLETE!
4. Cycle power to the machine.

## Drive Minimum Calibration

Use this calibration procedure to easily update drive minimum personality settings (forward and reverse).

### NOTICE

**THE MACHINE WILL MOVE SLIGHTLY IN FORWARD AND REVERSE DIRECTIONS DURING THIS PROCEDURE. ENSURE THERE IS ADEQUATE SPACE FOR MOVEMENT AROUND THE MACHINE.**

**NOTE:** Before beginning this calibration, ensure machine is parked on a firm, level surface, platform is stowed, and high drive mode is engaged on the platform console control box. Calibration will fail if these conditions are not met.

**NOTE:** Pressing ESCAPE any time during this procedure will result in restoration of previous values and requires the procedure be restarted.

1. On the Analyzer, enter Access Level 1, then scroll to the CALIBRATIONS menu.
2. Scroll right to DRV MINIMUM CAL. Press Enter.
3. If all calibration conditions have been met, the Analyzer will prompt DRV FWD MIN CAL: DRIVE, THEN ENTER.
4. Engage the drive forward function while simultaneously pressing the UP arrow on the Analyzer to increase drive forward minimum personality. Once the machine starts moving, release the drive function, then press Enter.
5. The Analyzer will then prompt DRV REV MIN CAL: DRIVE, THEN ENTER.
6. Engage the drive reverse function while simultaneously pressing the UP arrow on the Analyzer to increase drive reverse minimum personality. Once the machine starts moving, release the drive function, then press Enter.
7. Calibration is finished once the Analyzer displays COMPLETE!

## Reset Personality Calibration

Use this procedure to return the machine to default Personality settings. Calibration settings are not affected.

1. On the Analyzer, enter Access Level 1, then scroll to the CALIBRATIONS menu.
2. Scroll right to RESET PERSONALITY. Press Enter.
3. When the Analyzer displays COMPLETE!, all items under the Personalities menu are restored to default values.

**NOTE:** Function speeds must be checked and adjusted accordingly after performing this calibration.



## 5.5 MACHINE SETUP (CONFIGURATION) AND CALIBRATION PROCEDURE

1. The following steps MUST be done in the order specified.
  2. **MACHINE SETUP:**
  3. Configure the machine for the appropriate Market by setting Machine Setup - MARKET to the correct MARKET for the machine build. (Refer to Section 5.6.)
  4. Configure the machine for the appropriate engine by selecting MACHINE SETUP - ENGINE. The engine selection MUST match the engine that is installed on the machine. If it is not correct the engine will not run properly.
  5. Configure the machines Leveling Jacks by setting Leveling Jacks to 1=YES
  6. Configure the machines LOAD SENSING SYSTEM by setting MACHINE SETUP - LOAD to 0. The appropriate selection for the LOAD setting will be set later. Please refer to Section 5.6 to determine the appropriate LOAD setting for MARKET.
  7. Configure the machines BEACON LIGHT by setting the BEACON LIGHT option to 1=YES if the machine is equipped with a BEACON.
  8. Configure the machines AXLE Configuration by setting AXLE CONFIG to 0=FIXED for a fixed axle machine or 1=OSCILLATING for an oscillating axle machine.
  9. **SENSOR CALIBRATIONS:**
  10. Calibrate the CHASSIS TILT sensor by placing the machine on flat level ground and navigating to CALIBRATIONS - CHASSIS TILT.
  11. If the machine is equipped with an Axle Tilt sensor calibrate the AXLE TILT sensor by navigating to CALIBRATIONS -> AXLE TILT.
  12. Calibrate the Platform Joystick by switching to platform mode. Connect the Analyzer to the platform control box. Navigate to CALIBRATIONS -> JOYSTICK and follow the steps to calibrate the joystick.
- NOTE:** *If the joystick has not been calibrated you will not be able to start the engine from the platform control box.*
13. Calibrate the Rotary Angle sensor STOW Elevation with the platform stowed by navigating to CALIBRATIONS -> SET STOW ELEV.
  14. Run the Platform Unlock feature to clear any erroneous Transducer related DTCs by navigating to CALIBRATIONS -> PLTFM UNLOCK.
  15. **CYCLE POWER.** This step is very important! Power must always be cycled after using PLTFM UNLOCK.
  16. Check for any active DTCs. DTCs related to a lack of calibration can be ignored at this time, but other

DTCs should be investigated as they may prevent necessary operation.

17. While you are in the platform place the machine on the leveling jacks by pressing the autolevel button and then pushing the joystick forward. The autolevel button does not need to be held in. Press it one time and the lights will flash. While the lights are flashing you can engage the joystick. The jacks will extend by themselves and will continue to extend until the platform alarm beeps 3 times. The machine should remain on the leveling jacks for the remainder of the calibration procedure.
18. Perform an LSS ANGLE SENSOR calibration by navigating to CALIBRATIONS -> LSS ANGLE SENSOR. Follow the steps on the Analyzer. Leave the machine at max elevation.
19. **CYCLE POWER.** This step is very important! Power must always be cycled after a LSS ANGLE SENSOR Calibration.
20. Elevate the platform to 32ft and calibrate the rotary angle sensor 32ft height by performing CALBRATIONS-> SET 32FT ELEV.
21. If the machine is a CE machine Elevate the platform to 45ft and calibrate the rotary angle sensor 45ft height by performing CALBRATIONS-> SET 45FT ELEV.
22. Lower the platform to stowed.
23. **CYCLE POWER.**
24. If the machine has a LOAD SENSING SYSTEM navigate to CALIBRATIONS -> FULL LOAD and follow the steps on the Analyzer. This calibration should be performed with 110% of rated load centered in the platform. While lifting up the lift up button must not be released. While lifting down the lift down button must not be released.
25. After successful calibration of the load sensing system place 120% rated load in the platform and record the height at which LSS activates.
26. Lower the platform to stowed and remove the weight.
27. This completes machine setup/calibration.



## 5.6 MACHINE CONFIGURATION AND PROGRAMMING SETTINGS

The Machine Configuration Programming must be completed before any Personality settings can be changed. Changing the Personality settings first and then chang-

ing the Model of the Machine Configuration will cause the Personality settings to return to default values.

Configuration Digit	Setting	Description	Default Number
1 (MODEL)	0	33RT 2WD	4
	1	33RT 4WD	
	2	43RT 2WD	
	3	43RT 4WD	
	4	530LRT	
2 (ENGINE)	0	FORD E/F/D/F	7
	1	DEUTZ F3	
	2	FORD D/F (T2)	
	3	DEUTZ F3 (T2)	
	4	DEUTZ ECM	
	5	DUAL FUEL ECM - GM/PSI Engine	
	6	DEUTZ T4F ECM	
	7	KUBOTA T4F	
	8	KUBOTA T4I	
9	KUBOTA D/F ECM		
3 (MARKET)	0	ANSI USA	0
	1	ANSI EXPORT	
	2	CSA	
	3	CE	
4 (GLOW PLUGS)	0	NO GLOW PLUGS	3
	1	5 SEC GLOW	
	2	10 SEC GLOW	
	3	20 SEC GLOW	
	4	30 SEC GLOW	
	5	40 SEC GLOW	
	6	50 SEC GLOW	
	7	60 SEC GLOW	
5 (LEVELING JACKS)	0	No - Leveling Jacks not installed on vehicle.	1
	1	YES - Leveling Jacks are installed on vehicle.	
6 (LOAD)	0	NOT INSTALLED - Load Sensing System (LSS) is not fitted to the vehicle.	0
	1	CUTOUT PLT - Load Sensing System (LSS) is fitted, and Platform Controls are prevented in the event of an Overload. Ground Controls remain functional. This is the default setting for CE machines.	
7 (GROUND ALARM)	2	CUTOUT ALL - Load Sensing System (LSS) is fitted. Platform and Ground Controls are prevented in the event of an Overload.	2
	0	NOT INSTALLED - Vehicle alarm will function for Overload (if LOAD enabled).	
	1	DESCENT - Vehicle alarm will function for Overload (if LOAD enabled) and during Lift Down motion.	
8 (ENGINE SHUTDOWN)	2	MOTION - Vehicle alarm will function for Overload (if LOAD enabled), during Drive motion, and during Lift motion.	1
	0	NO - The engine will not be automatically shutdown.	
9 (LOW TEMP CUTOUT)	1	SHUTDOWN - The engine will automatically shutdown in the event of high engine coolant temperature, low oil pressure, or a temperature sensor or oil pressure sensor fault.	0
	0	NO - The machine will not have low temperature cutout functionality.	
	1	YES - The machine is equipped with low temperature cutout capability for the CE and ANSI EXPORT markets.	

## SECTION 5 - JLG CONTROL SYSTEM

Configuration Digit	Setting	Description	Default Number
10 (BEACON LIGHT)	0	NO - The beacon light will never flash except for when being used by Electronic Arm Guards (CE market). See footnote.	0
	1	YES - The beacon light will flash at 1 Hertz all the time the machine is powered and not being used by Electronic Arm Guards (CE market). See footnote.  <b>NOTE:</b> The beacon light will ALWAYS be used for unique visual indication (flash at 1 Hertz for 2 seconds, then off for 1 second) for the Electronic Arm Guards feature (only equipped on CE market) regardless of the BEACON LIGHT setting.	
11 (AXLE CONFIG)	0	FIXED - The machine is not equipped with an oscillating axle.	0
	1	OSCILLATING - The machine is equipped with an oscillating axle.	
			1001196919_A

**NOTE:** Bold Numbers indicate the default setting for that market. Plain text indicates another available selec-

tion. X indicates hidden menu or selection in that market.

CONFIG. DIGIT	1	2	3	4				5	6	7	8	9	10	11															
530LRT	MODEL NUMBER	ENGINE	MARKET	GLOW PLUG				LEVELING JACKS	LOAD	GROUND ALARM	ENGINE SHUTDOWN	LOW TEMP CUTOUT	BEACON LIGHT	AXLE CONFIG.															
ANSI USA	4	7	X	9	0	0	1	2	3	X	X	X	X	0	1	0	X	X	0	1	2	0	1	0	X	0	1	0	1
ANSI EXPORT	4	7	8	9	1	0	1	2	3	X	X	X	X	0	1	0	1	X	0	1	2	0	1	0	1	0	1	0	1
CSA	4	7	X	9	2	0	1	2	3	X	X	X	X	0	1	0	X	X	0	1	2	0	1	0	X	0	1	0	1
CE	4	X	8	X	3	0	1	2	3	X	X	X	X	0	1	0	X	2	0	1	2	0	1	0	1	0	1	0	1
AUSTRALIA	4	7	X	9	4	0	1	2	3	X	X	X	X	0	1	0	1	X	X	X	2	0	1	0	X	0	1	0	1
														1001196919_A															

### Machine Tilt Configuration

Model	Market	Lift Up and Drive prevented when Elevated and Tilted Front to Back beyond the following limits:	Lift Up and Drive prevented when Elevated and Tilted Side to Side beyond the following limits:	Drive prevented when Elevated beyond the following heights (regardless of tilt):	Lift Up prevented when Elevated beyond the following heights without outriggers deployed (regardless of tilt):
530LRT	ANSI USA	± 5° to 32 Feet ± 1.5° to 53 Feet	± 4° to 32 Feet ± 1.5° to 53 Feet	32 Feet	32 Feet
	ANSI EXPORT	± 5° to 32 Feet ± 1.5° to 53 Feet	± 4° to 32 Feet ± 1.5° to 53 Feet	32 Feet	32 Feet
	CSA	± 3° to 32 Feet ± 1.5° to 53 Feet	± 3° to 32 Feet ± 1.5° to 53 Feet	32 Feet	32 Feet
	CE	± 5° to 32 Feet ± 1.3° to 45 Feet, Jacks Not Set ± 1.5° to 53 Feet, Jacks Set	± 3° to 32 Feet ± 1.3° to 45 Feet, Jacks Not Set ± 1.5° to 53 Feet, Jacks Set	32 Feet	45 Feet
	AUSTRALIA	± 5° to 32 Feet ± 1.3° to 45 Feet, Jacks Not Set ± 1.5° to 53 Feet, Jacks Set	± 3° to 32 Feet ± 1.3° to 45 Feet, Jacks Not Set ± 1.5° to 53 Feet, Jacks Set	32 Feet	45 Feet
					1001196919_A

## Machine Model Personality Adjustment

Adjustment	Adjustment Range	Model Default Values
		530LRT
<b>DRIVE</b>		
Accel	0.1 - 5.0 (sec)	3.0
Decel	0.1 - 3.0 (sec)	1.5
Min Forward	0 - 30%	25
Rabbit Forward	40 - 65%	55
Torque Forward	45 - 70%	50
Turtle Forward	22 - 47%	42
Min Reverse	0 - 30%	25
Rabbit Reverse	40 - 65%	50
Torque Reverse	45 - 70%	50
Turtle Reverse	22 - 47%	42
Elev Fwd Max	16 - 41%	29
Elev Rev Max	16 - 41%	29
<b>LIFT</b>		
Accel	0.1 - 5.0 (sec)	2.0
Decel	0.1 - 1.5 (sec)	0.7
Min Up	0 - 35%	20
Max Up	0 - 100%	100
Min Down	0 - 35%	20
Max Down	0 - 100%	100
<b>GROUND</b>		
Lift Up	0 - 100%	100
Lift Down	0 - 100%	100
<b>LOAD</b>		
Overload Dbnce	0 - 10 (sec)	0.7
Overload Hold	1 - 10 (sec)	3.0
<b>JOYSTICK</b>		
Forward Max	0.00 - 5.00V	1.25
Forward Min	0.00 - 5.00V	2.57
Reverse Min	0.00 - 5.00V	3.28
Reverse Max	0.00 - 5.00V	4.63
<b>TEMP CUTOUT</b>		
Cutout Set	-30 - 0	-27
Offset	0 - 15	5
		1001196918_F
<b>NOTE:</b> These settings may be changed in order to achieve optimal performance.		

# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

**Search Manuals**

Enter your information to search for manuals and parts.

\* Brand:

\* Model:

\* Serial:

\* Part Number:

SEARCH

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

**Parts Order Form**

Please fill in the following information:

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Part Name:

Part Description:

Part Category:

Part Location:

Part Status:

Part Price:

Part Weight:

Part Dimensions:

Part Material:

Part Color:

Part Finish:

Part Notes:

Part Comments:

Part Attachments:

Part Images:

Part Videos:

Part Documents:

Part Links:

Part Other:

Part Status:

Part Price:

Part Weight:

Part Dimensions:

Part Material:

Part Color:

Part Finish:

Part Notes:

Part Comments:

Part Attachments:

Part Images:

Part Videos:

Part Documents:

Part Links:

Part Other:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar



## SECTION 6. GENERAL ELECTRICAL INFORMATION & SCHEMATICS

### 6.1 GENERAL

This section contains schematics to be used for locating and correcting most of the operating problems which may develop. If a problem should develop which is not

presented in this section or which is not corrected by listed corrective actions, technically qualified guidance should be obtained before proceeding with any maintenance.

### NOTICE

IT IS A GOOD PRACTICE TO AVOID PRESSURE-WASHING ELECTRICAL/ELECTRONIC COMPONENTS. SHOULD PRESSURE-WASHING BE UTILIZED TO WASH AREAS CONTAINING ELECTRICAL/ELECTRONIC COMPONENTS, JLG INDUSTRIES, INC. RECOMMENDS A MAXIMUM PRESSURE OF 750 PSI (52 BAR) AT A MINIMUM DISTANCE OF 12 INCHES (30.5 CM) AWAY FROM THESE COMPONENTS. IF ELECTRICAL/ELECTRONIC COMPONENTS ARE SPRAYED, SPRAYING MUST NOT BE DIRECT AND BE FOR BRIEF TIME PERIODS TO AVOID HEAVY SATURATION.

### 6.2 MULTIMETER BASICS

A wide variety of multimeters or Volt Ohm Meters (VOM) can be used for troubleshooting your equipment. A digital meter with reasonable accuracy (within 7%) is recommended for the measurements in these procedures. This section shows diagrams of a common, digital VOM configured for several different circuit measurements. Instructions for your VOM may vary. Please consult the meter operator's manual for more information.

#### Grounding

"Grounding the meter" means to take the black lead (which is connected to the COM (common) or negative port) and touch it to a good path to the negative side of the voltage source.

#### Backprobing

To "backprobe" means to take the measurement by accessing a connector's contact on the same side as the wires, the back of the connector. Readings can be done while maintaining circuit continuity this way. If the connector is the sealed type, great care must be taken to avoid damaging the seal around the wire. It is best to use probes or probe tips specifically designed for this technique, especially on sealed connectors. Whenever possible insert probes into the side of the connector such that the test also checks both terminals of the connection. It is possible to inspect a connection within a closed connector by backprobing both sides of a connector terminal and measuring resistance. Do this after giving each wire a gentle pull to ensure the wires are still attached to the contact and contacts are seated in the connector.

#### Min/Max

Use of the "Min/Max" recording feature of some meters can help when taking measurements of intermittent conditions while alone. For example, you can read the voltage applied to a solenoid when it is only operational while a switch, far from the solenoid and meter, is held down.

#### Polarity

Finding a negative voltage or current reading when expecting a positive reading frequently means the leads are reversed. Check what reading is expected, the location of the signal and that the leads are connected to the device under test correctly. Also check that the lead on the "COM" port goes to the ground or negative side of the signal and the lead on the other port goes to the positive side of the signal.

#### Scale

M = Mega = 1,000,000 \* (Displayed Number)

k = kilo = 1,000 \* (Displayed Number)


m = milli = (Displayed Number) / 1,000

$\mu$  = micro = (Displayed Number) / 1,000,000

Example: 1.2 k $\Omega$  = 1200  $\Omega$


Example: 50 mA = 0.05 A

### Voltage Measurement




- If meter is not auto ranging, set it to the correct range (See multimeter's operation manual)
- Use firm contact with meter leads

### Resistance Measurement




- First test meter and leads by touching leads together. Resistance should read a short circuit (very low resistance)
- Circuit power must be turned OFF before testing resistance
- Disconnect component from circuit before testing
- If meter is not auto ranging, set it to the correct range (See multimeter's operation manual)
- Use firm contact with meter leads



**Continuity Measurement**

- Some meters require a separate button press to enable audible continuity testing
- Circuit power must be turned OFF before testing continuity
- Disconnect component from circuit before testing
- Use firm contact with meter leads
- First test meter and leads by touching leads together. Meter should produce an audible alarm, indicating continuity

**Current Measurement**

- Set up the meter for the expected current range
- Be sure to connect the meter leads to the correct jacks for the current range you have selected
- If meter is not auto ranging, set it to the correct range (See multi meter's operation manual)
- Use firm contact with meter leads

### Continuity Measurement Over Long Distances

When trying to determine continuity of a harness or wire, longer than the reach of standard instrument leads, is possible to perform the check without excessively long leads. Using the other wires in the harness one can determine the condition of a particular wire in the harness.

#### Requirements:

- Harness with at least three separate wires including the wire under test.
- These wires must be able to be isolated from other wires, etc.
- Jumper or method to connect contacts on one side of harness.
- Meter that can measure resistance or continuity.

#### Procedure

Test multimeter leads resistance. Subtract this value from the measured resistance of the wires to get a more accurate measurement.

Consult the circuit schematic to determine which wires to use in addition to wire under test, here called wire #1 and wire #2, and how to isolate these wires. These wires should appear in the same connectors as the wire under test or are within reach of the jumper.

1. Disconnect all connections associated with the wire under test and the two additional wires. If harness is not completely isolated disconnect battery terminals also, as a precaution.
2. Measure continuity between all three wires, the wire under test, wire #1 and wire #2. These should be open. If not, repair the shorted wires or replace the harness.
3. On one side, jumper from contact of wire #1 and wire #2.
4. Measure continuity between wire #1 and wire #2. If there is continuity, both wires are good and can be used for this test. If there is not continuity, either wire could be bad. Check connections and measurement setup. Redo measurement. If still no continuity, repair wires or consult schematic for other wires to use for test.
5. Jumper from wire under test to wire #1.
6. Measure continuity. If there is continuity, the wire under test is good. Resistance of a wire increases as the length increases and as the diameter decreases.

One can find the continuity of two wires, here #1 and #2, at once by following steps 1 through 4. If there is a problem the third wire is used to troubleshoot the other wires. To find the problem, start at step 1 and use the entire procedure.

### 6.3 APPLYING SILICONE DIELECTRIC COMPOUND TO AMP CONNECTORS

Silicone Dielectric Compound must be used on the AMP connections for the following reasons:

- To prevent oxidation at the mechanical joint between male and female pins.
- To prevent electrical malfunction caused by low level conductivity between pins when wet.

Use the following procedure to apply Silicone Dielectric Compound to the electrical connectors.

1. To prevent oxidation and low level conductivity, silicone dielectric grease must be packed completely

around male and female pins on the inside of the connector after the mating of the housing to the header. This is easily achieved by using a syringe to fill the header with silicone dielectric compound, to a point just above the top of the male pins inside the header. When assembling the housing to the header, it is possible that the housing will become air locked, thus preventing the housing latch from engaging.

2. Pierce one of the unused wire seals to allow the trapped air inside the housing to escape.
3. Install a hole plug into this and/or any unused wire seal that has silicone dielectric compound escaping from it.





Figure 6-1. AMP Connector


**Assembly**

Check to be sure the wedge lock is in the open, or as-shipped, position (See Figure 6-2. Connector Assembly (1 of 4)). Proceed as follows:




**Figure 6-2. Connector Assembly (1 of 4)**


1. To insert a contact, push it straight into the appropriate circuit cavity as far as it will go (See Figure 6-3. Connector Assembly (2 of 4)).
2. Pull back on the contact wire with a force of 1 or 2 lbs. to be sure the retention fingers are holding the contact (See Figure 6-3. Connector Assembly (2 of 4)).
3. After all required contacts have been inserted, the wedge lock must be closed to its locked position. Release the locking latches by squeezing them inward (See Figure 6-4. Connector Assembly (3 of 4)).
4. Slide the wedge lock into the housing until it is flush with the housing (See Figure 6-5. Connector Assembly (4 of 4)).



**Figure 6-3. Connector Assembly (2 of 4)**




**Figure 6-4. Connector Assembly (3 of 4)**



**Figure 6-5. Connector Assembly (4 of 4)**

**Disassembly**

1. Insert a 4.8 mm (3/16") wide screwdriver blade between the mating seal and one of the red wedge lock tabs.
2. Pry open the wedge lock to the open position.
3. While rotating the wire back and forth over a half turn (1/4 turn in each direction), gently pull the wire until the contact is removed.

**Figure 6-6. Connector Disassembly**

**NOTE:** The wedge lock should never be removed from the housing for insertion or removal of the contacts.

**Wedge Lock**

The wedge lock has slotted openings in the forward, or mating end. These slots accommodate circuit testing in the field, by using a flat probe such as a pocket knife. DO NOT use a sharp point such as an ice pick.


### Service - Voltage Reading

**⚠ CAUTION**

**DO NOT PIERCE WIRE INSULATION TO TAKE VOLTAGE READINGS.**

It has been common practice in electrical troubleshooting to probe wires by piercing the insulation with a


sharp point. This practice should be discouraged when dealing with the AMPSEAL plug assembly, or any other sealed connector system. The resulting pinholes in the insulation will allow moisture to invade the system by traveling along the wire strands. This nullifies the effectiveness of the connector seals and could result in system failure.



**Figure 6-7. Connector Installation**

## 6.4 WORKING WITH DEUTSCH CONNECTORS

### DT/DTP Series Assembly



**Figure 6-8. DT/DTP Contact Installation**

1. Grasp crimped contact about 25mm behind the contact barrel.
2. Hold connector with rear grommet facing you.
3. Push contact straight into connector grommet until a click is felt. A slight tug will confirm that it is properly locked in place.
4. Once all contacts are in place, insert wedgelock with arrow pointing toward exterior locking mechanism. The wedgelock will snap into place. Rectangular wedges are not oriented. They may go in either way.

**NOTE:** The receptacle is shown - use the same procedure for plug.


### DT/DTP Series Disassembly



**Figure 6-9. DT/DTP Contact Removal**


1. Remove wedgelock using needlenose pliers or a hook shaped wire to pull wedge straight out.
2. To remove the contacts, gently pull wire backwards, while at the same time releasing the locking finger by moving it away from the contact with a screwdriver.
3. Hold the rear seal in place, as removing the contact may displace the seal.

### HD30/HDP20 Series Assembly



**Figure 6-10. HD/HDP Contact Installation**

1. Grasp contact about 25mm behind the contact crimp barrel.
2. Hold connector with rear grommet facing you.
3. Push contact straight into connector grommet until a positive stop is felt. A slight tug will confirm that it is properly locked in place.



**Figure 6-11. HD/HDP Locking Contacts Into Position**

**NOTE:** For unused wire cavities, insert sealing plugs for full environmental sealing

### HD30/HDP20 Series Disassembly



**Figure 6-12. HD/HDP Contact Removal**

1. With rear insert toward you, snap appropriate size extractor tool over the wire of contact to be removed.
2. Slide tool along into the insert cavity until it engages contact and resistance is felt.
3. Pull contact-wire assembly out of connector.



**Figure 6-13. HD/HDP Unlocking Contacts**

**NOTE:** Do Not twist or insert tool at an angle.



## 6.5 SWITCHES

### Basic check

The following check determines if the switch is functioning properly, not the circuit in which the switch is placed. A switch is functioning properly when there is continuity between the correct terminals or contacts only when selected.

1. De-energize the circuit.
2. Isolate the switch from the rest of the circuit if possible. If not possible, keep in mind it may affect readings.
3. Access the terminals to the switch.
4. If the switch has two terminals:
  - a. Measure resistance across the terminals.
  - b. Change the switch position.
  - c. Measure resistance again with the leads in the same positions. If the meter was reading short, it should read an open. If the meter was reading open it should read short.
5. If the switch has more than two terminals, consult the schematic or switch diagram to determine what terminals will be connected. The test is similar to testing a switch with two terminals.
  - a. Place one meter lead on the common contact and the other on a different contact in the same circuit.
  - b. Cycle through all positions of the switch. The meter should read short only when the switch connects the two terminals and open otherwise.
  - c. If the switch has more than one common contact repeat the process for that circuit.

### Limit Switches

Limit switches are used to control movement or indicate position. Mechanical limit switches are just like manually operated switches except that the moving object operates the switch. These switches can be tested the same way as a standard switch by manually operating the sensing arm.

Another type of limit switch used by JLG is the inductive proximity switch, also referred to as a "prox switch". Inductive proximity switches are actuated only by ferrous metal (metal that contains Iron, such as steel) near the switch. They do not require contact, and must be energized to actuate. These types of switches can be used to detect boom or platform position, for example. These switches have a sensing face where the switch can detect ferrous metal close to it. To find the sensing face, take note how the switch is mounted and how the mechanisms meet the switch. Test this type of switch as follows:

1. Remove prox switch from its mount.
2. Reconnect harness if it was disconnected for step a, and turn on machine.
3. Hold switch away from metal and observe switch state in the control system diagnostics using the Analyzer. See vehicle or control system documentation on how to do this.
4. Place sensing face of switch on the object to be sensed by the switch. If that is not available, use a piece of ferrous metal physically similar to it. The switch state in the control system diagnostics should change.
5. When reinstalling or replacing switch be sure to follow mounting instructions and properly set the gap between the switch and object sensed.

### Automatic Switches

If the switch is actuated automatically, by temperature or pressure for example, find a way to manually actuate the switch to test it. Do this either by applying heat or pressure, for example, to the switch. These switches may need to be energized to actuate.

1. Connect instrumentation to monitor and/or control the parameter the switch is measuring.
2. Observe switch state in control system with the Analyzer. See vehicle or control system documentation on how to do this.
3. Operate system such that the switch actuates. This could be going over a certain pressure or temperature, for example. The state indicated in the control system should change.

### Switch Wiring - Low Side, High Side

When controlling a load, a switch can be wired between the positive side of the power source and the load. This switch is called a "high side" switch. The switch supplies the power to the load. When a switch is wired between the negative side of the power source and the load, it is a "low side" switch. The switch provides the ground to the load.

A low side switch will allow voltage to be present on the load. No power is applied because the switch is stopping current flow. This voltage can be seen if the measurement is taken with one test lead on the load and the other on the battery negative side or grounded to the vehicle. What is actually being measured is the voltage drop across the switch. This could mislead a technician into thinking the load is receiving power but not operating. To produce an accurate picture of power or voltage applied to the load, measure voltage across the load's power terminals. Also, the technician can measure the voltage at both power terminals with respect to battery ground. The difference between those two measurements is the voltage applied to the load.


Go to Discount-Equipment.com





**SECTION 6 - GENERAL ELECTRICAL INFORMATION & SCHEMATICS**

**Platform Controls**




MAD000250  
1001191631-K

Go to Mount-Equipment.com to order your parts



SECTION 6 - GENERAL ELECTRICAL INFORMATION & SCHEMATICS

Kubota Diesel Engine













6.7 HYDRAULIC SCHEMATICS



MAD000310  
1001181764-E

Oscillating Axle Valve



MAD00320  
1001181764E



3121708

**JLG**<sup>®</sup>

An Oshkosh Corporation Company

**Discount  
Equipment**

[www.Discount-Equipment.com](http://www.Discount-Equipment.com)

Go to [Discount-Equipment.com](http://Discount-Equipment.com) to order your parts