



An Oshkosh Corporation Company



www.Discount-Equipment.com

---

# Service and Maintenance Manual


**Models**  
**400SC**  
**460SJC**

**3121705**

January 07, 2019 - Rev E

**ANSI**

**CE**



# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

**Search Manuals**

Enter your information to search for manuals and parts.

\* Brand:

\* Model:

\* Serial:

\* Part Number:

SEARCH

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

**Parts Order Form**

Please fill in the following information:

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Part Name:

Part Description:

Part Category:

Part Location:

Part Status:

Part Condition:

Part Material:

Part Color:

Part Weight:

Part Dimensions:

Part Price:

Part Notes:

Submit

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

## SECTION A. INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS

### A GENERAL

This section contains the general safety precautions which must be observed during maintenance of the aerial platform. It is of utmost importance that maintenance personnel pay strict attention to these warnings and precautions to avoid possible injury to themselves or others, or damage to the equipment. A maintenance program must be followed to ensure that the machine is safe to operate.

#### **⚠ WARNING**

**MODIFICATION OR ALTERATION OF AN AERIAL WORK PLATFORM SHALL BE MADE ONLY WITH WRITTEN PERMISSION FROM THE MANUFACTURER.**

The specific precautions to be observed during maintenance are inserted at the appropriate point in the manual. These precautions are, for the most part, those that apply when servicing hydraulic and larger machine component parts.

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

#### **⚠ WARNING**

**SINCE THE MACHINE MANUFACTURER HAS NO DIRECT CONTROL OVER THE FIELD INSPECTION AND MAINTENANCE, SAFETY IN THIS AREA RESPONSIBILITY OF THE OWNER/OPERATOR.**

### B HYDRAULIC SYSTEM SAFETY

It should be noted that the machines hydraulic systems operate at extremely high potentially dangerous pressures. Every effort should be made to relieve any system pressure prior to disconnecting or removing any portion of the system.

Do not use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks. Wear gloves to help protect hands from spraying fluid.



### C MAINTENANCE

#### **⚠ WARNING**

**FAILURE TO COMPLY WITH SAFETY PRECAUTIONS LISTED IN THIS SECTION COULD RESULT IN MACHINE DAMAGE, PERSONNEL INJURY OR DEATH AND IS A SAFETY VIOLATION.**

- ENSURE REPLACEMENT PARTS OR COMPONENTS ARE IDENTICAL OR EQUIVALENT TO ORIGINAL PARTS OR COMPONENTS.
- NO SMOKING IS MANDATORY. NEVER REFUEL DURING ELECTRICAL STORMS. ENSURE THAT FUEL CAP IS CLOSED AND SECURE AT ALL OTHER TIMES.
- REMOVE ALL RINGS, WATCHES AND JEWELRY WHEN PERFORMING ANY MAINTENANCE.
- DO NOT WEAR LONG HAIR UNRESTRAINED, OR LOOSE-FITTING CLOTHING AND NECKTIES WHICH ARE APT TO BECOME CAUGHT ON OR ENTANGLED IN EQUIPMENT.
- OBSERVE AND OBEY ALL WARNINGS AND CAUTIONS ON MACHINE AND IN SERVICE MANUAL.
- KEEP OIL, GREASE, WATER, ETC. WIPED FROM STANDING SURFACES AND HAND HOLDS.
- USE CAUTION WHEN CHECKING A HOT, PRESSURIZED COOLANT SYSTEM.
- NEVER WORK UNDER AN ELEVATED BOOM UNTIL BOOM HAS BEEN SAFELY RESTRAINED FROM ANY MOVEMENT BY BLOCKING OR OVERHEAD SLING, OR BOOM SAFETY PROP HAS BEEN ENGAGED.
- BEFORE MAKING ADJUSTMENTS, LUBRICATING OR PERFORMING ANY OTHER MAINTENANCE, SHUT OFF ALL POWER CONTROLS.
- BATTERY SHOULD ALWAYS BE DISCONNECTED DURING REPLACEMENT OF ELECTRICAL COMPONENTS.
- KEEP ALL SUPPORT EQUIPMENT AND ATTACHMENTS STOWED IN THEIR PROPER PLACE.
- USE ONLY APPROVED, NONFLAMMABLE CLEANING SOLVENTS.

**REVISION LOG**

Original Issue	A - October 23, 2015
Revised	B - March 07, 2017
Revised	C - June 29, 2018
Revised	D - August 24, 2018
Revised	E - January 07, 2019 - Revised pages 4-42, 4-43

Go to [Discount-Equipment.com](http://Discount-Equipment.com) to order your parts

<b>SECTION NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
<b>SECTION A - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS</b>		
A	General .....	A-1
B	Hydraulic System Safety .....	A-1
C	Maintenance .....	A-1
<b>SECTION 1 - SPECIFICATIONS</b>		
1.1	Operating Specifications .....	1-1
1.2	Capacities .....	1-2
1.3	Engine Data .....	1-2
1.4	Hydraulic Oil .....	1-3
1.5	Critical Stability Weights .....	1-4
1.6	Maintenance and Lubrication .....	1-5
<b>SECTION 2 - GENERAL</b>		
2.1	Machine Preparation, Inspection, and Maintenance .....	2-1
	General .....	2-1
	Preparation, Inspection, and Maintenance .....	2-1
	Pre-Start Inspection .....	2-1
	Pre-Delivery Inspection and Frequent Inspection .....	2-1
	Annual Machine Inspection .....	2-1
	Preventive Maintenance .....	2-1
2.2	Service and Guidelines .....	2-2
	General .....	2-2
	Safety and Workmanship .....	2-2
	Cleanliness .....	2-2
	Components Removal and Installation .....	2-2
	Component Disassembly and Reassembly .....	2-3
	Pressure-Fit Parts .....	2-3
	Bearings .....	2-3
	Gaskets .....	2-3
	Bolt Usage and Torque Application .....	2-3
	Hydraulic Lines and Electrical Wiring .....	2-3
	Hydraulic System .....	2-3
	Lubrication .....	2-3
	Battery .....	2-3
	Lubrication and Servicing .....	2-3
2.3	Lubrication and Information .....	2-4
	Hydraulic System .....	2-4
	Hydraulic Oil .....	2-4
	Changing Hydraulic Oil .....	2-4
	Lubrication Specifications .....	2-4
2.4	Cylinder Drift .....	2-4
	Theory .....	2-4
	Cylinder Leakage Test .....	2-5
	Cylinder Thermal Drift .....	2-5
2.5	Pins and Composite Bearing Repair Guidelines .....	2-5
2.6	Welding on JLG Equipment .....	2-5
	Do the Following When Welding on JLG Equipment .....	2-5
	Do NOT Do the Following When Welding on JLG Equipment .....	2-5

**TABLE OF CONTENTS**

<b>SECTION NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
<b>SECTION 3 - CHASSIS &amp; TURNTABLE</b>		
3.1	Chassis Components and Servicing .....	3-1
	Track Tension .....	3-2
	Replace Rubber Track.....	3-3
	Replace Steel Track.....	3-5
	Track Shoes .....	3-8
	Track Pin .....	3-8
	Sprocket Wear.....	3-8
3.2	Chassis Tilt Indicator System .....	3-8
3.3	Swing Drive Hub .....	3-8
	Brake Test .....	3-9
	Spring Checking Procedure .....	3-9
	Brake Leak Repair Procedure .....	3-10
	Roll and Leak Test .....	3-10
	Tightening and Torquing Bolts.....	3-11
	Lubrication Information .....	3-12
	Motor Removal.....	3-12
	Input Brake Disassembly.....	3-14
	Main Disassembly .....	3-15
	Housing-Shaft Disassembly.....	3-16
	Carrier Disassembly.....	3-17
	Carrier Assembly .....	3-18
	Housing - Shaft Assembly.....	3-20
	Main Assembly .....	3-21
	Motor and Brake Assembly .....	3-23
	Motor Control Valve Installation.....	3-25
3.4	Swing Motor .....	3-34
	Disassembly and inspection .....	3-34
	Assembly .....	3-41
	One Piece Stator Construction .....	3-48
3.5	Swing Bearing.....	3-49
	Swing Bearing Wear Tolerance .....	3-49
	Turntable Bearing Mounting Bolt Condition Check .....	3-50
	Swing Bearing Removal.....	3-53
	Swing Bearing Installation .....	3-53
3.6	Setting Swing Gear Backlash.....	3-54
3.7	Swing Bearing Torque Values .....	3-55
3.8	Rotary Coupling .....	3-57
3.9	Generator .....	3-62
	Maintenance Schedule .....	3-62
	Overload Protection .....	3-62
	Inspecting Brushes, Replacing Brushes and Cleaning Slip Rings .....	3-62
	Generator Disassembly and Assembly.....	3-64
	Lead Connection List for Generator .....	3-71
3.10	Deutz Engine (D2011I03) - T4i.....	3-72
	Checking Oil Level.....	3-76
	Changing Engine Oil.....	3-76
	Changing Oil Filter .....	3-77
	Replace Fuel Filter .....	3-77
	Clean Fuel Strainer .....	3-78
3.11	Deutz Engine (D2.9L4) - T4f .....	3-79
	Check Oil Level.....	3-83
	Change Engine Oil.....	3-83
	Change Oil Filter .....	3-84
	Change Fuel Filters .....	3-84
3.12	Engine Fault Codes .....	3-85

<b>SECTION NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
<b>SECTION 4 - BOOM &amp; PLATFORM</b>		
4.1	Boom Systems .....	4-1
	Platform Control Enable System .....	4-1
	Platform Load Sensing System (LSS) (If Equipped) .....	4-1
	Above Elevation (Above Horizontal) - Drive Speed Cutback System .....	4-1
	Transport Position Interlock System .....	4-1
	Function Speed Control System .....	4-1
	Emergency Decent System .....	4-1
	Main Boom Lift End of Stroke Damping .....	4-2
	Jib Lift End of Stroke Damping .....	4-2
	Machine Safety Override (MSSO) (CE Market Only) .....	4-2
	Transport Position Sensing System .....	4-2
	Dual Capacity Selection and Indicator System .....	4-6
4.2	Platform .....	4-8
	Platform/Support Removal .....	4-8
	Platform/Support Installation .....	4-9
4.3	Main Boom Powertrack .....	4-12
	Removal .....	4-12
	Installation .....	4-12
	Powertrack Maintenance .....	4-14
4.4	Boom Maintenance .....	4-23
	Removal - 400SC .....	4-23
	Removal - 460SJC .....	4-27
	Disassembly .....	4-31
	Inspection .....	4-33
	Assembly .....	4-33
	Installation .....	4-34
4.5	Jib - 460SJC .....	4-34
4.6	Boom Cleanliness Guidelines .....	4-35
4.7	Boom Shimming Procedure .....	4-36
4.8	Rotary Actuator .....	4-41
	Theory of Operation .....	4-41
	Required Tools .....	4-41
	Disassembly .....	4-43
	Inspection .....	4-47
	Assembly .....	4-48
	Installing Counterbalance Valve .....	4-52
4.9	Skyguard .....	4-53
	Operation .....	4-53
	Function Test .....	4-53
	Diagnostics & Troubleshooting .....	4-54
4.10	Platform Rotate Bleed Procedure .....	4-55
	General Notes & Precautions .....	4-55
	Procedure .....	4-55
<b>SECTION 5 - HYDRAULICS AND HYDRAULIC SCHEMATICS</b>		
5.1	O-Ring Lubrication .....	5-1
	Cup and Brush .....	5-1
	Dip Method .....	5-2
	Spray Method .....	5-2
	Brush-on Method .....	5-2

## TABLE OF CONTENTS

SECTION NO.	TITLE	PAGE NO.
5.2	Hydraulic Connection Assembly and Torque Specification .....	5-3
	Tapered Thread Types .....	5-3
	Straight Thread Types, Tube and Hose Connections .....	5-3
	Straight Thread Types, Port Connections .....	5-4
	Flange Connection Types .....	5-4
	Tightening Methods .....	5-4
	Assembly And Torque Specifications .....	5-5
	Assembly Instructions for American Standard Pipe Thread Tapered (NPTF) Connections.....	5-6
	Assembly Instructions for British Standard Pipe Thread Tapered (BSPT) Connections.....	5-7
	Assembly Instructions for 37° (JIC) Flare Fittings .....	5-8
	Assembly Instructions for 45° SAE Flare Fittings.....	5-11
	Assembly Instructions for O-ring Face Seal (ORFS) Fittings .....	5-13
	Assembly Instructions for DIN 24° Flare Bite Type Fittings (MBTL and MBTS) .....	5-15
	Assembly Instructions for Bulkhead (BH) Fittings .....	5-17
	Assembly Instructions for O-ring Boss (ORB) Fittings .....	5-20
	Assembly Instructions for Adjustable Port End Metric (MFF) Fittings.....	5-27
	Assembly Instructions for Metric ISO 6149 (MPP) Port Assembly Stud Ends .....	5-34
	Assembly instructions for Adjustable Port End (BSPP) Fittings .....	5-36
	Assembly Instructions for Flange Connections: (FL61 and FL62) .....	5-43
	Double Wrench Method .....	5-46
	FFWR and TFFT Methods.....	5-47
	Adjustable Stud End Assembly.....	5-47
	O-ring Installation (Replacement) .....	5-48
5.3	Hydraulic Cylinders .....	5-49
	Lift Cylinder .....	5-51
	Master Cylinder .....	5-57
	Telescope Cylinder .....	5-62
	Jib Lift Cylinder (460SJ Only).....	5-69
	Platform Level Cylinder .....	5-75
5.4	Hydraulic System Installation .....	5-80
5.5	Pressure Setting Procedure .....	5-111
	Main System Relief .....	5-111
	Steer Left Relief.....	5-111
	Steer Right Relief .....	5-112
	Boom Swing Relief .....	5-112
	Jib Lift Down Relief (460SJ) .....	5-113
	Platform Level Up Relief .....	5-113
	Platform Level Down Relief .....	5-114
5.6	Drive Pump Pre-Fill Procedure .....	5-121
5.7	Hydraulic Schematic.....	5-122
<b>SECTION 6 - JLG CONTROL SYSTEM</b>		
6.1	JLG Control System Analyzer Kit Instructions .....	6-1
	Introduction.....	6-1
	To Connect the JLG Control System Analyzer .....	6-2
	Using the Analyzer .....	6-2
	Changing the Access Level of the Hand Held Analyzer .....	6-3
	Adjusting Parameters Using Hand Held Analyzer .....	6-4
	Machine Setup .....	6-5
	Ground Control Console Display Gauge .....	6-6
6.2	LSS System .....	6-33
	Diagnostic Menu .....	6-34
	Calibration Procedure .....	6-35
	Testing & Evaluation.....	6-40
	Troubleshooting .....	6-41
6.3	Resetting The MSSO System .....	6-42



<b>SECTION NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
6.4	Machine Model Adjustment .....	6-44
	Adjustment Notes .....	6-44
	Machine Orientation When Performing Test .....	6-44
6.5	System Test .....	6-50
	Test from the Platform .....	6-50
	Test from the Ground Station .....	6-52
6.6	System Test Messages .....	6-54
6.7	Machine Diagnostics Parameters .....	6-56
6.8	Machine Fault Codes .....	6-68
6.9	Tilt Sensor Calibration .....	6-95
6.10	Calibrating Boom Angle .....	6-99
6.11	Calibrating Load Sensing .....	6-103
<b>SECTION 7</b>	<b>- BASIC ELECTRICAL INFORMATION &amp; ELECTRICAL SCHEMATICS</b>	
7.1	General .....	7-1
7.2	Multimeter Basics .....	7-1
	Grounding .....	7-1
	Backprobing .....	7-1
	Min/Max .....	7-1
	Polarity .....	7-1
	Scale .....	7-1
	Voltage Measurement .....	7-1
	Resistance Measurement .....	7-2
	Continuity Measurement .....	7-2
	Current Measurement .....	7-3
7.3	Applying Silicone Dielectric Compound to Electrical Connections .....	7-3
	Installation of Dielectric Grease .....	7-4
	Deutsch HD, DT, DTM, DRC Series .....	7-4
	AMP Seal .....	7-4
	AMP Mate-N-Lok .....	7-5
	DIN Connectors .....	7-5
	Exclusions .....	7-5
7.4	AMP Connector .....	7-7
	Assembly .....	7-7
	Disassembly .....	7-9
	Wedge Lock .....	7-9
	Service - Voltage Reading .....	7-9
7.5	Deutsch Connectors .....	7-11
	DT/DTP Series Assembly .....	7-11
	DT/DTP Series Disassembly .....	7-11
	HD30/HDP20 Series Assembly .....	7-12
	HD30/HDP20 Series Disassembly .....	7-12
7.6	Wiring Harness .....	7-13
	Connector Labels .....	7-13
	Component Labels .....	7-13
7.7	Electrical Installation .....	7-15
7.8	Wiring Harness Connector Label Diagrams .....	7-19
7.9	Electrical Schematics .....	7-89

<b>FIGURE NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
1-1.	Maintenance and Lubrication Diagram - Deutz D2011L03.....	1-6
1-2.	Maintenance and Lubrication Diagram - Deutz 2.9L4 .....	1-7
1-3.	Torque Chart - Sheet 1 of 5 - (SAE Fasteners).....	1-11
1-4.	Torque Chart - Sheet 2 of 5 - (SAE Fasteners).....	1-12
1-5.	Torque Chart - Sheet 3 of 5 - (SAE Fasteners).....	1-13
1-6.	Torque Chart - Sheet 4 of 5 - (METRIC Fasteners).....	1-14
1-7.	Torque Chart - Sheet 5 of 5 - (METRIC Fasteners).....	1-15
2-1.	Engine Operating Temperature Specifications - Deutz D2011 .....	2-9
2-2.	Engine Operating Temperature Specifications - Deutz 2.9 L04.....	2-10
2-3.	Hydraulic Oil Operating Temperature Specifications .....	2-11
3-1.	Basic Chassis Assembly .....	3-1
3-2.	Tensioning Track .....	3-2
3-3.	Rubber Track Tension Mark .....	3-2
3-4.	Grease Valve .....	3-3
3-5.	Floor Jack Location .....	3-3
3-6.	Lift Track and Compress Idler Cylinder.....	3-3
3-7.	Remove Rubber Track .....	3-3
3-8.	Rubber Track Direction of Travel .....	3-3
3-9.	Preparation for Installation .....	3-4
3-10.	Install on Drive Sprocket.....	3-4
3-11.	Aligning Track on Frame.....	3-4
3-12.	Install Track on Idler .....	3-4
3-13.	Grease Valve .....	3-5
3-14.	Floor Jack Location .....	3-5
3-15.	Brace Steel Track .....	3-5
3-16.	Track Direction of Travel.....	3-6
3-17.	Installing Track .....	3-6
3-18.	Grouser Shoes Removed.....	3-6
3-19.	Track Chain Block Plate .....	3-6
3-20.	Installing Master Pin .....	3-7
3-21.	Track Tensioning .....	3-7
3-22.	Track Tension .....	3-7
3-23.	Reinstall Triple Grouser Shoes.....	3-7
3-24.	Sprocket Wear Measurement .....	3-8
3-25.	Bolt Tightening Sequence .....	3-11
3-26.	Swing Motor Valve Removal .....	3-13
3-27.	Swing Motor Removal .....	3-14
3-28.	Input Brake Disassembly.....	3-15
3-29.	Main Disassembly .....	3-16
3-30.	Housing Shaft Disassembly .....	3-17
3-31.	Carrier Disassembly .....	3-18
3-32.	Carrier Assembly .....	3-19
3-33.	Housing - Shaft Assembly.....	3-20
3-34.	Main Assembly .....	3-22
3-35.	Brake Port Alignment.....	3-23
3-36.	Swing Motor Installation.....	3-24
3-37.	Motor and Brake Assembly .....	3-25
3-38.	Swing Motor Valve Installation.....	3-26
3-39.	Bearing Cone Press Tool .....	3-27
3-40.	Bearing Cone Press Tool .....	3-27
3-41.	Bearing Cup Press Tool .....	3-28
3-42.	Lockout Wrench Tool.....	3-29
3-43.	Bearing Cup Press Tool .....	3-30
3-44.	Seal Press Tool .....	3-31
3-45.	Leak Test Adapter Plate.....	3-32
3-46.	Swing Drive Test Plate .....	3-33
3-47.	Swing Drive Motor .....	3-35

FIGURE NO.	TITLE	PAGE NO.
3-48.	Swing Bolt Feeler Gauge Check .....	3-50
3-49.	Swing Bearing Wear Tolerance .....	3-51
3-50.	Swing Bearing Removal .....	3-52
3-51.	Swing Bearing Torque Sequence .....	3-56
3-52.	Rotary Coupling Seal Installation .....	3-57
3-53.	Rotary Coupling Cutaway .....	3-58
3-54.	Rotary Coupling Installation (With Turntable Bearing Spacer) .....	3-59
3-55.	Rotary Coupling Installation (Without Turntable Bearing Spacer) .....	3-60
3-56.	Rotary Coupling Port Location .....	3-61
3-57.	Inspecting Generator Brushes, Replacing Brushes and Cleaning Slip Rings .....	3-63
3-58.	Generator Disassembly and Assembly .....	3-64
3-59.	Generator Troubleshooting Circuit Diagram - Sheet 1 of 2 .....	3-65
3-60.	Generator Troubleshooting Circuit Diagram - Sheet 2 of 2 .....	3-66
3-61.	Generator Electrical Circuit Diagram .....	3-67
3-62.	Power Board PC1 Electrical Circuit Diagram .....	3-68
3-63.	Power Board PC2 Electrical Circuit Diagram - Sheet 1 of 2 .....	3-69
3-64.	Power Board PC2 Electrical Circuit Diagram - Sheet 2 of 2 .....	3-70
3-65.	Deutz Engine (D2011L03) - T4i (Sheet 1 of 4) .....	3-72
3-66.	Deutz Engine (D2011L03) - T4i (Sheet 2 of 4) .....	3-73
3-67.	Deutz Engine (D2011L03) - T4i (Sheet 3 of 4) .....	3-74
3-68.	Deutz Engine (D2011L03) - T4i (Sheet 4 of 4) .....	3-75
3-69.	Deutz D2011L03 T4Fi Dipstick Markings .....	3-76
3-70.	Engine Oil Viscosity .....	3-76
3-71.	Deutz Engine (D2.9L4) - T4F (Sheet 1 of 4) .....	3-79
3-72.	Deutz Engine (D2.9L4) - T4F (Sheet 2 of 4) .....	3-80
3-73.	Deutz Engine (D2.9L4) - T4F (Sheet 3 of 4) .....	3-81
3-74.	Deutz Engine (D2.9L4) - T4F (Sheet 4 of 4) .....	3-82
3-75.	Deutz 2.9 T4FDipstick Markings .....	3-83
3-76.	Engine Oil Viscosity .....	3-83
4-1.	Boom Angle Sensor Circuit .....	4-3
4-2.	Boom Length Sensors Circuit .....	4-4
4-2.	Boom Length Sensors Circuit .....	4-4
4-3.	Transport Switches Installation .....	4-5
4-4.	Dual Capacity Sensor Circuit .....	4-6
4-5.	Capacity Switch Installation .....	4-7
4-6.	Location of Components .....	4-8
4-7.	Platform Support Torque Values (Without LSS) .....	4-10
4-8.	Platform Support Torque Values (Single Cell LSS) .....	4-11
4-9.	Location of Components - Main Boom Powertrack .....	4-12
4-10.	Powertrack Installation Main Boom .....	4-13
4-11.	Boom Installation - 400SC .....	4-25
4-12.	Boom Hydraulic System - 400SC .....	4-26
4-13.	Boom Installation - 460SJC .....	4-28
4-14.	Boom Hydraulic System - 460SJC .....	4-29
4-15.	Boom Assembly .....	4-32
4-16.	Fly Boom Wear Pads .....	4-36
4-17.	Base Boom Wear Pads .....	4-36
4-18.	Cables and Clamps Installation - 400SC (Sheet 1 of 2) .....	4-37
4-19.	Cables and Clamps Installation - 400SC (Sheet 2 of 2) .....	4-38
4-20.	Cables and Clamps Installation - 460SJC (Sheet 1 of 2) .....	4-39
4-21.	Cables and Clamps Installation - 460SJC (Sheet 2 of 2) .....	4-40
4-22.	Rotary Actuator - Exploded View .....	4-42
4-23.	Rotator Counterbalance Valve .....	4-52
5-1.	NPTF thread .....	5-3
5-2.	BSPT thread .....	5-3
5-3.	JIC Thread .....	5-3
5-4.	SAE Thread .....	5-3

<b>FIGURE NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
5-5.	ORFS Thread .....	5-3
5-6.	MTBL-MBTS Thread.....	5-3
5-7.	Bulkhead Thread .....	5-3
5-8.	MFF-BSPP Thread.....	5-4
5-9.	ORB-MPP Thread .....	5-4
5-10.	Torque Wrench Angle .....	5-5
5-11.	Double Wrench Method .....	5-46
5-12.	FFWR Method .....	5-47
5-13.	Adjustable Stud End Assembly.....	5-48
5-14.	Hydraulic Cylinder Locations - 400SC.....	5-49
5-15.	Hydraulic Cylinder Locations - 460SJC.....	5-50
5-16.	Cylinder Barrel Support.....	5-51
5-17.	Cylinder Head Removal.....	5-51
5-18.	Cylinder Rod Support.....	5-51
5-19.	Lift Cylinder .....	5-52
5-20.	Tapered Bushing Removal .....	5-53
5-21.	Piston and Spacer Disassembly .....	5-53
5-22.	Cylinder Head Disassembly .....	5-53
5-23.	Composite Bushing Installation .....	5-54
5-24.	Cylinder Head Seal Installation .....	5-54
5-25.	Cylinder Head Assembly.....	5-54
5-26.	Piston and Spacer Seal Installation .....	5-55
5-27.	Piston and Spacer Assembly .....	5-55
5-28.	Tapered Bushing Installation.....	5-55
5-29.	Seating Tapered Bushing .....	5-56
5-30.	Cylinder Head Installation .....	5-56
5-31.	Cylinder Barrel Support.....	5-57
5-32.	Cylinder Head Removal.....	5-57
5-33.	Cylinder Rod Support.....	5-57
5-34.	Master Cylinder .....	5-58
5-34.	Piston Disassembly .....	5-59
5-35.	Cylinder Head Disassembly .....	5-59
5-36.	Composite Bushing Installation .....	5-60
5-37.	Cylinder Head Seal Installation .....	5-60
5-38.	Cylinder Head Assembly.....	5-60
5-39.	Piston Seal Installation.....	5-61
5-40.	Piston Assembly.....	5-61
5-41.	Cylinder Head Installation .....	5-61
5-42.	Cylinder Barrel Support.....	5-62
5-43.	Valve Block Disassembly.....	5-62
5-44.	Cylinder Head Removal.....	5-62
5-45.	Telescope Cylinder .....	5-63
5-46.	Cylinder Rod Support.....	5-64
5-47.	Tapered Bushing Removal .....	5-64
5-48.	Piston and Spacer Disassembly .....	5-64
5-49.	Cylinder Head Disassembly .....	5-64
5-50.	Composite Bushing Installation .....	5-65
5-51.	Cylinder Head Seal Installation .....	5-66
5-52.	Cylinder Head Assembly.....	5-66
5-53.	Piston and Spacer Seal Installation .....	5-66
5-54.	Piston and Spacer Assembly .....	5-66
5-55.	Tapered Bushing Installation.....	5-67
5-56.	Seating Tapered Bushing .....	5-67
5-57.	Cylinder Head Installation .....	5-67
5-58.	Valve Block Assembly.....	5-68
5-59.	Cylinder Barrel Support.....	5-69
5-60.	Capscrew Removal .....	5-69

FIGURE NO.	TITLE	PAGE NO.
5-61.	Cylinder Rod Support	5-69
5-62.	Jib Lift Cylinder (460SJC Only)	5-70
5-63.	Tapered Bushing Removal	5-71
5-64.	Composite Bearing Installation	5-72
5-65.	Rod Seal Installation	5-72
5-66.	Cylinder Head Seal Installation	5-72
5-67.	Wiper Seal Installation	5-73
5-68.	Installation of Head Seal Kit	5-73
5-69.	Tapered Bushing Installation	5-73
5-70.	Seating the Tapered Bearing	5-73
5-71.	Hydrolock Piston Seal Installation	5-74
5-72.	Piston Seal Kit Installation	5-74
5-73.	Rod Assembly Installation	5-74
5-74.	Cylinder Barrel Support	5-75
5-75.	Removing Cylinder Head	5-75
5-76.	Cylinder Rod Support	5-75
5-77.	Platform Level Cylinder	5-76
5-77.	Piston Disassembly	5-77
5-78.	Cylinder Head Disassembly	5-77
5-79.	Composite Bushing Installation	5-78
5-80.	Cylinder Head Seal Installation	5-78
5-81.	Cylinder Head Assembly	5-78
5-82.	Piston Seal Installation	5-79
5-83.	Piston Assembly	5-79
5-84.	Cylinder Head Installation	5-79
5-85.	Hydraulic System Installation (400SC) - Sheet 1 of 16	5-80
5-86.	Hydraulic System Installation (400SC) - Sheet 2 of 16	5-81
5-87.	Hydraulic System Installation (400SC) - Sheet 3 of 16	5-82
5-88.	Hydraulic System Installation (400SC) - Sheet 4 of 16	5-83
5-89.	Hydraulic System Installation (400SC) - Sheet 5 of 16	5-84
5-90.	Hydraulic System Installation (400SC) - Sheet 6 of 16	5-85
5-91.	Hydraulic System Installation (400SC) - Sheet 7 of 16	5-86
5-92.	Hydraulic System Installation (400SC) - Sheet 8 of 16	5-87
5-93.	Hydraulic System Installation (400SC) - Sheet 9 of 16	5-88
5-94.	Hydraulic System Installation (400SC) - Sheet 10 of 16	5-89
5-95.	Hydraulic System Installation (400SC) - Sheet 11 of 16	5-90
5-96.	Hydraulic System Installation (400SC) - Sheet 12 of 16	5-91
5-97.	Hydraulic System Installation (400SC) - Sheet 13 of 16	5-92
5-98.	Hydraulic System Installation (400SC) - Sheet 14 of 16	5-93
5-99.	Hydraulic System Installation (400SC) - Sheet 15 of 16	5-94
5-100.	Hydraulic System Installation (400SC) - Sheet 16 of 16	5-95
5-101.	Hydraulic System Installation (460SJC) - Sheet 1 of 15	5-96
5-102.	Hydraulic System Installation (460SJC) - Sheet 2 of 15	5-97
5-103.	Hydraulic System Installation (460SJC) - Sheet 3 of 15	5-98
5-104.	Hydraulic System Installation (460SJC) - Sheet 4 of 15	5-99
5-105.	Hydraulic System Installation (460SJC) - Sheet 5 of 15	5-100
5-106.	Hydraulic System Installation (460SJC) - Sheet 6 of 15	5-101
5-107.	Hydraulic System Installation (460SJC) - Sheet 7 of 15	5-102
5-108.	Hydraulic System Installation (460SJC) - Sheet 8 of 15	5-103
5-109.	Hydraulic System Installation (460SJC) - Sheet 9 of 15	5-104
5-110.	Hydraulic System Installation (460SJC) - Sheet 10 of 15	5-105
5-111.	Hydraulic System Installation (460SJC) - Sheet 11 of 15	5-106
5-112.	Hydraulic System Installation (460SJC) - Sheet 12 of 15	5-107
5-113.	Hydraulic System Installation (460SJC) - Sheet 13 of 15	5-108
5-114.	Hydraulic System Installation (460SJC) - Sheet 14 of 15	5-109
5-115.	Hydraulic System Installation (460SJC) - Sheet 15 of 15	5-110

<b>FIGURE NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
5-116.	Main Control Valve Identification (400SC) - Sheet 1 of 2	5-115
5-117.	Main Control Valve Identification (400SC) - Sheet 2 of 2	5-116
5-118.	Main Control Valve Identification - 460SJC - Sheet 1 of 2	5-117
5-119.	Main Control Valve Identification - 460SJC - Sheet 2 of 2	5-118
5-120.	Main Control Valve Torque Values - Sheet 1 of 2	5-119
5-121.	Main Control Valve Torque Values - Sheet 2 of 2	5-120
5-122.	Hydraulic Schematic (400SC) - Sheet 1 of 2	5-122
5-123.	Hydraulic Schematic (400SC) - Sheet 2 of 2	5-123
5-124.	Hydraulic Schematic (460SJC) - Sheet 1 of 2	5-124
5-125.	Hydraulic Schematic (460SJC) - Sheet 2 of 2	5-125
6-1.	Hand Held Analyzer	6-1
6-2.	Splash Screen	6-6
6-3.	Diagnostic Screen	6-6
6-4.	Engine Diagnostic Screen	6-6
6-5.	Ground Control Console Display Gauge	6-7
6-6.	Analyzer Connecting Points	6-10
6-7.	Analyzer Flow Chart (Software Version P2.10)	6-11
6-8.	Analyzer Flow Chart - Diagnostics (Software Version P2.10) - Sheet 1 of 4	6-12
6-9.	Analyzer Flow Chart - Diagnostics (Software Version P2.10) - Sheet 2 of 4	6-13
6-10.	Analyzer Flow Chart - Diagnostics (Software Version P2.10) - Sheet 3 of 4	6-14
6-11.	Analyzer Flow Chart - Diagnostics (Software Version P2.10) - Sheet 4 of 4	6-15
6-12.	Analyzer Flow Chart - Personalities (Software Version P2.10) - Sheet 1 of 2	6-16
6-13.	Analyzer Flow Chart - Personalities (Software Version P2.10) - Sheet 2 of 2	6-17
6-14.	Analyzer Flow Chart - Machine setup (Software Version P2.10)	6-18
6-15.	Analyzer Flow Chart - Calibrations (Software Version P2.10)	6-19
6-16.	Ground Control Module - Sheet 1 of 3	6-20
6-17.	Ground Control Module - Sheet 2 of 3	6-21
6-18.	Ground Control Module - Sheet 3 of 3	6-22
6-19.	Platform Module - Sheet 1 of 2	6-23
6-20.	Platform Module - Sheet 2 of 2	6-24
6-21.	System Test Flow Chart- Platform Tests	6-51
6-22.	System Test Flow Chart - Ground Station Tests	6-53
6-23.	Tilt Sensor Location	6-98
7-1.	Voltage Measurement (DC)	7-1
7-2.	Resistance Measurement	7-2
7-3.	Continuity Measurement	7-2
7-4.	Current Measurement (DC)	7-3
7-5.	Application to Female Contacts	7-4
7-6.	Use of Seal Plugs	7-5
7-7.	Connector Assembly Figure 1	7-7
7-8.	AMP Connector	7-7
7-9.	Connector Assembly Figure 2	7-8
7-10.	Connector Assembly Figure 3	7-8
7-11.	Connector Assembly Figure 4	7-8
7-12.	Connector Disassembly	7-9
7-13.	Connector Installation	7-10
7-14.	DT/DTP Contact Installation	7-11
7-15.	DT/DTP Contact Removal	7-11
7-16.	HD/HDP Contact Installation	7-12
7-17.	HD/HDP Locking Contacts Into Position	7-12
7-18.	HD/HDP Contact Removal	7-12
7-19.	HD/HDP Unlocking Contacts	7-12
7-20.	Electrical Installation - Sheet 1 of 4	7-15
7-21.	Electrical Installation - Sheet 2 of 4	7-16
7-22.	Electrical Installation - Sheet 3 of 4	7-17
7-23.	Electrical Installation - Sheet 4 of 4	7-18

FIGURE NO.	TITLE	PAGE NO.
7-24.	Platform Control Box Harness Without Skyguard - Sheet 1 of 12 .....	7-19
7-25.	Platform Control Box Harness Without Skyguard - Sheet 2 of 12 .....	7-20
7-26.	Platform Control Box Harness Without Skyguard - Sheet 3 of 12 .....	7-21
7-27.	Platform Control Box Harness Without Skyguard - Sheet 4 of 12 .....	7-22
7-28.	Platform Control Box Harness Without Skyguard - Sheet 5 of 12 .....	7-23
7-29.	Platform Control Box Harness Without Skyguard - Sheet 6 of 12 .....	7-24
7-30.	Platform Control Box Harness Without Skyguard - Sheet 7 of 12 .....	7-25
7-31.	Platform Control Box Harness Without Skyguard - Sheet 8 of 12 .....	7-26
7-32.	Platform Control Box Harness Without Skyguard - Sheet 9 of 12 .....	7-28
7-33.	Platform Control Box Harness Without Skyguard - Sheet 10 of 12 .....	7-29
7-34.	Platform Control Box Harness Without Skyguard - Sheet 11 of 12 .....	7-30
7-35.	Platform Control Box Harness Without Skyguard - Sheet 12 of 12 .....	7-31
7-36.	LSS Harness .....	7-32
7-37.	Main Boom Harness - 400SC .....	7-33
7-38.	Main Boom with Jib Harness - 460SJC .....	7-34
7-39.	Tele In Proximity Switches Harness .....	7-35
7-40.	Capacity Proximity Switches Harness .....	7-36
7-41.	Ground Control Panel Harness - Sheet 1 of 5 .....	7-37
7-42.	Ground Control Panel Harness - Sheet 2 of 5 .....	7-38
7-43.	Ground Control Panel Harness - Sheet 3 of 5 .....	7-39
7-44.	Ground Control Panel Harness - Sheet 4 of 5 .....	7-40
7-45.	Ground Control Panel Harness - Sheet 5 of 5 .....	7-41
7-46.	Deutz T4i Harness - Sheet 1 of 4 .....	7-42
7-47.	Deutz T4i Harness - Sheet 2 of 4 .....	7-43
7-48.	Deutz T4i Harness - Sheet 3 of 4 .....	7-44
7-49.	Deutz T4i Harness - Sheet 4 of 4 .....	7-45
7-50.	Skyguard Harness - Sheet 1 of 2 .....	7-46
7-51.	Skyguard Harness - Sheet 2 of 2 .....	7-47
7-52.	Deutz T4F Harness - Sheet 1 of 12 .....	7-48
7-53.	Deutz T4F Harness - Sheet 2 of 12 .....	7-49
7-54.	Deutz T4F Harness - Sheet 3 of 12 .....	7-50
7-55.	Deutz T4F Harness - Sheet 4 of 12 .....	7-51
7-56.	Deutz T4F Harness - Sheet 5 of 12 .....	7-52
7-57.	Deutz T4F Harness - Sheet 6 of 12 .....	7-53
7-58.	Deutz T4F Harness - Sheet 7 of 12 .....	7-54
7-59.	Deutz T4F Harness - Sheet 8 of 12 .....	7-55
7-60.	Deutz T4F Harness - Sheet 9 of 12 .....	7-56
7-61.	Deutz T4F Harness - Sheet 10 of 12 .....	7-57
7-62.	Deutz T4F Harness - Sheet 11 of 12 .....	7-58
7-63.	Deutz T4F Harness - Sheet 12 of 12 .....	7-59
7-64.	Chassis Head and Tail Lights Harness - Sheet 1 of 3 .....	7-60
7-65.	Chassis Head and Tail Lights Harness - Sheet 2 of 3 .....	7-61
7-66.	Chassis Head and Tail Lights Harness - Sheet 3 of 3 .....	7-62
7-67.	Chassis Work Lights Harness- Sheet 1 of 3 .....	7-64
7-68.	Chassis Work Lights Harness - Sheet 2 of 3 .....	7-65
7-69.	Chassis Work Lights Harness - Sheet 3 of 3 .....	7-66
7-70.	400SC Turntable Harness - Sheet 1 of 14 .....	7-67
7-71.	400SC Turntable Harness - Sheet 2 of 14 .....	7-68
7-72.	400SC Turntable Harness - Sheet 3 of 14 .....	7-69
7-73.	400SC Turntable Harness - Sheet 4 of 14 .....	7-70
7-74.	400SC Turntable Harness - Sheet 5 of 14 .....	7-71
7-75.	400SC Turntable Harness - Sheet 6 of 14 .....	7-72
7-76.	400SC Turntable Harness - Sheet 7 of 14 .....	7-73
7-77.	400SC Turntable Harness - Sheet 8 of 14 .....	7-74
7-78.	400SC Turntable Harness - Sheet 9 of 14 .....	7-75
7-79.	400SC Turntable Harness - Sheet 10 of 14 .....	7-76
7-80.	400SC Turntable Harness - Sheet 11 of 14 .....	7-77

**LIST OF FIGURES**

---

<b>FIGURE NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
7-81.	400SC Turntable Harness - Sheet 12 of 14 .....	7-78
7-82.	400SC Turntable Harness - Sheet 13 of 14 .....	7-79
7-83.	400SC Turntable Harness - Sheet 14 of 14 .....	7-80
7-84.	400SC Main Valve Harness - Sheet 1 of 6 .....	7-82
7-85.	400SC Main Valve Harness - Sheet 2 of 6 .....	7-83
7-86.	400SC Main Valve Harness - Sheet 3 of 6 .....	7-84
7-87.	400SC Main Valve Harness - Sheet 4 of 6 .....	7-85
7-88.	400SC Main Valve Harness - Sheet 5 of 6 .....	7-86
7-89.	400SC Main Valve Harness - Sheet 6 of 6 .....	7-87
7-90.	Electrical Schematic - Sheet 1 of 25 .....	7-89
7-91.	Electrical Schematic - Sheet 2 of 25 .....	7-90
7-92.	Electrical Schematic - Sheet 3 of 25 .....	7-91
7-93.	Electrical Schematic - Sheet 4 of 25 .....	7-92
7-94.	Electrical Schematic - Sheet 5 of 25 .....	7-93
7-95.	Electrical Schematic - Sheet 6 of 25 .....	7-94
7-96.	Electrical Schematic - Sheet 7 of 25 .....	7-95
7-97.	Electrical Schematic - Sheet 8 of 25 .....	7-96
7-98.	Electrical Schematic - Sheet 9 of 25 .....	7-97
7-99.	Electrical Schematic - Sheet 10 of 25 .....	7-98
7-100.	Electrical Schematic - Sheet 11 of 25 .....	7-99
7-101.	Electrical Schematic - Sheet 12 of 25 .....	7-100
7-102.	Electrical Schematic - Sheet 13 of 25 .....	7-101
7-103.	Electrical Schematic - Sheet 14 of 25 .....	7-102
7-104.	Electrical Schematic - Sheet 15 of 25 .....	7-103
7-105.	Electrical Schematic - Sheet 16 of 25 .....	7-104
7-106.	Electrical Schematic - Sheet 17 of 25 .....	7-106
7-107.	Electrical Schematic - Sheet 18 of 25 .....	7-107
7-108.	Electrical Schematic - Sheet 19 of 25 .....	7-108
7-109.	Electrical Schematic - Sheet 20 of 25 .....	7-109
7-110.	Electrical Schematic - Sheet 21 of 25 .....	7-110
7-111.	Electrical Schematic - Sheet 22 of 25 .....	7-112
7-112.	Electrical Schematic - Sheet 23 of 25 .....	7-113
7-113.	Electrical Schematic - Sheet 24 of 25 .....	7-114
7-114.	Electrical Schematic - Sheet 25 of 25 .....	7-115

Go to Discount-Equipment.com to order your parts



TABLE NO.	TITLE	PAGE NO.
1-1	Operating Specifications - 400SC .....	1-1
1-2	Operating Specifications - 460SJC .....	1-1
1-3	Capacities .....	1-2
1-4	Deutz D2011L03 .....	1-2
1-5	Deutz 2.9L4 .....	1-2
1-6	Hydraulic Oil .....	1-3
1-7	Mobilfluid 424 Specs .....	1-3
1-8	Mobil DTE 10 Excel 32 Specs .....	1-3
1-9	Quintolubric 888-46 Specs .....	1-3
1-10	Mobil EAL EnviroSyn H 46 Specs .....	1-3
1-11	Mobil SHC EAL H 46 Specs .....	1-3
1-12	Exxon Univis HVI 26 Specs .....	1-4
1-13	Critical Stability Weights .....	1-4
1-14	Lubrication Specifications .....	1-5
2-1	Inspection and Maintenance .....	2-2
2-2	Cylinder Drift .....	2-5
2-3	Inspection and Preventive Maintenance Schedule .....	2-6
3-1	Brake Chart .....	3-9
3-2	Recommended Viscosities .....	3-12
3-3	Coupling Port Information - 7 Port .....	3-61
3-3	Lead Connection List for Generator .....	3-71
3-4	Engine Fault Code Chart .....	3-85
3-5	Deutz Trouble Codes (D2.9L4 Engine) .....	3-116
4-1	SkyGuard Function Table .....	4-54
5-1	NPTF Pipe Thread .....	5-6
5-2	BSPT Pipe Thread .....	5-7
5-3	37° Flare (JIC)Thread - Steel .....	5-9
5-4	37° Flare (JIC)Thread - Aluminum/Brass .....	5-10
5-5	45° Flare (SAE) - Steel .....	5-12
5-6	45° Flare (SAE) - Aluminum/Brass .....	5-12
5-7	O-ring Face Seal (ORFS) - Steel .....	5-13
5-8	O-ring Face Seal (ORFS) - Aluminum/Brass .....	5-14
5-9	DIN 24° Cone (MBTL & MBTS) .....	5-16
5-10	Bulkhead Fittings (BH) - INCH .....	5-18
5-11	Bulkhead Fittings (BH) - METRIC .....	5-19
5-12	O-ring Boss (ORB) - Table 1 of 6 .....	5-21
5-13	O-ring Boss (ORB) - Table 2 of 6 .....	5-22
5-14	O-ring Boss (ORB) - Table 3 of 6 .....	5-23
5-15	O-ring Boss (ORB) - Table 4 of 6 .....	5-24
5-16	O-ring Boss (ORB) - Table 5 of 6 .....	5-25
5-17	O-ring Boss (ORB) - Table 6 of 6 .....	5-26
5-18	Metric Flat Face Port (MFF) - L Series - Table 1 of 3 .....	5-28
5-19	Metric Flat Face Port (MFF) - L Series - Table 2 of 3 .....	5-29
5-20	Metric Flat Face Port (MFF) - L Series - Table 3 of 3 .....	5-30
5-21	Metric Flat Face Port (MFF) - S Series - Table 1 of 3 .....	5-31
5-22	Metric Flat Face Port (MFF) - S Series - Table 2 of 3 .....	5-32
5-23	Metric Flat Face Port (MFF) - L Series - Table 3 of 3 .....	5-33
5-24	Metric Pipe Parallel O-ring Boss (MPP) .....	5-35
5-25	British Standard Parallel Pipe Port (BSPP) - L Series - Table 1 of 3 .....	5-37
5-26	British Standard Parallel Pipe Port (BSPP) - L Series - Table 2 of 3 .....	5-38
5-27	British Standard Parallel Pipe Port (BSPP) - L Series - Table 3 of 3 .....	5-39
5-28	British Standard Parallel Pipe Port (BSPP) - S Series - Table 1 of 3 .....	5-40
5-29	British Standard Parallel Pipe Port (BSPP) - S Series - Table 2 of 3 .....	5-41
5-30	British Standard Parallel Pipe Port (BSPP) - S Series - Table 3 of 3 .....	5-42
5-31	Flange Code (FL61 & FL62) -Inch Fasteners .....	5-44
5-32	Flange Code (FL61 & FL62) - Metric Fasteners .....	5-45
5-33	Cartridge Torque Values .....	5-120

## LIST OF TABLES

---

<b>TABLE NO.</b>	<b>TITLE</b>	<b>PAGE NO.</b>
5-34	Coil Torque Values.....	5-120
5-35	Coil Resistance Values.....	5-120
6-1	Analyzer Abbreviations.....	6-8
6-2	Machine Configuration Programming Information (Software Version P2.10).....	6-25
6-3	Machine Configuration Programming Settings - 400SC.....	6-31
6-4	Machine Configuration Programming Settings - 460SJC.....	6-32
6-5	Diagnostic Menu Descriptions.....	6-34
6-6	Accessory Weights.....	6-36
6-7	SkyGlazier Capacity Reductions.....	6-38
6-8	Pipe Rack Capacity Reductions.....	6-38
6-9	LSS Troubleshooting Chart.....	6-41
6-10	Machine Model Adjustment Speeds.....	6-47
6-11	System Test Messages.....	6-54
6-12	Machine Diagnostics Parameters.....	6-56
6-13	Diagnostic Trouble Code Chart.....	6-68
7-1	Wiring Harness Connector Labels.....	7-13

Go to [Discount-Equipment.com](http://Discount-Equipment.com) to order your parts

# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

A screenshot of the "Search Manuals" form. The form has a title "Search Manuals" and a subtitle "Please provide information to help us locate the manual and/or parts you need." It includes fields for "Brand", "Model", "Serial", "Part Number", "Part Name", and "Quantity". There is a "Search" button at the bottom.

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

A screenshot of the "Parts Order Form". The form has a title "Parts Order Form" and a subtitle "Please fill in as much information as possible." It includes fields for "Manufacturer", "Model", "Description", "Part Number", "Part Name", "Quantity", and "Comments". There is a "Submit" button at the bottom.

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

## SECTION 1. SPECIFICATIONS

## 1.1 OPERATING SPECIFICATIONS

Table 1-1. Operating Specifications - 400SC

Maximum Work Load (Capacity): Unrestricted (CE) Restricted (CE)	272 kg (600 lb) 454 kg (1000 lb)
Maximum Travel Grade, Stowed Position (Gradeability)	51%
Maximum Travel Grade, Stowed Position (Side Slope)	5°
Platform Height: With out Turntable Spacer With Turntable Spacer	11.89 m (39 ft) 12.05 m (39 ft-6.5 in)
Horizontal Platform Reach:	10 m (33 ft)
Turning Radius (Outside)	Nil (0)
Turning Radius (Inside)	Nil (0)
Overall Width	2.23 m (7 ft-4 in)
Stowed Height: With out Turntable Spacer With Turntable Spacer	2.16 m (7 ft-1 in) 2.32 m (7 ft-7.5 in ft)
Stowed Length	7.57 m (24 ft-10 in)
Wheelbase	2.25 m (7 ft-4.8 in)
Ground Clearance	0.32 m (12.5 in)
Ground Bearing Pressure: With out Turntable Spacer With Turntable Spacer	3626 kg/m <sup>2</sup> (5.16 psi) 3661 kg/m <sup>2</sup> (5.21 psi)
Travel Speed	2.57 km/h (1.6 mph)
Rubber Track GVW: Without Turntable Spacer With Turntable Spacer	6,542 kg (14,422 lb) 6,604 kg (14,559 lb)
Steel Track GVW: Without Turntable Spacer With Turntable Spacer	6,989.9 kg (15,410 lb) 7,052 kg (15,547 lb)
Maximum Rubber Track Load	5769 kg (12,718 lb)
Maximum System Voltage	12V
Max. Hydraulic System Operating Pressure	207 bar (3000 psi)
Manual Force (CE) (Force applied by work platform occupant on fixed structure)	400 N (90 lb)
Maximum Wind Speed	12.5 m/s (28 mph)

Table 1-2. Operating Specifications - 460SJC

Maximum Work Load (Capacity):	272 kg (600 lb)
Maximum Travel Grade, Stowed Position (Gradeability)	51%
Maximum Travel Grade, Stowed Position (Side Slope)	5°
Platform Height: With out Turntable Spacer With Turntable Spacer	13.72 m (45 ft) 13.88 m (45 ft-6.5 in)
Horizontal Platform Reach:	12 m (39 ft)
Turning Radius (Outside)	0 m (0 ft)
Turning Radius (Inside)	0 m (0 ft)
Overall Width	2.23 m (7 ft-4 in)
Stowed Height: With out Turntable Spacer With Turntable Spacer	2.17 m (7 ft-1 in) 2.33 m (7 ft-7.2 in ft)
Stowed Length	8.9 m (29 ft-3 in)
Wheelbase	2.25 m (7 ft-4.8 in)
Ground Clearance	0.32 m (12.5 in)
Tailswing	0.3 m (0.97 ft)
Ground Bearing Pressure: With out Turntable Spacer With Turntable Spacer	4642 kg/m <sup>2</sup> (8.11 psi) 4777 kg/m <sup>2</sup> (8.35 psi)
Maximum Travel Speed	2.9 km/h (1.8 mph)
Rubber Track GVW: Without Turntable Spacer With Turntable Spacer	8,102 kg (17,862 lb) 8,164 kg (17,998 lb)
Steel Track GVW Without Turntable Spacer With Turntable Spacer	8,549.8 kg (18,849 lb) 8,611.9 kg (18,986 lb)
Maximum Rubber Track Load	5,769 kg (12,718 lb)
Maximum System Voltage	12V
Max. Hydraulic System Operating Pressure	207 bar (3000 psi)
Manual Force (CE) (Force applied by work platform occupant on fixed structure)	400 N (90 lb)
Maximum Wind Speed	12.5 m/s (28 mph)

## SECTION 1 - SPECIFICATIONS

### 1.2 CAPACITIES

**Table 1-3. Capacities**

Fuel Tank 400SC	83.3 L (22 Gal)
Hydraulic Tank (Usable)	136.28 L (36 Gal)
Hydraulic System (Including Tank)	N/A
Final Drive Hub	1 L (33.824 oz)
Drive Brake	0.8 L (27 oz)

### 1.3 ENGINE DATA

**NOTE:** RPM Tolerances are  $\pm 100$ .

**Table 1-4. Deutz D2011L03**

Engine Type	Four-stroke Diesel
Fuel	Diesel
No. of Cylinders	3
Horse power	36.4 kW (48.8 hp) @ 2800 rpm
Bore	94 mm (3.7 in)
Stroke	112 mm (4.4 in)
Displacement	2331 cm <sup>3</sup> (142 cu. in)
Oil Capacity	10.5 L (2.8 Gal)
Low RPM	1000
Mid RPM	
Tower Lift, Upper Lift, Tele Swing, Basket Level, Basket Rotate, Jib Lift	1800 1500
High RPM	2800
Fuel Consumption (Average)	3.2 L/hr (0.85 Gal/hr)
Torque	137 Nm (101 ft. lbs) @ 1700 rpm
Acceptable Fuel Grades (Dependent on Regulated Area)	Diesel Max 2000 PPM Sulfur

**Table 1-5. Deutz 2.9L4**

Engine Type	Four-stroke Diesel
Fuel	Diesel
No. of Cylinders	4
Horse power	36.4 kW (48.8 hp) @ 2600 rpm
Bore	92 mm (3.6 in)
Stroke	110 mm (4.3 in)
Displacement	2925 cm <sup>3</sup> (178 cu. in)
Oil Capacity	8.9 L (9.5 qt)
Coolant Capacity	0.79 gal (3.0 L)
Min. Low Engine RPM	900
Mid Engine RPM	1800
Max. High Engine RPM	2600
Output	49 hp (36.5 kW)
Acceptable Fuel Grades	Ultra Low Sulfur (15 ppm) Up to 5% Bio Diesel
Fuel Consumption (Average)	2.6 L/hr (0.70 Gal/hr)
Torque	147 Nm (108 ft. lbs) @ 1600 rpm

## 1.4 HYDRAULIC OIL

Table 1-6. Hydraulic Oil

Hydraulic System Operating Temperature Range	S.A.E. Viscosity Grade
+0° to +180°F (-18° to +83°C)	10W
+0° to +210°F (-18° to +99°C)	10W-20, 10W-30
+50° to +210°F (+10° to +99°C)	20W-20

Aside from JLG recommendations, it is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. If use of hydraulic oil other than Mobil 424 is desired refer Figure 2-3., Hydraulic Oil Operating Temperature Specifications.

Table 1-7. Mobilfluid 424 Specs

SAE Grade	10W-30
Gravity, API	29.0
Density, Lb/Gal. 60°F	7.35
Pour Point, Max	-46°F (-43°C)
Flash Point, Min.	442°F (228°C)
Viscosity	
Brookfield, cP at -18°C	2700
at 40°C	55 cSt
at 100°C	9.3 cSt
Viscosity Index	152

Table 1-8. Mobil DTE 10 Excel 32 Specs

ISO Viscosity Grade	#32
Pour Point, Max	-65°F (-54°C)
Flash Point, Min.	482°F (250°C)
Viscosity	
at 40°C	32.7cSt
at 100°C	6.63 cSt
at 100°F	32.7cSt
at 212°F	6.63 cSt
Viscosity Index	164
Density (Kg/l) at 15°C	0.8468
Density (lb/in <sup>3</sup> ) at 60°F	0.0305

Table 1-9. Quintolubric 888-46 Specs

Type	Synthetic Fire Resistant Biodegradable
Density	0.91 @ 15°C (59°F)
Pour Point	<-20°C (<-4°F)
Flash Point	275°C (527°F)
Fire Point	325°C (617°F)
Auto Ignition Temperature	450°C (842°F)
Viscosity	
at 0°C (32°F)	360 cSt
at 20°C (68°F)	102 cSt
at 40°C (104°F)	46 cSt
at 100°C (212°F)	10 cSt
Viscosity Index	220

Table 1-10. Mobil EAL Envirosyn H 46 Specs

Type	Synthetic Biodegradable
ISO Viscosity Grade	46
Density	0.874 @ 15°C (59°F)
Pour Point	-49°F (-45°C)
Flash Point	500°F (260°C)
Operating Temp.	-29 to 93°C (-20 to 200°F)
Viscosity	
at 40°C	48.8 cSt
at 100°C	7.8 cSt
Viscosity Index	145

Table 1-11. Mobil SHC EAL H 46 Specs

Type	Synthetic Biodegradable
ISO Viscosity Grade	46
Density	0.93 @ 15°C (59°F)
Pour Point	-27°F (-33°C)
Flash Point	568°F (298°C)
Operating Temp.	-29 to 93°C (-20 to 200°F)
Viscosity	
at 40°C	43.3 cSt
at 100°C	7.7 cSt
Viscosity Index	149

**Table 1-12. Exxon Unavis HVI 26 Specs**

Specific Gravity	32.1
Pour Point	-76°F (-60°C)
Flash Point	217°F (103°C)
<b>Viscosity</b>	
at 40° C	25.8 cSt
at 100° C	9.3 cSt
Viscosity Index	376
<b>NOTE:</b> Mobil/Exxon recommends this oil be checked on a yearly basis for viscosity.	

## 1.5 CRITICAL STABILITY WEIGHTS

**Table 1-13. Critical Stability Weights**

Component	lb	kg
Battery	66	30
Counterweight (400SC) - Turnable	1060	4812
Counterweight (460SJC) - Turnable	2700	1225
Counterweight (400SJC) - Chassis (Front)	1200	544
Counterweight (400SJC) - Chassis (Rear)	1210	549
Counterweight (460SJC) - Chassis (Front)	1773	804
Counterweight (460SJC) - Chassis (Rear)	1787	810.5
Rubber Track (Each) - Excavator Tracks	580	263
Rubber Track (Each) - Carrier Tracks	565	256
Rubber Track (Each) - Non-Marking	560	254
Steel Track - Each	747.5	339
Track Pad - Each	7.7	3.5
Platform and Console - 30 x 60	170	77
Platform and Console - 36 x 72	209	95
Platform and Console - 36 x 96	240	109

## 1.6 MAINTENANCE AND LUBRICATION

**NOTE:** The following numbers correspond to those in Figure 1-1. and Figure 1-2.

**Table 1-14. Lubrication Specifications**


KEY	SPECIFICATIONS
MPG	Multipurpose Grease having a minimum dripping point of 350°F (177°C). Excellent water resistance and adhesive qualities, and being of extreme pressure type. (Timken OK 40 pounds minimum.)
EPGL	Extreme Pressure Gear Lube (oil) meeting API service classification GL-5 or MIL-Spec MIL-L-2105
HO	Hydraulic Oil. Refer Section 1.4, Hydraulic Oil.
EO	Engine (crankcase). Gas (5W30)- API SN, -Arctic ACEA A1/BI, A5/B5 - API SM, SL, SJ, EC, CF, CD - ILSAC GF-4. Diesel (15W40, 5W30 Arctic) - API CJ-4.
OGL	Open Gear Lubricant - Mobilvac 375 or equivalent.

### NOTICE

LUBRICATION INTERVALS ARE BASED ON MACHINE OPERATION UNDER NORMAL CONDITIONS. FOR MACHINES USED IN MULTI-SHIFT OPERATIONS AND/OR EXPOSED TO HOSTILE ENVIRONMENTS OR CONDITIONS, LUBRICATION FREQUENCIES MUST BE INCREASED ACCORDINGLY.

**NOTE:** It is recommended as a good practice to replace all filters at the same time.

#### 1. Final Drive Hub




Lube Point(s) - Level/Fill Plug

Capacity - 33.8 oz (1 L)(1/2 Full)

Lube - EPGL


Interval - Check level every 3 months or 150 hours of operation; change every 2 years or 1200 hours of operation

#### 2. Hydraulic Return Filter



Interval - Change after first 50 hours and every 6 months or 300 hours thereafter or whenever Charge Filter is replaced

#### 3. Hydraulic Tank Breather



Interval - Change after first 50 hours and every 6 months or 300 hours thereafter.

Comments - Remove wing nut and cover to replace. Under certain conditions, it may be necessary to replace on a more frequent basis.






Figure 1-1. Maintenance and Lubrication Diagram - Deutz D2011L03




Figure 1-2. Maintenance and Lubrication Diagram - Deutz 2.9L4

## SECTION 1 - SPECIFICATIONS

### 4. Hydraulic Tank




Lube Point(s) - Fill Cap  
Capacity - 32.5 gal tank (123 L) 40.0 gal system (151 L)  
Lube - HO  
Interval - Check Level daily; Change every 2 years or 1200 hours of operation

### 5. Hydraulic Charge Filter




Interval - Change after first 50 hours and every 6 months or 300 hours thereafter or as indicated by Condition Indicator

### 6. Oil Change w/Filter - Deutz D2011




Lube Point(s) - Fill Cap/Spin-on Element  
Capacity - 10 qt (9.5 L) w/Filter  
Lube - EO  
Interval - Check level daily; change every 1200 hours of operation or every year, whichever comes first. Adjust final oil level by mark on dipstick. Use Deutz approved engine oil type.

### 7. Fuel Filter - Deutz D2011



Lube Point(s) - Replaceable Element  
Interval - Every year or 600 hours of operation

**8. Oil Change w/Filter - Deutz 2.9L4**



Lube Point(s) - Fill Cap/Spin-on Element  
 Capacity - 9.5 qt (8.9 L) w/Filter  
 Lube - EO  
 Interval - Check level daily; change every 1200 hours of operation or every year, whichever comes first. Adjust final oil level by mark on dipstick. Use Deutz approved engine oil type.

**9. Fuel Pre-Filter D2.9L4**



Lube Point(s) - Replaceable Element  
 Interval - Drain water daily. Change every year or 600 hours of operation

**10. Fuel Filter - Deutz 2.9L4**



Lube Point(s) - Replaceable Element  
 Interval - Every year or 600 hours of operation


**11. Radiator Coolant Deutz 2.9L4**



Lube Point(s) - Fill Cap  
 Capacity - 2.9 Gallon (11.3L)  
 Lube - Anti-Freeze  
 Type - Deutz approved Engine Coolant  
 Interval - Check level daily; change every 1000 hours or 2 years, whichever comes first

## SECTION 1 - SPECIFICATIONS

### 12. Air Filter




Lube Point(s) - Replaceable Element  
Interval - Every 6 months or 300 hours of operation or  
as indicated by condition Indicator  
Comments - Check Dust Valve daily

### 13. Swing Bearing - Internal Ball Bearing

Lube Point(s) - 2 Grease Fittings  
Capacity - A/R  
Lube - MPG  
Interval - Every 3 months or 150 hours of operation  
Comments - Fittings in center of bearing; Remote  
Access is optional: Apply grease and rotate in 90  
degree intervals until bearing is completely  
lubricated

### 14. Swing Drive Hub



Lube Point - Level/Fill Plug  
Capacity - 40 oz (1.2 L)  
Lube - 90w80 Gear Oil  
Interval - Check level every 3 months or 150 hours of  
operation; change after first 50 hours and every 2  
years or 1200 hours of operation thereafter

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)																			
SAE GRADE 5 BOLTS & GRADE 2 NUTS						SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS*													
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry)		Torque Lubricated		Torque (Locite® 262™ or 271™ OR Vibra-TITE™ 111 or 140)		Torque (Locite® 262™ or Vibra-TITE™ 131)		Torque (Dry or Locite® 263) K=0.20		Torque (Locite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K=0.18		Torque (Locite® 262™ or Vibra-TITE™ 131) K=0.15		
					IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB
4	40	0.1120	0.00604	380	8	0.9	6	0.7											
4.8	48	0.1120	0.00661	420	9	1.0	7	0.8											
6	32	0.1380	0.00909	580	16	1.8	12	1.4											
40	0.1380	0.01015	610	18	2.0	1.8	13	1.5											
8	32	0.1640	0.01400	900	30	3.4	22	2.5											
36	0.1640	0.01474	940	31	3.5	2.3	23	2.6											
10	24	0.1900	0.01750	1120	43	4.8	32	3.5											
32	0.1900	0.02000	1285	49	5.5	3.6	36	4											
1/4	20	0.2500	0.0318	2020	96	10.8	75	9	105	12									
28	0.2500	0.0364	2320	120	13.5	10.8	86	10	135	15									
			Sq In	LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB
5/16	18	0.3125	0.0524	3340	17	23	13	18	19	26	16	22	4720	25	35	20	25	20	25
24	0.3125	0.0580	3700	19	26	14	19	21	29	29	17	23	5220	25	35	20	25	20	25
3/8	16	0.3750	0.0775	4940	30	41	23	31	35	48	28	38	7000	45	60	40	55	35	50
24	0.3750	0.0878	5600	35	47	25	25	34	40	54	32	43	7900	50	70	45	60	35	50
7/16	14	0.4375	0.1063	6800	50	68	35	47	55	75	45	61	9550	70	95	60	90	50	70
20	0.4375	0.1187	7550	55	75	40	40	54	60	82	50	68	10700	80	110	70	95	60	80
1/2	13	0.5000	0.1419	9050	75	102	55	75	85	116	66	86	12750	105	145	95	130	80	110
20	0.5000	0.1599	10700	90	122	65	88	100	100	136	80	108	14400	120	165	110	150	90	120
9/16	12	0.5625	0.1820	11600	110	149	80	108	120	163	98	133	16400	150	210	140	190	115	155
18	0.5625	0.2030	12950	120	163	90	122	135	184	109	148	18250	170	230	155	210	130	175	220
5/8	11	0.6250	0.2260	14400	150	203	110	149	165	224	135	183	20350	210	285	210	285	160	220
18	0.6250	0.2560	16300	170	230	130	176	190	258	153	200	240	23000	240	325	250	290	180	245
3/4	10	0.7500	0.3340	21300	260	353	200	285	388	240	325	30100	300	400	300	460	280	360	430
16	0.7500	0.3730	23800	300	407	220	298	330	449	268	363	33600	420	570	380	515	315	430	500
9	0.8750	0.4620	29400	430	583	320	434	475	648	386	523	41600	605	825	545	740	455	620	700
14	0.8750	0.5060	32400	470	637	350	475	520	707	425	576	45800	670	910	600	815	500	680	780
1	8	1.0000	0.6060	38600	640	868	480	651	875	579	785	51500	860	1170	770	1045	645	875	1015
11/8	7	1.1250	0.6630	42200	700	949	530	719	935	633	858	59700	995	1355	895	1215	745	1015	1155
12	0.7500	0.7630	42300	800	1085	600	813	840	1142	714	968	68700	1290	1755	1160	1580	965	1310	1475
12	1.1250	0.8560	47500	880	1193	660	895	925	1258	802	1087	77000	1445	1965	1300	1770	1085	1475	1655
11/4	7	1.2500	0.9690	53800	1120	1518	840	1139	1598	1009	1368	87200	1815	2470	1635	2225	1365	1855	2055
12	1.2500	1.0730	59600	1240	1681	920	1247	1300	1768	1118	1516	96600	2015	2740	1810	2460	1510	2055	2300
13/8	6	1.3750	1.1550	64100	1460	1979	1100	1491	1925	1322	1792	104000	2385	3245	2145	2915	1785	2430	2760
12	1.3750	1.3150	73000	1680	2278	1260	1708	1750	2380	1506	2042	118100	2705	3680	2435	3310	2030	2760	3225
11/2	6	1.5000	1.4050	78000	1940	2630	1460	1979	2025	2754	1755	2379	126500	3165	4305	2845	3870	2370	3225
12	1.5000	1.5800	87700	2200	2983	1640	2224	2300	3128	1974	2676	142200	3555	4835	3200	4350	2665	3625	4300

NO. 5000059 REV. K

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS  
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%  
 3. \* ASSEMBLY USES HARDENED WASHER

REFERENCE JLG THREAD LOCKING COMPOUND		
JLG P/N	Locite® P/N	Description
0100011	242™	Medium Strength (Blue)
0100019	271™	High Strength (Red)
0100071	262™	Medium - High Strength (Red)

Figure 1-3. Torque Chart - Sheet 1 of 5 - (SAE Fasteners)

Values for Magni Coated Fasteners (Ref 4150701)										
CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS					CLASS 10.9 METRIC (HEX HEAD) BOLTS CLASS 10 METRIC NUTS CLASS 12.9 SOCKET HEAD CAP SCREWS M6 AND ABOVE*					
Size	PITCH	Tensile Stress Area	Clamp Load	Torque (Dry or Loctite® 263™) K=0.17	Torque (Loctite® 262™ OR Vibra-TITE™ 131) K=0.16	Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K=0.15	Clamp Load	Torque (Dry or Loctite® 263™) K=0.17	Torque (Lub OR Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K=0.16	Torque (Loctite® 262™ OR Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	2.19	1.1	1.1	1.0	3.13			
3.5	0.6	6.78	2.95	1.8	1.7	1.5	4.22			
4	0.7	8.78	3.82	2.6	2.4	2.3	5.47			
5	0.8	14.20	6.18	5.3	4.9	4.6	8.85			
6	1	20.10	8.74	9	8.4	7.9	12.5	13	12	11
7	1	28.90	12.6	15	14	13	18.0	21	20	19
8	1.25	36.60	15.9	22	20	19	22.8	31	29	27
10	1.5	58.00	25.2	43	40	38	36.1	61	58	55
12	1.75	84.30	36.7	75	70	66	52.5	105	100	95
14	2	115	50.0	119	110	105	71.6	170	160	150
16	2	157	68.3	186	175	165	97.8	265	250	235
18	2.5	192	83.5	256	240	225	119.5	365	345	325
20	2.5	245	106.5	362	340	320	152.5	520	490	460
22	2.5	303	132.0	494	465	435	189.0	705	665	625
24	3	353	153.5	627	590	555	222.0	905	850	800
27	3	459	199.5	916	860	810	286.0	1315	1235	1160
30	3.5	561	244.0	1245	1170	1100	349.5	1780	1680	1575
33	3.5	694	302.0	1694	1595	1495	432.5	2425	2285	2140
36	4	817	355.5	2176	2050	1920	509.0	3115	2930	2750
42	4.5	1120	487.0	3477	3275	3070	698.0	4985	4690	4395

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS  
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%  
 \*3. ASSEMBLY USES HARDENED WASHER OR FASTENER IS PLACED AGAINST PLATED STEEL OR RAW ALUMINUM  
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

NO. 500059 REV. K

Figure 1-4. Torque Chart - Sheet 2 of 5 - (SAE Fasteners)

SOCKET HEAD CAP SCREWS		Zinc Yellow Chromate Fasteners (Ref 4150707)*														
Size	TPI	Bolt Dia	Tensile Stress Area	Magni Coating (Ref 4150701)*					Zinc Yellow Chromate Fasteners (Ref 4150707)*							
				Clamp Load See Note 4	Torque (Dry) K = .17	Torque (Locite® 242™ or 271™ OR Vibra-TITE™, 111 or 140 OR Precoat 85®) K=0.16	Torque (Locite® 262™ or Vibra-TITE™ 131) K=0.15	Clamp Load See Note 4	Torque (Dry) K = .20	Torque (Locite® 242™ or 271™ OR Vibra-TITE™, 111 or 140 OR Precoat 85®) K=0.18	Torque (Locite® 262™ or Vibra-TITE™ 131) K=0.15					
		In	Sq In	LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB	IN-LB	FT-LB
4	40	0.1120	0.00604													
	48	0.1120	0.00661													
6	32	0.1380	0.00909													
	40	0.1380	0.01015													
8	32	0.1640	0.01400													
	36	0.1640	0.01474													
10	24	0.1900	0.01750													
	32	0.1900	0.02000													
1/4	20	0.2500	0.0318	2860	122	14	114	13	15	2860	143	16	129	148	15	17
	28	0.2500	0.0364	3280	139	16	131	15		3280	164	19				
5/16	18	0.3125	0.0524	4720	20	25	20	25	25	4720	25	35	20	25	20	25
	24	0.3125	0.0580	5220	25	35	20	25	25	5220	25	35	25	35	20	25
3/8	16	0.3750	0.0775	7000	35	50	35	50	35	7000	45	60	40	55	35	50
	24	0.3750	0.0878	7900	40	55	40	55	35	7900	50	70	45	60	35	50
7/16	14	0.4375	0.1063	9550	60	80	55	75	50	9550	70	95	65	90	50	70
	20	0.4375	0.1187	10700	65	90	60	80	60	10700	80	110	70	95	60	80
1/2	13	0.5000	0.1419	12750	90	120	85	115	80	12750	105	145	95	130	80	110
	20	0.5000	0.1599	14400	100	135	95	130	90	14400	120	165	110	150	90	120
9/16	12	0.5625	0.1820	16400	130	175	125	170	115	16400	155	210	140	190	115	155
	18	0.5625	0.2030	18250	145	195	135	185	130	18250	170	230	155	210	130	175
5/8	11	0.6250	0.2260	20350	180	245	170	230	160	20350	210	285	190	260	160	220
	18	0.6250	0.2560	23000	205	280	190	260	180	23000	240	325	215	290	180	245
3/4	10	0.7500	0.3340	30100	320	435	300	380	280	30100	375	510	340	460	280	380
	16	0.7500	0.3730	33600	355	485	335	455	315	33600	420	570	380	515	315	430
7/8	9	0.8750	0.4620	41600	515	700	485	660	455	41600	605	825	545	740	455	620
	14	0.8750	0.5090	45800	570	775	535	730	500	45800	670	910	600	815	500	680
1	8	1.0000	0.6060	51500	730	995	685	930	645	51500	860	1170	775	1055	645	875
	12	1.0000	0.6630	59700	845	1150	795	1080	745	59700	995	1355	895	1215	745	1015
1 1/8	7	1.1250	0.7630	68700	1095	1490	1030	1400	965	68700	1290	1755	1160	1580	965	1310
	12	1.1250	0.8560	77000	1225	1665	1155	1570	1085	77000	1445	1965	1300	1770	1085	1475
1 1/4	7	1.2500	0.9690	87200	1545	2100	1455	1980	1365	87200	1815	2470	1635	2225	1365	1855
	12	1.2500	1.0730	96600	1710	2325	1610	2190	1510	96600	2015	2740	1810	2460	1510	2055
1 3/8	6	1.3750	1.1550	104000	2025	2755	1905	2590	1785	104000	2385	3245	2145	2915	1785	2430
	12	1.3750	1.3150	118100	2300	3130	2165	2945	2030	118100	2705	3680	2435	3310	2030	2760
1 1/2	6	1.5000	1.4050	126500	2690	3660	2530	3440	2370	126500	3165	4305	2845	3870	2370	3225
	12	1.5000	1.5800	142200	3020	4105	2845	3870	2665	142200	3555	4835	3200	4350	2665	3625

NO. 500059 REV. K

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS  
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = +10%  
 \*3. ASSEMBLY USES HARDENED WASHER OR FASTENER IS PLACED AGAINST PLATED STEEL OR RAW ALUMINUM  
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

Figure 1-5. Torque Chart - Sheet 3 of 5 - (SAE Fasteners)



Values for Zinc Yellow Chromate Fasteners (Ref 4150707)											
CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS					CLASS 10.9 METRIC (HEX HEAD) BOLTS CLASS 10 METRIC NUTS CLASS 12.9 SOCKET HEAD CAP SCREWS M3 - M5*						
Size	PITCH	Tensile Stress Area	Clamp Load	Torque (Dry or Loctite® 263™)	Torque (Lub)	Torque (Loctite® 262™ OR Vibra-TITE™ 131)	Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140)	Clamp Load	Torque (Dry or Loctite® 263™) K = 0.20	Torque (Lub OR Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K = 0.18	Torque (Loctite® 262™ OR Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]	[N.m]	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	2.19	1.3	1.0	1.2	1.4	3.13			
3.5	0.6	6.78	2.95	2.1	1.6	1.9	2.3	4.22			
4	0.7	8.78	3.82	3.1	2.3	2.8	3.4	5.47			
5	0.8	14.20	6.18	6.2	4.6	5.6	6.8	8.85			
6	1	20.10	8.74	11	7.9	9.4	12	12.5			
7	1	28.90	12.6	18	13	16	19	18.0	25	23	19
8	1.25	36.60	15.9	26	19	23	28	22.8	37	33	27
10	1.5	58.00	25.2	50	38	45	55	36.1	70	65	55
12	1.75	84.30	36.7	88	66	79	97	52.5	125	115	95
14	2	115	50.0	140	105	126	154	71.6	200	180	150
16	2	157	68.3	219	164	197	241	97.8	315	280	235
18	2.5	192	83.5	301	226	271	331	119.5	430	385	325
20	2.5	245	106.5	426	320	383	469	152.5	610	550	460
22	2.5	303	132.0	581	436	523	639	189.0	830	750	625
24	3	353	153.5	737	553	663	811	222.0	1065	960	800
27	3	459	199.5	1080	810	970	1130	286.0	1545	1390	1160
30	3.5	561	244.0	1460	1100	1320	1530	349.5	2095	1885	1575
33	3.5	694	302.0	1990	1490	1790	2090	432.5	2855	2570	2140
36	4	817	355.5	2560	1920	2300	2690	509.0	3665	3300	2750
42	4.5	1120	487.0	4090	3070	3680	4290	698.0	5865	5275	4395

NO. 5000059 REV. K

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS  
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%  
 \*3. ASSEMBLY USES HARDENED WASHER OR FASTENER IS PLACED AGAINST PLATED STEEL OR RAW ALUMINUM  
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS.  
 IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

Figure 1-6. Torque Chart - Sheet 4 of 5 - (METRIC Fasteners)

Values for Magni Coated Fasteners (Ref 4150701)										
CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS					CLASS 10.9 METRIC (HEX HEAD) BOLTS CLASS 10 METRIC NUTS CLASS 12.9 SOCKET HEAD CAP SCREWS M6 AND ABOVE*					
Size	PITCH	Tensile Stress Area	Clamp Load	Torque (Dry or Loctite® 263™) K=0.17	Torque (Loctite® 262™ OR Vibra-TITE™ 131) K=0.16	Torque (Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K=0.15	Clamp Load	Torque (Dry or Loctite® 263™) K = 0.17	Torque (Lub OR Loctite® 242™ or 271™ OR Vibra-TITE™ 111 or 140) K= 0.16	Torque (Loctite® 262™ OR Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	2.19	1.1	1.1	1.0	3.13			
3.5	0.6	6.78	2.95	1.8	1.7	1.5	4.22			
4	0.7	8.78	3.82	2.6	2.4	2.3	5.47			
5	0.8	14.20	6.18	5.3	4.9	4.6	8.85			
6	1	20.10	8.74	9	8.4	7.9	12.5	13	12	11
7	1	28.90	12.6	15	14	13	18.0	21	20	19
8	1.25	36.60	15.9	22	20	19	22.8	31	29	27
10	1.5	58.00	25.2	43	40	38	36.1	61	58	55
12	1.75	84.30	36.7	75	70	66	52.5	105	100	95
14	2	115	50.0	119	110	105	71.6	170	160	150
16	2	157	68.3	186	175	165	97.8	265	250	235
18	2.5	192	83.5	256	240	225	119.5	365	345	325
20	2.5	245	106.5	362	340	320	152.5	520	490	460
22	2.5	303	132.0	494	465	435	189.0	705	665	625
24	3	353	153.5	627	590	555	222.0	905	850	800
27	3	459	199.5	916	860	810	286.0	1315	1235	1160
30	3.5	561	244.0	1245	1170	1100	349.5	1780	1680	1575
33	3.5	694	302.0	1694	1595	1495	432.5	2425	2285	2140
36	4	817	355.5	2176	2050	1920	509.0	3115	2930	2750
42	4.5	1120	487.0	3477	3275	3070	698.0	4985	4690	4395

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS  
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%  
 \*3. ASSEMBLY USES HARDENED WASHER OR FASTENER IS PLACED AGAINST PLATED STEEL OR RAW ALUMINUM  
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

NO. 5000059 REV. K

Figure 1-7. Torque Chart - Sheet 5 of 5 - (METRIC Fasteners)

# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

A screenshot of the "Search Manuals" form. It includes fields for "Brand", "Model", "Serial", "Part Number", and "Quantity". There is a "Search" button at the bottom.

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

A screenshot of the "Parts Order Form". It is a form with multiple rows and columns for entering part information, including fields for "Quantity", "Description", "Manufacturer", "Model", and "Part Number".

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

## SECTION 2. GENERAL

### 2.1 MACHINE PREPARATION, INSPECTION, AND MAINTENANCE

#### General

This section provides the necessary information needed by those personnel that are responsible to place the machine in operation readiness and maintain its safe operating condition. For maximum service life and safe operation, ensure that all the necessary inspections and maintenance have been completed before placing the machine into service. With proper care, maintenance, and inspections performed per JLG's recommendations, and with any and all discrepancies corrected, this product will be fit for continued use.

#### Preparation, Inspection, and Maintenance

It is important to establish and conform to a comprehensive inspection and preventive maintenance program. The following table outlines the periodic machine inspections and maintenance recommended by JLG Industries, Inc. Consult your national, regional, or local regulations for further requirements for aerial work platforms. The frequency of inspections and maintenance must be increased as environment, severity and frequency of usage requires.

#### Pre-Start Inspection

It is the User's or Operator's primary responsibility to perform a Pre-Start Inspection of the machine prior to use daily or at each change of operator. Reference the Operation and Safety Manual for complete procedures for the Pre-Start Inspection. The Operation and Safety Manual must be read in its entirety and understood prior to performing the Pre-Start Inspection.

#### Pre-Delivery Inspection and Frequent Inspection

The Pre-Delivery Inspection and Frequent Inspection shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

The Pre-Delivery Inspection and Frequent Inspection procedures are performed in the same manner, but at different times. The Pre-Delivery Inspection shall be performed prior to each sale, lease, or rental delivery. The Frequent Inspection shall be accomplished for each machine in service for 3 months or 150 hours (whichever comes first); out of service for a period of more than 3 months; or when purchased used. The frequency of this inspection must be increased as environment, severity and frequency of usage requires.

Reference the JLG Pre-Delivery and Frequent Inspection Form and the Inspection and Preventive Maintenance Schedule for

items requiring inspection during the performance of these inspections. Reference the appropriate areas of this manual for servicing and maintenance procedures.

#### Annual Machine Inspection

The Annual Machine Inspection must be performed on an annual basis, no later than thirteen (13) months from the date of the prior Annual Machine Inspection. JLG Industries recommends this task be performed by a Factory-Trained Service Technician. JLG Industries, Inc. recognizes a Factory-Trained Service Technician as a person who has successfully completed the JLG Service Training School for the subject JLG product model. Reference the machine Service and Maintenance Manual and appropriate JLG inspection form for performance of this inspection.

Reference the JLG Annual Machine Inspection Form and the Inspection and Preventive Maintenance Schedule for items requiring inspection during the performance of this inspection. Reference the appropriate areas of this manual for servicing and maintenance procedures.

For the purpose of receiving safety-related bulletins, it is important that JLG Industries, Inc. has updated ownership information for each machine. When performing each Annual Machine Inspection, notify JLG Industries, Inc. of the current machine ownership.

#### Preventive Maintenance

In conjunction with the specified inspections, maintenance shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

Reference the Preventive Maintenance Schedule and the appropriate areas of this manual for servicing and maintenance procedures. The frequency of service and maintenance must be increased as environment, severity and frequency of usage requires.

Table 2-1. Inspection and Maintenance

Type	Frequency	Primary Responsibility	Service Qualification	Reference
Pre-Start Inspection	Prior to use each day; or At each Operator change.	User or Operator	User or Operator	Operation and Safety Manual
Pre-Delivery Inspection	Prior to each sale, lease, or rental delivery.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form.
Frequent Inspection	In service for 3 months or 150 hours, whichever comes first; or Out of service for a period of more than 3 months; or purchased used.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form.
Annual Machine Inspection	Annually, no later than 13 months from the date of the prior inspection.	Owner, Dealer, or User	Factory-Trained Service Technician (Recommended)	Service and Maintenance Manual and applicable JLG inspection form.
Preventive Maintenance	At intervals as specified in the Service and Maintenance Manual.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual

## 2.2 SERVICE AND GUIDELINES

### General

The following information is provided to assist you in the use and application of servicing and maintenance procedures contained in this book.

### Safety and Workmanship

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

### Cleanliness

1. The most important single item in preserving the long service life of a machine is to keep dirt and foreign materials out of the vital components. Precautions have been taken to safeguard against this. Shields, covers, seals, and filters are provided to keep air, fuel, and oil supplies clean; however, these items must be maintained on a scheduled basis in order to function properly.

2. At any time when air, fuel, or oil lines are disconnected, clear adjacent areas as well as the openings and fittings themselves. As soon as a line or component is disconnected, cap or cover all openings to prevent entry of foreign matter.
3. Clean and inspect all parts during servicing or maintenance, and assure that all passages and openings are unobstructed. Cover all parts to keep them clean. Be sure all parts are clean before they are installed. New parts should remain in their containers until they are ready to be used.

### Components Removal and Installation

1. Use adjustable lifting devices, whenever possible, if mechanical assistance is required. All slings (chains, cables, etc.) should be parallel to each other and as near perpendicular as possible to top of part being lifted.
2. Should it be necessary to remove a component on an angle, keep in mind that the capacity of an eyebolt or similar bracket lessens, as the angle between the supporting structure and the component becomes less than 90 degrees.
3. If a part resists removal, check to see whether all nuts, bolts, cables, brackets, wiring, etc., have been removed and that no adjacent parts are interfering.

## Component Disassembly and Reassembly

When disassembling or reassembling a component, complete the procedural steps in sequence. Do not partially disassemble or assemble one part, then start on another. Always recheck your work to assure that nothing has been overlooked. Do not make any adjustments, other than those recommended, without obtaining proper approval.

## Pressure-Fit Parts

When assembling pressure-fit parts, use a molybdenum disulfide base compound or equivalent to lubricate the mating surface.

## Bearings

1. When a bearing is removed, cover it to keep out dirt and abrasives. Clean bearings in nonflammable cleaning solvent and allow to drip dry. Compressed air can be used but do not spin the bearing.
2. Discard bearings if the races and balls (or rollers) are pitted, scored, or burned.
3. If bearing is found to be serviceable, apply a light coat of oil and wrap it in clean (waxed) paper. Do not unwrap reusable or new bearings until they are ready to install.
4. Lubricate new or used serviceable bearings before installation. When pressing a bearing into a retainer or bore, apply pressure to the outer race. If the bearing is to be installed on a shaft, apply pressure to the inner race.

## Gaskets

Check that holes in gaskets align with openings in the mating parts. If it becomes necessary to hand-fabricate a gasket, use gasket material or stock of equivalent material and thickness. Be sure to cut holes in the right location, as blank gaskets can cause serious system damage.

## Bolt Usage and Torque Application

### NOTICE

**SELF LOCKING FASTENERS, SUCH AS NYLON INSERT AND THREAD DEFORMING LOCKNUTS, ARE NOT INTENDED TO BE REINSTALLED AFTER REMOVAL.**

1. Always use new replacement hardware when installing locking fasteners. Use bolts of proper length. A bolt which is too long will bottom before the head is tight against its related part. If a bolt is too short, there will not be enough thread area to engage and hold the part properly. When replacing bolts, use only those having the same specifications of the original, or one which is equivalent.

2. Unless specific torque requirements are given within the text, standard torque values should be used on heat-treated bolts, studs, and steel nuts, in accordance with recommended shop practices. (See Torque Chart Section 1.)

## Hydraulic Lines and Electrical Wiring

Clearly mark or tag hydraulic lines and electrical wiring, as well as their receptacles, when disconnecting or removing them from the unit. This will assure that they are correctly reinstalled.

## Hydraulic System

1. Keep the system clean. If evidence of metal or rubber particles are found in the hydraulic system, drain and flush the entire system.
2. Disassemble and reassemble parts on clean work surface. Clean all metal parts with non-flammable cleaning solvent. Lubricate components, as required, to aid assembly.

## Lubrication

Service applicable components with the amount, type, and grade of lubricant recommended in this manual, at the specified intervals. When recommended lubricants are not available, consult your local supplier for an equivalent that meets or exceeds the specifications listed.

## Battery

Clean battery using a non-metallic brush and a solution of baking soda and water. Rinse with clean water. After cleaning, thoroughly dry battery and coat terminals with an anti corrosion compound.

## Lubrication and Servicing

Components and assemblies requiring lubrication and servicing are shown in the Lubrication Chart in Section 1.

## 2.3 LUBRICATION AND INFORMATION

### Hydraulic System

1. The primary enemy of a hydraulic system is contamination. Contaminants enter the system by various means, e.g., using inadequate hydraulic oil, allowing moisture, grease, filings, sealing components, sand, etc., to enter when performing maintenance, or by permitting the pump to cavitate due to insufficient system warm-up or leaks in the pump supply (suction) lines.
2. The design and manufacturing tolerances of the component working parts are very close, therefore, even the smallest amount of dirt or foreign matter entering a system can cause wear or damage to the components and generally results in faulty operation. Every precaution must be taken to keep hydraulic oil clean, including reserve oil in storage. Hydraulic system filters should be checked, cleaned, and/or replaced as necessary, at the specified intervals required in the Lubrication Chart in Section 1. Always examine filters for evidence of metal particles.
3. Cloudy oils indicate a high moisture content which permits organic growth, resulting in oxidation or corrosion. If this condition occurs, the system must be drained, flushed, and refilled with clean oil.
4. It is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. Good grade mineral oils, with viscosities suited to the ambient temperatures in which the machine is operating, are recommended for use.

**NOTE:** Metal particles may appear in the oil or filters of new machines due to the wear-in of meshing components.

### Hydraulic Oil

1. Refer to Section 1 for recommendations for viscosity ranges.

### Changing Hydraulic Oil

1. Filter elements must be changed after the first 50 hours of operation and every 300 hours (unless specified otherwise) thereafter. If it is necessary to change the oil, use only those oils meeting or exceeding the specifications appearing in this manual. If unable to obtain the same type of oil supplied with the machine, consult local supplier for assistance in selecting the proper equivalent. Avoid mixing petroleum and synthetic base oils.
2. Use every precaution to keep the hydraulic oil clean. If the oil must be poured from the original container into another, be sure to clean all possible contaminants from the service container. Always clean the mesh element of the filter and replace the cartridge any time the system oil is changed.
3. While the unit is shut down, a good preventive maintenance measure is to make a thorough inspection of all hydraulic components, lines, fittings, etc., as well as a functional check of each system, before placing the machine back in service.

### Lubrication Specifications

Specified lubricants, as recommended by the component manufacturers, are always the best choice, however, multi-purpose greases usually have the qualities which meet a variety of single purpose grease requirements. Should any question arise, regarding the use of greases in maintenance stock, consult your local supplier for evaluation. Refer to Section 1 for an explanation of the lubricant key designations appearing in the Lubrication Chart.

## 2.4 CYLINDER DRIFT

### Theory

When a hydraulic cylinder is supporting a load, cylinder drift may occur as a result of any of the circumstances below:

- Normal leakage of load holding valves or malfunction of load holding valves. See Cylinder Leakage Test and Table 2- 2, Cylinder Drift below for evaluation.
- Damaged or worn piston seals.
- Normal thermal expansion or contraction of the hydraulic oil within cylinders (See Cylinder Thermal Drift below).

The first two circumstances may result in cylinder movement due to oil leaking out of the cylinder externally or by leaking back to tank or due to oil leaking internally from one cylinder chamber to the other.

Thermal expansion or contraction of oil in hydraulic cylinders is a normal occurrence and does not result in oil leaking out of the cylinder or leaking internally from one cylinder chamber to the other. Thermal expansion or contraction is the tendency for materials to change size in response to a change in temperature.

## Cylinder Leakage Test

**Cylinder oil must be at stabilized ambient temperature before beginning this test.**

Measure drift at cylinder rod with a calibrated dial indicator.

In an area free of obstructions, cylinder must have load applied and appropriately positioned to detect drift.

Cylinder leakage is acceptable if it passes this test.

**Table 2-2. Cylinder Drift**

Cylinder Bore Diameter		Max. Acceptable Drift in 10 Minutes	
inches	mm	inches	mm
3	76.2	0.026	0.66
3.5	89	0.019	0.48
4	101.6	0.015	0.38
5	127	0.009	0.22
6	152.4	0.006	0.15
7	177.8	0.005	0.13
8	203.2	0.004	0.10
9	228.6	0.003	0.08

**NOTE:** This information is based on 6 drops per minute cylinder leakage.

## Cylinder Thermal Drift

The oil in all hydraulic cylinders will expand or contract due to thermal effects over time and may result in changes to the boom and/or platform position while the machine is stationary. These effects occur as the cylinder oil changes temperature, usually from a higher oil temperature as it cools and approaches the ambient air temperature. Results of these effects are related to several factors including cylinder length and change in temperature over the time the cylinder remains stationary.

## 2.5 PINS AND COMPOSITE BEARING REPAIR GUIDELINES

Filament wound bearings.

1. Pinned joints should be disassembled and inspected if the following occurs:
  - a. Excessive sloppiness in joints.
  - b. Noise originating from the joint during operation.
2. Filament wound bearings should be replaced if any of the following is observed:
  - a. Frayed or separated fibers on the liner surface.
  - b. Cracked or damaged liner backing.
  - c. Bearings that have moved or spun in their housing.

- d. Debris embedded in liner surface.
3. Pins should be replaced if any of the following is observed (pin should be properly cleaned prior to inspection):
  - a. Detectable wear in the bearing area.
  - b. Flaking, peeling, scoring, or scratches on the pin surface.
  - c. Rusting of the pin in the bearing area.
4. Re-assembly of pinned joints using filament wound bearings.
  - a. Housing should be blown out to remove all dirt and debris...bearings and bearing housings must be free of all contamination.
  - b. Bearing / pins should be cleaned with a solvent to remove all grease and oil...filament wound bearing are a dry joint and should not be lubricated unless otherwise instructed (i.e. sheave pins).
  - c. Pins should be inspected to ensure it is free of burrs, nicks, and scratches which would damage the bearing during installation and operation.

## 2.6 WELDING ON JLG EQUIPMENT

**NOTE:** This instruction applies to repairs, or modifications to the machine and to welding performed from the machine on an external structure, or component,

### Do the Following When Welding on JLG Equipment

- Disconnect the battery.
- Disconnect the moment pin connection (where fitted)
- Ground only to structure being welded.

### Do NOT Do the Following When Welding on JLG Equipment

- Ground on frame and weld on any other area than the chassis.
- Ground on turntable and weld on any other area than the turntable.
- Ground on the platform/support and weld on any other area than the platform/support.
- Ground on a specific boom section and weld on any other area than that specific boom section.
- Allow pins, wear pads, wire ropes, bearings, gearing, seals, valves, electrical wiring, or hoses to be between the grounding position and the welded area.

### NOTICE

**FAILURE TO COMPLY WITH THE ABOVE REQUIREMENTS MAY RESULT IN COMPONENT DAMAGE (I.E. ELECTRONIC MODULES, SWING BEARING, COLLECTOR RING, BOOM WIRE ROPES ETC.)**



## SECTION 2 - GENERAL

**NOTE:** Reference the Operation and Safety Manual for completion procedures for the Pre-Start Inspection.

**Table 2-3. Inspection and Preventive Maintenance Schedule**

AREA	Inspections	
	Pre-Delivery <sup>1</sup> or Frequent <sup>2</sup> (Quarterly) Inspection	Annual <sup>3</sup> (Yearly) Inspection
<b>Boom Assembly</b>		
Boom Weldments	1,2	1,2
Hose/Cable Carrier Installations	1,2	1,2
Pivot Pins and Pin Retainers	1,2	1,2
Sheaves, Sheave Pins	1,2	1,2
Bearings	1,2	1,2
Wear Pads	1,2	1,2
Covers or Shields	1,2	1,2
Extend/Retract Chain or Cable Systems <sup>4</sup>	1,2	1,2
<b>Platform Assembly</b>		
Railing	2	2
Gate	1,2,3	1,2,3
Floor	2	2
Rotator	1,2,3,4	1,2,3,4
Lanyard Anchorage Point	1,2,6	1,2,6
<b>Turntable Assembly</b>		
Swing Bearing or Worm Gear	1 <sup>50</sup> ,2	1 <sup>50</sup> ,2
Oil Coupling	4	4
Swing Drive System	1,4	1,4
Turntable Lock	1,2,3	1,2,3
Hood, Hood Props, Hood Latches	3	3
<b>Chassis Assembly</b>		
Tires	1,2	1,2
Wheel Nuts/Bolts	1 <sup>50</sup>	1 <sup>50</sup>
Wheel Bearings		1,2,4,5
Oscillating Axle/Lockout Cylinder Systems		1,2,4,5
Extendable Axle Systems	3	3
Steer Components		1,2
Spindle Thrust Bearing/Washers		1,2
Drive Hubs	1,4	1,4


Table 2-3. Inspection and Preventive Maintenance Schedule

AREA	Inspections	
	Pre-Delivery <sup>1</sup> or Frequent <sup>2</sup> (Quarterly) Inspection	Annual <sup>3</sup> (Yearly) Inspection
<b>Functions/Controls</b>		
Platform Controls return to neutral/off when released	1,3,6,9	1,3,6,9
Ground Controls return to neutral/off when released	1,3,6,9	1,3,6,9
Function Control Locks, Guards, or Detents	1,3,9	1,3,9
Footswitch (shuts off function when released)	1,3,9	1,3,9
Emergency Stop Switches (Ground & Platform) arrest all platform movement	1,3,6	1,3,6
Function Limit or Cutout Switch Systems	1,3,9	1,3,9
Capacity Indicator	1,3,9	1,3,9
Drive Brakes	1,3,9	1,3,9
Swing Brakes	1,3,9	1,3,9
Auxiliary Power	1,3,9	1,3,9
<b>Power System</b>		
Engine Idle, Throttle, and RPM	1,3,7	1,3,7
Engine Fluids: Oil	4	4
Engine Fluids: Coolant	1,4,7	1,4,7
Air Filter	1,4	1,4
Fuel Filter(s)	1,5	1,5
Drain Oil Build Up in 2-Stage Vaporizer (LP Only)	1,4	1,4
Exhaust System	1,4	1,4
Batteries	1,4	1,4
Battery Fluid	4	4
Battery Charger	1,3	1,3
Intake System	1,2	1,2
Glow Plug (Diesel Only)	1,2,3	1,2,3
Serpentine Belt, Tensioner, Pulleys	1,2,3	1,2,3
Fuel Reservoir, Cap, and Breather	1,2,4	1,2,4
<b>Hydraulic/Electric System</b>		
Hydraulic Pumps	1,2,4	1,2,4
Hydraulic Cylinders	1,2,4,5	1,2,4,5
Cylinder Attachment Pins and Pin Retainers	1,2	1,2
Hydraulic Hoses, Lines, and Fittings	1,2,4	1,2,3,4
Hydraulic Reservoir, Cap, and Breather	1,2,3,4,5	1,2,3,4,5
Hydraulic Filter(s)	1,4,5	1,4,5
Hydraulic Fluid	4,5	4,5
Electrical Connections	1,2	1,2
Instruments, Gauges, Switches, Lights, Horn		1,3

**SECTION 2 - GENERAL**


**Table 2-3. Inspection and Preventive Maintenance Schedule**

AREA	Inspections	
	Pre-Delivery <sup>1</sup> or Frequent <sup>2</sup> (Quarterly) Inspection	Annual <sup>3</sup> (Yearly) Inspection
<b>General</b>		
All Decals/Placards Installed, Secure, Legible	9	9
Annual Machine Inspection Due		9
No Unauthorized Modifications or Additions	9	9
All Relevant Safety Publications Incorporated	9	9
General Structural Condition and Welds	2	2
All Fasteners, Pins, Shields, and Covers	1,2	1,2
Grease and Lubricate to Specifications	9	9
Function Test of All Systems	9	9
Paint and Appearance	5	5
Stamp Inspection Date on Frame		9
Notify JLG of Machine Ownership		9
Footnotes:		
<sup>1</sup> Prior to each sale, lease, or delivery		
<sup>2</sup> In service for 3 months; Out of service for 3 months or more; Purchased used		
<sup>3</sup> Annually, no later than 13 months from the date of the prior inspection, Includes all daily and quarterly inspections, mandated by regulating body		
<sup>4</sup> Replace every 12 years or 7,000 hours		
<sup>50</sup> Indicates a 50 hour interval required to perform task after initial use of machine. This only occurs once in machine life		
Performance Codes:		
1 - Check for proper and secure: installation, adjustment, or torque		
2 - Visual inspection for damage: (cracks, corrosion, abrasions, distortion, excessive wear, broken welds, gouges, chafing and threads showing)		
3 - Proper operation		
4 - Check for proper sealing, signs of leakage and fluid level		
5 - Clean and free of debris		
6 - Decals installed and legible		
7 - Check for proper tolerances, routing, and lubrication		
8 - Fully Charged		
9 - Verify/Perform		




1001151190\_B

Figure 2-1. Engine Operating Temperature Specifications - Deutz D2011



1001159163\_B

Figure 2-2. Engine Operating Temperature Specifications - Deutz 2.9 L04



1001206353\_B

Fluid	Properties		Base				Classifications			
	Description	Viscosity at 40° C (cSt, Typical)	Viscosity Index	Mineral Oils	Vegetable Oils	Synthetic	Synthetic Polyol Esters	Readily Biodegradable*	Virtually Non-toxic**	Fire Resistant***
Mobilfluid 424		55	145	X						
Mobil DTE 10 Excel 32		32	141	X						
Unavis HVI 26		26	376	X						
Mobil EAL 224 H		36	212		X		X	X		
Mobil EnviroSyn H46		49	145			X	X	X		
Quintolubric 888-46		50	185				X	X	X	X

\* Readily biodegradable classification indicates one of the following:

CO2 Conversion > 60% per EPA 560/6-82-003

CO2 Conversion > 80% per CEC-L-33-A-93

\*\* Virtually Non-toxic classification indicates an LC50 > 5000 ppm per OECD 203

\*\*\* Fire Resistant classification indicates Factory Mutual Research Corp. (FMRC) Approval

Figure 2-3. Hydraulic Oil Operating Temperature Specifications

# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

**Search Manuals**

Enter your information to search for manuals and parts.

\* Brand:

\* Model:

\* Serial:

\* Part Number:

SEARCH

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

**Parts Order Form**

Please fill in the following information:

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Part Name:

Part Description:

Part Location:

Part Condition:

Part Status:

Part Price:

Part Weight:

Part Dimensions:

Part Material:

Part Color:

Part Finish:

Part Notes:

Submit

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**


**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 3. CHASSIS & TURNTABLE

3.1 CHASSIS COMPONENTS AND SERVICING



- |                           |                            |                      |            |            |
|---------------------------|----------------------------|----------------------|------------|------------|
| 1. Drive Hub              | 5. Lower Track Roller      | 9. Bottom Cover Plat | 13. Washer | 17. Bolt   |
| 2. Drive Sprocket         | 6. Upper Track Roller      | 10. Not Used         | 14. Bolt   | 18. Bolt   |
| 3. Idler Assembly         | 7. Side Frame Cover Plate  | 11. Not Used         | 15. Bolt   | 19. Washer |
| 4. Tension Grease Fitting | 8. Drive Motor Cover Plate | 12. Not Used         | 16. Washer | 20. Nut    |

Figure 3-1. Basic Chassis Assembly



## Track Tension

Refer to Figure 3-1.

**NOTE:** Always check rubber or steel track tension with track off ground.

1. Remove two bolts (17), washers (13) and side frame cover plate (7) from frame.

### **CAUTION**

**DO NOT UNSCREW GREASE FITTING MORE THAN 1-1/2 TURN. GREASE IS UNDER PRESSURE. FITTING COULD FLY OFF AND CAUSE INJURY.**

2. Use grease gun with appropriate fitting to tension track or slowly unscrew fitting to release track tension.



Figure 3-2. Tensioning Track

3. Make sure grease fitting is tight. Re-install cover plate.

## RUBBER TRACK

**NOTE:** Always check rubber track tension with track off ground.

1. Locate the ? mark on inside of track towards the edge.





Figure 3-3. Rubber Track Tension Mark

2. Position ? mark at the lower part of the undercarriage centered between sprocket and idler.
3. Measure clearance between roller and rubber tracks near the ? mark.
4. Rubber track is correctly tensioned if measurement is 1 - 1.45 cm (0.393-0.59 in).

## STEEL TRACK

1. Place a straight-edge on top of the track at location shown below.



2. Measure deflection between straight-edge and track.
3. Steel track is correctly tensioned when chain bend is approximately 2 cm (0.787 in).

## Replace Rubber Track

1. Thoroughly wash entire chassis and all components.

**Note:** Rubber track assemblies weigh 263 kg (580 lb) each.

2. Position machine on a firm level surface near an overhead lifting device. Ensure boom is in the lowered and stowed position.
3. Rotate turntable as needed for unrestricted access to side of chassis having track replaced.

### **⚠ CAUTION**

**DO NOT REMOVE GREASE FITTING COMPLETELY UNTIL TRACK TENSION IS RELEASED. GREASE IS UNDER PRESSURE. FITTING COULD FLY OFF AND CAUSE INJURY.**

4. Remove track tensioner coverplate. Unscrew grease valve until grease starts to come out of slot, then unscrew three more turns.




Figure 3-4. Grease Valve

5. Place a hydraulic floor jack beneath front chassis extension nearest idler wheel.



Figure 3-5. Floor Jack Location

6. Jack up chassis to remove weight from lower rollers.
7. Attach a sling through top of the track and lift. This will compress the idler cylinder assembly.




Figure 3-6. Lift Track and Compress Idler Cylinder

8. With idler cylinder compressed, lower track.
9. Remove rubber track starting at idler using large pry bar. Move forward to drive sprocket until entire track is removed.



Figure 3-7. Remove Rubber Track


10. Position new rubber track in correct direction of travel.



Figure 3-8. Rubber Track Direction of Travel

## SECTION 3 - CHASSIS & TURNTABLE

11. Attach a board or other long, rigid object to top of tread as shown below and lift into position along frame.



**Figure 3-9. Preparation for Installation**

12. Position rubber tracks around drive sprocket. Core metal of the rubber track must be in sprocket grooves.




**Figure 3-10. Install on Drive Sprocket**

13. Place a spacer close to the upper roller and bring the rubber track close to idler.



**Figure 3-11. Aligning Track on Frame**

14. Use a crowbar to complete installing over idler. Idler must engage correctly with rubber track.



**Figure 3-12. Install Track on Idler**

15. Adjust track tension. Refer to "Track Tension" on page 3-2.
16. Re-check track tension after first 10 hours of operation.

## Replace Steel Track

1. Thoroughly wash entire chassis and all components.

**Note:** Steel track assemblies weigh 340 kg (748 lb) each.

2. Position machine on a firm level surface near an overhead lifting device. Ensure boom is in the lowered and stowed position.
3. Rotate turntable as needed for unrestricted access to side of chassis having track replaced.

### ⚠ CAUTION

**DO NOT REMOVE GREASE FITTING COMPLETELY UNTIL TRACK TENSION IS RELEASED. GREASE IS UNDER PRESSURE. FITTING COULD FLY OFF AND CAUSE INJURY.**

4. Remove track tensioner coverplate. Unscrew grease valve until grease starts to come out of slot, then unscrew three more turns.




Figure 3-13. Grease Valve

5. Place a hydraulic floor jack beneath front chassis extension nearest idler wheel.



Typical Illustration

Figure 3-14. Floor Jack Location

6. Lift chassis 200 mm (8 in) above floor.

### ⚠ WARNING

**UNCONTROLLED TRACK MOVEMENT CAN CAUSE SERIOUS INJURY. KEEP CLEAR OF TRACK WHEN REMOVING PIN.**

7. If equipped, remove rubber pads from the steel track assembly.
8. Use wood blocking or other device to prevent track and chain assembly from falling uncontrolled to ground.




Figure 3-15. Brace Steel Track

9. Press out main pin with hydraulic press and C-clamp, and separate track. Remove track.
10. Place new steel track assembly next to chassis. If track is not already separated, press out main pin with hydraulic press and C-clamp, and separate track. If track is already separated, locate or remove pin if partially installed in track.

## SECTION 3 - CHASSIS & TURNTABLE

11. Check track direction of travel. Lay out track next to chassis with end of track under drive sprocket.
12. Slide track under chassis and under rollers, drive sprocket, and idler wheel.
13. Lower chassis until rollers and idler wheel are in contact with track.



**Figure 3-16. Track Direction of Travel**

14. Pull track over idler wheel to drive sprocket. Roll track around drive sprocket until track bushings engage upper sprocket grooves. Position track so at least two links remain free as shown below.




**Figure 3-17. Installing Track**

15. Remove triple grouser shoe from first and last chain links.



**Figure 3-18. Grouser Shoes Removed**

16. Attach track chain block plate (6) using two M12-1.75 x 40 bolts (7) in place of grouser shoes on lower track segment.



**Figure 3-19. Track Chain Block Plate**

17. Clean chain link holes. Lubricate chain link holes and master pin with PTFE BC 101 grease or equivalent.

18. Overlap chain links and hold in place with rod or large screwdriver. Insert master pin and drive into place with hydraulic press or similar method.



Figure 3-20. Installing Master Pin

**Note:** Chassis must be lifted off ground when tensioning track.

19. Lift chassis far enough for track to clear ground. Re-check correct position of track bushings in sprocket grooves.
20. Make sure tensioning grease valve is closed and tight. Use grease gun and extension to tension track.



Figure 3-21. Track Tensioning

21. Track is correctly tensioned when track deflection at position indicated in Figure 3-22. is approximately 20 mm (0.787 in).




Figure 3-22. Track Tension

22. Lower chassis to ground.
23. Remove two bolts and track chain block plate.
24. Install two removed triple grouser shoes using original hardware. Torque to 147.1 Nm (108.5 ft-lb).



Figure 3-23. Reinstall Triple Grouser Shoes

**NOTE:** Re-check track tension after first 10 hours of operation. Idler tensioning valve may have allowed air bubbles in cylinder which can cause track to become loose.

### Track Shoes

1. Visually check for loose or missing bolts at the start of each operating shift.
2. Check bolt torque approximately every 100 hours. Torque track shoe bolts to 65 ft-lb, +6 (91 Nm, +8.4), then tighten 1/3 turn (120°) further.

### Track Pin

The track pin is pressed in the right and left link of the chain. It is also installed through bushing at each end of the link. Outside diameter (O.D.) of pin wears against inside diameter (I.D.) of bushing with which it is making contact. Once pin reaches allowable wear limit it may be rotated 180 degrees for extended life.

### Sprocket Wear

Replace sprocket when wear reaches 4mm (.157 in). Wear is never even. Always measure the point where wear is greatest.




Figure 3-24. Sprocket Wear Measurement

### 3.2 CHASSIS TILT INDICATOR SYSTEM

The Chassis Tilt Indicator System measures the turntable angle with respect to level ground. The control system reads the reading and compares it to a pre-set turntable tilt angle value.

When the machine is in transport position, it can travel at up to maximum speed until it tilts more than 8.0°, then the system will limit the drive speed to maximum displacement mode (slow drive speed).

However, when the machine is out of transport position and the turntable tilts more than the pre-set value, the boom functions and drive functions are disabled. The operator must return the machine into transport mode in order to continue.

Refer Table 6-2, Machine Configuration Programming Information (Software Version P2.10) for details.

### 3.3 SWING DRIVE HUB

Users of this manual should note that each part mentioned is followed by an identification number enclosed in parentheses. These part numbers may be referred to in the Parts List and Assembly Drawing sections of this manual.

Specialized tools used to assemble this unit are noted in the assembly procedures and diagrammed in the Assembly Tools section.

Users should familiarize themselves with the procedures for roll and leak testing, as well as bolt tightening and torquing found on the following pages before starting any repairs.


Standard safety practices should be followed during the disassembly and assembly procedures described. Safety glasses and safety shoes should be worn, and heavy, heat resistant gloves should be used when handling heated components. Be especially alert when you see the word CAUTION. This indicates that a particular operation could cause personal injury if not performed properly or if certain safety procedures are not followed. The word NOTE is used to bring attention to certain procedures or helpful hints that will aid in the disassembly and assembly process.

### Brake Test

Prior to brake check remove Motor, Tubing and Elbow as per Motor disassembly instructions in the following subsections. To perform a brake check, use a 7/16-20 thread fitting. Install a hydraulic hand pump with pressure gauge into brake port in Brake Housing using thread fitting.

Place ROLL TEST Tool into Sun gear (8).

Apply 25 in-lbs (29 kgcm) torque. While trying to rotate tool, pump the handle on the hydraulic hand pump and increase the pressure until the brake releases. The brake is released when you are able to rotate the tool.



Record the release pressure. If brake does not release within limits shown in Table 3-1, Brake Chart, check to see if it has the proper number of springs using the SPRING CHECKING PROCEDURE.

Increase to maximum pressure (refer to Table 3-1) and hold at that pressure for one minute. If the brake does not leak or lose pressure, the unit has passed the brake test. If brake loses pressure, attempt to repair leak using the leak repair procedure at the end of this procedure.

While brake is still released, roll check the unit for one revolution of the output member by rotating the tool. Bleed off pressure slowly while rotating the ROLL TEST Tool.

Record the pressure at which the brake locks up. Using a clean rag, wipe off excess fluid from around brake port and install the pipe plug.


**Table 3-1. Brake Chart**

Number Of Springs	Release Pressure Minimum (psi)	Release Pressure Maximum (psi)	Full Release Pressure (psi)	Maximum Release Pressure (psi)	Brake Torque (in-lbs)
7	75	124	140	2000	472

### Spring Checking Procedure

Install two Flat Socket Head Cap Screws 0.250-20 UNC, 1/2" length into holes in brake piston. Tighten bolts evenly to ensure that brake piston remains straight while being compressed into brake cavity of brake housing.

Carefully remove retaining ring from brake housing. Slowly remove bolts evenly from the input brake. Remove the pressure plate from the end of the input brake and check the number of springs in brake. If incorrect, correct the count.



Install the Pressure Plate using two 0.250-20 UNC flat Socket Head Cap Screws. Tighten bolts evenly to ensure that Pressure Plate (8M) does not get wedged to the Brake Cylinder.



Install the large retaining ring into groove in Housing making sure that it is seated properly. Remove all bolts from the brake piston and discard.

**NOTE:** Use caution when removing bolts as they are subject to spring pressure. Make sure the retaining ring is secured before removing bolts.

Re-test input brake. If release and/or lockup pressures still do not match the brake chart contact JLG Service Department.

Grease and install O-ring onto motor pilot. Place motor into brake pilot and line up holes. Check timing marks. Assemble lift lugs onto hex bolts and assemble hex bolts with lugs through the motor and brake against the motor flange. Torque to 80-100 ft-lb (108-136 Nm).

Re-test input brake. If release and/or lockup pressures still do not match the brake chart contact JLG Service Department.

### Brake Leak Repair Procedure

Remove brake piston from housing using the Brake Disassembly Procedure.

Check O-rings, Backup Rings, and brake cavity in Brake Housing for damage. If no damage is found, then reinstall Input Brake according to Input Brake Installation Procedure under Main Assembly procedure and perform pressure test again. If brake still leaks, contact the service department.


**NOTE:** Failure to perform this test may result in damaged or ineffective brake parts.

### Roll and Leak Test

Torque-Hubs should always be roll and leak tested before disassembly (if possible) and after assembly to make sure the gears, bearings, and seals are working properly. The following information briefly outlines what to look for when performing these tests.

#### THE ROLL TEST

The purpose of the roll test is to determine if the unit gears are rotating consistently, easily and properly. Remove Motor and release the brake by applying 400 psi to the brake port. To perform a roll test, use the recommended tool from table below (or something equivalent) to apply constant rotational force to the input of the gearbox. If more drag is felt in the gears only at certain points, then the gears are not rolling consistently and easily and should be examined for improper installation or defects. Some gear packages roll with more difficulty than others. Do not be concerned if the gears in the unit seem to roll hard as long as they roll with consistency. Rotate the gearbox 36 revolutions both clockwise and counterclockwise.



**THE LEAK TEST**

The purpose of a leak test is to make sure the unit is airtight. To perform a leak test, use the leak test fixture from the table below. If the tool is not available, the gearbox must be sealed to perform the test. This can be accomplished by assembling the sealed input device onto the gearbox at the input end and replace one of the oil plugs with an air chuck.


**NOTICE**

**DO NOT EXCEED 10 PSI PRESSURE DURING LEAK TEST.**

Higher pressure will create a false sealing effect in assemblies with lip-seals. The unit has a leak if the pressure gauge reading on your leak check fitting starts to fall after the gearbox has been pressurized and allowed to equalize.


Leaks will most likely occur at the pipe plugs, the main seal or wherever O-rings or gaskets are located. The exact location of a leak can usually be detected by brushing a soap and water solution around the main seal and where O-rings or gaskets meet on the exterior of the unit and then checking for air bubbles.

If a leak is detected in a seal, O-ring, or gasket, the part must be replaced and the unit rechecked. Leak test at 10 psi for 20 minutes.

**Tightening and Torquing Bolts**

If an air impact wrench is used to tighten bolts, extreme care should be taken to ensure the bolts are not tightened beyond their specified torque. The following steps describe how to tighten and torque bolts or socket head cap screws in a bolt circle.

1. Tighten (but do not torque) bolt A until snug.



**Figure 3-25. Bolt Tightening Sequence**

2. Go to the opposite side of the bolt circle and tighten bolt B until equally snug.
3. Crisscross around the bolt circle and tighten the remaining bolts.
4. Use a torque wrench to apply the specified torque to bolt A.
5. Using the same sequence, crisscross around the bolt circle and apply an equal torque to the remaining bolts.

## Lubrication Information

### GENERAL PROPERTIES

Lubricant should be petroleum based gear fluid containing anti-oxidation, anti-foaming, and extreme pressure additives. The lubricant should have a minimum viscosity index of 95 cst and maintain a minimum viscosity of 40 cst under normal operating conditions. Some applications require special considerations; consult the JLG Service Department for additional information.

The table below lists recommended viscosities for various ambient operating temperatures. Recommendations are based on temperature rise of 50° to 100°F at normal operating conditions.

Table 3-2. Recommended Viscosities

Ambient Temperature	Differential Planetary		Simple Planetary	
	ISO Index	AGMA Lubricant Number	ISO Index	AGMA Lubricant Number
-40° to -5°F <sup>(1)</sup>	VG100	3EP	VG100	3EP
-5° to 40°F	VG150	4EP	VG100	3EP
40° to 105°F	VG220/VG320	5EP/6EP	VG150/VG220	4EP/5EP
105° to 150°F <sup>(2)</sup>	VG460	7EP	VG320	6EP

Footnotes  
 1. For operation in this ambient temperature range, synthetic oil is recommended with a pour point of 10°F lower than the minimum ambient temperature.  
 2. For operation in this ambient temperature range, synthetic oil is recommended for proper lubricant life at elevated temperatures.

### MAINTENANCE

Oil amounts for each series of Torque-Hub drives are indicated in the appropriate series literature. An initial oil change should be made after the first 50 hours of operation. Subsequent oil changes should be made at 1,000 hour intervals or annually, whichever comes first.

Oil temperatures should be not higher than 71° to 82°C (160° to 180°F) for continuous operation, and no higher than 93°C (200°F) for intermittent operation. For special applications, consult the JLG Service Department.

## Motor Removal

Refer to Figure 3-26. and Figure 3-27.

1. Place unit on bench with motor end up.
2. Remove magnetic Pipe Plug (1P) and drain oil from gear-box.

**NOTE:** Record oil condition and volume.

3. Remove Hydraulic Tubing Assembly (35) by loosening fittings on both ends of tube with a wrench.
4. Using a wrench, loosen jam nuts on Elbow Fittings (30) and remove fittings from Brake Housing (6) and Motor Control Valve (32).
5. Remove O-ring Pipe Plugs (23) from Motor Control Valve (32).
6. Remove Motor Control Valve (32) from Motor (31) by removing the four Bolts (21) and washers (22).
7. Remove O-ring (99) between Motor Control Valve (32) and Motor (31). Discard O-ring.
8. With unit resting on bench with Motor (31) end up, loosen Hex Bolts (29) and remove Lift Lugs (28) from the Motor (31).
9. Pull Motor (31) straight up and remove Motor (31) from Brake Housing (6).
10. Remove O-ring (26) from between Motor (31) and Brake Housing (6). Discard O-ring.




Figure 3-26. Swing Motor Valve Removal




Figure 3-27. Swing Motor Removal

## Input Brake Disassembly

Refer to Figure 3-28.

1. Insert and tighten 0.250-20 UNC flat Socket Head Cap Screws through the Pressure Plate (8M) and into the Brake Piston (8A) to compress springs and relieve pressure on the Retaining Ring (8N).

### ⚠ CAUTION

**SAFETY GLASSES MUST BE WORN DURING THESE NEXT STEPS.**

**NOTE:** Ensure Step 1 is completed before doing this next step.

2. Using retaining ring pliers, remove Retaining Ring (8N) holding Brake Piston assembly in place.
3. Lift Brake Piston Assembly (8A) out of Brake Housing (6). If Brake Piston assembly (8A) will not lift out, apply no more than 50 psi air to the Brake port to remove Brake Piston (8A). Remove Inner (Rotor) (8J) and Outer (Stator) Plates (8K) from inside Brake Housing (6).
4. Remove O-rings (8D, 8F) and Backup Rings (8E, 8H) from the Brake Housing (6).

Discard O-rings and Backup Rings.

5. Remove 0.250-20 UNC flat Socket Head Cap Screws and lift the Pressure Plate (8M) from the Brake Piston (8A).

**NOTE:** Record number of springs and mark locations before removing from brake piston.

6. Remove Springs (8L) from Brake Piston (8A).




Figure 3-28. Input Brake Disassembly

## Main Disassembly

Refer to Figure 3-29.

### **CAUTION**

**SAFETY GLASSES MUST BE WORN DURING THESE NEXT STEPS.**

1. Remove Sun Gear (8).
2. With unit resting on the Output Shaft (Pinion) (1A), remove Bolts (12) from Brake Housing (6).
3. Remove Brake Housing (6) from main assembly.
4. Remove O-ring (5A) between Brake Housing (6) and Ring Gear (4). Discard O-Ring.
5. Remove Thrust Washer (11) between Brake Housing (6) and Carrier Sub-Assembly.
6. Remove Ring Gear (4) from Housing (1G).
7. Remove O-ring (5) between Ring Gear (4) and Housing (1G), discard O-ring.
8. Remove Carrier Sub-Assembly.
9. Remove Thrust Washer (11) between Carrier Sub-assembly and Internal Gear (2).
10. Remove Internal Gear (2).




Figure 3-29. Main Disassembly

### Housing-Shaft Disassembly

Refer to Figure 3-30.

1. Set unit on a bench with Housing (1G) flange down.

**⚠ CAUTION**

SAFETY GLASSES MUST BE WORN DURING THESE NEXT STEPS.

2. Using retaining ring pliers, remove Retaining Ring (1I) from groove in Output Shaft (1A) and discard.

**⚠ CAUTION**

EYE PROTECTION SHOULD BE WORN DURING THIS PROCEDURE.

3. Remove Thrust Washer (1H).
4. While supporting Housing (1G) on Output Shaft (1A) end, press Output Shaft (1A) out of Housing (1G).

**NOTE:** Lip Seal (1B) will be pressed out of Housing (1G) by the Bearing Cone (1D) during this step.

5. Remove Bearing Cone (1E) from Housing (1G).
6. Use a bearing puller to remove Bearing Cone (1D) from Shaft (1A).
7. Bearing Cups (1C & 1F) will remain in Housing (1G).

**NOTE:** If bearing replacement is necessary, Bearing Cups (1C & 1F) can be removed with a slide hammer puller or driven out with a punch.




Figure 3-30. Housing Shaft Disassembly

### Carrier Disassembly

Refer to Figure 3-31.

1. Drive Planet Shaft (3E) out of carrier pin holes; forcing Roll Pin (3G) to shear off.
2. Hold Planet Gear (3F) and push Planet Shaft (3E) out of Carrier (3A). Thrust Washers (3B) will slide off shaft as it is removed.
3. Slide Planet Gear (3F) and two Thrust Washers (3B) out of Carrier (3A).
4. Using a hammer and punch, drive pieces of Roll Pin (3G) out of Planet Shaft (3E) and Carrier (3A).
5. Remove both rows of Needle Bearings (3C) and Spacer (3D) from bore of Planet Gear (3F).
6. Repeat Steps 1 thru 5 for remaining two Cluster Gears (3F).






Figure 3-31. Carrier Disassembly

### Carrier Assembly

Refer to Figure 3-32.

1. Apply a liberal coat of grease to the bore of Cluster Gear (3F). This will enable the Needle Rollers (3C) to be held in place during assembly.
2. Install one half of the inside of the Cluster Gear (3F) with 16 Needle Rollers (3C).

**NOTE:** Last roller installed must be installed end-wise. That is, the end of the last roller must be placed in between the ends of the two rollers that form the space, and then slid parallel to the other rollers into place.

3. Place one Spacer (3D) on top of Needle Rollers (3C) inside Planet Gear (3F).
4. Install other half of Cluster Gear (3F) with 16 Needle Rollers (3C).
5. Place Carrier (3A) into tool fixture so that one of the roll pin holes is straight up.
6. Start Planet Shaft (3E), with end opposite roll pin hole first, through planet shaft hole in carrier (3A). Ensure roll pin hole with large chamfer in planet shaft is straight up.
7. Using ample grease to hold them in position, locate Thrust Washer (3B) on each side of interior carrier wall with tangs located in Carrier Pad slots.

8. With large end of Cluster Gear (3F) facing roll pin hole in Carrier, place Cluster Gear in position in Carrier (3A). Push Planet Shaft (3E) through Cluster Gear (3F) without going all the way through the carrier (3A).
9. Finish sliding Planet Shaft (3E) in Carrier (3A) until roll pin holes of planet shaft and carrier are aligned. Align roll pin hole using a 1/8 inch diameter punch.
10. Drive roll pin (3G) through Carrier (3A) and into Planet Shaft (3E) until flush with the bottom of cast slot in Carrier (3A) outside diameter at Thrust Washer (3B) tang. Use a 1/4" pin punch to make sure roll pin (3G) is flush in the slot.
11. Repeat Steps 6 through 10 for remaining two Cluster Gears (3F).

**NOTE:** Chamfer on Roll Pin hole should face towards roll pin hole in Carrier.




Figure 3-32. Carrier Assembly

## Housing - Shaft Assembly

Refer to Figure 3-33.

**NOTE:** Spray a light film of oil on all component parts during assembly. Spray a generous amount of oil on bearings during installation.

1. Press Bearing Cup (1C) in Housing (1G). Ensure cup starts square with bore of Hub (1G).
2. Place Bearing Cone (1D) in Bearing Cup (1C) in Housing (1G).
3. Press Seal (1B) in counterbore of Housing (1G) until flush with Housing (1G) face. Ensure Seal (1B) is installed (smooth face up). Apply oil to rubber portion of seal.
4. Invert Hub (1A) and press Bearing Cup (1F) into counterbore of Housing (1G).
5. Carefully lower Housing (1G) on Output Shaft (1A) until Bearing Cone (1D) contacts Output Shaft (1A).
6. Press on small end of the Bearing Cone (1D), being careful not to contact the bearing cage, until Bearing Cone (1D) seats on shoulder of Output Shaft (1A).
7. Start Bearing Cone (1E) on Output Shaft (1A).
8. Press or tap Bearing Cone (1E) on Output Shaft (1A) until it is just seated in Bearing Cup (1F), while rotating Housing (1G).
9. Install Bearing Spacer (1H) on Output Shaft (1A) against Bearing Cone (1F).
10. Install Retaining Ring (1I) into groove of Output Shaft (1A). This Retaining Ring (1I) should never be reused in a repair or rebuild.
11. Tap Retaining Ring (1I) with a soft metal punch to ensure Retaining Ring (1I) is completely seated in groove of Output Shaft (1A).
12. Install O-ring Plug (1P). Torque to 23 to 24 ft-lb (31 to 32.5Nm).

**⚠ CAUTION**

WEAR EYE PROTECTION DURING THIS PROCEDURE.

**⚠ CAUTION**

WEAR EYE PROTECTION DURING THIS PROCEDURE.





Figure 3-33. Housing - Shaft Assembly

## Main Assembly

Refer to Figure 3-34.

1. Slightly tap Internal Gear (2) with spline side down onto Output Shaft (1A) splines to ensure Internal Gear (2) is properly seated.
2. Grease and install O-ring (5) on Housing (1G) O-ring groove.
3. Grease and install Thrust Spacer (11) into counter bore of Carrier Sub-assembly on smaller diameter cluster gear side. The grease should hold the Thrust Spacer (11) in place for assembly.
4. Place Carrier Sub-assembly on table oriented as shown below, with large end of Cluster Gear (3F) facing up. Position all three punch-marks on face of the large gears at 12 o'clock.

Timing marks on the two upper Cluster Gears will be visible through slots in the Carrier if Cluster Gears are correctly marked. Secure gear teeth using timing fixture.



5. Place Ring Gear (4) in to large end of Cluster Gear to secure timing.
6. Remove Carrier sub-assembly and Ring Gear (4) from the table and assemble into the Internal gear (2) being careful to keep the ring gear, or sun gear, in mesh with the cluster gears.

7. After engaging internal gear teeth and before rotating carrier, look at the Carrier sub-assembly in the main assembly and ensure the timing is correct by locating the timing marks in the slots in the carrier and at 12 o'clock on the gear that the timing mark is visible in the carrier bore.
8. Grease and install O-ring (5A) onto Brake Housing (6) counter bore.
9. Install Brake Housing (6) onto Ring Gear (4) by aligning the bolt holes in brake housing with ring gear holes.
10. Ensure the pipe plugs in Housing (1G) and Brake Housing (6) are timed as shown.
11. Pull one Cover Bolt (12) and place into the bolt hole and repeat for remaining bolts.
12. Torque Bolts (12) in star pattern to 23-27 ft-lb (31-36.5 Nm).
13. Install Input Shaft (8) with spline side up into housing bore. Ensure the input shaft gear teeth and planet gears are engaged.
14. Install O-ring plugs (1P) into Brake Housing (6) and Housing (1G). Torque 23 to 24 ft-lb (31 to 32.5Nm).
15. Perform leak and roll check per instructions in this section.
16. Fill oil through opening in Brake Housing (6) with 43 oz (1.3 L) of 80W90 gear oil.




Figure 3-34. Main Assembly




Figure 3-35. Brake Port Alignment

### Motor and Brake Assembly

1. Starting with a Stator (8K), alternately stack and install Stators (8K) into Lobes of Brake Housing (6) and Rotors (8J) (internal splines) onto splines of Sun Gear (8).


**NOTE:** There should always be a Stator on top and bottom of the stack.

2. Insert Brake Piston (8A) completely into Brake Housing (6) without O-rings (8D, 8F) and Backup Rings (8E, 8H) to check fit of brake. The Brake Piston (8A) should slide into Brake Housing (6) without being forced. If Brake Piston (8A) does not fit, check for burrs or size problems before proceeding.

3. Grease O-rings (8D, 8F) and install smaller diameter O-Ring (8F) into smaller diameter O-Ring groove in Brake Housing (6) and install larger diameter O-Ring (8D) into larger diameter O-Ring groove in Brake Housing (6).
4. Insert smaller diameter Solid Backup Ring (8H) into smaller groove in Brake Housing (6) between O-Ring (8F) and side of groove towards Output Shaft (1A).
5. Insert larger diameter Solid Backup Ring (8E) into groove in Brake Housing (6) between O-Ring (8D) and side of groove towards Motor (31).

## SECTION 3 - CHASSIS & TURNTABLE

**NOTE:** Refer to figure below for installing O-Rings (8D), (8F) and Backup Rings (8E), (8H).



6. Lightly grease cylinder walls of Brake Housing (6) and install Brake Piston (8A) into Brake Housing (6). If necessary, place T-134711 on top of brake and lightly tap until Brake Piston (8A) contacts brake disk stack.
7. Insert 8 Springs (8L) into Brake Piston (8A) spring holes.
8. Install Pressure Plate (8M) into Brake Housing (6) bore and onto top of Springs (8L).
9. Insert and tighten the 0.250-20 UNC Flat Head Cap Screws through the Pressure Plate (8M) and into the Brake Piston (8A) to compress the springs. Tighten Socket Head Cap Screws incrementally to evenly compress Springs (8L)

### **CAUTION**


**SAFETY GLASSES MUST BE WORN DURING THESE NEXT STEPS.**

10. Using retaining ring pliers, install large Retaining Ring (8N) into groove in Brake Housing (6) making sure that it is seated properly.

**NOTE:** Use caution when installing retaining ring (8N) into Brake Housing (6). It may cause injury if it slips out of retaining ring pliers.

11. Remove Flat Head Cap Screws from Brake Piston (8A) incrementally to release slowly release spring tension. Discard Flat Head Cap Screws.
12. Perform brake test following instructions in this section.
13. Grease and install O-Ring (26) in Motor (31) pilot.

14. Install Motor (31) in Brake Housing (6). Ensure motor valve mounting face is aligned with radial brake release port in Housing (1G).



**Figure 3-36. Swing Motor Installation**

15. Install Bolts (29) in Brake Housing (6) through Lifting Lugs (28) and Motor (31) flange. Torque bolts to 80-100 ft-lb (108.5-135.5 Nm).




Figure 3-37. Motor and Brake Assembly

### Motor Control Valve Installation

**NOTE:** Verify o-rings are located in between the motor and valve.

1. Install O-Rings (99) into counter bore on Motor Valve face.
2. Install Motor Control Valve (32) on Motor (31) using Bolts (21) and Washers (22). Torque Bolts to 18-20 ft-lb (24.5-27 Nm). Ensure holes in Motor Control Valve (32) are aligned with holes in Motor (31).
3. Install Elbow Fitting (30) into Brake Housing (6). Ensure the thread fitting O-ring seats onto the Brake Housing (6). Rotate the Elbow Fitting (30) to horizontal position as shown in picture.
4. Install Elbow Fitting (30) into Motor Valve (32). Ensure the thread fitting O-ring seats onto the Motor Valve (32). Rotate the Elbow Fitting (30) to horizontal position as shown in picture.
5. Install Tube Assembly (35) to elbow fittings as shown in picture. Torque tube assembly nut to 13-15 ft-lb (17.5-20 Nm). Tighten Jam Nut on Elbow Fitting (30) into 13-15 ft-lb (17.5- 20 Nm), torque.
6. Install one O-Ring Plug (23) onto Motor Control Valve (32). Torque to 18-20 ft-lb (24.5-27 Nm).
7. Install hydraulic test fitting into the other control valve O-ring Plug (23) hydraulic port.
8. Perform pressure decay test at "MAXIMUM PRESSURE". Hold pressure for 1 minute. If pressure does decay, remove the pressure and inspect connections and retest.
9. Remove hydraulic test fitting.
10. Install O-ring plug (23) onto motor control valve (32). Torque to 18-20 ft-lb (24.5-27 Nm).






Figure 3-38. Swing Motor Valve Installation




Figure 3-39. Bearing Cone Press Tool




Figure 3-40. Bearing Cone Press Tool




Figure 3-41. Bearing Cup Press Tool




Figure 3-42. Lockout Wrench Tool




Figure 3-43. Bearing Cup Press Tool





Figure 3-44. Seal Press Tool







Figure 3-46. Swing Drive Test Plate



### 3.4 SWING MOTOR

#### Disassembly and inspection



1. Place Torqlink™ in a soft jawed vice, with coupling shaft (12) pointed down and vise jaws clamping firmly on sides of housing (18) mounting flange or port bosses. Remove manifold port O-Rings (18A) if applicable.



**⚠ WARNING**

**IF THE TORQLINK™ IS NOT FIRMLY HELD IN THE VISE, IT COULD BE DISLODGED DURING THE SERVICE PROCEDURES, CAUSING INJURY.**

2. Scribe an alignment mark down and across the Torqlink™ components from end cover (2) to housing (18) to facilitate reassembly orientation where required. Loosen two shuttle or relief valve plugs (21) for disassembly later if included in end cover. 3/16 or 3/8 inch Allen wrench or 1 inch hex socket required.




3. Remove five, six, or seven special ring head bolts (1) using a 1/2 or 9/16 inch size socket. Inspect bolts for damaged threads or sealing rings under the bolt head. Replace damaged bolts.



4. Remove end cover assembly (2) and seal ring (4). Discard seal ring.



**NOTE:** Refer to appropriate "alternate cover construction" on the exploded view to determine end cover type being serviced.



- |                         |                            |                            |
|-------------------------|----------------------------|----------------------------|
| 1. Special Bolts        | 8B. Stator or Stator Vane  | 15. Thrust Bearing         |
| 2. End Cover            | 8C. Vane                   | 16. Seal                   |
| 3. Seal Ring-Commutator | 8D. Stator Half            | 17. Back-up Washer         |
| 4. Seal Ring            | 9. Wear Plate              | 18. Housing                |
| 5. Commutator Ring      | 10. Drive Link             | 18A. O-Ring                |
| 6. Commutator Ring      | 11. Not Used               | 19. Bearing/Bushing, Outer |
| 7. Manifold             | 12. Coupling Shaft         | 20. Dirt & Water Seal      |
| 8. Rotor Set            | 13. Bearing/Bushing, Inner | 21. Plug                   |
| 8A. Rotor               | 14. Thrust Washer          |                            |

**Figure 3-47. Swing Drive Motor**

5. If end cover (2) is equipped with shuttle valve components, remove two previously loosened plugs (21).




**NOTICE**

**BE READY TO CATCH THE SHUTTLE VALVE OR RELIEF VALVE COMPONENTS THAT FALL OUT OF END COVER VALVE CAVITY WHEN PLUGS ARE REMOVED.**

**NOTE:** Do not remove the insert (and orifice plug if included) in the end cover (2). They are serviced as an integral part of the end cover.

## SECTION 3 - CHASSIS & TURNTABLE

6. Thoroughly wash end cover (2) in proper solvent and blow dry. Be sure the end cover valve apertures, including the internal orifice plug, are free of contamination. Inspect end cover for cracks and bolt head recesses for good bolt head sealing surfaces. Replace end cover as necessary.



**NOTE:** A polished pattern (not scratches) on the cover from rotation of commutator (5) is normal. Discoloration indicates excess fluid temperature, thermal shock, or excess speed and requires system investigation for cause and close inspection of end cover, commutator, manifold, and rotor set.

7. Remove commutator ring (6). Inspect commutator ring for cracks, or burrs.



8. Remove commutator (5) and seal ring (3) Remove seal ring from commutator, using an air hose to blow air into ring groove until seal ring is lifted out and discard seal ring. Inspect commutator for cracks or burrs, wear, scoring, spalling or brinelling. If any of these conditions exist, replace commutator and commutator ring as a matched set.



9. Remove manifold (7) and inspect for cracks surface scoring, brinelling or spalling. Replace manifold if any of these conditions exist. A polished pattern on the ground surface from commutator or rotor rotation is normal. Remove and discard the seal rings (4) that are on both sides of the manifold.



**NOTE:** The manifold is constructed of plates bonded together to form an integral component not subject to further disassembly for service. Compare configuration of both sides of them as if old to ensure that same surface is reassembled against the rotor set.

10. Remove rotor set (8) and warplane (9), together to retain the rotor set in its assembled form, maintaining the same rotor vane (8C) to stator (8B) contact surfaces. The drive link (10) may come away from the coupling shaft (12) with the rotor set, and wearplate. You may have to shift the rotor set on the warplane to work the drive link out of the rotor (8A) and warplane. Inspect the rotor set in its assembled form for nicks, scoring, or spalling on any surface and for broken or worn splines. If the rotor set component requires replacement, the complete rotor set must be replaced as it is a matched set. Inspect the warplane for cracks, brinelling, or scoring. Discard seal ring (4) that is between the rotor set and wearplate.




**NOTE:** Rotor set (8) components may become disassembled during service procedures. Marking surface of rotor and stator that is facing UP, with etching ink or grease pencil before removal from Torqlink™ will ensure correct reassembly of rotor into stator and rotor set into Torqlink™. Marking all rotor components and mating spline components for exact repositioning at assembly will ensure maximum wear life and performance of rotor set and Torqlink™.



**NOTE:** Series TG Torqlinks™ may have a rotor set with two stator halves (8B) with a seal ring (4) between them and two sets of seven vanes (8C). Discard seal ring only if stator halves become disassembled during the service procedures.


**NOTE:** A polished pattern on wear plate from rotor rotation is normal.

11. Place rotor set (8) and wear plate (9) on a flat surface and center rotor (8A) in stator (8B) such that two rotor lobes (180 degrees apart) and a roller vane (8C) centerline are on the same stator centerline. Check the rotor lobe to roller vane clearance with a feeler gage at this common centerline. If there is more than 0.005 inches (0.13 mm) of clearance, replace rotor set.



**NOTE:** If rotor set (8) has two stator halves (8B & 8D) and two sets of seven vanes (8C & 8E) as shown in the alternate construction TG rotor set assembly view, check the rotor lobe to roller vane clearance at both ends of rotor.


12. Remove drive link (10) from coupling shaft (12) if it was not removed with rotor set and wear plate. Inspect drive link for cracks and worn or damaged splines. No perceptible lash (play) should be noted between mating spline parts. Remove and discard seal ring (4) from housing (18).





13. Remove thrust bearing (11) from top of coupling shaft (12). Inspect for wear, brinelling, corrosion and a full complement of retained rollers.



14. Check exposed portion of coupling shaft (12) to be sure you have removed all signs of rust and corrosion which might prevent its withdrawal through the seal and bearing. Crocus cloth or fine emery paper may be used.



15. Remove coupling shaft (12), by pushing on the output end of shaft. Inspect coupling shaft bearing and seal surfaces for spalling, nicks, grooves, severe wear or corrosion and discoloration. Inspect for damaged or worn internal and external splines or keyway. Replace coupling shaft if any of these conditions exist.



**NOTE:** Minor shaft wear in seal area is permissible. If wear exceeds 0.020 inches (0.51 mm) diametrically, replace coupling shaft.

**NOTE:** A slight "polish" is permissible in shaft bearing areas. Anything more requires coupling shaft replacement.

16. Remove and discard seal ring (4) from housing (18).


- 17.** Remove thrust bearing (15) and thrust washer (14) Inspect for wear, brinelling, corrosion and a full complement of retained rollers.




- 18.** Remove and discard seal (16) and back up washer (17) from Small Frame housing (18).



- 19.** Remove housing (18) from vise, invert it and remove and discard seal (20). A blind hole bearing or seal puller is required.





- 20.** Inspect housing (18) assembly for cracks and machined surfaces for nicks, burrs, brinelling, or corrosion. Remove burrs that can be removed without changing dimensional characteristics. Inspect tapped holes for thread damage. Discard housing assembly if damaged.




- 21.** If housing (18) assembly has passed inspection to this point, inspect housing bearings/bushings (19) and (13) and if they are captured in the housing cavity the two thrust washers (14) and thrust bearing (15). The bearing rollers must be firmly retained in the bearing cages, but must rotate and orbit freely. All rollers and thrust washers must be free of brinelling and corrosion. The bushing (19) or (13) to coupling shaft diameter clearance must not exceed 0.010 inch (0.025 mm). A bearing, bushing, or thrust washer that does not pass inspection must be

## SECTION 3 - CHASSIS & TURNTABLE



replaced. If the housing has passed this inspection the disassembly of the Torqlink™ is completed.



**NOTE:** Depth or location of bearing/bushing (13) in relation to the housing wear plate surface and the depth or location of bearing/bushing (19) in relation to the beginning of bearing/bushing counter bore should be measured and noted before removing the bearings/ bushings. This will facilitate the correct reassembly of new bearings/bushings.



22. If bearings, bushing, or thrust washers must be replaced use a suitable size bearing puller to remove bearing/ bushings (19) and (13) from housing (18) without damaging the housing. Remove thrust washers (14) and thrust bearing (15) if previously retained in housing by bearing (13).



## Assembly

Replace all seals and seal rings with new ones each time you reassemble the Torqlink™ unit. Lubricate all seals and seal rings with SAE 10W40 oil or clean grease before assembly.

**NOTE:** Individual seals and seal rings as well as a complete seal kit are available. The parts should be available through most OEM parts distributors or Parker approved Torqlink™ distributors. (Contact your local dealer for availability).

**NOTE:** Unless otherwise indicated, do not oil or grease parts before assembly.

Wash all parts in clean petroleum-based solvents before assembly. Blow them dry with compressed air. Remove any paint chips from mating surfaces of the end cover, commutator set, manifold rotor set, wear plate and housing and from port and sealing areas.

### **⚠ WARNING**

SOLVENTS ARE FLAMMABLE. BE EXTREMELY CAREFUL WHEN USING ANY SOLVENT. EVEN A SMALL EXPLOSION OR FIRE COULD CAUSE INJURY OR DEATH.

### **⚠ WARNING**

WEAR EYE PROTECTION AND BE SURE TO COMPLY WITH OSHA OR OTHER MAXIMUM AIR PRESSURE REQUIREMENTS.

1. If the housing (18) bearing components were removed for replacement, thoroughly coat and pack a **new** outer bearing/bushing (19) with clean corrosion resistant grease recommended in the material section. Press the new bearing/bushing into the counterbore at the mounting flange end of the housing, using the appropriate sized bearing mandrel, which will control the bearing/ bushing depth.

Torqlink™ housings require the use of bearing mandrel to press bearing/ bushing (19) into the housing to a required depth of 0.151/0.161 inches (3.84/4.09 mm) from the end of the bearing counterbore.




**NOTE:** Bearing mandrel must be pressed against lettered end of bearing shell. Take care housing bore is square with press base and bearing/bushing is not cocked when pressing a bearing/bushing into the housing.

### **NOTICE**

IF BEARING MANDREL SPECIFIED IN "TOOLS AND MATERIALS REQUIRED FOR SERVICING" SECTION IS NOT AVAILABLE AND ALTERNATE METHODS ARE USED TO PRESS IN BEARING/BUSHING (13) AND (19), BEARING/BUSHING DEPTHS SPECIFIED MUST BE ACHIEVED TO ENSURE ADEQUATE BEARING SUPPORT AND CORRECT RELATIONSHIP TO ADJACENT COMPONENTS WHEN ASSEMBLED.

### **NOTICE**



BECAUSE THE BEARING/BUSHINGS (13) AND (19) HAVE A PRESS FIT INTO THE HOUSING THEY MUST BE DISCARDED WHEN REMOVED. THEY MUST NOT BE REUSED.








## SECTION 3 - CHASSIS & TURNTABLE

2. The Torqlink™ inner housing bearing/bushing (13) can now be pressed into its counterbore in housing (18) flush to 0.03 inch (.76 mm) below the housing wear plate contact face. Use the opposite end of the bearing mandrel that was used to press in the outer bearing/bushing (19).




3. Press a **new** dirt and water seal (20) into the housing (18) outer bearing counterbore.


The Torqlink™ dirt and water seal (20) must be pressed in until its flange is flush against the housing.



- Place housing (18) assembly into a soft jawed vise with coupling shaft bore down, clamping against the mounting flange.




- On the Torqlinks™ assemble a **new** backup washer (17) and **new** seal (16) with the seal lip facing toward the inside of Torqlink™, into their respective counterbores in housing (18) if they were not assembled in procedure 2.



**NOTICE**

ORIGINAL DESIGN LARGE FRAME, TF & TG TORQLINKS™ THAT DO NOT HAVE BACKUP WASHER (25) WHEN DISASSEMBLED MUST BE ASSEMBLED WITH A NEW BACKUP WASHER (17), NEW BACKUP WASHER (25), AND NEW SEAL (16).

- Assemble thrust washer (14) then thrust bearing (15) that was removed from the Torqlink™.




**NOTE:** Torqlinks™ require one thrust washer (14) with thrust bearing (15). The coupling shaft will be seated directly against the thrust washer.

- Apply masking tape around splines or keyway on shaft (12) to prevent damage to seal.



- Apply a generous amount of clean corrosion resistant to lower (outer) housing bearing/bushing (19). Install coupling shaft (12) in housing (18), seating it against thrust bearing (15) in housings.




**NOTICE**

OUTER BEARING (19) IS NOT LUBRICATED BY SYSTEM HYDRAULIC FLUID. BE SURE IT IS THOROUGHLY PACKED WITH RECOMMENDED GREASE, PARKER GEAR GREASE SPECIFICATION #045236, E/M LUBRICANT #K-70M.


**NOTE:** Mobil Mobilith SHC<sup>®</sup> 460

**NOTE:** A 102Tube (P/N 406010) is included in each seal kit.

**NOTE:** The coupling shaft (12) will be flush or just below the housing wear plate surface on Torqlinks™ when properly seated. The coupling shaft must rotate smoothly on the thrust bearing package.



9. Apply a small amount of clean grease to a **new** seal ring (4) and insert it in housing (18) seal ring groove.




**NOTE:** One or two alignment studs screwed finger tight into housing (18) bolt holes, approximately 180 degrees apart, will facilitate the assembly and alignment of components as required in the following procedures. The studs can be made by cutting off the heads of either 3/8-24 UNF 2A or 5/16-24 UNF 2A bolts as required that are over 0.5 inch (12.7 mm) longer than the bolts (1) used in the Torqlink™.

10. Install drive link (10) the long splined end down into the coupling shaft (12) and engage the drive link splines into mesh with the coupling shaft splines.




**NOTE:** Use any alignment marks on coupling shaft and drive link to assemble drive link splines in their original position in the mating coupling shaft splines.


11. Assemble wear plate (9) over drive link (10) and alignment studs to housing (18).



12. Apply a small amount of clean grease to a new seal ring (4) and assemble it into the seal ring groove on the wear plate side of the rotor set stator (8B).



13. Install the assembled rotor set (8) onto wear plate (9) with rotor (8A) counterbore and seal ring side down and the splines into mesh with the drive link splines.




**NOTE:** It may be necessary to turn one alignment stud out of the housing (18) temporarily to assemble rotor set (8) or manifold (7) over the drive link.

**NOTE:** If necessary, go to the appropriate, "Rotor Set Component Assembly Procedure."


**NOTE:** Rotor set rotor counterbore side must be against wear plate for drive link clearance and to maintain original rotor-drive link spline contact. A rotor set without a counterbore that was not etched before disassembly can be reinstalled using drive link spline pattern on rotor splines to determine which side was down. Rotor set seal ring groove faces toward wear plate (9).

14. Apply clean grease to a new seal ring (4) and assemble it into the seal ring groove in the rotor set contact side of manifold (7).





**NOTE:** The manifold (7) is made up of several plates bonded together permanently to form an integral component. The manifold surface that must contact the rotor set has its series of irregular shaped cavities on the largest circumference or circle around the inside diameter. The polished impression left on the manifold by the rotor set is another indication of which surface must contact the rotor set.

15. Assemble manifold (7) over alignment studs and drive link (10) onto the rotor set. Ensure correct manifold surface is against rotor set.




## SECTION 3 - CHASSIS & TURNTABLE

16. Apply grease to a **new** seal ring (4) and insert it in the seal ring groove exposed on the manifold.



17. Assemble commutator ring (6) over alignment studs onto the manifold.







18. Assemble a **new** seal ring (3) flat side up, into commutator (5) and assemble commutator over the end of drive link (10) onto manifold (7) with seal ring side up.



19. If shuttle valve components items #21, were removed from end cover (2) turn a plug (21), loosely into one end of the valve cavity in the end cover. A 3/16 inch Allen wrench is required.

20. Assemble a **new** seal ring (4) into end cover (2) and assemble end cover over the alignment studs and onto the commutator set. If the end cover has only 5 bolt holes be sure the cover holes are aligned with the 5 threaded holes in housing (18). The correct 5 bolt end cover bolt hole relationship to housing port bosses.





**NOTE:** If end cover has a valve (24) or has five bolt holes, use the line previously scribed on the cover to radially align end cover into its original position.


21. Assemble five or seven special bolts (1). Screw in finger tight. Remove and replace the two alignment studs with bolts after the other bolts are in place. Alternately and progressively tighten the bolts to pull the end cover and other components into place with a final torque of 22-26 ft.-lbs., (30-35 Nm) 45-55 ft.-lbs. (61-75 Nm) for the seven 3/8-24 threaded bolts.

**NOTE:** Special bolts required for use with the relief or shuttle valve (24) end cover assembly (2) are longer than bolts required with standard and cover assembly. Refer to individual service parts lists or parts list charts for correct service part number if replacement is required.



22. Torque two shuttle valve plug assemblies (21) in end cover assembly to 9-12 ft-lb (12-16 Nm) if cover is so equipped.


Torque two relief valve plug assemblies (21) in end cover assembly to 45-55 ft-lb (61-75 Nm) if cover is so equipped.




### One Piece Stator Construction

A disassembled rotor (8A) stator (8B) and vanes (8C) that cannot be readily assembled by hand can be assembled by the following procedures.

1. Place stator (8B) onto wear plate (9) with seal ring (4) side down, after following Torqlink™ assembly procedures 1 through 13. Be sure the seal ring is in place.



2. If assembly alignment studs are not used, align stator bolt holes with wear plate and housing bolt holes and turn two bolts (1) finger tight into bolt holes approximately 180 degrees apart to retain stator and wear plate stationary.
3. Assemble rotor (8A), counterbore down if applicable, into stator (8B), and onto wear plate (9) with rotor splines in mesh with drive link (10) splines.



**NOTE:** If manifold side of rotor was etched during Torqlink disassembly, this side should be up. If rotor is not etched and does not have a counterbore, use drive link spline contact pattern on rotor splines to determine rotor side that must be against the wear plate.


4. Assemble six vanes (8C), or as many vanes that will readily assemble into the stator vane pockets.



### NOTICE

EXCESSIVE FORCE USED TO PUSH ROTOR VANES INTO PLACE COULD SHEAR OFF COATING APPLIED TO STATOR VANE POCKETS.

5. Grasp the output end of coupling shaft (12) with locking pliers or other appropriate turning device and rotate coupling shaft, drive link and rotor to seat the rotor and the assembled vanes (8C) into stator (8B), creating the necessary clearance to assemble the seventh or full complement of seven vanes. Assemble the seven vanes using minimum force.



6. Remove two assembled bolts (1) if used to retain stator and wear plate.

### 3.5 SWING BEARING

#### Swing Bearing Wear Tolerance

See Figure 3-49., Swing Bearing Wear Tolerance.

1. Position the machine as follows and as seen in Figure 3-49., Swing Bearing Wear Tolerance, Position 1:
  - a. The turntable needs to be centered between the rear wheels.
  - b. Lift the boom to horizontal and fully extend the main boom
  - c. Lift the jib to be horizontal
  - d. Keep the jib and platform centered and unloaded
2. Set up a dial indicator as follows:
  - a. The dial indicator location is to be at the front center of the machine, next to the bearing, opposite of the tower pivot pin.
  - b. The magnetic base of the indicator should be positioned on the frame
6. Verify the dial indicator has not shifted. Record the value for bearing play.
7. Return the machine to Figure 3-49., Swing Bearing Wear Tolerance, Position 1. The dial indicator should return to zero. If the dial indicator does not return to zero, take corrective action and repeat the test.
8. If the measurement is more than 0.10 in. (4.2 mm), replace the bearing. If the measurement is less than 0.10 in. (4.2 mm), and any of the following conditions exist, the bearing should be removed, disassembled, and inspected.
  - a. Metal particles in the grease.
  - b. Increased drive power required.
  - c. Noise.
  - d. Rough rotation.
9. If bearing inspection shows no defects, reassemble and return to service.



- c. The indicator point needs positioned to measure the turntable base plate 2 in. (51 mm) from the root of the gear tooth. Refer to Figure 3-49., Swing Bearing Wear Tolerance.
3. Zero the dial indicator.
4. Check dial indicator accuracy once positioned, using a feeler gauge and ensure the dial indicator reading, is the same as the feeler gauge thickness.
5. Position the machine as follows and as seen in Figure 3-49., Swing Bearing Wear Tolerance, Position 2:
  - a. Do not rotate the turntable
  - b. Raise the main boom to be fully elevated and retracted
  - c. Raise the jib to be fully elevated and centered
  - d. Center the platform and keep it unloaded



## Turntable Bearing Mounting Bolt Condition Check

### NOTICE

THE SWING BEARING IS ONE OF THE MOST CRITICAL POINTS ON AN AERIAL LIFT. IT IS HERE THAT THE STRESSES OF LIFTING ARE CONCENTRATED, AT THE CENTER OF ROTATION. BECAUSE OF THIS, PROPER MAINTENANCE OF THE SWING BEARING BOLTS IS A MUST FOR SAFE OPERATION.

**NOTE:** This check is designed to replace the existing bearing bolt torque checks on JLG Lifts in service. This check must be performed after the first 50 hours of machine operation and every 600 hours of machine operation thereafter. If during this check any bolts are found to be missing or loose, replace missing or loose bolts with new bolts and torque to the value specified in the torque chart, after lubricating the bolt threads with JLG Threadlocker P/N 0100019. After replacing and retorquing bolt or bolts recheck all existing bolts for looseness.

1. Check the frame to bearing. Attach bolts as follows:
  - a. Elevate the fully extended main boom to horizontal as shown in Figure 3-50.
  - b. At the positions indicated on Figure 3-49, try and insert the 0.0015 in. feeler gauge between the bolt head and hardened washer at the arrow indicated position.
  - c. Assure that the 0.0015 in. feeler gauge will not penetrate under the bolt head to the bolt shank.
  - d. Swing the turntable 90 degrees, and check some selected bolts at the new position.
  - e. Continue rotating the turntable at 90 degree intervals until a sampling of bolts have been checked in all quadrants.

2. Check the turntable to bearing. Attach bolts as follows:
  - a. Elevate the fully retracted main boom to full elevation as shown in Figure 3-50.
  - b. At the positions indicated on Figure 3-49, try and insert the 0.0015 in. feeler gauge between the bolt head and hardened washer at the arrow indicated position.
  - c. Lower the boom to horizontal and fully extend the boom.
  - d. At the position indicated on Figure 3-49, try and insert the 0.0015 in. feeler gauge between the bolt head and hardened washer at the arrow indicated position.




Figure 3-48. Swing Bolt Feeler Gauge Check





Figure 3-49. Swing Bearing Wear Tolerance

MODELS	A	B
400SC	74.4" (189 cm)	42.1" (107 cm)
460SJC	75.19" (191 cm)	42.35" (105 cm)

**Gross Weight: 7,994 lbs (3,626 kg)  
Boom and Turntable Assembly**

**NOTE: Do not lift boom**



MAE18200

Figure 3-50. Swing Bearing Removal

## Swing Bearing Removal

1. From ground control station, operate the boom adequately to provide access to frame opening to rotary coupling.

### **⚠ WARNING**

**NEVER WORK BENEATH THE BOOM WITHOUT FIRST ENGAGING BOOM SAFETY PROP OR PROVIDING ADEQUATE OVERHEAD SLING SUPPORT AND/OR BLOCKING.**

2. Attach an adequate support sling to the boom and draw all slack from sling. Prop or block the boom if feasible.
3. From inside turntable, remove mounting hardware from rotary coupling mount bracket.
4. Tag and disconnect the hydraulic lines from the fittings on the top of the rotary coupling. Use a suitable container to retain any residual hydraulic fluid. Cap or plug all openings of hydraulic lines and port.
5. Disconnect wiring harness connected to the rotary coupling and tag and disconnect remote grease fitting line (if equipped).
6. Attach suitable overhead lifting equipment to the base of the turntable weldment. See Figure 3-50., Swing Bearing Removal.
7. Use a suitable tool to scribe a line on the inner race of the swing bearing and on the underside of the turntable. This will aid in aligning the bearing upon installation. Remove the bolts and washers which attach the turntable to the bearing inner race. Discard the bolts.
8. Use the lifting equipment to carefully lift the complete turntable assembly from the bearing. Ensure that no damage occurs to the turntable, bearing or frame-mounted components.
9. Carefully place the turntable on a suitably supported trestle.

**NOTE:** *The swing bearing approximately weighs 138 lbs. (55 kg).*

10. Use a suitable tool to scribe a line on the outer race of the swing bearing and the frame. This line will aid in aligning the bearing upon installation. Remove the bolts and washers which attach the outer race of the bearing to the frame. Discard the bolts. Use suitable lifting equipment to remove the bearing from the frame, then move the bearing to a clean, suitably supported work area.

## Swing Bearing Installation

**NOTE:** *The swing bearing approximately weighs 138 lbs. (55 kg).*

1. Using suitable lifting equipment, carefully lower the swing bearing into position on the frame. Ensure the scribed line of the outer race of the bearing aligns with the scribed line on the frame. If a new swing bearing is used, ensure that the filler plug fitting is at 90 degrees from the fore and aft center line of the frame.

### **⚠ CAUTION**

**JLG INDUSTRIES RECOMMENDS THAT ALL REMOVED BEARING BOLTS BE DISCARDED AND REPLACED WITH NEW BOLTS. SINCE THE SWING BEARING IS THE ONLY STRUCTURAL LINK BETWEEN THE FRAME AND TURNTABLE, IT IS IMPERATIVE THAT SUCH REPLACEMENT HARDWARE MEETS JLG SPECIFICATIONS. USE OF GENUINE JLG HARDWARE IS HIGHLY RECOMMENDED.**

2. Apply a light coating of JLG Threadlocker P/N 0100019 to the new bearing bolts and loosely install the bolts and washers through the frame and outer race of bearing.

### **NOTICE**

**IF COMPRESSED AIR OR ELECTRICALLY OPERATED IMPACT WRENCH IS USED FOR TIGHTENING THE BEARING ATTACHMENT BOLTS, THE TORQUE SETTING ACCURACY OF THE TOOL SHOULD BE CHECKED PRIOR TO USE.**


3. Refer to the Torque Sequence diagram as shown in Figure 3-51., Swing Bearing Torque Sequence. Clean any residue off the new bearing bolts, then apply a light coating of JLG Threadlocker P/N 0100019 and install the bolts and washers through the frame and outer race of the bearing. Tighten the bolts to an initial torque of 190 ft. lbs. (258 Nm) w/JLG Threadlocker P/N 0100019.
4. Remove the lifting equipment from the bearing.
5. Using suitable lifting equipment, carefully position the turntable assembly above the machine frame.
6. Carefully lower the turntable onto the swing bearing, ensuring that the scribed line of the inner race of the bearing aligns with scribed line on the turntable. If a new swing bearing is used, ensure that the filler plug fitting is at 90 degrees from the fore and aft center line of the turntable.
7. Clean any residue off the new bearing bolts, then apply a light coating of JLG Threadlocker P/N 0100019 and install the bolts and washers through the turntable and inner race of the bearing.
8. Following the Torque Sequence diagram shown in Figure 3-51., Swing Bearing Torque Sequence, tighten the bolts to a torque of 190 ft. lbs. (258 Nm).
9. Remove the lifting equipment.

## SECTION 3 - CHASSIS & TURNTABLE

10. Install the rotary coupling mount bracket, apply a light coating of JLG Threadlocker P/N 0100011 to the attaching bolts and secure the mount bracket to the turntable with the mounting hardware.
11. Connect the hydraulic lines, electrical harness and remote grease fitting line (if equipped) to the rotary coupling as tagged prior to removal.
12. At ground control station, use boom lift control to lower boom to stowed position.
13. Using all applicable safety precautions, activate the hydraulic system and check the swing system for proper and safe operation.


### 3.6 SETTING SWING GEAR BACKLASH

1. Set swing gear backlash to 0.005 - 0.010 in (0.127 - 0.254 mm).
2. Place shim (JLG P/N 1001190964) between pinion and bearing on high spot.




**NOTE:** High spot is marked with yellow paint.

3. Apply JLG Threadlocker (P/N 0100019) to pivot bolt. Torque to 205 ft-lb (280 Nm).




4. Remove turntable lock pin.




5. Apply JLG Threadlocker (P/N 0100019) to remaining swing drive mounting bolts. Torque to 30 ft-lb (40 Nm).

6. Tighten jack bolt until pinion is completely snug against shim and bearing. After pinion is snug, loosen jack bolt.



7. Apply JLG Threadlocker (P/N 0100019) to jack bolt and jam nut. Torque jack bolt to 50 ft-lb (68 Nm).
8. Tighten jam nut.



9. Torque remaining swing drive retaining bolts to 405 ft-lb (550 Nm).
10. Remove and discard shim.

### 3.7 SWING BEARING TORQUE VALUES

1. Outer Race - 190 ft-lb (258 Nm) with JLG Threadlocker P/N 0100019.
2. Inner Race - 190 ft-lb (258 Nm) with JLG Threadlocker P/N 0100019.
3. See Swing Bearing Torque Sequence.

#### **⚠ WARNING**

**CHECK INNER AND OUTER BEARING RACES FOR MISSING OR LOOSE BOLTS AFTER FIRST 50 HOURS OF OPERATION, AND EVERY 600 HOURS THEREAFTER.**




Figure 3-51. Swing Bearing Torque Sequence

### 3.8 ROTARY COUPLING

Use the following procedure to install the seal kit.

1. If not already removed, remove the axle oscillation valve from the cylinder barrel. The Shaft of the valve protrudes into the barrel and will damage the Shaft and seals if left in place.
2. Remove retaining ring (5) from end.
3. Remove thrust ring (4) from the same end.
4. Remove center body (2) from housing (1).
5. Cut off old Seals (6, 8, 9).
6. Remove proximity switch.
7. Assemble seals (3) in direction shown in Figure 3-52., Rotary Coupling Seal Installation.
8. Reassemble O-ring (8).
9. Heat cap seals (9) in hydraulic oil for 5 minutes at 300° F (149° C).
10. Assemble cap seals over O-rings
11. Reinsert center body into housing (lube with hydraulic oil).
12. Replace Spacer and snap ring.





Figure 3-52. Rotary Coupling Seal Installation






MAF06160

- |            |                   |            |
|------------|-------------------|------------|
| 1. Body    | 4. Thrust Ring    | 7. Bearing |
| 2. Housing | 5. Retaining Ring | 8. O-Ring  |
| 3. Seal    | 6. O-Ring         | 9. Seal    |


Figure 3-53. Rotary Coupling Cutaway



MAF04550

- |            |                    |                             |                      |                      |
|------------|--------------------|-----------------------------|----------------------|----------------------|
| 1. Bolt    | 5. Nut             | 9. Lug                      | 13. Locknut          | 17. Fitting          |
| 2. Bolt    | 6. Nut             | 10. Switch Mounting Bracket | 14. Washer           | 18. Fitting          |
| 3. Fitting | 7. Washer          | 11. Proximity Switch        | 15. Screw            | 19. Fitting          |
| 4. Fitting | 8. Rotary Coupling | 12. Plug                    | 16. Mounting Bracket | 20. Swivel Elbow Nut |


Figure 3-54. Rotary Coupling Installation (With Turntable Bearing Spacer)



MAF04560

- |         |                           |                             |             |             |
|---------|---------------------------|-----------------------------|-------------|-------------|
| 1. Bolt | 5. Washer                 | 9. Lug                      | 13. Locknut | 17. Fitting |
| 2. Bolt | 6. Swivel Mount           | 10. Switch Mounting Bracket | 14. Washer  | 18. Fitting |
| 3. Nut  | 7. Swivel Mount Shim      | 11. Proximity Switch        | 15. Screw   | 19. Fitting |
| 4. Nut  | 8. Swivel 7 Port Coupling | 12. Plug                    | 16. Adapter | 20. Fitting |

Figure 3-55. Rotary Coupling Installation (Without Turntable Bearing Spacer)



1001189523\_G  
MAF04570

**Table 3-3. Coupling Port Information - 7 Port**

Port No.	Port Size	Description	Max Rated Pressure PSI (Bar)	Proof Pressure PSI (Bar)
1	-12 SAE	Right Drive, FWD	5000 (345)	7500 (517)
2	-12 SAE	Left Drive, FWD	5000 (345)	7500 (517)
3	-12 SAE	Right Drive, Reverse	5000 (345)	7500 (517)
4	-12 SAE	Left Drive, Reverse	5000 (345)	7500 (517)
5	-6 SAE	2 Speed Shift	500 (34)	750 (52)
6	-6 SAE	Case Drain	375 (26)	563 (39)
7	-6 SAE	Brake Release	500 (34)	750 (52)

**Figure 3-56. Rotary Coupling Port Location**

### 3.9 GENERATOR

**⚠ WARNING**


STOP ENGINE BEFORE CARRY OUT SCHEDULE MAINTENANCE.

**NOTE:** Do often service, if operating in hostile environment.

#### Maintenance Schedule


##### EVERY 250 HOURS

Every 250 hours of operation, check the drive belt for proper tension.




##### EVERY 500 HOURS

Every 500 hours of operation, service the generator brushes and slip rings. Hostile environments may require more frequent service.



Every 500 hours of service, blow out the inside of the generator. If operating in a hostile environment, clean monthly.




### Overload Protection

**⚠ WARNING**

STOP THE ENGINE WHENEVER CHECKING OR INSPECTING THE CIRCUIT BREAKER.

The circuit breaker protects the generator windings from overload. If the circuit breaker opens, generator output stops. If the circuit breaker continues to open, check for faulty equipment connected to the platform receptacles.



#### Inspecting Brushes, Replacing Brushes and Cleaning Slip Rings

Refer to Figure 3-57., Inspecting Generator Brushes, Replacing Brushes and Cleaning Slip Rings.

##### INSPECTING BRUSH POSITION

Inspect brush alignment with slip rings. View alignment through the air vents in the stator barrel. The brushes must ride completely on the slip rings.

##### INSPECTING BRUSHES

Remove the end panel. Inspect the wires. Remove the brush holder assembly. Pull the brushes from the holders.

Replace the brushes if damaged, or if the brush is at or near minimum length.

##### CLEANING SLIP RINGS

Visually inspect the slip rings. Under normal use, the rings turn dark brown.

If the slip rings are corroded or their surface is uneven, remove the belt to turn the shaft by hand for cleaning.

Clean the rings with 220 grit emery paper. Remove as little material as possible. If the rings are deeply pitted and do not clean up, consult generator factory service.

Reinstall the belt, brush holder assembly and end panel.




Figure 3-57. Inspecting Generator Brushes, Replacing Brushes and Cleaning Slip Rings

### Generator Disassembly and Assembly

Refer to Figure 3-59. and Figure 3-60. to determine if trouble is in stator, rotor, control box, or combination of these components.

1. Rotor
2. Stator Assembly

**⚠ CAUTION**

**DO NOT DAMAGE ROTOR OR STATOR WINDINGS DURING DISASSEMBLY AND ASSEMBLY PROCEDURE.**

#### DISASSEMBLY

1. Mark and disconnect all electrical leads, secure using cable ties.

2. Remove brush holder assembly.
3. Disassemble generator parts shown in Figure 3-58.
4. Clean all parts with approved solvent and dry with compressed air, if applicable.
5. Inspect all part for damage. Replace if necessary.

#### ASSEMBLY

1. Assemble generator parts using torque values in table.
2. Reconnect all leads. Use cable ties to secure leads away from moving or hot parts.




Figure 3-58. Generator Disassembly and Assembly




Figure 3-59. Generator Troubleshooting Circuit Diagram - Sheet 1 of 2






Figure 3-60. Generator Troubleshooting Circuit Diagram - Sheet 2 of 2




Figure 3-61. Generator Electrical Circuit Diagram




Figure 3-62. Power Board PC1 Electrical Circuit Diagram





**Lead Connection List for Generator**


**NOTE:** Apply small amount of dielectric grade, nonconductive electric grease to connectors where factory-applied grease had been present.

**NOTE:** Table shows physical lead connections and should be used with circuit diagram (table replaces wiring diagram).

**Table 3-3. Lead Connection List for Generator**


Leads	Connections
1A	STATOR TO CB1
2A	STATOR TO CB1
3A	STATOR TO CB1
4A	STATOR TO TE1 (C)
5A	STATOR TO RC4 (3)
5B	PLG2 (C) TO PLG4 (3)
5C	RC2 (C) PLG31 (8)
6A	STATOR TO RC4 (4)
6B	PLG2 (D) TO PLG4 (4)
6C	RC2 (D) PLG31 (9)
9A	RC5 (B) TO PLG3 (B) (Customer Supplied)
9B	RC3 (B) PLG1 (8)
12A	PLG2 (E) TO PLG4 (5)
12B	RC2 (E) PLG1 (9)
12C	RC4 (5) TO BRUSH
13A	PLG2 (F) TO PLG4 (6)
13B	RC2 (F) PLG31 (4)
13C	RC4 (6) TO BRUSH
15A	PLG1 (6) TO PLG31 (6)
16A	PLG1 (3) TO PLG31 (1)
17A	PLG1 (4) TO PLG31 (2)
21A	CB1 TO TE1 (F)
21B	PLG2 (A) TO PLG4 (1)
21C	PLG1 (1) TO RC2 (A)
21D	RC4 (1) TO CB1
22A	CB1 TO TE1 (E)
22B	PLG2 (B) TO PLG4 (2)
22C	PLG1 (2) TO RC2 (B)
22D	RC4 (2) TO CB1
23A	CB1 TO TE1 (D)
42A	RC5 (C) TO PLG3 (C) (Customer Supplied)
42B	RC3 (C) TO CONNECTION POINT 1
42C	PLG31 (7) TO CONNECTION POINT 1
42D	PLG1 (5) TO CONNECTION POINT 1
42F	END BELL SHROUD TO ENGINE MOUNT
42G	CHASSIS TO TE1 (B)
43A	RC5 (A) TO PLG3 (A) (Customer Supplied)
43B	RC3 (A) TO CONNECTION POINT 2
43C	PLG31 (3) TO CONNECTION POINT 2
43D	PLG1 (7) TO CONNECTION POINT 2

3.10 DEUTZ ENGINE (D2011L03) - T4I



- |               |                |                  |
|---------------|----------------|------------------|
| 1. Air Filter | 4. Muffler     | 7. Pump Coupling |
| 2. Radiator   | 5. Gear Pump   | 8. Tray          |
| 3. Alternator | 6. Piston Pump | 9. Fan           |

Figure 3-65. Deutz Engine (D2011L03) - T4i (Sheet 1 of 4)



- |                |                |             |
|----------------|----------------|-------------|
| 10. Fuel Tank  | 12. Muffler    | 14. Battery |
| 11. Air Filter | 13. Oil Filter |             |

Figure 3-66. Deutz Engine (D2011L03) - T4i (Sheet 2 of 4)






Figure 3-67. Deutz Engine (D2011L03) - T4i (Sheet 3 of 4)




Figure 3-68. Deutz Engine (D2011L03) - T4i (Sheet 4 of 4)

### Checking Oil Level

1. Make sure machine and engine are level and switch engine OFF before checking oil level.
2. Remove oil dipstick and wipe with clean cloth.
3. Insert dipstick to the stop and remove again.
4. Check oil level. Top oil level as shown in figure below with an approved grade and type of oil outlined in engine manufacturer's operator's manual.




Figure 3-69. Deutz D2011L03 T4Fi Dipstick Markings

5. Replace dipstick until fully seated.

### Changing Engine Oil

1. Allow engine to warm up. Engine oil should reach approximately 176° F (80° C).
2. Make sure machine and engine are level and switch off engine.
3. Place oil tray under engine.

**CAUTION**

HOT ENGINE OIL CAN CAUSE BURNS. AVOID CONTACT WITH HOT OIL WHEN DRAINING.

**NOTICE**

COLLECT USED OIL IN A CONTAINER SUITABLE FOR DISPOSAL OR RECYCLING. DISPOSE OF USED ENGINE OIL IN ACCORDANCE WITH ENVIRONMENTAL REGULATIONS.

4. Open oil drain valve and drain oil.
5. Close oil drain valve.
6. Pour in new engine oil. Refer to Section 1 for capacity and Figure 3-70., Engine Oil Viscosity.






Figure 3-70. Engine Oil Viscosity

### Changing Oil Filter


1. Wipe area around filter to clean any dirt from area.
2. Using a suitable oil filter removal tool, loosen lube oil filter cartridge and spin off.



3. Catch any escaping oil.
4. Clean any dirt from filter carrier sealing surface.
5. Lightly coat new oil filter rubber gasket with clean oil.



6. Screw in new filter by hand until gasket is flush.



7. Hand-tighten filter another half-turn.
8. Check oil level.
9. Check oil pressure.
10. Check oil filter cartridge for leaks.

### Replace Fuel Filter

#### **⚠ WARNING**

**FUEL IS FLAMMABLE AND CAN CAUSE DEATH OR SERIOUS INJURY. MAKE SURE NO OPEN FLAMES OR SPARKS ARE IN THE AREA WHEN WORKING ON FUEL SYSTEM. DO NOT SMOKE WHEN WORKING ON FUEL SYSTEM.**


1. Wipe area around filter to clean any dirt from area.
2. Remove fuel filter cartridge. Catch any escaping fuel.
3. Clean dirt from filter carrier sealing surface.
4. Apply light film of oil or diesel fuel to rubber gasket of new filter cartridge.
5. Screw in new filter by hand until gasket is flush. hand tighten filter another half-turn.
6. Open fuel shut-off valve.
7. Check for leaks.

## **Clean Fuel Strainer**

**⚠ WARNING**

**FUEL IS FLAMMABLE AND CAN CAUSE DEATH OR SERIOUS INJURY. MAKE SURE NO OPEN FLAMES OR SPARKS ARE IN THE AREA WHEN WORKING ON FUEL SYSTEM. DO NOT SMOKE WHEN WORKING ON THE FUEL SYSTEM.**


1. Unscrew the hexagonal nut (1).



2. Remove the fuel strainer cover (2).
3. Clean fuel strainer with diesel fuel and replace as needed.
4. Place the seal (3) in position.
5. Install fuel strainer cover (2). Tighten screw (1).
6. Check for leaks.


Go to Discount-Equipment.com to order your parts

## 3.11 DEUTZ ENGINE (D2.9L4) - T4F



- |                          |                        |                   |                   |
|--------------------------|------------------------|-------------------|-------------------|
| 1. Air Filter            | 4. Alternator          | 7. Gear Pump      | 10. Pump Coupling |
| 2. Radiator Coolant Tank | 5. Oil Filter          | 8. Exhaust System | 11. Fan           |
| 3. Radiator              | 6. Fuel Primary Filter | 9. Piston Pump    | 12. Tray          |

Figure 3-71. Deutz Engine (D2.9L4) - T4F (Sheet 1 of 4)



- |                     |                            |                  |
|---------------------|----------------------------|------------------|
| 13. Fuel Tank       | 15. Air Filter             | 17. Exhaust Pipe |
| 14. Fuel Pre-Filter | 16. Coolant Expansion Tank | 18. Battery      |

Figure 3-72. Deutz Engine (D2.9L4) - T4F (Sheet 2 of 4)




Figure 3-73. Deutz Engine (D2.9L4) - T4F (Sheet 3 of 4)

1001227569-B  
MAF06020







Figure 3-74. Deutz Engine (D2.9L4) - T4F (Sheet 4 of 4)

## Check Oil Level

1. Make sure machine and engine are level and switch engine OFF before checking oil level.
2. Remove oil dipstick and wipe with clean cloth.
3. Insert dipstick to the stop and remove again.
4. Check oil level. Top oil level as shown in figure below with an approved grade and type of oil outlined in engine manufacturer's operator's manual.



**Figure 3-75. Deutz 2.9 T4F Dipstick Markings**

5. Replace dipstick until fully seated.

## Change Engine Oil

1. Allow engine to warm up. Engine oil should reach approximately 176° F (80° C).
2. Make sure machine and engine are level and switch off engine.
3. Place oil tray under engine.


### **CAUTION**

**HOT ENGINE OIL CAN CAUSE BURNS. AVOID CONTACT WITH HOT OIL WHEN DRAINING.**

### **NOTICE**

**COLLECT USED OIL IN A CONTAINER SUITABLE FOR DISPOSAL OR RECYCLING. DISPOSE OF USED ENGINE OIL IN ACCORDANCE WITH ENVIRONMENTAL REGULATIONS.**


4. Open oil drain valve and drain oil.
5. Close oil drain valve.
6. Pour in new engine oil. Refer to Section 1 for capacity and Figure 3-76., Engine Oil Viscosity.




**Figure 3-76. Engine Oil Viscosity**

### Change Oil Filter

1. Wipe area around filter to clean any dirt from area.
2. Using a suitable oil filter removal tool, loosen lube oil filter cartridge and spin off.



3. Catch any escaping oil.
4. Clean any dirt from filter carrier sealing surface.
5. Lightly coat new oil filter rubber gasket with clean oil
6. Screw in new filter by hand until gasket is flush.
7. Hand-tighten filter another half-turn.




8. Check oil level.
9. Check oil pressure.
10. Check oil filter cartridge for leaks.

### Change Fuel Filters


**⚠ WARNING**

**FUEL IS FLAMMABLE AND CAN CAUSE DEATH OR SERIOUS INJURY. MAKE SURE NO OPEN FLAMES OR SPARKS ARE IN THE AREA WHEN WORKING ON FUEL SYSTEM. DO NOT SMOKE WHEN WORKING ON THE FUEL SYSTEMS.**

1. Wipe area around filter to clean any dirt from area.
2. Disconnect water sensor connector (Pre-filter Only).
3. Remove fuel filter cartridge. Catch any escaping fuel.



4. Clean dirt from filter carrier sealing surface.
5. Apply light film of oil or diesel fuel to rubber gasket of new filter cartridge.
6. Screw in new filter by hand until gasket is flush. Hand-tighten filter another half-turn.



7. Connect water sensor connector (Pre-filter Only).
8. Open fuel shut-off valve.
9. Check for leaks.

## 3.12 ENGINE FAULT CODES

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
16	0	No detail information
16	0	BusOff error CAN; No detail information
29	3	Hand throttle idle validation switch; short circuit to battery
29	4	Hand throttle; short circuit to ground
29	2	Plausibility error between sensor and idle switch, Acceleration Pedal Detection. In case of Hand Throttle with Low Idle Switch, it is the plausibility check between hand throttle and idle switch.
51	5	Intake Throttle Flap, H-Bridge, wiring harness broken at connected actuator
51	6	Intake Throttle Flap, H-Bridge, current above maximum threshold
51	3	Intake Throttle Flap, H-Bridge, short circuit to battery (A02)
51	3	Intake Throttle Flap, H-Bridge, short circuit to battery (A67)
51	4	Intake Throttle Flap, H-Bridge, short circuit to ground (A02)
51	4	Intake Throttle Flap, H-Bridge, short circuit to ground (A67)
51	7	Intake Throttle Flap, H-Bridge, position of actuator not plausible (deviation from set point more than 7%)
51	3	Intake Throttle Flap, H-Bridge, short circuit to battery oder broken wiring harness
51	4	Intake Throttle Flap, H-Bridge, short circuit to ground
91	3	Sensor error accelerator pedal. signal range check high.
91	4	Sensor error accelerator pedal. Signal is below the range.
91	11	Plausibility error between APP1 and APP2 or APP1 and idle switch.
94	3	Sensor error low fuel pressure; signal range check high
94	4	Sensor error low fuel pressure; signal range check low
94	1	Low fuel pressure; warning threshold exceeded
94	1	Low fuel pressure; shut off threshold exceeded
97	3	Sensor error water in fuel; signal range check high
97	4	Sensor error water in fuel; signal range check low.
97	12	Water in fuel level prefilter; maximum value exceeded
98	2	Plausibility Check; No detail information
100	3	Sensor error oil pressure; signal range check high

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
100	4	Sensor error oil pressure sensor; signal range check low
100	0	High oil pressure; warning threshold exceeded.
100	0	High oil pressure; shut off threshold exceeded
100	1	Low oil pressure; warning threshold exceeded
100	1	Low oil pressure; shut off threshold exceeded
102	2	Charged air pressure above warning threshold.
102	2	Charged air pressure above shut off threshold.
102	2	Pressure downstream charge air cooler, plausibility error
102	1	Pressure downstream charge air cooler, pressure below lower physical threshold
102	3	Pressure downstream charge air cooler, short circuit to battery or open load
102	4	Pressure downstream charge air cooler, short circuit to ground
105	1	Charged Air cooler down stream temperature. Temperature below lower physical threshold.
105	3	Electrical error charged air temperature. Signal range check high.(SRC)
105	4	Electrical error charged air temperature. Signal range check low.
105	0	Charged air cooler temperature. System reaction initiated. High charged air cooler temperature. Warning threshold exceeded.
105	0	High charged air cooler temperature. Shut off threshold exceeded.
105	11	Diagnostic fault check for charged air cooler downstream temperature sensor; No detail information
107	3	Sensor error air filter differential pressure; short circuit to battery
107	0	Sensor error air filter differential pressure; short circuit to ground
107	0	Air filter differential pressure; air filter clogged.
108	11	DFC for CAN message
108	3	Sensor error ambient air pressure; signal range check high
108	4	Sensor error ambient air pressure; signal range check low
110	2	Defect fault check for Absolute plausibility test No detail information
110	0	Physical Range Check high for Coolant temperature
110	1	Physical Range Check low for Coolant temperature.
110	3	Sensor error coolant temperature; signal range check high

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
110	4	Sensor error coolant temperature; signal range check low
110	0	High coolant temperature; warning threshold exceeded
110	0	Coolant temperature; system reaction initiated
111	1	Coolant level too low
132	1	The air mass flow AFS_dm is greater than or equal to AFS_PhysRng.Min_C Physical Range Check low for air mass flow sensor No detail information
157	0	Rail pressure raw value is intermittent No detail information
157	1	Rail pressure raw value is above maximum offset No detail information
157	3	Sensor error rail pressure. Sensor voltage above upper limit.
157	4	Sensor error rail pressure. Sensor voltage below lower limit.
164	2	Rail pressure safety function is not executed correctly ()
168	3	Sensor error battery voltage; signal range check high.
168	4	Sensor error battery voltage; signal range check low
168	2	High battery voltage; warning threshold exceeded
168	2	High battery voltage; shot off threshold exceeded
168	0	Physical range check high for battery voltage
168	1	Physical range check low for battery voltage
171	0	Environment temperature sensor, temperature above upper physical threshold
171	1	Environment Temperature Physical Range Check low
171	3	Sensor error SCR-System environment temperature; DPF-System air inlet temperature; signal range check high
171	4	Sensor error SCR-System environment temperature; DPF-System air inlet temperature; signal range check low
172	2	Air inlet filter temperature, plausibility error
172	3	Air flow temperature sensor; short circuit to battery or open load.
172	4	Air flow temperature sensor; short circuit to ground
172	1	Air inlet filter sensor out of physical range check
172	0	air temperature within air filter box above maximum physical value
174	11	DFC for fuel temperature plausibility check function No detail information

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
175	3	Sensor error oil temperature; signal range check high
175	4	Sensor error oil temperature; signal range check low
175	0	High oil temperature; warning threshold exceeded
175	0	High oil temperature; shut off threshold exceeded
175	2	Customer oil temperature: signal unplausible
190	0	Engine speed above warning threshold; Over speed detection in component engine protection
190	0	Engine speed above warning threshold (FOC-Level 1)
190	11	Engine speed above warning threshold (FOC-Level 2)
190	14	Engine speed above warning threshold (Overrun Mode)
190	8	Sensor camshaft speed; disturbed signal
190	12	Sensor camshaft detection; out of range, signal disrupted; no signal
190	2	Offset angle between crank- and camshaft sensor is too large.
190	8	Sensor crankshaft detection; out of range, signal disrupted; disturbed signal
190	12	Speed detection; out of range, signal disrupted Sensor crankshaft speed; no signal
190	14	Camshaft- and Crankshaft speed sensor signal not available on CAN
411	4	Physical range check low for EGR differential pressure
411	0	Delta pressure across venturi in EGR line above physical high limit
411	0	Plausibility Check fault for deviation of desired and actual EGR-mass flow, where the latter is calculated out of EGR Delta Pressure Sensor
411	3	Sensor error differential pressure Venturiunit (EGR), signal range check low.
411	4	Sensor error differential pressure Venturiunit (EGR), signal range check high.
412	3	Electrical error EGR cooler downstream temperature. Signal range check high.
412	4	electrical error EGR cooler downstream temperature. Signal range check low.
520	9	Timeout Error of CAN-Receive-Frame TSC1TR; control signal
598	2	Plausibility check for Clutch No detail information
624	5	SVS lamp; open load
624	12	SVS lamp: power stage over temperature
624	3	SVS lamp; short circuit to battery

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
624	4	SVS lamp; short circuit to ground
630	12	Access error EEPROM memory (delete)
630	12	Access error EEPROM memory (read)
630	12	Access error EEPROM memory (write)
639	14	CAN-Bus 0 "BusOff-Status"
651	5	Injector 1 (in firing order); interruption of electric connection
651	3	Injector 1 (in firing order); short circuit
652	5	Injector 2 (in firing order); interruption of electric connection
652	3	Injector 2 (in firing order); short circuit
653	5	Injector 3 (in firing order); interruption of electric connection
653	3	Injector 3 (in firing order); short circuit
654	5	Injector 4 (in firing order); interruption of electric connection
654	3	Injector 4 (in firing order); short circuit
655	5	Injector 5 (in firing order); interruption of electric connection
655	3	Injector 5 (in firing order); short circuit
655	4	High side to low side short circuit in the injector 5 (in firing order)
656	5	Injector 6 (in firing order); interruption of electric connection
656	3	Injector 6 (in firing order); short circuit
656	4	High side to low side short circuit in the injector 6 (in firing order)
676	11	Cold start device relay error
676	11	Cold start aid relay open load
677	3	Starter relay high side. Short circuit to battery.
677	4	Starter relay high side short circuit to ground.
677	5	Starter relay low side no load error.
677	12	Starter relay power stage over temperature.
677	3	Starter relay low side short circuit to battery.
677	4	Starter relay low side short circuit to ground.
729	5	Cold start aid relay open load



## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
729	12	Cold start aid relay; over temperature error
729	3	Intake Air Heater Device; Short circuit to battery
729	4	Air intake heater; Short circuit to ground error for power stage on CJ945.
898	9	Timeout Error of CAN-Receive-Frame TSC1TE; Set point
975	5	PWM-Signal Fan, Open load or short-circuit ground
975	3	PWM-Signal Fan, short-circuit to plus
975	4	PWM-Signal Fan, open load or short circuit to ground
1079	13	Failure of sensor supply voltage 1
1080	13	Failure of sensor supply voltage 2
1109	2	Engine shut off demand ignored
1136	0	Physical range check high for ECU temperature
1176	0	Pressure sensor upstream turbine, Physical Range Check high
1176	1	Pressure sensor upstream turbine, Physical Range Check low
1176	3	Pressure sensor upstream turbine, signal range check (SRC) high
1176	4	Pressure sensor upstream turbine, signal range check (SRC) low
1180	3	Sensor error exhaust gas temperature upstream turbine; signal range check high
1180	4	Sensor error exhaust gas temperature upstream turbine; signal range check low
1180	0	Physical range check high for exhaust gas temperature upstream turbine
1180	1	Physical range check low for exhaust gas temperature upstream turbine
1188	11	Wastegate actuator; internal error
1188	11	Wastegate actuator; EOL calibration not performed correctly
1188	13	Wastegate actuator calibration deviation too large, re-calibration required
1188	2	Wastegate; status message from ECU missing
1188	7	Wastegate actuator; blocked
1188	11	Wastegate actuator; over temperature (> 135°C)
1188	11	Wastegate actuator; operating voltage error
1188	7	Turbocharger wastegate, mechanical blocking detected
1188	2	Turbocharger wastegate, CAN Error

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
1188	13	Turbocharger wastegate, EOL calibration error
1188	12	Turbocharger wastegate, internal electrical error
1188	13	Turbocharger wastegate, learning process aborted
1188	6	Turbocharger wastegate, current above maximum threshold
1188	3	Turbocharger wastegate, supply voltage above maximum threshold
1188	4	Turbocharger wastegate, supply voltage below minimum threshold
1188	13	Turbocharger wastegate, learning process out of range
1188	7	Turbocharger wastegate, broken spring detected
1188	0	Turbocharger wastegate, temperature critical high
1231	14	CAN-Bus 1 "BusOff-Status"
1235	14	CAN-Bus 2 = CAN_C reports Bus-error (for engines <8L and CV52 it is the engine-CAN@250kbaud) CAN Bus error passive; warning CAN C - engine CAN
1235	14	CAN-Bus 2 = engine bus "BusOff-Status"
1237	2	Override switch; plausibility error
1322	12	
1323	12	Too many recognized misfires in cylinder 1 (in firing order)
1323	12	
1323	12	
1323	12	
1323	12	
1323	12	
1323	12	
1346	0	Misfire detection monitoring No detail information
1638	2	Hydraulic oil temperature check for Shut off condition
1639	12	Fan speed sensor; electrical error or signal disturbed or very low fan speed
1639	0	Sensor error fan speed; signal range check high or engine speed resp. fan speed too high
1639	1	Sensor error fan speed; signal range check low or fan speed too low
1761	14	DEF tank level; warning threshold exceeded
1761	0	DEF tank, DEF level above upper physical threshold
1761	1	DEF tank, DEF level below lower physical threshold

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
1761	14	Urea Tank Signal to HMI for indicating the Urea Tank-Level (Urea tank volume ratio low threshold 1)
1761	14	DEF tank, DEF level below first warning threshold
1761	14	DEF tank, DEF level below second warning threshold
1761	2	DEF tank level, plausibility error
1761	14	DEF tank, DEF level below third warning threshold
2634	12	Early opening defect of main relay No detail information
2634	12	DFC for stuck main relay error No detail information
2659	2	Exhaust Gas Recirculation AGS Sensor; signal not plausible
2659	0	Exhaust Gas Recirculation AGS Sensor; Sensed exhaust mass value above maximum physical value
2659	1	Exhaust Gas Recirculation AGS Sensor; Sensed exhaust mass value below minimum physical value
2659	12	Exhaust Gas Recirculation AGS Sensor; plausibility error, AGS sensor has not passed the burn off process
2659	2	Exhaust Gas Recirculation AGS Sensor; Temperature of EGR mass not plausible
2791	12	Actuator EGR Valve; power stage over temperature
2791	7	EGR actuator, actuator blocked
2791	2	EGR actuator, CAN error
2791	13	EGR actuator, EOL calibration error
2791	12	EGR Actuator, internal electrical fault
2791	13	EGR actuator, learning process aborted
2791	6	EGR actuator current is above maximum threshold
2791	3	EGR actuator supply voltage is above the maximum threshold
2791	4	EGR actuator supply voltage is below minimum threshold
2791	13	EGR actuator, learning process out of range
2791	7	EGR actuator, broken spring detected
2791	16	EGR actuator, temperature high
2791	0	EGR actuator, temperature critical high
2797	4	Timeout of Short-Circuit Ground Diagnosis Cyl. Bank 0;_IVDiaShCirGndToutBnk_0
2797	4	Injector diagnostic; Short circuit to ground cylinder bank 0
2798	4	Timeout of Short-Circuit Ground Diagnosis Cyl. Bank 1;_IVDiaShCirGndToutBnk_1

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
2798	4	Injector diagnostic; Short circuit to ground cylinder bank 1
3031	0	DEF tank, DEF temperature in DEF tank is to high
3031	1	DEF tank, DEF temperature below lower physical threshold
3031	2	Urea tank temperature outside of plausible thresholds
3219	2	DFC SAE J1939 error No detail information
3224	2	DLC Error of CAN-Receive-Frame AT11G1 NOX Sensor (SCR-system upstream cat; DPF-system downstream cat); length of frame incorrect
3224	9	Timeout Error of CAN-Receive-Frame AT11G1; NOX sensor upstream
3224	2	DLC Error of CAN-Receive-Frame AT11G1Vol NOX sensor
3224	9	Timeout Error of CAN-Receive-Frame AT11G1Vol; NOX sensor
3224	1	DFC for plausibility error Max for NOx sensor upstream of SCR Cat
3226	2	Nox feed back fault detection No detail information
3227	2	DFC SAE J1939 error No detail information
3234	2	DLC Error of CAN-Receive-Frame AT101 No detail information
3234	9	Timeout Error of CAN-Receive-Frame AT10G1; NOX sensor (SCR-system downstream cat; DPF-system downstream cat)
3234	2	DLC Error of CAN-Receive-Frame AT101Vol NOX
3234	9	Timeout Error of CAN-Receive-Frame AT10G1Vol
3234	11	DFC for plausibility error Min for NOx sensor downstream of SCR Cat
3241	0	Sensor SCR catalyst upstream temperature too high; plausibility error
3248	4	Sensor error particle filter downstream temperature; signal range check low
3251	0	Differential pressure DPF maximum value is exceeded
3251	0	Differential pressure sensor across DPF exceeds warning high limit
3251	1	Differential pressure DPF, pressure below lower shutoff threshold
3251	1	Differential pressure DPF, pressure below lower warning threshold
3253	2	Differential pressure DPF, plausibility error
3253	3	Electrical error differential pressure B58 (DPF). (signal range check high)
3253	4	Electrical error differential pressure (DPF). signal range check low.
3253	2	Sensor differential pressure (DPF); plausibility error

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
3361	7	DEF dosing valve blocked (SCR)
3361	6	DEF dosing valve; power at the end of injection too high
3361	3	DEF dosing valve; short circuit to battery on low side
3361	3	DEF dosing valve; short circuit to battery or open load on high side
3361	4	Urea dosing valve; short circuit to ground or open load on low side
3361	4	DEF dosing valve; short circuit on high side
3519	12	DEF tank temperature, temperature too high
3519	3	DEF quality sensor, internal temperature sensor short circuit to battery or open load
3519	4	DEF quality sensor, internal temperature sensor short circuit to ground
3519	13	Temperature at UQS invalid
3520	3	DEF quality sensor, short circuit to battery or open load
3520	4	DEF quality sensor, short circuit to ground
3520	2	DEF quality sensor, bad DEF quality detected or no DEF measuring possible
3520	13	Urea quality at UQS invalid
3532	3	Sensor error DEF tank level; signal range check high
3532	4	Sensor error DEF tank level; signal range check low
3532	3	The DEF Level at UQS out of max. physical range
3532	4	Quality at UQS out of min. physical range
3699	2	Passive regeneration of DPF; plausibility error DPF differential pressure sensor and a further sensor or actuator CRT system defective
3699	2	Passive regeneration of DPF; DOC error Temperature sensor us. and ds. DOC simultaneously defect
3699	0	Maximum standstill time reached; oil exchange request ignored
3711	12	Temperature during stand-still main phase too low or too high
3936	14	Standstill request ignored too long
3936	14	Standstill time based escalation requests Inducement step 2
4171	2	Dynamic temperature check of temp before SCR
4243	11	SCR heater; Pressure line heater error and temperature condition to perform an afterrun (Group error diagnosis heater) SCR system heater diagnostic reports error; shut off SCR-system

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
4334	0	Supply module DEF, DEF pressure above upper physical threshold
4334	1	Urea supply module pressure sensor; physical range check low (defect pressure sensor)
4334	0	Urea pump pressure sensor; high signal not plausible
4334	1	Urea pump pressure sensor; low signal not plausible
4334	2	DEF supply module pressure, plausibility error
4341	5	SCR heater relay DEF supply line secondary side; open load
4341	5	SCR heater relay DEF supply line primary side; open load
4341	3	SCR-heater DEF supply line; short circuit to battery
4341	4	SCR-heater DEF supply line; short circuit to ground
4343	11	SCR Monitoring; Pressure stabilization error, general pressure check error (SCR)
4343	5	SCR heater relay DEF pressure line secondary side; open load
4343	5	SCR heater relay DEF pressure line primary side; open load
4343	12	Over Temperature error No detail information
4343	3	SCR heater DEF pressure line; short circuit to battery
4343	4	SCR heater DEF pressure line; short circuit to ground
4345	11	Sensor back flow line pressure (SCR); plausibility error
4345	5	SCR heater relay DEF return line secondary side; open load
4345	5	SCR heater relay DEF return line primary side; open load
4345	12	Over Temperature error No detail information
4345	3	SCR heater DEF return line; short circuit to battery
4345	4	SCR heater DEF return line; short circuit to ground
4360	0	Exhaust temperature upstream SCR-Cat, temperature above upper physical threshold
4360	1	Sensed exhaust temperature before SCR-Cat is < physical low limit
4360	2	Exhaust temperature sensor upstream SCR, plausibility error
4361	2	Signal error for CAN message No detail information
4361	3	Sensor error DEF catalyst exhaust gas temperature upstream; signal range check high
4361	4	Sensor error DEF catalyst exhaust gas temperature upstream; signal range check low
4365	0	DEF tank temperature too high

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
4365	2	Tank temperature signal error for CAN message
4365	3	Sensor error urea tank temperature: short circuit to battery
4365	4	Sensor error urea tank temperature; short circuit to ground
4365	3	DEF quality sensor, tank temperature; Short circuit to battery or open load
4365	4	DEF quality sensor, tank temperature; Short circuit to ground
4366	5	SCR main relay (secondary side): open load
4366	5	SCR main relay (secondary side); Shortcut to battery
4366	5	SCR main relay (secondary side), heat relay (secondary side), heating elements or heating valve short to ground
4366	5	SCR Tank heating valve secondary side: open load
4366	5	SCR tank heating valve primary side; open load
4366	12	SCR-heater relay urea tank power stage output; over temperature
4366	3	SCR Tank heating valve; short circuit to battery
4366	4	SCR Tank heating valve; short circuit to ground
4374	13	Pressure stabilization error dosing valve (SCR)
4375	5	Urea pump motor; open load
4375	3	Urea pump motor; short circuit to battery
4375	4	Urea pump motor; short circuit to ground
4376	5	SCR reversal valve; open load
4376	12	SCR reversing valve; over temperature
4376	3	SCR reversal valve; short circuit to battery
4376	4	SCR reversing valve; short circuit to ground
4376	5	SCR reverting valve; open load
4376	12	SCR reverting valve; over temperature
4376	4	eSCR reverting valve; short circuit to ground
4765	0	Temperature upstream DOC, temperature above upper shutoff threshold
4765	0	Temperature upstream DOC, temperature above upper warning threshold
4766	0	Temperature downstream DOC, temperature above upper shutoff threshold
4766	0	Temperature downstream DOC, temperature above upper warning threshold

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
4768	2	Temperature upstream DOC, plausibility error
4768	3	Electrical error exhaust gas temperature upstream (DOC); signal range check high
4768	4	Electrical error exhaust gas temperature upstream (DOC); signal range check low
4768	2	Exhaust gas temperature sensors up and downstream DOC are physically swapped
4769	2	Temperature downstream DOC, plausibility error
4769	3	Sensor error exhaust gas temperature downstream (DOC); signal range check high
4769	4	Sensor error exhaust gas temperature downstream (DOC); signal range check low
4769	2	Sensor exhaust gas temperature OxiCat downstream (normal operation); plausibility error
4769	2	Sensor exhaust gas temperature OxiCat downstream (regeneration); plausibility error
5763	6	Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8). Signal range check high.
5763	7	Actuator position for EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8) not plausible.
5763	6	Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); signal range check high
5763	5	Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); signal range check low
5763	3	Position sensor error of actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8). Signal range check high.
5763	4	Position sensor error actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8). Signal range check low.
5763	5	Actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); open load
5763	6	Actuator EGR-Valve (2.9;3.6) or Throttle-Valve (6.1,7.8); over current
5763	3	EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to battery
5763	3	EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to battery
5763	4	EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to ground
5763	4	EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to ground
5763	6	Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); Overload by short-circuit
5763	11	Power stage over temperature due to high current
5763	4	Actuator AGR valve (2.9;3.6) throttle valve (4.1;6.1;7.8); Voltage below threshold
5763	0	Warning threshold for an internal actuator error exceeded, < 4L EGR.actuator und >4L Air Intake Flap



## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
5763	1	Shut off threshold for an internal actuator error exceeded, < 4L EGR.actuator und >4L Air Intake Flap
520521	5	Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); signal range check low
523008	1	Manipulation control was triggered
523008	2	Timeout error in Manipulation control
523009	9	The pressure relief valve (PRV) has reached the number of allowed activations
523009	10	Open time of Pressure Relief Valve (PRV) for wear out monitoring had exceeded
523090	2	Engine Brake Pre-Selection switch; Plausibility Error
523211	9	Timeout Error of CAN-Receive-Frame EBC1
523212	9	Timeout Error of CAN-Receive-Frame ComEngPrt; Engine Protection
523213	12	Timeout Error of CAN-Transmit-Frame ERC1 No detail information
523216	9	Timeout Error of CAN-Receive-Frame PrHtEnCmd; pre-heat command, engine command
523240	9	Timeout CAN-message FunModCtl; Function Mode Control
523330	14	Immobilizer status; fuel blocked
523330	14	DFC to block the fuel by Sia No detail information
523330	14	DFC to indicate that TEN-code or UC-code received if ECU is learned No detail information
523330	14	DFC to indicate that no code is received via CAN. No detail information
523330	14	DFC to indicate that wrong code is received. No detail information
523350	4	Injector cylinder-bank 1; short circuit
523352	4	Injector cylinder-bank 2; short circuit
523354	12	Injector power stage output defect
523470	2	Pressure relief valve is forced to open, perform pressure increase
523470	2	Pressure Relief Valve (PRV) forced to open. Performed by pressure increase.
523470	12	Pressure Relief Valve (PRV) forced to open. Shutoff conditions
523470	12	Pressure Relief Valve (PRV) forced to open. Warning conditions
523470	14	Open Pressure Relief Valve (PRV)
523470	11	Pressure Relief Valve (PRV) error; Rail pressure out of tolerance range
523470	11	Rail pressure out of tolerance range. The PRV can not be opened at this operating point with a pressure shock.

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
523470	7	Maximum rail pressure exceeded (PRV)
523550	12	Terminal 50 was operated too long
523580	2	Data set variant with the desired number not found Invalid variant data set Identifier error No detail information
523580	11	An error has occurred in the switch over to the desired data set variant in the code word Variant data set switching error No detail information
523580	11	The code word could not be read correctly from the EEPROM Variant dataset switching error; No detail information
523601	13	Failure of sensor supply voltage 3
523602	0	High fan speed; warning threshold exceeded
523602	0	High fan speed; shut off threshold exceeded
523603	9	Timeout Error of CAN-Receive-Frame AMB; Ambient Temperature Sensor
523605	9	Timeout Error of CAN-Receive-Frame TSC1AE; Traction Control
523606	9	Timeout Error of CAN-Receive-Frame TSC1AR; Retarder
523612	12	Internal software error ECU; injection cut off
523612	12	Internal ECU monitoring detection reported error
523612	12	ECU reported internal software error Internal ECU monitoring detection reported error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	Injection system, electrical error injectors
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error
523612	12	ECU reported internal software error

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
523612	12	ECU reported internal software error
523612	12	Diagnostic fault check to report the accelerator pedal position error
523612	12	Diagnostic fault check to report the engine speed error
523612	12	Error in the plausibility of the injection energizing time
523612	12	Error in the plausibility of the start of energizing angles
523612	12	Diagnostic fault check to report the error due to non plausibility in ZFC
523612	12	Diagnosis fault check to report the demand for normal mode due to an error in the Pol2 quantity
523612	12	Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol2 shut-off
523612	12	Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol3 efficiency factor
523612	12	Internal ECU monitoring detection reported error
523612	12	Monitoring of Fuel Quantity Correction
523612	12	Diagnostic fault check to report the plausibility error in rail pressure monitoring
523612	12	Diagnostic fault check to report the error due to torque comparison
523612	12	Diagnosis of curr path limitation forced by ECU monitoring level 2
523612	12	Diagnosis of lead path limitation forced by ECU monitoring level 2
523612	12	Diagnosis of set path limitation forced by ECU monitoring level 2
523612	3	Reported Over Voltage of Supply
523612	4	Reported UnderVoltage of Supply
523612	12	Diagnostic fault check to report WDA active due to errors in query-/response communication
523612	12	Diagnostic fault check to report ABE active due to undervoltage detection
523612	12	Diagnostic fault check to report ABE active due to overvoltage detection
523612	12	Diagnostic fault check to report WDA/ABE active due to unknown reason
523612	14	Software reset CPU SWReset_0
523612	14	Software reset CPU SWReset_1
523612	14	Software reset CPU SWReset_2
523612	12	Internal software error ECU
523612	12	Engine starter, plausibility error of starter release condition
523613	0	Rail pressure metering unit, Positive governor deviation

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
523613	0	Rail pressure metering unit, Rail pressure disrupted. Maximum positive deviation of rail pressure exceeded
523613	0	Rail pressure metering unit, Rail pressure disrupted. Maximum positive deviation of rail pressure in metering unit exceeded (RailMeUn1).
523613	0	Rail pressure metering unit, Rail pressure below the target range (RailMeUn2) Rail system leakage detected. (RailMeUn10)
523613	1	Rail pressure metering unit, Minimum rail pressure exceeded (RailMeUn3) Negative deviation of rail pressure second stage (RailMeUn22)
523613	0	Rail pressure metering unit, Maximum rail pressure exceeded.
523613	2	Rail pressure metering unit, Set point of metering unit in overrun mode not plausible.
523613	0	Set point of metering unit in overrun mode not plausible
523615	5	Metering unit (Fuel-System); open load
523615	12	Metering unit (Fuel-System); power stage over temperature
523615	3	Metering unit (Fuel-System); short circuit to battery high side
523615	4	Metering unit (Fuel-System); short circuit to ground high side
523615	3	Metering unit (Fuel-System); short circuit to battery low side
523615	4	Metering Unit (Fuel-System); short circuit to ground low side
523615	3	Metering unit, short circuit to battery
523615	4	Metering unit, short circuit to ground
523618	3	Gearbox oil temperature; Short circuit to battery or broken harness
523618	4	Gearbox oil temperature; Short circuit to ground
523619	2	Physical range check high for exhaust gas temperature up stream (SCR-CAT)
523632	16	Pump pressure SCR metering unit too high
523632	18	Pump pressure SCR metering unit too low
523632	0	Pressure overload of SCR-System
523632	1	Pressure build-up error SCR-System
523632	11	Pump motor not available for actuation
523632	2	Signal error for CAN message No detail information
523632	3	Sensor error urea pump pressure; signal range check high
523632	4	Sensor error urea pump pressure; signal range check low

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
523633	11	Long term adoption factor below threshold
523633	11	Nox conversion rate insufficient (SCR-Cat defect, bad DEF quality)
523633	11	Nox conversion rate insufficient (SCR-Cat defect, bad DEF quality); temperature range 1
523698	11	Shut off request from supervisory monitoring function
523699	3	Boost pressure control; negative governor deviation below limit
523699	4	learning value too high No detail information
523704	12	Timeout Error of CAN-Transmit-Frame EEC3
523706	12	Timeout Error of CAN-Transmit-Frame FIEco No detail information
523717	12	Timeout Error of CAN-Transmit-Frame AmbCon; Weather environments
523718	5	tank heating valve; open load
523718	12	SCR main relay (primary side); power stage over temperature
523718	3	SCR main relay (primary side); short circuit to battery
523718	4	SCR main relay (primary side); short circuit to ground
523718	5	SCR main relay; open load (only CV56B)
523718	3	SCR main relay; short circuit to battery (only CV56B)
523718	4	SCR main relay; short circuit to ground (only CV56B)
523719	5	SCR heater relay DEF supply module secondary side; open load
523719	5	SCR heater relay DEF supply module primary side; open load
523719	12	Over Temperature error No detail information
523719	3	SCR heater DEF supply module; short circuit to battery
523719	4	SCR heater DEF supply module; short circuit to ground
523720	2	DEF supply module heater temperature; plausibility error (normal condition)
523720	2	Sensor DEF supply module heater temperature; plausibility error (cold start condition)
523720	8	DEF supply module heater temperature; duty cycle in failure range
523720	8	DEF supply module heater temperature; duty cycle in invalid range
523721	2	Sensor DEF supply module temperature; plausibility error (normal condition)
523721	2	Sensor DEF supply module temperature; plausibility error (cold start condition)
523721	11	Urea supply module temperature measurement not available

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
523721	8	DEF supply module temperature; duty cycle in failure range
523721	8	Urea supply module temperature; duty cycle in invalid range
523722	8	DEF supply module PWM signal; period outside valid range
523722	8	Detect faulty PWM signal from Supply Module
523741	14	Engine shut off request through CAN No detail information
523752	0	Plausibility error during Rich to Lean switch over No detail information
523752	0	Monitoring of Nox signal readiness No detail information
523756	14	special pattern for special cases No detail information
523757	14	special pattern for special cases No detail information
523758	14	special pattern for special cases No detail information
523759	14	special pattern for special cases No detail information
523760	14	special pattern for special cases No detail information
523766	9	Timeout Error of CAN-Receive-Frame Active TSC1AE
523767	9	Timeout Error of CAN-Receive-Frame Passive TSC1AE
523768	9	Timeout Error of CAN-Receive-Frame Active TSC1AR
523769	9	Timeout Error of CAN-Receive-Frame Passive TSC1AR
523776	9	Timeout Error of CAN-Receive-Frame TSC1TE - active
523777	9	Passive Timeout Error of CAN-Receive-Frame TSC1TE; Set point
523778	9	Timeout Error of CAN-Receive-Frame TSC1TR
523779	9	Passive Timeout Error of CAN-Receive-Frame TSC1TR
523788	12	Timeout Error of CAN-Transmit-Frame TrbCH; Status Waste gate
523788	0	Waste gate plausibility error off CAN transmit message
523788	0	Timeout Error of CAN-Receive-Frame ComTrbChActr; Wastegate
523793	9	Timeout Error of CAN-Receive-Frame UAA10; AGS sensor service message
523794	9	Timeout Error of CAN-Receive-Frame UAA11; AGS sensor data
523803	9	Timeout error of CAN Receive Message RxEngPres; Status Burner Air Pump
523858	12	Timeout Error of CAN-Transmit-Frame UAA11
523867	12	Ansteuerung Brenner Luftpumpe; Timeout Error of CAN-Transmit-Frame UAA1 on CAN A

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
523889	3	over teperature of device driver of pressure control valve No detail information
523891	14	When AirHt_ctDefSRCLoOn_mp is less than AirHt_ctMaxDef_C . DFC to SRC Low error when heater is On No detail information
523895	13	Check of missing injector adjustment value programming (IMA) injector 1 (in firing order).
523896	13	check of missing injector adjustment value programming (IMA) injector 2 (in firing order).
523897	13	check of missing injector adjustment value programming (IMA) injector 3 (in firing order).
523898	13	check of missing injector adjustment value programming (IMA) injector 4 (in firing order).
523899	13	check of missing injector adjustment value programming (IMA) injector 5 (in firing order).
523900	13	check of missing injector adjustment value programming (IMA) injector 6 (in firing order).
523906	5	Electrical fuel pre - supply pump; open load
523906	12	Electrical fuel pre - supply pump. ECU powerstage over temperature.
523906	3	Electrical fuel pre - supply pump; short circuit to battery
523906	4	Electrical fuel pre - supply pump. Short circuit to ground.
523910	14	Air pump doesn't achieve air mass flow setpoint Burner Control - burner air pump
523910	9	Burner Control; Air Pump - CAN Lost Air Pump; CAN communication lost
523910	7	Air pump; CAN communication interrupted no purge function available
523910	12	Air Pump; internal error
523910	0	Air Pump; operating voltage error
523910	6	Burner Control Air Pump; over current Air pump electrically overloaded
523911	0	Burner dosing valve (DV2); over current at the end of the injection phase
523911	12	Burner dosing valve (DV2); power stage over temperature
523911	3	Burner dosing valve (DV2); short circuit to battery
523911	4	Burner dosing valve (DV2); short circuit to ground
523911	11	Burner dosing valve (DV2); short circuit high side power stage
523912	2	Burner dosing valve (DV2) downstream pressure sensor; plausibility error
523912	0	Physical range check high for burner dosing valve (DV2) downstream pressure; shut off regeneration
523912	1	Physical range check low for burner dosing valve (DV2) downstream pressure; shut off regeneration. When burner injector is actuated, the measured pressure does not rise above ca. 1250mbar abs (expected: ca. 2400mbar).

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
523912	3	Sensor error burner dosing valve (DV2) downstream pressure sensor; signal range check high
523912	4	@ engines < 4l: Throttle valve error, Open Load or Short cut to Battery, blocked valve or wrong control signal for valve. @ engines with Burner T4i: Pressure Sensor error after valve (DV2), lower limit reached
523913	3	Sensor error glow plug control diagnostic line voltage; signal range check high
523913	4	Sensor error glow plug control diagnostic line voltage; signal range check low
523914	5	Glow plug control; open load water pump control (PWM)
523914	12	Glow plug control; power stage over temperature
523914	3	Glow plug control; short circuit to battery water pump control (PWM)
523914	4	Glow plug control; short circuit to ground water pump control (PWM)
523915	0	HCl dosing valve (DV1); over current at the end of the injection phase
523915	12	HCl dosing valve (DV1); power stage over temperature
523915	3	HCl dosing valve (DV1); short circuit to battery
523915	3	HCl dosing valve (DV1); short circuit to battery high side
523915	4	HCl dosing valve (DV1); short circuit to ground
523915	11	HCl dosing valve (DV1); short circuit high side power stage
523915	7	HCl dosing valve (DV1); blocked open
523916	2	Sensor HCl dosing valve (DV1) downstream pressure; plausibility error
523916	0	Physical range check high for HCl dosing valve (DV1) downstream pressure; shut off regeneration
523916	1	Physical range check low for HCl dosing valve (DV1) downstream pressure; shut off regeneration
523916	3	Sensor error HCl dosing valve (DV1) downstream pressure; signal range check high
523916	4	Sensor error HCl dosing valve (DV1) downstream pressure; signal range check low
523917	3	Sensor error DV1 & DV2 upstream pressure; signal range check high
523917	4	Sensor error DV1 & DV2 upstream pressure; signal range check low
523918	3	Sensor error DV1 & DV2 upstream temperature; signal range check high
523918	4	Sensor error DV1 & DV2 upstream temperature; signal range check low
523919	2	DPF burner air pump pressure sensor, plausibility error
523919	0	DPF burner air pump pressure sensor, pressure above upper shutoff threshold
523919	1	DPF burner air pump pressure sensor, pressure below lower shutoff threshold



## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
523919	3	DPF burner air pump pressure sensor, short circuit to battery or open load
523919	4	DPF burner air pump pressure sensor, short circuit to ground
523919	2	Sensor air pump air pressure; plausibility error
523920	2	Exhaust gas pressure upstream burner, plausibility error
523920	0	Exhaust gas pressure upstream burner, pressure above upper shutoff threshold
523920	3	Exhaust gas pressure upstream burner, short circuit to battery or open load
523920	4	Exhaust gas pressure upstream burner, short circuit to ground
523920	2	Sensor exhaust gas back pressure burner; plausibility error
523921	3	Sensor error burner temperature; signal range check high
523921	4	Sensor error burner temperature; signal range check low
523921	0	Burner temperature, temperature above upper shutoff threshold
523921	1	Burner temperature, temperature below lower shutoff threshold
523921	2	Burner temperature sensor; Plausibility Check for burner temperature sensor Sensor burner temperature; plausibility error
523922	3	Burner shut of valve; short circuit to battery
523922	7	Burner Control; Shut-off Valve - Blocked closed Burner Shut Off Valve; blocked closed
523922	7	Burner Shut Off Valve; blocked open
523922	5	Burner Shut Off Valve; open load
523922	12	Burner Shut Off Valve; power stage over temperature
523922	4	Burner Shut Off Valve; short circuit to ground
523923	3	UB1; Short circuit to battery error of actuator relay 1
523923	4	Short circuit to ground error No detail information
523924	3	UB2; Short circuit to battery error of actuator relay 2
523924	4	UB2; Short circuit to ground actuator relay 2
523925	3	UB3; Short circuit to battery error of actuator relay 3
523925	4	UB3; Short circuit to ground actuator relay 3
523926	4	UB4; Short circuit to ground actuator relay 4
523927	3	UB5; Short circuit to battery error of actuator relay 5
523935	12	Timeout Error of CAN-Transmit-Frame EEC3VOL1; Engine send messages

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
523936	12	Timeout Error of CAN-Transmit-Frame EEC3VOL2; Engine send messages
523937	9	Timeout DFC for NOxSensGlbReqTx. No detail information
523938	9	Timeout Error (BAM to packet) for CAN-Receive-Frame AT1IGCVol1.
523939	9	Broadcast Announce Message of the calibration message of the upstream catalytic NOx sensor has failed.
523940	9	Timeout Error (PCK2PCK) for CAN-Receive-Frame AT1IGCVol1
523941	9	Timeout Error (BAM to packet) for CAN-Receive-Frame AT10GCVol2
523942	9	Calibration message 1 of the after catalyst NOx sensor has failed
523943	9	Timeout Error (PCK2PCK) for CAN-Receive-Frame AT10GCVol2
523946	0	Zerofuel calibration injector 1 (in firing order); maximum value exceeded
523946	1	Zerofuel calibration injector 1 (in firing order); minimum value exceeded
523947	0	Zerofuel calibration injector 2 (in firing order); maximum value exceeded
523947	1	Zerofuel calibration injector 2 (in firing order); minimum value exceeded
523948	0	Zerofuel calibration injector 3 (in firing order); maximum value exceeded
523948	1	Zerofuel calibration injector 3 (in firing order); minimum value exceeded
523949	0	Zerofuel calibration injector 4 (in firing order); maximum value exceeded
523949	1	Zerofuel calibration injector 4 (in firing order); minimum value exceeded
523950	0	Zerofuel calibration injector 5 (in firing order); maximum value exceeded
523950	1	Zerofuel calibration injector 5 (in firing order); minimum value exceeded
523951	0	Zerofuel calibration injector 6 (in firing order); maximum value exceeded
523953	2	Healing takes place if the condition for error detection is not present. Air temprature monitoring plausibility check array No detail information
523955	2	Healing takes place if the condition for error detection is not present. Air temprature monitoring plausibility check array No detail information
523960	0	Physical range check high for EGR cooler downstream temperature.
523960	1	Physical range check low for EGR cooler downstream temperature.
523960	0	High exhaust gas temperature EGR cooler downstream; warning threshold exceeded.
523969	11	Fault entry for override control mode. No detail information
523973	14	SCR Tamper detection; derating timer below limit 1
523974	14	SCR Tamper detection; derating timer below limit 2

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
523975	14	Urea quality; derating timer below limit 1
523976	14	Urea quality; derating timer below limit 2
523977	14	Urea tank level; derating timer below limit 1
523978	14	Urea tank level; derating timer below limit 2
523981	11	SCR plausibility, OBD and diagnosis; Stuck in range check of DEF tank temperature sensor DEF-tank without heating function (heating phase)
523982	0	Power stage diagnosis disabled; high battery voltage
523982	1	Power stage diagnosis disabled; low battery voltage
523984	3	UB7; Short circuit to battery error of actuator relay 7
523986	4	UB6; Short circuit to ground actuator relais 6
523987	4	UB7; Short circuit to ground actuator relay 7
523992	9	
523993	9	
523995	13	Check of missing injector adjustment value programming (IMA) injector 7 (in firing order)
523996	13	check of missing injector adjustment value programming (IMA) injector 8 (in firing order)
523997	4	Injector cylinder bank 1 slave; short circuit
523998	4	Injector cylinder bank 2 slave; short circuit
523999	12	Injector power stage output Slave defect
524000	5	Injector 7 (in firing order); interruption of electric connection
524000	3	Injector 7 (in firing order); short circuit
524001	5	Injector 8 (in firing order); interruption of electric connection
524001	3	Injector 8 (in firing order); short circuit
524013	7	Burner Control; burner Flame; Burner does not start after x trials (burner flame lost detection) Burner flame unintentional deleted
524013	7	Burner Control; Flame lost max Burner operation is interrupted too often
524014	1	Air inlet EPV - pressure too low Air pressure glow plug flush line; below limit
524016	11	Burner Control; HFM - Electrical Fault HFM sensor; electrical fault

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
524016	2	Burner Control; HFM - Plausibility error1 Amount of air is not plausible to pump speed
524018	14	HMI engine derate service state DPF wasn't regenerated, power reduction phase 1 (manual regeneration request)
524019	11	Burner Control; Air Line - Blocked Air Pump; air lines blocked
524020	14	Burner Control: power reduction due to low lambda. Engine power; Not enough oxygen for regeneration.
524021	11	Burner Control; Fuel line ShutOff downstream - broken Burner fuel line pipe leak behind Shut Off Valve
524022	14	HMI engine derate stop state DPF wasn't regenerated, power reduction phase 2 (manual regeneration request)
524024	11	Deviation of the exhaust gas temperature set point to actual value downstream (DOC) too high
524025	14	Particulate filter regeneration. Regeneration after time X is not successful (The error occurs when the regeneration times (3x) over the max. has been aborted allowed recovery time)
524025	5	DPF system; operating voltage error
524025	14	The standstill-regeneration mode time exceeds the long-limit. Vehicle was too long or too often in standstill mode. Make oil change and reset counter.
524025	14	The standstill-regeneration mode time exceeds the short-limit. Vehicle was too long or too often within a short time in standstill mode. Make oil change and reset counter.
524025	8	Max. launch time for stand still exceeded (60min).
524028	2	CAN message PROEGRActr; plausibility error
524029	2	Timeout Error of CAN-Receive-Frame ComEGRActr - exhaust gas recirculation positioner
524030	7	EGR actuator; internal error
524031	13	EGR actuator, calibration error
524032	2	EGR actuator; status message "EGRCust" is missing
524033	7	EGR actuator; due to overload in Save Mode
524034	5	Disc Separator; open load
524034	12	Disc Separator; power stage over temperature
524034	3	Disc separator; short circuit to battery
524034	4	Disc separator; short circuit to ground
524035	12	Injector diagnostics; time out error in the SPI communication
524036	12	Injector diagnostics Slave; time out error in the SPI communication

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
524038	9	Timeout error of CAN-Receive-Frame ComMS_Sys1TO (error memory Slave); Master-Slave internal CAN message
524039	9	Timeout error of CAN-Receive-Frame ComMS_Sys2TO (error memory Slave); Master-Slave internal CAN message
524040	9	Timeout error of CAN-Receive-Frame ComMS_Sys3TO (error memory Slave); Master-Slave internal CAN message
524041	9	Timeout error of CAN-Receive-Frame ComMS_Sys4TO (error memory Slave); Master-Slave internal CAN message
524042	9	Timeout error of CAN-Receive-Frame ComMS_Sys5TO (error memory Slave); Master-Slave internal CAN message
524043	9	Timeout error of CAN-Receive-Frame ComMS_Sys6TO (error memory Slave); Master-Slave internal CAN message
524044	9	CAN message ComMS_Sys7 not received from slave
524045	9	Master Slave, Error of message counter CAN receive message ComMSMoFovR; ComMSMoFovR1CNT
524046	9	Master-Slave CAN; Error Checksum of CAN-Receive Message
524047	9	Master-Slave CAN; Error of message length of CAN receive message ComMSMoFovR;_ComMSMoFovR1DLC
524048	9	Timeout error CAN message ComMSMoFovR1TO error memory Slave
524052	11	Error memory Slave reports FID MSMonFC2 (collective error)
524052	11	Error memory Slave reports FID MSMonFC3 (collective error)
524052	11	Master ECU and Slave ECU data sets or software are not identical
524057	2	Fuel low pressure pump; error pressure build up
524058	2	Particulate filter; regeneration not successful
524063	5	Relay Urea back flow line heater: broken wiring detected (open load) Row engine: SCR-back flow line (K29) V-engine: Master: SCR-suction / back flow line (K32.1) Slave: SCR-suction / back flow line (K32.2)
524063	5	SCR main relay not connected
524063	5	SCR heater pressure line; open load
524063	3	SCR heater main relay; short circuit to battery
524063	4	SCR heater main relay load side (K31) on heating valve (Y31), Short cut to ground.
524063	5	Relay Urea suction line: broken wiring detected (open load) Row engine: SCR suction line (K28) V-engine: Master: common SCR-suction line (K28) Slave: common SCR back flow line (K29)
524063	5	SCR heater supply module; open load
524063	5	SCR heater tank; open load
524063	12	DEF supply module, time for defrosting too long

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
524063	12	DEF tank, time for defrosting too long
524065	0	Pressure sensor upstream SCR-CAT, pressure above upper physical threshold
524065	1	Pressure sensor upstream SCR-CAT, pressure below lower physical threshold
524065	3	Pressure sensor upstream SCR-CAT; short circuit battery or open load
524065	4	Pressure sensor upstream SCR-CAT; short circuit ground
524065	2	Pressure sensor upstream SCR-CAT, plausibility error
524066	3	SCR measurement heater output stage; short circuit battery or open load
524067	0	DEF supply module, heater temperature above upper physical threshold
524067	1	DEF supply module, heater temperature below lower physical threshold
524067	0	DEF supply module, temperature above upper physical threshold
524067	1	DEF supply module, temperature below lower physical threshold
524067	2	Supply module heater temperature, plausibility error
524067	2	Supply module temperature, plausibility error
524068	2	Master ECU and Slave ECU have been identified as the same types
524069	9	Timeout Error of CAN-Receive-Frame MSMon_FidFCCT0; Master-Slave CAN communication faulty
524070	2	(Upstream NOx-Sensor) Diagnostic Fault Check for invalid upstream NOx value (Sensor self diagnostic DFC set by Deutz-SW) NOx-Sensor before SCR-Cat: Invalid upstream NOx value
524071	2	(Downstream NOx-Sensor) Diagnostic Fault Check for invalid downstream lambda value (Sensor self diagnostic DFC set by Deutz-SW)
524072	2	(Upstream NOx-Sensor) Diagnostic Fault Check for invalid upstream lambda value (Sensor self diagnostic DFC set by Deutz-SW)
524073	2	(Downstream NOx-Sensor) Diagnostic Fault Check for invalid downstream NOx value (Sensor self diagnostic DFC set by Deutz-SW)
524074	9	NOx sensor downstream SCR-CAT, sensor internally open load
524074	2	NOx-Sensor after SCR-Cat: Nox-Sensor dew point problem or plausibility problem
524075	11	NOx sensor downstream SCR-CAT, sensor internally short circuit
524076	9	NOx sensor upstream SCR-CAT, sensor internally open line
524076	2	NOx-Sensor before SCR-Cat: Nox-Sensor dew point problem or plausibility problem

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
524077	11	NOx sensor upstream SCR-CAT, sensor internally short circuit
524078	9	NOx sensor downstream SCR-CAT, lambda value above upper physical threshold
524079	9	NOx sensor downstream SCR-CAT, lambda value below lower physical threshold
524080	9	NOx sensor upstream SCR-CAT, lambda value above upper physical threshold
524081	9	NOx sensor upstream SCR-CAT, lambda value below lower physical threshold
524082	9	(Downstream NOx-Sensor) Diagnostic Fault Check for downstream NOx value over maximum limit (DFC set by Deutz-SW)
524083	9	NOx-Sensor downstream SCR-CAT, NOx value below minimum value.
524084	9	NOx-Sensor upstream SCR-CAT, NOx value above maximum value.
524085	9	NOx sensor upstream SCR-CAT, NOx value below lower physical threshold
524087	5	Urea Error Lamp; open load
524087	12	Urea Error Lamp; temperature over limit
524087	3	Urea Error Lamp; short circuit battery
524087	4	Urea Error Lamp; short circuit ground
524096	14	Control of the SCR system; If the start stop counter (EPA-Counter) exceeds the threshold SCRctI_ctEngStrtStopThresh_C. This counter will increment only once in each driving cycle in case of an SCR error. If the counter reaches the threshold, the DFC will be set to inhibit the engine start. Engine will not be started, because of EPA-Counter
524097	9	Timeout error of CAN-Transmit-Frame DPFBrnAirPmpCtl
524098	9	Timeout error of CAN-Transmit-Frame ComDPFBrnPT
524099	9	Timeout error of CAN-Transmit-Frame ComDPFC1
524100	9	Timeout error of CAN-Transmit-Frame ComDPFHisDat
524101	9	Timeout error of CAN-Transmit-Frame ComDPFTstMon
524102	9	Timeout error of CAN-Receive-Frame ComRxDPFBrnAirPmpCtl
524103	9	Timeout error of CAN-Receive-Frame ComRxDPFBrnAirPmp
524104	9	Timeout error of CAN-Receive-Frame ComRxDPFC1
524105	9	Timeout error of CAN-Transmit-Frame ComEGRMsFlw (EGR Steller)
524106	9	Timeout error of CAN-Receive-Frame ComRxEGRMsFlw1 (EGR actuator)
524107	9	Timeout error of CAN-Receive-Frame ComRxEGRMsFlw2 (EGR actuator)
524108	9	Timeout error of CAN-Transmit-Frame ComEGRTVActr (EGR actuator)

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
524109	9	Timeout error of CAN-Receive-Frame ComRxEGRTVActr (EGR actuator)
524110	9	Timeout error of CAN-Transmit-Frame ComETVActrTO
524111	9	Timeout error of CAN-Receive-Frame ComRxETVActr
524112	9	Timeout ComIntake Throttle Valve Actr
524113	9	Timeout error of CAN-Receive-Frame ComRxITVActr
524114	9	Timeout error of CAN-Transmit-Frame A1DOC
524115	9	Timeout error of CAN-Transmit-Frame AT1S
524116	9	Timeout error of CAN-Transmit-Frame SCR2
524117	9	Timeout error of CAN-Transmit-Frame SCR3
524118	9	Timeout error of CAN-Receive-Frame ComRxCM1
524119	9	Timeout error of CAN-Receive-Frame ComRxCustSCR3
524120	9	Timeout error of CAN-Receive-Frame ComRxSCRHtDiag
524121	9	Timeout error of CAN-Receive-Frame ComRxTrbChActr (wastegate actuator)
524122	9	Timeout error of CAN-Receive-Frame ComRxUQSens (Urea quality)
524123	9	Timeout error of CAN-Receive-Frame ComSCRHtCtl
524124	9	Timeout error of CAN-Receive-Frame ComTxAT1IMG
524125	9	Timeout error of CAN-Receive-Frame ComTxTrbChActr (Wastegate actuator)
524132	2	Fuel low pressure upstream fuel low pressure pump not plausible
524132	0	Fuel low pressure upstream fuel low pressure pump, pressure above maximum warning threshold
524132	0	Fuel low pressure upstream fuel low pressure pump, pressure above maximum shut off threshold
524132	1	Fuel low pressure upstream fuel low pressure pump, pressure below minimum shut off threshold
524132	1	Fuel low pressure upstream fuel low pressure pump, pressure below minimum warning threshold
524133	2	HMI system; set if restore button blocked
524134	0	DPF, ash load exceeds the shutoff threshold
524134	0	DPF, ash load exceeds the warning threshold
524135	0	DPF, soot load exceeds the shutoff threshold
524135	14	DPF, soot load exceeds the service request threshold
524135	0	DPF, soot load exceeds the warning threshold



## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-4. Engine Fault Code Chart**

SPN	FMI	Error Identification
524141	7	DEF dosing valve, dosing valve blocked
524147	13	SCR System, pressure build up not possible
524147	7	SCR-System, reverting valve blocked
524147	13	Set together with DFC_SCRCoBldUpLoPres. DFC_SCRCoBldUpLoPresRst is only used for inducement purposes. It ensures that legal inducement is working correctly.
524149	2	Plausibility error between pressure downstream turbine (PTRbnDs) and ambient air pressure (EnvP)
524149	2	Pressure downstream turbine, plausibility error
524152	2	Urea Quality Sensor; Timeout CAN message
524153	2	Urea tank level & urea tank temperature via CAN bus, timeout of CAN message
524156	9	Timeout error of CAN-Receive-Frame ComRxEBC2
524157	9	Fan control; time out for fan governing
524159	0	Fan; short circuit battery or open load
524159	1	Fan; short circuit ground
524160	5	Fan; in/outlet valve 1; open load
524160	3	Fan; in/outlet valve 1; short circuit battery
524160	4	Fan; in/outlet valve 1; open load ground
524161	5	Fan; in/outlet valve 2; open load
524161	3	Fan; in/outlet valve 2; short circuit battery
524161	4	Fan; in/outlet valve 2; open load ground
524162	12	Fan; fan control; angle sensor defect
524163	12	Fan; fan control; fan or valve defect
524175	0	SCR-CAT, Nox emissions above maximum threshold
524177	7	SCR System, DEF suction line blocked
524178	7	SCR System, DEF pressure out of range
524189	9	Master / Slave Can disturbed
524190	14	Inducement level 1 active
524191	14	Inducement level 2 active
524193	8	The standstill-regeneration mode time exceeds the long limit threshold. Vehicle was too long or too often in standstill mode. Change oil and reset counter.

Table 3-4. Engine Fault Code Chart

SPN	FMI	Error Identification
524194	8	The standstill-regeneration mode time exceeds the short-limit. Vehicle was too long or too often within a short time in standstill mode. Change oil and reset counter.
524195	14	Standstill request due to crystallization ignored too long
524196	13	Variant handling, address error
524196	2	Variant handling, Synchronisation error
524202	11	SCR error code in master ECU active
524203	11	DEF tank level failure is in master ECU active
524204	11	SCR after run failure is in master ECU active
524205	11	SCR Co2off failure is in master ECU active
524206	11	SCR disable DEF dosing failure is in master ECU active
524230	11	Inducement HW Failure Slave
524231	11	Inducement SCR Tamp. Slave
524232	11	Inducement DEF Quality in Slave ECU
524239	11	SCR regeneration failure is in slave ECU active
524248	11	NOX sensor downstream error in slave ECU
524249	11	DEF dosing valve error in slave ECU
524251	11	DEF pressure problems in slave ECU
524252	11	Reverting valve error in slave ECU
524253	11	DEF back flow line heater error on slave ECU
524254	11	Error NOx-Tailpipe emissions exceeded on Slave ECU
524255	11	DEF suction line heater error on slave ECU
524256	11	DEF supply module heater error on slave ECU
524257	11	Error Exhaust pressure upstream SCR on Slave ECU
524258	11	Error Exhaust temperature upstream SCR on Slave ECU
524259	11	DEF pressure line heater error on slave ECU
524260	11	Error Urea pump temperature on Slave ECU
524261	11	Error DEF heater relays on Slave ECU
524267	14	Announcement triggers the Inducement Level 2

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)**

KWP-Code	SPN	FMI	Blink code	Error Identification
1	110	11	226	Air flow sensor load correction factor exceeding the maximum drift limit; plausibility error.
8	132	1	226	The air mass flow AFS_dm is greater than or equal to AFS_PhysRng.Min_C. Physical Range Check low for air mass flow sensor No detail informationen!
9	172	2	226	Air inlet filter temperature, plausibility error.
26	523891	14	263	When AirHt_ctDefSRCLoOn_mp is less than AirHt_ctMaxDef_C. DFC to SRC Low error when heater is On No detail informationen!
28	523953	2	728	Healing takes place if the condition for error detection is not present. Air temperature monitoring plausibility check array No detail informationen!
30	523955	2	728	Healing takes place if the condition for error detection is not present. Air temperature monitoring plausibility check array No detail informationen!
36	523923	3	729	UB1; Short circuit to battery error of actuator relay 1.
37	523924	3	167	UB2; Short circuit to battery error of actuator relay 2.
38	523925	3	731	UB3; Short circuit to battery error of actuator relay 3.
40	523927	3	733	UB5; Short circuit to battery error of actuator relay 5, SCR-Heater/Rev.Valve.
41	523923	4	729	Short circuit to ground error No detail informationen!
42	523924	4	167	UB2; Short circuit to ground actuator relais 2.
43	523925	4	731	UB3; Short circuit to ground actuator relais 3.
44	523926	4	732	UB4; Short circuit to ground aktuator relais 4.
45	168	3	318	Sensor error battery voltage; signal range check high.
46	168	4	318	Sensor error battery voltage; signal range check low.
47	168	2	318	High battery voltage; warning threshold exceeded.
48	168	2	318	High battery voltage; shot off threshold exceeded.
55	523910	14	695	Air pump doesn't achieve air mass flow setpoint. Burner Control - burner air pump.
56	524013	7	856	Burner Control; burner Flame; Burner does not start after x trials (burner flame lost detection). Burner flame unintentional deleted.
57	524020	14	863	Burner Control: power reduction due to low lambda. Engine power; Not enough oxygen for regeneration.
58	523911	0	723	Burner dosing valve (DV2); overcurrent at the end of the injection phase.
59	523911	12	723	Burner dosing valve (DV2); powerstage over temperature.
60	523911	3	723	Burner dosing valve (DV2); short circuit to battery.
62	523911	4	723	Burner dosing valve (DV2); short circuit to ground.
63	523911	11	723	Burner dosing valve (DV2); short circuit high side powerstage.
64	523912	2	722	Burner dosing valve (DV2) downstream pressure sensor; plausibility error.
66	523912	0	722	Physical range check high for burner dosing valve (DV2) downstream pressure; shut off regeneration.
69	523912	1	722	Physical range check low for burner dosing valve (DV2) downstream pressure; shut off regeneration. When burner injector is actuated, the measured pressure does not rise above ca. 1250mbar abs (expected: ca. 2400mbar).
72	523912	3	722	Sensor error burner dosing valve (DV2) downstream pressure sensor; signal range check high.

Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)

KWP-Code	SPN	FMI	Blink code	Error Identification
73	523912	4	722	@ engines < 4l: Throttle valve error, Open Load or Short cut to Battery, blocked valve or wrong control signal for valve. @ engines with Burner T4i: Pressure Sensor error after valve (DV2), lower limit reached.
74	523913	3	721	Sensor error glow plug control diagnostic line voltage; signal range check high.
75	523913	4	721	Sensor error glow plug control diagnostic line voltage; signal range check low.
76	523914	5	721	Glow plug control; open load water pump control (PWM).
77	523914	12	721	Glow plug control; powerstage over temperature.
78	523914	3	721	Glow plug control; short circuit to battery water pump control (PWM).
79	523914	4	721	Glow plug control; short circuit to ground.
82	1235	14	271	CAN-Bus 2 = CAN_C reports Bus-error (for engines < 8L and CV52 it is the engine-CAN@250kbaud) CAN Bus error passive; warning CAN C - engine CAN.
83	16	0	271	No detail informationen!
84	639	14	271	CAN-Bus 0 "BusOff-Status"
85	1231	14	271	CAN-Bus 1 "BusOff-Status"
86	1235	14	271	CAN-Bus 2 = engine bus "BusOff-Status"
87	16	0	271	BusOff error CAN No detail informationen!
88	102	2	223	Charged air pressure above warning threshold.
89	102	2	223	Charged air pressure above shut off threshold.
90	110	2	225	defect fault check for Absolute plausibility test No detail informationen!
92	110	0	225	Physical Range Check high for Coolant temperature.
93	110	1	225	Physical Range Check low for Coolant temperature.
96	110	3	225	Sensor error coolant temperature; signal range check high.
97	110	4	225	Sensor error coolant temperature; signal range check low.
98	110	0	232	High coolant temperature; warning threshold exceeded.
99	110	0	232	Coolant temperature; system reaction initiated.
101	111	1	235	Coolant level too low.
106	598	2	325	Plausibility check for Clutch No detail informationen!
121	1109	2	341	Engine shut off demand ignored.
122	523698	11	591	Shut off request from supervisory monitoring function.
124	523969	11	774	Fault entry for override control mode. No detail informationen!
125	523717	12	595	Timeout Error of CAN-Transmit-Frame AmbCon; Weather environments.
126	523603	9	338	Timeout Error of CAN-Receive-Frame AMB; Ambient Temperature Sensor.
127	3224	2	596	DLC Error of CAN-Receive-Frame AT1IG1 NOX Sensor (SCR-system upstream cat; DPF-system downstream cat); length of frame incorrect.
128	3224	9	597	Timeout Error of CAN-Receive-Frame AT1IG1; NOX sensor upstream.
129	3224	2	596	DLC Error of CAN-Receive-Frame AT1IG1Vol NOX sensor.
130	3224	9	597	Timeout Error of CAN-Receive-Frame AT1IG1Vol; NOX sensor.
133	523938	9	766	Timeout Error (BAM to packet) for CAN-Receive-Frame AT1IGCVol1.
134	523939	9	766	Broadcast Announce Message of the calibration message of the upstream catalytic NOx sensor has failed.
135	523940	9	766	Timeout Error (PCK2PCK) for CAN-Receive-Frame AT1IGCVol1
136	3234	2	114	DLC Error of CAN-Receive-Frame AT101 No detail informationen!

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)**

KWP-Code	SPN	FMI	Blink code	Error Identification
137	3234	9	117	Timeout Error of CAN-Receive-Frame AT10G1; NOX sensor (SCR-system downstream cat; DPF-system downstream cat).
138	3234	2	114	DLC Error of CAN-Receive-Frame AT101Vol NOX.
139	3234	9	117	Timeout Error of CAN-Receive-Frame AT10G1Vol.
140	523941	9	767	Timeout Error (BAM to packet) for CAN-Receive-Frame AT10GCVol2.
141	523942	9	767	Calibration message 1 of the after catalyst NOx sensor has failed.
142	523943	9	767	Timeout Error (PCK2PCK) for CAN-Receive-Frame AT10GCVol2.
153	523992	9	793	
155	0	0	-	
164	523211	9	331	Timeout Error of CAN-Receive-Frame EBC1.
167	523704	12	615	Timeout Error of CAN-Transmit-Frame EEC3.
168	523935	12	763	Timeout Error of CAN-Transmit-Frame EEC3VOL1; Engine send messages.
169	523936	12	764	Timeout Error of CAN-Transmit-Frame EEC3VOL2; Engine send messages.
171	523212	9	333	Timeout Error of CAN-Receive-Frame ComEngPrt; Engine Protection.
172	523741	14	618	Engine shut off request through CAN No detail informationen!
174	523213	12	334	Timeout Error of CAN-Transmit-Frame ERC1 No detail informationen!
178	523706	12	623	Timeout Error of CAN-Transmit-Frame FlEco No detail informationen!
179	523240	9	527	Timeout CAN-message FunModCtl; Function Mode Control.
193	523937	9	765	Timeout DFC for NOxSensGlbReqTx. No detail informationen!
196	3227	2	638	DFCSAE J1939 error No detail informationen!
198	523216	9	337	Timeout Error of CAN-Receive-Frame PrHtEnCmd; pre-heat command, engine command.
202	523793	9	678	Timeout Error of CAN-Receive-Frame UAA10; AGS sensor service message.
203	523794	9	678	Timeout Error of CAN-Receive-Frame UAA11; AGS sensor data.
212	523803	9	678	Timeout error of CAN Receive Message RxEngPres; Status Burner Air Pump.
273	3219	2	649	DFCSAE J1939 error No detail informationen!
281	523766	9	118	Timeout Error of CAN-Receive-Frame Active TSC1AE.
282	523767	9	118	Timeout Error of CAN-Receive-Frame Passive TSC1AE.
283	523768	9	119	Timeout Error of CAN-Receive-Frame Active TSC1AR.
284	523769	9	119	Timeout Error of CAN-Receive-Frame Passive TSC1AR.
291	523776	9	119	Timeout Error of CAN-Receive-Frame TSC1TE - active.
292	523777	9	119	Passive Timeout Error of CAN-Receive-Frame TSC1TE; Setpoint.
293	523778	9	118	Timeout Error of CAN-Receive-Frame TSC1TR.
294	523779	9	118	Passive Timeout Error of CAN-Receive-Frame TSC1TR.
299	523788	12	655	Timeout Error of CAN-Transmit-Frame TrbCH; Status Wastegate.
300	523605	9	118	Timeout Error of CAN-Receive-Frame TSC1AE; Traction Control.
301	523606	9	119	Timeout Error of CAN-Receive-Frame TSC1AR; Retarder.
305	898	9	118	Timeout Error of CAN-Receive-Frame TSC1TE; Setpoint.
306	520	9	119	Timeout Error of CAN-Receive-Frame TSC1TR; control signal.
313	523858	12	679	Timeout Error of CAN-Transmit-Frame UAA11.
322	523867	12	679	Ansteuerung Brenner Luftpumpe; _Timeout Error of CAN-Transmit-Frame UAA1 on CAN A.
360	523982	0	737	Powerstage diagnosis disabled; high battery voltage.
361	523982	1	737	Powerstage diagnosis disabled; low battery voltage.

Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)

KWP-Code	SPN	FMI	Blink code	Error Identification
362	523090	2	329	Engine Brake Pre-Selection switch; Plausibility Error.
376	630	12	281	Access error EEPROM memory (delete).
377	630	12	281	Access error EEPROM memory (read).
378	630	12	281	Access error EEPROM memory (write).
381	411	4	693	Physical range check low for EGR differential pressure.
384	2791	12	415	Actuator EGR Valve; powerstage over temperature.
387	523612	12	555	Internal software error ECU; injection cut off.
388	190	0	214	Engine speed above warning threshold. Overspeed detection in component engine protection.
389	190	0	214	Engine speed above warning threshold (FOC-Level 1).
390	190	11	214	Engine speed above warning threshold (FOC-Level 2).
391	190	14	214	Engine speed above warning threshold (Overrun Mode).
411	108	11	292	DFC for CAN message.
412	108	3	292	Sensor error ambient air pressure; signal range check high.
413	108	4	292	Sensor error ambient air pressure; signal range check low.
415	171	0	312	Environment temperature sensor, temperature above upper physical threshold.
416	171	1	312	Environment Temperature Physical Range Check low.
417	171	3	312	Sensor error SCR-System environment temperature; DPF-System air inlet temperature; signal range check high.
418	171	4	312	Sensor error SCR-System environment temperature; DPF-System air inlet temperature; signal range check low.
419	190	8	212	Sensor camshaft speed; disturbed signal.
420	190	12	212	Sensor camshaft detection; out of range, signal disrupted; no signal.
421	190	2	213	Offset angle between crank- and camshaft sensor is too large.
422	190	8	212	Sensor crankshaft detection; out of range, signal disrupted; disturbed signal.
423	190	12	212	Speed detection; out of range, signal disrupted Sensor crankshaft speed; no signal.
455	975	5	238	PWM-Signal Fan, Open load or short-circuit ground.
457	975	3	238	PWM-Signal Fan, short-circuit to plus.
458	975	4	238	PWM-Signal Fan, open load or short circuit to ground.
459	1639	12	238	Fan speed sensor; electrical error or signal disturbed or very low fan speed.
460	1639	0	238	Sensor error fan speed; signal range check high or engine speed resp. fan speed too big.
461	1639	1	238	Sensor error fan speed; signal range check low or fan speed too low.
462	523602	0	238	High fan speed; warning threshold exceeded.
463	523602	0	238	High fan speed; shut off threshold exceeded.
464	97	3	228	Sensor error water in fuel; signal range check high.
465	97	4	228	Sensor error water in fuel; signal range check low.
472	94	3	216	Sensor error low fuel pressure; signal range check high.
473	94	4	216	Sensor error low fuel pressure; signal range check low.
474	94	1	216	Low fuel pressure; warning threshold exceeded.
475	94	1	216	Low fuel pressure; shut off threshold exceeded.
483	174	11	227	DFC for fuel temperature plausibility check function No detail informationen!
486	523618	3	133	Gearbox oil temperature; Short circuit to battery or broken harness.
487	523618	4	133	Gearbox oil temperature; Short circuit to ground.

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)**

KWP-Code	SPN	FMI	Blink code	Error Identification
488	523619	2	133	Physical range check high for exhaust gas temperature upstream (SCR-CAT).
500	523915	0	165	HCI dosing valve (DV1); overcurrent at the end of the injection phase.
501	523915	12	166	HCI dosing valve (DV1); powerstage overtemperature.
502	523915	3	159	HCI dosing valve (DV1); short circuit to battery.
503	523915	3	164	HCI dosing valve (DV1); short circuit to battery high side.
504	523915	4	159	HCI dosing valve (DV1); short circuit to ground.
505	523915	11	164	HCI dosing valve (DV1); short circuit high side powerstage.
506	523916	2	719	Sensor HCI dosing valve (DV1) downstream pressure; plausibility error.
508	523916	0	719	Physical range check high for HCI dosing valve (DV1) downstream pressure; shut off regeneration.
511	523916	1	719	Physical range check low for HCI dosing valve (DV1) downstream pressure; shut off regeneration.
514	523916	3	719	Sensor error HCI dosing valve (DV1) downstream pressure; signal range check high.
515	523916	4	719	Sensor error HCI dosing valve (DV1) downstream pressure; signal range check low.
524	523917	3	718	Sensor error DV1 & DV2 upstream pressure; signal range check high.
525	523917	4	718	Sensor error DV1 & DV2 upstream pressure; signal range check low.
534	523918	3	717	Sensor error DV1 & DV2 upstream temperature; signal range check high.
535	523918	4	717	Sensor error DV1 & DV2 upstream temperature; signal range check low.
542	1638	2	314	Hydraulic oil temperature check for Shut off condition No detail informationen!
543	676	11	263	Cold start device relay error.
544	676	11	263	Cold start aid relay open load.
545	729	5	263	Cold start aid relay open load.
547	729	12	263	Cold start aid relay; over temperature error.
549	729	3	263	Intake Air Heater Device; Short circuit to battery.
551	729	4	263	Air intake heater; Short circuit to ground error for powerstage on CJ945.
559	523895	13	158	Check of missing injector adjustment value programming (IMA) injector 1 (in firing order).
560	523896	13	158	check of missing injector adjustment value programming (IMA) injector 2 (in firing order).
561	523897	13	158	check of missing injector adjustment value programming (IMA) injector 3 (in firing order).
562	523898	13	158	check of missing injector adjustment value programming (IMA) injector 4 (in firing order).
563	523899	13	158	check of missing injector adjustment value programming (IMA) injector 5 (in firing order).
564	523900	13	158	check of missing injector adjustment value programming (IMA) injector 6 (in firing order).
565	523350	4	151	Injector cylinder-bank 1; short circuit.
566	523352	4	152	Injector cylinder-bank 2; short circuit.
567	523354	12	153	Injector powerstage output defect.
568	651	5	154	Injector 1 (in firing order); interruption of electric connection.
569	652	5	155	Injector 2 (in firing order); interruption of electric connection.
570	653	5	156	Injector 3 (in firing order); interruption of electric connection.
571	654	5	161	Injector 4 (in firing order); interruption of electric connection.
572	655	5	162	Injector 5 (in firing order); interruption of electric connection.

Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)

KWP-Code	SPN	FMI	Blink code	Error Identification
573	656	5	163	Injector 6 (in firing order); interruption of electric connection.
575	523756	14	155	special pattern for special cases No detail informationen!
576	523757	14	156	special pattern for special cases No detail informationen!
577	523758	14	161	special pattern for special cases No detail informationen!
578	523759	14	162	special pattern for special cases No detail informationen!
579	523760	14	163	special pattern for special cases No detail informationen!
580	651	3	154	Injector 1 (in firing order); short circuit.
581	652	3	155	Injector 2 (in firing order); short circuit.
582	653	3	156	Injector 3 (in firing order); short circuit.
583	654	3	161	Injector 4 (in firing order); short circuit.
584	655	3	162	Injector 5 (in firing order); short circuit.
585	656	3	163	Injector 6 (in firing order); short circuit.
590	655	4	162	High side to low side short circuit in the injector 5 (in firing order).
591	656	4	163	High side to low side short circuit in the injector 6 (in firing order).
592	523615	5	135	Metering unit (Fuel-System); open load.
593	523615	12	135	Metering unit (Fuel-System); powerstage over temperature.
594	523615	3	135	Metering unit (Fuel-System); short circuit to battery highside.
595	523615	4	135	Metering unit (Fuel-System); short circuit to ground high side.
596	523615	3	135	Metering unit (Fuel-System); short circuit to battery low side.
597	523615	4	135	Metering Unit (Fuel-System); short circuit to ground low side.
598	523615	3	135	Metering unit, short circuit to battery.
599	523615	4	135	Metering unit, short circuit to ground.
604	1323	12	241	Too many recognized misfires in cylinder 1 (in firing order).
611	1346	0	241	Misfire detection monitoring No detail informationen!
612	523612	12	555	Internal ECU monitoring detection reported error.
613	523612	12	555	ECU reported internal software error. Internal ECU monitoring detection reported error.
614	523612	12	555	ECU reported internal software error.
615	523612	12	555	ECU reported internal software error.
616	523612	12	555	ECU reported internal software error.
617	523612	12	555	ECU reported internal software error.
618	523612	12	555	ECU reported internal software error.
619	523612	12	555	Injection system, electrical error injectors.
620	523612	12	555	ECU reported internal software error.
621	523612	12	555	ECU reported internal software error.
623	523612	12	555	ECU reported internal software error.
624	523612	12	555	ECU reported internal software error.
625	523612	12	555	ECU reported internal software error.
627	523612	12	555	ECU reported internal software error.
628	523612	12	555	ECU reported internal software error.
629	523612	12	555	Diagnostic fault check to report the accelerator pedal position error.
630	523612	12	555	Diagnostic fault check to report the engine speed error.
631	523612	12	555	Error in the plausibility of the injection energizing time.



## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)**

KWP-Code	SPN	FMI	Blink code	Error Identification
632	523612	12	555	Error in the plausibility of the start of energising angles.
633	523612	12	555	Diagnostic fault check to report the error due to non plausibility in ZFC.
634	523612	12	555	Diagnosis fault check to report the demand for normal mode due to an error in the Pol2 quantity.
635	523612	12	555	Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol2 shut-off.
636	523612	12	555	Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol3 efficiency factor.
637	523612	12	555	Internal ECU monitoring detection reported error.
638	523612	12	555	Monitoring of Fuel Quantity Correction.
639	523612	12	555	Diagnostic fault check to report the plausibility error in rail pressure monitoring.
640	523612	12	555	Diagnostic fault check to report the error due to torque comparison.
641	523612	12	555	Diagnosis of curr path limitation forced by ECU monitoring level 2.
642	523612	12	555	Diagnosis of lead path limitation forced by ECU monitoring level 2.
643	523612	12	555	Diagnosis of set path limitation forced by ECU monitoring level 2.
644	523612	3	555	Reported Over Voltage of Supply.
646	523612	4	555	Reported Under Voltage of Supply.
648	523008	1	424	Manipulation control was triggered.
649	523008	2	424	Timeout error in Manipulation control.
654	2634	12	757	Early opening defect of main relay No detail informationen!
656	2634	12	757	DFC for stuck main relay error No detail informationen!
659	3226	2	813	Nox feed back fault detection No detail informationen!
692	523752	0	758	Plausibiliti error during Rich to Lean switch over No detail informationen!
693	523752	0	758	Monitoring of Nox signal readiness No detail informationen!
714	523612	12	555	Diagnostic fault check to report WDA active due to errors in query-/response communication.
715	523612	12	555	Diagnostic fault check to report ABE active due to undervoltage detection.
716	523612	12	555	Diagnostic fault check to report ABE active due to overvoltage detection.
717	523612	12	555	Diagnostic fault check to report WDA/ABE active due to unknown reason.
720	98	2	211	Plausibility Check. No detail informationen!
732	100	3	224	Sensor error oil pressure; signal range check high.
733	100	4	224	Sensor error oil pressure sensor; signal range check low.
734	100	0	231	High oil pressure; warning threshold exceeded.
735	100	0	231	High oil pressure; shut off threshold exceeded.
736	100	1	231	Low oil pressure; warning threshold exceeded.
737	100	1	231	Low oil pressure; shut off threshold exceeded.
743	175	3	144	Sensor error oil temperature; signal range check high.
744	175	4	144	Sensor error oil temperature; signal range check low.
745	175	0	144	High oil temperature; warning threshold exceeded.
746	175	0	144	High oil temperature; shut off threshold exceeded.
747	1237	2	145	Override switch; plausibility error.
750	107	3	136	Sensor error airfilter differential pressure; short circuit to battery.
751	107	0	136	Sensor error airfilter differential pressure; short circuit to ground.

Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)

KWP-Code	SPN	FMI	Blink code	Error Identification
752	107	0	136	Air filter differential pressure; short circuit to ground.
753	523919	2	694	DPF burner air pump pressure sensor, plausibility error.
755	523919	0	694	DPF burner air pump pressure sensor, pressure above upper shutoff threshold.
758	523919	1	694	DPF burner air pump pressure sensor, pressure below lower shutoff threshold.
761	523919	3	694	DPF burner air pump pressure sensor, short circuit to battery or open load.
762	523919	4	694	DPF burner air pump pressure sensor, short circuit to ground.
763	523920	2	716	Exhaust gas pressure upstream burner, plausibility error.
765	523920	0	716	Exhaust gas pressure upstream burner, pressure above upper shutoff threshold.
770	523920	3	716	Exhaust gas pressure upstream burner, short circuit to battery or open load.
771	523920	4	716	Exhaust gas pressure upstream burner, short circuit to ground.
772	102	2	223	Pressure downstream charge air cooler, plausibility error.
774	102	1	223	Pressure downstream charge air cooler, pressure below lower physical threshold.
776	102	3	223	Pressure downstream charge air cooler, short circuit to battery or open load.
777	102	4	223	Pressure downstream charge air cooler, short circuit to ground.
780	523699	3	113	Boost pressure control; negative governor deviation below limit.
781	523699	4	113	learning valu too high No detail informationen!
785	523889	3	113	over teperature of device driver of pressure control valve No detail informationen!
791	411	0	693	delta pressure across venturi in EGR line above physical high limit.
793	411	11	693	Plausibility Check fault for deviation of desired and actual EGR-mass flow, where the latter is calculated out of EGR Delta Pressure Sensor.
795	411	3	693	Sensor error differential pressure Venturiunit (EGR), signal range check low.
796	411	4	693	Sensor error differential pressure Venturiunit (EGR), signal range check high.
805	524025	14	845	Particulate filter regeneration. Regeneration after time X is not successful (The error occurs when the regeneration times (3x) over the max. has been aborted allowed recovery time).
806	524058	2	844	Particulate filter; regeneration not successful.
807	3253	2	692	Differential pressure DPF, plausibility error.
809	3251	0	692	Differential pressure DPF maximum value is exceeded.
810	3251	0	692	Differential pressure sensor across DPF exceeds warning high limit.
812	3251	1	692	Differential pressure DPF, pressure below lower shutoff threshold.
813	3251	1	692	Differential pressure DPF, pressure below lower warning threshold.
814	3253	3	692	Electrical error differential pressure B58 (DPF). (signal range check high).
815	3253	4	692	Electrical error differential pressure (DPF). signal range check low.
825	523009	9	253	The pressure relief valve (PRV) has reached the number of allowed activations.
826	523470	2	146	Pressure relief valve is forced to open, perform pressure increase.
827	523470	2	146	Pressure Relief Valve (PRV) forced to open. Performed by pressure increase.
828	523470	12	146	Pressure Relief Valve (PRV) forced to open. Shutoff conditions.
829	523470	12	146	Pressure Relief Valve (PRV) forced to open. Warning conditions.
830	523470	14	146	Open Pressure Relief Valve (PRV).
831	523470	11	146	Pressure Relief Valve (PRV) error; Rail pressure out of tolerance range.
832	523470	11	146	Rail pressure out of tolerance range. The PRV can not be opened at this operating point with a pressure shock.
833	523009	10	253	Open time of Pressure Relief Valve (PRV) for wear out monitoring had exceeded.
834	523906	5	761	Electrical fuel pre - supply pump; open load.

## SECTION 3 - CHASSIS & TURNTABLE

**Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)**

KWP-Code	SPN	FMI	Blink code	Error Identification
835	523906	12	761	Electrical fuel pre - supply pump. ECU powerstage over temperature.
836	523906	3	761	Electrical fuel pre - supply pump; short circuit to battery.
837	523906	4	761	Electrical fuel pre - supply pump. Short circuit to ground.
847	1176	0	139	Pressure sensor upstream turbine, Physical Range Check high.
848	1176	1	139	Pressure sensor upstream turbine, Physical Range Check low.
849	1176	3	141	Pressure sensor upstream turbine, signal range check (SRC) high.
850	1176	4	141	Pressure sensor upstream turbine, signal range check (SRC) low.
856	523613	0	134	Rail pressure metering unit, Positive governor deviation.
857	523613	0	134	Rail pressure metering unit, Rail pressure disrupted. Maximum positive deviation of rail pressure exceeded.
858	523613	0	134	Rail pressure metering unit, Rail pressure disrupted. Maximum positive deviation of rail pressure in metering unit exceeded (RailMeUn1).
859	523613	0	134	Rail pressure metering unit, Rail pressure below the target range. (RailMeUn2) Railsystem leakage detected. (RailMeUn10).
861	523613	1	134	Rail pressure metering unit, Minimum rail pressure exceeded (RailMeUn3). Negative deviation of rail pressure second stage (RailMeUn22).
862	523613	0	134	Rail pressure metering unit, Maximum rail pressure exceeded.
864	523613	2	134	Rail pressure metering unit, Setpoint of metering unit in overrun mode not plausible.
865	523613	0	134	Setpoint of metering unit in overrun mode not plausible.
874	157	0	147	Rail pressure raw value is intermittent No detail informationen!
875	157	1	147	rail pressure raw value is above maximum offset No detail informationen!
876	523470	7	146	Maximum rail pressure exceeded (PRV).
877	157	3	147	Sensor error rail pressure. Sensor voltage above upper limit.
878	157	4	147	Sensor error rail pressure. Sensor voltage below lower limit.
881	523633	11	149	Lonterm adaption factor below threshold.
882	523633	11	149	Nox conversion rate insufficient (SCR-Cat defect, bad DEF quality).
883	523633	11	149	Nox conversion rate insufficient (SCR-Cat defect, bad DEF quality); temperature range 1.
887	3234	11	184	DFC for plausibility error Min for NOx sensor downstream of SCR Cat.
889	3224	1	185	DFC for plausibility error Max for NOx sensor upstream of SCR Cat.
892	4345	11	236	Sensor backflow line pressure (SCR); plausibility error.
893	4343	11	871	SCR Monitoring; Pressure stabilisation error, general pressure check error (SCR).
894	4374	13	872	Pressure stabilisation error dosing valve (SCR).
897	523632	16	875	Pump pressure SCR metering unit too high.
898	523632	18	876	Pump pressure SCR metering unit too low.
899	523632	0	877	Pressure overload of SCR-System.
900	523632	1	878	Pressure build-up error SCR-System.
903	4365	0	881	DEF tank temperature too high.
905	3241	0	883	Sensor SCR catalyst upstream temperature too high; plausibility error.
908	3361	7	886	DEF dosing valve blocked (SCR).
914	523720	2	148	DEF supply module heater temperature; plausibility error (normal condition).
915	523720	2	148	Sensor DEF supply module heater temperature; plausibility error (cold start condition).

Table 3-5. Deutz Trouble Codes (D2.9L4 Engine)

KWP-Code	SPN	FMI	Blink code	Error Identification
916	523721	2	689	Sensor DEF supply module temperature; plausibility error (normal condition).
917	523721	2	689	Sensor DEF supply module temperature; plausibility error (cold start condition).
918	523981	11	243	SCR plausibility, OBD and diagnosis; Stuck in range check of DEF tank temperature sensor. DEF-tank without heating function (heating phase).
919	523330	14	131	Immobilizer status; fuel blocked.
920	523330	14	131	DFC to block the fuel by Sia No detail informationen!
921	523330	14	131	DFC to indicate that TEN-code or UC-code received if ECU is learned. No detail informationen!
922	523330	14	131	DFC to indicate that no code is received via CAN. No detail informationen!
923	523330	14	131	DFC to indicate that wrong code is received. No detail informationen!
925	523720	8	148	DEF supply module heater temperature; duty cycle in failure range.
926	523720	8	148	DEF supply module heater temperature; duty cycle in invalid range.
927	523721	11	689	Urea supply module temperature measurement not available.
928	523722	8	691	DEF supply module PWM signal; period outside valid range.
929	523722	8	691	Detect faulty PWM signal from Supply Modul.
930	523721	8	689	DEF supply module temperature; duty cycle in failure range.
931	523721	8	689	Urea supply module temperature; duty cycle in invalid range.
932	29	3	126	Handthrottle idle validation switch; short circuit to battery.
935	91	3	226	Sensor error accelerator pedal. signal range check high.
937	29	4	126	Handthrottle; short circuit to ground.
940	91	4	226	Sensor error accelerator pedal. Signal is below the range.
942	523921	3	714	Sensor error burner temperature; signal range check high.
943	3532	3	127	Sensor error DEF tank level; signal range check high.
944	523921	4	714	Sensor error burner temperature; signal range check low.
945	3532	4	127	Sensor error DEF tank level; signal range check low.
946	1079	13	282	Failure of sensor supply voltage 1.
947	1080	13	282	Failure of sensor supply voltage 2.
948	523601	13	282	Failure of sensor supply voltage 3.
952	523580	2	555	Data set variant with the desired number not found Invalid variant dataset Identifier error. No detail informationen!
953	523580	11	555	An error has occurred in the switch over to the desired data set variant in the code word. Variant dataset switching error No detail informationen!
954	523580	11	555	The code word could not be read correctly from the EEPROM Variant dataset switching error. No detail informationen!
956	677	3	512	Starter relay high side. Short circuit to battery.
957	677	4	512	Starter relay high side short circuit to ground.
958	677	5	512	Starter relay low side no load error.
959	677	12	512	Starter relay powerstage over temperature.
960	677	3	512	Starter relay low side short circuit to battery.
961	677	4	512	Starter relay low side short circuit to ground.
965	523922	3	715	Burner shut of valve; short circuit to battery.