

Table 3-17. Symptom Diagnosis

Checks	Action
Additional Check	² Check the transmission shift pattern. Refer to the OEM Transmission Controls section the Service Manual. ² Check for dragging brakes.
Rough, Unstable, or Incorrect Idle, Stalling	
DEFINITION: The engine runs unevenly at idle. If severe enough, the engine or vehicle may shake. The engine idle speed may vary in RPM. Either condition may be severe enough to stall the engine.	
Preliminary Check	Refer to Important Preliminary Checks.
Sensor Checks	² Check for silicon contamination from fuel or improperly used sealant. The sensor will have a white powdery coating. The sensor will result in a high but false signal voltage (rich exhaust indication). The ECM will reduce the amount of fuel delivered to the engine causing a severe drive-ability problem. ² Check the Heated Exhaust Gas Oxygen Sensor (HEGO) performance: ² Check the Temperature Manifold Absolute Pressure (TMAP) sensor response and accuracy.
Fuel System Checks	² Check for rich or lean symptom that causes the condition. Drive the vehicle at the speed of the complaint. Monitoring the oxygen sensors will help identify the problem. ² Check for a sticking mixer air valve. ² Verify proper operation of the EPR. ² Perform a cylinder compression test. Refer to Engine Mechanical in the Service Manual. ² Check the LPR fuel pressure. Refer to the LPG Fuel System Diagnosis. ² Check mixer module assembly for proper installation and connection.
Ignition System Checks	² Check for the proper ignition output voltage using the spark tester J26792 or the equivalent. ² Verify that the spark plugs are correct for use with LPG (R42LTS). ² Check the spark plugs. Remove the plugs and inspect them for the following conditions: - Wet plugs - Cracks - Wear - Improper gap - Burned electrodes - Blistered insulators - Heavy deposits ² Check the spark plug wires by connecting an ohmmeter to the ends of each wire in question. If the meter reads over 30,000 ohms, replace the wires.
Additional Checks	Important: The LPG Fuel system works on a fumigation principle of fuel introduction and is more sensitive to intake manifold leakage than the gasoline fuel supply system. ² Check for vacuum leaks. Vacuum leaks can cause a higher than normal idle and low throttle angle control command. ² Check the ECM grounds for being clean, tight, and in their proper locations. ² Check the battery cables and ground straps. They should be clean and secure. Erratic voltage may cause all sensor readings to be skewed resulting in poor idle quality.
Engine Mechanical Check	² Check the engine for the following: - Broken motor mounts - Improper valve timing - Low compression - Bent pushrods - Worn rocker arms - Broken or weak valve springs - Worn camshaft lobes
Surges/Chuggles	
DEFINITION: The engine has a power variation under a steady throttle or cruise. The vehicle feels as if it speeds up and slows down with no change in the accelerator pedal.	
Preliminary Checks	Refer to Important Preliminary Checks.
Sensor Checks	² Check Heated Exhaust Gas Oxygen Sensor (HEGO) performance.

Table 3-17. Symptom Diagnosis

Checks	Action
Fuel System Checks	² Check for Rich or Lean symptom that causes the condition. Drive the vehicle at the speed of the complaint. Monitoring the oxygen sensors will help identify the problem. ² Check the fuel pressure while the condition exists. Refer to LPG Fuel System Diagnosis. ² Verify proper fuel control solenoid operation. ² Verify that the LPG manual shut-off valve is fully open. ² Check the in-line fuel filter for restrictions.
Ignition System Checks	² Check for the proper ignition output voltage using the spark tester J26792 or the equivalent. ² Verify that the spark plugs are correct for use with LPG (R42LTS). ² Check the spark plugs. Remove the plugs and inspect them for the following conditions: <ul style="list-style-type: none"> - Wet plugs - Cracks - Wear - Improper gap - Burned electrodes - Heavy deposits - Check the Crankshaft Position (CKP) sensor.
Additional Check	² Check the ECM grounds for being clean, tight, and in their proper locations. ² Check the generator output voltage. ² Check the vacuum hoses for kinks or leaks. ² Check Transmission

Go to Discount-Equipment.com to order your parts

Table 3-18. DTC to SPN/FMI Cross Reference Chart

DTC	Description	SPN Code	FMI Code
16	Crank Never Synced at Start	636	8
91	Fuel Pump Low Voltage	94	4
92	Fuel Pump High Voltage	94	3
107	MAP Low Voltage	106	4
108	MAP High Pressure	106	16
111	IAT Higher Than Expected 1	105	15
112	IAT Low Voltage	105	4
113	IAT High Voltage	105	3
116	ECT Higher Than Expected 1	110	15
117	ECT Low Voltage	110	4
118	ECT High Voltage	110	3
121	TPS 1 Lower Than TPS 2	51	1
122	TPS 1 Signal Voltage Low	51	4
123	TPS 1 Signal Voltage High	51	3
127	IAT Higher Than Expected 2	105	0
129	BP Low Pressure	108	1
134	EGO 1 Open/Inactive	724	10
154	EGO 2 Open/Inactive	520208	10
171	Adaptive Learn High Gasoline	520200	0
172	Adaptive Learn Low Gasoline	520200	1
182	Fuel Temp Gasoline Low Voltage	174	4
183	Fuel Temp Gasoline High Voltage	174	3
187	Fuel Temp LPG Low Voltage	520240	4
188	Fuel Temp LPG High Voltage	520240	3
217	ECT Higher Than Expected 2	110	0
219	Max Govern Speed Override	515	15
221	TPS 2 Signal Voltage Low	51	0
222	TPS 2 Signal Low Voltage	520251	4
223	TPS 2 Signal High Voltage	520251	3
261	Injector Driver 1 Open	651	5
262	Injector Driver 1 Shorted	651	6
264	Injector Driver 2 Open	652	5
265	Injector Driver 2 Shorted	652	6
267	Injector Driver 3 Open	653	5
268	Injector Driver 3 Shorted	653	6
270	Injector Driver 4 Open	654	5
271	Injector Driver 4 Shorted	654	6
336	Crank Sync Noise	636	2
337	Crank Loss	636	4
341	Cam Sync Noise	723	2
342	Cam Sensor Loss	723	4
420	Gasoline Cat Monitor	520211	10

SECTION 3 - CHASSIS & TURNTABLE

Table 3-18. DTC to SPN/FMI Cross Reference Chart

DTC	Description	SPN Code	FMI Code
524	Oil Pressure Low	100	1
562	System Voltage Low	168	17
563	System Voltage High	168	15
601	Flash Checksum Invalid	628	13
604	RAM Failure	630	12
606	COP Failure	629	31
642	External 5V Reference Low	1079	4
643	External 5V Reference High	1079	3
685	Power Relay Open	1485	5
686	Power Relay Shorted	1485	4
687	Power Relay Short to Power	1485	3
1111	Fuel Rev Limit	515	16
1112	Spark Rev Limit	515	0
1151	Closed Loop Multiplier High LPG	520206	0
1152	Closed Loop Multiplier Low LPG	520206	1
1155	Closed Loop Multiplier High Gasoline	520204	0
1156	Closed Loop Multiplier Low Gasoline	520204	1
1161	Adaptive Learn High LPG	520202	0
1162	Adaptive Learn Low LPG	520202	1
1165	LPG Cat Monitor	520213	10
1171	LPG Pressure Higher Than Expected	520260	0
1172	LPG Pressure Lower Than Expected	520260	1
1173	EPR Comm Lost	520260	31
1174	EPR Voltage Supply High	520260	3
1175	EPR Voltage Supply Low	520260	4
1176	EPR Internal Actuator Fault	520260	12
1177	EPR Internal Circuitry Fault	520260	12
1178	EPR Internal Comm Fault	520260	12
1612	RTI 1 Loss	629	31
1613	RTI 2 Loss	629	31
1614	RTI 3 Loss	629	31
1615	A/D Loss	629	31
1616	Invalid Interrupt	629	31
1625	Shutdown Request	1384	31
1626	CAN Tx Failure	639	12
1627	CAN Rx Failure	639	12
1628	CAN Address Conflict Failure	639	13
1629	Loss of TSC 1	639	31
2111	Unable to Reach Lower TPS	51	7
2112	Unable to Reach Higher TPS	51	
2135	TPS 1/2 Simultaneous Voltages	51	31
2229	BP Pressure High	108	0

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your manual number or description and we will search our parts library.

* Brand:

* Serial Number:

* Model:

Serial:

Part Number:

Quantity:

Submit

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in as much information as possible to help us locate the part you need.

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Serial Number:

Brand:

Part Name:

Part Location:

Part Condition:

Part Material:

Part Color:

Part Weight:

Part Dimensions:

Part Notes:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 4. BOOM & PLATFORM

4.1 PLATFORM

Support Removal





Figure 4-1. Location of Components Platform Support

1. Disconnect electrical cables from control console.
2. Remove the bolts securing the platform to the platform support, then remove the platform.


NOTE: The platform weighs approximately 127.9 lbs. (58 kg).




3. Using a suitable device, support the platform support.

NOTE: The platform support weighs approximately 76.4 lbs. (34.7 kg).

4. Remove the bolts and locknut securing the support to the rotator.



5. Using a suitable brass drift and hammer, remove the rotator center bolt




6. Remove the platform support from rotator.

Support Installation


1. Using a suitable device, support the platform support and position it on the rotator.

NOTE: The platform support weighs approximately 76.4 lbs. (34.7 kg).

2. Install the rotator center bolt.




3. Apply JLG Threadlocker P/N 0100011 to the eight bolts and locknut securing the support to the rotator and install the bolts and locknut.




4. Torque the nut on the rotator center bolt to 586 ft. lbs. (795 Nm). Torque the retaining bolts to 40 ft. lbs. (55 Nm).

5. Position the platform on the platform support and install the bolts securing the platform to the platform support. Torque the bolts to 85 ft. lbs. (116 Nm).



6. Connect the electrical cables to the platform control console.



- A Torque to 40 ft. lbs. (55 Nm)
- B JLG Threadlocker P/N0100011
- C Torque to 586 ft. lbs. (795 Nm)
- D Check torque every 150 hours of operation
- E Torque to 85 ft. lbs. (116 Nm)

Figure 4-2. Platform Support Torque Values

4.2 ROTATOR AND SLAVE CYLINDER

Removal

600S

1. Tag and disconnect hydraulic lines to rotator. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
2. Supporting the rotator, remove hardware from pin #1. Using a suitable brass drift and hammer remove pin #1 from the fly boom.
3. Remove the hardware from pin #2. Using a suitable brass drift and hammer, remove pin #2 from the fly boom and remove the rotator.
4. Supporting the slave cylinder, remove the hardware from pin #3. Using a suitable brass drift and hammer remove pin #3 from the fly boom.
5. Tag and disconnect hydraulic lines to the slave leveling cylinder. Use a suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports. Remove the slave cylinder.

600SJ/660SJ

1. Tag and disconnect hydraulic lines to rotator. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
2. Supporting the rotator, remove hardware from pin #1. Using a suitable brass drift and hammer remove pin #1 from the jib assembly.
3. Remove the hardware from pin #2. Using a suitable brass drift and hammer, remove pin #2 from the jib assembly and remove the rotator.
4. Telescope the fly section out approximately 20" (50.8 cm) to gain access to the slave leveling cylinder.
5. Remove the hardware from pin #3. Using a suitable brass drift and hammer remove pin #3 from the jib assembly.
6. Supporting the slave cylinder, remove the hardware from pin #4. Using a suitable brass drift and hammer remove pin #4 from the fly boom.
7. Tag and disconnect hydraulic lines to the slave leveling cylinder. Use a suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports. Remove the slave cylinder.




Figure 4-3. Removal of Components - Rotator and Leveling Cylinder

Installation

600S

1. Support the slave cylinder. Using a suitable brass drift and hammer, install pin #3 to the fly boom.
2. Install the rotator into fly boom and insert the pin#2 using a suitable brass drift and hammer.
3. Using a suitable brass drift and hammer, install pin #1 to the rotator.
4. Remove tag and reconnect the hydraulic lines to the rotator and the slave cylinder.

600SJ/660SJ

1. Telescope the fly section out approximately 20 in. (50.8 cm) to gain access to the slave leveling cylinder.
2. Support the slave cylinder. Using a suitable brass drift and hammer, install pin #3 to the jib assembly.
3. Install the rotator onto jib assembly and insert pin#3 using a suitable brass drift and hammer.
4. Using a suitable brass drift and hammer, install pin #1 to the rotator.
5. Remove tag and reconnect the hydraulic lines to the rotator and the slave cylinder.




Figure 4-4. Removal of Components - Rotator and Leveling Cylinder

4.3 MAIN BOOM POWERTRACK

Removal

1. Disconnect wiring harness connectors located in turntable.

NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID ENTRY OF CONTAMINANTS INTO SYSTEM.

2. Tag and disconnect hydraulic lines from connectors at boom assembly. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
3. Disconnect dual capacity indicator limit switch from side of boom section.
4. Remove hydraulic lines and electrical cables from Powertrack.
5. Using suitable lifting equipment, adequately support Powertrack weight along entire length.
6. Remove bolt #1 securing the push tube on the fly boom section.




Figure 4-5. Main Boom Powertrack Components

7. Remove bolt #2 securing the push tube on the mid boom section.
8. With Powertrack supported and using all applicable safety precautions, remove bolts #3, #4 and #5 securing rail to the base boom section. Remove Powertrack from boom section.

Installation

1. Using suitable lifting equipment, adequately support the Powertrack weight along entire length.
2. With powertrack supported and using all applicable safety precautions, install bolts #3 securing rail to the base boom.
3. Install bolts #2 that attaches rail to the push tube on the main boom section.
4. Install bolts #1 securing the push tube on the fly boom section.
5. Remove tag and reconnect all hydraulic lines and electrical cable from powertrack.
6. Reconnect dual capacity indicator limit switch from side of boom section.
7. Remove tag and reconnect hydraulic lines from connectors at boom assembly.




Figure 4-6. Main Boom Powertrack Components




Figure 4-7. Powertrack Installation Main Boom - Sheet 1 of 2




Figure 4-8. Powertrack Installation Main Boom - Sheet 2 of 2




Figure 4-9. Boom Powertrack Installation


4.4 POWERTRACK MAINTENANCE

One Piece Bracket Maintenance

1. Place the powertrack on a workbench.



2. Remove the screws from the bars on one side of the powertrack on the first link.




3. Remove the screws from the flat bar on the other side of the powertrack.




4. Pull up on the loose side of the round bar to allow the poly roller to slide off.





5. Slide the poly roller off of the round bar.



- 6.** Hold the round bar to remove the other screw.




- 7.** Slide the flat bar out.



- 8.** Remove the snap ring from one side of the bracket.



- 9.** Remove the snap ring from the other side of the bracket.



- 10.** Push down with slight pressure on the link and slide the bracket side up and over the extrusion on the link.



- 11.** Repeat the previous step on the other side.




SECTION 4 - BOOM & PLATFORM

12. Slide the bracket off of the powertrack.




Two Piece Bracket Maintenance

1. Loosen the screw.



2. Slide the roller off the bar.



3. Hold the bar tightly and remove the other screw.



4. Hold the flat bar and remove the screws.



5. Remove the snap rings and pins.



- 6. Remove the screws from the bar. Remove the snap ring and pin.



- 7. Slide the link out.




Snap Rings and Screws


NOTICE

WHEN PERFORMING MAINTENANCE ON THE POWERTRACK, MAKE SURE TO DISCARD AND REPLACE ALL OLD SCREWS.

Make sure screws are tight and installed properly.




Make sure that all snap rings are closed and seated.



An open snap ring is shown below.



A snap ring that is not seated is shown below.



A seated and closed snap ring is shown below.



10-24 x 0.812 button torx socket head with blue locking patch:

- Tighten to 45-50 in. lbs. (5-5.6 Nm).
- Use T-25 torx bit.
- Do not reuse this screw. After removing replace with a new one.

4.5 BOOM CLEANLINESS GUIDELINES

The following are guidelines for internal boom cleanliness for machines that are used in excessively dirty environments.

1. JLG recommends the use of the JLG Hostile Environment Package if available to keep the internal portions of a boom cleaner and to help prevent dirt and debris from entering the boom. This package reduces the amount of contamination which can enter the boom but does not eliminate the need for more frequent inspections and maintenance when used in these types of environments.
2. JLG recommends that you follow all guidelines for servicing your equipment in accordance with the instructions outlined in the JLG Service & Maintenance Manual for your machine. Periodic maintenance and inspection is vital to the proper operation of the machine. The frequency of service and maintenance must be increased as environment, severity and frequency of usage requires.
3. Debris and foreign matter inside of the boom can cause premature failure of components and should be removed. Methods to remove debris should always be done using all applicable safety precautions outlined in the JLG Service & Maintenance Manuals.
4. The first attempt to remove debris from inside the boom must be to utilize pressurized air to blow the debris toward the nearest exiting point from the boom. Make sure that all debris is removed before operating the machine.
5. If pressurized air cannot dislodge the debris, then water with mild solvents applied via a pressure washer can be used. Again the method is to wash the debris toward the nearest exiting point from the boom. Make sure that all debris is removed, that no "puddling" of water has occurred, and that the boom internal components are dry prior to operating the machine. Make sure you comply with all federal and local laws for disposing of the wash water and debris.
6. If neither pressurized air nor washing of the boom dislodges and removes the debris, then disassemble the boom in accordance to the instructions outlined in the JLG Service & Maintenance Manual to remove the debris.

4.6 MAIN BOOM ASSEMBLY


Removal

1. Using suitable lifting equipment, adequately support boom assembly weight along entire length.

NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID ENTRY OF CONTAMINANTS INTO SYSTEM.


2. Tag and disconnect hydraulic lines from telescope cylinder. Use a suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
3. Use adequate support for the main boom lift cylinder.
4. Using a suitable brass drift and hammer, remove hardware securing the main boom lift cylinder rod end pin to the base boom section. Remove the main boom lift cylinder pin from base boom. Retract the main boom lift cylinder by using the auxiliary power switch.




5. Using an adequate supporting device, support the master cylinder so it doesn't fall when the retaining pins are removed.

NOTE: The master cylinder weighs approximately 39.7 lbs. (18 kg).

6. Using a suitable brass drift and hammer, remove hardware securing the master cylinder rod end pin to the base boom section. Remove the master cylinder pin from base boom.




7. Using a suitable brass drift and hammer, remove hardware securing the main boom section to the turntable.



SECTION 4 - BOOM & PLATFORM

- Using a suitable brass drift and hammer, remove hardware securing the push bar and cover pin to the turntable.




- Using all applicable safety precautions, carefully lift boom assembly clear of turntable and lower to ground or suitably supported work surface.

NOTE: The main boom alone weighs approximately 2661 lbs. (1207 kg). Including the slave cylinder, rotator, and platform support the assembly weighs approximately 2907 lbs (1319 kg).


Boom Disassembly

NOTE: The following procedure assumes the boom is removed from the machine.


- Remove hardware securing the cover from the top of main boom.



- Remove hardware securing the push bar to aft end of the telescope cylinder, then remove pin from cylinder.



- Remove hardware securing the cover plate on the bottom front of the base boom section.




NOTE: Do not allow wire rope to rotate. This may damage the wire rope.

4. Clamp both threaded ends of wire rope to prevent rotation.


NOTE: Do not clamp on threads. Remove jam nuts and nuts which secure the wire rope adjustments to the bottom front of the base boom section.

NOTE: Step 5 is only applicable to CE specification machines.


5. Remove the spring mounting plate, spring, and proximity switch from the aft end of the base section.




6. Remove hardware securing the wire rope adjustment block to aft end of the base boom section and remove the block.



7. Remove hardware securing the telescope cylinder and support wear pad.



8. Remove the four bolts, shims, and mounting blocks that secure the telescope cylinder rod to the aft end of mid boom section.




NOTICE

WHEN REMOVING THE TELESCOPE CYLINDER FROM THE BOOM, IT MAY BE NECESSARY AT SOME POINT TO TURN THE CYLINDER SLIGHTLY IN ORDER TO CLEAR ASSEMBLIES MOUNTED WITHIN THE BOOM. CARE MUST BE TAKEN TO MOVE THE CYLINDER SLOWLY FROM THE BOOM. DAMAGE TO COMPONENTS MAY RESULT FROM FORCIBLE IMPACT WITH THESE ASSEMBLIES.


NOTE: The telescope cylinder weighs approximately 421.6 lbs. (191.2 kg).

SECTION 4 - BOOM & PLATFORM


9. Remove bolts securing wire rope attach bar to top of fly boom section.



10. Pull the telescope cylinder and wire ropes partially from aft end of the base boom section; secure the cylinder with a suitable sling and lifting device at approximately the center of gravity.



11. Carefully remove the telescope cylinder and sheave assembly. Place telescope cylinder on a suitable trestle.
- Remove hardware from the wear pads; remove wear pads from cylinder.
 - Remove hardware from the wire rope guard; remove guard from cylinder.
 - Remove hardware from the sheave pin; remove pin and sheave from cylinder.



This page left blank intentionally.

Go to Discount-Equipment.com to order your parts





Figure 4-10. Boom Assembly Cutaway - Sheet 1 of 2



- | | |
|-----------------------|------------------------------|
| 1. Base Boom | 9. Retract Cable |
| 2. Mid Boom | 10. Extend Cable Adjustment |
| 3. Fly Boom | 11. Retract Cable Adjustment |
| 4. Telescope Cylinder | 12. Proximity Switch |
| 5. Extend Sheave | 13. Wear Pad |
| 6. Retract Sheave | 14. Shims |
| 7. Sheave Block | 15. Wear Pad |
| 8. Extend Cable | |

Figure 4-11. Boom Assembly Cutaway - Sheet 2 of 2

SECTION 4 - BOOM & PLATFORM

12. Remove hardware which secures the wear pads to the front of base boom section; remove wear pads from the top, sides and bottom of the base boom section.

13. Using an overhead crane or suitable lifting device, remove mid and fly boom sections from base section.

NOTE: When removing mid and fly boom sections from base boom section, retract wire rope must be dragged along with boom sections.

14. Remove hardware which secures the wear pads to the aft end of mid boom section; remove the wear pads from the top, sides and bottom of the mid boom section.

15. Remove hardware which secures the sheave guards and sheave assemblies to mid boom section, remove sheave assemblies from mid boom section.


16. Remove hardware which secures the wear pads to the front of mid boom section; remove wear pads from the top, sides and bottom of the mid boom section.

17. Using an overhead crane or suitable lifting device, remove fly boom section from mid section.

NOTE: When removing fly boom section from mid boom section, retract wire rope must be dragged along with fly boom section.

18. Remove hardware which secures the wear pads to the aft end of fly boom section; remove wear pads from the top, sides and bottom of the fly boom section.

19. When removing wire rope from fly boom section, push the cable into fly boom. Route wire rope back through holes in the side of the fly boom section.



Inspection

NOTE: When inspecting pins and bearings Refer to the guidelines established in Section 2 - General.

1. Inspect all sheaves (extend and retract wire ropes and telescope cylinder) for excessive groove wear, burrs or other damage. Replace sheaves as necessary.

NOTE: To check the size, contour and amount of wear, a groove gauge is used. Replace the sheave if worn as shown in the following drawing.




Figure 4-12. Dimension of Sheaves When New

2. Inspect extend and retract wire rope sheave bearings for wear, scoring, or other damage, and for ovality.
3. Inspect extend wire rope and retract wire rope sheave pins for scoring, tapering and ovality. Replace pins as necessary.
4. Inspect telescope cylinder sheave pin for scoring, tapering and ovality. Replace pins as necessary.
5. Inspect boom pivot pin for wear, scoring, tapering and ovality, or other damage. Replace pins as necessary.
6. Inspect telescope cylinder attach point for scoring, tapering and ovality. Replace pins as necessary.
7. Inspect upper lift cylinder attach pin for wear, scoring, tapering and ovality, or other damage. Ensure pin surfaces are protected prior to installation. Replace pins as necessary.
8. Inspect inner diameter of boom pivot bushing for scoring, distortion, wear, or other damage. Replace bearing as necessary.
9. Inspect all wear pads for excessive wear or other damage. Replace pads when worn to within 1/8 inch (3.2 mm) of threaded insert.
10. Inspect extend and retract wire rope attach point components for cracks, stretching, distortion, or other damage. Replace components as necessary.

11. Inspect all threaded components for damage such as stretching, thread deformation, or twisting. Replace as necessary.
12. Inspect structural units of boom assembly for bending, cracking, separation of welds, or other damage. Replace boom sections as necessary.

Assembly

NOTE: When installing fly section wear pads, install same number and thickness of shims as were removed during disassembly.

1. Measure inside dimensions of the base and mid sections to determine the number of shims required for proper lift.
2. Measure inside dimensions of the mid section to determine the number of shims required for proper lift.
3. Install side, top and bottom wear pads to the rear end of fly section; shim evenly to the measurements of the inside of mid section.
4. Install retract wire ropes into rear end of fly section, route wire ropes through holes in side of fly boom section and pull into slot.




Figure 4-13. Routing Installation of Retract Wire Ropes

SECTION 4 - BOOM & PLATFORM


5. Install side, top and bottom wear pads to the rear end of mid section; shim evenly to the measurements of the inside of mid section.

NOTICE

WHEN ASSEMBLING BOOM SECTIONS, ENSURE THAT THE BOOM SLIDING TRAJECTORIES HAVE BEEN CLEARED OF CHAINS, TOOLS, AND OTHER OBSTRUCTIONS.

6. Shim the insides of the boom sections for a total of 1/16 inch (1.58 mm) clearance (if the action is centered, there will be 1/32 clearance on each side).
7. Slide fly boom section into the mid boom section. Shim boom, if necessary, for a total of 1/16 inch (1.58 mm) clearance.
8. Install wear pads into the forward position of the mid boom section. Shim boom, if necessary, for a total of 2/10 inch (5.08 mm) clearance.
9. Properly position the retraction wire rope sheaves assemblies at the rear end of the mid boom section; ensure all sheave-to-mounting block attachment holes align. Install the sheave pins and secure them with mounting hardware. Position retract wire ropes onto the sheaves.
10. Install sheave guards to rear end of mid boom section and secure with mounting hardware.
11. Slide mid boom section into the base boom section. Allow the retraction wire ropes to trail between the bottom surfaces of boom sections. Shim boom, if necessary, for a total of 1/16 inch (1.58 mm) clearance.
12. Install wear pads into the forward position of the base boom section. Shim boom, if necessary, for a total of 2/10 inch (5.08 mm) clearance.
13. Install sheave block to bottom of base boom section and adjust block so that retract wire ropes do not come into contact with boom surfaces.
14. Install wire rope threaded ends through attachment holes in the bottom of base boom section. Loosely install nuts and jam nuts onto the threaded ends of wire ropes.
15. Align the telescope cylinder barrel-to-sheave attachment point. Install extend sheave pin through the telescope cylinder barrel and sheave assembly; secure pin with mounting hardware.
16. Route extend wire ropes around extend sheave and secure wire ropes to the telescope cylinder.
17. Install extend wire rope mounting blocks to threaded ends of wire ropes. Loosely install nuts and jam nuts onto the threaded ends of wire ropes.

NOTE: When installing wire ropes, care must be taken not to twist or cross the wire ropes.



NOTE: For non CE specification machines, skip step 18 and proceed to step 19.

18. Install extend wire rope mounting blocks, proximity mounting plate and spring to threaded ends of wire ropes. Loosely install nuts and jam nuts onto the

threaded ends of wire ropes. Refer to Figure 4-14. Installing the Proximity Switch.




Figure 4-14. Proximity Switch Adjustment


SECTION 4 - BOOM & PLATFORM

19. Secure the sling and lifting device at the telescope cylinder's approximate center of gravity, and lift the cylinder to the aft end of the boom assembly.


NOTICE

WHEN INSERTING THE TELESCOPE CYLINDER INTO THE BOOM, IT MAY BE NECESSARY AT SOME POINT TO TURN THE CYLINDER SLIGHTLY IN ORDER TO CLEAR ASSEMBLIES MOUNTED WITHIN THE BOOM. CARE MUST BE TAKEN TO MOVE THE CYLINDER SLOWLY INTO POSITION. DAMAGE TO COMPONENTS MAY RESULT FROM FORCIBLE IMPACT WITH THESE ASSEMBLIES.


20. Align the cylinder with the slots at aft end of mid boom section, then secure cylinder with mounting hardware.




21. Align holes in aft end of the fly boom section with holes in wire rope mounting block, then secure with mounting hardware.




22. Install the four bolts, shims, and mounting blocks that secure the telescope cylinder rod to the aft end of mid boom section.




- 23.** Install hardware securing the telescope cylinder and support wear pad.



- 24.** Install hardware securing the wire rope adjustment block to aft end of the base boom section and remove the block.



- 25.** Install the spring mounting plate, spring, and proximity switch from the aft end of the base section.




- 26.** Clamp both threaded ends of wire rope to prevent rotation.

NOTE: Do not clamp on threads. Install jam nuts and nuts which secure the wire rope adjustments to the bottom front of the base boom section.


NOTE: Do not allow wire rope to rotate. This may damage the wire rope.

- 27.** Remove hardware securing the cover plate on the bottom front of the base boom section.




SECTION 4 - BOOM & PLATFORM

28. Align holes in rod end of the telescope cylinder with holes in push bar. Install push bar pin and secure with mounting hardware.



29. Install hardware securing the cover from the top of main boom.



30. Install the hydraulic lines and electrical cables, and the harnessing powertrack components as follows:

- Align holes in powertrack rail with attachment holes in side of the base boom section. Secure the rail with mounting hardware.
- Install powertrack to rail with mounting hardware.
- Attach push tube bracket to the side of the mid boom section with mounting hardware.

NOTE: Do not over tighten attach bolt on push tube bracket. It should pivot freely.

- Install slide block and wear pads to the powertrack rail with mounting hardware.
- Install powertrack to push tube with mounting hardware.
- Carefully feed the hoses and electrical cables through the aft end of the powertrack rail, powertrack and push tube.
- Ensure all hoses and cables are properly routed through the powertrack rail, powertrack and push tube. Tighten or install all clamping or securing apparatus to the hoses or cables, as necessary.
- Install powertrack cover and push tube rods with mounting hardware.






Figure 4-15. Reassembly of Components - Boom Powertrack Assembly

Installation

1. Using a suitable lifting device, position boom assembly on turntable so that the pivot holes of boom, push bar, cover, and turntable are aligned.
2. Install boom pivot pin, ensuring that location of hole in pin is aligned with attach point on turntable.
3. If necessary, gently tap pin into position with soft headed mallet. Secure pin mounting hardware..




4. Using a suitable brass drift and hammer, install hardware securing the main boom section to the turntable.




5. Using an adequate supporting device, align the master cylinder with the mounting holes on the boom and upright.
6. Using a suitable brass drift and hammer, install hardware securing the master cylinder rod end pin to the base boom section. Install the master cylinder pin into base boom.

NOTE: When installing the master cylinder rod end pin, insert the keeper hardware pin to prevent the pin from inserting too far.



7. Connect hydraulic lines to the master cylinder as tagged during removal.
8. Using an adequate supporting device, align the main boom lift cylinder with the mounting holes on the boom section.
9. Extend the main boom lift cylinder by using the auxiliary power switch. Using a suitable brass drift and hammer, install hardware secured to the main boom lift cylinder rod end pin into the base boom section.



10. Connect all wiring to the ground control box.
11. Connect all hydraulic lines running along side of boom assembly.

12. Adjust retract and extend cables to the proper torque. Refer to Section 4.10, Boom Rope Torquing Procedure for boom cable torque procedures.
13. Using all applicable safety precautions, operate machine systems and raise and extend boom fully, noting the performance of the extension cycle.
14. Retract and lower boom, noting the performance of the retraction cycle.

4.7 ARTICULATING JIB BOOM

Removal

1. For platform/support removal see platform/support removal diagram. See Section 4.1, Platform.
2. Position the articulating jib boom level with ground.
3. Remove mounting hardware from slave leveling cylinder pin #1. Using a suitable brass drift and hammer, remove the cylinder pin from articulating jib boom.
4. Remove mounting hardware from articulating jib boom pivot pin #2. Using a suitable brass drift and hammer, remove the pivot pin from boom assembly.

Disassembly

1. Remove mounting hardware from articulating jib boom pivot pins #3 and #4. Using a suitable brass drift and hammer, remove the pins from articulating jib boom pivot weldment.
2. Remove mounting hardware from rotator support pins #5 and #6. Using a suitable brass drift and hammer, remove the pins from rotator support.
3. Remove mounting hardware from lift cylinder pin #7. Using a suitable brass drift and hammer, remove the cylinder pin from articulating jib boom.




Figure 4-16. Location of Components - Articulating Jib Boom

Inspection

NOTE: When inspecting pins and bearings refer to Section 2 - General.

1. Inspect articulating fly boom pivot pin for wear, scoring, tapering and ovality, or other damage. Replace pins as necessary.
2. Inspect articulating fly boom pivot attach points for scoring, tapering and ovality, or other damage. Replace pins as necessary.
3. Inspect inner diameter of articulating fly boom pivot bearings for scoring, distortion, wear, or other damage. Replace bearings as necessary.
4. Inspect lift cylinder attach pin for wear, scoring, tapering and ovality, or other damage. Ensure pin surfaces are protected prior to installation. Replace pins as necessary.
5. Inspect inner diameter of rotator attach point bearings for scoring, distortion, wear, or other damage. Replace bearing as necessary.
6. Inspect all threaded components for damage such as stretching, thread deformation, or twisting. Replace as necessary.
7. Inspect structural units of articulating jib boom assembly for bending, cracking, separation of welds, or other damage. Replace boom sections as necessary.

Assembly

1. Align lift cylinder with attach holes in articulating jib boom. Using a soft head mallet, install cylinder pin #7 into articulating jib boom and secure with mounting hardware.
2. Align rotator support with attach hole in articulating jib boom. Using a soft head mallet, install rotator support pin #6 into articulating jib boom and secure with mounting hardware.
3. Align bottom tubes with attach holes in rotator support. Using a soft head mallet, install rotator support pin #5 into articulating jib boom and secure with mounting hardware.
4. Align articulating jib boom with attach hole in articulating jib boom pivot weldment. Using a soft head mallet, install rotator support pin #4 into articulating jib boom and secure with mounting hardware.
5. Align bottom tubes with attach holes in articulating jib boom pivot weldment. Using a soft head mallet, install rotator support pin #3 into articulating jib boom pivot weldment and secure with mounting hardware.

Installation

1. Align articulating jib boom pivot weldment with attach holes in fly boom assembly. Using a soft head mallet, install pivot pin #2 into fly boom assembly and secure with mounting hardware.
2. Align the slave leveling cylinder with attach holes in articulating jib boom pivot weldment. Using a soft head mallet, install slave leveling cylinder pin #1 into articulating jib boom pivot weldment and secure with mounting hardware.




Figure 4-17. Location of Components - Articulating Jib Boom

4.8 LIMIT SWITCHES AND CAM VALVE ADJUSTMENT

Adjust switches and cam valve as shown in Figure 4-18., Horizontal Limit and Dual Capacity Limit Switches Adjustments and Figure 4-19., Transport Switch Adjustments - CE Machines Only.




Figure 4-18. Horizontal Limit and Dual Capacity Limit Switches Adjustments




Figure 4-19. Transport Switch Adjustments - CE Machines Only

4.9 PLATFORM

Platform Sections Replacement

The platform is made up of five sections: floor, right side, left side, back (console box mounting) and gate. The sections are secured with huck magna grip fastener and collars. Replace damaged platform sections as follows:

1. Support the huck collar with a sledge hammer or other suitable support.
2. Using a hammer and chisel, remove the collar from the fastener as shown in the diagram below.





Figure 4-20. Platform Section Replacement

3. When installing new section of platform replace huck fasteners with 1/4 x 20 NC x 2 1/4 in. grade 5 bolts, flatwashers and locknuts.
4. When installing a new gate to platform, replace rivets with 1/4 x 20 NC x 2 in. grade 5 bolts, flatwashers and locknuts.

4.10 BOOM ROPE TORQUING PROCEDURE

Torque Procedures

1. Position boom in fully down and fully retracted position.



2. Clamp both threaded ends of wire rope to prevent rotation.

NOTE: Do not clamp on threads.




Figure 4-21. Clamping Wire Ropes

3. Install adjusting nuts (or remove nylon collar locknut if re-adjusting) to both retract and extend wire ropes.
4. Torque retract adjusting nuts (platform end) to 15 ft. lbs. (20 Nm) alternating between the two wire ropes and keeping approximately the same amount of thread beyond the adjusting nut.

NOTE: Do not allow wire rope to rotate. This may damage the wire rope.

5. Repeat the torque procedure in step #4 to the extend wire ropes (turntable end).
6. Extend the boom 2 - 3 feet using the telescope function. Repeat step #4.

7. Retract the boom 1 - 2 feet using the telescope function. Do not bottom out telescope cylinder. Repeat step #5.
8. Extend the boom approximately 2 - 3 feet again and check torque on the retract wire ropes.
9. Retract the boom without bottoming out telescope cylinder and check torque on the extend wire ropes.

NOTE: Step #8 and #9 may need to be repeated to equalize the torque on all 4 wire ropes.

10. After all wire ropes have been properly torqued, install nylon collar locknut. Remove all clamping devices and install all cover and guards. Check the boom for proper function.

4.11 WEAR PADS




Figure 4-22. Location and Thickness of Wear Pads

Main Boom

1. Shim up wear pads to within 1/32 in. (0.76 mm) tolerance between wear pad and adjacent surface.
2. Replace wear pads when worn within 1/16 in. (1.59 mm) and 1/8 inch (3.18 mm) - B, C, D of threaded insert. See Location and Thickness Of Wear Pads.
3. Adjusting wear pads, removing or adding shims, bolt length must also be changed.
 - a. When adding shims, longer bolts must be used to ensure proper thread engagement in insert.
 - b. When shims are removed, shorter bolts must be used so bolt does not protrude from insert and come into contact with boom surface.

4.12 WIRE ROPE


Each day before using the machine:

1. Raise the main boom to approximately horizontal.
2. Extend and retract the boom sections.
3. Check for delayed movement of the fly section, which indicates loose wire ropes.

Inspection


NOTE: The pictures in this paragraph are just samples to show the replacement criteria of the rope.

1. Inspect ropes for broken wires, particularly valley wire breaks and breaks at end terminations.




Flexing a wire rope can often expose broken wires hidden in valleys between strands.

2. Inspect ropes for corrosion.
3. Inspect ropes for kinks or abuse.



A kink is caused by pulling down a loop in a slack line during improper handling, installation, or operation.

4. Inspect sheaves for condition of bearings/pins. (See Dimension Of Sheaves for proper dimension).
5. Inspect sheaves for condition of flanges. (See Dimension Of Sheaves for proper dimension).
6. Inspect sheaves with a groove wearout gauge for excessive wear.



Observe the groove so that it may be clearly seen whether the contour of the gauge matches the contour of the bottom of the groove.

7. Ropes passing inspection should be lubricated with wire rope lubricant before reassembly.

Three Month Inspection

1. Remove boom covers and visually (with flashlight) inspect the ropes for rust, broken wires, frays, abuse, or any signs of abnormalities.
2. Check rope tension by deflecting the ropes by hand, properly tensioned ropes should have little or no movement.

12 Year or 7000 Hour Inspection

1. Mandatory wire rope and sheave replacement.

Additional inspection required if:

- a. Machine is exposed to hostile environment or conditions.
- b. Erratic boom operation or unusual noise exists.
- c. Machine is idle for an extended period.
- d. Boom is overloaded or sustained a shock load.
- e. Boom exposed to electrical arc...wires may be fused internally.

Additional Replacement Criteria

1. Sheaves and wire rope must be replaced as sets.
2. Rusted or corroded wire ropes.
3. Kinked, "bird caged", or crushed ropes.
4. Ropes at end of adjustment range.
5. Sheaves failing wearout gage inspection.
6. Ropes with 6 total broken wires in one rope lay, 3 in one strand in one rope lay, 1 valley break, or 1 break at any end termination.

4.13 ROTATOR ASSEMBLY

Theory of Operation


The rotary actuator is a simple mechanism that uses the sliding spline operating concept to convert axial piston motion into powerful shaft rotation. Each actuator is composed of a housing with integrated gear ring (1) and only two moving parts: the central shaft with integrated bearing tube and mounting flange (2), and the annular piston sleeve (3). Helical spline teeth machined on the shaft engage matching splines on the inside diameter of the piston. The outside diameter of the piston carries a second set of splines, of opposite hand, which engage with matching splines in the housing. As hydraulic pressure is applied, the piston is displaced axially within the housing similar to the operation of a hydraulic cylinder while the splines cause the shaft to rotate. When the control valve is closed, oil is trapped inside the housing, preventing piston movement and locking the shaft in position.

The shaft is supported radially by the large main radial bearing and the lower radial bearing. Axially, the shaft is separated from the housing by the main and lower thrust washers. The end cap is adjusted for axial clearance and locked in position by set screws or pins.

The actuators are equipped with factory installed counterbalance valves, which performs four major functions.

- Protects the actuator in the event of overload
- Enables the actuator to hold position without drifting when external loads are applied
- Reduces hydraulic backlash by pressuring the hydraulic fluid

Provides a constant controlled rate of rotation in over-center load conditions.



Required Tools

Upon assembly and disassembly of the actuator there are basic tools required. The tools and their intended functions are as follows:



1. PIPE VISE
2. HEX WRENCH - Removal and replacement of port plugs and setscrews.
3. ASSORTED SCREWS
4. SAFETY GLASSES
5. END CAP REMOVAL TOOLS (provided with Helac seal kit).
6. DRILL
7. FLASHLIGHT - Helps to locate and examine timing marks, component failure and overall condition.
8. RUBBER MALLETT - Removal and installation of shaft and piston sleeve assembly.
9. PLASTIC MANDREL
10. PRY BAR - Removal of end cap and manual rotation of shaft.
11. FELT MARKER - Highlights the timing marks and outline troubled areas.
12. T-HANDLE SCREW EXTRACTOR
13. HEX WRENCH SET - Removal and replacement of port plugs and setscrews (106 & 110).
14. SEAL TOOLS - Removal and installation of seals and wear guides. Directions to make a seal tool are provided below Making a Seal Tool.
15. PUNCH
16. DOWEL PINS - Removal and installation of end cap.

Making a Seal Tool

The seal tool is merely a customized standard flat head screwdriver.

CAUTION

TO AVOID INJURY BE CAREFUL WHILE HANDLING THE HOT SCREWDRIVER.


1. Heat the flat end with a torch until it glows.
2. Secure the heated end of the screwdriver in a vise and bend the heated end to a slight radius.
3. Round off all sharp edges of the heated to a polished finish. The tool may be modified slightly to your own personal preference. To avoid injury be careful while handling the hot screwdriver.




Before Disassembly

Inspect the actuator for corrosion prior to disassembly. Severe corrosion can make it difficult to remove the lock pins (109) and unthread the end cap (04). If corrosion is evident, soak the lock pins and end cap with penetrating oil for several hours before disassembly.


Disassembly is considerably easier if the actuator is firmly secured to the work bench. A pipe vise or mounting fixture work well.





- | | | |
|------------------|------------------|---------------------------|
| 1. Housing | 200. T-Seal | 302. Wear Guide |
| 2. Shaft | 202. T-Seal | 304. Thrust Washer |
| 3. Piston Sleeve | 204. O-ring | 304.1. Wiper Seal |
| 4. End Cap | 205. Cup Seal | 401. Counterbalance Valve |
| 109. Lock Pin | 207. Backup Ring | 400. Stop Tube |
| 113. Cap Screw | | |

Figure 4-23. Rotary Actuator (Exploded View)



- | | | |
|--------------------------|------------------|---------------------------|
| 1. Housing | 109. Lock Pin | 302. WearGuide |
| 2. Shaft | 113. Cap Screw | 304. Thrust Washer |
| 3. Piston Sleeve | 200. T-Seal | 304.1. Wiper Seal |
| 4. End Cap | 202. T-Seal | 400. Stop Tube (Optional) |
| 103.1. Screw (Optional) | 204. O-ring | 420.1. Bushing |
| 103.2. Washer (Optional) | 205. Cup Seal | 420.2. Bushing (Optional) |
| 106.1. Port Plug | 207. Backup Ring | 421.1. Bushing (Optional) |
| 106.2. Port Plug | | |

Figure 4-24. Rotary Actuator (Cutaway View)

Disassembly

CAUTION

TO AVOID INJURY OR DAMAGE TO PRODUCT: SECURE PRODUCT TO SLOTTED TABLE OR VISE.

CAUTION

SPRAYING FLUIDS. CONTENT UNDER PRESSURE. WEAR APPROVED EYE PROTECTION. USE CAUTION WHEN REMOVING PORT PLUGS AND FITTINGS.

NOTICE

MAKE SURE WORK AREA IS CLEAN.

1. Remove port plugs (106.1 & 106.2) and drain oil. Inspect oil for signs of contamination, i.e. water, metal shavings.
2. Remove the cap screws (113) over end cap lock pins (109).



3. Using a 1/8 in. (3.18 mm) drill bit, drill a hole in the center of each lock pin to a depth of approximately 3/16 in. (4.76 mm).



4. Remove the lock pins using an "Easy Out" (a size #2 is shown).

NOTE: If the pin will not come out with the "Easy Out", use 5/16 in. drill bit to a depth of 1/2 in. (12.7 mm) to drill out the entire pin. Do not drill deeper than 1/2 in. (12.7 mm).



5. Install the end cap (4) removal tools provided with the Helac seal kit.



SECTION 4 - BOOM & PLATFORM

- Using a metal bar, or similar tool, unscrew the end cap (4) by turning it counter clockwise.





- Remove the end cap (4) and set aside for later inspection.



- Remove the stop tube if equipped with one. The stop tube is an available option to limit the rotation of the actuator.



- Every actuator has timing marks for proper engagement.



- Prior to removing the shaft (2), use a felt marker to clearly indicate the timing marks between shaft and piston. This will greatly simplify timing during assembly.




- 11.** Remove the shaft (2). It may be necessary to strike the threaded end of the shaft with a rubber mallet.



- 12.** Before removing the piston (3), mark the housing (1) ring gear in relation to the piston O.D. gear. There should now be timing marks on the housing (1) ring gear, the piston (3) and the shaft (2).



- 13.** To remove the piston (3) use a rubber mallet and a plastic mandrel so the piston is not damaged.



- 14.** At the point when the piston gear teeth come out of engagement with the housing gear teeth, mark the piston and housing with a marker as shown.



- 15.** Remove the o-ring (204) and backup ring (207) from end cap (4) and set aside for inspection.




- 16.** Remove the wear guides (302) from the end cap (4) and shaft (2).



SECTION 4 - BOOM & PLATFORM

17. To remove the main pressure seals (205), it is easiest to cut them using a sharp razor blade being careful not to damage the seal groove.



18. Remove the thrust washers (304) from the end cap (4) and shaft (2).



19. Remove the wiper seal (304.1) from its groove in the end cap (4) and shaft (2).



20. Remove the piston O.D. seal (202) from the piston.



21. Remove the piston I.D. seal (200). You may now proceed to the inspection process.



Inspection

NOTICE

SMALL OR MINOR SURFACE SCRATCHES CAN BE CAREFULLY POLISHED.

1. Clean all parts in a solvent tank and dry with compressed air prior to inspecting. Carefully inspect all critical areas for any surface finish abnormalities: Seal grooves, bearing grooves, thrust surfaces, rod surface, housing bore and gear teeth.



2. Inspect the thrust washers (304) for rough or worn edges and surfaces. Measure its thickness to make sure it is within specifications (Not less than 0.092 in. or 2.34 mm).



3. Inspect the wear guide condition and measure thickness (not less than 0.123 in. or 3.12 mm).



Assembly

1. Gather all the components and tools into one location prior to re-assembly. Use the cut away drawing to reference the seal orientations.



SECTION 4 - BOOM & PLATFORM

2. Install the thrust washer (304) onto shaft (2) and end cap (4).



3. Install the wiper seal (304.1/green O-ring) into the groove on the shaft (2) and end cap (4) around the outside edge of the thrust washer (304).



4. Using a seal tool install the main pressure seal (205) onto shaft (2) and end cap (4). Use the seal tool in a circular motion.



5. Install the wear guide (302) on the end cap (4) and shaft (2).



6. Install the O-ring (204) and backup ring (207) into the inner seal groove on the end cap (4).



7. Install the inner T-seal (200) into the piston (3) using a circular motion.

Install the outer T-seal (202) by stretching it around the groove in a circular motion.

Each T-seal has 2 backup rings (see drawing for orientation).



Beginning with the inner seal (200) insert one end of backup ring in the lower groove and feed the rest in using a circular motion. Make sure the wedged ends overlap correctly.

Repeat this step for the outer seal (202).



8. Insert the piston (3) into the housing (1) as shown, until the outer piston seal (202) is touching inside the housing bore.



SECTION 4 - BOOM & PLATFORM

9. Looking from the angle shown, rotate the piston (3) until the marks you put on the piston and the housing (1) during disassembly line up as shown. Using a rubber mallet, tap the piston into the housing up to the point where the gear teeth meet.



10. Looking from the opposite end of the housing (1) you can see if your timing marks are lining up. When they do, tap the piston (3) in until the gear teeth mesh together. Tap the piston into the housing the rest of the way until it bottoms out.



11. Install the shaft (2) into the piston (3). Be careful not to damage the seals. Do not engage the piston gear teeth yet.




12. Looking from the view shown, use the existing timing marks to line up the gear teeth on the shaft (2) with the gear teeth on the inside of the piston (3). Now tap the flange end of the shaft with a rubber mallet until the gear teeth engage.



13. Install two bolts in the threaded holes in the flange. Using a bar, rotate the shaft in a clockwise direction until the wear guides are seated inside the housing bore.

NOTICE

AS THE SHAFT IS ROTATED, BE CAREFUL NOT TO DISENGAGE THE PISTON AND HOUSE GEARING.



14. Install the stop tube (400) onto the shaft end, if equipped. Stop tube is an available option to limit the rotation of an actuator.



15. Coat the threads on the end of the shaft with anti-seize grease to prevent galling.




16. Thread the end cap (4) onto the shaft (2) end. Make sure the wear guide remains in place on the end cap as it is threaded into the housing (1).



SECTION 4 - BOOM & PLATFORM

- 17.** Tighten the end cap (4). In most cases the original holes for the lock pins will line up.



- 19.** Insert the set screws (113) over the lock pins. Tighten them to 25 in. lbs. (2.825 Nm).



- 18.** Place the lock pins (109) provided in the Helac seal kit in the holes with the dimple side up. Then, using a punch, tap the lock pins to the bottom of the hole.



Go to Discount-Equipment.com to order your parts

Installing Counterbalance Valve

Refer to Figure 4-25., Rotator Counterbalance Valve.

1. Make sure the surface of the actuator is clean, free of any contamination and foreign debris including old JLG Threadlocker P/N 0100011.
2. Make sure the new valve has the O-rings in the counterbores of the valve to seal it to the actuator housing.
3. The bolts that come with the valve are grade 8 bolts. New bolts should be installed with a new valve. JLG Threadlocker P/N 0100011 should be applied to the shank of the three bolts at the time of installation.
4. Torque the 1/4 in. bolts 110-120 in. lbs. (12.4-13.5 Nm). Do not torque over 125 in. lbs. (14.1 Nm). Torque the 5/16 in. bolts to 140 in. lbs. (15.8 Nm). Do not torque over 145 in. lbs. (16.3 Nm).
5. Make sure the valve is seated against the housing valve flat. If it is raised up on any side or corner, remove the valve to determine what the obstruction is. If possible, test this using a hydraulic hand pump or electric test.




Figure 4-25. Rotator Counterbalance Valve

Greasing Thrust Washers


1. After the actuator is assembled but before it is put into service, the thrust washer area must be packed with Lithium grease.
2. There are two grease ports located on both the shaft flange and the end cap. They are plugged with cap screws (113) or set screws. Remove the grease port screws from the shaft flange and end cap. (See exploded view).



NOTICE

IF A HYDRAULIC TEST BENCH IS NOT AVAILABLE, THE ACTUATOR CAN BE ROTATED BY HAND, OPEN THE PRESSURE PORTS AND USE A PRY BAR WITH CAP SCREWS INSERTED INTO THE SHAFT FLANGE TO TURN THE SHAFT IN THE DESIRED DIRECTION.

3. Insert the tip of a grease gun into one port and apply grease to the shaft flange. Continue applying until grease flows from the opposite port. Cycle the actuator five times and apply grease again. Repeat this process on the end cap. Insert the cap screws into the grease ports and tighten to 25 in.lbs. (2.8 Nm).



Testing the Actuator

If the equipment is available, the actuator should be tested on a hydraulic test bench. The breakaway pressure — the pressure at which the shaft begins to rotate — should be approximately 400 psi (28 bar). Cycle the actuator at least 25 times at 3000 psi (210 bar) pressure. After the 25 rotations, increase the pressure to 4500 psi (315 bar) to check for leaks and cracks. Perform the test again at the end of the rotation in the opposite direction.

TESTING THE ACTUATOR FOR INTERNAL LEAKAGE

If the actuator is equipped with a counterbalance valve, plug the valve ports. Connect the hydraulic lines to the housing ports. Bleed all air from the actuator (see Installation and Bleeding) Rotate the shaft to the end of rotation at 3000 psi (210 bar) and maintain pressure. Remove the hydraulic line from the non-pressurized side.

Continuous oil flow from the open housing port indicates internal leakage across the piston. Replace the line and rotate the shaft to the end of rotation in the opposite direction. Repeat the test procedure outlined above for the other port. If there is an internal leak, disassemble, inspect and repair.

Installation and Bleeding


After installation of the actuator on the equipment, it is important that all safety devices such as tie rods or safety cables are properly reattached.

To purge air from the hydraulic lines, connect them together to create a closed loop and pump hydraulic fluid through them. Review the hydraulic schematic to determine which hydraulic lines to connect. The linear feet and inside diameter of the hydraulic supply lines together with pump capacity will determine the amount of pumping time required to fully purge the hydraulic system.

Bleeding may be necessary if excessive backlash is exhibited after the actuator is connected to the hydraulic system. The following steps are recommended when a minimum of two gallons (8 liters) is purged.

1. Connect a 3/16 in. inside diameter x 5/16 in. outside diameter x 5 foot clear, vinyl drain tube to each of the two bleed nipples. Secure them with hose clamps. Place the vinyl tubes in a clean 5-gallon container to collect the purged oil. The oil can be returned to the reservoir after this procedure is completed.

2. With an operator in the platform, open both bleed nipples 1/4 turn. Hydraulically rotate the platform to the end of rotation (either clockwise or counterclockwise), and maintain hydraulic pressure. Oil with small air bubbles will be seen flowing through the tubes. Allow a 1/2 gallon of fluid to be purged from the actuator.
3. Keep the fittings open and rotate the platform in the opposite direction to the end position. Maintain hydraulic pressure until an additional 1/4 gallon of fluid is pumped into the container.
4. Repeat steps 2 & 3. After the last 1/2 gallon is purged, close both bleed nipples before rotating away from the end position.



Troubleshooting

Table 4-1. Troubleshooting

Problem	Cause	Solution
1. Shaft rotates slowly or not at all	<p>a. Insufficient torque output</p> <p>b. Low rate of fluid flow</p> <p>c. Control or counterbalance valve has internal leak</p> <p>d. Piston and/or shaft seal leak</p> <p>e. Corrosion build-up on the thrust surfaces</p> <p>f. Swollen seals and composite bearings caused by incompatible hydraulic fluid (Standard actuators only)</p>	<p>a. Verify correct operating pressure. Do not exceed OEM's pressure specifications. Load may be above maximum capacity of the actuator.</p> <p>b. Inspect ports for obstructions and hydraulic lines for restrictions and leaks.</p> <p>c. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports.</p> <p>d. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test.</p> <p>e. Re-build the actuator. Remove all rust then polish. Replacement parts may be needed.</p> <p>f. Re-build the actuator. Use fluid that is compatible with seals and bearings.</p>
2. Operation is erratic or not responsive	a. Air in actuator	a. Purge air from actuator. See bleeding procedures.
3. Shaft will not fully rotate	<p>a. Twisted or chipped gear teeth overload conditions</p> <p>b. Port fittings are obstructing the piston during stroke</p>	<p>a. Check for gear binding. Actuator may not be able to be rebuilt and may need to be replaced. Damage could be a result of overload or shock.</p> <p>b. Check thread length of port fittings. Fittings should during stroke not reach inside the housing bore.</p>
4. Selected position cannot be maintained	<p>a. Control or counterbalance valve has internal leak</p> <p>b. Piston and/or shaft seal leak</p> <p>c. Air in actuator</p>	<p>a. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports.</p> <p>b. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test.</p> <p>c. Purge air from actuator. See bleeding procedures</p>

4.14 FOOT SWITCH ADJUSTMENT

Adjust so that functions will operate when pedal is at center of travel. If switch operates within last 1/4 in. (6.35 mm) of travel, top or bottom, it should be adjusted.

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 5. BASIC HYDRAULICS INFORMATION & SCHEMATICS

5.1 LUBRICATING O-RINGS IN THE HYDRAULIC SYSTEM


When assembling connectors in the hydraulic that use o-ring fittings, it is necessary to lubricate all fittings with hydraulic oil prior to assembly. To lubricate the fittings, use one of the following procedures.

NOTE: All O-ring fittings must be pre-lubricated with hydraulic oil prior to assembly.

Cup and Brush

The following is needed to correctly oil the o-ring in this manner:

- A small container for hydraulic oil
- Small paint brush



1. Hold the fitting in one hand while using the brush with the other hand to dip into the container. Remove excess hydraulic oil from the brush so an even film of oil is applied on the o-ring.



2. Holding the fitting over the hydraulic oil container, brush an even film of oil around the entire o-ring in the fitting, making sure the entire o-ring is completely saturated.



3. Turn the o-ring on the other side of the fitting and repeat the previous step, ensuring the entire o-ring is coated with hydraulic oil.



Dip Method

NOTE: This method works best with Face Seal o-rings, but will work for all o-ring fitting types.

The following is needed to correctly oil the o-ring in this manner:

- A small leak proof container
 - Sponge cut to fit inside the container
 - A small amount of hydraulic oil to saturate the sponge.
1. Place the sponge inside the container and add hydraulic oil to the sponge until it is fully saturated.
 2. Dip the fitting into the sponge using firm pressure. Upon lifting the fitting, a small droplet will form and drip from the bottom of the fitting. This should signify an even coating of oil on the fitting.



3. O-ring Boss type fittings will require more pressure in able to immerse more of the fitting into the saturated sponge. This will also cause more oil to be dispersed from the sponge.



Spray Method

This method requires a pump or trigger spray bottle.

1. Fill the spray bottle with hydraulic oil.
2. Hold the fitting over a suitable catch can.
3. Spray the entire o-ring surface with a medium coat of oil.



Brush-on Method

This method requires a sealed bottle brush.

1. Fill the bottle with hydraulic oil.
2. Using slight pressure to the body of the spray bottle, invert the bottle so the brush end is in the downward position.
3. Brush hydraulic oil on the entire o-ring, applying an even coat of oil.



5.2 CYLINDERS - THEORY OF OPERATION

Systems Incorporating Double Acting Cylinders

Cylinders are of the double acting type. Systems incorporating double acting cylinders are as follows: Slave Level, Master Level, Lift, Telescope, Articulating Jib Boom Lift, Axle Lockout and Steer. A double acting cylinder is one that requires oil flow to operate the cylinder rod in both directions. Directing oil (by actuating the corresponding control valve to the piston side of the cylinder) forces the piston to travel toward the rod end of the barrel, extending the cylinder rod (piston attached to rod). When the oil flow is stopped, movement of rod will stop. By directing oil to the rod side of the cylinder, the piston will be forced in the opposite direction and the cylinder rod will retract.

Systems Incorporating Holding Valves

Holding valves are used in the Lift, Telescope, Lockout, Slave Level and Articulating Jib Boom Lift circuits to prevent retraction of the cylinder rod should a hydraulic line rupture or a leak develop between the cylinder and its related control valve.

5.3 CYLINDER CHECKING PROCEDURE

NOTE: *Cylinder check must be performed anytime a system component is replaced or when an improper system operation is suspected.*

Cylinders Without Counterbalance Valves - Master Cylinder and Steer Cylinder

1. Using all applicable safety precautions, activate engine and fully extend cylinder to be checked. Shut down engine.
2. Carefully disconnect hydraulic hoses from retract port of cylinder. There will be some initial weeping of hydraulic fluid which can be caught in a suitable container. After the initial discharge, there should be no further drainage from the retract port.
3. Activate engine and extend cylinder.
4. If cylinder retract port leakage is less than 6-8 drops per minute, carefully reconnect hose to port and retract cylinder. If leakage continues at a rate of 6-8 drops per minute or more, cylinder repair must be made.
5. With cylinder fully retracted, shut down engine and carefully disconnect hydraulic hose from cylinder extend port.
6. Activate engine and retract cylinder. Check extend port for leakage.

7. If extend port leakage is less than 6-8 drops per minute, carefully reconnect hose to extend port, then activate cylinder through one complete cycle and check for leaks. If leakage continues at a rate of 6-8 drops per minute or more, cylinder repairs must be made.

Cylinders With Single Counterbalance Valve

(Main Lift Cylinder)

NOTICE

OPERATE ALL FUNCTIONS FROM GROUND CONTROL STATION ONLY.

1. Using all applicable safety precautions, activate hydraulic system.

WARNING

WHEN WORKING ON THE MAIN LIFT CYLINDER, RAISE THE BOOM TO HORIZONTAL AND PLACE A BOOM PROP APPROXIMATELY 1 INCH (2.54 CM) BELOW THE MAIN BOOM. DO NOT WORK ON THE CYLINDER WITHOUT A SUITABLE PROP IN PLACE.

2. Shut down hydraulic system and allow machine to sit for 10-15 minutes. If machine is equipped with bang-bang or proportional control valves, turn IGNITION SWITCH to ON, move control switch or lever for applicable cylinder in each direction, then turn IGNITION SWITCH to OFF. If machine is equipped with hydraulic control valves, move control lever for applicable cylinder in each direction. This is done to relieve pressure in the hydraulic lines. Carefully remove hydraulic hoses from appropriate cylinder port block.
3. There will be initial weeping of hydraulic fluid, which can be caught in a suitable container. After the initial discharge, there should be no further leakage from the ports. If leakage continues at a rate of 6-8 drops per minute or more, the counterbalance valve is defective and must be replaced.
4. To check piston seals, carefully remove the counterbalance valve from the retract port. After initial discharge, there should be no further leakage from the ports. If leakage continues at a rate of 6-8 drops per minute or more, the counterbalance valve is defective and must be replaced.
5. If no repairs are necessary or when repairs have been made, replace counterbalance valve and carefully connect hydraulic hoses to cylinder port block.
6. If used, remove lifting device from upright or remove prop from below main boom, activate hydraulic system and run cylinder through one complete cycle to check for leaks.

Cylinders With Dual Counterbalance Valves

(Articulating Jib Boom Lift, Slave Level and Main Telescope.)

NOTICE

OPERATE ALL FUNCTIONS FROM GROUND CONTROL STATION ONLY.

1. Using all applicable safety precautions, activate hydraulic system.

WARNING

IF WORKING ON THE TOWER BOOM LIFT CYLINDER, RAISE TOWER BOOM HALFWAY, FULLY ELEVATE MAIN BOOM WITH TELESCOPE CYLINDER FULLY RETRACTED AND ATTACH AN OVERHEAD CRANE TO THE UPRIGHT FOR SUPPORT, LEAVING APPROXIMATELY 1 INCH (2.54 CM) OF SLACK IN CHAIN OR SLING FOR TEST PURPOSES. IF WORKING ON THE UPRIGHT LEVEL, RAISE THE TOWER BOOM HALFWAY, THEN RAISE MAIN BOOM TO HORIZONTAL AND POSITION A SUITABLE BOOM PROP APPROXIMATELY 1 INCH (2.54 CM) BELOW MAIN BOOM. IF WORKING ON THE PLATFORM LEVEL CYLINDER, STROKE PLATFORM LEVEL CYLINDER FORWARD UNTIL PLATFORM SITS AT A 45 DEGREES ANGLE.

2. Shut down hydraulic system and allow machine to sit for 10-15 minutes. If machine is equipped with bang-bang or proportional control valves, turn IGNITION SWITCH to ON, move control switch or lever for applicable cylinder in each direction, then turn IGNITION SWITCH to OFF. If machine is equipped with hydraulic control valves, move control lever for applicable cylinder in each direction. This is done to relieve pressure in the hydraulic lines. Carefully remove hydraulic hoses from appropriate cylinder port block.

3. There will be initial weeping of hydraulic fluid, which can be caught in a suitable container. After the initial discharge, there should be no further leakage from the ports. If leakage continues at a rate of 6-8 drops per minute or more, the counterbalance valve is defective and must be replaced.
4. To check piston seals, carefully remove the counterbalance valve from the retract port. After initial discharge, there should be no further leakage from the ports. If leakage occurs at a rate of 6-8 drops per minute or more, the piston seals are defective and must be replaced.
5. If no repairs are necessary or when repairs have been made, replace counterbalance valve and carefully connect hydraulic hoses to cylinder port block.
6. If used, remove lifting device from upright or remove prop from below main boom, activate hydraulic system and run cylinder through one complete cycle to check for leaks.

5.4 HYDRAULIC CYLINDERS

Axle Lockout Cylinder (USA Built Machines, SN 0300087000 through 0300089728)

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

⚠ WARNING

ROD CAN FALL OUT OF BARREL AND CAUSE INJURY OR DAMAGE TO THE EQUIPMENT. BE CAREFUL WHEN REMOVING AXLE CYLINDER. OPENING BLEED VALVE CAN CAUSE ROD TO FALL OUT OF BARREL.

1. Open bleeder valve. Rotate rod and remove from barrel.
2. Remove two wear rings, wiper seal and rod seal from grooves of barrel bore. Do not scratch barrel bore.
3. Remove counterbalance valve.

CLEANING AND INSPECTION

1. Inspect bore and rod for scoring, pitting, or excessive wear.
2. Remove minor surface blemishes with wet sandpaper. Pitting requires replacement of barrel and rod.
3. Clean all parts with approved solvent and dry with compressed air.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

NOTICE


WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.

1. Install two new wear rings, wiper seal and rod seal in barrel bore grooves. Make sure they are not twisted.
2. Lubricate rod bore with clean hydraulic fluid.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE ROD. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE ROD AND CYLINDER BARREL SURFACES.

3. Insert and push the rod into top of barrel bore, rotate to install the rod into barrel bore.
4. Install counterbalance valve. Torque to 30-35 ft. lbs. (40-47 Nm).
5. Bleed system.



- | | |
|--------------|-------------------------|
| 1. Barrel | 5. Wiper Seal |
| 2. Rod | 6. Bleeder Valve |
| 3. Wear Ring | 7. Counterbalance Valve |
| 4. Rod Seal | |

Figure 5-1. Axle Lockout Cylinder (USA Built Machines, SN 0300087000 through 0300089728)

Axle Lockout Cylinder (USA Built Machines SN 0300089729 through 0300171769 and China Built Machines, SN B300000100 through B300000969)

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

⚠ WARNING

ROD CAN FALL OUT OF BARREL AND CAUSE INJURY OR DAMAGE TO THE EQUIPMENT. BE CAREFUL WHEN REMOVING AXLE CYLINDER. OPENING BLEED VALVE CAN CAUSE ROD TO FALL OUT OF BARREL.

1. Remove plug and pilot piston from the barrel.
2. Open bleeder valve. Rotate rod and remove from barrel.
3. Remove two wear rings, wiper seal and rod seal from grooves of barrel bore. Do not scratch barrel bore.
4. Remove counterbalance valve.

CLEANING AND INSPECTION

1. Inspect bore and rod for scoring, pitting, or excessive wear.
2. Remove minor surface blemishes with wet sandpaper. Pitting requires replacement of barrel and rod.
3. Clean all parts with approved solvent and dry with compressed air.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

NOTICE


WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.

1. Install two new wear rings, wiper seal and rod seal in barrel bore grooves. Make sure they are not twisted.
2. Lubricate rod bore with clean hydraulic fluid.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE ROD. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE ROD AND CYLINDER BARREL SURFACES.

3. Insert and push the rod into top of barrel bore and rotate to install the rod into barrel bore.
4. Install counterbalance valve. Torque to 25-27 ft. lbs. (34-37 Nm).
5. Install plug and pilot piston into the barrel.
6. Bleed system.



1684465 J

- | | |
|-----------------|-------------------------|
| 1. Barrel | 6. Wiper Seal |
| 2. Rod | 7. Rod Seal |
| 3. Plug | 8. Bleeder Valve |
| 4. Pilot Piston | 9. Counterbalance Valve |
| 5. Wear Ring | |

Figure 5-2. Axle Lockout Cylinder (USA Built Machines, SN 0300089729 through 0300171769 and China Built Machines, SN B300000100 through B300000969)

Platform Level Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Remove counterbalance valves and fittings from the cylinder port block. Discard o-rings.
4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-3. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrows and remove capscrows from cylinder barrel.




Figure 5-4. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-5. Cylinder Rod Support

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS



- | | | | | |
|------------------|------------------------|--------------------|-----------------|-------------------------|
| 1. Barrel | 6. Tapered Bushing | 11. Washer Ring | 16. Wear Ring | 21. Conterbalance Valve |
| 2. Rod | 7. Spacer | 12. Hydrolock Seal | 17. O-Ring | 22. Plug |
| 3. Bushing | 8. Conterbalance Valve | 13. Guidelockring | 18. Backup Ring | 23. Capscrew |
| 4. Piston | 9. Plug | 14. O-ring | 19. Rod Seal | |
| 5. cylinder Head | 10. Capscrew | 15. Backup Ring | 20. Wiper Seal | |

Figure 5-6. Platform Level Cylinder

8. Using suitable support, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
9. Remove capscrews from drilled holes.
10. Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen on the piston.
11. Remove the bushing from the piston.




Figure 5-7. Tapered Bushing Removal

12. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
13. Remove and discard the piston o-ring, backup ring, hydrolock seals and guidelock rings.
14. Remove piston spacer from the rod.
15. Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-ring, backup ring, rod seal, wear ring and wiper seal.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
6. Inspect threaded portion of piston for damage. Dress threads as necessary.
7. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
8. Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
9. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
10. Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
11. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-8. Composite Bearing Installation

12. Inspect spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
13. If applicable, inspect port block fittings and holding valve. Replace as necessary.
14. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
15. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-9. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-10. Cylinder Head Seal Installation

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-11. Wiper Seal Installation

3. Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-12. Installation of Head Seal Kit

4. Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
5. Carefully slide the piston spacer on rod.
6. Using suitable support, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
7. Place a new o-ring and backup ring in the inner piston diameter groove.
8. Carefully thread the piston on the cylinder rod and hand tight, ensuring that the o-ring and backup ring are not damaged or dislodged.
9. Thread piston onto rod until it abuts the spacer end and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

10. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-13. Tapered Bushing Installation

11. Tighten the capscrews evenly and progressively in rotation to 5 ft. lbs. (7 Nm) for 600S and 9 ft. lbs. (12 Nm) for 600SJ and 660SJ.
12. After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4 in. in diameter) as follows:
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - b. Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-14. Seating the Tapered Bearing

13. Rotate the capscrews evenly and progressively in rotation to 5 ft. lbs. (7 Nm) for 600S and 9 ft. lbs. (12 Nm) for 600SJ and 660SJ.
14. Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-15. Hydrolock Piston Seal Installation

15. Place new hydrolock seals and guidelock rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-16. Piston Seal Kit Installation

16. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

17. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading hydrolock seals and guidelock rings are not damaged or dislodged.
18. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.




Figure 5-17. Rod Assembly Installation

19. Apply JLG Threadlocker P/N 0100011 to the socket head capscrews and secure the cylinder head gland using the washer ring and capscrews. Torque capscrews to 40 ft. lbs. (55 Nm).
20. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the re-installation of any holding valve or valves.
21. If applicable, install the counterbalance valves and fittings in the rod port block, using new o-rings as applicable. Torque valves to 50-55 ft. lbs. (68-75 Nm).

Jib Lift Cylinder (600SJ/660SJ)

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Remove the counterbalance holding valves and fittings from the cylinder port block. Discard o-rings.
4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-18. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-19. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-20. Cylinder Rod Support



- | | | | | |
|----------------|-------------------------|--------------------|-----------------|---------------|
| 1. Barrel | 6. Counterbalance Valve | 11. Spacer | 16. O-ring | 20. Wear Ring |
| 2. Head | 7. Plug | 12. Hydrolock Seal | 17. Backup Ring | 21. Capscrew |
| 3. Washer Ring | 8. Plug | 13. Guidelock Ring | 18. Rod Seal | 22. Bushing |
| 4. Capscrew | 9. Piston | 14. O-ring | 19. Wiper Seal | |
| 5. Rod | 10. Tapered Bushing | 15. Backup Ring | | |

Figure 5-21. Jib Lift Cylinder (600SJ/660SJ)

8. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
9. Remove capscrews from drilled holes.
10. Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen on the piston.
11. Remove the bushing from the piston.




Figure 5-22. Tapered Bushing Removal

12. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
13. Remove and discard the piston o-ring, hydrolock seals, guidelock rings and backup rings.
14. Remove piston spacer from the rod and discard the o-ring.
15. Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-ring, backup ring, rod seal, wear ring and wiper seal.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
6. Inspect threaded portion of piston for damage. Dress threads as necessary.
7. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
8. Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
9. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
10. Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
11. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-23. Composite Bearing Installation

12. Inspect spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
13. If applicable, inspect port block fittings and holding valve. Replace as necessary.
14. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
15. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-24. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-25. Cylinder Head Seal Installation

- Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-26. Wiper Seal Installation

- Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-27. Installation of Head Seal Kit

- Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper seal and rod seal are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
- Insert o-ring into spacer and carefully slide the piston spacer onto the rod.
- Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
- Place new o-rings and backup rings in the inner piston diameter groove.
- Carefully thread the piston on the cylinder rod and hand tight, ensuring that the o-rings and backup rings are not damaged or dislodged.
- Thread piston onto rod until it abuts the spacer end and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

- Install the capscrews in tapered bushing.
- Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-28. Tapered Bushing Installation

- Tighten the capscrews evenly and progressively in rotation to 5 ft. lbs. (7 Nm).
- After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4 in. in diameter) as follows:
 - Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-29. Seating the Tapered Bearing

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

14. Rotate the capscrews evenly and progressively in rotation to 5 ft. lbs. (7 Nm).
15. Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-30. Hydrolock Piston Seal Installation

16. Place new hydrolock seals and guidelock rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-31. Piston Seal Kit Installation

17. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

18. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading hydrolock seals and guidelock rings are not damaged or dislodged.
19. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.




Figure 5-32. Rod Assembly Installation

20. Apply JLG Threadlocker P/N 0100011 to the socket head capscrews and secure the cylinder head gland using the washer ring and capscrews. Torque capscrews to 20 ft. lbs. (27 Nm).
21. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves.
22. If applicable, install the counterbalance valves and fittings in the rod port block, using new o-rings as applicable. Torque valves to 50-55 ft. lbs. (68-75 Nm).

Main Boom Lift Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Remove the Counterbalance valve and fittings from the cylinder port block. Discard o-rings.
4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-33. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-34. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-35. Cylinder Rod Support



- | | | | | |
|--------------------|-------------------------|--------------------|-----------------|-----------------|
| 1. Barrel | 6. Spacer | 11. Guidelock Ring | 16. O-ring | 20. Washer Ring |
| 2. Rod | 7. Counterbalance Valve | 12. Hydrolock Seal | 17. Backup Ring | 21. Capscrew |
| 3. Head | 8. Plug | 13. O-ring | 18. Rod Seal | 22. Plug |
| 4. Piston | 9. Capscrew | 14. Backup Ring | 19. Wiper Seal | 23. Bushing |
| 5. Tapered Bushing | 10. Plug | 15. Wear Ring | | |

Figure 5-36. Main Boom Lift Cylinder

8. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
9. Remove capscrews from drilled holes.
10. Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen on the piston.
11. Remove the bushing from the piston.




Figure 5-37. Tapered Bushing Removal

12. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
13. Remove and discard the piston o-ring, hydrolock seals, guidelock rings and backup ring.
14. Remove the rod from the holding fixture. Remove capscrews and washer ring. Remove the cylinder head gland. Discard the o-ring, backup ring, rod seal, wear ring and wiper seal.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
6. Inspect threaded portion of piston for damage. Dress threads as necessary.
7. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
8. Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
9. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
10. Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
11. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-38. Composite Bearing Installation

12. Inspect spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
13. If applicable, inspect port block fittings and holding valve. Replace as necessary.
14. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
15. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-39. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-40. Cylinder Head Seal Installation

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-41. Wiper Seal Installation

3. Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-42. Installation of Head Seal Kit

4. Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper seal and rod seal are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
5. Carefully slide the piston spacer on the rod.
6. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
7. Place a new o-ring and backup ring in the inner piston diameter groove.
8. Carefully thread the piston on the cylinder rod and hand tight, ensuring that the o-ring and backup ring are not damaged or dislodged.
9. Thread piston onto until it abuts the spacer end and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

10. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-43. Tapered Bushing Installation

11. Tighten the capscrews evenly and progressively in rotation to 30 ft. lbs. (41 Nm).
12. After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows:
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - b. Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-44. Seating the Tapered Bearing

13. Rotate the capscrews evenly and progressively in rotation to 30 ft. lbs. (41 Nm).
14. Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-45. Hydrolock Piston Seal Installation

15. Place new hydrolock seals and guidelock rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-46. Piston Seal Kit Installation

16. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

17. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading hydrolock seals and guidelock rings are not damaged or dislodged.
18. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.




Figure 5-47. Rod Assembly Installation

19. Apply JLG Threadlocker P/N 0100011 to the socket head capscrews and secure the cylinder head gland using the washer ring and capscrews. Torque capscrews to 55 ft. lbs. (75 Nm).
20. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the re-installation of any holding valve or valves.
21. Install the counterbalance valve and fittings in the rod port block, using new o-rings as applicable. Torque valves to 50-55 ft. lbs. (68-75 Nm).

Master Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Place the cylinder barrel into a suitable holding fixture.




Figure 5-48. Cylinder Barrel Support

4. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-49. Capscrew Removal

5. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

6. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-50. Cylinder Rod Support



- | | | | | |
|-----------|--------------------|--------------------|-----------------|----------------|
| 1. Barrel | 5. Tapered Bushing | 9. Hydrolock Seal | 13. Wear Ring | 17. Wiper Seal |
| 2. Rod | 6. Spacer | 10. Guidelock Ring | 14. O-ring | 18. Capscrew |
| 3. Piston | 7. Capscrew | 11. O-ring | 15. Backup Ring | 19. Plug |
| 4. Head | 8. Washer Ring | 12. Backup Ring | 16. Rod Seal | 20. Bushing |

Figure 5-51. Master Cylinder

7. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
8. Remove capscrews from drilled holes.
9. Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen on the piston.
10. Remove the bushing from the piston.




Figure 5-52. Tapered Bushing Removal

11. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
12. Remove and discard the piston o-ring, hydrolock seals, guidelock rings and backup ring.
13. Remove piston spacer from the rod.
14. Remove the rod from the holding fixture. Remove capscrews and washer ring. Remove the cylinder head gland. Discard the o-ring, backup ring, rod seal, wiper seal and wear ring.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
6. Inspect threaded portion of piston for damage. Dress threads as necessary.
7. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
8. Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
9. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
10. Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
11. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-53. Composite Bearing Installation

12. Inspect spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
13. If applicable, inspect port block fittings and holding valve. Replace as necessary.
14. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
15. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-54. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-55. Cylinder Head Seal Installation

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear ring into the applicable cylinder head gland groove.




Figure 5-56. Wiper Seal Installation

3. Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-57. Installation of Head Seal Kit

4. Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper seal and rod seal are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
5. Carefully slide the piston spacer on the rod.
6. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
7. Place a new o-ring and backup ring in the inner piston diameter groove.
8. Carefully slide piston spacer onto the cylinder rod.
9. Carefully thread the piston on the cylinder rod and hand tight, ensuring that the o-ring and backup ring are not damaged or dislodged.
10. Thread piston onto rod until it abuts the spacer end and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

11. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-58. Tapered Bushing Installation

12. Tighten the capscrews evenly and progressively in rotation to 5 ft. lbs. (7 Nm) for 600S and 9 ft. lbs. (12 Nm) for 600SJ/660SJ.
13. After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4 in. in diameter) as follows:
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - b. Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-59. Seating the Tapered Bearing

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

14. Rotate the capscrews evenly and progressively in rotation to 5 ft. lbs. (7 Nm) for 600S and 9 ft. lbs. (12 Nm) for 600SJ/ 660SJ.
15. Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-60. Hydrolock Piston Seal Installation

16. Place new hydrolock seals and guidelock rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-61. Piston Seal Kit Installation

17. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

18. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading hydrolock seals and guidelock rings are not damaged or dislodged.
19. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.




Figure 5-62. Rod Assembly Installation

20. Apply JLG Threadlocker P/N 0100011 to the socket head capscrews and secure the cylinder head gland using the washer ring and capscrews. Torque capscrews to 40 ft. lbs. (55 Nm).
21. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the re-installation of any holding valve or valves, if applicable.

Steer Cylinder (USA Built Machines, SN 0300087000 through 0300142634)

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Place the cylinder barrel into a suitable holding fixture.




Figure 5-63. Cylinder Barrel Support

4. Using a hook spanner, loosen the spanner nut retainer and remove spanner nut from cylinder barrel.




Figure 5-64. Spanner Nut Removal

5. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

6. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-65. Cylinder Rod Support



- | | | |
|------------|--------------------|-----------------|
| 1. Locknut | 6. Rod | 11. Rodseal |
| 2. Piston | 7. Head | 12. Spanner Nut |
| 3. Seal | 8. O-ring | 13. Wiper Ring |
| 4. O-ring | 9. Backup Ring | 14. Bushing |
| 5. Barrel | 10. Retaining Ring | |

Figure 5-66. Steer Cylinder USA Built Machines, SN 0300087000 through 0300142634)

7. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
8. Remove Locknut from the piston rod.
9. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
10. Remove and discard the piston seal.
11. Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-ring, backup ring, retainer ring, rod seal and wiper seal.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
6. Inspect threaded portion of barrel for damage. Dress threads as necessary.
7. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
8. Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
9. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
10. Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.

11. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-67. Composite Bearing Installation

12. Inspect spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
13. If applicable, inspect port block fittings and holding valve. Replace as necessary.
14. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
15. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-68. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-69. Cylinder Head Seal Installation

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove.




Figure 5-70. Wiper Seal Installation

3. Place a new o-ring, backup ring and retainer ring in the applicable outside diameter groove of the cylinder head.




Figure 5-71. Installation of Head Seal Kit

4. Install spanner nut onto rod. Carefully install the head gland on the rod, ensuring that the wiper seal and rod seal are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
5. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
6. Carefully thread the piston on the cylinder rod and hand tight, ensuring that the o-ring and backup ring are not damaged or dislodged.

7. Install locknut onto the piston rod.
8. Remove the cylinder rod from the holding fixture.
9. Place new piston seal in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-72. Piston Seal Kit Installation

10. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

11. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading piston seal is not damaged or dislodged.
12. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.
13. Secure spanner nut into the cylinder barrel. Torque nut to 57-63 ft. lbs. (77-85 Nm).
14. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves, if applicable.

Steer Cylinder (USA Built Machines, SN 0300142635 through 0300171769 & China Built Machines SN B300000100 through B300000969)

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Place the cylinder barrel into a suitable holding fixture.




Figure 5-73. Cylinder Barrel Support

4. Using a hook spanner, loosen the spanner nut retainer and remove spanner nut from cylinder barrel.




Figure 5-74. Spanner Nut Removal

5. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

6. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-75. Cylinder Rod Support



- | | | |
|-------------|----------------|-------------------|
| 1. Piston | 6. Rod | 11. Retainer Ring |
| 2. Seal | 7. Head | 12. Wiper Seal |
| 3. O-ring | 8. O-ring | 13. Spanner Nut |
| 4. Setscrew | 9. Backup Ring | 14. Bushing |
| 5. Barrel | 10. Rod Seal | |

Figure 5-76. Steer Cylinder (USA Built Machines, SN 0300142635 through 0300171769 & China Built Machines, SN B300000100 through B300000969)

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

7. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
8. Remove the setscrews from the piston.
9. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
10. Remove piston seals and discard o-ring.
11. Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup ring, rod seal, and wiper seal.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
6. Inspect threaded portion of barrel for damage. Dress threads as necessary.
7. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
8. Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
9. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
10. Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
11. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-77. Composite Bearing Installation

12. Inspect spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
13. If applicable, inspect port block fittings and holding valve. Replace as necessary.
14. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
15. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-78. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-79. Cylinder Head Seal Installation

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove.




Figure 5-80. Wiper Seal Installation

3. Place a new backup ring, o-rings and retainer ring in the applicable outside diameter groove of the cylinder head.




Figure 5-81. Installation of Head Seal Kit

4. Install spanner nut onto rod. Carefully install the head gland on the rod, ensuring that the wiper seal and rod seal are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
5. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
6. Carefully thread the piston on the cylinder rod and hand tight, ensuring that the o-ring is not damaged or dislodged. Torque to 150-180 ft.lbs. (203-244 Nm).
7. Install the setscrews on the piston.
8. Remove the cylinder rod from the holding fixture.

9. Place new piston seals and O-ring in the outer piston diameter grooves. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-82. Piston Seal Kit Installation

10. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

11. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading o-ring and piston seals are not damaged or dislodged.
12. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.
13. Secure spanner nut into the cylinder barrel. Torque nut to 57-63 ft. lbs. (77-85 Nm).
14. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any holding valve or valves, if applicable.

Telescope Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Remove capscrews and valve assembly from the barrel end. Discard o-rings.
4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-83. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-84. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod port block end or cylinder rod end, as applicable.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully withdraw the complete rod assembly from the cylinder barrel.





Figure 5-85. Cylinder Rod Support



- | | | | | |
|--------------------|-------------------|----------------|-----------------|---------------|
| 1. Barrel | 6. Spacer | 11. Capscrew | 16. Backup Ring | 21. Wear Ring |
| 2. Rod | 7. Valve Assembly | 12. Capscrew | 17. Wear Ring | 22. Capscrew |
| 3. Head | 8. Plug | 13. Wiper Seal | 18. O-ring | |
| 4. Piston | 9. Capscrew | 14. Rod Seal | 19. Backup Ring | |
| 5. Tapered Bushing | 10. Washer Ring | 15. O-ring | 20. T-Seal | |

Figure 5-86. Telescope Cylinder

8. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
9. Remove capscrews from drilled holes.
10. Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen on the piston.
11. Remove the bushing from the piston.




Figure 5-87. Tapered Bushing Removal

12. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
13. Remove and discard the piston o-ring, backup rings, wear rings and T-seal.
14. Remove the capscrew from the piston spacer. Remove the piston spacer from the rod.
15. Remove the rod from the holding fixture. Remove the cylinder head gland. Remove capscrews and washer ring, discard the o-ring, backup ring, rod seal, wear rings and wiper seal.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
6. Inspect threaded portion of piston for damage. Dress threads as necessary.
7. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
8. Inspect cylinder head inside diameter for scoring or other damage and for ovality and tapering. Replace as necessary.
9. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
10. Inspect cylinder head outside diameter for scoring or other damage and ovality and tapering. Replace as necessary.
11. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.
12. Inspect spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
13. If applicable, inspect port block fittings and holding valve. Replace as necessary.
14. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
15. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-88. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-89. Cylinder Head Seal Installation

2. Use a soft mallet to tap a new wiper seal into the applicable cylinder head gland groove. Install a new wear rings into the applicable cylinder head gland groove.




Figure 5-90. Wiper Seal Installation

3. Place a new o-ring and backup ring in the applicable outside diameter groove of the cylinder head.




Figure 5-91. Installation of Head Seal Kit

4. Carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end, as applicable.
5. Carefully slide the spacer onto the rod. Secure the spacer onto rod with the capscrew.
6. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to piston as possible.
7. Place a new o-ring and backup rings in the inner piston diameter groove.

8. Carefully thread the piston on the cylinder rod and hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.
9. Thread piston onto rod until it abuts the spacer end and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

10. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-92. Tapered Bushing Installation

11. Tighten the capscrews evenly and progressively in rotation to 9 ft. lbs. (12 Nm).
12. After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4 in. in diameter) as follows:
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - b. Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-93. Seating the Tapered Bearing

13. Rotate the capscrews evenly and progressively in rotation to 9 ft. lbs. (12 Nm).
14. Remove the cylinder rod from the holding fixture.
15. Place new T-seal and wear rings in the outer piston diameter groove. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the solid seal).




Figure 5-94. Piston Seal Kit Installation

16. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

17. With barrel clamped securely, and while adequately supporting the rod, insert the piston end into the barrel cylinder. Ensure that the piston loading T-seal and wear rings are not damaged or dislodged.
18. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.

19. Apply JLG Threadlocker P/N 0100011 to the socket head capscrews and secure the cylinder head gland using the washer ring and capscrews. Torque capscrews to 40 ft. lbs. (55 Nm).
20. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the re-installation of any holding valve or valves.
21. Install o-ring plug onto the rod assembly.
22. Install the valve assembly back onto the rod using capscrews. Torque capscrews to 9 ft. lbs. (12 Nm).




Figure 5-95. Rod Assembly Installation

5.5 CYLINDER REMOVAL AND INSTALLATION

Main Boom Telescope Cylinder Removal

1. Place machine on a flat and level surface, with main boom in the horizontal position.
2. Shut down engine. Support main boom basket end with a prop. (See Figure 5-96.)

NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID THE ENTRY OF CONTAMINANTS INTO THE SYSTEM.

3. Tag and disconnect hydraulic lines to telescope cylinder. Use a suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
4. Remove the hardware securing cover plate on bottom of the base boom section and remove cover.

NOTE: Do not allow cable to rotate. This may damage the cable.

5. Clamp both threaded ends of cable to prevent rotation. Note: Do not clamp on threads. Remove jam nuts and loosen adjustment nuts so there is slack in the cables. (See Section 4 - Boom & Platform).
6. Remove the hardware securing push bar to turntable and telescope cylinder.
7. Using a suitable brass drift, carefully drive the push bar pins from the telescope cylinder rod and turntable.
8. Remove hardware securing cable adjustment block to aft end of the base boom section and remove block.
9. Remove hardware securing telescope cylinder to aft end of the mid boom section.

NOTICE

WHEN REMOVING THE TELESCOPE CYLINDER FROM THE BOOM, IT MAY BE NECESSARY AT SOME POINT TO TURN THE CYLINDER SLIGHTLY IN ORDER TO CLEAR ASSEMBLIES MOUNTED WITHIN THE BOOM. CARE MUST BE TAKEN TO MOVE THE CYLINDER SLOWLY INTO POSITION: DAMAGE TO COMPONENTS MAY RESULT FROM FORCIBLE IMPACT WITH THESE ASSEMBLIES.

10. Remove bolts securing cable attach bar to top of fly boom section.
11. Pull the telescope cylinder and cables partially from aft end of the base boom section; secure the cylinder with a suitable sling and lifting device at approximately the center of gravity.
12. Carefully remove the telescope cylinder and sheave assembly. Place telescope cylinder on a suitable trestle.

Main Boom Telescope Cylinder Installation

1. Route extend cables around extend sheave and secure cables to the telescope cylinder.
2. Install extend cables mounting blocks to threaded ends of cables. Loosely install nuts and jam nuts onto the threaded end of cables.

NOTE: When installing cables care must be taken not to twist or cross the cables.

3. Secure the sling and lifting device at the telescope cylinder's approximate center of gravity, and lift the cylinder to the aft end of the boom assembly.
4. Install extend cable mounting blocks to threaded ends of cables. Loosely install nuts and jam nuts onto the threaded ends of cables.

NOTE: When installing cables, care must be taken not to twist or cross the cables.

5. Secure the sling and lifting device at the telescope cylinder's approximate center of gravity, and lift the cylinder to the aft end of the boom assembly.

NOTICE

WHEN INSERTING THE TELESCOPE CYLINDER INTO THE BOOM, IT MAY BE NECESSARY AT SOME POINT TO TURN THE CYLINDER SLIGHTLY IN ORDER TO CLEAR ASSEMBLIES MOUNTED WITHIN THE BOOM. CARE MUST BE TAKEN TO MOVE THE CYLINDER SLOWLY INTO POSITION: DAMAGE TO COMPONENTS MAY RESULT FROM FORCIBLE IMPACT WITH THESE ASSEMBLIES.

6. Carefully install the telescope cylinder barrel end support into slots in mid boom and secure with blocks and bolts. Apply JLG Threadlocker P/N 0100019 on bolts.
7. Align holes in aft end of the fly boom section with holes in cable mounting block, then secure with mounting hardware.
8. Align holes in aft end of the base boom section with holes in cable mounting block, then secure with mounting hardware.
9. Remove cylinder port plugs and hydraulic line caps and correctly attach lines to cylinder ports.
10. Align holes in rod end of the telescope cylinder with holes in push bar. Install push bar pin and secure with mounting hardware.
11. Align holes in push bar with holes in turntable. Install push bar pin and secure with mounting hardware.
12. Boom cables must be torqued after installation of the telescope cylinder. (See Section 4.11, Boom Rope Torquing Procedures).






Figure 5-96. Boom Positioning and Support

Main Boom Lift Cylinder Removal

1. Place the machine on a flat and level surface. Start the engine and place the main boom in the horizontal position. Shut down engine and prop the boom. (See Figure 5-96.)
2. Remove the hardware retaining the cylinder rod attach pin to the boom. Using a suitable brass drift, drive out the cylinder rod attach pin.

4. Disconnect, cap and tag the main boom lift cylinder hydraulic lines and ports.
5. Remove barrel end attach pin retaining hardware. Using a suitable brass drift drive out the barrel end attach pin from the turntable.




3. Using auxiliary power, retract the lift cylinder rod completely.

6. Remove the cylinder from the turntable and place in a suitable work area.


Main Boom Lift Cylinder Installation

1. Install lift cylinder in place using suitable slings or supports, aligning attach pin mounting holes on the turntable.
2. Using a suitable drift, drive the barrel end attach pin through the mounting holes in the lift cylinder and the turntable. Secure in place with the pin retaining hardware.



3. Remove cylinder port plugs and hydraulic line caps and correctly attach lines to cylinder ports.


4. Using auxiliary power, extend the cylinder rod until the attach pin hole aligns with those in the boom. Using a suitable soft mallet, drive the cylinder rod attach pin through the boom and lift cylinder. Secure the pin in place with attaching hardware.




5. Remove boom prop and overhead crane. Activate hydraulic system.
6. Using all applicable safety precautions, operate the boom functions. Check for correct operation and hydraulic leaks. Secure as necessary.
7. Check fluid level of hydraulic tank and adjust as necessary.

Master Cylinder Removal

1. Place the machine on a flat and level surface. Start the engine and place the main boom in the horizontal position. Shut down engine and prop the boom. (See Figure 5-96.)
2. Remove the hardware retaining the cylinder rod attach pin to the boom. Using a suitable brass drift, drive out the cylinder rod attach pin.




3. Using an adequate supporting device, support the master cylinder so it doesn't fall when the retaining pins are removed.
4. Remove the hardware retaining the cylinder barrel end attach pin to the turntable. Using a suitable brass drift, drive out the cylinder barrel end attach pin.




5. Remove the cylinder from the turntable and place in a suitable work area.

Master Cylinder Installation

1. Install master cylinder in place using suitable slings or supports, aligning attach pin mounting holes on the turntable.
2. Using a suitable drift, drive the barrel end attach pin through the mounting holes in the master cylinder and the turntable. Secure in place with the pin retaining hardware.



3. Using auxiliary power, extend the cylinder rod until the attach pin hole aligns with those in the boom. Using a suitable soft mallet, drive the cylinder rod attach pin through the boom and master cylinder. Secure the pin in place with attaching hardware.



4. Using all applicable safety precautions, operate the master cylinder. Check for correct operation and hydraulic leaks. Secure as necessary.

5.6 VARIABLE DISPLACEMENT PUMP (M46 SERIES)


Troubleshooting

GAUGE INSTALLATION

It will be necessary to install a high pressure gauge into the system pressure gauge ports to check the setting of the high pressure relief valves.

Measuring the charge pump inlet vacuum will help locate restrictions in the inlet lines, filter, etc.

Case pressure readings can help locate restrictions in the return lines, oil cooler, and return filter.



Gauge Information		
M1	System Pressure Port A	10,000 PSI or 600 Bar Gauge 9/16-18 O-ring Fitting
M2	System Pressure Port B	10,000 PSI or 600 Bar Gauge 9/16-18 O-ring Fitting
M3	Charge Pressure	1000 PSI or 60 Bar Gauge 9/16-18 O-ring Fitting or Tee into Charge Pressure Filter Outlet Line
L1 L2	Case Pressure	1000 PSI or 60 Bar Gauge 1-1/16-12 O-ring Fitting
S	Charge Pump Inlet Vacuum	Vacuum Gauge Tee into Charge Pump Inlet Line
M4	Servo Pressure	1000 PSI or 60 Bar Gauge 9/16-18 O-ring Fitting
M5	Servo Pressure	1000 PSI or 60 Bar Gauge 9/16-18 O-ring Fitting




Figure 5-97. Troubleshooting - Neutral Difficult or Impossible to Find




Figure 5-98. Troubleshooting - System Operating Hot




Figure 5-99. Troubleshooting - Transmission Operates in One Direction Only




Figure 5-100. Troubleshooting - System Response is Sluggish





Figure 5-101. Troubleshooting - System Will Not Operate in Either Direction

Inspections and Adjustments

CHECK/HIGH PRESSURE RELIEF VALVES

The system check/relief valves have the dual purpose of providing make-up oil during by-directional rotation and providing protection from system over pressure. When the problem occurs in one direction only, interchange the check/relief valves to see if the problem changes to the other direction. If so, one check/relief valve cartridge is either malfunctioning or does not have the proper setting.




CAUTION

THE RELIEF VALVES ARE FACTORY SET AND SHOULD NOT BE TAMPERED WITH EXCEPT FOR REPLACING THE ENTIRE CARTRIDGE. DISASSEMBLY MAY CHANGE THE SETTING AND CAUSE ERRATIC UNIT OPERATION OR PREMATURE FAILURE.

PUMP CHARGE RELIEF VALVE

If charge pressure is low (less than 220 psi [15.2 Bar] above case pressure), the charge relief valve should be inspected. Inspect for foreign material holding the poppet open, and for scoring or wear on the poppet and seat in the housing. Adjustments of the charge pressure is accomplished by changing the shim thickness behind the spring.



ELECTRICAL DISPLACEMENT CONTROL ORIFICES

NOTE: The pump should have two control orifices located under the servo covers.

1. With a 7/16" wrench, remove the five bolts from the servo cover opposite the neutral adjustment (cover without the adjustment screw).




2. With a 7/32" internal wrench, remove and inspect the orifice.



3. Remove the bolts from the servo cover on the neutral adjustment side. Install a spacer or sprocket, approximately 0.75 in. (19 mm) long, under the servo cover opposite the neutral adjustment.



4. Re-install the bolts and tighten until the servo cover on the neutral adjustment side of the pump separates 0.125 in. (3 mm) from the housing. Turn the cover and remove and inspect the orifice.




NOTE: The Displacement Control may first have to be removed in order to rotate the servo cover.

5. Remove spacer, re-install orifices, gaskets, and covers. Torque grade 5 bolts 8 to 11 ft.lbs. (10.8 to 14.9 Nm) and grade 8 bolts 11 to 13 ft.lbs. (14.9 to 17.8 Nm).

SWASHPLATE NEUTRAL ADJUSTMENT

1. Using a low pressure line (500 psi [35 Bar] min.), cross port servo port F to servo port G. This removes the effects of any control pressure on the servo piston.



2. Install pressure gauges (10,000 psi [690 Bar]) in the system pressure gauge ports. Start the engine and slowly accelerate to normal operating RPM.
3. Remove the protective cap and loosen the servo lock nut while holding the servo adjustment screw in position.



4. Turn the servo adjustment screw until the two system pressure gauge readings are equal.
5. Turn the servo adjustment screw clockwise until one of the system pressures starts to increase.



6. Noting the amount of rotation, turn the servo adjustment screw counter-clockwise until the other system pressure starts to increase.
7. Turn the servo adjustment screw clockwise half the amount of rotation noted above.

8. While holding the servo adjustment screw from turning, torque the servo lock nut 13 to 18 ft.lbs. (17.6 to 24.4 Nm). Stop the engine, install a new protective cap, remove the servo cross-port line, and proceed to the appropriate control adjustment.


EDC NEUTRAL ADJUSTMENT

1. Remove the electrical connector at the EDC. Remove the servo cross port line (installed while making the swash plate neutral adjustment) and install a 0 to 300 PSI (0 to 21 BAR) gauge in each servo port.

⚠ WARNING

THE FOLLOWING PROCEDURE MAY REQUIRE THE MACHINE TO BE DISABLED (WHEELS RAISED OFF THE GROUND, WORK FUNCTION DISCONNECTED, ETC.) WHILE PERFORMING THE PROCEDURES IN ORDER TO PREVENT INJURY TO THE TECHNICIAN AND BYSTANDERS.

2. Start the engine and accelerate to normal operating RPM.
3. Loosen lock nut with 1/2" wrench and slowly rotate the neutral adjustment screw, with 5/32" internal hex wrench, until the pressure is equal on both servo gauges.



4. Slowly rotate the neutral adjustment screw until one of the servo gauges starts to increase in pressure.
5. Noting the amount of rotation, slowly rotate the neutral adjust screw in the opposite direction until the other servo gauge begins to increase in pressure.
6. Turn the neutral adjust screw back one - half the amount noted above. Hold the neutral adjust screw and torque the lock nut to 25 to 30 in.lbs. (2.8 to 3.4 NM).
7. Stop the engine. Connect the control input. Remove the servo pressure gauges. Return the machine to normal operating condition. Restart the engine and assure that the hydrostatic system is in neutral.

Minor Repair and Replacement

Minor repairs may be performed, following the procedures in this section.

Cleanliness is a primary means of assuring satisfactory transmission life, on either new or repaired units. Cleaning parts by using solvent wash and air drying is usually adequate. As with any precision equipment, all parts must be kept free of foreign materials and chemicals.

Protect all exposed sealing surfaces and open cavities from damage and foreign material.

It is recommended that all gaskets and O-rings be replaced. Lightly lubricate all O-rings with clean petroleum jelly prior to assembly. All gasket sealing surfaces must be cleaned prior to installing new gaskets.




Figure 5-102. Variable Displacement Pump


SHAFT SEAL

Lip type shafts are used on Series 40 - M46 pumps and motors. These seals can be replaced without major disassembly of the unit. However, replacement of the shaft seal requires removal of the pump from the machine.

1. Remove the retaining ring from the housing.



2. Carefully remove the seal from the housing bore. The face of the seal may be punctured with a sharp instrument (such as a screw driver) to aid in prying the seal out, or a slide hammer type puller may be used to remove the seal. Care must be taken so as not to damage the housing bore or shaft. Once removed, the seal is not reusable.




3. Prior to installing the new seal, inspect the sealing area on the shaft for rust, wear, or contamination. Polish the sealing area on the shaft if necessary.
4. Wrap the spline or key end of the shaft with thin plastic to prevent damage to the seal lip during installation. Lubricate the inside diameter of the new seal with petroleum jelly.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

NOTE: The outside diameter of the seal may be lightly coated with sealant (such as Loctite High Performance Sealant #59231) prior to installation. This will aid in preventing leaks caused by damage to the housing seal bore.


5. Slide the new seal over the shaft and press it into the housing bore. Be careful not to damage seal. A seal installer tool can be made to aid in installing the seal.



6. Reinstall the seal retaining ring.

BYPASS VALVE (PUMP)

1. Unscrew the bypass valve from the housing. Inspect the valve and mating seat for damage or foreign material. It is recommended that the O-ring and back-up ring be replaced.




NOTE: Bypass valves are available with integral bypass orifices for specific applications. Refer to the appropriate Service Parts Manual for more information.


2. Reinstall the bypass valve into the housing. Torque to 7 to 10 ft. lbs. (9.5 - 13.6 Nm).

CHARGE CHECK AND HIGH PRESSURE RELIEF VALVES


1. Remove the charge check and high pressure relief valve hex plug.



2. Remove the spring and check poppet or valve cartridge from the housing. Inspect the valve and mating seat in the housing for damage or foreign material. It will be necessary to replace the housing if the seat is damaged.



3. Several designs of charge check and high pressure relief valves have been used. Do not attempt to mix different vintage parts.



The appropriate check valve kit and/ or check and relief valve kit should be used. Refer to appropriate Service Parts Manual.

NOTE: Always replace ball type charge check valves with the poppet type.

4. Reinstall the valve cartridge, spring, and plug (with O-ring) into the housing. Torque the plug to 30 to 70 ft. lbs. (41 to 95 Nm).

⚠ CAUTION

THE RELIEF VALVES ARE FACTORY SET AND SHOULD NOT BE TAMPERED WITH EXCEPT FOR REPLACING THE ENTIRE CARTRIDGE. DISASSEMBLY MAY CHANGE THE SETTING AND CAUSE ERRATIC UNIT OPERATION OR PREMATURE FAILURE.

CHARGE PRESSURE RELIEF VALVE

1. Remove charge relief valve hex plug.



2. Remove the spring and poppet from the housing. Do not alter the shims or interchange parts with another valve. Inspect the poppet and mating seat in the end cap for damage or foreign material.



3. Reinstall the poppet, spring, and plug (with shims and O-ring) into the housing. Torque the plug to 30 to 70 ft. lbs. (41 to 95 Nm).

ELECTRICAL DISPLACEMENT CONTROLS (EDC)


⚠ CAUTION

THE REMOVAL OF ANY PORTION OF THE CONTROL MECHANISM MAY RESULT IN LOSS OF NEUTRAL, WHICH WILL NECESSITATE READJUSTMENT.


1. Remove the four control mounting screws using an internal hex wrench (3/16").



- Carefully lift the control off the pump housing.




- Remove the control sleeve from the pump.




- Remove the control inlet screen plug from the inlet passage next to the control sleeve bore, using an internal hex wrench (5/32").
- The control orifice plugs are located in threaded passages under the servo piston cover. Remove the servo piston cover and gasket, and remove the orifice plugs using an internal hex wrench (7/32").




- Replace the O-ring on the bottom of the control housing. Lightly lubricate all O-rings with clean petroleum jelly prior to assembly. The control spool and sleeve are a matched set and are not available separately.



- Reinstall the control orifice plugs into their passages and replace the servo piston covers.
- Install the control inlet screen plug and torque to 20 to 30 in.lbs. (2.2 to 3.4 Nm). Always install a screen plug (with a 0.156" (3.96 mm.) thru hole) when servicing earlier production pumps. Pumps prior to date code 86 - 14 use a plug with a thread that is different from later units. Refer to the Service Parts Manual for plug part numbers.



9. Align the control sleeve so its slot will engage the swash plate feedback pin (slot positioned toward the pump cover) and insert the sleeve into the housing. Carefully align the control spool with the sleeve and install the control onto the pump housing. Install the four mounting screws and torque to 10 to 11 ft.lbs. (13 to 14 Nm).



10. Install the four cover screws and torque to 18 to 24 in. lbs. (2.0 to 2.7 Nm).
11. Readjust the neutral position of the control. Refer to the instructions in the Inspections and Adjustment.

5.7 VALVES - THEORY OF OPERATION

Solenoid Control Valve - Rexroth

Control valves used are four-way three-position solenoid valves of the sliding spool design. When a circuit is activated and the control valve solenoid energizes, the spool is shifted and the corresponding work port opens to permit oil flow to the component in the selected circuit with the opposite work port opening to reservoir. Once the circuit is deactivated (control returned to neutral) the valve spool returns to neutral (center) and oil flow is then directed through the valve body and returns to reservoir. A typical control valve consists of the valve body, sliding spool, and two solenoid assemblies. The spool is machine fitted in the bore of the valve body. Lands on the spool divide the bore into various chambers, which, when the spool is shifted, align with corresponding ports in the valve body open to common flow. At the same time other ports would be blocked to flow. The spool is spring loaded to center position, therefore when the control is released, the spool automatically returns to neutral, prohibiting any flow through the circuit.

Relief Valves

Relief valves are installed at various points within the hydraulic system to protect associated systems and components against excessive pressure. Excessive pressure can be developed when a cylinder reaches its limit of travel and the flow of pressurized fluid continues from the system control. The relief valve provides an alternate path for the continuing flow from the pump, thus preventing rupture of the cylinder, hydraulic line or fitting. Complete failure of the system pump is also avoided by relieving circuit pressure. The relief valve is installed in the circuit between the pump outlet (pressure line) and the cylinder of the circuit, generally as an integral part of the system valve bank. Relief pressures are set slightly higher than the load requirement, with the valve diverting excess pump delivery back to the reservoir when operating pressure of the component is reached.

5.8 PRESSURE SETTING PROCEDURES

NOTICE

COLD TEMPERATURES HAVE A SIGNIFICANT IMPACT ON PRESSURE READINGS. JLG INDUSTRIES, INC. RECOMMENDS OPERATING THE MACHINE UNTIL THE HYDRAULIC SYSTEM HAS WARMED TO NORMAL OPERATING TEMPERATURES PRIOR TO CHECKING PRESSURES. JLG ALSO RECOMMENDS USING A CALIBRATED GAUGE. PRESSURE READINGS ARE ACCEPTABLE IF WITHIN +/- 5% OF SPECIFIED PRESSURES.

To ensure all pressures are set correctly, the following procedures must be followed in order.

1. All applicable steps must be followed.
2. Set up of the function pump.
3. Adjustments Made at the Main Valve Block.
4. Adjustments Made at the Platform Valve Block.

Main Relief, Steer, Swing and Lift Down

1. Install pressure gauge at quick disconnect on port MP on main valve
2. With the aid of an assistant, activate telescope in.
3. While monitoring pressure gauge, adjust main relief to 3000 PSI (206.85 Bar).
4. With the aid of an assistant, activate steer left.
5. While monitoring pressure gauge, adjust steer left relief to 1800 PSI (124.1 Bar).
6. With the aid of an assistant, activate steer right.
7. While monitoring pressure gauge, adjust steer right relief to 1800 PSI (124.1 Bar).
8. With the aid of an assistant, activate swing left or right.
9. While monitoring pressure gauge, adjust swing relief to 1700 PSI (117.2 Bar).
10. With the aid of an assistant, activate lift down.
11. While monitoring pressure gauge, adjust lift down relief to 1200 PSI (82.7 Bar).

Platform Level

1. Install pressure gauge at quick disconnect on port M3 on main valve.
2. With the aid of an assistant, activate platform level forward.
3. While monitoring pressure gauge, adjust platform level relief to 2800 PSI (193.06 Bar).
4. Install pressure gauge at quick disconnect on port M4 on main valve.
5. With the aid of an assistant, activate platform level backward.
6. While monitoring pressure gauge, adjust platform level relief to 1800 PSI (124.11 Bar).

Articulating Jib Boom (If Equipped)

1. Install pressure gauge at quick disconnect on articulating valve.
2. With the aid of an assistant, activate articulating jib up.
3. While monitoring pressure gauge, adjust articulating jib up relief to 1500 PSI (103 Bar).
4. With the aid of an assistant, activate articulating jib down.
5. While monitoring pressure gauge, adjust activate articulating jib down relief to 1200 PSI (83 Bar).





Figure 5-103. Articulating Jib Boom Pressure Adjustments


4 Wheel Steer (If Equipped)

1. At the platform console using the steer select switch activate "2 wheel steer".
2. Install a pressure gauge in port MP on main control valve.
3. With the aid of an assistant, activate steer left and right, adjust front steer relief valve to 2500 PSI (172.4 Bar). This pressure only affects the front axle.
4. At the platform console using the steer select switch activate "crab" or "coordinated" steer.
5. At the main control valve block disconnect the wire din connectors on the front steer valve. When steer is activated only the rear steer will work.
6. Install a pressure gauge in port MP on main control valve.
7. With the aid of an assistant, activate steer left and right, adjust rear steer relief valve to 2500 PSI (172.4 Bar). Reading at the valve bank 2500 PSI (172.4 Bar) will give you 2000PSI (137.9 Bar) at the cylinders.
8. Re-connect the front steer din connectors at the valve bank.



- | | | | |
|--------------------------------------|---|--|--|
| 1. Direct Operated Relief Valve | 6. Directional Control Valve (Main Lift) | 10. Directional Control Valve (Platform Level) | 15. Direct Operated Relief Valve |
| 2. Load Shuttle Valve | 7. Directional Control Valve (Flow Control) | 11. Directional Operated Relief Valve | 16. Pressure Compensated Flow Control |
| 3. Pressure Control Load Sense | 8. Directional Control Valve (Main) | 12. Load Shuttle Valve | 17. Pilot Operated Check Valve |
| 4. Directional Control Valve (Steer) | 9. Directional Control Valve (Platform Rotator) | 13. Load Shuttle Valve | 18. Direct Operated Relief Valve (Main Relief) |
| 5. Directional Control Valve (Swing) | | 14. Solenoid Operated 2-Way Valve | |

Figure 5-104. Main Valve Components



1001091303 B

POS	PSI	BAR
A	3000	207
B	230	16
C	50	3

Figure 5-105. Main Valve Components Pressure Adjustments

5.9 HYDRAULIC COMPONENT START-UP PROCEDURES AND RECOMMENDATIONS

From a hydrostatic component standpoint, the goal at system start up is to put into functional operation, the hydrostatic system in such a way as to preserve the designed life span of the system. The following start-up procedure should be adhered to whenever a new pump or motor is initially installed into a machine, or a system is restarted after either a pump or motor has been removed and/or replaced.

⚠ WARNING

THE FOLLOWING PROCEDURE MAY REQUIRE THE MACHINE TO BE DISABLED (WHEELS RAISED OFF THE GROUND, WORK FUNCTIONS DISCONNECTED, ETC.) WHILE PERFORMING THE PROCEDURE IN ORDER TO PREVENT INJURY. TAKE NECESSARY SAFETY PRECAUTIONS BEFORE MOVING THE VEHICLE/MACHINE.

Prior to installing the pump and/or motor, inspect the unit(s) for damage that may have been incurred during shipping and handling. Make certain that all system components (reservoir, hoses, valves, fittings, heat exchanger, etc.) are clean prior to filling with fluid.

Fill the reservoir with recommended hydraulic fluid. This fluid should be passed through a 10 micron (nominal, no bypass) filter prior to entering the reservoir. The use of contaminated fluid will cause damage to the components, which may result in unexpected vehicle/machine movement.

NOTE: *If a pump or motor is being replaced due to internal damage, the remaining units (pump or motors) need to be inspected for damage and contamination, and the entire hydraulic system will need to be flushed and the fluid replaced. Failure to do so may cause considerable damage to the entire system.*

The inlet line leading from the reservoir to the pump must be filled prior to start-up. Check the inlet line for property tightened fittings and make sure it is free of restrictions and air leaks.

NOTE: *In most cases, the reservoir is above the pump inlet so that the pressure head created by the higher oil level helps to keep the inlet pressures within an acceptable range and prevent high vacuum levels. However, due to hose routing or low reservoir locations, there may be air trapped within this line. It is important to assure that the air is bled from this line. This can be accomplished by loosening the hose at the fitting closest the pump. When oil begins to flow, the line is full, the air has been purged, and the fitting can be retightened to its specified torque. If the tank needs to be pressurized in order to start the flow of oil, a vacuum reading should be taken at the inlet of the pump during operation in order to verify that the pump is not being asked to draw an inlet vacuum higher than it is capable of.*

Be certain to fill the pump and/or motor housing with clean hydraulic fluid prior to start up. Fill the housing by pouring filtered oil into the upper case drain port.

NOTE: *It is highly recommended to use the highest possible case drain port, this ensures that the housing contains as much oil as possible and offers the greatest amount of lubrication to the internal components.*

NOTE: *In initial start-up conditions, it may be convenient to fill the housing, just prior to installing the case drain line. Component, (especially motor), location may be such that access to the case drain port after installation is not realistic.*

NOTE: *Make certain that the oil being used to fill the component housing is as clean as possible, and store the fill container in such a way as to prevent it from becoming contaminated.*

Install a 60 bar (or 1000 psi) pressure gauge in the charge pressure gauge port in order to monitor the charge pressure during start-up.

It is recommended that the external control input signal, (electrical connections for EDC), be disconnected at the pump control until after initial start-up. This will ensure that the pump remains in its neutral position.

⚠ WARNING

DO NOT START THE ENGINE UNLESS PUMP IS IN THE NEUTRAL POSITION (0 DEGREES SWASHPLATE ANGLE). TAKE PRECAUTIONS TO PREVENT MACHINE MOVEMENT IN CASE PUMP IS ACTUATED DURING INITIAL START-UP.

“Jog” or slowly rotate the engine until charge pressure starts to rise. Start the engine and run at the lowest possible RPM until charge pressure has been established. Excess air should be bled from the system lines as close to the motors as possible.

NOTE: *With the engine on low idle, “crack”, (loosen-don't remove), the system lines at the motor(s). Continue to run the engine at low idle and tighten the system lines as soon as oil is observed to leak from them. When oil is observed to “leak” at the motor the line is full, the air has been purged, and the system hoses should be retightened to their specified torque.*

Once charge pressure has been established, increase speed to normal operating RPM. Charge pressure should be as indicated in the pump model code. If charge pressure is inadequate, shut down and determine the cause for improper pressure.

⚠ WARNING

INADEQUATE CHARGE PRESSURE WILL AFFECT THE OPERATOR'S ABILITY TO CONTROL THE MACHINE.

Shut down the engine and connect the external control input signal. Also reconnect the machine function(s), if disconnected earlier. Start the engine, checking to be certain the pump remains in neutral. With the engine at normal operating RPM, slowly check for forward and reverse machine operation.

Charge pressure may slightly decrease during forward or reverse operation. Continue to cycle slowly between forward and reverse for at least five minutes.

Shut down engine, remove gauges, and plug ports. Check reservoir level and add filtered fluid if needed.

The machine is now ready for operation.

**5.10 HYDRAULIC PUMP W/HAYES PUMP
DRIVE COUPLING LUBRICATION**

Any time pump or pump drive coupling is removed coat, pump and drive coupling splines with Lithium Soap Base Grease (TEXACO CODE 1912 OR EQUIVALENT) coupling is greased prior to assembly.

5.11 HYDRAULIC SCHEMATICS




Figure 5-106. Hydraulic Schematic - Sheet 1 of 6

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS




Figure 5-107. Hydraulic Schematic - Sheet 2 of 6

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS




Figure 5-108. Hydraulic Schematic - Sheet 3 of 6




Figure 5-109. Hydraulic Schematic - Sheet 4 of 6

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS




Figure 5-110. Hydraulic Schematic - Sheet 5 of 6




Figure 5-111. Hydraulic Schematic - Sheet 6 of 6

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your manual number or description and we will search our parts manual library for you.

* Brand:

* Serial Number:

* Model:

Serial:

Part Number:

Part Description:

Keywords:

Search

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in as much information as possible to help us find the right part for you.

Manufacturer:

Model:

Description:

Part Number:

Part Description:

Keywords:

Quantity:

Price:

Notes:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 6. JLG CONTROL SYSTEM

6.1 JLG CONTROL SYSTEM ANALYZER KIT INSTRUCTIONS

Introduction

NOTICE

WHEN INSTALLING A NEW POWER MODULE CONTROLLER ON THE MACHINE, IT WILL BE NECESSARY TO PROGRAM THE CONTROLLER FOR THE PROPER MACHINE CONFIGURATION, INCLUDING OPTIONS.

NOTICE

IT IS A GOOD PRACTICE TO AVOID PRESSURE-WASHING ELECTRICAL/ELECTRONIC COMPONENTS. SHOULD PRESSURE-WASHING BE UTILIZED TO WASH AREAS CONTAINING ELECTRICAL/ELECTRONIC COMPONENTS, JLG INDUSTRIES, INC. RECOMMENDS A MAXIMUM PRESSURE OF 750 PSI (52 BAR) AT A MINIMUM DISTANCE OF 12 INCHES (30.5 CM) AWAY FROM THESE COMPONENTS. IF ELECTRICAL/ELECTRONIC COMPONENTS ARE SPRAYED, SPRAYING MUST NOT BE DIRECT AND BE FOR BRIEF TIME PERIODS TO AVOID HEAVY SATURATION.

The JLG designed Control System is a 12 volt based control unit installed on the boom lift.

The JLG Control System has reduced the need for exposed terminal strips, diodes and trimpots and provides simplicity in

viewing and adjusting the various personality settings for smooth control of: acceleration, deceleration, creep, min speed, and max.-speed for all boom, drive, and steering functions.

The main lift, swing, and drive are controlled by individual joysticks, with steering being controlled by a rocker switch built into the top the drive joystick. To activate Drive, Lift, and Swing simply pull up on the slide lock location on the joystick and move the handle into the direction desired.

The control system will control the voltage output to the valves and pump, as programmed for smooth operation and maximum cycle time. Ground control speeds for all boom functions can also be programmed into the control system.

The JLG Control System controller has a built in LED to indicate any faults. The system stores recent faults which may be accessed for troubleshooting. Optional equipment includes a soft touch system, head and tail lights, and ground alarm. These options may be added later but must be programmed into the control system when installed.

The Control System may be accessed utilizing a custom designed, hand held analyzer (Analyzer Kit, JLG part no. 2901443) which will display two lines of information at a time, by scrolling through the program.




Figure 6-1. Hand Held Analyzer

To Connect the JLG Control System Analyzer


1. Connect the four pin end of the cable supplied with the analyzer, to the motor controller module located in the platform box or at the power module and connect the remaining end of the cable to the analyzer.

NOTE: The cable has a four pin connector at each end of the cable; the cable cannot be connected backwards.

2. Power up the Control System by turning the lower key to the platform or ground position and pulling both emergency stop buttons on.


Using the Analyzer

With the machine power on and the analyzer connected properly, the analyzer will display the following:



**HELP:
PRESS ENTER**


At this point, using the **RIGHT**  and **LEFT**  arrow keys, you can move between the top level menu items. To


select a displayed menu item, press **ENTER** . To cancel a


selected menu item, press **ESC** ; then you will be able to scroll using the right and left arrow keys to select a different menu item.

The top level menus are as follows:

- HELP
- DIAGNOSTICS
- ACTIVATE TEST
- ACCESS LEVEL
- PERSONALITIES
- MACHINE SETUP
- LEVEL VEHICLE (level 1 only)
- CALIBRATIONS (view only)

If you press **ENTER** , at the **HELP: PRESS ENTER** display, and a fault is present, the analyzer display will scroll the fault across the screen. If there was no fault detected, the display will read: **HELP: EVERYTHING OK**. If powered up at the ground station, the display will read: **GROUND OK**.

If **ENTER**  is pressed again, the display moves to the following display:




LOGGED HELP
1: STARTUP (2/1)

At this point, the analyzer will display the last fault the system has seen, if any are present. You may scroll through the fault logs to view what the last 25 faults were. Use the right and left arrow keys to scroll through the fault logs. To return to the

beginning, press **ESC**  two times. **STARTUP (2/1)** indicates a power up.

When a top level menu is selected, a new set of menu items may be offered: for example:


- DRIVE
- BOOM
- SYSTEM
- DATALOG
- VERSIONS

Pressing **ENTER**  with any of the above displayed menus, will display additional sub-menus within the selected menu. In some cases, such as **DRIVE**, the next level is the parameter or information to be changed. Refer to the flow chart for what menus are available within the top level menus. You may only view the personality settings for selected menus while in access level 2. Remember, you may always cancel a selected


menu item by pressing the **ESC**  key.

Changing the Access Level of the Hand Held Analyzer

When the analyzer is first connected, you will be in access level 2 which enables you to only view most settings which cannot be changed until you enter a password to advance to a lower level. This ensures that a setting cannot be accidentally altered. To change the access level, the correct password must be entered. To enter the password, scroll to the **ACCESS LEVEL** menu. For example:




ACCESS LEVEL 2
CODE 0000


Press **ENTER**  to select the **ACCESS LEVEL** menu.

Using the **UP**  / **DOWN**  arrow keys, enter the first digit of the password, 3.

Then using the **RIGHT**  arrow key, position the cursor to the right one space to enter the second digit of the password.

Use the **UP**  / **DOWN**  arrow key to enter the second digit of the password which is 33271.

Once the correct password is displayed, press **ENTER** . The access level should display the following, if the password was entered correctly:




**MENU:
ACCESS LEVEL 1**

Repeat the above steps if the correct access level is not displayed or you can not adjust the personality settings.

Adjusting Parameters Using the Hand Held Analyzer


Once you have gained access to level 1, and a personality item


is selected, press the **UP**  / **DOWN**  arrow keys to adjust its value, for example:





**PERSONALITIES:
DRIVE ACCEL 1.5s**


There will be a minimum and maximum for the value to ensure efficient operation. The Value will not increase if the **UP**

 arrow is pressed when at the maximum value nor will

the value decrease if the **DOWN**  arrow is pressed and the value is at the minimum value for any particular personality. If the value does not change when pressing the up and down arrows, check the access level to ensure you are at access level 1.

Machine Setup

When a machine digit item is selected, press the **UP**  or **DOWN**  arrow keys to adjust its value, for example:



**GROUND ALARM:
2 = LIFT DOWN**

The effect of the machine digit value is displayed along with its value. The above display would be selected if the machine was equipped with a ground alarm and you wanted it to sound when driving. There are certain settings allowed to install optional features or select the machine model.

When selection the machine model to match the size of the machine, the personality settings will all default to the factory recommended settings.

NOTE: Refer to *Personality Ranges/Defaults for the recommended factory settings.*

NOTE: Password 33271 will give you access to level 1, which will permit you to change all machine personality settings.

There is a setting that JLG strongly recommends that you do not change. This setting is so noted below:

ELEVATION CUTBACK

⚠ WARNING

CHANGING THIS SETTING MAY ADVERSELY AFFECT THE PERFORMANCE OF YOUR MACHINE.

NOTICE

ITS IS A GOOD PRACTICE TO AVOID PRESSURE-WASHING ELECTRICAL/ELECTRONIC COMPONENTS. SHOULD PRESSURE-WASHING BE UTILIZED TO WASH AREAS CONTAINING ELECTRICAL/ELECTRONIC COMPONENTS, JLG INDUSTRIES INC. RECOMMENDS A MAXIMUM PRESSURE OF 750 PSI (52 BAR) AT A MINIMUM DISTANCE OF 12 INCHES (30.5 CM) AWAY FROM THESE COMPONENTS. IF ELECTRICAL/ELECTRONIC COMPONENTS ARE SPRAYED, SPRAYING MUST NOT BE DIRECT AND BE FOR BRIEF TIME PERIODS TO AVOID HEAVY SATURATION.


Level Vehicle Description

NOTICE

A NEW TILT MODULE WILL ACT AS IF IT IS TILTED ALL OF THE TIME UNTIL THE FOLLOWING PROCEDURE IS PERFORMED.

⚠ WARNING

DO NOT CALIBRATE THE LEVEL SENSOR EXCEPT ON A LEVEL SURFACE.



Place machine in stowed position with the boom between the rear wheels.

To level machine chose:

**CALIBRATION:
TILT SENSOR**

Press **ENTER** .

When prompted, swing machine to 180°.

Press **ENTER** .

SECTION 6 - JLG CONTROL SYSTEM

Table 6-1. Analyzer Abbreviations

ABBREVIATION	MEANING
ACCEL	ACCELERATE
ACT	ACTIVE
A/D	ANALOG DIGITAL CONVERTER COUNT
AMB.	AMBIENT
ANG	ANGLE
AUX	AUXILIARY
BCS	BOOM CONTROL SYSTEM
BM	BOOM LENGTH ANGLE MODULE
BLAM	BOOM LENGTH ANGLE MODULE
BR	BROKEN
BSK	BASKET
CAL	CALIBRATION
CL	CLOSED
CM	CHASSIS MODULE
CNTL	CONTROL
CNTRL	CONTROL
C/O	CUTOUT
CONT(S)	CONTRACTOR(S)
COOR	COORDINATED
CRKPT	CRACK POINT
CRP	CREEP
CUT	CUTOUT
CYL	CYLINDER
DECEL	DECELERATE
D	DOWN
DN	DOWN
DWN	DOWN
DEG.	DEGREE
DOS	DRIVE ORIENTATION SYSTEM
DRV	DRIVE
E	ERROR
E&T	ELEVATED & TILTED
ELEV	ELEVATION
ENG	ENGINE
EXT	EXTEND
F	FRONT
FL	FLOW
FNT	FRONT
FOR	FORWARD
FWD	FORWARD
FSW	FOOT SWITCH
FUNC	FUNCTION
G	GROUND

Table 6-1. Analyzer Abbreviations

ABBREVIATION	MEANING
GND	GROUND
GRN	GREEN
GM	GROUND MODULE
H	HOURS
HW	HARDWARE
HWFS	HARDWARE FAILSAFE
I	IN or CURRENT
JOY	JOYSTICK
L	LEFT
LB	POUND
LEN	LENGTH
LIM	LIMIT
LT	LEFT
LVL	LEVEL
M	MINUTES
MIN	MINIMUM
MAX	MAXIMUM
M	MAIN
MN	MAIN
NO	NORMALLY OPEN or NO
NC	NORMALLY CLOSED
O	OUT
O/C	OPEN CIRCUIT
OP	OPEN
O/R	OVERRIDE or OUTRIGGER
O//R	OVERRIDE
OSC	OSCILLATING
OVRD	OVERRIDE
P	PLATFORM
P	PRESSURE
PCV	PROPORTIONAL CONTROL VALVE
PLAT	PLATFORM
PLT	PLATFORM
PM	PLATFORM MODULE
POT	POTENTIOMETER
PRES	PRESSURE
PRS	PRESSURE
PT	POINT
R	REAR or RIGHT
REV	REVERSE or REVISION
RET	RETRACT
ROT.	ROTATE
RT	RIGHT

Table 6-1. Analyzer Abbreviations

ABBREVIATION	MEANING
S/C	SHORT CIRCUIT
SEL	SELECTOR
SN	SERIAL NUMBER
SPD	SPEED
STOW	STOWED
STOWD	STOWED
SW	SWITCH or SOFTWARE
TELE	TELESCOPE
TEMP	TEMPERATURE
TORQ.	TORQUE
TRN	TRANSPORT
T/T	TURNTABLE
T	TOWER
TURNTBL	TURNTABLE
TWR	TOWER
U	MAIN or UP
V	VOLT
VER	VERSION
VLV	VALVE
WIT	WITNESS
YEL	YELLOW

Go to Discount-Equipment.com to order your parts




Figure 6-2. ADE Block Diagram

Table 6-2. Machine Configuration Programming Information Prior to Software Version P5.3

Configuration Digit	Number	Description	Default Number
MODELNUMBER: 1	1 2 3 4 5 6 7 8 9 10	400S 450A 510A 600S 600A 600SC 601S 740A 800A 800S	1
MARKET: 2	0 1 2 3 4 5	ANSI USA ANSI EXPORT CSA CE AUSTRALIA JAPAN	0
ENGINE: 3* * Engine selections vary depending on model selection.	1 2 3 4 5 6 7 8 9 10 11	FORD EFI GAS: Ford LRG425 EFI Gas (Tier 1) FORD EFI D/F: Ford LRG425 EFI dual fuel (Tier 1) DEUTZ F4 TIER1: Deutz F4M1011F Diesel (Tier 1) DEUTZ F3 TIER1: Deutz F3M1011F Diesel (Tier 1) CAT. 3024C: CAT 3024C Diesel (Tier 2) CAT. 3044C: CAT 3044C Diesel (Tier 2) DEUTZ F4 TIER2: Deutz F4M2011 Diesel (Tier 2) DEUTZ F3 TIER2: Deutz F3M2011 Diesel (Tier 2) FORD GAS TIER2: Ford LRG425 EFI Gas (Tier 2) FORD D/F TIER2: Ford LRG425 EFI Dual Fuel (Tier 2) DEUTZ ECM: Engine Control Module - ECM	11
FLYWHEEL TEETH: 4* * This menu item is only visible if Deutz engine selections 3 or 4 are selected.	0 1	133 TEETH: 133 flywheel teeth. 110 TEETH: 110 flywheel teeth.	1

SECTION 6 - JLG CONTROL SYSTEM

Table 6-2. Machine Configuration Programming Information Prior to Software Version P5.3

Configuration Digit	Number	Description	Default Number
GLOW PLUG: 5	0	NO GLOW PLUGS: No glow plugs installed.	1
	1	W/O STARTER LOCK: Automatic pre-glow time determined by ambient air temperature; engine start can be attempted at any time during pre-glow.	
	2	W/ STARTER LOCK: Automatic pre-glow time determined by ambient air temperature; engine start is NOT permitted until pre-glow is finished.	
ENGINE SHUTDOWN: 6	0	DISABLED: No engine shutdown.	1
	1	ENABLED: Shutdown engine when coolant temperature is greater than 110 deg. C or the oil pressure is less than 8 psi.	
TILT: 7* *Certain market selections will limit tilt options.	1	5 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep.	1
	2	4 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep.	
	3	3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep.	
	4	4 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up.	
	5	3 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up.	
	<i>Note: Any of the selections above will light the tilt lamp when a tilted condition occurs and will sound the platform alarm when the machine is also above elevation.</i>		
JIB: 8* *Only visible under certain model selections	0	NO: No jib installed.	0
	1	YES: Jib installed which has up and down movements only.	
4 WHEEL STEER: 9* *Only visible under certain model selections.	0	NO: No four-wheel steer installed.	0
	1	YES: Four-wheel steer installed.	
SOFT TOUCH: 10* *Only visible under certain model selections.	0	NO: No soft touch system installed.	0
	1	YES: Soft touch system installed.	
GEN SET/WELDER: 11	0	NO: No generator installed.	0
	1	BELT DRIVE: Belt driven setup.	

Table 6-2. Machine Configuration Programming Information Prior to Software Version P5.3

Configuration Digit	Number	Description	Default Number
GEN SET CUTOUT: 12* * Only visible if Gen Set / Welder Menu selection is not 0.	0	MOTION ENABLED: Motion enabled when generator is ON.	0
	1	MOTION CUTOUT: Motion cutout in platform mode only.	
H & T LIGHTS: 13	0	NO: No head and tail lights installed.	0
	1	YES: Head and tail lights installed.	
CABLE SWITCH: 14* * Only visible under certain model selections. * Certain market and model selections will alter the default setting.	0	NO: No broken cable switch installed.	0
	1	YES: Broken cable switch installed.	
LOAD SYSTEM: 15* * Only visible under certain model selections. * Certain market selections will limit load system options or alter default setting.	0	NO: No load sensor installed.	0
	1	WARN ONLY: Functions in creep, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF).	
	2	CUTOUT PLATFORM: All functions cutout, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF).	
	3	CUTOUT ALL: All functions cutout, flash overload light (500mS on, 500mS off), platform alarm beeps (5 sec ON, 2 sec OFF).	
	4	SPECIAL 1: Functions in creep, overload lamp lit, disables main telescope out & main lift up, platform alarm beeps (5 sec ON, 2 sec OFF).	
LOAD SENSOR: 16* * Only visible if Load Sensor Menu selection is not 0. * Market selections will limit certain load sensor options.	0	1 ON ROTATOR: Use the on-board load sensor for all models except those which use the Leveling Platform Module.	1
	1	4 UNDER PLATFORM: Use the EIM for load sensing.	
FUNCTION CUTOUT: 17* * Only visible under certain market selections. * Certain market selections will limit function cutout options or alter default setting.	0	NO: No drive cutout.	0
	1	BOOM CUTOUT: Boom function cutout while driving above elevation.	
	2	DRIVE CUTOUT: Drive cutout above elevation.	
GROUND ALARM: 18* * Certain market selections will alter default setting.	0	NO: No ground alarm installed.	0
	1	DRIVE: Travel alarm sounds when the drive function is active (Option).	
	2	DESCENT: Descent alarm sounds when lift down is active (Option).	
DRIVE: 19* * Only visible under certain model selections.	0	4WD: Four wheel drive.	0
	1	2WD: Two wheel drive.	
	2	2WD W/ 2-SPEED: Two wheel drive with 2-speed valve.	

SECTION 6 - JLG CONTROL SYSTEM

Table 6-2. Machine Configuration Programming Information Prior to Software Version P5.3

Configuration Digit	Number	Description	Default Number
TEMPERATURE: 20	0	CELSIUS: Celsius unit selection.	1
	1	FAHRENHEIT: Fahrenheit unit selection.	
LEVELING MODE: 21* * Only visible on 800S models.	0	ALL FUNCTIONS: Platform level with all functions.	0
	1	LEVEL LIFT/TELESCOPE: Platform level on lift and telescope only.	

4150364-14

Go to Discount-Equipment.com to order your parts

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

Configuration Label/Digit	Number	Description	Default Number
MODEL NUMBER: 1	1	400S	1
	2	450A	
	3	510A	
	4	600S	
	5	600A	
	6	600SC	
	7	601S	
	8	740A	
	9	800A	
	10	800S	
MARKET: 2	0	ANSI USA	0
	1	ANSI EXPORT	
	2	CSA	
	3	CE	
	4	AUSTRALIA	
	5	JAPAN	

SECTION 6 - JLG CONTROL SYSTEM

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

Configuration Label/Digit	Number	Description	Default Number
ENGINE: 3* * Engine selections vary depending on model selection.	1	FORD EFI GAS: Ford LRG425 EFI Gas (Tier 1)	7
	2	FORD EFI D/F: Ford LRG425 EFI dual fuel (Tier 1)	
	3	DEUTZ F4 TIER1: Deutz F4M1011F Diesel (Tier 1)	
	4	DEUTZ F3 TIER1: Deutz F3M1011F Diesel (Tier 1)	
	5	CAT. 3024C: CAT 3024C Diesel (Tier 2)	
	6	CAT. 3044C: CAT 3044C Diesel (Tier 2)	
	7	PERKINS 404C (Tier 2)	
	8	DEUTZ F4 TIER2: Deutz F4M2011 Diesel (Tier 2)	
	9	DEUTZ F3 TIER2: Deutz F3M2011 Diesel (Tier 2)	
	10	FORD GAS TIER2: Ford LRG425 EFI Gas (Tier 2)	
	11	FORD D/F TIER2: Ford LRG425 EFI Dual Fuel (Tier 2)	
	12	DEUTZ ECM: Engine Control Module - ECM	
	13	DUAL FUEL ECM: GM/PSI 3.0L Dual Fuel (Tier 2)	
FLYWHEEL TEETH: 4* * This menu item is only visible if Deutz engine selections 3 or 4 are selected.	0	133 TEETH: 133 flywheel teeth.	1
	1	110 TEETH: 110 flywheel teeth.	
GLOW PLUG: 5	0	NO GLOW PLUGS: No glow plugs installed.	2
	1	AIR INTAKE: Glow plugs installed in the air intake on the manifold.	
	2	IN-CYLINDER: Glow plugs installed in each cylinder.	
STARTER LOCKOUT: 6	0	DISABLED: Automatic pre-glow time determined by ambient air temperature; engine start can be attempted at any time during pre-glow.	0
	1	ENABLED: Automatic pre-glow time determined by ambient air temperature; engine start is NOT permitted until pre-glow is finished.	

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

Configuration Label/Digit	Number	Description	Default Number
ENGINE SHUTDOWN: 7	0	DISABLED: No engine shutdown.	1
	1	ENABLED: Shutdown engine when coolant temperature is greater than 110 deg. C or the oil pressure is less than 8 PSI.	
TILT: 8* *Certain market selections will limit tilt options and alter default setting. <i>Note: Any of the selections above will light the tilt lamp when a tilted condition occurs and will sound the platform alarm when the machine is also above elevation.</i>	1	5 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep.	1
	2	4 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep.	
	3	3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep.	
	4	4 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up.	
	5	3 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up.	
JIB: 9* *Only visible under certain model selections.	0	NO: No jib installed.	0
	1	YES: Jib installed which has up and down movements only.	
4 WHEEL STEER: 10* *Only visible under certain model selections.	0	NO: No four-wheel steer installed.	0
	1	YES: Four-wheel steer installed.	
SOFT TOUCH: 11* *Only visible under certain model selections.	0	NO: No soft touch system installed.	0
	1	YES: Soft touch system installed.	
GEN SET/WELDER: 12	0	NO: No generator installed.	0
	1	BELT DRIVE: Belt driven setup.	
GEN SET CUTOUT: 13* *Only visible if Gen Set / Welder Menu selection is not 0.	0	MOTION ENABLED: Motion enabled when generator is ON.	0
	1	MOTION CUTOUT: Motion cutout in platform mode only.	

SECTION 6 - JLG CONTROL SYSTEM

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

Configuration Label/Digit	Number	Description	Default Number
H & T LIGHTS: 14	0	NO: No head and tail lights installed.	0
	1	YES: Head and tail lights installed.	
CABLE SWITCH: 15* * Only visible under certain model selections. * Certain market and model selections will alter the default setting.	0	NO: No broken cable switch installed.	0
	1	YES: Broken cable switch installed.	
LOAD SYSTEM: 16* * Only visible under certain market selections. * Certain market selections will limit load system options or alter default setting.	0	NO: No load sensor installed.	0
	1	WARN ONLY: Functions in creep, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF).	
	2	CUTOUT PLATFORM: All functions cutout, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF).	
	3	CUTOUT ALL: All functions cutout, flash overload light (500mS on, 500mS off), platform alarm beeps (5 sec ON, 2 sec OFF).	
	4	SPECIAL 1: Functions in creep, overload lamp lit, disables main telescope out & main lift up, platform alarm beeps (5 sec ON, 2 sec OFF).	
LOAD SENSOR: 17* * Only visible if Load Sensor Menu selection is not 0 and under certain market selections. * Certain market selections will limit load sensor options.	0	1 ON ROTATOR: Use the on-board load sensor for all models except those which use the Leveling Platform Module.	1
	1	4 UNDER PLATFORM: Use the EIM for load sensing.	
FUNCTION CUTOUT: 18* * Only visible under certain market selections. * Certain market selections will limit function cutout options or alter default setting.	0	NO: No drive cutout.	0
	1	BOOM CUTOUT: Boom function cutout while driving above elevation.	
	2	DRIVE CUTOUT: Drive & steer cutout above elevation.	
	3	DRIVE CUTE&T: Drive & steer cutout above elevation and tilted.	

Table 6-3. Machine Configuration Programming Information Software Version P5.3 to P6.1

Configuration Label/Digit	Number	Description	Default Number
GROUND ALARM: 19* * Certain market selections will alter default setting.	0	NO: No ground alarm installed.	3
	1	DRIVE: Travel alarm sounds when the drive function is active (Option).	
	2	DESCENT: Descent alarm sounds when lift down is active (Option).	
	3	MOTION: Motion alarm sounds when any function is active (Option).	
DRIVE: 20* * Only visible under certain model selections.	0	4WD: Four wheel drive.	0
	1	2WD: Two wheel drive.	
	2	2WD W/ 2-SPEED: Two wheel drive with 2-speed valve.	
TEMPERATURE: 21* * Certain market selections will alter default setting.	0	CELSIUS: Celsius unit selection.	1
	1	FAHRENHEIT: Fahrenheit unit selection.	
LEVELING MODE: 22* * Only visible on 800S models.	0	ALL FUNCTIONS: Platform level with all functions.	0
	1	LEVEL LIFT/TELESCOPE: Platform level on lift and telescope only.	

4150364-18

SECTION 6 - JLG CONTROL SYSTEM

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

Configuration Label/Digit	Number	Description	Default Number
MODEL NUMBER: 1	1	400S	1
	2	450A	
	3	510A	
	4	600S	
	5	600A	
	6	600SC	
	7	601S	
	8	740A	
	9	800A	
	10	800S	
MARKET: 2	0	ANSI USA	0
	1	ANSI EXPORT	
	2	CSA	
	3	CE	
	4	AUSTRALIA	
	5	JAPAN	

Go to Discount-Equipment.com to order your parts

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

Configuration Label/Digit	Number	Description	Default Number
ENGINE: 3* * Engine selections vary depending on model selection.	1	FORD EFI GAS: Ford LRG425 EFI Gas (Tier 1)	14
	2	FORD EFI D/F: Ford LRG425 EFI dual fuel (Tier 1)	
	3	DEUTZ F4 TIER1: Deutz F4M1011F Diesel (Tier 1)	
	4	DEUTZ F3 TIER1: Deutz F3M1011F Diesel (Tier 1)	
	5	CAT. 3024C: CAT 3024C Diesel (Tier 2)	
	6	CAT. 3044C: CAT 3044C Diesel (Tier 2)	
	7	PERKINS 404C (Tier 2)	
	8	DEUTZ F4 TIER2: Deutz F4M2011 Diesel (Tier 2)	
	9	DEUTZ F3 TIER2: Deutz F3M2011 Diesel (Tier 2)	
	10	FORD GAS TIER2: Ford LRG425 EFI Gas (Tier 2)	
	11	FORD D/F TIER2: Ford LRG425 EFI Dual Fuel (Tier 2)	
	12	DEUTZ ECM: Engine Control Module - ECM (Tier 2 and Tier 3)	
	13	DUAL FUEL ECM: GM/PSI 3.0L Dual Fuel (Tier 2)	
	14	PERKINSECM	
	15	CAT ECM	
FLYWHEEL TEETH: 4* *This menu item is only visible if Deutz engine selections 3 or 4 are selected.	0	133 TEETH: 133 flywheel teeth.	1
	1	110 TEETH: 110 flywheel teeth.	
GLOW PLUG: 5	0	NO GLOW PLUGS: No glow plugs installed.	2
	1	AIR INTAKE: Glow plugs installed in the air intake on the manifold.	
	2	IN-CYLINDER: Glow plugs installed in each cylinder.	
STARTER LOCKOUT: 6	0	DISABLED: Automatic pre-glow time determined by ambient air temperature; engine start can be attempted at any time during pre-glow.	0
	1	ENABLED: Automatic pre-glow time determined by ambient air temperature; engine start is NOT permitted until pre-glow is finished.	

SECTION 6 - JLG CONTROL SYSTEM

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

Configuration Label/Digit	Number	Description	Default Number
ENGINE SHUTDOWN: 7	0	DISABLED: No engine shutdown.	1
	1	ENABLED: Shutdown engine when coolant temperature is greater than 110 deg. C or the oil pressure is less than 8 PSI.	
TILT: 8* *Certain market selections will limit tilt options and alter default setting. <i>Note: Any of the selections above will light the tilt lamp when a tilted condition occurs and will sound the platform alarm when the machine is also above elevation.</i>	1	5 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep.	1
	2	4 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep.	
	3	3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep.	
	4	4 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up.	
	5	3 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up.	
JIB: 9* *Only visible under certain model selections.	0	NO: No jib installed.	0
	1	YES: Jib installed which has up and down movements only.	
4 WHEEL STEER: 10* *Only visible under certain model selections.	0	NO: No four-wheel steer installed.	0
	1	YES: Four-wheel steer installed.	
SOFT TOUCH: 11* *Only visible under certain model selections.	0	NO: No soft touch system installed.	0
	1	YES: Soft touch system installed.	
GEN SET/WELDER: 12	0	NO: No generator installed.	0
	1	BELT DRIVE: Belt driven setup.	
GEN SET CUTOUT: 13* *Only visible if Gen Set / Welder Menu selection is not 0.	0	MOTION ENABLED: Motion enabled when generator is ON.	0
	1	MOTION CUTOUT: Motion cutout in platform mode only.	

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

Configuration Label/Digit	Number	Description	Default Number
H & T LIGHTS: 14	0	NO: No head and tail lights installed.	0
	1	YES: Head and tail lights installed.	
CABLE SWITCH: 15* * Only visible under certain model selections. * Certain market and model selections will alter the default setting.	0	NO: No broken cable switch installed.	0
	1	YES: Broken cable switch installed.	
LOAD SYSTEM: 16* * Only visible under certain market selections. * Certain market selections will limit load system options or alter default setting.	0	NO: No load sensor installed.	0
	1	WARN ONLY: Functions in creep, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF).	
	2	CUTOUT PLATFORM: All functions cutout, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF).	
	3	CUTOUT ALL: All functions cutout, flash overload light (500mS on, 500mS off), platform alarm beeps (5 sec ON, 2 sec OFF).	
	4	SPECIAL 1: Functions in creep, overload lamp lit, disables main telescope out & main lift up, platform alarm beeps (5 sec ON, 2 sec OFF).	
LOAD SENSOR: 17* * Only visible if Load Sensor Menu selection is not 0 and under certain market selections. * Certain market selections will limit load sensor options.	0	1 ON ROTATOR: Use the on-board load sensor for all models except those which use the Leveling Platform Module.	1
	1	4 UNDER PLATFORM: Use the EIM for load sensing.	
FUNCTION CUTOUT: 18* * Only visible under certain market selections. * Certain market selections will limit function cutout options or alter default setting.	0	NO: No drive cutout.	0
	1	BOOM CUTOUT: Boom function cutout while driving above elevation.	
	2	DRIVE CUTOUT: Drive & steer cutout above elevation.	
	3	DRIVE CUTE&T: Drive & steer cutout above elevation and tilted.	

SECTION 6 - JLG CONTROL SYSTEM

Table 6-4. Machine Configuration Programming Information Software Version P6.1 to Present

Configuration Label/Digit	Number	Description	Default Number
GROUND ALARM: 19* * Certain market selections will alter default setting.	0	NO: No ground alarm installed.	3
	1	DRIVE: Travel alarm sounds when the drive function is active (Option).	
	2	DESCENT: Descent alarm sounds when lift down is active (Option).	
	3	MOTION: Motion alarm sounds when any function is active (Option).	
DRIVE: 20* * Only visible under certain model selections.	0	4WD: Four wheel drive.	0
	1	2WD: Two wheel drive.	
	2	2WD W/ 2-SPEED: Two wheel drive with 2-speed valve.	
TEMPERATURE: 21* * Certain market selections will alter default setting.	0	CELSIUS: Celsius unit selection.	1
	1	FAHRENHEIT: Fahrenheit unit selection.	
LEVELING MODE: 22* * Only visible on 800S models.	0	ALL FUNCTIONS: Platform level with all functions.	0
	1	LEVEL LIFT/TELESCOPE: Platform level on lift and telescope only.	
DRIVE CONTROL: 23	0	NORMAL: Drive coils are energized from the Ground Module.	2
	1	PROPULSION: Drive coils are energized from the Propulsion Module.	
	2	ENHANCED: Drive coils are energized from the Ground Module and the ground side of the drive coils are brought back to current feedback returns.	
CLEARSKY: 24	0	NO: Clearsky (telematics) option is disabled.	0
	1	YES: Clearsky (telematics) option is enabled.	
CRIBBING OPTION: 25	0	NO: Cribbing Option is disabled.	0
	1	YES: Cribbing Option is enabled.	

4150364-19

Table 6-5. Machine Configuration Programming Information

Configuration Digit	Number	Description	Default Number
<p>NOTE: For version 6.X software, some screens may not be available depending upon machine configuration and software versions.</p> <p>NOTE: The machine configuration must be completed before any personality settings can be changed. Changing the personality settings first and then changing the model number of the machine configuration will cause the personality settings to return to default values.</p>			
MODEL NUMBER: 1	1	400S	1
	2	450A	
	3	510A	
	4	600S	
	5	600A	
	6	600SC	
	7	601S	
	8	740A	
	9	800A	
	10	800S	
MARKET: 2	0	ANSI USA	0
	1	ANSI EXPORT	
	2	CSA	
	3	CE	
	4	AUSTRALIA	
	5	JAPAN	
	6	GB	

SECTION 6 - JLG CONTROL SYSTEM

Table 6-5. Machine Configuration Programming Information

Configuration Digit	Number	Description	Default Number
ENGINE: 3* * Engine selections vary depending on model selection.	1	FORD EFI GAS: Ford LRG425 EFI Gas (Tier 1)	14
	2	FORD EFI D/F: Ford LRG425 EFI dual fuel (Tier 1)	
	3	DEUTZ F4 TIER1: Deutz F4M1011F Diesel (Tier 1)	
	4	DEUTZ F3 TIER1: Deutz F3M1011F Diesel (Tier 1)	
	5	CAT.3024C: CAT 3024C Diesel (Tier 2)	
	6	CAT. 3044C: CAT 3044C Diesel (Tier 2)	
	7	PERKINS 404C (Tier 2)	
	8	DEUTZ F4 TIER2: Deutz F4M2011 Diesel (Tier 2)	
	9	DEUTZ F3 TIER2: Deutz F3M2011 Diesel (Tier 2)	
	10	FORD GASTIER2: Ford LRG425 EFI Gas (Tier 2)	
	11	FORD D/F TIER2: Ford LRG425 EFI Dual Fuel (Tier 2)	
	12	DEUTZ ECM: Engine Control Module - ECM (Tier 2 and Tier 3)	
	13	DUAL FUEL ECM: GM/PSI 3.0L Dual Fuel (Tier 2)	
	14	PERKINSECM	
	15	CAT ECM	
	16	DEUTZ EMR4: Deutz Engine Control Module (Tier 4 Final)	
	17	FORD DUAL FUEL	
FLYWHEEL TEETH: 4* *This menu item is only visible if Deutz engine selections 3 or 4 are selected.	0	133 TEETH: 133 flywheel teeth.	1
	1	110 TEETH: 110 flywheel teeth.	

Table 6-5. Machine Configuration Programming Information

Configuration Digit	Number	Description	Default Number
GLOW PLUG: 5	0	NO GLOW PLUGS: No glow plugs installed.	2
	1	AIR INTAKE: Glow plugs installed in the air intake on the manifold.	
	2	IN-CYLINDER: Glow plugs installed in each cylinder.	
STARTER LOCKOUT: 6	0	DISABLED: Automatic pre-glow time determined by ambient air temperature; engine start can be attempted at any time during pre-glow.	0
	1	ENABLED: Automatic pre-glow time determined by ambient air temperature; engine start is NOT permitted until pre-glow is finished.	
FUEL CUTOUT 7 * This menu item is only visible if non dual fuel engines are selected.	0	RESTART: Engine allowed to be restarted multiple times when very low fuel level is reached.	0
	1	ONE RESTART: Engine allowed to be restarted once for 2 minutes when very low fuel level is reached.	
	2	ENGINE STOP: Engine not able to restart when very low fuel level is reached.	
ENGINE SHUTDOWN: 8	0	DISABLED: No engine shutdown.	1
	1	ENABLED: Shutdown engine when coolant temperature is greater than 110 deg. C or the oil pressure is less than 8 PSI (0.55 bar).	

Table 6-5. Machine Configuration Programming Information

Configuration Digit	Number	Description	Default Number
TILT: 9* *Certain market selections will limit tilt options and alter default setting. <i>Note: Any of the selections above will light the tilt lamp when a tilted condition occurs and will sound the platform alarm when the machine is also above elevation.</i>	1	5 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep.	1
	2	4 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep.	
	3	3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep.	
	4	4 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up.	
	5	3 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up.	
	6	5 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up.	
	7	5 DEG + DRV CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep when drive reversal is allowed, drive is disallowed otherwise.	
	8	4 DEG + DRV CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep when drive reversal is allowed, drive is disallowed otherwise.	
	9	3 DEG + DRV CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep when drive reversal is allowed, drive is disallowed otherwise.	
JIB: 10* *Only visible under certain model selections.	0	NO: No jib installed.	0
	1	YES: Jib installed which has up and down movements only.	
4 WHEEL STEER: 11* *Only visible under certain model selections.	0	NO: No four-wheel steer installed.	0
	1	YES: Four-wheel steer installed.	

Table 6-5. Machine Configuration Programming Information

Configuration Digit	Number	Description	Default Number
STOUCH/SKYGUARD: 12	0	NONE: No soft touch or skyguard system installed.	0
	1	SOFT TOUCH - Soft touch only installed.	
	2	SKYGUARD - Skyguard only installed.	
	3	BOTH (CUTOUT) - Soft touch and Skyguard installed.	
GENSET/WELDER: 13	0	NO: No generator installed.	0
	1	BELT DRIVE: Belt driven setup.	
GENSET CUTOUT: 14* * Only visible if Gen Set / Welder Menu selection is not 0.	0	MOTION ENABLED: Motion enabled when generator is ON.	0
	1	MOTION CUTOUT: Motion cutout in platform mode only.	
H & T LIGHTS: 15	0	NO: No head and tail lights installed.	0
	1	YES: Head and tail lights installed.	
CABLE SWITCH: 16* * Only visible under certain model selections. * Certain market and model selections will alter the default setting.	0	NO: No broken cable switch installed.	0
	1	YES: Broken cable switch installed.	

SECTION 6 - JLG CONTROL SYSTEM

Table 6-5. Machine Configuration Programming Information

Configuration Digit	Number	Description	Default Number
LOAD SYSTEM: 17* * Only visible under certain market selections. * Certain market selections will limit load system options or alter default setting. * LOAD SYSTEM will not be visible in CE and defaulted to CUTOUT ALL for machines equipped with MSSO.	0	NO: No load sensor installed.	0
	1	WARN ONLY: Functions in creep, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF).	
	2	CUTOUT PLATFORM: All functions cutout, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF).	
	3	CUTOUT ALL: All functions cutout, flash overload light (500mS on, 500mS off), platform alarm beeps (5 sec ON, 2 sec OFF).	
	4	SPECIAL 1: Functions in creep, overload lamp lit, disables main telescope out & main lift up, platform alarm beeps (5 sec ON, 2 sec OFF).	
LOAD SENSOR: 18* * Only visible if Load Sensor Menu selection is not 0 and under certain market selections. * Certain market selections will limit load sensor options.	0	1 ON ROTATOR: Use the on-board load sensor for all models except those which use the Leveling Platform Module.	1
	1	4 UNDER PLATFORM: Use the EIM for load sensing.	
	2	SINGLE CELL: Single Cell, CANbus based sensor.	
FUNCTION CUTOUT: 19* * Only visible under certain market selections. * Certain market selections will limit function cutout options or alter default setting.	0	NO: No drive cutout.	0
	1	BOOM CUTOUT: Boom function cutout while driving above elevation.	
	2	DRIVE CUTOUT: Drive & steer cutout above elevation.	
	3	DRIVE CUTE&T: Drive & steer cutout above elevation and tilted.	
GROUND ALARM: 20* * Certain market selections will alter default setting.	0	NO: No ground alarm installed.	3
	1	DRIVE: Travel alarm sounds when the drive function is active (Option).	
	2	DESCENT: Descent alarm sounds when lift down is active (Option).	
	3	MOTION: Motion alarm sounds when any function is active (Option).	
DRIVE: 21* * Only visible under certain model selections.	0	4WD: Four wheel drive.	0
	1	2WD: Two wheel drive.	
	2	2WD W/ 2-SPEED: Two wheel drive with 2-speed valve.	

Table 6-5. Machine Configuration Programming Information

Configuration Digit	Number	Description	Default Number
DISPLAY UNITS: 22*	0	IMPERIAL: DEG F, PSI, LBS.	0
*Certain market selections will alter default setting.	1	METRIC: DEG C, KPA, KGS	
LEVELING MODE: 23*	0	ALL FUNCTIONS: Platform level with all functions.	0
*Only visible on 800S models.	1	LEVEL LIFT/TELESCOPE: Platform level on lift and telescope only.	
DRIVE CONTROL: 24	0	NORMAL: Drive coils are energized from the Ground Module.	2
	1	PROPULSION: Drive coils are energized from the Propulsion Module.	
	2	ENHANCED: Drive coils are energized from the Ground Module and the ground side of the drive coils are brought back to current feedback returns.	
DRIVE PUMP 25*	0	SAUER DANFOSS: Machine equipped with Sauer Danfoss drive pump	0
*Only visible on 600A, 600S, and 800S models.	1	EATON: Machine equipped with Eaton drive pump.	
	2	M46 - XXXX: Machine equipped with M46 - XXXX drive pump.	
	3	830XXXXX: Machine equipped with 830XXXXX: drive pump.	
BOOM CONTROL: 26	0	NORMAL: Boom function coils are energized from the Ground Module.	0
	1	ENHANCED: Boom function are energized from the Ground Module and the ground side of the drive coils and brought back to current feedback returns.	
FUNCTION SPEED KNOB: 27	0	YES: Machine is equipped with Function Speed Knob.	0
	1	NO: Machine is equipped with Operation Speed Switch.	
CLEARSKY: 28	0	NO: Clearsky (telematics) option is disabled.	0
	1	YES: Clearsky (telematics) option is enabled.	

SECTION 6 - JLG CONTROL SYSTEM

Table 6-5. Machine Configuration Programming Information

Configuration Digit	Number	Description	Default Number
CRIBBING OPTION: 29	0	NO: Cribbing Option is disabled.	0
	1	YES: Cribbing Option is enabled.	
FUEL TANK SIZE: 30	0	31 Gallon Tank	0
	1	52 Gallon Tank	
ALARM / HORN: 31	0	SEPERATE: Separate alarm and horn.	0
	1	COMBINED: Combination alarm / horn.	
ALERT / BEACON: 32	0	OFF FOR CREEP: Alert beacon will not flash while in Creep.	0
	1	20 FPS FOR CREEP: Alert beacon will flash at 20 FPS while in Creep.	
TEMP CUTOUT: 33	0	NO: Temp Cutout is Disabled	0
	1	YES: Temp Cutout is Enabled	
PLAT LVL OVR CUT: 34	0	NO: Platform Level Override will always be functional.	0
	1	YES: Platform Level Override will only be functional when In Transport.	
WATER IN FUEL SENSOR: 35* *This menu item is only visible if Deutz EMR 4 engine is selected. *Only visible under certain market selections.	0	NO: Water in Fuel Sensor Disabled.	0
	1	YES: Water in Fuel Sensor Enabled.	

4150364 U

Table 6-6. 600S Machine Configuration Programming Settings

600 S	ANSI USA	ANSI Export	CSA	CE	Australia	Japan	GB
Model Number	4	4	4	4	4	4	4
Market	0	1	2	3	4	5	3
Engine	12	12	12	12	12	12	12
Flywheel Teeth	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Glow Plug	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Starter Lockout	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Fuel Cutout	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Engine Shut-down	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Tilt	1	1	1	X	X	1	X
	2	2	2	X	2	2	X
	3	3	3	X	3	3	X
	4	4	4	4	4	4	4
	5	5	5	5	5	5	5
	6	6	6	X	X	6	X
	7	7	7	X	X	7	X
	8	8	8	8	8	8	8
	9	9	9	9	9	9	9
Jib	0	0	0	0	0	0	0
4Wheel Steer	0	0	0	0	0	0	0
Soft Touch/Skyguard	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
	3	3	3	3	3	3	3
Gen Set/Welder	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Gen Set Cutout	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Head & Tail-lights	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Cable Break Switch	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Load System	0	0	0	0	0	0	0
	X	1	X	X	X	1	X
	X	2	X	2	2	2	2
	X	3	X	3	X	3	3
	X	4	X	X	X	4	X

Table 6-6. 600S Machine Configuration Programming Settings

600 S	ANSI USA	ANSI Export	CSA	CE	Australia	Japan	GB
Load Sensor	X	0	X	0	0	0	0
	1	1	1	1	1	1	1
	X	2	X	2	2	2	2
Function Cut-out	0	0	0	0	0	0	0
	X	1	1	1	1	1	1
	2	2	2	X	2	2	2
	X	3	3	X	3	3	3
Ground Alarm	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
	3	3	3	3	3	3	3
Drive Type	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Display Units	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Leveling Mode	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Drive Control	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Drive Pump	X	X	X	X	X	X	X
	X	X	X	X	X	X	X
	2	2	2	2	2	2	2
	3	3	3	3	3	3	3
Boom Control	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Function Speed Knob	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Clearsky	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Cribbing Option	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Fuel Tank Size	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Alarm/Horn	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Alert Beacon	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Temp Cutout	X	0	X	0	X	X	0
	X	1	X	1	X	X	1
Plat Lvl Ovr Cut	0	0	0	0	0	0	0
	1	1	1	1	1	1	1

SECTION 6 - JLG CONTROL SYSTEM

Table 6-6. 600S Machine Configuration Programming Settings

600 S	ANSI USA	ANSI Export	CSA	CE	Australia	Japan	GB
Water Fuel Sensor	X	0	X	X	X	X	0
	X	1	X	X	X	X	1
Dual Capacity	0	0	0	0	0	0	0
	1	1	1	1	1	1	1

BOLD BLUE text indicates the default setting. Plain text indicates another available selection. **RED ITALIC** text indicates the default when option is factory installed. SHADED CELLS indicate hidden menu or selection.

Table 6-7. 600SJ Machine Configuration Programming Settings

600 SJ	ANSI USA	ANSI Export	CSA	CE	Australia	Japan	GB
Model Number	4	4	4	4	4	4	4
Market	0	1	2	3	4	5	3
Engine	12	12	12	12	12	12	12
Flywheel Teeth	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Glow Plug	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Starter Lockout	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Fuel Cutout	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Engine Shut-down	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Tilt	1	1	1	X	X	1	X
	2	2	2	X	2	2	X
	3	3	3	X	3	3	X
	4	4	4	4	4	4	4
	5	5	5	5	5	5	5
	6	6	6	X	X	6	X
	7	7	7	X	X	7	X
	8	8	8	8	8	8	8
	9	9	9	9	9	9	9
Jib	1	1	1	1	1	1	1
4 Wheel Steer	0	0	0	0	0	0	0
Soft Touch/Skyguard	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
	3	3	3	3	3	3	3
Gen Set/Welder	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Gen Set Cutout	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Head & Tail-lights	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Cable Break Switch	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Load System	0	0	0	0	0	0	0
	X	1	X	X	X	1	X
	X	2	X	2	2	2	2
	X	3	X	3	X	3	3
	X	4	X	X	X	4	X

Table 6-7. 600SJ Machine Configuration Programming Settings

600 SJ	ANSI USA	ANSI Export	CSA	CE	Australia	Japan	GB
Load Sensor	X	0	X	0	0	0	0
	1	1	1	1	1	1	1
	X	2	X	2	2	2	2
Function Cut-out	0	0	0	0	0	0	0
	X	1	1	1	1	1	1
	2	2	2	X	2	2	2
Ground Alarm	X	3	3	X	3	3	3
	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Drive Type	2	2	2	2	2	2	2
	3	3	3	3	3	3	3
	0	0	0	0	0	0	0
Display Units	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
	3	3	3	3	3	3	3
Leveling Mode	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Drive Control	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Drive Pump	X	X	X	X	X	X	X
	X	X	X	X	X	X	X
	2	2	2	2	2	2	2
Boom Control	3	3	3	3	3	3	3
	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Function Speed Knob	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Clearsky	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Cribbing Option	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Fuel Tank Size	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Alarm / Horn	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Alert Beacon	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Temp Cutout	X	0	X	0	X	X	0
	X	1	X	1	X	X	1
	2	2	2	2	2	2	2
Plat Lvl Ovr Cut	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2

Table 6-7. 600SJ Machine Configuration Programming Settings

600 SJ	ANSI USA	ANSI Export	CSA	CE	Australia	Japan	GB
Water Fuel Sensor	X	0	X	X	X	X	0
	X	1	X	X	X	X	1
Dual Capacity	0	0	0	0	0	0	0
	1	<i>1</i>	1	1	1	<i>1</i>	<i>1</i>

BOLD BLUE text indicates the default setting. Plain text indicates another available selection. **RED ITALIC** text indicates the default when option is factory installed. SHADED CELLS indicate hidden menu or selection.

Table 6-8. 660SJ Machine Configuration Programming Settings

660 SJ	ANSI USA	ANSI Export	CSA	CE	Australia	Japan	GB
Model Number	4	4	4	4	4	4	4
Market	0	1	2	3	4	5	3
Engine	12	12	12	12	12	12	12
Flywheel Teeth	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Glow Plugs	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Starter Lockout	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Fuel Cutout	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Engine Shut-down	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Tilt	1	1	1	X	X	1	X
	2	2	2	X	2	2	X
	3	3	3	X	3	3	X
	4	4	4	4	4	4	4
	5	5	5	5	5	5	5
	6	6	6	X	X	6	X
	7	7	7	X	X	7	X
	8	8	8	8	8	8	8
	9	9	9	9	9	9	9
Jib	1	1	1	1	1	1	1
4 Wheel Steer	0	0	0	0	0	0	0
Soft Touch/Skyguard	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
	3	3	3	3	3	3	3
Gen Set/Welder	0	0	0	0	0	0	0
	1	1	1	1	1	1	1

SECTION 6 - JLG CONTROL SYSTEM

Table 6-8. 660SJ Machine Configuration Programming Settings

660 SJ	ANSI USA	ANSI Export	CSA	CE	Australia	Japan	GB
Gen Set Cutout	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Head & Tail-lights	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Cable Break Switch	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Load System	0	0	0	0	0	0	0
	X	<i>1</i>	X	X	X	1	X
	X	2	X	2	2	2	2
	X	3	X	3	X	3	3
	X	4	X	X	X	4	X
Load Sensor	X	0	X	0	0	0	0
	1	1	1	1	1	1	1
	X	2	X	2	2	2	2
Function Cut-out	0	0	0	0	0	0	0
	X	1	1	1	1	1	1
	2	2	2	X	2	2	2
	X	3	3	X	3	3	3
Ground Alarm	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
	3	3	3	3	3	3	3
Drive Type	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Display Units	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Leveling Mode	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Drive Control	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
	2	2	2	2	2	2	2
Drive Pump	X	X	X	X	X	X	X
	X	X	X	X	X	X	X
	2	2	2	2	2	2	2
	3	3	3	3	3	3	3
Boom Control	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Function Speed Knob	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Clearsky	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Cribbing Option	0	0	0	0	0	0	0
	1	1	1	1	1	1	1

Table 6-8. 660SJ Machine Configuration Programming Settings

660 SJ	ANSI USA	ANSI Export	CSA	CE	Australia	Japan	GB
Fuel Tank Size	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Alarm / Horn	0	0	0	0	0	0	0
Alert Beacon	0	0	0	0	0	0	0
Temp Cutout	X	0	X	0	X	X	0
	X	1	X	1	X	X	1
Plat Lvl Ovr Cut	0	0	0	0	0	0	0
	1	1	1	1	1	1	1
Water Fuel Sensor	X	0	X	X	X	X	0
	X	1	X	X	X	X	1
Dual Capacity	0	0	0	0	0	0	0
	1	<i>1</i>	1	1	1	<i>1</i>	<i>1</i>

BOLD BLUE text indicates the default setting. Plain text indicates another available selection. **RED ITALIC** text indicates the default when option is factory installed. SHADED CELLS indicate hidden menu or selection.

6.2 MACHINE PERSONALITY SETTINGS AND FUNCTION SPEEDS

NOTE: Personality settings can be adjusted within the adjustment range in order to achieve optimum machine performance.

Table 6-9. Machine Personality Settings

FUNCTION	PERSONALITY	RANGE	DEFAULTS-600S
DRIVE	ACCEleration	0.0 to 5.0 s	2.5
	DECEleration	0.0 to 3.0 s	0.8
	FORward MINImum speed	1 to 35%	4
	FORward MAXImum speed	1 to 100%	30
	REVerse MINImum speed	1 to 35%	4
	REVerse MAXImum speed	1 to 100%	31
	ELEVATED MAXImum speed	1 to 100%	18
	CREEP MAXImum speed	1 to 90%	15
STEER	MAXImum speed	1 to 100%	100
MAIN LIFT	ACCEleration	0.0 to 5.0s	2.5
	DECEleration	0.0 to 3.0s	1
	MINImum UP speed	1 to 60%	40
	MAXImum UP speed	1 to 100%	93
	CREEP UP speed	1 to 65%	65
	MINImum DOWN speed	1 to 60%	40
	MAXImum DOWN speed	1 to 100%	100
	CREEP DOWN speed	1 to 75%	69
SWING	ACCEleration	0.0 to 5.0s	2
	DECEleration	0.0 to 3.0s	1.8
	MINImum LEFT speed	1 to 50%	45
	MAXImum LEFT speed	1 to 100%	76
	CREEP maximum LEFT speed	1 to 65%	63
	MINImum RIGHT speed	1 to 50%	45
	MAXImum RIGHT speed	1 to 100%	76
	CREEP maximum RIGHT speed	1 to 65%	63
MAIN TELESCOPE	ACCEleration	0.0 to 5.0s	3.5
	DECEleration	0.0 to 3.0s	1.5
	MINImum IN speed	1 to 65%	48
	MAXImum IN speed	1 to 100%	80
	MINImum OUT speed	1 to 65%	49
	MAXImum OUT speed	1 to 100%	100
	Medium Speed	0.01 to 1.00	0.45

SECTION 6 - JLG CONTROL SYSTEM

Table 6-9. Machine Personality Settings

FUNCTION	PERSONALITY	RANGE	DEFAULTS-600S
PLATFORM LEVEL	ACCEleration	0.0 to 5.0s	2.5
	DECEleration	0.0 to 3.0s	0.5
	MINimum UP speed	1 to 65%	30
	MAXimum UP speed	1 to 100%	75
	MINimum DOWN speed	1 to 65%	30
	MAXimum DOWN speed	1 to 100%	75
	Medium Speed	0.01 to 1.00	0.40
PLATFORM ROTATE	ACCEleration	0.0 to 5.0s	1.9
	DECEleration	0.0 to 3.0s	0.8
	MINimum LEFT speed	1 to 100%	25
	MAXimum LEFT speed	1 to 100%	100
	MINimum RIGHT speed	1 to 100%	25
	MAXimum RIGHT speed	1 to 100%	100
	Medium Speed	0.01 to 1.00	0.45
JIB LIFT	Lift ACCEleration	0.0 to 5.0s	1.8
	Lift DECEleration	0.0 to 3.0s	0.8
	MINimum UP speed	1 to 65%	30
	MAXimum UP speed	1 to 100%	40
	MINimum down	1 to 65%	30
	MAXimum Down	1 to 100%	43
	Medium Speed	0.01 to 1.00	0.60
GROUND MODE	Tower LIFT UP speed	1 to 100%	N/A
	Tower LIFT DOWN speed	1 to 100%	N/A
	Main LIFT UP speed	1 to 100%	85
	Main LIFT DOWN speed	1 to 100%	92
	SWING speed	1 to 100%	75
	Main TELEscope speed	1 to 100%	70
	Tower TELEscope speed	1 to 100%	N/A
	Platform ROTATE speed	1 to 100%	99
	Platform LEVEL speed	1 to 100%	74
	Jib LIFT (UP/DOWN) speed	1 to 100%	39
	Jib Swing (LEFT/RIGHT) speed	1 to 100%	N/A
Note: Ground Mode speed are automatically limited to being lower than platform speed for a given function.			

41503651

6.3 MACHINE ORIENTATION WHEN DOING SPEED TESTS

Lift: Boom Retracted. Lift Up, Record Time, Lift Down, Record Time.

Swing: Boom at Full Elevation. Telescope Retracted. Swing the Turntable off center and stop. Swing the opposite direction and start the test when the turntable is centered up. This eliminates ramp up and down on the controller affecting times.

Telescope: Boom at Full Elevation; Telescope Retracted; Telescope Out, Record Time. Telescope In, Record Time.

Drive: Test should be done on a smooth level surface. Drive Select Switch should be set to high speed. Start approximately 25 ft. (7.62 m) from the starting point so that the unit is at maximum speed when starting the test. Results should be recorded for a 200 ft. (60.96 m) course. Drive Forward, Record Time. Drive Reverse, Record Time.

Drive (Above Horizontal): Test should be done on a smooth level surface. Drive Select Switch should be set to High Engine, High Speed. The boom should be raised above horizontal. The platform speed control knob should be selected out of creep speed. Results should be recorded for a 50 ft. (15.2 m) course. Drive Forward, Record Time. Drive Reverse, Record Time.

Platform Rotate: Platform level and completely rotated one direction. Rotate the opposite direction, Record Time. Rotate the other direction, Record Time.

Articulating Jib: Platform level and centered with the boom. Start with the Jib down. Jib Up, Record Time. Jib Down, Record Time.


Test Notes

1. Stop watch should be started with the function, not with the controller or switch.
2. Drive test results reflect on 600S, 600SJ & 660SJ, air or foam filled.
3. All speed tests are run from the platform. These speeds do not reflect the ground control operation.
4. The platform speed knob control must be at full speed (turned clockwise completely).
5. Function speeds may vary due to cold, thick hydraulic oil. Test should be run with the oil temperature above 100° F (38° C).
6. Some flow control functions may not work with the speed knob clicked into the creep position.

Table 6-10. Function Speeds (In Seconds)

Function	Speed (Seconds)
Lift Up	46-60
Lift Down	33-43
Swing Right & Left (No more than 10% difference between swing left and swing right.)	79-101
Telescope In	25-33
Telescope Out	50-67
Platform Rotate Right & Left (No more than 15% difference between rotate left and rotate right.)	16-25
Articulating Jib Up	22-34
Articulating Jib Down	16-26
Drive (2 - WD & 4 - WD) (Other Engines) (Forward & Reverse)	30-34 (4.25 MPH)
Drive (2 - WD & 4 - WD) (Deutz Engine) (Forward & Reverse)	34-38 (4.02 MPH)
Drive (2 - WD & 4 - WD) (Above Horizontal) (Forward & Reverse)	46-54 (0.68 MPH)

4150501-F



Note: Some screens may not be available depending upon machine configuration.

Figure 6-3. Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 1 of 4




Figure 6-4. Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 2 of 4




Figure 6-5. Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 3 of 4



Figure 6-6. Analyzer Flow Chart, Prior to Version 5.X Software - Sheet 4 of 4



TO:
PERSONALITIES:
TOWER LIFT

TO:
MENU:
MACHINE SETUP

NOTE: Some screens may not be available depending upon machine configuration.

Figure 6-7. Analyzer Flow Chart, Version 5.X Software - Sheet 1 of 4



Figure 6-8. Analyzer Flow Chart, Version 5.X Software - Sheet 2 of 4




Figure 6-9. Analyzer Flow Chart, Version 5.X Software - Sheet 3 of 4






Figure 6-10. Analyzer Flow Chart, Version 5.X Software - Sheet 4 of 4

SECTION 6 - JLG CONTROL SYSTEM




NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-11. Analyzer Flow Chart -Sheet 1 of 8




NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-12. Analyzer Flow Chart -Sheet 2 of 8



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-13. Analyzer Flow Chart -Sheet 3 of 8



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-14. Analyzer Flow Chart -Sheet 4 of 8

SECTION 6 - JLG CONTROL SYSTEM



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-15. Analyzer Flow Chart -Sheet 5 of 8



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-16. Analyzer Flow Chart -Sheet 6 of 8

SECTION 6 - JLG CONTROL SYSTEM



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-17. Analyzer Flow Chart - Sheet 7 of 8



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-18. Analyzer Flow Chart -Sheet 8 of 8





Figure 6-19. Control Module Location



PLATFORM CONNECTION



GROUND CONTROL CONNECTION

Figure 6-20. Analyzer Connecting Points

SECTION 6 - JLG CONTROL SYSTEM






Figure 6-21. Ground Control Module - Sheet 1 of 3



1001103667 Y

Figure 6-22. Ground Control Module - Sheet 2 of 3


Connector	Pin	Function	Type	
J8 (Black)	1	MODULE GROUND	GROUND	OUTPUT
	2	MODULE POWER	VBAT	INPUT
	3	GROUND TO PLATFORM MODULE	GROUND	INPUT
	4	POWER TO PLATFORM MODULE	VBAT	OUTPUT



Connector	Pin	Function	Type	
J4 (Blue)	1	CRIBBING ENGAGED INDICATOR	DIGITAL	OUTPUT
	2	500 LB CAPACITY LAMP	DIGITAL	OUTPUT
	3	GLOWPLUG INDICATOR	DIGITAL	OUTPUT
	4	ENGINE START	DIGITAL	INPUT
	5	PLATFORM LEVEL DOWN	DIGITAL	INPUT
	6	PLATFORM ROTATE LEFT	DIGITAL	INPUT
	7	MAIN TELESCOPE IN	DIGITAL	INPUT
	8	JIB DOWN	DIGITAL	INPUT
	9	JIB LEFT	DIGITAL	INPUT
	10	TOWER LIFT UP	DIGITAL	INPUT
	11	TOWER TELESCOPE IN	DIGITAL	INPUT
	12	HOURLY METER	DIGITAL	OUTPUT
	13	RETURN FILTER BY-PASS LAMP	DIGITAL	OUTPUT
	14	PLATFORM OVERLOADED INDICATOR	DIGITAL	OUTPUT
	15	BOOM MALFUNCTION INDICATOR	DIGITAL	OUTPUT
	16	AUXILIARY POWER / FUNCTION ENABLE	DIGITAL	INPUT
	17	PLATFORM LEVEL UP	DIGITAL	INPUT
	18	PLATFORM ROTATE RIGHT	DIGITAL	INPUT
	19	JIB UP	DIGITAL	INPUT
	20	JIB RIGHT	DIGITAL	INPUT
	21	TOWER LIFT DOWN	DIGITAL	INPUT
	22	TOWER TELESCOPE OUT	DIGITAL	INPUT
	23	MAIN LIFT UP	DIGITAL	INPUT
	24	BATTERY VOLTAGE	VBAT	OUTPUT
	25	BATTERY VOLTAGE - (GROUND ENABLE PRESENT)	VBAT	OUTPUT
	26	BATTERY LOW / NOT CHARGING INDICATOR	DIGITAL	OUTPUT
	27	CHARGE PUMP FILTER BY-PASS LAMP	DIGITAL	OUTPUT
	28	ENGINE HIGH COOLANT TEMPERATURE INDICATOR	DIGITAL	OUTPUT
	29	ENGINE LOW OIL PRESSURE INDICATOR	DIGITAL	OUTPUT
	30	MAIN TELESCOPE OUT	DIGITAL	INPUT
	31	GROUND	GROUND	INPUT
	32	GROUND	GROUND	INPUT
	33	MAIN LIFT DOWN	DIGITAL	INPUT
	34	SWING LEFT	DIGITAL	INPUT
	35	SWING RIGHT	DIGITAL	INPUT

1001103667 Y

Figure 6-23. Ground Control Module - Sheet 3 of 3



CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J2 GRAY	1	UNALLOCATED	DIGITAL INPUT
	2	UNALLOCATED	DIGITAL INPUT
	3	BATTERY VOLTAGE	HS DIGITAL INPUT
	4	DRIVE ORIENTATION SYSTEM OVERRIDE SWITCH	HS DIGITAL INPUT
	5	UNALLOCATED	LAMP OUTPUT
	6	CHASSIS TILTED INDICATOR	LAMP OUTPUT
	7	FUNCTION ENABLE INDICATOR	LAMP OUTPUT
	8	VEHICLE SYSTEM DISTRESS INDICATOR	LAMP OUTPUT
	9	CREEP SPEED INDICATOR	LAMP OUTPUT
	10	BROKEN CABLE INDICATOR	LAMP OUTPUT
	11	PLATFORM OVERLOADED INDICATOR	LAMP OUTPUT
	12	500 LB CAPACITY INDICATOR	LAMP OUTPUT
	13	1000 LB CAPACITY INDICATOR	LAMP OUTPUT
	14	DRIVE ORIENTATION SYSTEM INDICATOR	LAMP OUTPUT
	15	GENERATOR ON INDICATOR	LAMP OUTPUT
	16	SOFT TOUCH TRIGGERED INDICATOR	LAMP OUTPUT
	17	GLOW PLUG ENGAGED INDICATOR	LAMP OUTPUT
	18	LAMP RETURN	GROUND
	19	DRIVE DISABLED INDICATOR	LAMP OUTPUT
	20	UPRIGHT TILTED INDICATOR	LAMP OUTPUT
	21	LOW FUEL INDICATOR	LAMP OUTPUT
	22	1/4 FUEL LEVEL INDICATOR	LAMP OUTPUT
	23	3/4 FUEL LEVEL INDICATOR	LAMP OUTPUT
	24	1/2 FUEL LEVEL INDICATOR	LAMP OUTPUT
	25	FUEL LEVEL INDICATORS RETURN	GROUND
	26	ANALYZER POWER	ANALYZER POWER
	27	ANALYZER GROUND	ANALYZER GROUND
	28	ANALYZER RX	ANALYZER RX
	29	ANALYZER TX	ANALYZER TX
	30	BATTERY VOLTAGE	BATTERY VOLTAGE
	31	BATTERY VOLTAGE	BATTERY VOLTAGE
	32	BATTERY VOLTAGE	BATTERY VOLTAGE
	33	BATTERY VOLTAGE	BATTERY VOLTAGE
	34	SWITCH POWER	BATTERY VOLTAGE
	35	FULL FUEL LEVEL INDICATOR	LAMP OUTPUT

CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J1 NATURAL	1	TOWER LIFT UP	DIGITAL INPUT
	2	TOWER LIFT DOWN	DIGITAL INPUT
	3	TOWER TELESCOPE IN	DIGITAL INPUT
	4	TOWER TELESCOPE OUT	DIGITAL INPUT
	5	MAIN TELESCOPE IN	DIGITAL INPUT
	6	MAIN TELESCOPE OUT	DIGITAL INPUT
	7	PLATFORM ROTATE RIGHT	DIGITAL INPUT
	8	PLATFORM ROTATE LEFT	DIGITAL INPUT
	9	PLATFORM LEVEL UP	DIGITAL INPUT
	10	PLATFORM LEVEL DOWN	DIGITAL INPUT
	11	JIB UP	DIGITAL INPUT
	12	JIB DOWN	DIGITAL INPUT
	13	SPEED PUMP POTENTIOMETER GROUND	GROUND
	14	ENGINE START	DIGITAL INPUT
	15	AUXILIARY POWER	DIGITAL INPUT
	16	CRAB STEER SELECT	DIGITAL INPUT
	17	COORDINATED STEER SELECT	DIGITAL INPUT
	18	SWITCH POWER	BATTERY VOLTAGE
	19	UNALLOCATED	DIGITAL INPUT
	20	UNALLOCATED	DIGITAL INPUT
	21	UNALLOCATED	DIGITAL INPUT
	22	DRIVE ORIENTATION SYSTEM FEATURE ENABLE	DIGITAL INPUT
	23	UNALLOCATED	DIGITAL INPUT
	24	UNALLOCATED	DIGITAL INPUT
	25	UNALLOCATED	DIGITAL INPUT
	26	UNALLOCATED	DIGITAL INPUT
	27	TWO SPEED VALVE (HIGH ENGINE)	DIGITAL INPUT
	28	TORQUE MODE	DIGITAL INPUT
	29	SOFT TOUCH OVERRIDE	DIGITAL INPUT
	30	HEAD/TAIL LIGHT	DIGITAL INPUT
	31	HORN	DIGITAL INPUT
	32	CREEP MODE	DIGITAL INPUT
	33	DUAL-FUEL SELECT	DIGITAL INPUT
	34	SPEED PUMP POTENTIOMETER REFERENCE VOLTAGE	+7 REFERENCE VOLTAGE
	35	SPEED PUMP POTENTIOMETER	DIGITAL INPUT

1001106355 C

Figure 6-24. Platform Control Module (With UGM) - Sheet 1 of 2


SECTION 6 - JLG CONTROL SYSTEM

CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J8	1	MODULE GROUND	GROUND
	2	MODULE POWER	BATTERY VOLTAGE

CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J5 NATURAL	1	LIFT / SWING JOYSTICK SUPPLY VOLTAGE	SUPPLY VOLTAGE
	2	LIFT CENTER TAP	INPUT
	3	LIFT SIGNAL	INPUT
	4	SWING SIGNAL	INPUT
	5	SWING CENTER TAP	INPUT
	6	NOT CONNECTED	INPUT
	7	LIFT / SWING JOYSTICK RETURN	GROUND
	8	GROUND RETURN	GROUND


CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J6 BLACK	1	DRIVE / STEER JOYSTICK SUPPLY VOLTAGE	SUPPLY VOLTAGE
	2	DRIVE CENTER TAP	INPUT
	3	DRIVE SIGNAL	INPUT
	4	STEER SIGNAL	INPUT
	5	STEER LEFT	INPUT
	6	STEER RIGHT	INPUT
	7	DRIVE / STEER JOYSTICK RETURN	GROUND
	8	GROUND RETURN	GROUND

CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J7 BLACK	1	GROUND MODE	GROUND MODE
	2	PLATFORM EMS	PLATFORM EMS
	3	PLATFORM EMS TO GROUND MODULE	PLATFORM MODE
	4	FOOTSWITCH (FUNCTION ENABLE SWITCH) POWER	BATTERY VOLTAGE
	5	GENERATOR SWITCH POWER	BATTERY VOLTAGE
	6	JIB BLOCK LIMIT SWITCH POWER	BATTERY VOLTAGE
	7	SOFT TOUCH LIMIT SWITCH POWER	BATTERY VOLTAGE
	8	FOOTSWITCH SIGNAL	DIGITAL INPUT
	9	GENERATOR ON SIGNAL	DIGITAL INPUT
	10	+7 REFERENCE VOLTAGE	+7 REFERENCE VOLTAGE
	11	LOAD CELL INPUT 1	ANALOG INPUT
	12	LOAD CELL INPUT 2	ANALOG INPUT
	13	UNALLOCATED	ANALOG INPUT
	14	GROUND RETURN	GROUND
	15	LOAD CELL REFERENCE VOLTAGE	+7 REFERENCE VOLTAGE
	16	LOAD CELL RETURN	GROUND
	17	JIB BLOCK LIMIT SWITCH	HS DIGITAL INPUT
	18	SOFT TOUCH LIMIT SWITCH	HS DIGITAL INPUT
	19	PLATFORM ALARM	LAMP OUTPUT
	20	ALARM RETURN	GROUND
	21	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	22	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	23	GROUND RETURN	GROUND
	24	GROUND RETURN	GROUND
	25	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	26	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	27	UNALLOCATED	ME DIGITAL OUTPUT
	28	UNALLOCATED	ME DIGITAL OUTPUT
	29	GROUND RETURN	GROUND
	30	CAN LOW	CAN LOW
	31	CAN HIGH	CAN HIGH
	32	CAN SHIELD	CAN SHIELD
	33	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	34	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	35	GROUND RETURN	GROUND



1001106355 C

Figure 6-25. Platform Control Module (With UGM) - Sheet 2 of 2



1600375 E

Figure 6-26. Platform Control Module (Without UGM) - Sheet 1 of 2


SECTION 6 - JLG CONTROL SYSTEM

CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J8	1	MODULE GROUND	GROUND
	2	MODULE POWER	BATTERY VOLTAGE

CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J5 NATURAL	1	LIFT / SWING JOYSTICK SUPPLY VOLTAGE	SUPPLY VOLTAGE
	2	LIFT CENTER TAP	INPUT
	3	LIFT SIGNAL	INPUT
	4	SWING SIGNAL	INPUT
	5	SWING CENTER TAP	INPUT
	6	NOT CONNECTED	INPUT
	7	LIFT / SWING JOYSTICK RETURN	GROUND
	8	GROUND RETURN	GROUND

CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J6 BLACK	1	DRIVE / STEER JOYSTICK SUPPLY VOLTAGE	SUPPLY VOLTAGE
	2	DRIVE CENTER TAP	INPUT
	3	DRIVE SIGNAL	INPUT
	4	STEER SIGNAL	INPUT
	5	STEER LEFT	INPUT
	6	STEER RIGHT	INPUT
	7	DRIVE / STEER JOYSTICK RETURN	GROUND
	8	GROUND RETURN	GROUND

CONNECTOR	PIN	ASSIGNMENT	FUNCTION
J7 BLACK	1	GROUND MODE	GROUND MODE
	2	PLATFORM EMS	PLATFORM EMS
	3	PLATFORM EMS TO GROUND MODULE	PLATFORM MODE
	4	FOOTSWITCH FUNCTION ENABLE SWITCH) POWER	BATTERY VOLTAGE
	5	GENERATOR SWITCH POWER	BATTERY VOLTAGE
	6	JIB BLOCK LIMIT SWITCH POWER	BATTERY VOLTAGE
	7	SOFT TOUCH LIMIT SWITCH POWER	BATTERY VOLTAGE
	8	FOOTSWITCH SIGNAL	DIGITAL INPUT
	9	GENERATOR ON SIGNAL	DIGITAL INPUT
	10	+7 REFERENCE VOLTAGE	+7 REFERENCE VOLTAGE
	11	LOAD CELL INPUT 1	ANALOG INPUT
	12	LOAD CELL INPUT 2	ANALOG INPUT
	13	UNALLOCATED	ANALOG INPUT
	14	GROUND RETURN	GROUND
	15	LOAD CELL REFERENCE VOLTAGE	+7 REFERENCE VOLTAGE
	16	LOAD CELL RETURN	GROUND
	17	JIB BLOCK LIMIT SWITCH	HS DIGITAL INPUT
	18	SOFT TOUCH LIMIT SWITCH	HS DIGITAL INPUT
	19	PLATFORM ALARM	LAMP OUTPUT
	20	ALARM RETURN	GROUND
	21	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	22	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	23	GROUND RETURN	GROUND
	24	GROUND RETURN	GROUND
	25	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	26	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	27	UNALLOCATED	ME DIGITAL OUTPUT
	28	UNALLOCATED	ME DIGITAL OUTPUT
	29	GROUND RETURN	GROUND
	30	CAN LOW	CAN LOW
	31	CAN HIGH	CAN HIGH
	32	CAN SHIELD	CAN SHIELD
	33	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	34	UNALLOCATED/NOT POPULATED	ME DIGITAL OUTPUT
	35	GROUND RETURN	GROUND



1600375 E

Figure 6-27. Platform Control Module (Without UGM) - Sheet 2 of 2

Analyzer Diagnostics Menu Structure

In the following structure descriptions, an intended item is selected by pressing ENTER; pressing **ESC** steps back to the next outer level. The **LEFT** / **RIGHT** arrow keys

move between items in the same level. The **UP** / **DOWN** arrow keys alter a value if allowed.

Table 6-11. ADJUSTMENTS - Personality Descriptions

DRIVE	
ACCEL	Displays/adjusts drive acceleration
DECEL	Displays/adjusts drive deceleration
MIN FORWARD	Displays/adjusts minimum forward drive speed
MAX FORWARD	Displays/adjusts maximum forward drive speed
MIN REVERSE	Displays/adjusts minimum reverse drive speed
MAX REVERSE	Displays/adjusts maximum reverse drive speed
ELEVATED MAX	Displays/adjusts maximum drive speed NOTE: used when elevation cutout switches are limiting maximum speed
CREEP MAX	Displays/adjusts maximum drive speed NOTE: used when creep switch on pump pot is active
STEER MAX	Displays/adjusts the maximum steer speed
LIFT	
ACCEL	Displays/adjusts upper lift acceleration
DECEL	Displays/adjusts upper lift deceleration
MIN UP	Displays/adjusts minimum upper lift up speed
MAX UP	Displays/adjusts maximum upper lift up speed
CREEP UP	Displays/adjusts maximum upper lift up speed NOTE: used when creep switch on pump pot is active
MIN DOWN	Displays/adjusts minimum upper lift down speed
MAX DOWN	Displays/adjusts maximum upper lift down speed
CREEP DOWN	Displays/adjusts maximum upper lift down speed NOTE: used when creep switch on pump pot is active
SWING	
ACCEL	Displays/adjusts swing acceleration
DECEL	Displays/adjusts swing deceleration
MIN LEFT	Displays/adjusts minimum swing left speed
MAX LEFT	Displays/adjusts maximum swing left speed
CREEP LEFT	Displays/adjusts maximum swing left speed NOTE: used when creep switch on pump pot is active
MIN RIGHT	Displays/adjusts minimum swing right speed
MAX RIGHT	Displays/adjusts maximum swing right speed
CREEP RIGHT	Displays/adjusts maximum swing right speed NOTE: used when creep switch on pump pot is active
MAIN TELESCOPE	
ACCEL	Displays/adjusts telescope acceleration
DECEL	Displays/adjusts telescope deceleration
MIN IN	Displays/adjusts minimum telescope in speed

Table 6-11. ADJUSTMENTS - Personality Descriptions

MAX IN	Displays/adjusts maximum telescope in speed
MIN OUT	Displays/adjusts minimum telescope out speed
MAX OUT	Displays/adjusts maximum telescope out speed
BASKET LEVEL	
ACCEL	Displays/adjusts basket level acceleration
DECEL	Displays/adjusts basket level deceleration
MIN UP	Displays/adjusts minimum basket level up speed
MAX UP	Displays/adjusts maximum basket level up speed
MIN DOWN	Displays/adjusts minimum basket level down speed
MAX DOWN	Displays/adjusts maximum basket level down speed
BASKET ROTATE	
ACCEL	Displays/adjusts basket rotate acceleration
DECEL	Displays/adjusts basket rotate deceleration
MIN LEFT	Displays/adjusts minimum basket rotate left speed
MAX LEFT	Displays/adjusts maximum basket rotate left speed
MIN RIGHT	Displays/adjusts minimum basket rotate right speed
MAX RIGHT	Displays/adjusts maximum basket rotate right speed
JIB LIFT	Not displayed if JIB = NO
ACCEL	Displays/adjusts jib acceleration
DECEL	Displays/adjusts jib deceleration
MIN UP	Displays/adjusts minimum jib up speed
MAX UP	Displays/adjusts maximum jib up speed
MIN DOWN	Displays/adjusts minimum jib down speed
MAX DOWN	Displays/adjusts maximum jib down speed
MIN LEFT	Displays/adjusts minimum jib left speed
MAX LEFT	Displays/adjusts maximum jib left speed
MIN RIGHT	Displays/adjusts minimum jib right speed
MAX RIGHT	Displays/adjusts maximum jib right speed
STEER	
MAX SPEED	Displays/adjusts maximum steer speed, which applies when vehicle speed is at minimum
GROUND MODE	
LIFT UP	Displays/adjusts fixed lift up speed
LIFT DOWN	Displays/adjusts fixed lift down speed
SWING	Displays/adjusts fixed swing speed
TELE	Displays/adjusts fixed telescope speed
BASKETLEVEL	Displays/adjusts fixed basket level speed
BASKETROTATE	Displays/adjusts fixed basket rotate speed
JIB (U/D)	Displays/adjusts jib lift speed Not displayed if JIB = NO
JIB (L/R)	Displays/adjusts jib swing speed Not displayed if JIB = NO

Table 6-12. Diagnostic Menu Descriptions

DRIVE	
DRIVE FOR	Displays drive joystick direction & demand
STEER	Displays steer switch direction & demand NOTE: steer demand is inversely proportional to vehicle speed
BRAKES	Displays brake control system status
CREEP	Displays pump pot creep switch status
TWO SPEED	Displays two speed switch status
2 SPEED MODE	Displays status of two speed valve
HIGH ENGINE	Displays high engine switch status
BOOM	
U LIFT UP	Displays lift joystick direction & demand
SWING LEFT	Displays swing joystick direction & demand
LEVEL UP	Displays basket level switch direction & demand NOTE: demand is controlled by the pump pot
ROT. LEFT	Displays basket rotate switch direction & demand NOTE: demand is controlled by the pump pot
U TELE IN	Displays telescope switch direction & demand NOTE: demand is controlled by the pump pot
JIB UP	Displays jib lift switch direction & demand NOTE: demand is controlled by the pump pot Not displayed if JIB = NO
JIB LEFT	Displays jib swing switch direction & demand NOTE: demand is controlled by the pump pot Not displayed if JIB = NO
PUMP POT	Displays pump pot demand
ENGINE	
START	Displays start switch status
AIR FILTER	Displays air filter status
BATTERY	Displays measured battery voltage
COOLANT	Displays coolant temperature
OIL PRS	Displays oil pressure status
FUEL SELECT	Displays selected fuel (Dual Fuel only)
FUEL LEVEL	Displays fuel level status
RPM	Displays Engine RPM
GM BATTERY	Displays battery voltage at ground module
PM BATTERY	Displays battery voltage at platform module
TEMP	Displays ground module temperature
ELEV. CUTOUT	Displays elevation cutout switch status
FUNC. CUTOUT	Displays function cutout switch status
CREEP	Displays creep switch status
TILT	Displays measured vehicle tilt
AUX POWER	Displays status of auxiliary power switch
HORN	Displays status of horn switch
R FILTER	Displays status of return filter switch
C FILTER	Displays status of charge pump filter
LOAD LENGTH	Displays length switch status

Table 6-12. Diagnostic Menu Descriptions

ANGLE	Displays angle switch status
LOAD	Displays load sensor value NOTE: Not displayed if load = 0.
DATALOG	
ON	Displays total controller on (EMS) time
ENGINE	Displays engine run time
DRIVE	Displays total controller drive operation time
LIFT	Displays total controller lift operation time
SWING	Displays total controller swing operation time
TELE	Displays total controller tele operation time
MAX.TEMP	Displays maximum measured heatsink temp.
MIN.TEMP	Displays minimum measured heatsink temp.
MAX.VOLTS	Displays maximum measured battery voltage
RENTAL	Displays total controller operation time NOTE: can be reset
ERASE RENTAL	Not available at password level 2
YES:ENTER, NO:ESC	ENTER resets rental datalog time to zero
VERSIONS	
GROUND	Displays ground module software version
PLATFORM	Displays platform module software version
ANALYSER	Displays Analyzer software version

Table 6-13. Help Fault Codes, Displayed Faults, and Descriptions

Fault Flash Code	Communicated (Displayed on Analyzer) Fault	Description	Priority
None		No flash code is indicated for the following help messages. They are intended to hint at a possible problem if the vehicle is not behaving as expected.	1
	EVERYTHING OK	The "normal" help message in platform mode	
	GROUND MODE OK	The "normal" help message in ground mode	
	FSW OPEN	A drive or boom function has been selected but footswitch is open.	
	RUNNING AT CREEP – CREEP SWITCH OPEN	All function speeds are limited to creep because the creep switch is open.	
	RUNNING AT CREEP – TILTED AND ABOVE ELEVATION	All boom function speeds are limited to creep because the vehicle is tilted and above elevation.	
	RUNNING AT CUTBACK – ABOVE ELEVATION	Drive speed is limited to "ELEVATED MAX" because the vehicle is above elevation.	
	TILT SENSOR OUT OF RANGE	The tilt sensor has indicated a tilt angle greater than 19 degrees for more than 4 seconds. Not reported during 2 second power-up.	
	LOAD SENSOR READING UNDER WEIGHT	The load sensor is reading 20% or more under the calibrated zero point. This fault may occur if the basket is resting on the ground. Not reported during 2 second power-up.	
1/1		Flash code 1/1 indicates a "sleep" mode. NOT REQUIRED	
2/1		Flash code 2/1 indicates problems with footswitch.	2
	FSW FAULTY	The two footswitch inputs have read the same state for more than one second.	
	KEYSWITCH FAULTY	Both platform and ground modes are selected simultaneously	
2/2		Flash code 2/2 indicates problems with drive & steer selection. Except where noted, these faults are not reported during 2 second power-up sequence.	3
	DRIVE LOCKED – JOYSTICK MOVED BEFORE FOOTSWITCH	Drive was selected before and during footswitch closure. Can be reported during power-up sequence.	
	FSW INTERLOCK TRIPPED	Footswitch was closed for seven seconds with no function selected. Can be reported during power-up sequence.	
	STEER LOCKED – SELECTED BEFORE FOOTSWITCH	Steer was selected before and during footswitch closure.	
	STEER SWITCHES FAULTY	Both steer switches are active together.	
	DRIVE / STEER WITH NO QPROX	This fault only occurs with inductive joysticks. It occurs if the joystick is moved out of the neutral position with no Qprox sensors active.	
	D/S JOY. QPROX BAD	These faults only occur with inductive joysticks. They indicate that the Q-Prox sensor is reading above 3.18 volts.	
	D/S JOY. OUT OF RANGE LOW	Resistive joysticks: These faults do not occur. Inductive joysticks: The trigger points for these faults are dependent on the centertap voltage reading. These faults will be triggered when the voltage is less than the centertap voltage minus half the center tap voltage minus 0.3 volts. If the centertap is at the high end of the range, these faults will be triggered below 1.05 volts. If the centertap is at the low end of the range, these faults will be triggered below 0.79 volts.	
	D/S JOY. OUT OF RANGE HIGH	Resistive joysticks: These faults do not occur if the Vref voltage is below 8.1 volts. If Vref is above 7.7 volts, Vref is operating out of tolerance or a short to battery has occurred. Inductive joysticks: The trigger points for these faults are dependent on the centertap voltage reading. These faults will be triggered when the voltage is more than the centertap voltage plus half the centertap voltage plus 0.3 volts. If the centertap is at the high end of the range, these faults will be triggered above 4.35 volts. If the centertap is at the low end of the range, these faults will be triggered above 3.8 volts.	
	D/S JOY. CENTER TAP BAD	Resistive joysticks: These faults occur when the center tap voltage is not between 3.08 volts and 3.83 volts. Due to resistor tolerances there is a +/- .1 volt range around these values where the fault may be indicated. Inductive joysticks: These faults occur when the center tap voltage is not between 2.18 volts and 2.70 volts. Due to resistor tolerances there is a +/- .1 volt range around these values where the fault may be indicated.	
		WAITING FOR FSW TO BE OPEN	Footswitch was closed when platform mode was selected. Can be reported during power-up sequence.

SECTION 6 - JLG CONTROL SYSTEM

Table 6-13. Help Fault Codes, Displayed Faults, and Descriptions

Fault Flash Code	Communicated (Displayed on Analyzer) Fault	Description	Priority
2/3		Flash code 2/3 indicates problems with boom function selection.	3
	LIFT/SWING LOCKED – JOYSTICK MOVED BEFORE FOOTSWITCH	Platform upper lift or swing was selected before and during footswitch closure.	
	PUMP SWITCHES FAULTY – CHECK DIAGNOSTICS/BOOM	A boom function (lower lift, telescope, basket level, basket rotate, jib) has both directions selected together.	
	PUMP SWITCHES LOCKED – SELECTED BEFORE FOOTSWITCH	A platform boom function (lower lift, telescope, basket level, basket rotate, jib) was selected before key switch or footswitch closure.	
	PUMP SWITCHES LOCKED – SELECTED BEFORE AUX POWER	A ground boom function (lower lift, telescope, basket level, basket rotate, jib) was selected before aux power.	
	LIFT / SWING WITH NO QPROX	This fault only occurs with inductive joysticks. It occurs if the joystick is moved out of the neutral position with no Qprox sensors active.	
	l/s joy. qprox bad	These faults only occur with inductive joysticks. They indicate that the Q-Prox sensor is reading above 3.18 volts.	
	l/s joy. out of range low	Resistive joysticks: These faults do not occur. Inductive joysticks: The trigger points for these faults are dependent on the centertap voltage reading. These faults will be triggered when the voltage is less than the centertap voltage minus half the center tap voltage minus 0.3 volts. If the centertap is at the high end of the range, these faults will be triggered below 1.05 volts. If the centertap is at the low end of the range, these faults will be triggered below 0.79 volts.	
	l/s joy. out of range high	Resistive joysticks: These faults do not occur if the Vref voltage is below 8.1 volts. If Vref is above 7.7 volts, Vref is operating out of tolerance or a short to battery has occurred. Inductive joysticks: The trigger points for these faults are dependent on the centertap voltage reading. These faults will be triggered when the voltage is more than the centertap voltage plus half the centertap voltage plus 0.3 volts. If the centertap is at the high end of the range, these faults will be triggered above 4.35 volts. If the centertap is at the low end of the range, these faults will be triggered above 3.8 volts.	
	l/s joy. centertap bad	Resistive joysticks: These faults occur when the center tap voltage is not between 3.08 volts and 3.83 volts. Due to resistor tolerances there is a +/- .1 volt range around these values where the fault may be indicated. Inductive joysticks: These faults occur when the center tap voltage is not between 2.18 volts and 2.70 volts. Due to resistor tolerances there is a +/- .1 volt range around these values where the fault may be indicated.	
	PUMP SWITCHES LOCKED – SELECTED BEFORE START SWITCH	This fault occurs when a hydraulic function switch is closed before the start switch is closed.	
	FOOTSWITCH SELECTED BEFORE START	The user attempted to start the machine with the footswitch engaged.	
2/4		Flash code 2/4 indicates that steering digital inputs are faulty. NOT REQUIRED	
2/5		Flash code 2/5 indicates that a function is prevented due to a cutout.	4
	BOOM PREVENTED – DRIVE SELECTED	A boom function is selected while a drive function is selected and drive cutout is configured to prevent simultaneous drive & boom operation.	
	DRIVE PREVENTED – ABOVE ELEVATION	Drive is selected while above elevation and drive cutout is configured to prevent drive.	
	DRIVE PREVENTED – BOOM SELECTED	Drive is selected while a boom function is selected and drive cutout is configured to prevent simultaneous drive & boom operation.	
	DRIVE PREVENTED – TILTED & ABOVE ELEVATION	Drive is selected while tilted and above elevation and tilt is configured to cutout drive.	
	MODEL CHANGED – HYDRAULICS SUSPENDED – CYCLE EMS	User changed the model number using the analyzer. User must cycle power before the hydraulics system will be active again.	11
2/7		Flash code 2/7 indicates that the accelerator input is faulty. NOT REQUIRED	
2/8		Flash code 2/8 indicates a problem with a hydraulic filter. Not reported during 2 second power-up.	5
	RETURN FILTER BYPASSED	Hydraulic return filter clogged	
	charge pump filter bypassed	Charge pump filter clogged	

Table 6-13. Help Fault Codes, Displayed Faults, and Descriptions

Fault Flash Code	Communicated (Displayed on Analyzer) Fault	Description	Priority
3/1		Flash code 3/1 indicates that a contactor did not close when energized. NOT REQUIRED	
3/2		Flash code 3/2 indicates that a contactor did not open when energized. NOT REQUIRED	
3/3		Flash code 3/3 indicates a driver problem. All driver faults are detected in a similar manner. Open circuit faults are detected when the analog feedback reads too high and the output is commanded off. Short to ground is detected when the analog feedback reads low and the output is commanded on. Short to battery is detected when the analog feedback reads Vbat and the output is commanded off. Not reported during 2 second power-up.	6
	ALTERNATOR/ECM POWER SHORT TO GROUND		
	HOUR METER SHORT TO GROUND		
	HOUR METER SHORT TO BATTERY		
	HORN SHORT TO GROUND		
	HORN OPEN CIRCUIT		
	HORN SHORT TO BATTERY		
	AUX POWER SHORT TO GROUND		
	AUX POWER OPEN CIRCUIT		
	AUX POWER SHORT TO BATTERY		
	GLOW PLUG SHORT TO GROUND		
	GLOW PLUG OPEN CIRCUIT		
	GLOW PLUG SHORT TO BATTERY		
	LP LOCK SHORT TO GROUND		
	LP LOCK OPEN CIRCUIT		
	LP LOCK SHORT TO BATTERY		
	LP START ASSIST SHORT TO GROUND		
	LP START ASSIST OPEN CIRCUIT		
	LP START ASSIST SHORT TO BATTERY		
	MAIN DUMP SHORT TO GROUND		
	MAIN DUMP OPEN CIRCUIT		
	MAIN DUMP SHORT TO BATTERY		
	PARKING BRAKE SHORT TO GROUND		
	PARKING BRAKE OPEN CIRCUIT		
	PARKING BRAKE SHORT TO BATTERY		
	START SOLENOID SHORT TO GROUND		
	START SOLENOID OPEN CIRCUIT		
	START SOLENOID SHORT TO BATTERY		
	STEER DUMP SHORT TO GROUND		
	STEER DUMP OPEN CIRCUIT		
	STEER DUMP SHORT TO BATTERY		
	TWO SPEED SHORT TO GROUND		
	TWO SPEED OPEN CIRCUIT		
	TWO SPEED SHORT TO BATTERY		
	GROUND ALARM SHORT TO GROUND		

SECTION 6 - JLG CONTROL SYSTEM

Table 6-13. Help Fault Codes, Displayed Faults, and Descriptions

Fault Flash Code	Communicated (Displayed on Analyzer) Fault	Description	Priority
	GROUND ALARM OPEN CIRCUIT		
	GROUND ALARM SHORT TO BATTERY		
	GENERATOR SHORT TO GROUND		
	GENERATOR OPEN CIRCUIT		
	GENERATOR SHORT TO BATTERY		
	WELDER SHORT TO GROUND		
	WELDER OPEN CIRCUIT		
	WELDER SHORT TO BATTERY		
	HEAD TAIL LIGHT SHORT TO GROUND		
	HEAD TAIL LIGHT OPEN CIRCUIT		
	HEAD TAIL LIGHT SHORT TO BATTERY		
	BASKET UP OVERRIDE SHORT TO GROUND	Only occurs on machines with electronic leveling systems.	
	BASKET UP OVERRIDE OPEN CIRCUIT	Only occurs on machines with electronic leveling systems.	
	BASKET UP OVERRIDE SHORT TO BATTERY	Only occurs on machines with electronic leveling systems.	
	BASKET UP SHORT TO GROUND		
	BASKET UP OPEN CIRCUIT		
	BASKET UP SHORT TO BATTERY		
	BASKET DOWN SHORT TO GROUND		
	BASKET DOWN OPEN CIRCUIT		
	BASKET DOWN SHORT TO BATTERY		
	BASKET DOWN OVERRIDE SHORT TO GROUND	Only occurs on machines with electronic leveling systems.	
	BASKET DOWN OVERRIDE OPEN CIRCUIT	Only occurs on machines with electronic leveling systems.	
	BASKET DOWN OVERRIDE SHORT TO BATTERY	Only occurs on machines with electronic leveling systems.	
	BASKET LEFT OPEN CIRCUIT		
	BASKET LEFT SHORT TO BATTERY		
	BASKET LEFT SHORT TO GROUND		
	BASKET RIGHT SHORT TO GROUND		
	BASKET RIGHT OPEN CIRCUIT		
	BASKET RIGHT SHORT TO BATTERY		
	JIB UP SHORT TO GROUND		
	JIB UP OPEN CIRCUIT		
	JIB UP SHORT TO BATTERY		
	JIB DOWN SHORT TO GROUND		
	JIB DOWN OPEN CIRCUIT		
	JIB DOWN SHORT TO BATTERY		
	JIB LEFT SHORT TO GROUND		
	JIB LEFT OPEN CIRCUIT		
	JIB LEFT SHORT TO BATTERY		
	JIB RIGHT SHORT TO GROUND		
	JIB RIGHT OPEN CIRCUIT		
	JIB RIGHT SHORT TO BATTERY		
	TOWER UP SHORT TO GROUND		

Table 6-13. Help Fault Codes, Displayed Faults, and Descriptions

Fault Flash Code	Communicated (Displayed on Analyzer) Fault	Description	Priority
	TOWER UP OPEN CIRCUIT		
	TOWER UP SHORT TO BATTERY		
	TOWER DOWN SHORT TO GROUND		
	TOWER DOWN OPEN CIRCUIT		
	TOWER DOWN SHORT TO BATTERY		
	TOWER IN SHORT TO GROUND		
	TOWER IN OPEN CIRCUIT		
	TOWER IN SHORT TO BATTERY		
	TOWER OUT SHORT TO GROUND		
	TOWER OUT OPEN CIRCUIT		
	TOWER OUT SHORT TO BATTERY		
	UPPER IN SHORT TO GROUND		
	UPPER IN OPEN CIRCUIT		
	UPPER IN SHORT TO BATTERY		
	UPPER OUT SHORT TO GROUND		
	UPPER OUT OPEN CIRCUIT		
	UPPER OUT SHORT TO BATTERY		
	LIFT UP DUMP SHORT TO GROUND		
	LIFT UP DUMP OPEN CIRCUIT		
	LIFT UP DUMP SHORT TO BATTERY		
	LIFT DOWN HOLDING SHORT TO GROUND		
	LIFT DOWN HOLDING OPEN CIRCUIT		
	LIFT DOWN SHORT TO BATTERY		
	HOUR METER OPEN CIRCUIT	This fault cannot be detected during normal operation. It may be reported during self test.	
	FORD ECM POWER OPEN CIRCUIT	This fault cannot be detected during normal operation. It may be reported during self test.	
	FORD ECM POWER SHORT TO BATTERY	This fault cannot be detected during normal operation. It may be reported during self test.	
3/4		Flash code 3/4 indicates a driver problem on a platform valve block valve driver. All driver faults are detected in a similar manner. Open circuit faults are detected when the analog feedback reads too high and the output is commanded off. Short to ground is detected when the analog feedback reads low and the output is commanded on. Short to battery is detected when the analog feedback reads Vbat and the output is commanded off. Not reported during 2 second power-up.	6
	BASKET UP SHORT TO BATTERY		
	BASKET UP SHORT TO GROUND		
	BASKET UP OPEN CIRCUIT		
	BASKET UP SHORT TO BATTERY OR OPEN CIRCUIT	Only occurs on machines with electronic basket leveling	
	BASKET DOWN SHORT TO BATTERY		
	BASKET DOWN SHORT TO GROUND		
	BASKET DOWN OPEN CIRCUIT		
	BASKET DOWN SHORT TO BATTERY OR OPEN CIRCUIT	Only occurs on machines with electronic basket leveling.	
	BASKET LEFT SHORT TO BATTERY		
	BASKET LEFT SHORT TO GROUND		
	BASKET LEFT OPEN CIRCUIT		

SECTION 6 - JLG CONTROL SYSTEM

Table 6-13. Help Fault Codes, Displayed Faults, and Descriptions

Fault Flash Code	Communicated (Displayed on Analyzer) Fault	Description	Priority
	BASKET RIGHT SHORT TO BATTERY		
	BASKET RIGHT SHORT TO GROUND		
	BASKET RIGHT OPEN CIRCUIT		
	JIB UP SHORT TO BATTERY		
	JIB UP SHORT TO GROUND		
	JIB UP OPEN CIRCUIT		
	JIB DOWN SHORT TO BATTERY		
	JIB DOWN SHORT TO GROUND		
	JIB DOWN OPEN CIRCUIT		
	JIB LEFT SHORT TO BATTERY		
	JIB LEFT SHORT TO GROUND		
	JIB LEFT OPEN CIRCUIT		
	JIB RIGHT SHORT TO BATTERY		
	JIB RIGHT SHORT TO GROUND		
	JIB RIGHT OPEN CIRCUIT		
	PLATFORM CONTROL VALVE SHORT TO BATTERY	Only occurs on machines with electronic basket leveling	
	PLATFORM CONTROL VALVE SHORT TO GROUND	Only occurs on machines with electronic basket leveling	
	PLATFORM CONTROL VALVE OPEN CIRCUIT	Only occurs on machines with electronic basket leveling	
3/5		Flash code 3/5 indicates a brake pressure problem. NOT REQUIRED	
4/2		Flash code 4/2 indicates that the engine is over temperature. NOT REQUIRED	
4/3		Flash code 4/3 indicates problems with the engine. Except where noted, these faults are not reported during 2 second power-up sequence.	9
	high engine temp	Occurs when the engine temperature is above 117 degrees Celsius for the Ford engines, and above 130 degrees Celsius for the Deutz engines.	
	AIR FILTER BYPASSED	Air filter clogged	
	NO ALTERNATOR OUTPUT	The engine has been running for 15 seconds or more and the battery voltage is still below 12.5 volts.	
	LOW OIL PRESSURE	If a Deutz engine is installed, the oil pressure is below 8 PSI and the engine has been running for at least 10 seconds. If a Ford engine is installed, the Ford ECM has reported a low oil pressure fault.	
	OIL PRESSURE SHORT TO BATTERY	If a Deutz engine is installed, this indicates that the oil pressure sensor is reading above 6.6 volts.	
	OIL PRESSURE SHORT TO GROUND	If a Deutz engine is installed, this indicates that the oil pressure sensor is reading below 0.1 volts for more than 5 seconds. This fault is not detected during crank.	
	COOLANT TEMPERATURE SHORT TO GROUND	If a Deutz engine is installed, this indicates that the coolant temperature is reading below 0.1 volts.	
	FORD FAULT CODE ##	All Ford fault codes except 63 are simply passed through from the FORD ECM. They only occur if a Ford engine is selected in the machine configuration digits. Can be reported during power-up sequence.	
	FORD FAULT CODE UNKNOWN	An unrecognized Ford ECM fault code has been received. Can be reported during power-up sequence.	
	485 communications lost	This fault only occurs with a Ford engine. It occurs when no responses are received from the ECM for 2.5 seconds. Can be reported during power-up sequence.	
	FUEL SENSOR SHORT TO BATTERY	Indicates that the fuel sensor is reading above 4.3 volts.	
	FUEL SENSOR SHORT TO GROUND	Indicates that the fuel sensor is reading below 0.2 volts.	
4/4		Flash code 4/4 indicates problems with the battery supply. Not reported during 2 second power-up.	7

Table 6-13. Help Fault Codes, Displayed Faults, and Descriptions

Fault Flash Code	Communicated (Displayed on Analyzer) Fault	Description	Priority
	BATTERY LOW	Battery voltage is below 11V for more than 5 seconds. This fault is not detected during crank. This is a warning – the controller does not shut down.	
	BATTERY TOO HIGH – SYSTEM SHUT DOWN	Battery voltage is above 16V. EMS recycle required.	
	BATTERY TOO LOW – SYSTEM SHUT DOWN	Battery voltage is below 9V.	
5/5		Flash code 5/5 indicates problems with vehicle engine RPM or the encoder. Not reported during 2 second power-up.	8
	SPEED SENSOR READING INVALID SPEED	This fault is detected with diesel engines only. The RPM pickup is indicating a speed that greater than 4000 RPM or approximately 8875 Hz.	
	SPEED INPUT LOST	This fault is detected with diesel engines only. It occurs if there is no RPM detected and the oil pressure input is reading above 8 PSI for more than three seconds. This is probably due to wiring problems at the ground module or a faulty speed sensor.	
6/6		Flash code 6/6 indicates problems with the CAN bus.	10
	CAN BUS FAILURE:	The ground module or platform module is not receiving CAN messages. This is probably due to wiring problems between the platform and ground modules.	
7/7		Flash code 7/7 indicates problems with a motor. NOT REQUIRED	
9/9		Flash code 9/9 indicates problems with the controller.	11
	PLATFORM MODULE SOFTWARE UPDATE REQUIRED	Platform module code is too old to support the EIM or BPE load sensor and the machine is configured to use one of these two sensors. The PM code must be updated to a newer version.	
	HIGH RESOLUTION A2D FAILURE – INTERRUPT LOST	The ADS1213 chip in the platform module has stopped asserting its interrupt (DRDY) line for some reason. An EMS cycle is required.	
	HIGH RESOLUTION A2D FAILURE-REINIT LIMIT	The ADS1213 has needed to be reset 3 or more times.	
	PLATFORM MODULE FAILURE: hwfs CODE 1	Platform module V(Low) FET has failed	
	GROUND MODULE FAILURE: hwfs CODE 1	Ground module V(Low) FET has failed	
	GROUND SENSOR REF VOLTAGE OUT OF RANGE	These faults occur when the seven volt reference voltage used for the joysticks, sensors, etc. goes out of range. Not reported during 2 second power-up.	
	PLATFORM SENSOR REF VOLTAGE OUT OF RANGE	These faults occur when the seven volt reference voltage used for the joysticks, sensors, etc. goes out of range. Not reported during 2 second power-up.	
	EEPROM FAILURE – CHECK ALL SETTINGS	A critical failure occurred with the EEPROM. Personalities, machine configuration digits, etc. may be reset to default values and should be checked.	
	CHASSIS TILT SENSOR NOT GAIN CALIBRATED	Indicates that the chassis tilt sensor calibration information has been lost. Machine will indicate that it is tilted at all times. This calibration data is programmed into the unit at the factory.	
	CHASSIS TILT SENSOR GAIN OUT OF RANGE	Indicates that the chassis tilt sensor calibration has become corrupted.	

SECTION 6 - JLG CONTROL SYSTEM

Table 6-14. Diagnostic Trouble Code Listing

HELP MESSAGE	FAULT	FAULT REMOVAL
OK	0 0	CLEAR WHEN FAULT IS REMOVED
DRIVING AT CREEP - TILTED	0 0	CLEAR WHEN FAULT IS REMOVED
FSW OPEN	0 0	CLEAR WHEN FAULT IS REMOVED
RUNNING AT CREEP - CREEP SWITCH OPEN	0 0	CLEAR WHEN FAULT IS REMOVED
RUNNING AT CREEP - TILTED AND ABOVE ELEVATION	0 0	CLEAR WHEN FAULT IS REMOVED
RUNNING AT CUTBACK - ABOVE ELEVATION	0 0	CLEAR WHEN FAULT IS REMOVED
TILT SENSOR OUT OF RANGE	0 0	CLEAR WHEN FAULT IS REMOVED
LOAD SENSOR READING UNDER WEIGHT	0 0	CLEAR WHEN FAULT IS REMOVED
FSW FAULTY	2 1	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
KEYSWITCH FAULTY	2 1	CLEAR WHEN FAULT IS REMOVED
DRIVE LOCKED - JOYSTICK MOVED BEFORE FOOTSWITCH	2 2	CLEAR WHEN FAULT IS REMOVED
FSW INTERLOCK TRIPPED	2 2	CLEAR WHEN FAULT IS REMOVED
STEER LOCKED - SELECTED BEFORE FOOTSWITCH	2 2	CLEAR WHEN FAULT IS REMOVED
STEER SWITCHES FAULTY	2 2	CLEAR WHEN FAULT IS REMOVED
D/S JOY. QPROX BAD	2 2	CLEAR WHEN FAULT IS REMOVED
L/S JOY. QPROX BAD	2 3	CLEAR WHEN FAULT IS REMOVED
D/S JOY. OUT OF RANGE LOW	2 2	CLEAR WHEN FAULT IS REMOVED
D/S JOY. OUT OF RANGE HIGH	2 2	CLEAR WHEN FAULT IS REMOVED
L/S JOY. OUT OF RANGE LOW	2 3	CLEAR WHEN FAULT IS REMOVED
L/S JOY. OUT OF RANGE HIGH	2 3	CLEAR WHEN FAULT IS REMOVED
D/S JOY. CENTER TAP BAD	2 2	CLEAR WHEN FAULT IS REMOVED
L/S JOY. CENTER TAP BAD	2 3	CLEAR WHEN FAULT IS REMOVED
WAITING FOR FSW TO BE OPEN	2 2	CLEAR WHEN FAULT IS REMOVED
PUMP POT FAULTY	2 3	CLEAR WHEN FAULT IS REMOVED
PUMP SWITCHES FAULTY - CHECK DIAGNOSTICS/BOOM	2 3	CLEAR WHEN FAULT IS REMOVED
PUMP SWITCHES LOCKED - SELECTED BEFORE FOOTSWITCH	2 3	CLEAR WHEN FAULT IS REMOVED
PUMP SWITCHES LOCKED - SELECTED BEFORE START SWITCH	2 3	CLEAR WHEN FAULT IS REMOVED
FOOTSWITCH SELECTED BEFORE START	2 3	CLEAR WHEN FAULT IS REMOVED
BOOM PREVENTED - DRIVE SELECTED	2 5	CLEAR WHEN FAULT IS REMOVED
DRIVE PREVENTED - ABOVE ELEVATION	2 5	CLEAR WHEN FAULT IS REMOVED
DRIVE PREVENTED - TILTED & ABOVE ELEVATION	2 5	CLEAR WHEN FAULT IS REMOVED
DRIVE PREVENTED - BOOM SELECTED	2 5	CLEAR WHEN FAULT IS REMOVED
FORD ECM POWER SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT

Table 6-14. Diagnostic Trouble Code Listing

HELP MESSAGE	FAULT	FAULT REMOVAL
HORN SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
HORN OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
HORN SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
AUX POWER SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
AUX POWER OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
AUX POWER SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
GLOW PLUG SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
GLOW PLUG OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
GLOW PLUG SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
LP LOCK SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
LP LOCK OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
LP LOCK SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
LP START ASSIST SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
LP START ASSIST OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
LP START ASSIST SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
MAIN DUMP SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
MAIN DUMP OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
MAIN DUMP SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
PARKING BRAKE SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
PARKING BRAKE OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
PARKING BRAKE SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
START SOLENOID SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
START SOLENOID OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
START SOLENOID SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
STEER DUMP SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
STEER DUMP OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
STEER DUMP SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TWO SPEED SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TWO SPEED OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TWO SPEED SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
ALARM SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
ALARM OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
ALARM SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT

SECTION 6 - JLG CONTROL SYSTEM

Table 6-14. Diagnostic Trouble Code Listing

HELP MESSAGE	FAULT	FAULT REMOVAL
GENERATOR SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
GENERATOR OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
GENERATOR SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
HEAD TAIL LIGHT SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
HEAD TAIL LIGHT OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
HEAD TAIL LIGHT SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
HOUR METER SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
HOUR METER SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET UP SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET UP OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET UP SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET DOWN SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET DOWN OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET DOWN SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET LEFT SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET LEFT OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET LEFT SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET RIGHT SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET RIGHT OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BASKET RIGHT SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB UP SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB UP OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB UP SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB DOWN SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB DOWN OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB DOWN SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB LEFT SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB LEFT OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB LEFT SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB RIGHT SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB RIGHT OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
JIB RIGHT SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER UP SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT

Table 6-14. Diagnostic Trouble Code Listing

HELP MESSAGE	FAULT	FAULT REMOVAL
TOWER UP OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER UP SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER DOWN SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER DOWN OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER DOWN SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER IN SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER IN OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER IN SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER OUT SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER OUT OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
TOWER OUT SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
UPPER IN SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
UPPER IN OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
UPPER IN SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
UPPER OUT SHORT TO GROUND	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
UPPER OUT OPEN CIRCUIT	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
UPPER OUT SHORT TO BATTERY	3 3	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
FUEL SENSOR SHORT TO BATTERY	3 3	CLEAR WHEN FAULT IS REMOVED
FUEL SENSOR SHORT TO GROUND	3 3	CLEAR WHEN FAULT IS REMOVED
OIL PRESSURE SHORT TO BATTERY	4 3	CLEAR WHEN FAULT IS REMOVED
OIL PRESSURE SHORT TO GROUND	4 3	CLEAR WHEN FAULT IS REMOVED
COOLANT TEMPERATURE SHORT TO GROUND	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 12	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 13	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 14	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 15	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 21	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 22	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 23	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 24	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 25	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 26	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 31	4 3	CLEAR WHEN FAULT IS REMOVED

SECTION 6 - JLG CONTROL SYSTEM

Table 6-14. Diagnostic Trouble Code Listing

HELP MESSAGE	FAULT	FAULT REMOVAL
FORD FAULT CODE 32	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 33	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 34	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 35	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 36	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 41	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 42	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 43	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 44	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 45	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 46	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 51	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 52	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 53	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 54	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 55	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 56	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 57	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 61	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 62	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 63	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE 64	4 3	CLEAR WHEN FAULT IS REMOVED
FORD FAULT CODE UNKNOWN	4 3	CLEAR WHEN FAULT IS REMOVED
RETURN FILTER BYPASSED	2 8	CLEAR WHEN FAULT IS REMOVED
CHARGE PUMP FILTER BYPASSED	2 8	CLEAR WHEN FAULT IS REMOVED
BATTERY LOW	4 4	CLEAR WHEN FAULT IS REMOVED
BATTERY TOO HIGH - SYSTEM SHUT DOWN	4 4	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
BATTERY TOO LOW - SYSTEM SHUT DOWN	4 4	CLEAR WHEN FAULT IS REMOVED
SPEED SENSOR READING INVALID SPEED	5 5	CLEAR WHEN FAULT IS REMOVED
SPEED INPUT LOST	5 5	CLEAR WHEN FAULT IS REMOVED
ENGINE TEMP HIGH	4 3	CLEAR WHEN FAULT IS REMOVED
AIR FILTER BYPASSED	4 3	CLEAR WHEN FAULT IS REMOVED
NO ALTERNATOR OUTPUT	4 3	CLEAR WHEN FAULT IS REMOVED

Table 6-14. Diagnostic Trouble Code Listing

HELP MESSAGE	FAULT	FAULT REMOVAL
OIL PRESSURE LOW	4 3	CLEAR WHEN FAULT IS REMOVED
485 COMMUNICATIONS LOST	4 3	CLEAR WHEN FAULT IS REMOVED
CAN BUS FAILURE	6 6	CLEAR WHEN FAULT IS REMOVED
LOAD SENSOR NOT CALIBRATED	9 9	CLEAR WHEN FAULT IS REMOVED
TILT SENSOR NOT CALIBRATED	9 9	CLEAR WHEN FAULT IS REMOVED
EEPROM FAILURE - CHECK ALL SETTINGS	9 9	REQUIRES EMS TO BE RECYCLED TO CLEAR FAULT
PLATFORM MODULE FAILURE: HWFS CODE 1	9 9	CLEAR WHEN FAULT IS REMOVED
GROUND MODULE FAILURE: HWFS CODE 1	9 9	CLEAR WHEN FAULT IS REMOVED

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

A screenshot of the "Search Manuals" form. It includes fields for "Brand", "Model", "Serial", "Part Number", and "Quantity". There is a "Search" button at the bottom.

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

A screenshot of the "Parts Order Form". It is a form with multiple rows and columns for entering part information, including fields for "Quantity", "Description", "Manufacturer", "Model", and "Part Number".

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 7. BASIC ELECTRICAL INFORMATION & SCHEMATICS

7.1 GENERAL

This section contains basic electrical information and schematics to be used for locating and correcting most of the operating problems which may develop. If a problem should develop which is not presented in this section or which is not corrected by listed corrective actions, technically qualified guidance should be obtained before proceeding with any maintenance.

NOTE: Some of the procedures/connectors shown in this section may not be applicable to all models.

7.2 MULTIMETER BASICS

A wide variety of multimeters or Volt Ohm Meters (VOM) can be used for troubleshooting of equipment. This section shows diagrams of a common, digital VOM configured for several different circuit measurements. Instructions for your VOM may vary. Please consult the meter operator's manual for more information.

Grounding

"Grounding the meter" means to take the black lead (which is connected to the COM (common) or negative port) and touch it to a good path to the negative side of the Voltage source.

Backprobing

To "backprobe" means to take the measurement by accessing a connector's contact on the same side as the wires, the back of the connector. Readings can be done while maintaining circuit continuity this way. If the connector is the sealed type, great care must be taken to avoid damaging the seal around the wire. It is best to use probes or probe tips specifically designed for this technique, especially on sealed connectors. Whenever possible insert probes into the side of the connector such that the test also checks both terminals of the connection. It is possible to inspect a connection within a closed connector by backprobing both sides of a connector terminal and measuring resistance. Do this after giving each wire a gentle pull to ensure the wires are still attached to the contact and contacts are seated in the connector.

Min/Max

Use of the "Min/Max" recording feature of some meters can help when taking measurements of intermittent conditions while alone. For example, you can read the Voltage applied to a solenoid when it is only operational while a switch, far from the solenoid and meter, is held down.

Polarity

Getting a negative Voltage or current reading when expecting a positive reading frequently means the leads are reversed. Check what reading is expected, the location of the signal and that the leads are connected to the device under test correctly. Also check that the lead on the "COM" port goes to the Ground or negative side of the signal and the lead on the other port goes to the positive side of the signal.

Scale

M = Mega = 1,000,000 * (Displayed Number)

k = kilo = 1,000 * (Displayed Number)

m = milli = (Displayed Number) / 1,000

μ = micro = (Displayed Number) / 1,000,000

Example: 1.2 kW = 1200 W

Example: 50 mA = 0.05 A

Voltage Measurement




Figure 7-1. Voltage Measurement (DC)

- If meter is not auto ranging, set it to the correct range (See multimeter's operation manual).
- Use firm contact with meter leads.

Resistance Measurement




Figure 7-2. Resistance Measurement

- First test meter and leads by touching leads together. Resistance should read a short circuit (very low resistance).
- Circuit power must be turned OFF before testing resistance.
- Disconnect component from circuit before testing.
- If meter is not auto ranging, set it to the correct range (See multimeter's operation manual).

Continuity Measurement




Figure 7-3. Continuity Measurement

- Some meters require a separate button press to enable audible continuity testing.
- Circuit power must be turned OFF before testing continuity.
- Disconnect component from circuit before testing.
- Use firm contact with meter leads.
- First test meter and leads by touching leads together. Meter should produce an audible alarm, indicating continuity.

Current Measurement




Figure 7-4. Current Measurement (DC)

- Set up the meter for the expected current range.
- Be sure to connect the meter leads to the correct jacks for the current range you have selected.
- If meter is not auto ranging, set it to the correct range (See multi meter's operation manual).
- Use firm contact with meter leads.

7.3 APPLYING SILICONE DIELECTRIC COMPOUND TO ELECTRICAL CONNECTIONS

NOTE: This section is not applicable for battery terminals.

NOTICE

JLG P/N 0100048 DIELECTRIC GREASE (NOVAGARD G661) IS THE ONLY MATERIAL APPROVED FOR USE AS A DIELECTRIC GREASE.

NOTE: Do NOT apply dielectric grease to the following connections:

- Main Boom Rotary sensor connections (on Celesco Sensor),
- LSS Modules connections,
- Deutz EMR 2 ECM connection.

Silicone Dielectric Compound must be used on all electrical connections except for those mentioned above for the following reasons:

- To prevent oxidation at the mechanical joint between male and female pins.
- To prevent electrical malfunction caused by low level conductivity between pins when wet.

Use the following procedure to apply Silicone Dielectric Compound to the electrical connectors. This procedure applies to all plug connections not enclosed in a box. Silicone grease should not be applied to connectors with external seals.

1. To prevent oxidation, silicone grease must be packed completely around male and female pins on the inside of the connector prior to assembly. This is most easily achieved by using a syringe.

NOTE: Over a period of time, oxidation increases electrical resistance at the connection, eventually causing circuit failure.

2. To prevent shorting, silicone grease must be packed around each wire where they enter the outside of the connector housing. Also, silicone grease must be applied at the joint where the male and female connectors come together. Any other joints (around strain reliefs, etc.) where water could enter the connector should also be sealed.

NOTE: This condition is especially common when machines are pressure washed since the washing solution is much more conductive than water.

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS

- Anderson connectors for the battery boxes and battery chargers should have silicone grease applied to the contacts only.

NOTE: *Curing-type sealants might also be used to prevent shorting and would be less messy, but would make future pin removal more difficult.*


When applied to electrical connections, dielectric grease helps to prevent corrosion of electrical contacts and improper conductivity between contacts from moisture intrusion. Open and sealed connectors benefit from the application of dielectric grease.

Dielectric grease shall be applied to all electrical connectors at the time of connection (except those noted under Exclusions).

Installation of Dielectric Grease

Before following these instructions, refer to excluded connector types (See Exclusions below).

- Use dielectric grease in a tube for larger connection points or apply with a syringe for small connectors.
- Apply dielectric grease to the female contact (fill it approximately $\frac{1}{2}$ full; see example below)
- Leave a thin layer of dielectric grease on the face of the connector
- Assemble the connector system immediately to prevent moisture ingress or dust contamination
- Pierce one of the unused wire seals prior to assembly if the connector system tends to trap air (i.e. AMP Seal) and then install a seal plug.



Deutsch HD, DT, DTM, DRC Series

The Deutsch connector system is commonly used for harsh environment interconnect. Follow the installation instructions.



AWP Seal

The AMP Seal connector system is used on the Control ADE Platform and Ground Modules.

Apply dielectric grease to the female contact. If trapped air prevents the connector from latching, pierce one of the unused wire seals. After assembly, install a seal plug (JLG #4460905) in that location to prevent moisture ingress.

Note that seal plugs may be installed by the wire harness manufacturer if an unused wire seal becomes compromised (wire inserted in the wrong cavity during assembly and then corrected).



Figure 7-5. Application to Plug/Male Contacts





Figure 7-6. Use of Seal Plugs

AMP Mate-N-Lok

This connector system is widely used inside enclosures for general-purpose interconnect. Follow the installation instructions.



DIN Connectors

This connector is typically used on hydraulic valves. Follow the installation instructions.



Exclusions

A limited number of connectors do not benefit from dielectric grease, or may be permanently damaged by application. Dielectric grease may not be required in properly sealed enclosures.

BRAD HARRISON / PHOENIX CONTACT M12

The connector uses gold contact material to resist corrosion and an o-ring seal for moisture integrity. If dielectric grease is mistakenly applied to this connector system, the low-force contacts cannot displace the grease to achieve electrical contact. Once contaminated, there is no practical way to remove the dielectric grease (replacement of female contacts required). The JLG Load Sensing System and 1250AJP Rotary Angle Sensors are examples of components with the M12 connector system.



AMP JUNIOR TIMER

This type of connector uses back-seals for moisture integrity. However, the low-force contacts cannot displace dielectric grease and create electrical contact. It is possible to use solvents (i.e. contact cleaner or mineral spirits) for the removal of improperly applied dielectric grease. The EMR2 engine control module from Deutz employs this connector system (for example).



7.4 AMP CONNECTOR

Applying Silicone Dielectric Compound to AMP Connectors

Silicone Dielectric Compound must be used on the AMP connections for the following reasons:

- To prevent oxidation at the mechanical joint between male and female pins.
- To prevent electrical malfunction caused by low level conductivity between pins when wet.

Use the following procedure to apply Silicone Dielectric Compound to the electrical connectors.

1. To prevent oxidation and low level conductivity, silicone dielectric grease must be packed completely around male and female pins on the inside of the connector after the mating of the housing to the header. This is easily achieved by using a syringe to fill the header with silicone dielectric compound, to a point just above the top of the male pins inside the header. When assembling the housing to the header, it is possible that the housing will become air locked, thus preventing the housing latch from engaging.
2. Pierce one of the unused wire seals to allow the trapped air inside the housing to escape.
3. Install a hole plug into this and/or any unused wire seal that has silicone dielectric compound escaping from it.

Assembly

Check to be sure the wedge lock is in the open, or as-shipped, position (See Figure 7-7.). Proceed as follows:




Figure 7-7. Connector Assembly Figure 1

1. To insert a contact, push it straight into the appropriate circuit cavity as far as it will go (See Figure 7-9).
2. Pull back on the contact wire with a force of 1 or 2 lbs. to be sure the retention fingers are holding the contact (See Figure 7-9).




Figure 7-8. AMP Connector




Figure 7-9. Connector Assembly Figure 2

3. After all required contacts have been inserted, the wedge lock must be closed to its locked position. Release the locking latches by squeezing them inward (See Figure 7-10.).

4. Slide the wedge lock into the housing until it is flush with the housing (See Figure 7-11.).




Figure 7-10. Connector Assembly Figure 3




Figure 7-11. Connector Assembly Figure 4




Figure 7-12. Connector Disassembly

Disassembly

5. Insert a 4.8 mm (3/16") wide screwdriver blade between the mating seal and one of the red wedge lock tabs.
6. Pry open the wedge lock to the open position.
7. While rotating the wire back and forth over a half turn (1/4 turn in each direction), gently pull the wire until the contact is removed.

NOTE: The wedge lock should never be removed from the housing for insertion or removal of the contacts.

Wedge Lock

The wedge lock has slotted openings in the forward, or mating end. These slots accommodate circuit testing in the field, by using a flat probe such as a pocket knife. DO NOT use a sharp point such as an ice pick.

Service - Voltage Reading

NOTICE

DO NOT PIERCE WIRE INSULATION TO TAKE VOLTAGE READINGS.

It has been common practice in electrical troubleshooting to probe wires by piercing the insulation with a sharp point. This practice should be discouraged when dealing with the AMPSEAL plug assembly, or any other sealed connector system. The resulting pinholes in the insulation will allow moisture to invade the system by traveling along the wire strands. This nullifies the effectiveness of the connector seals and could result in system failure.




Figure 7-13. Connector Installation

7.5 DEUTSCH CONNECTORS

DT/DTP Series Assembly




Figure 7-14. DT/DTP Contact Installation

1. Grasp crimped contact about 25mm behind the contact barrel.
2. Hold connector with rear grommet facing you.
3. Push contact straight into connector grommet until a click is felt. A slight tug will confirm that it is properly locked in place.
4. Once all contacts are in place, insert wedgelock with arrow pointing toward exterior locking mechanism. The wedgelock will snap into place. Rectangular wedges are not oriented. They may go in either way.

NOTE: The receptacle is shown use the same procedure for plug.

DT/DTP Series Disassembly




Figure 7-15. DT/DTP Contact Removal

5. Remove wedgelock using needle nose pliers or a hook shaped wire to pull wedge straight out.
6. To remove the contacts, gently pull wire backwards, while at the same time releasing the locking finger by moving it away from the contact with a screwdriver.
7. Hold the rear seal in place, as removing the contact may displace the seal.

HD30/HDP20 Series Assembly




Figure 7-16. HD/HDP Contact Installation

8. Grasp contact about 25mm behind the contact crimp barrel.
9. Hold connector with rear grommet facing you.
10. Push contact straight into connector grommet until a positive stop is felt. A slight tug will confirm that it is properly locked in place.




Figure 7-17. HD/HDP Locking Contacts Into Position

NOTE: For unused wire cavities, insert sealing plugs for full environmental sealing.

HD30/HDP20 Series Disassembly




Figure 7-18. HD/HDP Contact Removal

11. With rear insert toward you, snap appropriate size extractor tool over the wire of contact to be removed.
12. Slide tool along into the insert cavity until it engages contact and resistance is felt.
13. Pull contact-wire assembly out of connector.




Figure 7-19. HD/HDP Unlocking Contacts

NOTE: Do Not twist or insert tool at an angle.

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-20. Electrical Components Installation (Without UGM) - Sheet 1 of 2




Figure 7-21. Electrical Components Installation (Without UGM) - Sheet 2 of 2

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-22. Electrical Components Installation (With UGM) - Sheet 1 of 2




Figure 7-23. Electrical Components Installation (With UGM) - Sheet 2 of 2

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS

7.6 ELECTRICAL SCHEMATICS




Figure 7-24. Electrical Schematic - Sheet 1 of 10

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-25. Electrical Schematic - Sheet 2 of 10

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-26. Electrical Schematic - Sheet 3 of 10

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-27. Electrical Schematic - Sheet 4 of 10

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-28. Electrical Schematic - Sheet 5 of 10

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-29. Electrical Schematic - Sheet 6 of 10

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-30. Electrical Schematic - Sheet 7 of 10




Figure 7-31. Electrical Schematic - Sheet 8 of 10

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-32. Electrical Schematic - Sheet 9 of 10

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-33. Electrical Schematic - Sheet 10 of 10

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-34. Electrical Schematic GM - Sheet 1 of 2

SECTION 7 - BASIC ELECTRICAL INFORMATION & SCHEMATICS




Figure 7-35. Electrical Schematic GM - Sheet 2 of 2

PROPOSITION 65 WARNING

- **Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.**
- **Batteries also contain other chemicals known to the State of California to cause cancer.**
- **Wash hands after handling.**



WARNING:



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

1702961



3121202



An Oshkosh Corporation Company



www.Discount-Equipment.com

Go to Discount-Equipment.com to order your parts

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter the model number for the equipment you are looking for to search the parts manual library.

* Brand:

* Serial Number:

* Model:

Serial:

Part Number:

Part Description:

Quantity:

Submit

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the information below to request help finding a part or manual.

Manufacturer:

Model:

Description:

Quantity:

Requester Name:

Requester Email:

Requester Phone:

Company Name:

Company Address:

Company City:

Company State:

Company Zip:

Company Website:

Comments:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar