

OPERATION AND PARTS MANUAL



MODEL PRO36 **WALK-BEHIND TROWEL** **(HONDA GX270UT2QA2 GASOLINE ENGINE)**

Revision #1 (8/20/15)

Original Version



THIS MANUAL MUST ACCOMPANY THE EQUIPMENT AT ALL TIMES.

PN: 30325

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter part number or description to find parts manual or lookup part numbers.

* Part #

* Model

Serial

Part Number

Comments

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information:

Manufacturer:

Model:

Description:

Part Number:

Quantity:

Unit Price:

Total Price:

Customer Name:

Address:

City:

State:

Zip:

Phone:

Fax:

E-mail:

Comments:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar

FUEL AND CHEMICAL EXPOSURE WARNINGS



WARNING

Gasoline engine exhaust and some of its constituents, and some dust created by power sanding, sawing, grinding, drilling and other construction activities contains chemicals known to the State of California to cause cancer, birth defects and other reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paints.
- Crystalline silica from bricks.
- Cement and other masonry products.
- Arsenic and chromium from chemically treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: **ALWAYS** work in a well ventilated area, and work with approved safety equipment, such as dust masks that are specially designed to filter out microscopic particles.

SILICOSIS/RESPIRATORY WARNINGS


WARNING



SILICOSIS WARNING

Grinding/cutting/drilling of masonry, concrete, metal and other materials with silica in their composition may give off dust or mists containing crystalline silica. Silica is a basic component of sand, quartz, brick clay, granite and numerous other minerals and rocks. Repeated and/or substantial inhalation of airborne crystalline silica can cause serious or fatal respiratory diseases, including silicosis. In addition, California and some other authorities have listed respirable crystalline silica as a substance known to cause cancer. When cutting such materials, always follow the respiratory precautions mentioned above.

WARNING



RESPIRATORY HAZARDS

Grinding/cutting/drilling of masonry, concrete, metal and other materials can generate dust, mists and fumes containing chemicals known to cause serious or fatal injury or illness, such as respiratory disease, cancer, birth defects or other reproductive harm. If you are unfamiliar with the risks associated with the particular process and/or material being cut or the composition of the tool being used, review the material safety data sheet and/or consult your employer, the material manufacturer/supplier, governmental agencies such as OSHA and NIOSH and other sources on hazardous materials. California and some other authorities, for instance, have published lists of substances known to cause cancer, reproductive toxicity, or other harmful effects.

Control dust, mist and fumes at the source where possible. In this regard use good work practices and follow the recommendations of the manufacturers or suppliers, OSHA/NIOSH, and occupational and trade associations. Water should be used for dust suppression when wet cutting is feasible. When the hazards from inhalation of dust, mists and fumes cannot be eliminated, the operator and any bystanders should always wear a respirator approved by NIOSH/MSHA for the materials being used.

TABLE OF CONTENTS

PRO36 WALK-BEHIND TROWEL

Fuel And Chemical Exposure Warnings	2
Silicosis/Respiratory Warnings	3
Table Of Contents	4
Training Checklist	5
Daily Pre-Operation Checklist	6
Safety Information	7-11
Trowel Specifications/Dimensions	12
Engine Specifications	13
General Information	14-15
Trowel Components	16-17
Engine Components	18
Assembly And Installation	19-28
Inspection	29-30
Operation	30-36
Options	37-38
Maintenance	39-47
Troubleshooting	48-51
Wiring Diagram	52
Explanation Of Code In Remarks Column	54
Suggested Spare Parts	55

Component Drawings

Nameplates And Decals	56-57
Standard Handle Assembly	58-61
Standard Handle Assembly (Continued)	62-63
Fresno Winch Assembly	64-65
Guard Ring And Engine Mounting Assembly ...	66-67
Fresno Boom Assembly	68-69
Brush To Fresno Kit 36"	70-71
Stabilizer Ring Assembly	72-73
Gearbox Assembly	74-75
Engine And Clutch Assembly	76-77
Spider Assembly	78-79
Blades And Pan Assembly	80-81

Honda GX270UT2QA2 Gasoline Engine

Recoil Starter Assembly	82-83
Fan Cover Assembly	84-85
Carburetor Assembly	86-87
Air Cleaner Assembly	88-89
Muffler Assembly	90-91
Fuel Tank Assembly	92-93
Flywheel Assembly	94-95
Cylinder Head Assembly	96-97
Ignition Coil Assembly	98-99
Control Assembly	100-101
Cylinder Barrel Assembly	102-103
Crankcase Cover Assembly	104-105
Crankshaft Assembly	106-107
Piston Assembly	108-109
Camshaft Assembly	110-111
Label Assembly	112-113
Terms And Conditions Of Sale — Parts	114

NOTICE

Specifications and part numbers are subject to change without notice.

TRAINING CHECKLIST

Training Checklist			
No.	Description	OK?	Date
1	Read operation manual completely.		
2	Machine layout, location of components, checking of engine oil level.		
3	Fuel system, refueling procedure.		
4	Operation of controls (machine not running).		
5	Safety controls, safety stop switch operation.		
6	Emergency stop procedures.		
7	Startup of machine, engine choke.		
8	Maintaining a hover.		
9	Maneuvering.		
10	Pitching.		
11	Concrete finishing techniques.		
12	Shutdown of machine.		
13	Lifting of machine (lifting bale).		
14	Machine transport and storage.		

DAILY PRE-OPERATION CHECKLIST

Daily Pre-Operation Checklist		✓	✓	✓	✓	✓	✓
1	Engine oil level						
2	Gearbox oil level						
3	Condition of blades						
4	Blade pitch operation						
5	Safety stop switch operation						

SAFETY INFORMATION





Do not operate or service the equipment before reading the entire manual. Safety precautions should be followed at all times when operating this equipment. Failure to read and understand the safety messages and operating instructions could result in injury to yourself and others.






SAFETY MESSAGES

The four safety messages shown below will inform you about potential hazards that could injure you or others. The safety messages specifically address the level of exposure to the operator and are preceded by one of four words: **DANGER**, **WARNING**, **CAUTION** or **NOTICE**.





SAFETY SYMBOLS

	DANGER
Indicates a hazardous situation which, if not avoided, WILL result in DEATH or SERIOUS INJURY .	
	WARNING
Indicates a hazardous situation which, if not avoided, COULD result in DEATH or SERIOUS INJURY .	
	CAUTION
Indicates a hazardous situation which, if not avoided, COULD result in MINOR or MODERATE INJURY .	
	NOTICE
Addresses practices not related to personal injury.	

Potential hazard associated with the operation of this equipment will be referenced with **hazard symbols** which may appear throughout this manual in conjunction with safety messages.

SYMBOL	SAFETY HAZARD
	WARNING Lethal Exhaust Gas Hazard <ul style="list-style-type: none"> • Inhaling exhaust fumes can result in severe injury or death. • Only operate equipment in well ventilated areas. • DO NOT inhale exhaust gases/fumes.
	WARNING Explosive Fuel Hazard <ul style="list-style-type: none"> • Gasoline fuel can cause fire or explosion. Stop engine before refueling. • Keep cigarettes, sparks and flames away from hot surfaces.
	CAUTION Burn Hazard <ul style="list-style-type: none"> • HOT PARTS can burn skin. • DO NOT touch hot parts. Allow machine a sufficient amount of time to cool before performing maintenance.

Warning decals associated with the operation of this equipment are defined below:

DECAL	SAFETY HAZARD
	WARNING Rotating Blade Hazard <ul style="list-style-type: none"> • Keep hands and feet clear of guard rings. • Stop engine before servicing.
	WARNING Read Manual To avoid injury you must read and understand operator's manual before using this machine.
	WARNING Lifting Crush Hazard <ul style="list-style-type: none"> • NEVER allow any person to stand underneath the trowel while lifting. • DO NOT lift trowel with pans attached. • ALWAYS make sure handle is securely attached. • On Quick Pitch™ models make sure T-Handle latch is locked (engaged).
	ALWAYS wear protective clothing when operating this equipment
	WARNING Training This machine to be operated by qualified personnel. Ask for training as needed.
	WARNING Guard Hazard NEVER operate this equipment with guards removed. Keep hands clear.

SAFETY INFORMATION

GENERAL SAFETY

⚠ CAUTION

- **NEVER** operate this equipment without proper protective clothing, shatterproof glasses, respiratory protection, hearing protection, steel-toed boots and other protective devices required by the job or city and state regulations.



- Avoid wearing jewelry or loose fitting clothes that may snag on the controls or moving parts as this can cause serious injury.

- **NEVER** operate this equipment when not feeling well due to fatigue, illness or when under medication.



- **NEVER** operate this equipment under the influence of drugs or alcohol.



- **ALWAYS** clear the work area of any debris, tools, etc. that would constitute a hazard while the equipment is in operation.

- No one other than the operator is to be in the working area when the equipment is in operation.

- **DO NOT** use the equipment for any purpose other than its intended purposes or applications.

NOTICE

- This equipment should only be operated by trained and qualified personnel 18 years of age and older.
- Whenever necessary, replace nameplate, operation and safety decals when they become difficult read.
- Manufacturer does not assume responsibility for any accident due to equipment modifications. Unauthorized equipment modification will void all warranties.
- **NEVER** use accessories or attachments that are not recommended by Multiquip for this equipment. Damage to the equipment and/or injury to user may result.
- **ALWAYS** know the location of the nearest fire extinguisher.
- **ALWAYS** know the location of the nearest first aid kit.
- **ALWAYS** know the location of the nearest phone or **keep a phone on the job site**. Also, know the phone numbers of the nearest **ambulance, doctor** and **fire department**. This information will be invaluable in the case of an emergency.



SAFETY INFORMATION

TROWEL SAFETY

DANGER

- Engine fuel exhaust gases contain poisonous carbon monoxide. This gas is colorless and odorless, and can cause death if inhaled.
- The engine of this equipment requires an adequate free flow of cooling air. **NEVER** operate this equipment in any enclosed or narrow area where free flow of the air is restricted. If the air flow is restricted it will cause injury to people and property and serious damage to the equipment or engine.



- **NEVER** operate the equipment in an explosive atmosphere or near combustible materials. An explosion or fire could result causing severe **bodily harm or even death.**



WARNING


- **ALWAYS** keep clear of rotating or moving parts while operating the trowel.
- **DO NOT** start or operate the trowel if the drive train will not disengage. Centrifugal force between the trowel and surface when starting can cause uncontrolled handle movement that can cause serious injury. The handle must not move while pulling the engine recoil starter.
- **NEVER** disconnect any **emergency or safety devices.** These devices are intended for operator safety. Disconnection of these devices can cause severe injury, bodily harm or even death. Disconnection of any of these devices will void all warranties.



CAUTION

- **NEVER** stand on trowel during operation.
- **NEVER** lubricate components or attempt service on a running machine.
- **NEVER** place your feet or hands inside the guard rings while starting or operating this equipment.

- **ALWAYS** keep work area clear around the trowel. Make sure it is free of debris and objects.



NOTICE

- **ALWAYS** keep the machine in proper running condition.
- Fix damage to machine and replace any broken parts immediately.
- **ALWAYS** store equipment properly when it is not being used. Equipment should be stored in a clean, dry location out of the reach of children and unauthorized personnel.
- A safety manual for operating and maintenance personnel of concrete power trowels produced by the Association of Equipment Manufacturers (AEM) can be obtained for a fee by ordering through their website at www.aem.org.

Order FORM PT-160

ENGINE SAFETY

WARNING

- **DO NOT** place hands or fingers inside engine compartment when engine is running.
- **NEVER** operate the engine with heat shields or guards removed.
- Keep fingers, hands hair and clothing away from all moving parts to prevent injury.
- **DO NOT** remove the engine oil drain plug while the engine is hot. Allow the oil to cool before performing maintenance. This will prevent scalding of personnel.



CAUTION

- **NEVER** touch the hot exhaust manifold, muffler or cylinder. Allow these parts to cool before servicing equipment.



SAFETY INFORMATION

NOTICE


- **NEVER** run engine without an air filter or with a dirty air filter. Severe engine damage may occur. Service air filter frequently to prevent engine malfunction.
- **NEVER** tamper with the factory settings of the engine or engine governor. Damage to the engine or equipment can result if operating in speed ranges above the maximum allowable.



FUEL SAFETY

DANGER

- **DO NOT** add fuel to equipment if it is placed inside truck bed with plastic liner. Possibility exists of explosion or fire due to static electricity.



- **DO NOT** start the engine near spilled fuel or combustible fluids. Fuel is extremely flammable and its vapors can cause an explosion if ignited.
- **ALWAYS** refuel in a well-ventilated area, away from sparks and open flames.
- **ALWAYS** use extreme caution when working with flammable liquids.
- **DO NOT** fill the fuel tank while the engine is running or hot.
- **DO NOT** overfill tank, since spilled fuel could ignite if it comes into contact with hot engine parts or sparks from the ignition system.

- Store fuel in appropriate containers, in well-ventilated areas and away from sparks and flames.
- **NEVER** use fuel as a cleaning agent.
- **DO NOT** smoke around or near the equipment. Fire or explosion could result from fuel vapors or if fuel is spilled on a hot engine.



TRANSPORTING SAFETY

CAUTION

- **NEVER** allow any person or animal to stand underneath the equipment while lifting.



NOTICE

- Some walk-behind trowels can be lifted or moved by two people utilizing lifting tubes or other special attachments. Generally, however, they must be lifted using lifting bales and cranes, hoists, or forklifts.
- **NEVER** transport trowel with float pans attached unless safety catches are used and are specifically cleared for such transport by the manufacturer.
- **NEVER** hoist the trowel more than three feet off the ground with float pans attached.
- Before lifting, make sure that the lifting bales are not damaged.
- Always make sure crane or lifting device has been properly secured to the lifting bales of the equipment.
- **ALWAYS** shutdown engine before transporting.
- **NEVER** lift the equipment while the engine is running.
- Tighten fuel tank cap securely and close fuel cock to prevent fuel from spilling.
- Use adequate lifting cable (wire or rope) of sufficient strength.
- **DO NOT** lift machine to unnecessary heights.
- **ALWAYS** tie down equipment during transport by securing the equipment with rope.

ENVIRONMENTAL SAFETY/DECOMMISSIONING

NOTICE

Decommissioning is a controlled process used to safely retire a piece of equipment that is no longer serviceable. If the equipment poses an unacceptable and unrepairable safety risk due to wear or damage or is no longer cost effective to maintain (beyond life-cycle reliability) and is to be decommissioned (demolition and dismantlement), be sure to follow rules below.

- **DO NOT** pour waste or oil directly onto the ground, down a drain or into any water source.
- Contact your country's Department of Public Works or recycling agency in your area and arrange for proper disposal of any electrical components, waste or oil associated with this equipment.
- When the life cycle of this equipment is over, remove battery and bring to appropriate facility for lead reclamation. Use safety precautions when handling batteries that contain sulfuric acid.
- When the life cycle of this equipment is over, it is recommended that the trowel frame and all other metal parts be sent to a recycling center.



Metal recycling involves the collection of metal from discarded products and its transformation into raw materials to use in manufacturing a new product.

Recyclers and manufacturers alike promote the process of recycling metal. Using a metal recycling center promotes energy cost savings.

EMISSIONS INFORMATION

NOTICE

The gasoline engine used in this equipment has been designed to reduce harmful levels of carbon monoxide (CO), hydrocarbons (HC) and nitrogen oxides (NOx) contained in gasoline exhaust emissions.

This engine has been certified to meet US EPA Evaporative emissions requirements in the installed configuration.

Attempting to modify or make adjustments to the engine emission system by unauthorized personnel without proper training could damage the equipment or create an unsafe condition.

Additionally, modifying the fuel system may adversely affect evaporative emissions, resulting in fines or other penalties.

Emission Control Label

The emission control label is an integral part of the emission system and is strictly controlled by regulation(s).

The label must remain with the engine for its entire life.

If a replacement emission label is needed, please contact your authorized engine distributor.

TROWEL SPECIFICATIONS/DIMENSIONS




Figure 1. Dimensions

Table 1. Trowel Specifications

A-Height (Lifting Bale) – in (mm.)		31.7 (931.6)	Path Width – in (mm.)	914 (36)
B-Height (Handle) – in (mm.) Standard		41.4 (1,044.2)	Rotor – RPM (Dry Concrete)	60-115
C-Width (Ring Diameter) – in (mm.)		36.5 (927.1)	Gear Box Oil Capacity – oz. (ml.)	769 (26)
D-Length – in (mm.)		70.5 (1,789.4)	Shipping Weight – lbs (kg.)	300 (136)
Number of Blades	Rotor	4		
	Fresno	1		

ENGINE SPECIFICATIONS

Table 2. PRO36 Noise and Vibration Emissions

Guaranteed ISO 11201:2010 Based Sound Pressure Level at Operator Station in dB(A)		TBD
Guaranteed ISO 3744:2010 Based Sound Power Level in dB(A)		TBD
Whole Body Vibration Per ISO 2631- 1:1997+A1:2010 in $m/s^2 \Sigma A(8)$	Standard Handle	TBD

NOTES:

1. Sound Pressure and Power Levels are "A" weighted Measures per ISO 226:2003 (ANSI S1.4-1981). They are measured with the operating condition of the machine which generates the most repeatable but highest values of the sound levels. Under normal circumstances, the sound level will vary depending on the condition of the material being worked upon.
2. The vibration level indicated is the vector sum of the RMS (Root Mean Square) Values of amplitudes on each axis, standardized to an 8 hour exposure period, and obtained using operating condition of the machine that generates the most repeatable but highest values in accordance with the applicable standards for the machine.
3. Per EU Directive 2002/44/EC, the daily exposure action value for whole body vibration is $0.5 m/s^2 \Sigma A(8)$. The daily exposure limit value is $1.15 m/s^2 \Sigma A(8)$.

Table 3. Engine Specifications/Dimensions

Model	Honda GX270UT2QA2 Engine
Type	Air-cooled 4 stroke, Single Cylinder, OHV, Horizontal Shaft Gasoline Engine
Bore X Stroke	3.0 in. X 2.3 in. (77 mm x 58 mm)
Displacement	16.4 cu-in (270 cc.)
Max. Output	9.0 H.P. @ 3600 RPM
Fuel Tank Capacity	Approx. 1.59 U.S. Gallons (6.0 Liters)
Fuel	Unleaded Gasoline
Lube Oil Capacity	1.06 qt. (1.1 liters)
Oil Type	4-Stroke API, SF or SG SAE 10W-30 General Use
Speed Control Method	Centrifugal Flyweight Type
Cooling System	Forced Air
Starting Method	Recoil Start
Spark Plug Type	BPR5ES NGK
Spark Plug Gap	0.028-0.031 in. (0.70 - 0.80 mm)
Dimension (L x W x H)	14.0 x 16.9 X 16.1 in. (355 X 430 X 410 mm)
Dry Net Weight	50.7 lbs (23 Kg.)

GENERAL INFORMATION

INTENDED USE

Operate this trowel, tools and components in accordance with the manufacturer's instructions. Use of any other tools for stated operation is considered contrary to designated use. The risk of such use lies entirely with the user. The manufacturer cannot be held liable for damages as a result of misuse.

TROWEL FAMILIARIZATION

This walk-behind trowel is designed for the floating and finishing of concrete slabs.

Take a walk around the trowel. Take notice of all the major components (Figure 2 and Figure 3) like the engine, blades, steering handle, kill switch, gearbox, etc. Check that there is always oil in the engine.

Read all the safety instructions carefully. Safety instructions will be found throughout this manual and on the trowel. Keep all safety information in good, readable condition. Operators should be well trained on the operation and maintenance of the trowel.

Before using your trowel, test it on a flat watered down section of finished concrete that is free of any debris and other objects.

This trial test run will increase your confidence in using the trowel and at the same time it will familiarize you with the trowel's controls. In addition you will understand how the trowel handles under actual conditions.

ENGINE

This trowel is equipped with a HONDA 11 HP gasoline engine. Refer to the engine owner's manual for instructions regarding the operation and maintenance of your engine. Please contact your nearest Multiquip Dealer for a replacement should the original manual disappear or otherwise become unusable.

DRIVE SYSTEM

Power is transferred from the engine to the gearbox input shaft via a V-belt pulley drive system. The pulley engages using a centrifugal clutch. See parts section of this manual for a breakdown of the drive system.

GEARBOX

The **gearbox** is located beneath the engine and transfers power to the **spider** assembly. The gearbox controls the rotational speed of the trowel and is equipped with two shafts (input and output).

SPIDER

The vertical output shaft of the gearbox connects to a cast hub called the **spider**. The spider has 4 arms that extend outward that are used for attachment of blades or other accessories. Remember as the gearbox output shaft rotates so does the spider assembly.

GUARD RING

This unit is equipped with a safety guard ring. It is designed to help protect items from coming into contact with the rotating blades while the trowel is in operation.

BLADES

The blades of the trowel finish the concrete as they are rotated around the surface. This trowel comes equipped with four **combination blades** (8 in./203 mm wide) per rotor equally spaced in a radial pattern and attached to a vertical rotating shaft by means of a spider assembly.

FRESNO BLADE

The **fresno blade** follows the path of the trowel and four combination blades as they are rotated around the troweling surface. This trowel comes equipped with a single fresno screed blade (5 in./127 mm wide, 48 in./1,219.2 mm long) that is either raised or lowered via a winch crank handle.

FRESNO BRUSH

The **fresno brush** follows the path of the trowel, fresno blade, and four combination blades to provide a decorative/textured finish to the troweling surface. The fresno brush is designed to follow the path of the fresno blade in a floating, or loose, configuration.

The floating configuration allows the fresno brush to independently match the operator's troweling preferences without having to manually pitch the brush relative to the troweling surface for each pass.

MECHANICAL BOOM

The **mechanical boom** is mounted in front of the trowel unit and supports the fresno brush, fresno blade, and plated weight(s). The boom raises and lowers the brush and blade via the hand crank winch, and has 180° range of lateral motion which is adjustable based on operator's preference and troweling surface.

TRAINING

For proper training, please use the “**TRAINING CHECKLIST**” form located in the front of this manual. This checklist will provide an outline for an experienced operator to provide training to a new operator.

TROWEL COMPONENTS




Figure 2. Trowel Components

Figure 2 and Figure 3 shows the location of the basic controls or components, for the trowel. Listed below is a brief explanation of each control or component.

1. **Handle Bar Pad** — Foam rubber pad that protects the body when coming in contact with handle bar.
2. **Vibratory Handle Bar** — Installed rubber shock mounts/isolators reduce vibration when the trowel is operating.
3. **Hand Grips** — When maneuvering of the trowel is required **ALWAYS** place both hands on each grip to operate the trowel. Replace hand grips when they become worn or damaged.
4. **Star Wheel Pitch Knob (4-Blade)** — To adjust the pitch of the blades, rotate the star wheel clockwise to pitch blades upwards. Rotate star wheel counterclockwise to pitch blades flat (no pitch).
5. **Star Wheel Pitch Knob (Fresno)** — To adjust the pitch of the fresno blade upward, rotate the star wheel clockwise. Rotate star wheel counterclockwise to pitch blade flat (no pitch).
6. **Blades** — This trowel is equipped with combination blades. These blades are versatile and should take care of most troweling needs. In addition, float discs can be attached to the trowel arms that will allow the trowel to float on "wet" concrete.
7. **Guard Ring** — **NEVER** put hands or feet inside guard ring while the machine is running.
8. **Trowel Arm** — **NEVER** operate the trowel with a bent, broken or out of adjustment trowel arm. If the blades show uneven wear patterns or some blades wear out faster than others, the trowel arm may need to be adjusted. Use the trowel arm adjustment tool P/N 1817 to adjust the trowel arms.

TROWEL COMPONENTS






Figure 3. Trowel Components (Continued)

9. **Gearbox** — Helical worm gear drive gearbox. Provides rotation of blades via engine interface. **ALWAYS** check gearbox oil level (sight glass) prior to each use. Fill with recommended type gearbox oil.
10. **Access Panel** — Allows access to the blade area. **NEVER** run the trowel with this access panel removed.
11. **Mechanical Boom** — Works in conjunction with the boom winch to either raise or lower the fresno blade/brush. Has 180° range of rotation. Removeable weights are provided to add stability.
12. **Fresno Blade** — Large troweling blade attached to the mechanical boom arm. Provides a smooth finish over large areas without the user having to walk out on the troweling surface.
13. **Fresno Brush** — Large broom brush that is attached to the fresno blade. Provides a textured or decorative finish to the troweling surface. There are three different color-coded, textured (stiffness) brushes compatible with this trowel unit: soft (black), medium (orange) and stiff (green).
14. **Lifting Bale** — Attach a suitable lifting device to lifting bale whenever lifting of the trowel is required.
15. **Engine** — Honda 11.0 HP gasoline engine. Reference Table 3 for engine specifications.
16. **Star Wheel Knob (Handlebar Adjustment)** — Changes the angle/height of the handlebar. Loosen the star wheel (turn counterclockwise) to place the handlebar in the desired position. Tighten the star wheel (turn clockwise) to lock handlebar.
17. **Boom Winch** — Mechanical device used to raise or lower the trowel boom arm. Rotating the crank handle clockwise will lower the boom arm, and rotating the handle counterclockwise will raise the boom arm.
18. **Throttle Lever** — Controls engine speed. May be mounted on either side.
19. **Left Clutch Lever** — Squeeze to engage clutch. 4-blade rotation will start. This is the primary control lever.
20. **Right Clutch Lever** — Pull up to engage the clutch. 4-blade rotation will start. This is the secondary control lever.

ENGINE COMPONENTS



INITIAL SERVICING

Figure 4. Engine Controls and Components

The engine (Figure 4) must be checked for proper lubrication and filled with fuel prior to operation. Refer to the manufacturer's engine manual for instructions and details of operation and servicing.

1. **Fuel Filler Cap** – Remove this cap to add unleaded gasoline to the fuel tank. Make sure cap is tightened securely. **DO NOT** over fill.

DANGER



Add fuel to the tank only when the engine is stopped and has had an opportunity to cool down. In the event of a fuel spill, **DO NOT** attempt to start the engine until the fuel residue has been completely wiped up and the area surrounding the engine is dry.

2. **Throttle Lever** – Used to adjust engine RPM speed. This lever is connect to the throttle lever cable located on the handle bars. Reference throttle cable installation procedure in this manual.
3. **Recoil Starter (pull rope)** – Manual-starting method. Pull the starter grip until resistance is felt, then pull briskly and smoothly.
4. **Fuel Valve Lever** – **OPEN** to let fuel flow, **CLOSE** to stop the flow of fuel.
5. **Choke Lever** – Used in the starting of a cold engine, or in cold weather conditions. The choke enriches the fuel mixture.

6. **Air Cleaner** – Prevents dirt and other debris from entering the fuel system. Remove wing-nut on top of air filter canister to gain access to filter element.

NOTICE

Operating the engine without an air filter, with a damaged air filter, or a filter in need of replacement will allow dirt to enter the engine, causing rapid engine wear.

7. **Spark Plug** – Provides spark to the ignition system. Set spark plug gap according to engine manufacturer's instructions. Clean spark plug once a week.
8. **Muffler** – Used to reduce noise and emissions. **NEVER** touch when **hot!**
9. **Fuel Tank** – Fill with unleaded gasoline. Refer to Table 3 for fuel tank capacity. For additional information refer to Honda engine owner's manual.
10. **Dipstick/Oil Filler Cap** – Remove this cap to determine if the engine oil is low. Add oil through this filler port as recommended in Table 4.
11. **Oil Drain Plug** – Remove this plug to remove oil from the engine's crankcase.
12. **Engine ON/OFF Switch** – **ON** position permits engine starting, **OFF** position stops engine operation.

ASSEMBLY AND INSTALLATION

UNPACKING THE TROWEL

The trowel is shipped with the handlebar in the folded or stowed position (Figure 5).

1. To place the handlebar in the operational position, simply turn the star wheel counterclockwise to release it from its locked/stowed position.
2. Next, pull back on the handlebar and place the handlebar in the desired position. Turn star wheel clockwise to lock handlebar firmly in place so that it will not move or slip.




Figure 5. Handlebar (Operational Position)

ASSEMBLY AND INSTALLATION

Before the trowel can be put into operation there are some components that must be installed. This section provides general instructions on how to install those components.

MAIN HANDLE TUBE INSTALLATION

1. Attach the main handle tube to the gearbox using the supplied hardware as shown in Figure 6.




Figure 6. Handle Installation

2. The handlebar is already attached to the main handle tube.
3. If readjustment is necessary, loosen the star wheel as shown in Figure 7 and move the handlebar to the desired position.




Figure 7. Handlebar Adjustment

ASSEMBLY AND INSTALLATION

4-BLADE PITCH CABLE INSTALLATION

1. To pitch the 4-blades flat, simply turn the star wheel counterclockwise. This releases tension on the pitch cable (Figure 8).




Figure 8. Adjusting 4-Blade Pitch Cable

2. Remove brass set nut #1 from the blade pitch cable end. See Figure 9.




Figure 9. 4-Blade Pitch Cable

3. Thread the brass set nut #2 towards the cable as far as possible. See Figure 9.
4. Insert the cable end through the yoke eyelet (Figure 10). Tighten brass set nut #1 by hand to remove all the slack from the cable.




Figure 10. Cable Yoke Attachment

5. Using a wrench, tighten the brass set nut #2 up against the yoke boss. This will lock the cable in place.
6. Using a wrench, tighten the brass set nut #1 against the yoke boss.

ASSEMBLY AND INSTALLATION

THROTTLE CABLE INSTALLATION

Refer to Figure 11 for the location of components.




Figure 11. Throttle Cable Installation

1. Uncoil the throttle cable and housing.
2. Check that the throttle cable is fed through the tube on the underside of the handle and secured to the upper handle and main tube with the zip ties.
3. Place the throttle in the run position (Figure 12).
4. Back off both the cable housing clamp screw and the swivel stop screw.
5. Place the primary throttle return spring (P/N 21746) between the cable housing clamp and the swivel stop screw.
6. Feed the cable assembly through the cable housing clamp, primary throttle return spring, and swivel stop hole, until the cable housing extends under the housing clamp to its far edge.
7. On the throttle lever, slightly loosen the locking nut and cable retaining screw as shown in Figure 12.
8. Ensure that the cable housing is seated in the throttle cable receiver as shown in Figure 12.

9. Route throttle wire past the cable retaining screw (Figure 12) approximately 1/2". To secure throttle wire, tighten the cable retaining screw.
10. Adjust cable tension by loosening or tightening the locking nut and cable retaining screw on the throttle lever (see Figure 12).




Figure 12. Adjusting Cable Tension

NOTICE

If the throttle lever does not return to the "neutral" position with throttle backed off, loosen adjusting nut 1/2 turn at a time, tighten and recheck. Readjust throttle tension as necessary.

ASSEMBLY AND INSTALLATION

INSTACLUTCH CABLE INSTALLATION

1. Uncoil the free end of the clutch cable.
2. Check that the clutch cable (Figure 13) is attached to the handlebar cable anchor.




Figure 13. Handlebar Clutch Cable Anchor

3. Check that the clutch cable is fed along the tube and secured with zip ties.
4. Using a 7/16" wrench remove the three 1/4" retaining bolts (Figure 14) that secure the clutch cover to the frame.




Figure 14. Clutch Cover Removal

5. Route the clutch cable (Figure 15) underneath the top most rung of the guard ring.




Figure 15. Clutch Cable Routing

6. Remove the 5/16" outer nut (Figure 16) and rubber cap from the threaded end on the clutch cable.




Figure 16. Outer Nut And Rubber Cap Removal

ASSEMBLY AND INSTALLATION

- Adjust the 5/16" inner nut (Figure 17) for a 7/8" distance from the threaded end on the clutch cable to the inner nut.




Figure 17. Inner Nut Adjustment

NOTICE

Positioning the inner nut 7/8" from the clutch cable's threaded end will help ensure proper clutch gap adjustment.

- Insert the exposed cable (Figure 18) into the cable slot on the cable anchor.




Figure 18. Inserting Clutch Cable Into Cable Anchor

- Place outer nut (Figure 19) onto the threaded end of the clutch cable. Hand tighten nut against the cable anchor.




Figure 19. Attaching Clutch Cable To Cable Anchor

- Using two 1/2" wrenches tighten the inner and outer nut against the clutch cable support bracket.
- Connect the clutch cable to the clutch anchor by placing the spring loop over the clutch anchor flats as shown in Figure 20. Use needle nose pliers to slide the spring loop fully into the groove.




Figure 20. Spring Loop Attachment.

ASSEMBLY AND INSTALLATION

BOOM INSTALLATION

1. Position the boom with the weight posts (2) as shown in Figure 21.
2. On the boom remove the 1/2" screw, 1/2" lock washer, and 1/2" hex nut from the rod end and set aside.
3. Pull and hold the T-handle to retract the locking pin.
4. While holding the T-handle align and place the boom anchor onto the stanchion pin mount as shown in Figure 21.
5. Release the T-handle.
6. Insert the 1/2" screw up through the rod end on the boom (Figure 21).
7. Using a 3/4" wrench secure rod end to stanchion using a 1/2" hex nut and lock washer. Do not over tighten.




Figure 21. Boom Installation

ATTACHING THE FRESNO BLADE

1. Align the two mounting holes on the blade with two center mounting holes (Figure 22) on the boom blade mounting plate.
2. Using a 9/16" wrench, secure the blade to the boom blade mounting plate using the two 3/8" screws, flat washers, and lock washers as shown in Figure 22. Do not over tighten.




Figure 22. Fresno Blade Attachment

ASSEMBLY AND INSTALLATION

ATTACHING THE BRUSH ARMS

NOTICE

Positioning of the brush arms/brush to the fresno blade is determined by operator.

1. Using a 9/16" wrench, slightly loosen the 3/8-16 x 1-1/4" screws (Figure 23) that are holding the pinch bracket, brush block, and brush arm together.
2. Allow enough separation between the pinch bracket and brush block to easily slide the brush block underneath the attachment bar on the fresno blade.
3. Once positioned, tighten the 3/8-16 x 1-1/4" screws on the pinch bracket.




Figure 23. Pinch Bracket Attachment

ATTACHING THE FRESNO BRUSH

1. Using a 7/16" wrench, remove the four 1/4-20" hex nuts and 1/4" lock washers (Figure 24) located on top of the left and right brush arms.




Figure 24. Brush Arm Hardware Removal

2. Slide the 1/4-20 x 1/2" screws (4) that were removed in step 1 into the brush channel as shown in Figure 25.
3. Align brush mounting hardware with brush arm. Once correctly positioned, secure the brush arm (Figure 25) to the brush channel by tightening the 1/4"-20 hex nut. Repeat for opposite side.




Figure 25. Attaching the Fresno Brush

ASSEMBLY AND INSTALLATION

INSTALLATION OF WEIGHTS (BLADE)

NOTICE

The four weights are an **optional** feature. The use of the weights is determined by the operator. It is recommended that the weights be equal on both sides of the weight posts.

1. Open the locking pin (Figure 27).
2. Place the weight(s) onto the weight posts and insert the locking pin into the weight post hole nearest the weight(s).
3. Close the locking pin.
4. A properly installed weight is shown in Figure 27 letter (A).





Figure 26. Weight Installation

INSTALLATION OF BRUSH WEIGHT KIT

NOTICE

The six brush weights are an **optional** feature. The use of the weights is determined by the operator. It is recommended that the weights be equal on both sides of the brush.

1. Slide the 1/4-20 X 1-1/4" screw into the brush channel as shown in Figure 28.
2. Once correctly positioned, place the brush weights (3) onto the 1/4-20 X 1-1/4" screw as shown in Figure 28.
3. Insert 1/4" flat washer and 1/4"-20 nyloc nut onto the screw.
4. Using a 7/16" wrench, tighten the 1/4-20 nyloc nut.
5. Repeat for opposite side.



NOTES:
1 FRESNO BRUSH WEIGHT KIT INSTALLATION IS IDENTICAL FOR BOTH SIDES.

Figure 27. Brush Weight Kit Installation

ASSEMBLY AND INSTALLATION

NOTICE

Refer to Figure 29 for the pitch and winch cable installation instructions.

PITCH CABLE INSTALLATION (FRESNO BLADE)

1. Uncoil the clevis end of the **fresno** blade pitch cable.
2. Check that the fresno pitch cable is attached to the fresno blade pitch bracket on the upper handle as shown by letter (A).
3. Check that the pitch cable is fed along the main tube and secured with zip ties.
4. Route the clevis end of the pitch cable around the engine and secure the pitch cable to the **boom arm** with zip ties.

NOTICE

Check and make sure the pitch cable is clear of any moving parts (free movement) on the trowel before continuing. Re-route the pitch cable if necessary.

5. On the threaded end on the pitch cable remove the 5/16" outer nut and rubber cap as shown by letter (C).
6. Adjust the 5/16" inner nut for a 7/8" distance from the threaded end on the pitch cable to the inner nut as shown by letter (C).
7. Insert the exposed cable into the cable anchor slot.
8. Place outer nut and rubber cap back onto the threaded end of the pitch cable. Hand tighten nut against the cable anchor.
9. Once the threaded end of the pitch cable is secure in the cable anchor, continue to route the pitch cable up to the pitch plate located at the top of the boom arm as shown by letter (D).
10. Align the clevis end of the pitch cable with the pitch plate mounting holes as shown by letter (D).
11. Insert the 5/16-18 x 1" bolt through the clevis. Place a 5/16-18" lock nut onto the bolt.
12. Using a 1/2" wrench tighten the 5/16-18" lock nut.

WINCH CABLE INSTALLATION

1. Uncoil the clevis end of the **winch** cable.
2. Check that the winch cable is attached to the winch bracket on the upper handle as shown by letter (B).
3. Check that the winch cable is fed along the main tube and secured with zip ties.
4. Route the clevis end of the winch cable around the engine up to the **boom cable anchor**.

NOTICE

Check and make sure the winch cable is clear of any moving parts (free movement) on the trowel before continuing. Re-route the pitch cable if necessary.

5. On the threaded end on the winch cable remove the 5/16" outer nut and rubber cap as shown by letter (C).
6. Adjust the 5/16" inner nut for a 7/8" distance from the threaded end on the clutch cable to the inner nut as shown by letter (C).
7. Insert the exposed cable into the cable anchor slot.
8. Place outer nut and rubber cap back onto the threaded end of the winch cable. Hand tighten nut against the cable anchor.
9. Once the threaded end is secured in the cable anchor, continue to route the winch cable over the upper pulley wheel, and over and under the lower pulley wheel as shown by letter (E) and (F) respectively.
10. Repeat steps 10 through 12 (Pitch Cable Installation) to secure the clevis end of the winch cable to the cable anchor, letter (G).

ASSEMBLY AND INSTALLATION




Figure 28. Fresno Pitch/Winch Cable Installation

Before Starting

1. Read all safety instructions at the beginning of manual.
2. Clean the trowel, removing dirt and dust, particularly the engine cooling air inlet, carburetor and air cleaner.
3. Check the air filter for dirt and dust. If air filter is dirty, replace air filter with a new one as required.
4. Check carburetor for external dirt and dust. Clean with dry compressed air.
5. Check fastening nuts and bolts for tightness.

Engine Oil Check

1. To check the engine oil level, place the trowel on secure level ground with the engine stopped.
2. Remove the dipstick from the engine oil filler hole (Figure 29) and wipe clean.




Figure 29. Engine Oil Dipstick Removal

3. Insert and remove the dipstick without screwing it into the filler neck. Check the oil level shown on the dipstick.
4. If the oil level is low (Figure 30), fill to the edge of the oil filler hole with the recommended oil type as listed in Table 4. Reference Table 3 for maximum engine oil capacity.




Figure 30. Engine Oil Dipstick (Oil Level)

Table 4. Oil Type

Season	Temperature	Oil Type
Summer	25°C or Higher	SAE 10W-30
Spring/Fall	25°C~10°C	SAE 10W-30/20
Winter	0°C or Lower	SAE 10W-10

! DANGER



EXPLOSIVE FUEL!

Motor fuels are highly flammable and can be dangerous if mishandled. **DO NOT** smoke while refueling. **DO NOT** attempt to refuel the trowel if the engine is hot! or running.

Fuel Check

1. Visually inspect to see if fuel level is low. If fuel is low, replenish with unleaded fuel.
2. When refueling, be sure to use a strainer for filtration. **DO NOT** top-off fuel. Wipe up any spilled fuel immediately.

Gearbox Oil

1. Determine if the gearbox oil is low by removing the oil plug located on the side of the gearbox. (Figure 31) This plug will be marked by the "check" decal. The correct level of the lubrication oil should be to the bottom of the fill plug.




Figure 31. Gearbox

2. If lubrication oil begins to seep out as the drain plug is being removed, then it can be assumed that the gearbox has a sufficient amount of oil.

INSPECTION/OPERATION

3. If lubrication oil does not seep out as the drain plug is being removed, fill with type ISO 680 (P/N 10139) gearbox lubricant oil until the oil filler hole overflows.

V-Belt Check

A worn or damaged V-belt can adversely affect the performance of the trowel. If a V-belt is defective or worn simply replace the V-belt as outlined in the maintenance section of this manual.

Belt Guard Check

Check for damage, loose or missing hardware.

Blade Check

Check for worn or damaged blades. Check to see if one blade is worn out while the others look new. If this is the case there could be a blade pitch problem. Refer to the maintenance section of this manual for blade pitch adjustment procedure. Replace any worn blades.

Operation

This section is intended to assist the operator with the initial start-up of the walk-behind trowel. It is extremely important that this section be read carefully before attempting to use the trowel in the field. **DO NOT** use your trowel until this section is thoroughly understood.

Lifting the Trowel Onto a Slab

Extra care should be taken when lifting the trowel off the ground. Serious damage to the machine or personal injury could be caused by dropping a trowel.

WARNING

NEVER attempt to lift this machine alone. **NEVER** lift the trowel by the guard ring as it may rotate and cause injury.

ALWAYS make certain the handle is secure and use only the manufacturer's approved lifting point. The trowel may be lifted at the center lifting bale by crane or other lifting device of adequate capacity.

NOTICE

DO NOT attempt to operate the trowel until the Safety, General Information and Inspection sections of this manual have been read and thoroughly understood.

NOTICE

The trowel is heavy and awkward to move around. Use proper heavy lifting procedures and **DO NOT** lift the trowel by the guard rings.

Lifting Bale

The lift bale provides an optimal lift point for lifting the trowel. When lifting the trowel onto a concrete slab, attach a chain or rope to the lifting bale. Make sure the lifting device has adequate lifting capacity to lift the trowel.

Using a crane or forklift (Figure 32) to lift the trowel is highly recommended, and is perfectly safe for the trowel. **ALWAYS** use extra care when lifting the trowel off the ground.




Figure 32. Lifting the Trowel

NEVER lift the trowel to unnecessary heights. **DO NOT** stand underneath the trowel while it is being lifted. Serious damage to the machine or personal injury could be caused by dropping a trowel.

Positioning Boom For Troweling (Side-To-Side)

1. Pull the T-handle (Figure 33) to release the boom from its locked position.
2. Position the boom arm in the desired position. Boom can be rotated left or right up to 90°.
3. When positioned, release the T-handle.




Figure 33. Boom Adjustment (Side-To-Side)

Positioning Fresno Brush

1. Pull the spring-loaded pin on both sides of the brush arm to release the brush (Figure 35).
2. Position the brush as required.
3. Release the spring-loaded pins.




Figure 34. Lowering the Fresno Brush

Lowering and Raising Boom for Troweling

1. Make sure that the fresno blade, fresno brush, and plated weights (if used) are secure and in the proper position before lowering or raising the boom.
2. Rotate the crank handle clockwise to lower, and counterclockwise to raise, the boom (Figure 36).




Figure 35. Winch Hand Crank Rotation

Starting the Engine

1. Turn the engine start/stop switch to the "ON" position (Figure 36).




Figure 36. Engine ON/OFF Switch (ON Position)

2. Place the engine fuel valve lever (Figure 37) in the "ON" position.




Figure 37. Engine Fuel Valve Lever (ON)

3. Place the *throttle lever* (Figure 38) in the "idle" position.




Figure 38. Throttle (Idle Position)

4. Place the **choke lever** (Figure 39) in the "**OPEN**" position.




Figure 39. Choke Lever Open

5. Grasp the starter grip (Figure 40) and slowly pull it out. The resistance becomes the hardest at a certain position, corresponding to the compression point. Pull the starter grip briskly and smoothly for starting.




Figure 40. Starter Grip

6. If the engine has started, slowly return the choke lever (Figure 41) to the **CLOSED** position. If the engine has not started repeat steps 1 through 5.




Figure 41. Choke Lever Closed

7. Before the trowel is placed into operation, run the engine for several minutes. Check for fuel leaks, and noises that would associate with a loose guard ring and/or covers.

To Begin Troweling

1. To begin troweling, place the throttle lever (Figure 42) in the "**RUN**" position.




Figure 42. Throttle Lever (Run)

2. Squeeze the clutch lever (Figure 43) to begin troweling. Verify that the blades are rotating.

NOTICE

When engaging the clutch lever, make sure to keep hands clear of the clutch lever engagement arc/path to prevent pinching and/or bodily harm as indicated in Figure 43.




Figure 43. Clutch Levers (Blade Activation)

Concrete Finishing Techniques

The following steps are intended as a basic guide to machine operation, and are not to be considered a complete guide to concrete finishing. We suggest that all operators (experienced and novice) read "**Slabs on Grade**" published by the **American Concrete Institute, Detroit, Michigan**. Read the "Training" section of this manual for more information.

Pitching the Blades

To pitch the blades upwards, (Figure 44) simply turn the **star-wheel** clockwise. Turning the star wheel counterclockwise will cause the blades to lay flat.





Figure 44. 4-Blade Pitch Star Wheel

Maneuvering the Trowel

1. Get into the operator's position behind the handlebar. With a secure foothold and a firm grasp on the handlebar, slowly increase the engine speed until the desired blade speed is obtained.
2. Figure 45 below illustrates a typical walk-behind trowel application. Practice maneuvering the trowel. The trick is to let the trowel do the work.
3. Continue to practice maneuvering the trowel. Try to practice as if you were finishing a slab of concrete. Practice edging and covering a large area.

Remember a good finishing technique is to work backwards or laterally. Be careful when moving backwards or laterally so that hazards can be avoided. The best way to get accustomed to the trowel is repeated use.

4. After the initial troweling pass, bring the trowel to a clean troweled section.

5. Rotate the winch clockwise to lower the fresno blade and brush to the troweling surface.
6. Slowly walk backwards or laterally to guide the trowel in a straight path. Make sure the fresno blade and brush follow the path of the trowel. This will cover all footprints and troweling marks on wet surfaces.
7. Rotate the winch counterclockwise to raise the fresno blade and brush at the end of the troweling path. If troweling laterally, rotate the boom to the opposite side between passes before beginning a new pass.
8. Repeat **Steps 4-7** until the troweling surface is completely finished.

CAUTION


NEVER place your **feet** or **hands** inside the guard rings while starting or operating this equipment.

CAUTION

ALWAYS keep clear of **rotating** or **moving** parts while operating this equipment.

To move the trowel to the operator's left, **lift up** on the handle, to move the trowel to the right **push down** on the handle.

Remember! that if you let go of the clutch lever, just **step away** as the trowel will stop immediately.



Remember! that if you let go of the trowel, just **step away** and let the trowel come to a complete **STOP** before trying to recover the trowel.

The best method for finishing concrete is to slowly walk **backwards** with the trowel, guiding the trowel from side to side. This will cover all footprints on wet concrete.

Figure 45. Maneuvering the Trowel

Stopping The Engine

1. Move the throttle lever to the (Figure 46) "IDLE" position and run the engine for three minutes at low speed.




Figure 46. Throttle Lever (Idle)

2. After the engine cools, turn the engine start/stop switch to the "OFF" position (Figure 47).




Figure 47. Engine ON/OFF Switch (OFF Position)

3. Close the fuel shut-off valve (Figure 48) by moving the fuel valve lever to the **OFF** position.




Figure 48. Fuel Valve Lever (OFF)

NOTICE

Trowel blades should be changed when they fail to finish concrete in a satisfactory manner.

Blades are a vital part of finishing concrete. This trowel, or finisher, has been designed to finish concrete and the blades are built to stringent quality standards out of the finest steel.

If you need replacement blades, consult the parts list in this manual for part numbers and order them from your Multiquip parts dealer or importer.

Combo Blades

This trowel is equipped with combination float/finish (Figure 49) blades as original equipment. These blades have been designed for optimum performance in both the floating and finishing operations. These blades are versatile and should take care of most troweling needs.




Figure 49. Combination Blade

Finish Blades (Optional)

These blades (Figure 50) have been specifically designed for finish operations with this trowel. They will provide a premium surface finishing capability from your trowel. They should only be used after the concrete has set to the point where the trowel does not sink into the concrete when placed on it.




Figure 50. Finish Blade

Clip-On Float Blades (Optional)

These blades will clip (Figure 51) onto an existing installed blade, allowing your finisher to float on “wet” concrete so that the troweling operation can begin as early as possible. These blades are easily removable, so that after the floating operation, when the concrete is sufficiently cured, they can be removed to expose the finish blades for continued troweling.




Figure 51. Clip-On Float Blade

Float Discs (Optional)

These round discs (Figure 52) attach to the spiders and allow the machine to “float” on “wet” concrete. The disc design allows early floating and easy movement from wet to dry areas. They are also very effective in embedding large aggregates and surface hardeners.




Figure 52. Float Disc/Pan

Trowel Arm Adjustment Tool (Optional)

If blades show uneven wear patterns or some tend to wear out faster than others, the trowel arms may need to be adjusted. A special tool is available (Figure 53) that will adjust all of the trowel arms consistently. The Trowel Arm Fixture P/N is 1817.




Figure 53. Trowel Arm Adjustment Fixture

FRESNO BRUSHES

NOTICE

Fresno brushes should be changed when they fail to finish concrete in a satisfactory manner.

Fresno brushes are a vital part of finishing concrete. The fresno brush is designed to finish concrete with a textured, or decorative, look using the sides of the brush bristles, not the ends. There are three different color-coded, textured (stiffness) brushes compatible with this trowel unit: soft (black), medium (orange), stiff (green).

If you need a replacement brush, or want a different finished look to the troweling surface, consult the parts list in this manual for part numbers and order them from your Multiquip parts dealer or importer.

MAINTENANCE

Table 5. Engine Maintenance Schedule

DESCRIPTION (3)	OPERATION	BEFORE EACH USE	FIRST MONTH OR 20 HRS.	EVERY 6 MONTHS OR 100 HRS.	EVERY YEAR OR 300 HRS.	EVERY 2 YEARS OR 500 HRS.
Engine Oil	Check	X				
	Change		X	X		
Engine Oil Filter	Replace	Every 200 Hrs.				
Air Cleaner	Check	X				
	Clean			X (1)		
	Change					X (*)
Spark Plugs	Check/Adjust			X		
	Replace				X	
Spark Arrester	Clean			X		
Fuel Filter	Replace				X (2)	
Fuel Tube	Check	Every 2 years (replace if necessary) (2)				

* - Replace the paper filter element only.

(1) Service more frequently when used in **DUSTY** areas.

(2) These items should be serviced by your service dealer, unless you have the proper tools and are mechanically proficient. Refer to the HONDA Shop Manual for service procedures.

(3) For commercial use, log hours of operation to determine proper maintenance intervals.

Table 6. Trowel Maintenance Schedule

ITEM	OPERATION	DAILY	Periodic Maintenance Interval		
			Every 50-60 Hrs	Every 200-300 Hrs	Every 2000-2500 Hrs
V-Belt	Check/Replace	X			
Relube Trowel Arms	Grease		X		
Blades	Check/Replace		X		
Trowel Arms	Remove/Clean			X	
Thrust Collar/Bushing	Remove/Clean			X	
Blade Arms	Adjust			X	
Arm Bushing	Remove/Replace				X
Wear Ring	Remove/Replace				X
Thrust Collar Bearing	Remove/Replace				X
Pitch Control Cable	Check				X
Clutch	Remove/Clean			X	

[illegible]

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment ,Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar

General maintenance practices are crucial to the performance and longevity of your trowel. This equipment requires routine cleaning, blade and trowel arm inspection, lubrication and V-belt inspection for wear and damage. Reference Table 5 and Table 6 for scheduled engine and trowel maintenance.

The following procedures, devoted to maintenance, can prevent serious trowel damage or malfunctioning.

NOTICE

Reference **HONDA** engine manual supplied with your trowel for more detailed engine maintenance and troubleshooting.

CAUTION



ALWAYS allow the engine to cool before servicing. **NEVER** attempt any maintenance work on a hot engine.

CAUTION

ALWAYS disconnect the spark plug wire from the spark plug and secure away from the engine before performing maintenance or adjustments on the machine.

WARNING



Some maintenance operations may require the engine to be run. Ensure that the maintenance area is well ventilated. Gasoline engine exhaust contains poisonous carbon monoxide gas that can cause unconsciousness and may result in **DEATH**.

GENERAL CLEANLINESS

Clean the trowel daily. Remove all dust and slurry buildup. If the trowel is steam-cleaned, ensure that lubrication is accomplished **AFTER** steam cleaning.

ENGINE CHECK

Check daily for any oil and/or fuel leakage, thread nut and bolt tightness, and overall cleanliness.

Engine Air Cleaner

DANGER



DO NOT use gasoline or low flash point solvents for cleaning the air cleaner, the possibility exists of fire or explosion which can cause damage to the equipment and severe bodily harm or even **DEATH**!

CAUTION



Wear protective equipment such as approved safety glasses or face shields and dust masks or respirators when cleaning air filters with compressed air.

This engine is equipped with a replaceable, high-density paper air cleaner element. See Figure 54 for air cleaner components.

1. Remove the air cleaner cover and foam filter element.
2. Tap the paper filter element several times on a hard surface to remove dirt, or blow compressed air not exceeding 30 psi (207 kPa, 2.1 kgf/cm²) through the filter element from the inside out. **NEVER** brush off dirt. Brushing will force dirt into the fibers. Replace the paper filter element if it is excessively dirty.
3. Clean foam element in warm, soapy water or nonflammable solvent. Rinse and dry thoroughly. Dip the element in clean engine oil and completely squeeze out the excess oil from the element before installing.




Figure 54. Engine Air Cleaner

NOTICE

Operating the engine with loose or damaged air cleaner components could allow unfiltered air into the engine causing premature wear and failure.

ENGINE OIL

1. Drain the engine oil when the oil is warm as shown in Figure 55.
2. Remove the oil drain bolt and sealing washer and allow the oil to drain into a suitable container.
3. Replace engine oil with recommended type oil as listed in Table 4. For engine oil capacity, see Table 3 (engine specifications). **DO NOT** overfill.
4. Reinstall drain bolt with sealing washer and tighten securely.




Figure 55. Draining Engine Oil

SPARK PLUG

NOTICE

NEVER use a spark plug of incorrect heat range.

1. Remove and clean spark plug (Figure 56) with a wire brush if it is to be reused. Discard spark plug if the insulator is cracked or chipped.
2. Using a feeler gauge adjust spark plug gap to 0.028 ~0.031 inch (0.7~0.8 mm).
3. Thread spark plug into cylinder hole by hand to prevent cross-threading, then tighten securely.




Figure 56. Spark Plug Gap

V-BELT

Visually examine the V-belt (Figure 57) and determine if it is full of tiny cracks, frayed, has pieces of rubber missing, is peeling or otherwise damaged.

Also, examine the belt and determine if it is **oil soaked** or **"glazed"** (hard shiny appearance on the sides of the belt). Either of these two conditions can cause the belt to run hot, which can weaken it and increase the danger of it breaking.

If the V-belt exhibits any of the above wear conditions replace the V-belt immediately.




Figure 57. V-Belt Inspection

SPARK ARRESTER CLEANING

Clean the spark arrester every 6 months or 100 hours.

1. Remove the 4 mm screw (3) from the exhaust deflector, then remove the deflector. See Figure 58.
2. Remove the 5 mm screw (4) from the muffler protector, then remove the muffler protector.
3. Remove the 4 mm screw from the spark arrester, then remove the spark arrester.




Figure 58. Spark Arrester Removal

4. Carefully remove carbon deposits from the spark arrester screen (Figure 59) with a wire brush.




Figure 59. Cleaning The Spark Arrester

5. If the spark arrester is damaged and has breaks or holes, replace with a new one.
6. Reinstall the spark arrester and muffler protector in reverse order of disassembly.

4-BLADE PITCH ADJUSTMENT PROCEDURE

The maintenance adjustment of blade pitch is an adjustment that is made by a bolt (Figure 60) on the arm of the trowel arm lever. This bolt is the contact point of the trowel arm lever to the lower wear plate on the thrust collar. The goal of the adjustment is to promote consistent blade pitch and finishing quality. Adjustments are made by tightening or loosening the blade pitch adjustment bolt.




Figure 60. Blade Pitch Adjustment Bolt

Watch for the following indications when determining if blade pitch adjustments are necessary:

- Is the machine wearing out blades unevenly, (i.e. one blade is completely worn out while the others look new)?
- Does the machine have a perceptible rolling or bouncing motion when in use?
- Look at the machine while it is running, do the guard rings "rock up and down" relative to the ground?

If it is determined that blade pitch adjustments are required, do the following:

NOTICE

Before any blade pitch adjustments can be made it is essential to have a clean level area free of dirt and debris to test the trowel. Any unlevel spots in the floor or debris under the trowel blades will give an incorrect perception of adjustment. Ideally, a 5 x 5 ft. (1.5 x 1.5 meter), three-quarter inch (19 mm) thick **FLAT** steel plate should be used for testing.

1. Place the trowel on a flat, level area free of dirt and debris.

2. Pitch the blades as flat as possible. The pitch adjustment bolts (Figure 61) should all barely make contact (0.10 inch max. clearance) with the **lower wear plate** on the spider. All pitch alignment bolts should be spaced the same distance from the lower wear plate. If one is not making contact, adjustment will be necessary.




Figure 61. Correct Blade Pitch (Flat)

3. Adjust the "high" bolts down to the level of the one that is not touching, or adjust the "low" bolt up to the level of the higher ones. If possible, adjust the low bolt up to the level of the rest of the bolts. This is the fastest way, but may not always work. Verify after adjustment the blades pitch correctly.
4. Blades that are incorrectly adjusted often will not be able to pitch flat. This can occur if the adjusting bolts are raised too high. Conversely, adjusting bolts that are too low will not allow the blades to be pitched high enough for finishing operations.
5. If, after making blade pitch adjustments the machine is still finishing poorly, blades, trowel arms, and trowel arm bushings may be suspect and should be looked at for adjustment, wear, or damage.
6. Figure 62 illustrates, "incorrect alignment", worn spider bushings or bent trowel arms.




Figure 62. Incorrect Spider Plate Alignment

SPIDER REMOVAL

Remove the spider assembly from the gearbox shaft as follows:

1. Locate the cone point square head set screw (Figure 63) and attached jam nut found on the side of the spider assembly.
2. Loosen the jam nut and cone point square head set screw.
3. Carefully lift the upper trowel/gearbox assembly off of the spider assembly. A slight tap with a rubber mallet may be necessary to dislodge the spider from the main shaft of the gearbox.




Figure 63. Spider Removal

CHANGING BLADES

It is recommended that **ALL** the blades on the trowel are changed at the same time. If only one or some of the blades are changed, the machine will not finish concrete consistently and the machine may wobble or bounce.

Perform the following procedure when changing blades: Please note the blade orientation on the trowel arm before removing.

1. Lift the trowel up, placing blocks under the main guard ring to support it.
2. Remove the bolts and lock washers from all the towel arms, and then remove the blades as shown in Figure 64.




Figure 64. Blade Removal

3. Wire brush and remove all concrete and debris from all six sides of each of the four trowel arms. This is important to properly seat the new blades.
4. Install the new blades, maintaining the proper blade orientation for direction of rotation.
5. Reinstall the bolts and lock washers.

TROWEL ARM REMOVAL

1. Each trowel arm is held in place at the spider plate by a hex head bolt (zerk grease fitting) and a roll pin. Remove both the hex head bolt and the roll pin (Figure 65) from the spider plate.
2. Remove the trowel arm from the spider plate.
3. Should the trowel arm inserts (bushing) come out with the trowel arm, remove the bushing from the trowel arm and set aside in a safe place. If the bushing is retained inside the spider plate, carefully remove the bushing.
4. Examine the trowel arm bushing insert (Figure 65), clean if necessary. Replace bushing if out of round or worn.




Figure 65. Trowel Arm Removal

CHECKING TROWEL ARM STRAIGHTNESS

Trowel arms (Figure 66) can be damaged by rough handling, such as dropping the trowel on the pad, or by striking exposed plumbing, forms, or rebar while in operation. A bent trowel arm will not allow the trowel to operate in a smooth fluid rotation. If bent trowel arms are suspect, check for flatness as follows:




Figure 66. Trowel Arm

1. Use a thick steel plate, granite slab or any surface which is true and flat, to check all six sides of each trowel arm for flatness (Figure 67).
2. Check each of the six sides of the trowel arm (hex section). A feeler gauge of .004 inch (0.10 mm) should not pass between the flat of the trowel arm and the test surface along its length on the test surface.




Figure 67. Checking Trowel Arm Flatness

3. Next, check the clearance between the round shaft and the test surface as one of the flat hex sections of the arm rests on the test surface. Rotate the arm to each of the flat hex sections and check the clearance of the round shaft. Use a feeler gauge (Figure 68) of .005 inch (0.127 mm). Each section should have the same clearance between the round of the trowel arm shaft and the test surface.
4. If the trowel arm is found to be uneven or bent, replace the trowel arm.

TROWEL ARM LEVER ADJUSTMENT

The easiest and most consistent way to adjust the trowel arm lever is to use the Trowel Arm Adjustment Fixture (P.N. 1817).

As each trowel arm is locked into the fixture, the arm bolt is adjusted to where it contacts a stop on the fixture. This will consistently adjust all of the trowel arms, keeping the finisher as flat and evenly pitched as possible.

This fixture will allow consistent adjustment of the trowel arm lever. It comes with all the hardware necessary to properly accomplish this maintenance and instructions on how to properly utilize this tool. Adjusting the trowel arm lever without a fixture requires a special talent.

Perform the following procedure when adjusting the trowel arm lever:

1. Unscrew the locking bolts on the adjustment fixture and place the trowel arm (lever attached) into the fixture channel as shown in Figure 68.
2. Ensure the fixture arm is in the up position.
3. A thin shim may be required to cover the blade holes on the trowel arm. Make sure to align the trowel adjustment bolt with the fixture adjustment bolt.




Figure 68. Trowel Arm Adjustment Fixture

4. Use an allen wrench to tighten the locking bolts securing the trowel arm in place.
5. Adjust the bolt distance shown in Figure 68 to match one of the arms. The other arms will be adjusted to match this distance.

6. Loosen the locking nut on the trowel arm lever, then turn the trowel arm adjusting bolt until it barely touches (.010") the fixture adjusting bolt.
7. Once the correct adjustment is made, tighten the lock nut on the trowel arm to lock in place.
8. Loosen locking nuts on the adjustment fixture, and remove trowel arm.
9. Repeat steps for the remaining trowel arms.

REASSEMBLY

1. Clean and examine the upper/lower wear plates and thrust collar. Examine the entire spider assembly. Wire brush any concrete or rust buildup. If any of the spider components are found to be damaged or out of round, replace them.
2. Make sure that the bronze trowel arm bushing is not damaged or out of round. Clean the bushing if necessary. If the bronze bushing is damaged or worn, replace it.
3. Reinstall bronze bushing onto trowel arm.
4. Repeat steps 2 -3 for each trowel arm.
5. Make sure that the spring tensioner is in the correct position to exert tension on the trowel arm.
6. Insert all trowel arms with levers into spider plate (with bronze bushing already installed) using care to align grease hole on bronze bushing with grease hole fitting on spider plate.
7. Lock trowel arms in place by tightening the hex head bolt with zerk grease fitting and jam nut.
8. Reinstall the blades onto the trowel arms.
9. Install stabilizer ring onto spider assembly.
10. Reinstall lower wear plate, thrust collar and upper wear ring in the reverse order that they were disassembled onto the spider shaft. Make sure that there is little or no lateral movement between the thrust collar and the spider shaft.
11. Carefully lift the upper trowel assembly, line up the keyway on gear box main shaft and insert into spider assembly.

12. Reinstall square head cone point into spider plate and tighten in place. Tighten jam nut. Use care in making sure point of set screw engages groove in gear box main shaft.
13. Lubricate all grease points (zerk fittings) with premium "Lithium 12" based grease, conforming to NLG1 Grade #2 consistency.

INSTALLING PANS ONTO FINISHER BLADES

These round discs, sometimes referred to as "pans", attach to the spiders arms and allow easy floating on wet concrete and easy movement from wet to dry areas. They are also very effective in embedding large aggregates and surface hardeners.

Refer to Figure 69 when installing pans onto finisher blades.




Figure 69. Z-Clip Finisher Pan Installation

1. Lift trowel just enough to slide pan under blades. Lower finisher onto pan with blades adjacent to Z-Clips.
2. Rotate blades into position under Z-Clips. Ensure that the blades are rotated in the direction of travel when the machine is in operation or use the engine to rotate the blades into position.
3. Attach the blade tie-downs to the far side of the Z-Clip brackets with tie-down knobs as shown in Figure 69.
4. Check to make certain that the blade edges are secured under the Z-Clips and the tie-downs are secured completely over the edges of the blade bar before the machine is put back into operation.

LONG-TERM STORAGE

For storage of the trowel for over 30 days, the following is required:

- Drain the fuel tank completely, or add STA-BIL to the fuel.
- Run the engine until the gasoline in the carburetor is completely consumed.
- Completely drain the oil from the crankcase and refill with fresh oil.
- Remove the spark plug. Pour 5 to 10 cc of SAE 30 oil into the cylinder. Turn the engine switch to the **START** position for a few seconds to distribute the oil. Reinstall the spark plug.
- Clean all external parts of the trowel with a cloth.
- Cover the trowel and store in a clean, dry place.

TROUBLESHOOTING

Troubleshooting (Engine)		
Symptom	Possible Problem	Solution
Difficult to start, fuel is available, but no spark at spark plug.	Spark plug bridging?	Check gap, insulation or replace spark plug.
	Carbon deposit on spark plug?	Clean or replace spark plug.
	Short circuit due to deficient spark plug insulation?	Check spark plug insulation, replace if worn.
	Improper spark plug gap?	Set to proper gap.
	Fuel reaching carburetor?	Check fuel line.
	Water in fuel tank?	Flush or replace fuel tank.
	Fuel filter clogged?	Replace fuel filter.
	Stuck carburetor?	Check float mechanism.
	Spark plug is red?	Check transistor ignition unit.
	Spark plug is bluish white?	If insufficient compression, repair or replace engine. If injected air leaking, correct leak. If carburetor jets clogged, clean carburetor.
	No spark present at tip of spark plug?	Check transistor ignition unit is broken, and replace defective unit. Check if voltage cord cracked or broken and replace. Check if spark plug if fouled and replace.
	No oil?	Add oil as required.
	Oil pressure alarm lamp blinks upon starting? (if applicable)	Check automatic shutdown circuit, "oil sensor". (if applicable)
Difficult to start, fuel is available, and spark is present at the spark plug.	ON/OFF switch is shorted?	Check switch wiring, replace switch.
	Ignition coil defective?	Replace ignition coil.
	Improper spark gap, points dirty?	Set correct spark gap and clean points.
	Condenser insulation worn or short circuiting?	Replace condenser.
	Spark plug wire broken or short circuiting?	Replace defective spark plug wiring.
Difficult to start, fuel is available, spark is present and compression is normal.	Wrong fuel type?	Flush fuel system, and replace with correct type of fuel.
	Water or dust in fuel system?	Flush fuel system.
	Air cleaner dirty?	Clean or replace air cleaner.
	Choke open?	Close choke.
Difficult to start, fuel is available, spark is present and compression is low.	Suction/exhaust valve stuck or protruded?	Reseat valves.
	Piston ring and/or cylinder worn?	Replace piston rings and/or piston.
	Cylinder head and/or spark plug not tightened properly?	Torque cylinder head bolts and spark plug.
	Head gasket and/or spark plug gasket damaged?	Replace head and spark plug gaskets.
No fuel present at carburetor.	No fuel in fuel tank?	Fill with correct type of fuel.
	Fuel cock does not open properly?	Apply lubricant to loosen fuel cock lever, replace if necessary.
	Fuel filter/lines clogged?	Replace fuel filter.
	Fuel tank cap breather hole clogged?	Clean or replace fuel tank cap.
	Air in fuel line?	Bleed fuel line.

TROUBLESHOOTING

Troubleshooting (Engine) - continued		
Symptom	Possible Problem	Solution
Weak in power, compression is proper and does not misfire.	Air cleaner dirty?	Clean or replace air cleaner.
	Improper level in carburetor?	Check float adjustment, rebuild carburetor.
	Defective spark plug?	Clean or replace spark plug.
	Improper spark plug?	Set to proper gap.
Weak in power, compression is proper but misfires.	Water in fuel system?	Flush fuel system and replace with correct type of fuel.
	Dirty spark plug?	Clean or replace spark plug.
	Ignition coil defective?	Replace ignition coil.
Engine overheats.	Spark plug heat value incorrect?	Replace with correct type of spark plug.
	Wrong type of fuel?	Replace with correct type of fuel.
	Cooling fins dirty?	Clean cooling fins.
	Intake air restricted?	Clear intake of dirt and debris. Replace air cleaner elements as necessary.
	Oil level too low or too high?	Adjust oil to proper level.
Rotational speed fluctuates.	Governor adjusted incorrectly?	Adjust governor.
	Governor spring defective?	Replace governor spring.
	Fuel flow restricted?	Check entire fuel system for leaks or clogs.
Recoil starter malfunctions. (if applicable)	Recoil mechanism clogged with dust and dirt?	Clean recoil assembly with soap and water.
	Spiral spring loose?	Replace spiral spring.
Starter malfunctions.	Loose, damaged wiring?	Ensure tight, clean connections on battery and starter.
	Battery insufficiently charged?	Recharge or replace battery.
	Starter damaged or internally shorted?	Replace starter.
Burns too much fuel.	Over-accumulation of exhaust products?	Check and clean valves. Check muffler and replace if necessary.
	Wrong spark plug?	Replace spark plug with manufacturer's suggested type.
Exhaust color is continuously "white".	Lubricating oil is wrong viscosity?	Replace lubricating oil with correct viscosity.
	Worn rings?	Replace rings.
Exhaust color is continuously "black".	Air cleaner clogged?	Clean or replace air cleaner.
	Choke valve set to incorrect position?	Adjust choke valve to correct position.
	Carburetor defective, seal on carburetor broken?	Replace carburetor or seal.
	Poor carburetor adjustment, engine runs too rich?	Adjust carburetor.
Will not start, no power with ON/OFF switch in "ON" position.	ON/OFF switch not activated ON?	Turn on ON/OFF Switch.
	ON/OFF switch/wiring defective?	Replace ON/OFF switch. Check wiring.
	Centrifugal stop switch not activated ON?	Turn on centrifugal stop switch.
	Centrifugal stop switch/wiring defective?	Replace centrifugal stop switch. Check wiring.



TROUBLESHOOTING

Troubleshooting (Walk-Behind Trowel)		
Symptom	Possible Problem	Solution
Engine running rough or not at all.	Engine ON/OFF Switch in "OFF" position or malfunctioning?	Make sure that the Engine ON/OFF Switch is ON or replace switch if necessary.
	Centrifugal ON/OFF Switch in "OFF" position or malfunctioning?	Place centrifugal stop switch in "ON" position. Check wiring. Replace switch if necessary.
	Fuel?	Look at the fuel system. Make sure there is fuel being supplied to the engine. Check to ensure that the fuel filter is not clogged.
	Ignition?	Check to ensure that the ignition switch has power and is functioning correctly.
	Loose wire connections	Check wiring. Replace or repair as necessary.
	Bad contacts in ON/OFF switch?	Replace ON/OFF switch.
Trowel bounces, rolls concrete, or makes uneven swirls in concrete.	Blades?	Make certain blades are in good condition, not excessively worn. Finish blades should measure no less than 2" (50mm) from the blade bar to the trailing edge, combo blades should measure no less than 3.5" (89mm). Trailing edge of blade should be straight and parallel to the blade bar.
	Pitch adjustment?	Check that all blades are set at the same pitch angle as measured at the spider. A field adjustment tool is available for height adjustment of the trowel arms. (Contact Parts Dept.)
	Bent trowel arms?	Check the spider assembly for bent trowel arms. If one of the arms is even slightly bent, replace it immediately.
	Spider?	Check fit of arms in spider. This can be done by moving the trowel arms up and down. If there is more than 1/8 inch (3.2 mm) of travel at the tip of the arm, the spider and arms should be replaced.
	Thrust collar?	Check the flatness of the thrust collar by rotating it on the spider. If it varies by more than 0.02 inch (0.5 mm) replace the thrust collar.
	Thrust collar bushing?	Check the thrust collar by rocking it on the spider. If it can tilt more than 3/32 inch (2.4 mm) - as measured at the thrust collar O.D., replace the thrust collar.
	Thrust bearing worn?	Check the thrust bearing to see that it is spinning freely. Replace if necessary.

TROUBLESHOOTING

Troubleshooting (Walk-Behind Trowel) - continued		
Symptom	Possible Problem	Solution
Machine has a perceptible rolling motion while running.	Main shaft?	The main output shaft of the gearbox assembly should be checked for straightness. The main shaft must run straight and cannot be more than 0.003" (0.08 mm) out of round at the spider attachment point.
	Yoke?	Check to make sure that both fingers of the yoke press evenly on the wear cap. Replace yoke as necessary.
	Blade Pitch?	Check to ensure that each blade is adjusted to have the same pitch as all other blades. Adjust per maintenance section in manual.
Clutch slipping or sluggish response to engine speed change.	Worn V-belts?	Replace V-belt.
	Hand clutch out of adjustment?	Adjust per instructions in maintenance section of this manual.
	Worn or defective hand clutch parts?	Replace parts as necessary.
	Worn bearings in gearbox?	Rotate input shaft by hand. If shaft rotates with difficulty, check the input and output shaft bearings. Replace as necessary.
	Worn or broken gears in gearbox?	Verify that the gearbox shaft rotates when the input shaft is rotated. Replace both the worm and worm gear as a set.
Trowel blades do not rotate.	Defective clutch?	Replace clutch.
	Broken V-belt?	Replace V-belt.
	Defective ON/OFF switch?	Check and replace ON/OFF switch if necessary.
	Defective centrifugal ON/OFF switch?	Check and replace centrifugal ON/OFF switch if necessary.

WIRING DIAGRAM



NOTES

[illegible]

EXPLANATION OF CODE IN REMARKS COLUMN

The following section explains the different symbols and remarks used in the Parts section of this manual. Use the help numbers found on the back page of the manual if there are any questions.

NOTICE

The contents and part numbers listed in the parts section are subject to change **without notice**. Multiquip does not guarantee the availability of the parts listed.

SAMPLE PARTS LIST

NO.	PART NO.	PART NAME	QTY.	REMARKS
1	12345	BOLT	1	INCLUDES ITEMS W/%
2%		WASHER, 1/4 IN.		NOT SOLD SEPARATELY
2%	12347	WASHER, 3/8 IN. ...	1	MQ-45T ONLY
3	12348	HOSE	A/R	MAKE LOCALLY
4	12349	BEARING	1	S/N 2345B AND ABOVE

NO. Column

Unique Symbols — All items with same unique symbol (@, #, +, %, or >) in the number column belong to the same assembly or kit, which is indicated by a note in the “Remarks” column.

Duplicate Item Numbers — Duplicate numbers indicate multiple part numbers, which are in effect for the same general item, such as different size saw blade guards in use or a part that has been updated on newer versions of the same machine.

NOTICE

When ordering a part that has more than one item number listed, check the remarks column for help in determining the proper part to order.

PART NO. Column

Numbers Used — Part numbers can be indicated by a number, a blank entry, or TBD.

TBD (To Be Determined) is generally used to show a part that has not been assigned a formal part number at the time of publication.

A blank entry generally indicates that the item is not sold separately or is not sold by Multiquip. Other entries will be clarified in the “Remarks” Column.

QTY. Column

Numbers Used — Item quantity can be indicated by a number, a blank entry, or A/R.

A/R (As Required) is generally used for hoses or other parts that are sold in bulk and cut to length.

A blank entry generally indicates that the item is not sold separately. Other entries will be clarified in the “Remarks” Column.

REMARKS Column

Some of the most common notes found in the “Remarks” Column are listed below. Other additional notes needed to describe the item can also be shown.

Assembly/Kit — All items on the parts list with the same unique symbol will be included when this item is purchased.

Indicated by:

“INCLUDES ITEMS W/(unique symbol)”

Serial Number Break — Used to list an effective serial number range where a particular part is used.

Indicated by:

“S/N XXXXX AND BELOW”

“S/N XXXX AND ABOVE”

“S/N XXXX TO S/N XXX”

Specific Model Number Use — Indicates that the part is used only with the specific model number or model number variant listed. It can also be used to show a part is NOT used on a specific model or model number variant.

Indicated by:

“XXXXX ONLY”

“NOT USED ON XXXX”

“Make/Obtain Locally” — Indicates that the part can be purchased at any hardware shop or made out of available items. Examples include battery cables, shims, and certain washers and nuts.

“Not Sold Separately” — Indicates that an item cannot be purchased as a separate item and is either part of an assembly/kit that can be purchased, or is not available for sale through Multiquip.

SUGGESTED SPARE PARTS

PRO36 WALK-BEHIND TROWEL

1 to 3 Units

Qty.	P/N	Description
1.....	30159.....	CABLE, THROTTLE 68"
1.....	30158.....	CABLE, CONTROL
1.....	30229.....	CABLE, INSTACLUTCH
1.....	30188.....	CABLE, FRESNO PITCH
1.....	30198.....	CABLE, FRESNO WINCH
2.....	0152 3.....	V-BELT, A28
4.....	1157 A.....	BUSHING, TROWEL ARM
4.....	2826-1.....	ARM, TROWEL 9-3/4"
1.....	10968.....	THRUST BEARING KIT
2.....	20111.....	OIL, MOBIL SYNTHETIC 220Z.


HONDA GX270UT2QA2 GASOLINE ENGINE

Qty.	P/N	Description
3.....	17210ZE2515.....	ELEMENT, AIR CLEANER
3.....	9807956846.....	SPARK PLUG, BPR6ES
1.....	28462ZE2W11.....	ROPE, RECOIL STARTER
1.....	17620Z4H030.....	CAP, FUEL TANK, CHROME
1.....	17672Z4H000.....	FUEL FILTER

NOTICE

Part numbers on this Suggested Spare Parts list may supersede/replace the part numbers shown in the following parts lists.


NAMEPLATES AND DECALS



NAMEPLATES AND DECALS

NO.	PART NO.	PART NAME	QTY.	REMARKS
1#	36099	ISO DECAL: PROTECTIVE CLOTHING, 3.50" X 1.13"	1	
2#	23701	ISO DECAL: ASK FOR TRAINING, 2.00" DIA.	1	
3	2942	DECAL: MQ WHITEMAN 13" WHITE	1	
4	1492	DECAL: FINISHER HANDLE	1	
5	30319	DECAL KIT	1	INCLUDES ALL ITEMS W/#
6	23803-107	ISO DECAL: GUARANTEED SOUND 107 dbA	1	
7#	20816	DECAL: MQ LOGO 6.78" X .80"	2	
8		DECAL: SERIAL PLATE	1	CONTACT DISCOUNT-EQUIPMENT
9	4014	SCREW, 2-3/16 P-K TYPE U-DRIVE	2	
10#	22070	DECAL: MQ MULTQUIP ROUND	1	
11#	23704	ISO DECAL: GUARD WARNING 2.00" DIA.	1	
12#	23698	ISO DECAL: ROTATING BLADE HAZARD, 2.00" DIA.	1	
13#	23810	ISO DECAL: INHALATION HAZARD, 2.00" DIA	1	
14#	23699	ISO DECAL: READ MANUAL, 2.00" DIA.	1	
15#	23700	ISO DECAL: LIFTING/CRUSH, 2.4" X 2.0"	1	


STANDARD HANDLE ASSY.



STANDARD HANDLE ASSY.

NO.	PART NO.	PART NAME	QTY.	REMARKS
1#%	30155	UPPER HANDLE	1	
2#%	30203	PIN, ROLL, 3/16" X 7/8"	3	
3#%	22208	PLUG, THROTTLE LEVER	2	
4#%	22762	GRIP, HANDLE	1	
5#%	30169	CASTING, RIGHT PADDLE	1	
6#%	30173	BUSHING, FLANGED, BRONZE, .51" ID X .625" OD	2	
7#%	22732	THROTTLE LEVER ASSY.	1	
8#%	30172	ROD, TORSION BAR	1	
9#%	30171	CASTING, CABLE PULL	1	
10#%	30170	CASTING, LEFT PADDLE	1	
11#%	22166	COVER, VIBE CONTROL HANDLE PAD	1	
12#	30156	UPPER HANDLE ASSY. INSTACLUTCH	1	INCLUDES ITEMS W/%
13#	20819	HAND WHEEL ASSY., PITCH CONTROL.....	1	INCLUDES ITEMS W/\$
14#\$	0122 C	SCREW, SHS 3/8-16 X 1/2"	1	
15#\$	0281	BEARING, THRUST	1	
16#\$	1478	SHAFT, TROWEL CONTROL	1	
17#\$	3615	COLLAR, SET 3/4" ID W/SET SCREW	1	
18#\$	20282	BEARING, TROWEL CONTROL	1	
19#\$	20817	WHEEL, HANDLE	1	
20#	0786	SCREW, BHC 1/4-20 X 3/8" NYL PATCH, NP	2	
21#	0786 A	SPACER, SLIDE BLOCK GUIDE, .360" X 17/64" X 1/8" L	1	
22#	1116	NUT, BRASS JAM 5/16-18	2	
24#	30158	CABLE, CONTROL	1	
25#	20287	SLIDE BLOCK, TROWEL CONTROL	1	
27#	21017	SCREW, HHC 3/8-16 x 3-1/4" FULL THRD GRD5	1	
28#	30159	CABLE, THROTTLE	1	
29#	30160	HOUSING, THROTTLE CABLE	1	
31#	30161	HANDLE, PRO TROWEL VIBE CONTROL	1	
32#	30232	KIT, HANDLE INSTALLATION	1	INCLUDES ITEMS W/◆
33#	30229	CABLE, INSTACLUTCH	1	
34	30204	MAIN HANDLE ASSY, PRO.....	1	INCLUDES ITEMS W/#


STANDARD HANDLE ASSY.



STANDARD HANDLE ASSY.

NO.	PART NO.	PART NAME	QTY.	REMARKS
35#	20280	BLOCK, PITCH CONTROL	1.....	INCLUDES ITEMS W/@
36#@	20279	PIN, SUPPORT BLOCK	1	
37#@	1118	PULLEY, PITCH CABLE ASSY.	1	
38#@	20275	BLOCK, SUPPORT	1	
39#❖	1665	SCREW, HHC 3/8-16 X 2"	2	
40#❖	3233	WASHER, FENDER, 1.5"OD X 3/8"ID	4	
41#❖	9154	SCREW, HHC 3/8-16 X 1-3/4"	1	
42#❖◆	10133	NUT, NYLOC 3/8-16"	4	
43#❖	22059	ISOLATOR, VIBRATION	3	
44#❖	22167	SCREW, HHC 3/8-16 X 6.5" GRD 5	1	
45#❖	22206	CHASSIS, CAST VIBRATION ISOLATOR	1	
46#❖	20439	WHEEL ASSY. , HAND	1	
47#	30206	VIBE CHASSIS ASSY.....	1.....	INCLUDES ITEMS W/❖
48#	60097	LOCTITE, BLUE #246	1	
49#◆	21746	SPRING, PRIMARY THROTTLE RETURN	1	
50#◆	1493	SCREW, HHC 3/8-16 X 3-1/4"	1	
51#◆	10136	WASHER, 3/8" FLAT	2	
54#	25383	TIE, CABLE TY-RAP, BLACK 14.7 X .1875	3	


STANDARD HANDLE ASSY. (CONTINUED)



STANDARD HANDLE ASSY. (CONTINUED)

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
55#	0786 A	SPACER, SLIDE BLOCK GUIDE, .360 X 17/64 X 1/8L	1	
56#	0786	SCREW, BHC 1/4-20 X 3/8 NYL PATCH ,NP	2	
57#	0122 C	SCREW, SHS 3/8-16 X 1/2"	1	
58#	20817	WHEEL, HAND	1	
59#	30166	ACME ROD, PITCH CONTROL	1	
60#	30197	FLANGE BUSHING, BRONZE, .750 ID X .875 OD	1	
61#	30196	RETAINING RING, CRIMP-ON, 3/4" SHAFT	1	
62#	30167	BLOCK, PITCH CONTROL	1	
63#	30173	BUSHING, FLANGED, BRONZE, .51 ID X .625 OD	1	
64#	30188	CABLE, FRESNO PITCH	1	
65#	30198	CABLE, FRESNO WINCH	1	
66#	30331	WINCH ASSY., FRESNO CONTROL	1	

FRESNO WINCH ASSY.




NOTES:
 1 USE LOCTITE BLUE# 246.

FRESNO WINCH ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1#	30195	HANDLE, REVOLVING PHENOLIC, 1.125" X 3.563"	1	
2#	1138	SNAP RING, EXTERNAL, 1.125" DIA	1	
3#	30483	WASHER, NEEDLE BEARING, 1.125"ID X 1.750"OD X 0.32"	1	
4#	30194	CRANK HANDLE	1	
5#	32445	RING, HVY DUTY RETAINING, 7/8"	1	
6#	0166 A	WASHER, LOCK, 3/8 MED.	1	
7#	1456	NUT, HEX FINISH 3/8-16	1	
8#	30178	SPRING PLUNGER, LONG NOSE, 1/4-20 THREAD	1	
9#	0949	NUT, HEX JAM 1/4-20	1	
10#	30175	HOUSING	1	
11#	30180	PAWL, STEEL	1	
12#	30313	SCREW, SH SHLDR 8-32, 3/16D X 1/4L	1	
13#	30181	FLANGE BUSHING, BRONZE, 1.130 ID X 1.375 OD	1	
14#	30176	NUT	1	
15#	30179	RATCHET, 24 TOOTH	1	
16#	30193	FRICTION DISC	2	
17#	4542	PIN, ROLL 3/16 X 1-3/4"	1	
18#	30185	HUB ASSY.	1	INCLUDESITEMSW/\$
19#\$	32443	SCREW, BHSC, 10- 32 x 3/4"	4	
20#\$	30183	DRUM PLATE	1	
21#\$	30192	SPRING, WINCH LOCK, 0.18 OD X 0.375 L	1	
22#\$	30184	LOCK PAWL	1	
23#\$	30182	DRUM	1	
24#	30177	SHAFT, ACME ROD	1	
25#	30173	BUSHING, FLANGED, BRONZE, .51 ID X .625 OD	1	
26	30331	WINCH ASSY., FRESNO CONTROL	1	INCLUDESITEMSW/#
27	60097	BLUE LOCTITE, #246	AR	
28	32443	SCREW, BHSC, 10- 32 X 3/4"	5	


GUARD RING AND ENGINE MOUNTING ASSY.



GUARD RING AND ENGINE MOUNTING ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	1391	SCREW, HHC 5/16-24 X 1-1/2" ZINC	4	
2	933241	WASHER, FLAT SAE 5/16 GRD 9 YZ	4	
3	13551	WASHER, FLAT 3/8 EXT THICK HIGH STRGTH	4	
4	0205	SCREW, HHC 3/8-16 X 1"	4	
5	30280	GUARD RING, W/BOOM STANCHION	1	
6	10024	NUT, NYLOC 1/4-20	2	
7	21922	CLAMP, 0.625" ID PIPE	2	
8	21894	CLIP, FAST LEAD	1	
9	21986	WASHER, FAST LEAD-STAINLESS	1	
10	30484	ACCESS PANEL	1	
11	21893	SCREW, FAST LEAD	1	
12	26250	SCREW, HHC 1/4-20 X 1-3/4"	2	
13	60097	BLUE LOCTITE, #246	AR	

FRESNO BOOM ASSY.




NOTES:

- 1 TO CABLE WINCH.
- 2 TO STAR WHEEL.
- 3 ORIENTATION ROTATED FOR CLARITY.
- 4 CORRECT SPRING HOOK MOUNTING.

FRESNO BOOM ASSY.


<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	22947	PULL-PIN, SPRING LOADED	1	
2	29155	SHEAVE, 2.00 OD X 0.500 ID	2	
3	19974	PIN, CLEVIS 1/2" X 1.25 EFF	2	
4	6014 B	PIN, COTTER 3/32" D X 1.00"	2	
5	30173	BUSHING, FLANGED, BRONZE, .51" ID X .625" OD	1	
6	30278	BOOM	1	
7	968011	NUT, HEX FINISH 1/2 MED.	1	
8	5054 A	WASHER, LOCK 1/2" MED.	1	
9	21944	ROD END, 1/2-20 M RH W/CUSTOM BALL	1	
10	12402	SCREW, HHC 1/2-13 X 2-1/2"	1	
11	21597	BUMPER, STEM 1.0"D X .5S X .31	1	
12	10133	NUT, NYLOC 3/8-16	2	
13	30272	BOOM, WBT PITCH	1	
14	10136	WASHER, FLAT SAE 3/8	2	
15	1493	SCREW, HHC 3/8-16 X 3-1/4"	1	
16	4370	SCREW, HHC 3/8-16 X 2-1/4"	1	
17	30250	BRACKET, ACCESSORY PLATE	1	
18	30276	ARM, WBT ROLL	1	
19	30332	PLATE, PITCH	1	
20	30251	PIVOT	1	
21	10096-001	RING, SNAP, TRUAC #5100-62	2	
22	30253	DETENT PIN, PITCH AXLE	1	
23	30248	SPRING, BLADE RETURN	1	
24	30243	SPRING, LOWER ASSIST	2	
25	0202	BOLT, HEX HEAD, 5/16-18 X 1"	2	
26	5283	NUT, NYLOC, 5/16-18	2	



BRUSH TO FRESNO KIT 36"

NO.	PART NO.	PART NAME	QTY.	REMARKS
1#	0131 A	SCREW, HHC 1/4-20 X 3/4"	4	
2#	30307	ARM, BRUSH TO FRESNO	2	
3#	3910382	SCREW, SHDLR 3/8D X3/8L, 5/16-1, SCKT HD	4	
4#	0181 B	WASHER, LOCK 1/4 MED	4	
5#	30308	L BRACKET, BRUSH TO FRESNO	2	
6#	0949	NUT, HEX FINISH 1/4-20 PLATED	4	
7#	5283	NUT, NYLOC 5/16-18	4	
8#	30312	PINCH BRACKET LEFT, BRUSH TO FRESNO	1	
9#	10136	WASHER, FLAT SAE 3/8	12	
10#	30378	RETRACTABLE PIN	2	
11#	968011	NUT, HEX FINISH 1/2-13	2	
12#	30305	BLOCK, BRUSH TO FRESNO	2	
13#	30298	FRESNO BRUSH, ORANGE, MEDIUM	1	STANDARD BRUSH
13	30419	FRESNO BRUSH, GREEN, STIFF	1	OPTIONAL BRUSH
13	30418	FRESNO BRUSH, BLACK, SOFT	1	OPTIONAL BRUSH
14	30310	KIT, BRUSH TO FRESNO	1	INCLUDES ITEMS W/#
15	30295	PIN, HITCH, WIRE LOCK	2	
16	32141	PLATE, 5LB WEIGHT	4	
17	38274	SCREW, HHFS 3/8-16 X .75 ZINC	2	
19	30296	FRESNO BLADE, 36"	1	
20	30306	PINCH BRACKET RIGHT, BRUSH TO FRESNO	1	
21	0205	SCREW, HHC 3/8-16 X 1.0	4	
22	30400	WEIGHT KIT, FRESNO BRUSH	1	INCLUDES ITEMS W/\$
23\$	0424	SCREW, HHC 1/4-20 X 1-1/4"	2	
24\$	10024	NUT, NYLOC 1/4-20	2	
25\$	25334	WASHER, FLAT 1/4" USS	2	
26\$	30401	WEIGHT, 0.18 LBS	6	


STABILIZER RING ASSY.



STABILIZER RING ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	6014 C	NUT, HEX FINISH 5/16-24	8	
2	1483	RING, STABILIZER	1	
3	1237	SCREW, SHC 5/16-18 X 7/8," NYL PATCH, NP	4	
4	1723	ROD END, 5/16 DIA X 5/16-24 MALE END RH	4	
5	0300 B	WASHER, FLAT SAE 5/16	4	

GEARBOX ASSY.



GEARBOX ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1%\$	0753	SEAL, OIL	1	
2%	0131 A	SCREW, HHC 1/4-20 X 3/4"	4	
3%	12876	FLANGE, INPUT SHAFT	1	
4%#	20466	BEARING, CUP, TIMKEN #M11910	2	
5%\$	20395	O-RING, 2"	1	
7%#	20465	BEARING, CONE, TIMKEN #LM11949	2	
9%	1851	GEAR, WORM "B" INPUT SHAFT	1	
10%	20407	GEARBOX ASSY. 2" SHAFT	1	
11%	21218	VENT, AIR	1	
12	21046	GASKET/SEAL KIT.....	1	INCLUDES ITEMS W/\$
13	21047	BEARING KIT	1	INCLUDES ITEMS W/#
14%	20476	SCREW, HHC 1/4-28 X 3/8"	2	
15%	21033	SIGHT GLASS, 3/4 M PIPE STEEL	1	
16%	0121 A	FITTING, PLUG 3/8 MP SQ HEAD	1	
17%	1138	RING, SNAP	1	
18%#	20475	BEARING, CUP TIMKEN #M86610	2	
19%#	20474	BEARING, CONE TIMKEN #M86647	2	
20%	1140	GEAR, WORM, COMPOSITE	1	
21%	20470	SHAFT, OUTPUT	1	
22%	1139	KEY, WOODRUFF #810	1	
25%\$	20396	O-RING	1	
26%	12875	COVER, GEARBOX	1	
27%	10235	WASHER, C/S EXT. SHKP	4	
28%	20875	SCREW, FHSC 5/16-18 X 3/4"	4	
29%\$	0254	SEAL, OIL	1	
30	20407	GEARBOX ASSY.	1	INCLUDES ITEMS W/%
31	20111	OIL, MOBIL SYNTHETIC SHC634, 22 OZ. (650 ML)	2	
32	22292	SPACER, 0.5" X 0.402" X .25"L UNTREATED	2	
33	20802	RING, SNAP	2	
34	1150	YOKE ARM	1	
35	20801	PIN, YOKE	1	
36	60091	LOCTITE, BLUE @242	AR	
37	60096	LOCTITE, WHITE #572	AR	

This diagram illustrates the assembly of a generator unit. Key components and their assembly points are indicated by numbered callouts:

- Engine and Mounting:** The engine (37) is mounted to a bracket (32) using a bolt (49) and a washer (54). A LOCTITE application point (2) is shown for the bolt.
- Generator Head Assembly:** The generator head (50) is secured with a nut (45) and a washer (41). The output terminal box (46) is attached with a screw (46) and a washer (46).
- Drive Pulley and Belt:** The drive pulley (36) is mounted on the engine shaft with a bolt (4) and a washer (4). A belt (25) is then wrapped around the pulley.
- Accessories:** A warning label (43) is attached to the side of the generator housing.


Additional callouts (1, 3, 5, 19, 32, 41, 45, 46, 52) likely refer to specific fasteners or components shown in detail elsewhere in the manual.

- 1 USE LOCTITE BLUE# 246.
(FOR CLUTCH AND PULLEY: TO ALL SET SCREWS)
- 2 TORQUE TO 8 FT.-LBS. (10.8 N·m)
- 3 TORQUE TO 17 FT.-LBS. (23 N·m)
- 4 TORQUE TO 14.5 FT.-LBS. (19.6 N·m)
- 5 TORQUE TO 26 FT.-LBS. (35 N·m)
- 6 CORRECT SPRING HOOK MOUNTING.

ENGINE AND CLUTCH ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	0152 3	V-BELT, A28	1	
2	60097	BLUE LOCTITE, #246	AR	
4	0627	KEY, 3/16 X 1-1/4	1	
5	22538-001	SCREW, HEX FLANGE, 1/4-20 X .5"	1	
19	10229	SCREW, HHC 5/16-24 X 1"	4	
25	21140	PULLEY AK54 X 3/4"	1	
32	21984	LIFTNG BALE ASSY.	1	
36	22891	FRICTION DRIVE CLUTCH W/ADJ SHEAVE, 1.0"	1	
37	22623	ENGINE, HONDA, GX270UT2QA2, 9 H.P.	1	
41	23965	SCREW, FHSC, 7/16-20 X 1.00"	1	
43	30119	SCREW, 1/4-20X7/8 IND HEX, DOG PT	3	
44	30344	BELT GUARD	1	
45	30200	BRACKET, CLUTCH, 1" SHAFT	1	
46	30202	ANCHOR, SPRING	1	
49	30236	SPACER, 1" SHAFT	1	
50	30240	END CAP, 1"	1	
52	32448	SCREW, BHC, 5/16-18 X 1/2"	3	
54	933241	WASHER, FLAT SAE 5/16 GRD 9 YZ	4	

SPIDER ASSY.



PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter the serial number or part number to search for parts.

* Find:

* Model:

* Serial:

Search

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information:

Manufacturer:

Model:

Serial:

Part Number:

Part Description:

Quantity:

Unit Price:

Total Price:

Customer Name:

Company Name:

Address:

City:

State:

Zip:

Phone:

Fax:

Email:

Comments:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?


Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar

SPIDER ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1%	0164 B	SCREW, HHC ROUNDED 3/8-16, FULL THREAD	4	
2%	0166 A	LOCK WASHER 3/8" MED	4	
3%	1157 A	BUSHING, TROWEL ARM	4	
4%	1161-1	SPIDER PLATE, 1-1/8" SHAFT 4BLD, SILVER	1	
5%	1162 A	CAP, GREASE ZERK #2 YELLOW	4	
6%	1163-1	LEVER, TROWEL ARM, RIGHT HAND, SILVER	4	
7%	1316	SPRING, LS ARM RETURN	4	
8%	1322	RETAINING SCREW ASSY.	4	
9%	1456	NUT, HEX FINISH 3/8-16	1	
10%	1875	WASHER, INT. SHKP. 3/8"	4	
11%	1876	NUT, HEX JAM 3/8-16 CLASS 2B	4	
12%	2826-1	ARM, TROWEL, SILVER	4	
13%	4164	ROLL PIN 5/16" X 1-3/4"	4	
14%	12097	SCREW, SQHS 3/8-16 X 1-3/4" CONE GRD 8 PLTD	1	
15	1215	SPIDER PLATE ASSY.	1	INCLUDES ITEMS W/%
16	10968	THRUST COLLAR ASSY.	1	INCLUDES ITEMS W/\$
17\$	12208	WEAR RING	1	
18\$	12778	FLANGE BEARING	1	
19\$	10793	THRUST COLLAR	1	INCLUDES ITEMS W/#
20\$#	1471	THRUST COLLAR BUSHING	1	
21\$	1154 A	WEAR PLATE	1	
22@	21906	SCREW, HHCS 5/16-18 X 1-1/2" GRD 5	12	
23	1477	BLUE LOCTITE, #242	AR	
24		BLADE ASSY.	4	CONTACT DISCOUNT-EQUIPMENT
25	23647	KIT, BOLT	1	INCLUDES ITEMS W/@
26@	1434	PLUG, BLADE	4	


BLADES AND PAN ASSY.



BLADES AND PAN ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1		BLADE, COMBO 8" X 14"	4.....	(ALL EXCEPT 30")
2		BLADE, COMBO, 8" X 10-1/2"	4.....	(30" TROWEL ONLY)
3	21906	SCREW, HHFS 5/16 - 18 X 1-1/2 GR5.....	8.....	ALL
5	20646	LATCH PIN FOR FLOAT PANS.....	4.....	CONTACT UNIT SALES DEPT./
			ACC. ITEM
6	1817	TRWL ARM ADJ. FIXTURE 36" TO 46" MODELS ...	1.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
7		FLOAT DISC	1.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
8		FLOAT BLADE	4.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
9		FINISH BLADE	4.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
10		COMBO FLOAT & FINISH BLADE	4.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
11		ENDURO UNIVERSAL FINISH BLADE	4.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
12		ENDURO UNIVERSAL COMBO BLADE.....	4.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
13		REVERSIBLE COMBO BLADE	4.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
14		UNIVERSAL MOUNTING BAR.....	4.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
15	QS1869	SNAP PIN FOR QC BLADES.....	8.....	CONTACT UNIT SALES DEPT./
				ACC. ITEM
16	1434	PLUG, BLADE (FINISH BLADE ONLY)	4	
17	0202	SCREW, HHC 5/16-18 X 1" ZINC	4	
18	0201	LUG, GUARD RING	4	


HONDA GX270 — RECOIL STARTER ASSY.



HONDA GX270 — RECOIL STARTER ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	28400Z5K305ZB	STARTER ASSY., RECOIL *NH1*	1.....	INCLUDES ITEMS W/# REPLACES P/N 28400Z5K003ZB
2#	28410ZE2W01ZB	CASE COMP., RECOIL STARTER, NH1, BLK	1	
3#	28421ZE2W01	PULLEY, RECOIL STARTER	1	
4#	28422ZE2W01	RATCHET, STARTER	2	
5#	28441ZE2W01	SPRING, FRICTION	1	
6#	28442ZE2W01	SPRING, STARTER RETURN	1	
7#	28443ZE2W01	SPRING, RATCHET	2	
8#	28444ZE2W01	RETAINER, SPRING	1	
10#	28462ZE2W11	ROPE, RECOIL STARTER	1	
11#	90004ZE2W01	SCREW, CENTER	1	
12	90008ZE2003	BOLT, FLANGE, 6X10	3	
13#	28461Z5T305	GRIP, STARTER	1	
14#	28463Z5T003	GRIP, REINFORCEMENT	1	


HONDA GX270 — FAN COVER ASSY.



HONDA GX270 — FAN COVER ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	16731ZE2003	CLIP, TUBE	1	
2	19610Z5K000ZA	COVER COMP., FAN, NH1, BLACK	1	
3	19631Z5K000	SHROUD	1	
6	90013883000	BOLT, FLANGE, 6X12	6	
10	35120Z5T003	SWITCH ASSY., ENGINE STOP	1	
11	90004Z5T000	SCREW, TAPPING, 3X6	2	

HONDA GX270 — CARBURETOR ASSY.




NOTICE

Gasket Set, item 1 included with items 6, 7, 13, 22, and 27.

HONDA GX270 — CARBURETOR ASSY.

NO.	PART NO.	PART NAME	QTY.	REMARKS
1#	16010ZE2812	GASKET SET	1	
2#	16011ZA0931	VALVE SET, FLOAT	1	
3#	16013Z1C003	FLOAT SET	1	
4#	16015Z5T901	CHAMBER SET, FLOAT	1	
5#	16016ZH7W01	SCREW SET, PILOT	1	
6#	16024Z5T901	SCREW SET, DRAIN	1	
7#	16028Z5T901	SCREW SET	1	
8#	16044ZE2005	CHOKE SET	1	
9	16100Z5KY01	CARBURETOR ASSY. (BE21J A)	1	INCLUDES ITEMS W/#
10#	16124ZE0005	SCREW, THROTTLE STOP	1	
11#	16166Z5KY01	NOZZLE, MAIN	1	
12#	16172ZE3W10	COLLAR, SETTING	1	
13#	16955283000	PACKING, FUEL STRAINER CUP	1	REPLACES P/N 16173001004
14	16211ZE2010	INSULATOR, CARBURETOR	1	
15	16220ZA0702	SPACER COMP., CARBURETOR	1	
16	16221Z5K000	PACKING, CARBURETOR	1	
17	16212Z5K000	PACKING, INSULATOR	1	
18	16610ZE1000	LEVER COMP., CHOKE (STD.)	1	INCLUDES ITEMS W/%
19#	16953ZE1812	LEVER, COCK	1	
20#	16954ZE1812	PLATE, LEVER SETTING	1	
21#	16956ZE1811	SPRING, COCK LEVER	1	
22#	16957ZE1812	PACKING, FUEL COCK	1	
23#	16967ZE0811	CUP, FUEL STRAINER	1	
24#	93500030060H	SCREW, PAN, 3X6	2	REPLACES P/N 93500030061H
25%	9430520122	PIN, SPRING, 2X12	1	
26#	99101ZH80820	JET, MAIN, #82	1	
26#	99101ZH80850	JET, MAIN, #85	1	
26#	99101ZH80880	JET, MAIN, #88	1	
27#	99204ZE20380	JET SET, PILOT, #38	1	
37#	16959Z5T901	FILTER, CUP	1	


HONDA GX270 — AIR CLEANER ASSY.



HONDA GX270 — AIR CLEANER ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	17210ZE2515	ELEMENT, AIR CLEANER (DUAL)	1.....	INCLUDES ITEMS W/# REPLACES P/N 17210ZE2822
2#	17218ZE2505	FILTER, OUTER	1.....	REPLACES P/N 17218ZE2821
3	17231Z5K000	COVER, AIR CLEANER CASE	1	
4#	17232891000	GROMMET, AIR CLEANER	1	
5	17235Z5K000	NOSE, SILENCER	1	
6%	17238ZE2310	COLLAR, AIR CLEANER	2	
7%	17239ZE1000	COLLAR B, AIR CLEANER	1	
8	17410Z5K000	ELBOW COMP., AIR CLEANER	1.....	INCLUDES ITEMS W/%
9	17417Z5T000	PACKING, AIR CLEANER CASE	1	
10	90009Z1C000	BOLTWASHER, 6X22	1	
11	90202Z2E000	NUT, AIR CLEANER COVER	1	
12	90325044000	NUT, TOOL BOX SETTING	1	
14	9405006000	NUT, FLANGE, 6MM	2	


HONDA GX270 — MUFFLER ASSY.



HONDA GX270 — MUFFLER ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	18310Z5K000	MUFFLER COMP.	1	
2	18320Z5K000	PROTECTOR COMP., MUFFLER	1	
3	18323ZE2W00	PROTECTOR, EX. PIPE	1	
5	18331ZE3811	CAP, MUFFLER	1	
6	18331Z5T000	PIPE, EX.	1	
7	18333Z1C801	GASKET, EX. PIPE	1	
9	18350Z5T800	ARRESTER COMP., SPARK	1	
10	18381ZE2W10	GASKET, MUFFLER (ARRESTER)	1	
12	90006ZE2000	SCREW, TAPPING, 6X10	1	
13	90013883000	BOLT, FLANGE, 6X12	1	
14	90050ZE1000	SCREW, TAPPING, 5X8	8	
15	90055ZE1000	SCREW, TAPPING, 4X6	3	
16	9405008000	NUT, FLANGE, 8MM	5	


HONDA GX270 — FUEL TANK ASSY.



HONDA GX270 — FUEL TANK ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	16854ZH8000	RUBBER, SUPPORTER (107MM)	1	
2	16955ZE1010	JOINT, FUEL TANK	1	
5 #	17631Z0T801	PACKING, FUEL FILL. CAP	1	
7	91353671003	O-RING, 14MM	1	REPLACES P/N 91353671004
8	9405008000	NUT, FLANGE, 8MM	2	
9	91424Z5K003	TUBE, FUEL, 4.5X210	1	
11	957010802500	BOLT, FLANGE, 8X25	2	
12	950024080008	CLAMP, TUBE (D8)	2	
21	17620Z4H030	CAP COMP., FUEL FILL. (CHROME PLT.)	1	INCLUDES ITEM W/#
22	17672Z4H000	FILTER, FUEL	1	
27	17510Z5K000ZA	TANK COMP., FUEL, NH1 BLACK	1	


HONDA GX270 — FLYWHEEL ASSY.



HONDA GX270 — FLYWHEEL ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	19511ZE2000	FAN, COOLING	1	
2	28450ZE2W11	PULLEY COMP., STARTER	1	
4	31110Z5K000	FLYWHEEL COMP.	1	
7	90201ZE3V00	NUT, SPECIAL, 16MM	1	
8	90741ZE2000	KEY, SPECIAL WOODRUFF, 25X18	1	

HONDA GX270 — CYLINDER HEAD ASSY.




HONDA GX270 — CYLINDER HEAD ASSY.

NO.	PART NO.	PART NAME	QTY.	REMARKS
1	12210Z5K405	HEAD COMP., CYLINDER	1.....	INCLUDES ITEMS W/#
2#	12204ZE2306	GUIDE, IN. VALVE (O.S.)	1	
3#	12205ZE2305	GUIDE, EX. VALVE (O.S.)	1	
4#	12216ZE2300	CLIP, VALVE GUIDE	1	
5	12251Z5K003	GASKET, CYLINDER HEAD	1	
6	12310ZE2020	COVER COMP., HEAD	1	
7	12391ZE2020	PACKING, HEAD COVER	1	
8	90014Z5T000	BOLT, HEAD COVER	1	
9	90042ZE2000	BOLT, STUD, 8X123	2	
10	90441ZE2010	WASHER COMP., HEAD COVER	1	
11	92900080320E	BOLT, STUD, 8X32	2	
12	9430112200	DOWEL PIN, 12X20	2	
14	957011008000	BOLT, FLANGE, 10X80	4	
15	9807955876	PLUG, SPARK (BPR5ES)	1	
15	9807956846	PLUG, SPARK (BPR6ES)	1.....	REPLACES P/N 9807956876
17	12357Z5T020	TUBE, BREATHER	1	

This diagram illustrates the assembly of a rear window wiper motor. The components are labeled with numbers: 4 (a small rectangular component), 10 (two screws), 12 (a small connector), 18 (the main motor housing), and 19 (a cable with a multi-pronged connector). The diagram shows the motor housing (18) with the cable (19) and connector (12) attached. The screws (10) are shown being inserted into the motor housing. The small component (4) is shown being attached to the cable. The multi-pronged connector (19) is shown being inserted into the motor housing.

HONDA GX270 — IGNITION COIL ASSY.


<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
2	30700Z1C811	CAP ASSY., NOISE SUPPRESSOR	1	
4	31512ZE2000	GROMMET, CORD	1	
10	90015883000	BOLT, FLANGE, 6X28	2	
12	90684ZA0601	CLIP, HARNESS	1	
18	30500Z5K003	COIL ASSY., IGNITION	1	
19	32110Z5K000	HARNESS ASSY., ENGINE WIRE	1	



HONDA GX270 — CONTROL ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	16551ZE2000	ARM, GOVERNOR	1	
2	16555ZE2000	ROD, GOVERNOR	1	
3	16561ZE2000	SPRING, GOVERNOR (L=145.0MM)	1	
4	16562ZE2000	SPRING, THROTTLE RETURN	1	
6	16500Z5K307	CONTROL ASSY. (REMOTE)	1	INCLUDES ITEMS W/#
8#	16571ZE2W00	LEVER, CONTROL	1	
9#	16574ZE1000	SPRING, LEVER	1	
10#	16575ZE2W00	WASHER, CONTROL LEVER	1	
11#	16576891000	HOLDER, CABLE	1	
12#	16578ZE1000	SPACER, CONTROL LEVER	1	
13#	16580Z5K000	BASE COMP., CONTROL	1	
14#	16584883300	SPRING, CONTROL ADJUSTING	1	
15#	16592883310	SPRING, CABLE RETURN	1	
17	90013883000	BOLT, FLANGE, 6X12	2	
18	90015Z5T000	BOLT, GOVERNOR ARM	1	
20#	90114SA0000	NUT, SELFLOCK, 6MM	1	
21#	0202005T125	SCREW, PAN, 5X16	1	REPLACES P/N 93500050160A
22#	93500050280A	SCREW, PAN, 5X28	1	
24	9405006000	NUT, FLANGE, 6MM	1	

HONDA GX270 — CYLINDER BARREL ASSY.



HONDA GX270 — CYLINDER BARREL ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	12000Z5KQ00	BARREL ASSY., CYLINDER	1.....	INCLUDES ITEMS W/#
3	16541ZE2010	SHAFT, GOVERNOR ARM	1	
6	90131896650	BOLT, DRAIN PLUG, 12X15	2.....	REPLACES P/N 90131883000
7	90446KE1000	WASHER, 8.2X17X0.8	1	
8#	91201Z1D003	OIL SEAL, 30X46X8	1	
9	91353671003	ORING, 14MM	1.....	REPLACES P/N 91353671004
10	9405010000	NUT, FLANGE, 10MM	1	
11	031112230	WASHER, DRAIN PLUG, 12MM	2.....	REPLACES P/N 9410912000
12	9425110000	PIN, LOCK, 10MM	1	
13	957010601200	BOLT, FLANGE, 6X12	2	
14#	961006202000	BEARING, RADIAL BALL, 6202	1	
16	35480ZF6003	SWITCH ASSY., OIL LEVEL	1	

This technical diagram illustrates the exploded view of a mechanical assembly, likely a pump or motor component. The parts are numbered as follows:


- 1**: A large, irregularly shaped metal housing or base plate.
- 2**: A central shaft or rotor assembly, shown in an exploded view from the housing.
- 3**: A small bolt or screw.
- 4**: A small bolt or screw.
- 5**: A small washer or spacer.
- 6**: A small bolt or screw.
- 7**: A small bolt or screw.
- 8**: A small bolt or screw.
- 9**: A small bolt or screw.
- 10**: A small bolt or screw.
- 11**: A small bolt or screw.
- 12**: A small bolt or screw.
- 13**: A small bolt or screw.
- 14**: A small bolt or screw.
- 15**: A small bolt or screw.
- 16**: A small bolt or screw.
- 17**: A small bolt or screw.

The diagram shows the housing (1) with various mounting points and internal features. The central shaft (2) is shown with its internal components (6, 7, 8, 9, 10, 11, 12) and external mounting points (3, 4, 5, 13, 14, 15, 16, 17). The exploded view indicates the assembly sequence and the relative positions of the parts.

HONDA GX270 — CRANKCASE COVER ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	11381Z5K000	PACKING, CASE COVER	1	
2	11400Z1D600	COVER ASSY., CRANKCASE	1	INCLUDES ITEMS W/#
3	15600Z0T820	CAP ASSY., OIL FILLER	1	INCLUDES ITEMS W/%
4	15600Z1C000	CAP ASSY., OIL FILLER	1	INCLUDES ITEMS W/\$
5%\$	15625Z0T800	PACKING, OIL FILLER CAP	2	
6#	16510ZE2811	GOVERNOR ASSY.	1	INCLUDES ITEMS W/@
7#@	16511ZE2000	WEIGHT, GOVERNOR	2	
8#@	16512ZE2811	HOLDER, GOVERNOR WEIGHT	1	
9#@	16513ZE2000	PIN, GOVERNOR WEIGHT	2	
10#	16531Z0A000	SLIDER, GOVERNOR	1	
11#	90602ZE1000	CLIP, GOVERNOR HOLDER	1	
12	90701HC4000	DOWEL PIN, 8X12	2	
13#	91201Z1D003	OIL SEAL, 30X46X8	1	
14#	58176	WASHER, FLAT 6MM	1	REPLACES P/N 9410106800
15	957010803500	BOLT, FLANGE, 8X35	7	
16#	961006202000	BEARING, RADIAL BALL, 6202	1	
17#	961006206000	BEARING, RADIAL BALL, 6206	1	

HONDA GX270 — CRANKSHAFT ASSY.




HONDA GX270 — CRANKSHAFT ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
2	13310ZH9811	CRANKSHAFT COMP.	1.....	INCLUDES ITEM W/#
6	13351ZE2010	WEIGHT, BALANCER	1	
7	90745ZE2600	KEY, 6.3X6.3X43	1	
8#	91001ZH9003	BEARING, RADIAL BALL	1	

Go to Discount-Equipment.com to order your parts


HONDA GX270 — PISTON ASSY.



HONDA GX270 — PISTON ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	13010Z5K004	RING SET, PISTON (STD.)	1	
1	13011Z5K004	RING SET, PISTON (0.25)	1	
1	13012Z5K004	RING SET, PISTON (0.50)	1	
1	13013Z5K004	RING SET, PISTON (0.75)	1	
2	13101Z5K000	PISTON (STD.)	1	
2	13102Z5K000	PISTON (0.25)	1	
2	13103Z5K000	PISTON (0.50)	1	
2	13104Z5K000	PISTON (0.75)	1	
3	13111Z5K000	PIN, PISTON	1	
4	13200Z1D000	ROD ASSY., CONNECTING (STD.)	1	INCLUDES ITEMS W/#
4	13200Z1D305	ROD ASSY., CONNEC. (0.25 UNDER SIZE)	1	INCLUDES ITEMS W/#
5#	90001ZE8000	BOLT, CONNECTING ROD	2	
6	90551ZE1000	CLIP, PISTON PIN, 18MM	2	


HONDA GX270 — CAMSHAFT ASSY.



HONDA GX270 — CAMSHAFT ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	12209ZE8003	SEAL, VALVE STEM	1	
2	14100Z5K810	CAMSHAFT ASSY.....	1.....	INCLUDES ITEMS W/# S/N 1043291 AND BELOW
3	14410Z1D000	ROD, PUSH	2	
4	14431ZE2010	ARM, VALVE ROCKER	2	
5	14441ZE2000	LIFTER, VALVE	2	
6	14451ZE1013	PIVOT, ROCKER ARM	2	
7#	14568ZE1000	SPRING, WEIGHT RETURN	1.....	S/N 1043291 AND BELOW
8	14711Z5K000	VALVE, IN.	1	
9	14721Z5K000	VALVE, EX.	1	
10	14751Z1C000	SPRING, VALVE	2	
11	14771Z8S000	RETAINER, IN. VALVE SPRING	1	
12	14771Z8S000	RETAINER, IN. VALVE SPRING	1	
13	14775ZE2010	SEAT, VALVE SPRING	1	
15	14791Z1D000	GUIDE, PUSH ROD	1	
16	90012ZE0010	BOLT, PIVOT, 8MM	2	
17	90206ZE1000	NUT, PIVOT ADJUSTING	2	
19#	14100Z5K910	CAMSHAFT COMP.....	1.....	S/N 1043292 AND ABOVE

HONDA GX270 — LABEL ASSY.



HONDA GX270— LABEL ASSY.

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	87521Z5K000	EMBLEM (GX270)	1	
2	87532ZH7000	MARK, THROTTLE INDICATION	1	
3	87528Z5T000	MARK, CHOKE	1	
4	87519Z4H000	MARK, OPERATOR CAUTION	1	
5	87539Z0J000	MARK, EX, CAUTION	1	
6	87516Z4H010	MARK, OPERATOR CAUTION	1	
7	87539Z0J800	MARK, EX. CAUTION	1	

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter part number or description to find parts manual or lookup part numbers

* Part #

* Model

Serial

Part Number

Comments

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information:

Manufacturer:

Model:

Description:

Part Number:

Quantity:

Unit Price:

Total Price:

Customer Name:

Company Name:

Address:

City:

State:

Zip:

Phone:

Fax:

Email:

Comments:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar