



An Oshkosh Corporation Company



www.Discount-Equipment.com

Service and Maintenance Manual

**Model
1850SJ**

PVC 2001

31215067

March 3, 2020 - Rev B


Go to Discount-Equipment.com to order your parts

ANSI

CE



AS/NZS



PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

A screenshot of the "Search Manuals" form. The form has a title "Search Manuals" and a subtitle "Please provide information to help us locate the manual and/or parts you need." It includes fields for "Brand", "Model Number", "Serial Number", "Part Number", "Part Name", "Part Description", "Part Location", "Part Quantity", and "Part Unit of Measure". There is a "Search" button at the bottom.

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

A screenshot of the "Parts Order Form". The form has a title "Parts Order Form" and a subtitle "Please fill in the information below." It includes fields for "Manufacturer", "Model", "Description", "Part Number", "Part Name", "Part Description", "Part Location", "Part Quantity", and "Part Unit of Measure". There is a "Submit" button at the bottom.

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION A. INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS

A GENERAL

This section contains the general safety precautions which must be observed during maintenance of the mobile elevating work platform. It is of utmost importance that maintenance personnel pay strict attention to these warnings and precautions to avoid possible injury to themselves or others, or damage to the equipment. A maintenance program must be followed to ensure that the machine is safe to operate.

⚠ WARNING

MODIFICATION OR ALTERATION OF A MOBILE ELEVATING WORK PLATFORM SHALL BE MADE ONLY WITH WRITTEN PERMISSION FROM THE MANUFACTURER.

The specific precautions to be observed during maintenance are inserted at the appropriate point in the manual. These precautions are, for the most part, those that apply when servicing hydraulic and larger machine component parts.

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

⚠ WARNING

SINCE THE MACHINE MANUFACTURER HAS NO DIRECT CONTROL OVER THE FIELD INSPECTION AND MAINTENANCE, SAFETY IN THIS AREA RESPONSIBILITY OF THE OWNER/OPERATOR.

B HYDRAULIC SYSTEM SAFETY

It should be noted that the machines hydraulic systems operate at extremely high potentially dangerous pressures. Every effort should be made to relieve any system pressure prior to disconnecting or removing any portion of the system.

Do not use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks. Wear gloves to help protect hands from spraying fluid.



C MAINTENANCE

⚠ WARNING

FAILURE TO COMPLY WITH SAFETY PRECAUTIONS LISTED IN THIS SECTION COULD RESULT IN MACHINE DAMAGE, PERSONNEL INJURY OR DEATH AND IS A SAFETY VIOLATION.

- USE ONLY REPLACEMENT PARTS OR COMPONENTS THAT ARE APPROVED BY JLG. TO BE CONSIDERED APPROVED, REPLACEMENT PARTS OR COMPONENTS MUST BE IDENTICAL OR EQUIVALENT TO ORIGINAL PARTS OR COMPONENTS.
- NO SMOKING IS MANDATORY. NEVER REFUEL DURING ELECTRICAL STORMS. ENSURE THAT FUEL CAP IS CLOSED AND SECURE AT ALL OTHER TIMES.
- REMOVE ALL RINGS, WATCHES AND JEWELRY WHEN PERFORMING ANY MAINTENANCE.
- DO NOT WEAR LONG HAIR UNRESTRAINED, OR LOOSE-FITTING CLOTHING AND NECKTIES WHICH ARE APT TO BECOME CAUGHT ON OR ENTANGLED IN EQUIPMENT.
- OBSERVE AND OBEY ALL WARNINGS AND CAUTIONS ON MACHINE AND IN SERVICE MANUAL.
- KEEP OIL, GREASE, WATER, ETC. WIPED FROM STANDING SURFACES AND HAND HOLDS.
- USE CAUTION WHEN CHECKING A HOT, PRESSURIZED COOLANT SYSTEM.
- NEVER WORK UNDER AN ELEVATED BOOM UNTIL BOOM HAS BEEN SAFELY RESTRAINED FROM ANY MOVEMENT BY BLOCKING OR OVERHEAD SLING, OR BOOM SAFETY PROP HAS BEEN ENGAGED.
- BEFORE MAKING ADJUSTMENTS, LUBRICATING OR PERFORMING ANY OTHER MAINTENANCE, SHUT OFF ALL POWER CONTROLS.
- BATTERY SHOULD ALWAYS BE DISCONNECTED DURING REPLACEMENT OF ELECTRICAL COMPONENTS.
- KEEP ALL SUPPORT EQUIPMENT AND ATTACHMENTS STOWED IN THEIR PROPER PLACE.
- USE ONLY APPROVED, NONFLAMMABLE CLEANING SOLVENTS.

REVISION LOG

Original Issue	A - December 10, 2019
Revised	B - March 3, 2020

Go to Discount-Equipment.com to order your parts

SECTION NO.	TITLE	PAGE NO.
SECTION A	- INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS	
A	General	A-1
B	Hydraulic System Safety	A-1
C	Maintenance	A-1
SECTION 1	- SPECIFICATIONS	
1.1	Operating Specifications	1-1
	Machine Specification	1-1
1.2	Dimensional Data	1-1
	Machine Dimensional Data	1-1
1.3	Capacities	1-2
1.4	Tires	1-2
1.5	Engine Data Section 5.5, Oil Sampling Procedure	1-2
1.6	Major Component Weights	1-2
1.7	Hydraulic Oil	1-2
1.8	Maintenance and Lubrication	1-5
1.9	ThreadLocking Compound	1-10
1.10	Torque Charts	1-11
	SAE Fastener Torque Chart	1-11
	SAE Fastener Torque Chart (Continued)	1-12
	SAE Fastener Torque Chart (Continued)	1-13
	SAE Fastener Torque Chart (Continued)	1-14
	SAE Fastener Torque Chart (Continued)	1-15
	SAE Fastener Torque Chart (Continued)	1-16
	Metric Fastener Torque Chart	1-17
	Metric Fastener Torque Chart (Continued)	1-18
	Metric Fastener Torque Chart (Continued)	1-19
	Metric Fastener Torque Chart (Continued)	1-20
SECTION 2	- GENERAL	
2.1	Machine Preparation, Inspection, and Maintenance	2-1
	General	2-1
	Preparation, Inspection, and Maintenance	2-1
	Pre-Start Inspection	2-1
	Pre-Delivery Inspection and Frequent Inspection	2-1
	Annual Machine Inspection	2-1
	Preventive Maintenance	2-1
2.2	Service and Guidelines	2-2
	General	2-2
	Safety and Workmanship	2-2
	Cleanliness	2-2
	Components Removal and Installation	2-2
	Component Disassembly and Reassembly	2-3
	Pressure-Fit Parts	2-3
	Bearings	2-3
	Gaskets	2-3
	Bolt Usage and Torque Application	2-3
	Hydraulic Lines and Electrical Wiring	2-3
	Hydraulic System	2-3
	Lubrication	2-4
	Battery	2-4
	Lubrication and Servicing	2-4
2.3	Lubrication and Information	2-4
	Hydraulic System	2-4
	Hydraulic Oil	2-4
	Changing Hydraulic Oil	2-4
	Lubrication Specifications	2-4

TABLE OF CONTENTS

SECTION NO.	TITLE	PAGE NO.
2.4	Cylinder Drift	2-5
	Theory	2-5
	Cylinder Leakage Test	2-5
	Cylinder Thermal Drift	2-5
2.5	Pins and Composite Bearing Repair Guidelines	2-6
2.6	Welding on JLG Equipment	2-6
	Do the Following When Welding on JLG Equipment	2-6
	DO NOT Do the Following When Welding on JLG Equipment	2-6
SECTION 3 - CHASSIS & TURNTABLE		
3.1	Tires and Wheels	3-1
	Tire Damage	3-1
	Tire Replacement	3-1
	Wheel Replacement	3-1
	Wheel Installation	3-1
3.2	Axle Extension System	3-2
3.3	Drive Orientation System	3-2
3.4	Steering Control System	3-3
3.5	Drive/Steering Speed Control	3-4
3.6	Traction Control System	3-4
3.7	Ground Control Keyswitch System	3-4
3.8	Jib Lift End of Stroke Dampening	3-4
3.9	Hydraulic System Warm Up	3-4
3.10	Function Speed Control System	3-4
3.11	Drive Assembly	3-12
3.12	Drive Hub	3-13
	Disassembly	3-14
	Assembly	3-17
3.13	Free Wheeling Option	3-21
	Disengage Drive Motors & Brakes for Towing, etc. (Free Wheel)	3-21
	Engage Drive Motors & Brakes (Normal Operation)	3-21
3.14	Gear Hub Oil Service	3-21
	Check Oil Level	3-21
	Change Gear Hub Oil	3-21
3.15	Drive Motor	3-23
	Description	3-23
	Shaft Seal Replacement	3-23
	Loop Flushing Valve	3-24
	Troubleshooting	3-25
	Initial Start-up	3-26
3.16	SWING DRIVE HUB	3-27
	Removal	3-27
	Assembly/Disassembly	3-27
	Installation	3-27
3.17	Swing Drive	3-28
3.18	Swing Brake	3-32
3.19	Setting Swing Gear Backlash	3-33
	Turntable Bearing Mounting Bolt Condition Check	3-34
3.20	Swing Bearing Torque Values	3-35
3.21	Swing Bearing Wear Tolerance	3-36
3.22	Rotary Coupling	3-42
	Assembly/Disassembly	3-42
3.23	Swing Control System	3-43
3.24	Chassis Tilt Indicator System	3-43
3.25	Auxiliary Power System	3-43
3.26	Water in Fuel Sensing System (Optional)	3-44
3.27	Deutz Turbocharger Operation	3-44
	Operating Practices	3-44

SECTION NO.	TITLE	PAGE NO.
3.28	Diesel Exhaust Fluid (DEF) Tank	3-45
	Cleaning and Flushing the Tank	3-45
3.29	Generator	3-48
	Every 250 hours	3-48
	Every 500 hours	3-48
	Overload Protection	3-48
	Inspecting Brushes, Replacing Brushes, and Cleaning Slip Rings	3-49
	Troubleshooting	3-50
	Generator Disassembly and Assembly	3-51
	Lead Connection List for Generator	3-58
3.30	Generator Pulley	3-59
	Removal	3-59
	Installation	3-59
3.31	Deutz Engine with Diesel Exhaust Fluid (DEF)	3-67
	Engine Oil	3-67
	Diesel Fuel	3-67
3.32	Selective Catalytic Reduction (SCR) - Machines Using Diesel Exhaust Fluid (DEF)	3-68
	Standstill Cleaning	3-68
	Maintenance Standstill Cleaning Initiation Methods	3-69
	Cancelling Maintenance Standstill	3-69
	Unsuccessful Cleaning Event	3-69
 SECTION 4 - BOOM & PLATFORM		
4.1	Boom Systems	4-1
	Broken Cable Indicator System	4-1
	Transport Position Sensing System	4-1
	Beyond Transport - Drive Speed Cutback System	4-1
	Drive/Steer - Boom Function Interlock System (CE ONLY)	4-1
	Jib Stow System	4-1
	Envelope Control System	4-2
	Moment Control System	4-2
	Boom Control System (BCS) Functional Check (Push to Test) System	4-2
	Controlled Arc System	4-2
	Controlled Boom Angle System	4-3
	Envelope Tracking	4-3
	Slow Down System	4-3
	Dual Capacity System	4-3
	Swing Speed Proportioning	4-3
	Platform Load Sensing System	4-4
	Electronic Platform Leveling	4-4
	Boom Control Select	4-4
	Platform Control Enable System	4-5
	Boom Recovery Mode	4-5
4.2	Platform	4-7
	Platform/Support Removal	4-7
	Platform/Support Installation	4-8
4.3	Rotator	4-10
	Removal	4-10
	Installation	4-10
4.4	Boom Removal and Installation	4-12
	Removal	4-12
	Installation	4-14
4.5	Boom Assembly	4-15
	Assembly	4-15
4.6	Telescope Cylinder	4-41
	Removal	4-41
4.7	Boom Shimming Procedure	4-42
4.8	Boom Lubrication Application	4-43

TABLE OF CONTENTS

SECTION NO.	TITLE	PAGE NO.
4.9	Boom Cleanliness Guidelines	4-43
4.10	Hose Adjustment Procedure	4-44
4.11	Jib	4-56
	Removal	4-56
	Installation	4-57
4.12	JIB Shimming Procedures	4-57
	Jib Straight Shimming Procedure	4-57
	Stowed Jib Shimming Procedure	4-62
4.13	Wire Rope	4-63
	Inspection	4-63
	Three Month Inspection	4-64
	Additional Inspection Required If:	4-64
	12 Year or 7000 Hour Replacement	4-64
	Additional Replacement Criteria	4-64
4.14	Wire Rope Tensioning Adjustment	4-64
	Boom Preparation for Section Repositioning	4-64
	Wire Rope Tensioning Procedure	4-71
	Confirm Proper Boom Deployment Function	4-73
	Re-Assembly	4-73
	Boom Calibration	4-73
4.15	Broken Boom Cable Proximity Switch	4-74
	Adjusting the Proximity Switch	4-74
4.16	Powertrack Maintenance	4-88
	One Piece Bracket Maintenance	4-88
	Two Piece Bracket Maintenance	4-90
	Snap Rings and Screws	4-91
4.17	SkyGuard®	4-93
	Operation	4-93
	Function Test	4-93
	Diagnostics & Troubleshooting	4-94
4.18	Bolt-on External Fall Arrest	4-95
	Inspection Before Use	4-95
	Installation	4-96
SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS		
5.1	Lubricating O-Rings in the Hydraulic System	5-1
	Cup and Brush	5-1
	Dip Method	5-2
	Spray Method	5-2
	Brush-on Method	5-2
5.2	Hydraulic Connection Assembly and Torque Specification	5-3
	Tapered Thread Types	5-3
	Straight Thread Types, Tube and Hose Connections	5-3
	Straight Thread Types, Port Connections	5-4
	Flange Connection Types	5-4
	Tightening Methods	5-4
	Assembly And Torque Specifications	5-5
	Assembly Instructions for American Standard Pipe Thread Tapered (NPTF) Connections	5-6
	Assembly Instructions for British Standard Pipe Thread Tapered (BSPT) Connections	5-7
	Assembly Instructions for 37° (JIC) Flare Fittings	5-8
	Assembly Instructions for 45° SAE Flare Fittings	5-12
	Assembly Instructions for O-Ring Face Seal (ORFS) Fittings	5-14
	Assembly Instructions for DIN 24° Flare Bite Type Fittings (MBTL and MBTS)	5-16
	Assembly Instructions for Bulkhead (BH) Fittings	5-18
	Assembly Instructions for O-Ring Boss (ORB) Fittings	5-22
	Assembly Instructions for Adjustable Port End Metric (MFF) Fittings	5-30
	Assembly Instructions for Metric ISO 6149 (MPP) Port Assembly Stud Ends	5-38
	Assembly instructions for Adjustable Port End (BSPP) Fittings	5-42

SECTION NO.	TITLE	PAGE NO.
	Assembly Instructions for Flange Connections: (FL61 and FL62)	5-50
	Double Wrench Method	5-53
	FFWR and TFFT Methods	5-54
	Adjustable Stud End Assembly	5-54
	O-ring Installation (Replacement)	5-55
5.3	Hydraulic Cylinders	5-65
	Axle Extend Cylinder	5-65
	Jib Level (Slave) Cylinder	5-70
	Platform Level Cylinder	5-76
	Boom Lift Cylinder	5-82
	Jib Lift Cylinder	5-87
	Jib Lock Cylinder	5-93
	Steer Cylinder	5-96
	Jib Telescope Cylinder	5-100
	Boom Telescope Cylinder	5-105
5.4	Cylinder Length Sensor	5-110
	Removal	5-110
	Installation	5-112
5.5	Oil Sampling Procedure	5-113
	Procedure	5-113
5.6	Pressure setting Procedure	5-118
	1. Setup of the Function Pump	5-118
	2. Adjustments Made at the Main Valve Bank	5-120
	3. Adjustments Made at the Frame Valve Bank	5-125
	4. Adjustments Made at the Platform Valve Bank	5-126
	5. Adjustments Made at Jib Valve	5-127
	6. Adjustments Made in Traction Circuit	5-133
5.7	Drive Pumps	5-134
	Port Locations and Gauge Installation	5-134
	Initial Startup Procedures	5-137
	Troubleshooting	5-137
	Adjustments	5-141
	Removing The Pump	5-145
	Inspection	5-145
	Replacement	5-145
	Electric Control Module	5-146
	Shaft, Seal, and Bearing	5-147
	Charge Pump	5-148
	Charge Check / HPRV	5-150
	Charge Pressure Relief Valve	5-151
	Control Cutoff Valve	5-152
5.8	Function Pump	5-155
	Disassembly	5-155
	Inspection	5-157
	Assembly	5-160
5.9	Gear pump	5-164
	Disassembly	5-164
	Assembly	5-167
	Trouble Shooting	5-174
5.10	Drive & Function Pump Start Up Procedures	5-175
	Start-Up Procedure	5-175
5.11	Hydraulic Schematic	5-178

SECTION NO.	TITLE	PAGE NO.
SECTION 6 - JLG CONTROL SYSTEM		
6.1	JLG Control System Analyzer Kit Instructions	6-1
	Introduction	6-1
	To Connect the JLG Control System Analyzer	6-2
	Using the Analyzer	6-2
	Changing the Access Level of the Hand Held Analyzer	6-3
	Adjusting Parameters Using the Hand Held Analyzer	6-4
	Machine Setup	6-5
	Level Vehicle Description	6-5
	Ground Control Console Display Gauge - Machines using Diesel Exhaust Fluid (DEF)	6-6
6.2	Machine Personality Settings and Function Speeds	6-18
6.3	Machine Orientation When Setting Function Speeds	6-22
	Test Notes	6-22
6.4	CANbus Communications	6-23
6.5	Calibration Instructions	6-26
6.6	Control System Boom Sensors	6-51
	Sensor #1 - Load Pin (1)	6-51
	Sensor #2 - Main Boom Angle Sensors (2)	6-51
	Sensor #3 - Main Boom Length Sensor (1)	6-51
	Sensor #4 - Main Boom Cylinder Angle Sensor (1)	6-54
	Sensor #5 - Main Boom Transport Length Switch (1)	6-54
	Sensor #6 - Jib Level Angle Sensor (1)	6-56
	Sensor #7 - Jib Lock Pin Proximity Sensor (1)	6-56
	Sensor #8 - Jib Stow Angle Sensor (1)	6-58
	Sensor #9 - Jib Lift Angle Sensor (1)	6-58
	Sensor #10 - Dual Capacity / Jib Transport Length Switches (2)	6-59
	Sensor #11 - Platform Level Angle Sensor (1)	6-59
	Sensor #12 - Platform Level Angle Gravity Sensors (2)	6-60
	Sensor #13 - Turntable Swing Angle (1)	6-60
	Sensor #14 - Steer Angle Sensor (4)	6-60
	Sensor #15 - Axle extend/retract Sensor (4)	6-60
	Sensor #16 - Brake-Two Speed Pressure Sensor (1)	6-60
	Sensor #17 - Chassis Tilt Sensor (Externally mounted) (1)	6-60
	Sensor #18 - Tilt Sensor (1)	6-60
	Sensor #19 - Warm up Switch (1)	6-60
	Sensor #20 - Main Valve Pressure Transducer (1)	6-60
	Sensor #21 - Main Lift Cylinder Pressure Transducer (1)	6-61
6.7	System Test	6-61
	Test from the Platform	6-61
	Test from the Ground Station	6-65
6.8	Calibration Procedures	6-70
	Axle Calibration	6-70
	Boom Sensor Calibration	6-70
6.9	Jib Sensor Calibrations	6-73
	Calibrating the Jib Level Up and Down Valve Crackpoints	6-82
6.10	Boom Unlock Procedure	6-84
	Initial Conditions	6-84
	Procedure	6-84
6.11	Setting Crackpoints	6-88
	Platform Level Up and Down Crackpoints	6-88
	Jib Level Up and Down Crackpoints	6-91
	Main Lift Up and Down Crackpoints	6-94
	Main Telescope Out and In Crackpoints	6-99

SECTION NO.	TITLE	PAGE NO.
6.12	LSS System	6-103
	Diagnostic Menu	6-108
	Calibration Procedure	6-109
	Testing & Evaluation	6-114
	Troubleshooting	6-115
6.13	Resetting The MSSO System	6-116
6.14	Electronic Platform Leveling	6-118
	Platform Leveling Fault Warning	6-118
	Fault Response	6-118
 SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS		
7.1	General	7-1
7.2	Multimeter Basics	7-1
	Grounding	7-1
	Backprobing	7-1
	Min/Max	7-1
	Polarity	7-1
	Scale	7-1
	Voltage Measurement	7-1
	Resistance Measurement	7-2
	Continuity Measurement	7-2
	Current Measurement	7-3
7.3	Applying Silicone Dielectric Compound to Electrical Connections	7-3
	Installation of Dielectric Grease	7-4
	AMP Mate-N-Lok	7-4
	AMP Faston	7-4
	AMP Micro-Fit	7-4
	AMP Mini Fit Jr	7-4
	Mini Fit Sr	7-5
	DIN Connectors	7-5
	Exceptions	7-5
	Enclosures	7-5
	Carling Switch Connectors	7-5
7.4	AMP Connector	7-6
	Assembly	7-6
	Disassembly	7-8
	Wedge Lock	7-8
	Service - Voltage Reading	7-8
7.5	Deutsch Connectors	7-10
	DT/DTP Series Assembly	7-10
	DT/DTP Series Disassembly	7-10
	HD30/HDP20 Series Assembly	7-11
	HD30/HDP20 Series Disassembly	7-11
7.6	Telematics Gateway	7-12
	Telematics-Ready (TCU) Plug	7-12
7.7	Wiring Harness Connector Labels	7-16
	Connector Labels	7-16
	Component Labels	7-16
7.8	Electrical Schematic	7-133

FIGURE NO.	TITLE	PAGE NO.
1-1.	Maintenance and Lubrication Diagram	1-4
2-1.	Engine Operating Temperature Specifications - Deutz	2-10
2-2.	Hydraulic Oil Operating Temperature Specifications	2-11
3-1.	Crab Steer	3-3
3-2.	Coordinated Steer	3-3
3-3.	Conventional Two Wheel Steer	3-3
3-4.	Axle Hose Routing - Sheet 1 of 2	3-6
3-5.	Axle Hose Routing - Sheet 2 of 2	3-7
3-6.	Steering/Axle Hydraulic Circuit	3-8
3-7.	Drive System Hydraulic Circuit - Sheet 1 of 2	3-9
3-8.	Drive System Hydraulic Circuit - Sheet 2 of 2	3-10
3-9.	Turntable Hydraulic System	3-11
3-10.	Drive Hub	3-13
3-11.	Disengaging Drive Hubs	3-21
3-12.	Gear Hub Oil Fill and Drain	3-21
3-13.	Drive Motor	3-22
3-14.	Drive Motor Cross Section	3-23
3-15.	Removing Shaft Seal	3-23
3-16.	Loop Flushing Spool	3-24
3-17.	Swing Drive Installation	3-27
3-18.	Swing Motor - Sheet 1 of 2	3-30
3-19.	Swing Motor - Sheet 2 of 2	3-31
3-20.	Swing Bolt Feeler Gauge Check	3-34
3-21.	Swing Bearing Torquing Sequence	3-35
3-22.	Swing Bearing Wear Tolerance	3-37
3-23.	Swing Bearing Removal - Sheet 1 of 4	3-38
3-24.	Swing Bearing Removal - Sheet 2 of 4	3-39
3-25.	Swing Bearing Removal - Sheet 3 of 4	3-40
3-26.	Swing Bearing Removal - Sheet 4 of 4	3-41
3-27.	Rotary Coupling Installation	3-42
3-28.	Diesel Exhaust Fluid (DEF) Tank - Sheet 1 of 2	3-46
3-29.	Diesel Exhaust Fluid (DEF) Tank - Sheet 2 of 2	3-47
3-30.	Generator Belt Tension	3-48
3-31.	Generator Brushes and Slip Rings	3-48
3-32.	Generator Cleaning	3-48
3-33.	Generator Circuit Breaker Location (If Equipped with 4000W)	3-48
3-34.	Generator Circuit Breaker Location (If Equipped with 7500W)	3-48
3-35.	Inspecting Generator Brushes, Replacing Brushes, and Cleaning Slip Rings	3-49
3-36.	Generator Disassembly and Assembly	3-51
3-37.	Generator Troubleshooting Circuit Diagram (Sheet 1 of 2)	3-52
3-38.	Generator Troubleshooting Circuit Diagram (Sheet 2 of 2)	3-53
3-39.	Generator Electrical Circuit Diagram	3-54
3-40.	Power Board PC1 Electrical Circuit Diagram	3-55
3-41.	Power Board PC2 Electrical Circuit Diagram (Sheet 1 of 2)	3-56
3-42.	Power Board PC2 Electrical Circuit Diagram (Sheet 2 of 2)	3-57
3-43.	Generator Pulley	3-59
3-44.	Engine Installation and Diesel Exhaust Fluid (DEF) System (T4F & Stage IV) - Sheet 1 of 6	3-60
3-45.	Engine Installation and Diesel Exhaust Fluid (DEF) System (T4F & Stage IV) - Sheet 2 of 6	3-61
3-46.	Engine Installation and Diesel Exhaust Fluid (DEF) System (T4F & Stage IV) - Sheet 3 of 6	3-62
3-47.	Engine Installation and Diesel Exhaust Fluid (DEF) System (T4F & Stage IV) - Sheet 4 of 6	3-63
3-48.	Engine Installation and Diesel Exhaust Fluid (DEF) System (T4F & Stage IV) - Sheet 5 of 6	3-64
3-49.	Engine Installation and Diesel Exhaust Fluid (DEF) System (T4F & Stage IV) - Sheet 6 of 6	3-65
3-50.	Engine Electrical Circuit	3-66
3-51.	Mixing Petroleum With Summer Diesel Fuel	3-67
4-1.	Location of Components	4-7
4-2.	Platform Support Torque Values	4-9
4-3.	Rotator Removal/Installation	4-11

FIGURE NO.	TITLE	PAGE NO.
4-4.	Boom Hydraulic System	4-13
4-5.	Boom Assembly - Sheet 1 of 9	4-17
4-6.	Boom Assembly - Sheet 2 of 9	4-18
4-7.	Boom Assembly - Sheet 3 of 9	4-19
4-8.	Boom Assembly - Sheet 4 of 9	4-20
4-9.	Boom Assembly - Sheet 5 of 9	4-21
4-10.	Boom Assembly - Sheet 6 of 9	4-22
4-11.	Boom Assembly - Sheet 7 of 9	4-23
4-12.	Boom Assembly - Sheet 8 of 9	4-24
4-13.	Boom Assembly - Sheet 9 of 9	4-25
4-14.	Locations for Threadlocker Application - Sheet 1 of 5	4-26
4-15.	Locations for Threadlocker Application - Sheet 2 of 5	4-27
4-16.	Locations for Threadlocker Application - Sheet 3 of 5	4-28
4-17.	Locations for Threadlocker Application - Sheet 4 of 5	4-29
4-18.	Locations for Threadlocker Application - Sheet 5 of 5	4-30
4-19.	Boom Assembly Torque Values - Sheet 1 of 4	4-31
4-20.	Boom Assembly Torque Values - Sheet 2 of 4	4-32
4-21.	Boom Assembly Torque Values - Sheet 3 of 4	4-33
4-22.	Boom Assembly Torque Values - Sheet 4 of 4	4-34
4-23.	Hose Adjustment	4-45
4-24.	Section 3 Boom Cables	4-46
4-25.	Section 4 Boom Cables	4-47
4-26.	Section 5 Boom Cables	4-48
4-27.	Jib Hydraulics - Sheet 1 of 7	4-49
4-28.	Jib Hydraulics - Sheet 2 of 7	4-50
4-29.	Jib Hydraulics - Sheet 3 of 7	4-51
4-30.	Jib Hydraulics - Sheet 4 of 7	4-52
4-31.	Jib Hydraulics - Sheet 5 of 7	4-53
4-32.	Jib Hydraulics - Sheet 6 of 7	4-54
4-33.	Jib Hydraulics - Sheet 7 of 7	4-55
4-34.	Jib Assembly - Sheet 1 of 4	4-58
4-35.	Jib Assembly - Sheet 2 of 4	4-59
4-36.	Jib Assembly - Sheet 3 of 4	4-60
4-37.	Jib Assembly - Sheet 4 of 4	4-61
4-38.	Jib Stow Shimming Measurements	4-62
4-39.	Wire Rope Wire Breaks	4-63
4-40.	Wire Rope Kink	4-63
4-41.	Sheave Groove Wear	4-63
4-42.	Fully Retracted Boom Section Positions	4-65
4-43.	Initial Exposed Thread Length for Wire Rope Adjustment	4-66
4-44.	Boom Wire Rope Torques	4-73
4-45.	Broken Cable Proximity Switch Location	4-74
4-46.	Powertrack Installation - Sheet 1 of 4	4-75
4-47.	Powertrack Installation - Sheet 2 of 4	4-76
4-48.	Powertrack Installation - Sheet 3 of 4	4-77
4-49.	Powertrack Installation - Sheet 4 of 4	4-78
4-50.	Powertrack Shimming Instructions	4-79
4-51.	Powertrack Locations for Threadlocker Application and Torque - Sheet 1 of 4	4-80
4-52.	Powertrack Locations for Threadlocker Application and Torque - Sheet 2 of 4	4-81
4-53.	Powertrack Locations for Threadlocker Application and Torque - Sheet 3 of 4	4-82
4-54.	Powertrack Locations for Threadlocker Application and Torque - Sheet 4 of 4	4-83
4-55.	Powertrack Hose Installation - Sheet 1 of 4	4-84
4-56.	Powertrack Hose Installation - Sheet 2 of 4	4-85
4-57.	Powertrack Hose Installation - Sheet 3 of 4	4-86
4-58.	Powertrack Hose Installation - Sheet 4 of 4	4-87
4-59.	Bolt-On External Fall Arrest Cable Tension	4-95
4-60.	Bolt-On External Fall Arrest System	4-97

FIGURE NO.	TITLE	PAGE NO.
5-1.	NPTF Thread	5-3
5-2.	BSPT Thread.....	5-3
5-3.	JIC Thread.....	5-3
5-4.	SAE Thread.....	5-3
5-5.	ORFS Thread	5-3
5-6.	MTBL-MBTS Thread.....	5-3
5-7.	Bulkhead Thread	5-3
5-8.	ORB-MPP Thread	5-4
5-9.	MFF-BSPP Thread.....	5-4
5-10.	ORB-MPP Thread	5-4
5-11.	Torque Wrench Angle	5-5
5-12.	Double Wrench Method	5-53
5-13.	FFWR Method	5-54
5-14.	Adjustable Stud End Assembly.....	5-55
5-15.	Turntable Hydraulic System.....	5-56
5-16.	Hydraulic Hose Installation - Sheet 1 of 8	5-57
5-17.	Hydraulic Hose Installation - Sheet 2 of 8	5-58
5-18.	Hydraulic Hose Installation - Sheet 3 of 8	5-59
5-19.	Hydraulic Hose Installation - Sheet 4 of 8	5-60
5-20.	Hydraulic Hose Installation - Sheet 5 of 8	5-61
5-21.	Hydraulic Hose Installation - Sheet 6 of 8	5-62
5-22.	Hydraulic Hose Installation - Sheet 7 of 8	5-63
5-23.	Hydraulic Hose Installation - Sheet 8 of 8	5-64
5-24.	Cylinder Barrel Support.....	5-65
5-25.	Capcrew Removal	5-65
5-26.	Cylinder Rod Support.....	5-65
5-27.	Axle Extend Cylinder Assembly	5-66
5-28.	Tapered Bushing Removal	5-67
5-29.	Bushing Installation	5-68
5-30.	Cylinder Head Seal Installation.....	5-68
5-31.	Piston Seal Kit Installation.....	5-68
5-32.	Tapered Bushing Installation.....	5-69
5-33.	Seating the Tapered Bearing.....	5-69
5-34.	Rod Assembly Installation	5-69
5-35.	Cylinder Barrel Support.....	5-70
5-36.	Cylinder Head Removal	5-70
5-37.	Cylinder Rod Support.....	5-70
5-38.	Jib Level (Slave) Cylinder Assembly	5-71
5-39.	Piston Removal.....	5-72
5-40.	Piston Seal Disassembly	5-72
5-41.	Cylinder Head Disassembly	5-72
5-42.	Bushing Installation	5-73
5-43.	Wiper Seal Installation	5-74
5-44.	Cylinder Head Assembly.....	5-74
5-45.	Piston Seal Installation.....	5-75
5-46.	Cylinder Head Tightening.....	5-75
5-47.	Caulking	5-75
5-48.	Rod Assembly Installation	5-75
5-49.	Cylinder Barrel Support.....	5-76
5-50.	Cylinder Length Sensor Removal.....	5-76
5-51.	Cylinder Head Installation	5-76
5-52.	Platform Level Cylinder Assembly	5-77
5-53.	Cylinder Rod Support.....	5-78
5-54.	Tapered Bushing Removal	5-78
5-55.	Piston Disassembly	5-78
5-56.	Cylinder Head Disassembly	5-78
5-57.	Composite Bushing Installation	5-79

FIGURE NO.	TITLE	PAGE NO.
5-58.	Cylinder Head Seal Kit Installation	5-79
5-59.	Piston Seal Kit Installation	5-80
5-60.	Tapered Bushing Installation	5-80
5-61.	Seating the Tapered Bearing	5-80
5-62.	Rod and Cylinder Head Installation	5-81
5-63.	Cylinder Head Tightening	5-81
5-64.	Cylinder Barrel Support	5-82
5-65.	Capcrew Removal	5-82
5-66.	Cylinder Rod Support	5-82
5-67.	Boom Lift Cylinder Assembly	5-83
5-68.	Piston Removal	5-84
5-69.	Piston Disassembly	5-84
5-70.	Cylinder Head Disassembly	5-84
5-71.	Bushing Installation	5-85
5-72.	Cylinder Head Assembly	5-85
5-73.	Piston Assembly	5-86
5-74.	Piston Removal	5-86
5-75.	Rod Assembly Installation	5-86
5-76.	Cylinder Barrel Support	5-87
5-77.	Cylinder Length Sensor Removal	5-87
5-78.	Capcrew Removal	5-87
5-79.	Jib Lift Cylinder Assembly	5-88
5-80.	Cylinder Rod Support	5-89
5-81.	Tapered Bushing Removal	5-89
5-82.	Piston Disassembly	5-89
5-83.	Cylinder Head Disassembly	5-89
5-84.	Composite Bushing Installation	5-90
5-85.	Cylinder Head Seal Kit Installation	5-91
5-86.	Piston Seal Kit Installation	5-91
5-87.	Tapered Bushing Installation	5-91
5-88.	Seating the Tapered Bearing	5-92
5-89.	Rod Assembly Installation	5-92
5-90.	Cylinder Head Removal	5-93
5-91.	Jib Lock Cylinder Assembly	5-94
5-92.	Cylinder Head Installation	5-95
5-93.	Cylinder Head Removal	5-96
5-94.	Cylinder Rod Support	5-96
5-95.	Steer Cylinder Assembly	5-97
5-96.	Piston and Cylinder Head Disassembly	5-98
5-97.	Cylinder Head and Piston Assembly	5-99
5-98.	Cylinder Head Installation	5-99
5-99.	Cylinder Head and Wear Pads	5-100
5-100.	Cylinder Rod Support	5-100
5-101.	Jib Telescope Cylinder Assembly	5-101
5-102.	Piston and Spacer Disassembly	5-102
5-103.	Cylinder Head Disassembly	5-102
5-104.	Cylinder Head Assembly	5-103
5-105.	Piston and Spacer Assembly	5-103
5-106.	Rod Assembly Installation	5-104
5-107.	Cylinder Head Torque Sequence	5-104
5-108.	Valve Installation	5-104
5-109.	Cylinder Barrel Support	5-105
5-110.	Port Block And Rod Removal	5-105
5-111.	Cylinder Rod Support	5-105
5-112.	Boom Telescope Cylinder Assembly	5-106
5-113.	Piston Disassembly	5-107
5-114.	Cylinder Head Disassembly	5-107

FIGURE NO.	TITLE	PAGE NO.
5-115.	Cylinder Head Seal Kit Installation.....	5-108
5-116.	Piston Seal Kit Installation.....	5-109
5-117.	Rod Assembly And Valve Installation.....	5-109
5-118.	Cylinder Length Sensor.....	5-110
5-119.	Oil Sampling Valve Location.....	5-113
5-120.	Main Valve Identification - Sheet 1 of 2.....	5-114
5-121.	Main Valve Identification - Sheet 2 of 2.....	5-115
5-122.	Main Valve Torque Values - Sheet 1 of 2.....	5-116
5-123.	Main Valve Torque Values - Sheet 2 of 2.....	5-117
5-124.	Piston Pump Cross Sectional View.....	5-134
5-125.	Port locations - Sheet 1 of 2.....	5-135
5-126.	Port locations - Sheet 2 of 2.....	5-136
5-127.	Charge Pressure Adjustment.....	5-141
5-128.	Control Neutral Adjustment.....	5-142
5-129.	Servo and System Pressure Gauge Port Locations.....	5-144
5-130.	Control Module And Solenoid Removal/installation.....	5-146
5-131.	Shaft Assembly.....	5-147
5-132.	Charge Pump.....	5-149
5-133.	Charge Check / HPRV.....	5-150
5-134.	Charge Check / HPRV.....	5-151
5-135.	Charge Pressure Relief Valve.....	5-152
5-136.	Control Cutoff Valve.....	5-153
5-137.	Fastener and Plug Locations.....	5-154
5-138.	Hydraulic Schematic - Sheet 1 of 8.....	5-178
5-139.	Hydraulic Schematic - Sheet 2 of 8.....	5-179
5-140.	Hydraulic Schematic - Sheet 3 of 8.....	5-180
5-141.	Hydraulic Schematic - Sheet 4 of 8.....	5-181
5-142.	Hydraulic Schematic - Sheet 5 of 8.....	5-182
5-143.	Hydraulic Schematic - Sheet 6 of 8.....	5-183
5-144.	Hydraulic Schematic - Sheet 7 of 8.....	5-184
5-145.	Hydraulic Schematic - Sheet 8 of 8.....	5-185
6-1.	Hand Held Analyzer.....	6-1
6-2.	Splash Screen.....	6-6
6-3.	Diagnostic Screen.....	6-6
6-4.	Engine Diagnostic Screen.....	6-6
6-5.	Ground Control Console Display Gauge.....	6-7
6-6.	Control System CAN Circuit 1 of 2.....	6-24
6-7.	Control System CAN Circuit 2 of 2.....	6-25
6-8.	Analyzer Flow Chart - Sheet 1 of 5 (Software Version P7.32).....	6-27
6-9.	Analyzer Flow Chart - Sheet 2 of 5 (Software Version P7.32).....	6-28
6-10.	Analyzer Flow Chart - Sheet 3 of 5 (Software Version P7.32).....	6-29
6-11.	Analyzer Flow Chart - Sheet 4 of 5 (Software Version P7.32).....	6-30
6-12.	Analyzer Flow Chart - Sheet 5 of 5 (Software Version P7.32).....	6-31
6-13.	Ground Control Module.....	6-32
6-14.	Platform Control Module.....	6-36
6-15.	Chassis Control Module.....	6-40
6-16.	BLAM Control Module.....	6-42
6-17.	Ultra Boom Control Module.....	6-44
6-18.	Jib Control Module.....	6-48
6-19.	Analyzer Connecting Points.....	6-50
6-20.	Main Boom Angle Sensors.....	6-52
6-21.	Main Boom Cylinder Angle (Protractor) Sensor.....	6-54
6-22.	Main Boom Transport Length Switch.....	6-55
6-23.	Jib Lock Pin Proximity Sensor.....	6-56
6-24.	Jib Level Angle Sensor.....	6-57
6-25.	Jib Stow Angle Sensor.....	6-58
6-26.	Jib Transport Length Sensors.....	6-59

FIGURE NO.	TITLE	PAGE NO.
6-27.	Platform Level Sensor	6-60
6-28.	System Test Flow Chart - Platform Tests - Sheet 1 of 2	6-63
6-29.	System Test Flow Chart - Platform Tests - Sheet 2 of 2	6-64
6-30.	System Test Flow Chart - Ground Station Tests	6-66
6-31.	LSS Installation - Sheet 1 of 4	6-104
6-32.	LSS Installation - Sheet 2 of 4	6-105
6-33.	LSS Installation - Sheet 3 of 4	6-106
6-34.	LSS Installation - Sheet 4 of 4	6-107
7-1.	Voltage Measurement (DC)	7-1
7-2.	Resistance Measurement	7-2
7-3.	Continuity Measurement	7-2
7-4.	Current Measurement (DC)	7-3
7-5.	Connector Assembly Figure 1	7-6
7-6.	AMP Connector	7-6
7-7.	Connector Assembly Figure 2	7-7
7-8.	Connector Assembly Figure 3	7-7
7-9.	Connector Assembly Figure 4	7-7
7-10.	Connector Disassembly	7-8
7-11.	Connector Installation	7-9
7-12.	DT/DTP Contact Installation	7-10
7-13.	DT/DTP Contact Removal	7-10
7-14.	HD/HDP Contact Installation	7-11
7-15.	HD/HDP Locking Contacts Into Position	7-11
7-16.	HD/HDP Contact Removal	7-11
7-17.	HD/HDP Unlocking Contacts	7-11
7-18.	Telematics Gateway Harness - Sheet 1 of 3	7-13
7-19.	Telematics Gateway Harness - Sheet 2 of 3	7-14
7-20.	Telematics Gateway Harness - Sheet 3 of 3	7-15
7-21.	Platform Box Wiring Harness - Sheet 1 of 5	7-18
7-22.	Platform Box Wiring Harness - Sheet 2 of 5	7-19
7-23.	Platform Box Wiring Harness - Sheet 3 of 5	7-20
7-24.	Platform Box Wiring Harness - Sheet 4 of 5	7-21
7-25.	Platform Box Wiring Harness - Sheet 5 of 5	7-22
7-26.	Platform Valve Wiring Harness	7-24
7-27.	Jib Valve Wiring Harness	7-28
7-28.	BLAM Module Wiring Harness - Sheet 1 of 2	7-34
7-29.	BLAM Module Wiring Harness - Sheet 2 of 2	7-35
7-30.	Load Sensing Pin Cable	7-36
7-31.	Base Boom Sensor Harness	7-38
7-32.	Beacon/Strobe Harness	7-40
7-33.	Fuel Pump & Water-In-Fuel Harness	7-42
7-34.	Turntable Wiring Harness - Sheet 1 of 7	7-44
7-35.	Turntable Wiring Harness - Sheet 2 of 7	7-45
7-36.	Turntable Wiring Harness - Sheet 3 of 7	7-46
7-37.	Turntable Wiring Harness - Sheet 4 of 7	7-48
7-38.	Turntable Wiring Harness - Sheet 5 of 7	7-49
7-39.	Turntable Wiring Harness - Sheet 6 of 7	7-50
7-40.	Turntable Wiring Harness - Sheet 7 of 7	7-51
7-41.	Ground Console Wiring Harness - Sheet 1 of 3	7-52
7-42.	Ground Console Wiring Harness - Sheet 2 of 3	7-53
7-43.	Ground Console Wiring Harness - Sheet 3 of 3	7-54
7-44.	Chassis Harness	7-56
7-45.	Hydraulic Valve Bank Harness	7-62
7-46.	Drive Pump Harness	7-66
7-47.	T4i Engine Harness	7-68
7-48.	CAN Engine Harness - Sheet 1 of 2	7-74
7-49.	CAN Engine Harness - Sheet 2 of 2	7-76

LIST OF FIGURES

FIGURE NO.	TITLE	PAGE NO.
7-50.	Generator Enable Harness	7-78
7-51.	T4F Engine Harness - Sheet 1 of 14	7-81
7-52.	T4F Engine Harness - Sheet 2 of 14	7-82
7-53.	T4F Engine Harness - Sheet 3 of 14	7-83
7-54.	T4F Engine Harness - Sheet 4 of 14	7-84
7-55.	T4F Engine Harness - Sheet 5 of 14	7-86
7-56.	T4F Engine Harness - Sheet 6 of 14	7-87
7-57.	T4F Engine Harness - Sheet 7 of 14	7-88
7-58.	T4F Engine Harness - Sheet 8 of 14	7-89
7-59.	T4F Engine Harness - Sheet 9 of 14	7-90
7-60.	T4F Engine Harness - Sheet 10 of 14	7-92
7-61.	T4F Engine Harness - Sheet 11 of 14	7-93
7-62.	T4F Engine Harness - Sheet 12 of 14	7-94
7-63.	T4F Engine Harness - Sheet 13 of 14	7-95
7-64.	T4F Engine Harness - Sheet 14 of 14	7-96
7-65.	Urea Tank/Supply Module Harness	7-98
7-66.	Platform Interface Harness	7-100
7-67.	Cribbing Module Harness - Sheet 1 of 2	7-102
7-68.	Cribbing Module Harness - Sheet 2 of 2	7-104
7-69.	Electrical Installation - Sheet 1 of 12	7-106
7-70.	Electrical Installation - Sheet 2 of 12	7-107
7-71.	Electrical Installation - Sheet 3 of 12	7-108
7-72.	Electrical Installation - Sheet 4 of 12	7-109
7-73.	Electrical Installation - Sheet 5 of 12	7-110
7-74.	Electrical Installation - Sheet 6 of 12	7-111
7-75.	Electrical Installation - Sheet 7 of 12	7-112
7-76.	Electrical Installation - Sheet 8 of 12	7-113
7-77.	Electrical Installation - Sheet 9 of 12	7-114
7-78.	Electrical Installation - Sheet 10 of 12	7-115
7-79.	Electrical Installation - Sheet 11 of 12	7-116
7-80.	Electrical Installation - Sheet 12 of 12	7-117
7-81.	Electrical Installation (T4F) - Sheet 1 of 11	7-118
7-82.	Electrical Installation (T4F) - Sheet 2 of 11	7-119
7-83.	Electrical Installation (T4F) - Sheet 3 of 11	7-120
7-84.	Electrical Installation (T4F) - Sheet 4 of 11	7-121
7-85.	Electrical Installation (T4F) - Sheet 5 of 11	7-122
7-86.	Electrical Installation (T4F) - Sheet 6 of 11	7-123
7-87.	Electrical Installation (T4F) - Sheet 7 of 11	7-124
7-88.	Electrical Installation (T4F) - Sheet 8 of 11	7-125
7-89.	Electrical Installation (T4F) - Sheet 9 of 11	7-126
7-90.	Electrical Installation (T4F) - Sheet 10 of 11	7-127
7-91.	Electrical Installation (T4F) - Sheet 11 of 11	7-128
7-92.	Battery Jump-Start Hookup	7-129
7-93.	Battery Installation - Sheet 1 of 2	7-130
7-94.	Battery Installation - Sheet 2 of 2	7-131
7-95.	Electrical Schematic - Sheet 2 of 21	7-134
7-96.	Electrical Schematic - Sheet 3 of 21	7-135
7-97.	Electrical Schematic - Sheet 4 of 21	7-136
7-98.	Electrical Schematic - Sheet 5 of 21	7-137
7-99.	Electrical Schematic - Sheet 6 of 21	7-138
7-100.	Electrical Schematic - Sheet 7 of 21	7-139
7-101.	Electrical Schematic - Sheet 8 of 21	7-140
7-102.	Electrical Schematic - Sheet 9 of 21	7-141
7-103.	Electrical Schematic - Sheet 10 of 21	7-142
7-104.	Electrical Schematic - Sheet 11 of 21	7-143
7-105.	Electrical Schematic - Sheet 12 of 21	7-144
7-106.	Electrical Schematic - Sheet 13 of 21	7-145

FIGURE NO.	TITLE	PAGE NO.
7-107.	Electrical Schematic - Sheet 14 of 21	7-146
7-108.	Electrical Schematic - Sheet 15 of 21	7-147
7-109.	Electrical Schematic - Sheet 16 of 21	7-148
7-110.	Electrical Schematic - Sheet 17 of 21	7-149
7-111.	Electrical Schematic - Sheet 18 of 21	7-150
7-112.	Electrical Schematic - Sheet 19 of 21	7-151
7-113.	Electrical Schematic - Sheet 20 of 21	7-152
7-114.	Electrical Schematic - Sheet 21 of 21	7-153

Go to Discount-Equipment.com to order your parts

TABLE NO.	TITLE	PAGE NO.
1-1	Engine Data - Deutz TD 3.6L	1-2
1-2	Critical Stability Weights	1-2
1-3	Mobil DTE 10 Excel 32 Specs	1-3
1-4	Mobil EAL H 46 Specs	1-3
1-5	Mobilfluid 424 Specs	1-3
1-6	Exxon Univis HVI 26 Specs	1-3
1-7	Quintolubric 888-46	1-3
1-8	UCon Hydrolube HP-5046	1-3
1-9	Lubrication Specifications	1-5
2-1	Inspection and Maintenance	2-2
2-2	Cylinder Drift	2-5
2-3	Inspection and Preventive Maintenance Schedule	2-7
3-1	Wheel Torque Chart	3-1
3-2	Excessive Noise and/or Vibration	3-25
3-3	System Operating Hot	3-25
3-4	Won't Shift or Slow to Start	3-25
3-5	Connector TYCO HDSCS 4POL	3-47
3-6	Troubleshooting	3-50
3-7	Lead Connection List for Generator	3-58
3-8	Maintenance Standstill Cleaning	3-70
3-9	Cleaning When Crystallization is Detected During SCR	3-70
3-10	Engine Fault Codes (Deutz Engine)	3-71
4-1	SkyGuard Function Table	4-94
5-1	NPTF Pipe Thread	5-6
5-2	BSPT Pipe Thread	5-7
5-3	37° Flare (JIC)Thread - Steel	5-9
5-4	37° Flare (JIC)Thread - Aluminum/Brass	5-10
5-5	45° Flare (SAE) - Steel	5-13
5-6	45° Flare (SAE) - Aluminum/Brass	5-13
5-7	O-ring Face Seal (ORFS) - Steel	5-14
5-8	O-ring Face Seal (ORFS) - Aluminum/Brass	5-15
5-9	DIN 24° Cone (MBTL & MBTS)	5-17
5-10	Bulkhead Fittings (BH) - INCH	5-19
5-11	Bulkhead Fittings (BH) - METRIC	5-20
5-12	O-ring Boss (ORB) - Table 1 of 6	5-23
5-13	O-ring Boss (ORB) - Table 2 of 6	5-24
5-14	O-ring Boss (ORB) - Table 3 of 6	5-25
5-15	O-ring Boss (ORB) - Table 4 of 6	5-26
5-16	O-ring Boss (ORB) - Table 5 of 6	5-27
5-17	O-ring Boss (ORB) - Table 6 of 6	5-28
5-18	Metric Flat Face Port (MFF) - L Series - Table 1 of 3	5-31
5-19	Metric Flat Face Port (MFF) - L Series - Table 2 of 3	5-32
5-20	Metric Flat Face Port (MFF) - L Series - Table 3 of 3	5-33
5-21	Metric Flat Face Port (MFF) - S Series - Table 1 of 3	5-34
5-22	Metric Flat Face Port (MFF) - S Series - Table 2 of 3	5-35
5-23	Metric Flat Face Port (MFF) - S Series - Table 3 of 3	5-36
5-24	Metric Pipe Parallel O-Ring Boss (MPP)	5-39
5-25	British Standard Parallel Pipe Port (BSPP) - L Series - Table 1 of 3	5-43
5-26	British Standard Parallel Pipe Port (BSPP) - L Series - Table 2 of 3	5-44
5-27	British Standard Parallel Pipe Port (BSPP) - L Series - Table 3 of 3	5-45
5-28	British Standard Parallel Pipe Port (BSPP) - S Series - Table 1 of 3	5-46
5-29	British Standard Parallel Pipe Port (BSPP) - S Series - Table 2 of 3	5-47
5-30	British Standard Parallel Pipe Port (BSPP) - S Series - Table 3 of 3	5-48
5-31	Flange Code (FL61 & FL62) - Inch Fasteners	5-51
5-32	Flange Code (FL61 & FL62) - Metric Fasteners	5-52
5-33	Port information	5-134
5-34	Electrical Troubleshooting	5-138

TABLE NO.	TITLE	PAGE NO.
5-35	Neutral Difficult or Impossible to find	5-138
5-36	System Operating Hot	5-138
5-37	System Will Not Operate	5-139
5-38	System Noise or Vibration	5-139
5-39	Sluggish system response	5-140
5-40	Displacement Limiter Adjustment Data	5-142
5-41	Fastener Size and Torque Chart	5-153
5-42	Plug Size and Torque Chart	5-153
5-43	Troubleshooting	5-174
6-1	Analyzer Abbreviations	6-8
6-2	Machine Configuration Programming Information (Software Version P7.32)	6-10
6-3	Machine Configuration Programming Settings (Software Version P7.32)	6-16
6-4	Machine Personality Settings and Function Speeds (Software Version P7.32)	6-18
6-5	Calibration Instructions	6-26
6-6	System Test Messages	6-67
6-7	Diagnostic Menu Descriptions	6-108
6-8	Accessory Weights	6-110
6-9	SkyGlazier Capacity Reductions	6-112
6-10	Pipe Rack Capacity Reductions	6-112
6-11	LSS Troubleshooting Chart	6-115
6-12	Diagnostic Fault Code Chart	6-120
6-13	Diagnostic Trouble Code Chart	6-139
7-1	Wiring Harness Connector Labels	7-16

SECTION 1. SPECIFICATIONS

1.1 OPERATING SPECIFICATIONS

Machine Specification

Capacity - ANSI Unrestricted Restricted	500 lb (227 kg) 1000 lb (454 kg)
Capacity - CE, GB & Australia Unrestricted Restricted	500 lb (230 kg) 1000 lb (450 kg)
Maximum Operating Slope	5°
Maximum Travel Grade, stowed Position (Gradeability)	40%
Maximum Travel Grade, stowed Position (Side Slope)	5°
Drive Speed	2.8 mph (4.5 km/h)
Drive Speed at Elevation	0.3 mph (0.48 km/h)
Gross Machine Weight - Approximate	59,900 lb (27170 kg)
Ground Bearing Pressure - Maximum	119.6 psi (8.41 kg/cm ²)
Maximum Wind Speed	28 mph (12.5 m/s)
Maximum Manual Force	90 lb (400N)
Maximum System Voltage	12 volts
Maximum Main Relief Hyd. Pressure	5000 psi (345 Bar)

1.2 DIMENSIONAL DATA

Machine Dimensional Data

Turning Radius (Axles Retracted) Outside Inside	31 ft. 2.75 in. (9.52 m) 23 ft. 4.25 in. (7.12 m)
Turning Radius (Axles Extended) Inside Outside	7 ft. 6.75 in. (2.3 m) 21 ft. 7.75 in. (6.6 m)
Machine Height (stowed)	10 ft. 0.5 in. (3.06 m)
Machine Length (stowed)	47 ft. 9.5 in. (14.57 m)
Machine Length (Transport Position)	63'9.5" (19.44 m)
Platform Height (500 lb./230 kg. capacity)	185 ft. 7 in. (56.56 m)
Platform Height (1000 lb./450 kg. capacity)	165 ft. 2 in. (50.34 m)
Horizontal Reach from centerline of rotation Unrestricted Capacity Restricted Capacity	80 ft. 0 in. (24.38 m) 68 ft. 11 in. (21.01 m)
Horizontal Reach over end Unrestricted Capacity Restricted Capacity	70 ft. 6 in. (21.59 m) 59 ft. 6 in. (18.13 m)
Horizontal Reach over side Unrestricted Capacity Restricted Capacity	71 ft. 9 in. (21.86 m) 60 ft. 8 in. (18.49 m)
Overall Width Axles Retracted Axles Extended	8 ft. 2 in. (2.48 m) 16 ft. 6.5 in. (5.04 m)
Wheelbase Axles Retracted Axles Extended	17 ft. 1.5 in. (5.22 m) 15 ft. 0.5 in. (4.59 m)
Tailswing	7 ft. 7.5 in. (2.32 m)
Ground Clearance (Axle)	9.75 in. (0.25 m)
Ground Clearance (Chassis)	1 ft. 4.25 in. (0.41 m)

1.3 CAPACITIES

Hydraulic Oil Tank	75.1 Gal. (284.2L)
Fuel Tank	52.8 Gal. (200L)
Drive Hub	2.6 quarts (2.5 liters)
Swing Gearbox	3 qt. (2.8L)

1.4 TIRES

Size	445/50D710
Load Range	N
Ply Rating	24
Foam Fill	Polyurethane HD (55 Durometer) Foam
Diameter	46.45 in. (117.9 cm)
Width	16.81 in. (427 mm)
Rim Size	15x28
Tire & Wheel Weight	1025 lb (465 kg)
Max Tire Load	36000 lb (16,329 kg)

1.5 ENGINE DATA SECTION 5.5, OIL SAMPLING

Table 1-1. Engine Data - Deutz TD 3.6L

Type	Turbo-charged Diesel
Number of Cylinders	4
Bore	3.9 in. (98 mm)
Stroke	4.7 in. (120 mm)
Total Displacement	221 cu.in. (3.6L)
Firing Order	1-3-4-2
Output	99.8 hp (74.4 kW)
Low Idle Engine RPM	1000 ±50
High Engine RPM	2300 ±50
Average Fuel Consumption	2.73 gph (10.3 lph)
Acceptable Fuel Grades	Ultra Low Sulfur (15 ppm) Up to 5% BioDiesel

PROCEDURE

1.6 MAJOR COMPONENT WEIGHTS

⚠ WARNING

DO NOT REPLACE ITEMS CRITICAL TO STABILITY WITH ITEMS OF DIFFERENT WEIGHT OR SPECIFICATION (FOR EXAMPLE: BATTERIES, FILLED TIRES, PLATFORM) DO NOT MODIFY UNIT IN ANY WAY TO AFFECT STABILITY.

Table 1-2. Critical Stability Weights

Components	LB	KG
Tire & Wheel	1025	465
Drive Hub & Motor	337	153
Swing Drive	223	101.2
Engine Assembly	822	373
Complete Boom (including jib & platform)	23,600	10705
Main Boom Assembly	21,600	9798
Jib Assembly	1493	677

1.7 HYDRAULIC OIL

Hydraulic System Operating Temperature Range	S.A.E. Viscosity Grade
+0° to +180° F (-18° to +83° C)	10W
+0° to +210° F (-18° to +99° C)	10W-20, 10W30
+50° to +210° F (+10° to +99° C)	20W-20

NOTE: Hydraulic oils require anti-wear qualities at least API Service Classification GL-3, and sufficient chemical stability for mobile hydraulic system service.

NOTE: Aside from JLG recommendations, it is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities.

OIL SAMPLING

This machine is equipped with an oil sampling valve to allow for verification of hydraulic oil condition. Refer to Section 5.5, Oil Sampling Procedure.

Table 1-3. Mobil DTE 10 Excel 32 Specs

ISO Viscosity Grade	#32
Specific Gravity	0.877
Pour Point, Max.	-40°F (-40°C)
Flash Point, Min.	330°F (166°C)
Viscosity	
at 40°C	33 cSt
at 100°C	6.6 cSt
at 100°F	169 SUS
at 210°F	48 SUS
cPat-30°F	6,200
Viscosity Index	140

Table 1-4. Mobil EAL H 46 Specs

Type	Synthetic Biodegradable
ISO Viscosity Grade	46
Specific Gravity	0.910
Pour Point	-44°F (-42°C)
Flash Point	500°F (260°C)
Operating Temp.	0 to 180°F (-17 to 162°C)
Weight	7.64 lb. per gal. (0.9 kg per liter)
Viscosity	
at 40°C	45 cSt
at 100°C	8.0 cSt
Viscosity Index	153

Table 1-5. Mobilfluid 424 Specs

SAE Grade	10W30
Gravity, API	29.0
Density, Lb/Gal. 60°F	7.35
Pour Point, Max	-46°F (-43°C)
Flash Point, Min.	442°F (228°C)
Viscosity	
Brookfield, cPat -18°C	2700
at 40°C	55 cSt
at 100°C	9.3 cSt
Viscosity Index	152

Table 1-6. Exxon Univil HVI 26 Specs

Specific Gravity	32.1
Pour Point	-76°F (-60°C)
Flash Point	217°F (103°C)
Viscosity	
at 40°C	25.8 cSt
at 100°C	9.3 cSt
Viscosity Index	376
NOTE: Mobil/Exxon recommends that this oil be checked on a yearly basis for viscosity.	

Table 1-7. Quintolubric 888-46

Density	0.92 g/cm ³
Pour Point	<-30°C (<-22°F)
Flash Point	300°C (572°F)
Fire Point	360°C (680°F)
Autoignition Temperature	>450°C (842°F)
Viscosity	
at 0°C (32°F)	320 cSt
at 20°C (68°F)	109 cSt
at 40°C (104°F)	47.5 cSt
at 100°C (212°F)	9.5 cSt
Viscosity Index	190

Table 1-8. UCon Hydrolube HP-5046

Type	Synthetic Biodegradable
Specific Gravity	1.082
Pour Point, Max	-58°F (-50°C)
pH	9.1
Viscosity	
at 0°C (32°F)	340 cSt (1600SUS)
at 40°C (104°F)	46 cSt (215SUS)
at 65°C (150°F)	22 cSt (106SUS)
Viscosity Index	170




Figure 1-1. Maintenance and Lubrication Diagram

1.8 MAINTENANCE AND LUBRICATION

NOTE: The following numbers correspond to those in Figure 1-1., Maintenance and Lubrication Diagram.


Table 1-9. Lubrication Specifications

KEY	SPECIFICATIONS
MPG	Multipurpose Grease having a minimum dripping point of 350°F (177°C). Excellent water resistance and adhesive qualities, and being of extreme pressure type. (Timken OK 40 pounds minimum.)
EPGL	Extreme Pressure Gear Lube (oil) meeting API service classification GL-5 or MIL-Spec MIL-L-2105
HO	Hydraulic Oil. API service classification GL-3, e.g. Mobilfluid 424
EO	Engine (crankcase) API CJ-4
Super Lube®	Synthetic-Based Oil, Non-Flammable. Withstands temperatures within -45° to 450°F (-43° to 232°C). JLG PN 3020042.

NOTICE


LUBRICATION INTERVALS ARE BASED ON MACHINE OPERATION UNDER NORMAL CONDITIONS. FOR MACHINES USED IN MULTI-SHIFT OPERATIONS AND/OR EXPOSED TO HOSTILE ENVIRONMENTS OR CONDITIONS, LUBRICATION FREQUENCIES MUST BE INCREASED ACCORDINGLY.

1. Swing Bearing - Remote Lube




Lube Point(s) - 3 Grease Fitting
 Capacity - A/R
 Lube - MPG
 Interval - Every 3 months or 150 hours of operation
 Comments - Apply grease and rotate in 45 degree intervals until bearing is completely lubricated.

2. Swing Gearbox



Lube Point(s) - Fill Plug
 Capacity - 3 qt. (2.8 L)
 Lube - GL-5
 Interval - Check level every 150 hrs/Change every 1200 hours of operation. Fill to cover ring gear.

3. Wheel Drive Hub



Lube Point(s) - Level/Fill Plug
 Capacity - 2.6 quarts (2.5 liters) ± 10%
 Interval - Check level every 3 months or 150 hrs of operation; change every 2 years or 1200 hours of operation

SECTION 1 - SPECIFICATIONS

4. Hydraulic Return Filter



Lube Point(s) - Replaceable Element
Interval - Change after first 50 hours and every 6 months or 300 hours thereafter.


5. Hydraulic Tank Breather



Interval - Change after first 50 hrs. and every 6 months or 300 hrs. thereafter.


Comments - Remove wing nut and cover to replace. Under certain conditions, it may be necessary to replace on a more frequent basis.

6. Hydraulic Charge Filter



Lube Point(s) - Replaceable Element
Interval - Change after first 50 hours and every 6 months or 300 hours thereafter.

7. High Pressure Filter




Lube Point(s) - Replaceable Element
Interval - Change after first 50 hours and every 6 months or 300 hours thereafter.

8. Hydraulic Oil




Lube Point(s) - Fill Cap
Capacity - 75 Gallons (208 liters) Tank to Full Mark
82 Gallons (310.4 L) System
Lube - HO
Interval - Check level daily. Change every 2 years or 1200 hours of operation.

9. Main Valve Filter



Lube Point(s) - Replaceable Element
Interval - Change after first 50 hours and every 6 months or 300 hours thereafter.

10. Oil Change w/Filter - Deutz



Lube Point(s) - Fill Cap/Spin-on Element
Capacity - 9.6 Quarts (9.1 L)
Lube - EO
Interval - Check level daily; change every 500 hours or yearly, whichever comes first. Adjust final oil level by mark on dipstick.


SECTION 1 - SPECIFICATIONS

11. Fuel Filter - Deutz




Lube Point(s) - Replaceable Element
Interval - Every year or 500 hours of operation

12. Fuel Pre-Filter



Lube Point(s) - Replaceable Element
Interval - Every year or 500 hours of operation

13. Air Filter



Lube Point(s) - Replaceable Element
Interval - Every 6 months or 300 hours of operation or as indicated by the condition indicator
Comments - Check dust valve for dirt daily

14. Boom

Lube Point(s) - Apply to wear pad contact paths
Lube - Super Lube®
Interval - Every year or 600 hours of operation. Refer to the Service Manual for detailed procedures

15. Radiator


Lube Point(s) - Fill Cap
Lube - Anti-Freeze Coolant (Refer to Engine Manual for compatible coolants)
Capacity - 13.2 qt. (12.5 L)

16. Diesel Exhaust Fluid (DEF) (If Equipped)




Lube Point - Fill Cap
Lube - DEF
Capacity - 5.7 gal. (21.5 L)

17. DEF Supply Module Filter (If Equipped)



Interval - 500 hours or 2 years, whichever comes first

18. Optional Fuel Filter/Water Separator



Lube Point(s) - Replaceable Element
Interval - Drain water daily; Change every year or 600 hours of operation

SECTION 1 - SPECIFICATIONS

1.9 THREADLOCKING COMPOUND

JLG PN	Loctite®	ND Industries	Description
0100011	242™	Vibra-TITE™ 121	Medium Strength (Blue)
1001095650	243™	Vibra-TITE™ 122	Medium Strength (Blue)
0100019	271™	Vibra-TITE™ 140	High Strength (Red)
0100071	262™	Vibra-TITE™ 131	Medium - High Strength (Red)

NOTE: Loctite® 243™ can be substituted in place of Loctite® 242™. Vibra-TITE™ 122 can be substituted in place of Vibra-TITE™ 121.

Go to Discount-Equipment.com to order your parts

1.10 TORQUE CHARTS

SAE Fastener Torque Chart

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)												
SAE GRADE 5 BOLTS & GRADE 2 NUTS												
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry)		Torque Lubricated		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140)		Torque (Loctite® 262™ or Vibra-TITE™ 111)	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
4	40	0.1120	0.00604	380	8	0.9	6	0.7				
	48	0.1120	0.00661	420	9	1.0	7	0.8				
6	32	0.1380	0.00909	580	16	1.8	12	1.4				
	40	0.1380	0.01015	610	18	2.0	13	1.5				
8	32	0.1640	0.01400	900	30	3.4	22	2.5				
	36	0.1640	0.01474	940	31	3.5	23	2.6				
10	24	0.1900	0.01750	1120	43	4.8	32	3.5				
	32	0.1900	0.02000	1285	49	5.5	36	4				
1/4	20	0.2500	0.0318	2020	96	10.8	75	9	105	12		
	28	0.2500	0.0364	2320	120	13.5	86	10	135	15		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	3340	17	23	13	18	19	26	16	22
	24	0.3125	0.0580	3700	19	26	14	19	21	29	17	23
3/8	16	0.3750	0.0775	4940	30	41	23	31	35	48	28	38
	24	0.3750	0.0878	5600	35	47	25	34	40	54	32	43
7/16	14	0.4375	0.1063	6800	50	68	35	47	55	75	45	61
	20	0.4375	0.1187	7550	55	75	40	54	60	82	50	68
1/2	13	0.5000	0.1419	9050	75	102	55	75	85	116	68	92
	20	0.5000	0.1599	10700	90	122	65	88	100	136	80	108
9/16	12	0.5625	0.1820	11600	110	149	80	108	120	163	98	133
	18	0.5625	0.2030	12950	120	163	90	122	135	184	109	148
5/8	11	0.6250	0.2260	14400	150	203	110	149	165	224	135	183
	18	0.6250	0.2560	16300	170	230	130	176	190	258	153	207
3/4	10	0.7500	0.3340	21300	260	353	200	271	285	388	240	325
	16	0.7500	0.3730	23800	300	407	220	298	330	449	268	363
7/8	9	0.8750	0.4620	29400	430	583	320	434	475	646	386	523
	14	0.8750	0.5090	32400	470	637	350	475	520	707	425	576
1	8	1.0000	0.6060	38600	640	868	480	651	675	918	579	785
	12	1.0000	0.6630	42200	700	949	530	719	735	1000	633	858
1 1/8	7	1.1250	0.7630	42300	800	1085	600	813	840	1142	714	968
	12	1.1250	0.8560	47500	880	1193	660	895	925	1258	802	1087
1 1/4	7	1.2500	0.9690	53800	1120	1518	840	1139	1175	1598	1009	1368
	12	1.2500	1.0730	59600	1240	1681	920	1247	1300	1768	1118	1516
1 3/8	6	1.3750	1.1550	64100	1460	1979	1100	1491	1525	2074	1322	1792
	12	1.3750	1.3150	73000	1680	2278	1260	1708	1750	2380	1506	2042
1 1/2	6	1.5000	1.4050	78000	1940	2630	1460	1979	2025	2754	1755	2379
	12	1.5000	1.5800	87700	2200	2983	1640	2224	2300	3128	1974	2676

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS

5000059K

2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%

3. * ASSEMBLY USES HARDENED WASHER

SECTION 1 - SPECIFICATIONS

SAE Fastener Torque Chart (Continued)

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)										
SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS*										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry or Loctite® 263) K=0.20		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.18		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB						
4	40	0.1120	0.00604							
	48	0.1120	0.00661							
6	32	0.1380	0.00909							
	40	0.1380	0.01015							
8	32	0.1640	0.01400							
	36	0.1640	0.01474	1320	43	5				
10	24	0.1900	0.01750	1580	60	7				
	32	0.1900	0.02000	1800	68	8				
1/4	20	0.2500	0.0318	2860	143	16	129	15		
	28	0.2500	0.0364	3280	164	19	148	17		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	4720	25	35	20	25	20	25
	24	0.3125	0.0580	5220	25	35	25	35	20	25
3/8	16	0.3750	0.0775	7000	45	60	40	55	35	50
	24	0.3750	0.0878	7900	50	70	45	60	35	50
7/16	14	0.4375	0.1063	9550	70	95	65	90	50	70
	20	0.4375	0.1187	10700	80	110	70	95	60	80
1/2	13	0.5000	0.1419	12750	105	145	95	130	80	110
	20	0.5000	0.1599	14400	120	165	110	150	90	120
9/16	12	0.5625	0.1820	16400	155	210	140	190	115	155
	18	0.5625	0.2030	18250	170	230	155	210	130	175
5/8	11	0.6250	0.2260	20350	210	285	190	260	160	220
	18	0.6250	0.2560	23000	240	325	215	290	180	245
3/4	10	0.7500	0.3340	30100	375	510	340	460	280	380
	16	0.7500	0.3730	33600	420	570	380	515	315	430
7/8	9	0.8750	0.4620	41600	605	825	545	740	455	620
	14	0.8750	0.5090	45800	670	910	600	815	500	680
1	8	1.0000	0.6060	51500	860	1170	770	1045	645	875
	12	1.0000	0.6630	59700	995	1355	895	1215	745	1015
1 1/8	7	1.1250	0.7630	68700	1290	1755	1160	1580	965	1310
	12	1.1250	0.8560	77000	1445	1965	1300	1770	1085	1475
1 1/4	7	1.2500	0.9690	87200	1815	2470	1635	2225	1365	1855
	12	1.2500	1.0730	96600	2015	2740	1810	2460	1510	2055
1 3/8	6	1.3750	1.1550	104000	2385	3245	2145	2915	1785	2430
	12	1.3750	1.3150	118100	2705	3680	2435	3310	2030	2760
1 1/2	6	1.5000	1.4050	126500	3165	4305	2845	3870	2370	3225
	12	1.5000	1.5800	142200	3555	4835	3200	4350	2665	3625

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER

5000059K

SAE Fastener Torque Chart (Continued)

Values for Magni Coating Fasteners (Ref 4150701)										
SAE GRADE 5 BOLTS & GRADE 2 NUTS										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry) K=0.17		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.16		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
4	40	0.1120	0.00604	380	7	0.8				
	48	0.1120	0.00661	420	8	0.9				
6	32	0.1380	0.00909	580	14	1.5				
	40	0.1380	0.01015	610	14	1.6				
8	32	0.1640	0.01400	900	25	2.8				
	36	0.1640	0.01474	940	26	2.9				
10	24	0.1900	0.01750	1120	36	4.1				
	32	0.1900	0.02000	1285	42	4.7				
1/4	20	0.2500	0.0318	2020	86	9.7	80	9		
	28	0.2500	0.0364	2320	99	11.1	95	11		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	3340	15	20	14	19	15	20
	24	0.3125	0.0580	3700	15	20	15	21	15	20
3/8	16	0.3750	0.0775	4940	25	35	25	34	25	34
	24	0.3750	0.0878	5600	30	40	28	38	25	34
7/16	14	0.4375	0.1063	6800	40	55	40	54	35	48
	20	0.4375	0.1187	7550	45	60	44	60	40	54
1/2	13	0.5000	0.1419	9050	65	90	60	82	55	75
	20	0.5000	0.1599	10700	75	100	71	97	65	88
9/16	12	0.5625	0.1820	11600	90	120	87	118	80	109
	18	0.5625	0.2030	12950	105	145	97	132	90	122
5/8	11	0.6250	0.2260	14400	130	175	120	163	115	156
	18	0.6250	0.2560	16300	145	195	136	185	125	170
3/4	10	0.7500	0.3340	21300	225	305	213	290	200	272
	16	0.7500	0.3730	23800	255	345	238	324	225	306
7/8	9	0.8750	0.4620	29400	365	495	343	466	320	435
	14	0.8750	0.5090	32400	400	545	378	514	355	483
1	8	1.0000	0.6060	38600	545	740	515	700	480	653
	12	1.0000	0.6630	42200	600	815	563	765	530	721
1 1/8	7	1.1250	0.7630	42300	675	920	635	863	595	809
	12	1.1250	0.8560	47500	755	1025	713	969	670	911
1 1/4	7	1.2500	0.9690	53800	955	1300	897	1219	840	1142
	12	1.2500	1.0730	59600	1055	1435	993	1351	930	1265
1 3/8	6	1.3750	1.1550	64100	1250	1700	1175	1598	1100	1496
	12	1.3750	1.3150	73000	1420	1930	1338	1820	1255	1707
1 1/2	6	1.5000	1.4050	78000	1660	2260	1560	2122	1465	1992
	12	1.5000	1.5800	87700	1865	2535	1754	2385	1645	2237

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER

5000059K

SECTION 1 - SPECIFICATIONS

SAE Fastener Torque Chart (Continued)

Values for Magni Coating Fasteners (Ref 4150701)										
SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS*										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry or Loctite® 263) K=0.17		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.16		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
4	40	0.1120	0.00604							
	48	0.1120	0.00661							
6	32	0.1380	0.00909							
	40	0.1380	0.01015							
8	32	0.1640	0.01400							
	36	0.1640	0.01474	1320	37	4				
10	24	0.1900	0.01750	1580	51	6				
	32	0.1900	0.02000	1800	58	7				
1/4	20	0.2500	0.0318	2860	122	14	114	13		
	28	0.2500	0.0364	3280	139	16	131	15		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	4720	20	25	20	25	20	25
	24	0.3125	0.0580	5220	25	35	20	25	20	25
3/8	16	0.3750	0.0775	7000	35	50	35	50	35	50
	24	0.3750	0.0878	7900	40	55	40	55	35	50
7/16	14	0.4375	0.1063	9550	60	80	55	75	50	70
	20	0.4375	0.1187	10700	65	90	60	80	60	80
1/2	13	0.5000	0.1419	12750	90	120	85	115	80	110
	20	0.5000	0.1599	14400	100	135	95	130	90	120
9/16	12	0.5625	0.1820	16400	130	175	125	170	115	155
	18	0.5625	0.2030	18250	145	195	135	185	130	175
5/8	11	0.6250	0.2260	20350	180	245	170	230	160	220
	18	0.6250	0.2560	23000	205	280	190	260	180	245
3/4	10	0.7500	0.3340	30100	320	435	300	410	280	380
	16	0.7500	0.3730	33600	355	485	335	455	315	430
7/8	9	0.8750	0.4620	41600	515	700	485	660	455	620
	14	0.8750	0.5090	45800	570	775	535	730	500	680
1	8	1.0000	0.6060	51500	730	995	685	930	645	875
	12	1.0000	0.6630	59700	845	1150	795	1080	745	1015
1 1/8	7	1.1250	0.7630	68700	1095	1490	1030	1400	965	1310
	12	1.1250	0.8560	77000	1225	1665	1155	1570	1085	1475
1 1/4	7	1.2500	0.9690	87200	1545	2100	1455	1980	1365	1855
	12	1.2500	1.0730	96600	1710	2325	1610	2190	1510	2055
1 3/8	6	1.3750	1.1550	104000	2025	2755	1905	2590	1785	2430
	12	1.3750	1.3150	118100	2300	3130	2165	2945	2030	2760
1 1/2	6	1.5000	1.4050	126500	2690	3660	2530	3440	2370	3225
	12	1.5000	1.5800	142200	3020	4105	2845	3870	2665	3625

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER

5000059K

SAE Fastener Torque Chart (Continued)

Values for Magni Coating Fasteners (Ref 4150701)										
SOCKET HEAD CAPSCREWS										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry) K=0.17		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) or Precoat® 85 K=0.16		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
4	40	0.1120	0.00604							
	48	0.1120	0.00661							
6	32	0.1380	0.00909							
	40	0.1380	0.01015							
8	32	0.1640	0.01400							
	36	0.1640	0.01474							
10	24	0.1900	0.01750							
	32	0.1900	0.02000							
1/4	20	0.2500	0.0318	2860	122	14	114	13		
	28	0.2500	0.0364	3280	139	16	131	15		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	4720	20	25	20	25	20	25
	24	0.3125	0.0580	5220	25	35	20	25	20	25
3/8	16	0.3750	0.0775	7000	35	50	35	50	35	50
	24	0.3750	0.0878	7900	40	55	40	55	35	50
7/16	14	0.4375	0.1063	9550	60	80	55	75	50	70
	20	0.4375	0.1187	10700	65	90	60	80	60	80
1/2	13	0.5000	0.1419	12750	90	120	85	115	80	110
	20	0.5000	0.1599	14400	100	135	95	130	90	120
9/16	12	0.5625	0.1820	16400	130	175	125	170	115	155
	18	0.5625	0.2030	18250	145	195	135	185	130	175
5/8	11	0.6250	0.2260	20350	180	245	170	230	160	220
	18	0.6250	0.2560	23000	205	280	190	260	180	245
3/4	10	0.7500	0.3340	30100	320	435	300	415	280	380
	16	0.7500	0.3730	33600	355	485	335	455	315	430
7/8	9	0.8750	0.4620	41600	515	700	485	660	455	620
	14	0.8750	0.5090	45800	570	775	535	730	500	680
1	8	1.0000	0.6060	51500	730	995	685	930	645	875
	12	1.0000	0.6630	59700	845	1150	795	1080	745	1015
1 1/8	7	1.1250	0.7630	68700	1095	1490	1030	1400	965	1310
	12	1.1250	0.8560	77000	1225	1665	1155	1570	1085	1475
1 1/4	7	1.2500	0.9690	87200	1545	2100	1455	1980	1365	1855
	12	1.2500	1.0730	96600	1710	2325	1610	2190	1510	2055
1 3/8	6	1.3750	1.1550	104000	2025	2755	1905	2590	1785	2430
	12	1.3750	1.3150	118100	2300	3130	2165	2945	2030	2760
1 1/2	6	1.5000	1.4050	126500	2690	3660	2530	3440	2370	3225
	12	1.5000	1.5800	142200	3020	4105	2845	3870	2665	3625

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 1 - SPECIFICATIONS

SAE Fastener Torque Chart (Continued)

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)*										
SOCKET HEAD CAPSCREWS										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry) K=0.17		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) or Precoat® 85 K=0.16		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB						
4	40	0.1120	0.00604							
	48	0.1120	0.00661							
6	32	0.1380	0.00909							
	40	0.1380	0.01015							
8	32	0.1640	0.01400							
	36	0.1640	0.01474							
10	24	0.1900	0.01750							
	32	0.1900	0.02000							
1/4	20	0.2500	0.0318	2860	122	14	114	13		
	28	0.2500	0.0364	3280	139	16	131	15		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	4720	20	25	20	25	20	25
	24	0.3125	0.0580	5220	25	35	20	25	20	25
3/8	16	0.3750	0.0775	7000	35	50	35	50	35	50
	24	0.3750	0.0878	7900	40	55	40	55	35	50
7/16	14	0.4375	0.1063	9550	60	80	55	75	50	70
	20	0.4375	0.1187	10700	65	90	60	80	60	80
1/2	13	0.5000	0.1419	12750	90	120	85	115	80	110
	20	0.5000	0.1599	14400	100	135	95	130	90	120
9/16	12	0.5625	0.1820	16400	130	175	125	170	115	155
	18	0.5625	0.2030	18250	145	195	135	185	130	175
5/8	11	0.6250	0.2260	20350	180	245	170	230	160	220
	18	0.6250	0.2560	23000	205	280	190	260	180	245
3/4	10	0.7500	0.3340	30100	320	435	300	415	280	380
	16	0.7500	0.3730	33600	355	485	335	455	315	430
7/8	9	0.8750	0.4620	41600	515	700	485	660	455	620
	14	0.8750	0.5090	45800	570	775	535	730	500	680
1	8	1.0000	0.6060	51500	730	995	685	930	645	875
	12	1.0000	0.6630	59700	845	1150	795	1080	745	1015
1 1/8	7	1.1250	0.7630	68700	1095	1490	1030	1400	965	1310
	12	1.1250	0.8560	77000	1225	1665	1155	1570	1085	1475
1 1/4	7	1.2500	0.9690	87200	1545	2100	1455	1980	1365	1855
	12	1.2500	1.0730	96600	1710	2325	1610	2190	1510	2055
1 3/8	6	1.3750	1.1550	104000	2025	2755	1905	2590	1785	2430
	12	1.3750	1.3150	118100	2300	3130	2165	2945	2030	2760
1 1/2	6	1.5000	1.4050	126500	2690	3660	2530	3440	2370	3225
	12	1.5000	1.5800	142200	3020	4105	2845	3870	2665	3625

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS 5000059K
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

Metric Fastener Torque Chart

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)*							
CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS							
Size	Pitch	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry or Loctite® 263™)	Torque (Lube)	Torque (Loctite® 262™ or 271™ or Vibra-TITE™ 131)	Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 141)
		Sq mm	KN	[N.m]		[N.m]	[N.m]
3	0.5	5.03	2.19	1.3	1.0	1.2	1.4
3.5	0.6	6.78	2.95	2.1	1.6	1.9	2.3
4	0.7	8.78	3.82	3.1	2.3	2.8	3.4
5	0.8	14.20	6.18	6.2	4.6	5.6	6.8
6	1	20.10	8.74	11	7.9	9.4	12
7	1	28.90	12.6	18	13	16	19
8	1.25	36.60	15.9	26	19	23	28
10	1.5	58.00	25.2	50	38	45	55
12	1.75	84.30	36.7	88	66	79	97
14	2	115	50.0	140	105	126	154
16	2	157	68.3	219	164	197	241
18	2.5	192	83.5	301	226	271	331
20	2.5	245	106.5	426	320	383	469
22	2.5	303	132.0	581	436	523	639
24	3	353	153.5	737	553	663	811
27	3	459	199.5	1080	810	970	1130
30	3.5	561	244.0	1460	1100	1320	1530
33	3.5	694	302.0	1990	1490	1790	2090
36	4	817	355.5	2560	1920	2300	2690
42	4.5	1120	487.0	4090	3070	3680	4290

- NOTES:
1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 1 - SPECIFICATIONS

Metric Fastener Torque Chart (Continued)

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)*						
CLASS 10.9 METRIC (HEX HEAD) BOLTS, CLASS 10 METRIC NUTS CLASS 12.9 SOCKET HEAD CAPSCREWS M3 - M5*						
Size	Pitch	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry or Loctite® 263™) K=0.20	Torque (Lube or Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.18	Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	3.13			
3.5	0.6	6.78	4.22			
4	0.7	8.78	5.47			
5	0.8	14.20	8.85			
6	1	20.10	12.5			
7	1	28.90	18.0	25	23	19
8	1.25	36.60	22.8	37	33	27
10	1.5	58.00	36.1	70	65	55
12	1.75	84.30	52.5	125	115	95
14	2	115	71.6	200	180	150
16	2	157	97.8	315	280	235
18	2.5	192	119.5	430	385	325
20	2.5	245	152.5	610	550	460
22	2.5	303	189.0	830	750	625
24	3	353	222.0	1065	960	800
27	3	459	286.0	1545	1390	1160
30	3.5	561	349.5	2095	1885	1575
33	3.5	694	432.5	2855	2570	2140
36	4	817	509.0	3665	3300	2750
42	4.5	1120	698.0	5865	5275	4395

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

Metric Fastener Torque Chart (Continued)

Values for Magni Coated Fasteners (Ref 4150701)*						
CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS						
Size	Pitch	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry or Loctite® 263™) K=0.17	Torque (Lube or Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.16	Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	2.19	1.1	1.1	1.0
3.5	0.6	6.78	2.95	1.8	1.7	1.5
4	0.7	8.78	3.82	2.6	2.4	2.3
5	0.8	14.20	6.18	5.3	4.9	4.6
6	1	20.10	8.74	9	8.4	7.9
7	1	28.90	12.6	15	14	13
8	1.25	36.60	15.9	22	20	19
10	1.5	58.00	25.2	43	40	38
12	1.75	84.30	36.7	75	70	66
14	2	115	50.0	119	110	105
16	2	157	68.3	186	175	165
18	2.5	192	83.5	256	240	225
20	2.5	245	106.5	362	340	320
22	2.5	303	132.0	494	465	435
24	3	353	153.5	627	590	555
27	3	459	199.5	916	860	810
30	3.5	561	244.0	1245	1170	1100
33	3.5	694	302.0	1694	1595	1495
36	4	817	355.5	2176	2050	1920
42	4.5	1120	487.0	3477	3275	3070

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 1 - SPECIFICATIONS

Metric Fastener Torque Chart (Continued)

Values for Magni Coated Fasteners (Ref 4150701)*						
CLASS 10.9 METRIC (HEX HEAD) BOLTS CLASS 10 METRIC NUTS, CLASS 12.9 SOCKET HEAD CAPSCREWS M6 AND ABOVE*						
Size	Pitch	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry or Loctite® 263™) K=0.17	Torque (Lube or Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.18	Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	3.13			
3.5	0.6	6.78	4.22			
4	0.7	8.78	5.47			
5	0.8	14.20	8.85			
6	1	20.10	12.5	13	12	11
7	1	28.90	18.0	21	20	19
8	1.25	36.60	22.8	31	29	27
10	1.5	58.00	36.1	61	58	55
12	1.75	84.30	52.5	105	100	95
14	2	115	71.6	170	160	150
16	2	157	97.8	265	250	235
18	2.5	192	119.5	365	345	325
20	2.5	245	152.5	520	490	460
22	2.5	303	189.0	705	665	625
24	3	353	222.0	905	850	800
27	3	459	286.0	1315	1235	1160
30	3.5	561	349.5	1780	1680	1575
33	3.5	694	432.5	2425	2285	2140
36	4	817	509.0	3115	2930	2750
42	4.5	1120	698.0	4985	4690	4395

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your information to search for parts manuals and lookup part numbers.

* Brand:

* Model:

* Serial:

* Part Number:

SEARCH

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information to request help finding a part or manual.

Manufacturer:

Model:

Description:

Part Number:

Quantity:

Price:

Submit

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 2. GENERAL

2.1 MACHINE PREPARATION, INSPECTION, AND MAINTENANCE

General

This section provides the necessary information needed by those personnel that are responsible to place the machine in operation readiness and maintain its safe operating condition. For maximum service life and safe operation, ensure that all the necessary inspections and maintenance have been completed before placing the machine into service. With proper care, maintenance, and inspections performed per JLG's recommendations, and with any and all discrepancies corrected, this product will be fit for continued use.

Preparation, Inspection, and Maintenance

It is important to establish and conform to a comprehensive inspection and preventive maintenance program. The following table outlines the periodic machine inspections and maintenance recommended by JLG Industries, Inc. Consult your national, regional, or local regulations for further requirements for mobile elevating work platforms. The frequency of inspections and maintenance must be increased as environment, severity, and frequency of usage requires.

Pre-Start Inspection

It is the User's or Operator's primary responsibility to perform a Pre-Start Inspection of the machine prior to use daily or at each change of operator. Reference the Operation and Safety Manual for completion procedures for the Pre-Start Inspection. The Operation and Safety Manual must be read in its entirety and understood prior to performing the Pre-Start Inspection.

Pre-Delivery Inspection and Frequent Inspection

The Pre-Delivery Inspection and Frequent Inspection shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

The Pre-Delivery Inspection and Frequent Inspection procedures are performed in the same manner, but at different times. The Pre-Delivery Inspection shall be performed prior to each sale, lease, or rental delivery. The Frequent Inspection shall be accomplished for each machine in service for 3 months or 150 hours (whichever comes first); out of service for a period of more than 3 months; or when purchased used. The frequency of this inspection must be increased as environment, severity and frequency of usage requires.

Reference the JLG Pre-Delivery and Frequent Inspection Form and the Inspection and Preventive Maintenance Schedule for items requiring inspection during the performance of these inspections. Reference the appropriate areas of this manual for servicing and maintenance procedures.

Annual Machine Inspection

The Annual Machine Inspection must be performed on an annual basis, no later than thirteen (13) months from the date of the prior Annual Machine Inspection. JLG Industries recommends this task be performed by a Factory-Trained Service Technician. JLG Industries, Inc. recognizes a Factory-Trained Service Technician as a person who has successfully completed the JLG Service Training School for the subject JLG product model. Reference the machine Service and Maintenance Manual and appropriate JLG inspection form for performance of this inspection.

Reference the JLG Annual Machine Inspection Form and the Inspection and Preventive Maintenance Schedule for items requiring inspection during the performance of this inspection. Reference the appropriate areas of this manual for servicing and maintenance procedures.

For the purpose of receiving safety-related bulletins, it is important that JLG Industries, Inc. has updated ownership information for each machine. When performing each Annual Machine Inspection, notify JLG Industries, Inc. of the current machine ownership.

Preventive Maintenance

In conjunction with the specified inspections, maintenance shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

Reference the Preventive Maintenance Schedule and the appropriate areas of this manual for servicing and maintenance procedures. The frequency of service and maintenance must be increased as environment, severity, and frequency of usage requires.

Table 2-1. Inspection and Maintenance

Type	Frequency	Primary Responsibility	Service Qualification	Reference
Pre-Start Inspection	Prior to use each day; or At each Operator change.	User or Operator	User or Operator	Operation and Safety Manual
Pre-Delivery Inspection	Prior to each sale, lease, or rental delivery.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form.
Frequent Inspection	In service for 3 months or 150 hours, whichever comes first; or Out of service for a period of more than 3 months; or purchased used.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form.
Annual Machine Inspection	Annually, no later than 13 months from the date of the prior inspection.	Owner, Dealer, or User	Factory-Trained Service Technician (Recommended)	Service and Maintenance Manual and applicable JLG inspection form.
Preventive Maintenance	At intervals as specified in the Service and Maintenance Manual.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual

2.2 SERVICE AND GUIDELINES

General

The following information is provided to assist you in the use and application of servicing and maintenance procedures contained in this book.

Safety and Workmanship

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

Cleanliness

1. The most important single item in preserving the long service life of a machine is to keep dirt and foreign materials out of the vital components. Precautions have been taken to safeguard against this. Shields, covers, seals, and filters are provided to keep air, fuel, and oil supplies clean; however, these items must be maintained on a scheduled basis in order to function properly.

2. At any time when air, fuel, or oil lines are disconnected, clear adjacent areas as well as the openings and fittings themselves. As soon as a line or component is disconnected, cap or cover all openings to prevent entry of foreign matter.
3. Clean and inspect all parts during servicing or maintenance, and assure that all passages and openings are unobstructed. Cover all parts to keep them clean. Be sure all parts are clean before they are installed. New parts should remain in their containers until they are ready to be used.

Components Removal and Installation

1. Use adjustable lifting devices, whenever possible, if mechanical assistance is required. All slings (chains, cables, etc.) should be parallel to each other and as near perpendicular as possible to top of part being lifted.
2. Should it be necessary to remove a component on an angle, keep in mind that the capacity of an eyebolt or similar bracket lessens, as the angle between the supporting structure and the component becomes less than 90 degrees.
3. If a part resists removal, check to see whether all nuts, bolts, cables, brackets, wiring, etc., have been removed and that no adjacent parts are interfering.

Component Disassembly and Reassembly

When disassembling or reassembling a component, complete the procedural steps in sequence. Do not partially disassemble or assemble one part, then start on another. Always recheck your work to assure that nothing has been overlooked. Do not make any adjustments, other than those recommended, without obtaining proper approval.

Pressure-Fit Parts

When assembling pressure-fit parts, use a molybdenum disulfide base compound or equivalent to lubricate the mating surface.

Bearings

1. When a bearing is removed, cover it to keep out dirt and abrasives. Clean bearings in nonflammable cleaning solvent and allow to drip dry. Compressed air can be used but do not spin the bearing.
2. Discard bearings if the races and balls (or rollers) are pitted, scored, or burned.
3. If bearing is found to be serviceable, apply a light coat of oil and wrap it in clean (waxed) paper. Do not unwrap reusable or new bearings until they are ready to install.
4. Lubricate new or used serviceable bearings before installation. When pressing a bearing into a retainer or bore, apply pressure to the outer race. If the bearing is to be installed on a shaft, apply pressure to the inner race.

Gaskets

Check that holes in gaskets align with openings in the mating parts. If it becomes necessary to hand-fabricate a gasket, use gasket material or stock of equivalent material and thickness. Be sure to cut holes in the right location, as blank gaskets can cause serious system damage.

Bolt Usage and Torque Application

NOTICE

SELF LOCKING FASTENERS, SUCH AS NYLON INSERT AND THREAD DEFORMING LOCKNUTS, ARE NOT INTENDED TO BE REINSTALLED AFTER REMOVAL.

1. Always use new replacement hardware when installing locking fasteners. Use bolts of proper length. A bolt which is too long will bottom before the head is tight against its related part. If a bolt is too short, there will not be enough thread area to engage and hold the part properly. When replacing bolts, use only those having the same specifications of the original, or one which is equivalent.
2. Unless specific torque requirements are given within the text, standard torque values should be used on heat-treated bolts, studs, and steel nuts, in accordance with recommended shop practices. (See Torque Chart Section 1.)

Hydraulic Lines and Electrical Wiring

Clearly mark or tag hydraulic lines and electrical wiring, as well as their receptacles, when disconnecting or removing them from the unit. This will assure that they are correctly reinstalled.

Hydraulic System

1. Keep the system clean. If evidence of metal or rubber particles are found in the hydraulic system, drain and flush the entire system.
2. Disassemble and reassemble parts on clean work surface. Clean all metal parts with non-flammable cleaning solvent. Lubricate components, as required, to aid assembly.

Lubrication

Service applicable components with the amount, type, and grade of lubricant recommended in this manual, at the specified intervals. When recommended lubricants are not available, consult your local supplier for an equivalent that meets or exceeds the specifications listed.

Battery

Clean battery using a non-metallic brush and a solution of baking soda and water. Rinse with clean water. After cleaning, thoroughly dry battery and coat terminals with an anti corrosion compound.

Lubrication and Servicing

Components and assemblies requiring lubrication and servicing are shown in the Lubrication Chart in Section 1.

2.3 LUBRICATION AND INFORMATION

Hydraulic System

1. The primary enemy of a hydraulic system is contamination. Contaminants enter the system by various means, e.g., using inadequate hydraulic oil, allowing moisture, grease, filings, sealing components, sand, etc., to enter when performing maintenance, or by permitting the pump to cavitate due to insufficient system warm-up or leaks in the pump supply (suction) lines.
2. The design and manufacturing tolerances of the component working parts are very close, therefore, even the smallest amount of dirt or foreign matter entering a system can cause wear or damage to the components and generally results in faulty operation. Every precaution must be taken to keep hydraulic oil clean, including reserve oil in storage. Hydraulic system filters should be checked, cleaned, and/or replaced as necessary, at the specified intervals required in the Lubrication Chart in Section 1. Always examine filters for evidence of metal particles.
3. Cloudy oils indicate a high moisture content which permits organic growth, resulting in oxidation or corrosion. If this condition occurs, the system must be drained, flushed, and refilled with clean oil.
4. It is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. Good grade mineral oils, with viscosities suited to the ambient temperatures in which the machine is operating, are recommended for use.

NOTE: *Metal particles may appear in the oil or filters of new machines due to the wear-in of meshing components.*

Hydraulic Oil

1. Refer to Section 1 for recommendations for viscosity ranges.

Changing Hydraulic Oil

1. Filter elements must be changed after the first 50 hours of operation and every 300 hours (unless specified otherwise) thereafter. If it is necessary to change the oil, use only those oils meeting or exceeding the specifications appearing in this manual. If unable to obtain the same type of oil supplied with the machine, consult local supplier for assistance in selecting the proper equivalent. Avoid mixing petroleum and synthetic base oils.
2. Use every precaution to keep the hydraulic oil clean. If the oil must be poured from the original container into another, be sure to clean all possible contaminants from the service container. Always clean the mesh element of the filter and replace the cartridge any time the system oil is changed.
3. While the unit is shut down, a good preventive maintenance measure is to make a thorough inspection of all hydraulic components, lines, fittings, etc., as well as a functional check of each system, before placing the machine back in service.

Lubrication Specifications

Specified lubricants, as recommended by the component manufacturers, are always the best choice, however, multi-purpose greases usually have the qualities which meet a variety of single purpose grease requirements. Should any question arise, regarding the use of greases in maintenance stock, consult your local supplier for evaluation. Refer to Section 1 for an explanation of the lubricant key designations appearing in the Lubrication Chart.

2.4 CYLINDER DRIFT

Theory

When a hydraulic cylinder is supporting a load, cylinder drift may occur as a result of any of the circumstances below:

- Normal leakage of load holding valves or malfunction of load holding valves. See Cylinder Leakage Test and Table 2-2, Cylinder Drift below for evaluation.
- Damaged or worn piston seals.
- Normal thermal expansion or contraction of the hydraulic oil within cylinders (See Cylinder Thermal Drift below).

The first two circumstances may result in cylinder movement due to oil leaking out of the cylinder externally or by leaking back to tank or due to oil leaking internally from one cylinder chamber to the other.

Thermal expansion or contraction of oil in hydraulic cylinders is a normal occurrence and does not result in oil leaking out of the cylinder or leaking internally from one cylinder chamber to the other. Thermal expansion or contraction is the tendency for materials to change size in response to a change in temperature.

Cylinder Leakage Test

Cylinder oil must be at stabilized ambient temperature before beginning this test.

Measure drift at cylinder rod with a calibrated dial indicator.

In an area free of obstructions, cylinder must have load applied and appropriately positioned to detect drift.

Cylinder leakage is acceptable if it passes this test.

Table 2-2. Cylinder Drift

Cylinder Bore Diameter		Max. Acceptable Drift in 10 Minutes	
inches	mm	inches	mm
3	76.2	0.026	0.66
3.5	89	0.019	0.48
4	101.6	0.015	0.38
5	127	0.009	0.22
6	152.4	0.006	0.15
7	177.8	0.005	0.13
8	203.2	0.004	0.10
9	228.6	0.003	0.08

NOTE: This information is based on 6 drops per minute cylinder leakage.

Cylinder Thermal Drift

The oil in all hydraulic cylinders will expand or contract due to thermal effects over time and may result in changes to the boom and/or platform position while the machine is stationary. These effects occur as the cylinder oil changes temperature, usually from a higher oil temperature as it cools and approaches the ambient air temperature. Results of these effects are related to several factors including cylinder length and change in temperature over the time the cylinder remains stationary.

2.5 PINS AND COMPOSITE BEARING REPAIR GUIDELINES

Filament wound bearings.

1. Pinned joints should be disassembled and inspected if the following occurs:
 - a. Excessive sloppiness in joints.
 - b. Noise originating from the joint during operation.
2. Filament wound bearings should be replaced if any of the following is observed:
 - a. Frayed or separated fibers on the liner surface.
 - b. Cracked or damaged liner backing.
 - c. Bearings that have moved or spun in their housing.
 - d. Debris embedded in liner surface.
3. Pins should be replaced if any of the following is observed (pin should be properly cleaned prior to inspection):
 - a. Detectable wear in the bearing area.
 - b. Flaking, peeling, scoring, or scratches on the pin surface.
 - c. Rusting of the pin in the bearing area.
4. Re-assembly of pinned joints using filament wound bearings.
 - a. Housing should be blown out to remove all dirt and debris...bearings and bearing housings must be free of all contamination.
 - b. Bearing / pins should be cleaned with a solvent to remove all grease and oil...filament wound bearing are a dry joint and should not be lubricated unless otherwise instructed (i.e. sheave pins).
 - c. Pins should be inspected to ensure it is free of burrs, nicks, and scratches which would damage the bearing during installation and operation.

2.6 WELDING ON JLG EQUIPMENT

NOTE: This instruction applies to repairs, or modifications to the machine and to welding performed from the machine on an external structure, or component.

Do the Following When Welding on JLG Equipment

- Disconnect the battery.
- Disconnect the moment pin connection (where fitted).
- Ground only to structure being welded.

DO NOT Do the Following When Welding on JLG Equipment

- Ground on frame and weld on any other area than the chassis.
- Ground on turntable and weld on any other area than the turntable.
- Ground on the platform/support and weld on any other area than the platform/support.
- Ground on a specific boom section and weld on any other area than that specific boom section.
- Allow pins, wear pads, wire ropes, bearings, gearing, seals, valves, electrical wiring, or hoses to be between the grounding position and the welded area.

NOTICE

FAILURE TO COMPLY WITH THE ABOVE REQUIREMENTS MAY RESULT IN COMPONENT DAMAGE (I.E. ELECTRONIC MODULES, SWING BEARING, COLLECTOR RING, BOOM WIRE ROPES, ETC.)

NOTE: Refer the Operation and Safety Manual for completion procedures for the Pre-Start Inspection.

Table 2-3. Inspection and Preventive Maintenance Schedule

AREA	Inspections	
	Pre-Delivery ¹ or Frequent ² (Quarterly) Inspection	Annual ³ (Yearly) Inspection
Boom Assembly		
Boom Weldments	1,2	1,2
Hose/Cable Carrier Installations	1,2	1,2
Pivot Pins and Pin Retainers	1,2	1,2
Sheaves, Sheave Pins	1,2	1,2
Bearings	1,2	1,2
Wear Pads	1,2	1,2
Covers or Shields	1,2	1,2
Extend/Retract Chain or Cable Systems ⁴	1,2	1,2
Platform Assembly		
Railing	2	2
Gate	1,2,3	1,2,3
Floor	2	2
Rotator	1,2,3,4	1,2,3,4
Lanyard Anchorage Point	1,2,6	1,2,6
Turntable Assembly		
Swing Bearing or Worm Gear	1 ⁵⁰ , 2	1 ⁵⁰ , 2
Oil Coupling	4	4
Swing Drive System	1,4	1,4
Turntable Lock	1,2,3	1,2,3
Hood, Hood Props, Hood Latches	3	3
Chassis Assembly		
Tires	1,2	1,2
Wheel Nuts/Bolts	1 ⁵⁰	1 ⁵⁰
Wheel Bearings	1,2,4,5	1,2,4,5
Oscillating Axle/Lockout Cylinder Systems	1,2,4,5	1,2,4,5
Extendable Axle Systems	3	3
Steer Components	1,2	1,2
Spindle Thrust Bearing/Washers	1,2	1,2
Drive Hubs	1,4	1,4

SECTION 2 - GENERAL

Table 2-3. Inspection and Preventive Maintenance Schedule

AREA	Inspections	
	Pre-Delivery ¹ or Frequent ² (Quarterly) Inspection	Annual ³ (Yearly) Inspection
Functions/Controls		
Platform Controls return to neutral/off when released	1, 3, 6, 9	1, 3, 6, 9
Ground Controls return to neutral/off when released	1, 3, 6, 9	1, 3, 6, 9
Function Control Locks, Guards, or Detents	1, 3, 9	1, 3, 9
Footswitch (shuts off function when released)	1, 3, 9	1, 3, 9
Emergency Stop Switches (Ground & Platform) arrest all platform movement	1, 3, 6	1, 3, 6
Function Limit or Cutout Switch Systems	1, 3, 9	1, 3, 9
Capacity Indicator	1, 3, 9	1, 3, 9
Drive Brakes	1, 3, 9	1, 3, 9
Swing Brakes	1, 3, 9	1, 3, 9
Auxiliary Power	1, 3, 9	1, 3, 9
Power System		
Engine Idle, Throttle, and RPM	1, 3, 7	1, 3, 7
Engine Fluids: Oil	4	4
Engine Fluids: Coolant	1, 4, 7	1, 4, 7
Air Filter	1, 4	1, 4
Fuel Filter(s)	1, 5	1, 5
Drain Oil Build Up in 2-Stage Vaporizer (LP Only)	1, 4	1, 4
Exhaust System	1, 4	1, 4
Batteries	1, 4	1, 4
Battery Fluid	4	4
Battery Charger	1, 3	1, 3
Intake System	1, 2	1, 2
Glow Plug (Diesel Only)	1, 2, 3	1, 2, 3
Serpentine Belt, Tensioner, Pulleys	1, 2, 3	1, 2, 3
Fuel Reservoir, Cap, and Breather	1, 2, 4	1, 2, 4
Hydraulic/Electric System		
Hydraulic Pumps	1, 2, 4	1, 2, 4
Hydraulic Cylinders	1, 2, 4, 5	1, 2, 4, 5
Cylinder Attachment Pins and Pin Retainers	1, 2	1, 2
Hydraulic Hoses, Lines, and Fittings	1, 2, 4	1, 2, 3, 4
Hydraulic Reservoir, Cap, and Breather	1, 2, 3, 4, 5	1, 2, 3, 4, 5
Hydraulic Filter(s)	1, 4, 5	1, 4, 5
Hydraulic Fluid	4, 5	4, 5
Electrical Connections	1, 2	1, 2
Instruments, Gauges, Switches, Lights, Horn	1, 3	1, 3

Table 2-3. Inspection and Preventive Maintenance Schedule

AREA	Inspections	
	Pre-Delivery ¹ or Frequent ² (Quarterly) Inspection	Annual ³ (Yearly) Inspection
General		
All Decals/Placards Installed, Secure, Legible	9	9
Annual Machine Inspection Due	-	9
No Unauthorized Modifications or Additions	9	9
All Relevant Safety Publications Incorporated	9	9
General Structural Condition and Welds	2	2
All Fasteners, Pins, Shields, and Covers	1,2	1,2
Grease and Lubricate to Specifications	9	9
Function Test of All Systems	9	9
Paint and Appearance	5	5
Stamp Inspection Date on Frame	-	9
Notify JLG of Machine Ownership	-	9
Footnotes:		
¹ Prior to each sale, lease, or delivery		
² In service for 3 months; Out of service for 3 months or more; Purchased used		
³ Annually, no later than 13 months from the date of the prior inspection, Includes all daily and quarterly inspections, mandated by regulating body		
⁴ Replace every 12 years or 7,000 hours		
⁵⁰ Indicates a 50 hour interval required to perform task after initial use of machine. This only occurs once in machine life		
²⁵⁰ Indicates a 250 hour interval required to perform task after initial use of machine. This only occurs once in machine life		
Performance Codes:		
1 - Check for proper and secure: installation, adjustment, or torque		
2 - Visual inspection for damage: (cracks, corrosion, abrasions, distortion, excessive wear, broken welds, gouges, chafing and threads showing)		
3 - Proper operation		
4 - Check for proper sealing, signs of leakage and fluid level		
5 - Clean and free of debris		
6 - Decals installed and legible		
7 - Check for proper tolerances, routing, and lubrication		
8 - Fully Charged		
9 - Verify/Perform		





Figure 2-1. Engine Operating Temperature Specifications - Deutz



Fluid	Properties		Base				Classifications			
	Description	Viscosity at 40°C (cSt, Typical)	Viscosity Index	Mineral Oils	Vegetable Oils	Synthetic	Synthetic-Polyol Esters	Readily Biodegradable*	Virtually Non-toxic**	Fire Resistant***
Mobilfluid 424		55	145	X						
Mobil DTE 10 Excel 32		32	164	X					X	
Univis HVI 26		26	376	X						
Mobil EAL Hydraulic Oil		47	176		X			X	X	
Mobil EAL EnviroSyn H46		49	145			X		X	X	
Quintolubric 888-46		50	185				X	X	X	X

* Readily biodegradable classification indicates one of the following:

CO2 Conversion > 60% per EPA 560/6-82-003

CO2 Conversion > 80% per CEC-L-33-A-93

** Virtually Non-toxic classification indicates an LC50 > 5000 ppm per OECD 203

*** Fire Resistant classification indicates Factory Mutual Research Corp. (FMRC) Approval

4150740-8

Figure 2-2. Hydraulic Oil Operating Temperature Specifications

SECTION 3. CHASSIS & TURNTABLE

3.1 TIRES AND WHEELS

Tire Damage

For polyurethane foam filled tires, JLG Industries, Inc. recommends that when any of the following are discovered, measures must be taken to remove the JLG product from service immediately and arrangements must be made for replacement of the tire or tire assembly.

- a smooth, even cut through the cord plies which exceeds 3 inches (7.5 cm) in total length
- any tears or rips (ragged edges) in the cord plies which exceeds 1 inch (2.5 cm) in any direction
- any punctures which exceed 1 inch in diameter
- any damage to the bead area cords of the tire

If a tire is damaged but is within the above noted criteria, the tire must be inspected on a daily basis to insure the damage hasn't propagated beyond the allowable criteria.

Tire Replacement

JLG recommends a replacement tire be the same size, ply and brand as originally installed on the machine. Refer to the JLG Parts Manual for part number of approved tires for a particular machine model. If not using a JLG approved replacement tire, we recommend replacement tires have the following characteristics:

- Equal or greater ply/load rating and size of original
- Tire tread contact width equal or greater than original
- Wheel diameter, width, and offset dimensions equal to original
- Approved for application by the tire manufacturer (including inflation pressure and maximum tire load)

Unless specifically approved by JLG Industries Inc. Do not replace a foam filled or ballast filled tire assembly with a pneumatic tire. Due to size variations between tire brands, both tires on the same axle should be the same.

Wheel Replacement

The rims installed on each product model have been designed for stability requirements which consist of track width, tire pressure, and load capacity. Size changes such as rim width, center piece location, larger or smaller diameter, etc., without written factory recommendations, may result in an unsafe condition regarding stability.

Wheel Installation

It is extremely important to apply and maintain proper wheel mounting torque.


WARNING

WHEEL NUTS MUST BE INSTALLED AND MAINTAINED AT THE PROPER TORQUE TO PREVENT LOOSE WHEELS, BROKEN STUDS, AND POSSIBLE DANGEROUS SEPARATION OF WHEEL FROM THE AXLE. BE SURE TO USE ONLY THE NUTS MATCHED TO THE CONE ANGLE OF THE WHEEL.

Tighten the lug nuts to the proper torque to prevent wheels from coming loose. Use a torque wrench to tighten the fasteners. If you do not have a torque wrench, tighten the fasteners with a lug wrench, then immediately have a service garage or dealer tighten the lug nuts to the proper torque. Over-tightening will result in breaking the studs or permanently deforming the mounting stud holes in the wheels.

The proper procedure for attaching wheels is as follows:

1. Start all nuts by hand to prevent cross threading. DO NOT use a lubricant on threads or nuts.
2. Tighten nuts in the following sequence:



3. The tightening of the nuts should be done in stages. Following the recommended sequence, tighten nuts per wheel torque chart.

Table 3-1. Wheel Torque Chart

TORQUE SEQUENCE		
1st Stage	2nd Stage	3rd Stage
35 ft. lbs. (47 Nm)	80 ft. lbs. (108 Nm)	140 ft. lbs. (190 Nm)

NOTE: Ensure all mating surface are clean and free from damage or debris.

4. Wheel nuts should be torqued before first road use and after each wheel removal. Check and torque every 3 months or 150 hours of operation.

3.2 AXLE EXTENSION SYSTEM

NOTE: The boom must be oriented between the rear wheels to extend or retract the axles.

The Axle Extension System allows each of the four axles to be extended and retracted together while maintaining full steering control as the machine is driven. The system allows the axles to extend or retract only while the boom is in the transport position (see Section 4-1, Transport Position Sensing System) and in order to minimize wheel scrubbing during axle movement, a minimum drive speed must be attained before axle extension/retraction will be permitted.

The system uses four linear sensors (one at each axle) to sense when the axles are fully extended. If any of the linear sensors detect an out of range value for axle set, the control system considers the axles retracted. To extend/retract the axles, the user engages the axle extend/retract switch on the platform console and the drive control at the same time.

The axle set indicator will be off when the axles are not fully extended and the axle extend/retract switch is not engaged. It will flash while the axles are extending or retracting and will be on constantly when the axles are fully extended. With the axles not fully extended, the boom is restricted to operation within the transport position (see Section 4-1, Transport Position Sensing System).

If a signal from any axle linear sensor is lost when the boom is beyond the transport position, the axle set indicator will flash and drive/steer functions will be disabled until the boom is brought back into the transport position. The steering angle will be automatically limited to +/- 20 degrees anytime the axles are not fully extended. If the wheel angle is more than +/- 20 degrees when the axle retract command is engaged, the control system will automatically reduce the wheel angle to 20 degrees during axle retraction.

3.3 DRIVE ORIENTATION SYSTEM

The Drive Orientation System (DOS) is intended to indicate to the operator conditions that could make the direction of movement of the chassis different than the direction of movement of the drive/steer control handle.

The system indicates to the operator the need to match the black and white directional arrows on the platform control panel to the arrows on the chassis for the intended direction of travel. The system uses a proximity switch mounted on the hydraulic swivel, an indicator light and an override switch on the platform display panel. The proximity switch trips when the turntable is swung +/- 45 degrees off center of the normal driving position.

This occurs roughly when the boom is swung past a rear tire. When the turntable is in the normal drive position with the boom between the rear tires, no indications or interlocks are made. When the machine is actively driving when the turntable is swung past the switch point, the system is ignored until drive/steer is released.

When drive is initiated with the boom swung past the switch point, the DOS indicator will flash and the drive/steer functions will be disabled. The operator must engage the DOS override switch to enable Drive/steer (high drive will remain disabled).

When the DOS is enabled, the DOS indicator will be illuminated continuously and a 3-second enable timer will be started and will continue for 3 seconds after the end the last drive/steer command. If the timer expires, the DOS override switch must be re-engaged to enable drive/steer.

3.4 STEERING CONTROL SYSTEM

There are three different modes of steering selectable by the position of the steer select switch on the platform control panel: crab, coordinated, and conventional two wheel steering. These are shown below.



Figure 3-1. Crab Steer



Figure 3-2. Coordinated Steer



Figure 3-3. Conventional Two Wheel Steer

Each wheel has its own steer cylinder, wheel angle sensor, axle extend linear sensor, and proportional valve, allowing the control system to position each wheel to the ideal angle for all steering modes and all steering commands. This is done whether the axle is retracted, extended, or somewhere in between. Changes in steering modes while drive is engaged requires the operator to return the joystick to the neutral position before the steer cylinders are adjusted. Once the footswitch is depressed and drive or steer is engaged, the wheels automatically adjust to the appropriate angle for the selected steering mode based on the position of the inside front wheel. If the steer select switch is changed without the footswitch depressed or the EMS is off, the wheels will not move until the footswitch is depressed and a steering or drive command has been initiated. The steering angles are limited to +/- 20 degrees anytime the axles are not fully extended. See the Axle Extension System for interaction with the axle extension system. If a wheel cannot achieve its commanded angle within a specified time, it is considered jammed. When a wheel is considered jammed during steering, a fault is reported and the remaining wheels will continue to their commanded position. The fault is cleared when the footswitch is cycled. If a wheel is jammed making it significantly out of position, with regard to the other wheels, the drive motors are restricted to their maximum displacement (slow speed). Wheel angle sensor failures will result in an approximated steering control logic that will allow the operator to move the machine until it can be repaired. The wheel at the failed sensor will be driven based on the information available from the other sensors. This wheel will not track perfectly and will become farther out of position over time. When the wheel becomes prohibitively out of position, the wheels can be resynchronized by fully steering against the mechanical stops.

Axle extend sensor failures will result in an approximated steering control logic that will allow the operator to move the machine until it can be repaired. The axle at the failed sensor will be driven based on the information available from the other sensors. This axle will not track perfectly and will become farther out of position over time. When the wheel becomes prohibitively out of position, the wheels can be resynchronized by fully steering against the mechanical stops. Coordinated and crab steer modes are limited to low speed drive, regardless of speed select switch position.

3.5 DRIVE/STEERING SPEED CONTROL

The Drive/Steering Speed Control system uses the steering sensors from the steering control system to increase operator control and comfort by reducing the effect of turning the chassis on the resulting lateral platform speed. The system proportionally varies the drive speed based on the predicted turning radius of the chassis for conventional two wheel steer mode. The tighter the turn the slower the allowable drive speed. As crab steer does not steer on a radius, low speed drive is maintained regardless of steer angle.

3.6 TRACTION CONTROL SYSTEM

The traction control system uses the steering sensors from the steering control system to optimize the performance of the drive system. This is especially important due to the disparity of wheel speeds generated between the inside and outside wheels of the extended axle chassis with large steering angle capability. The steering sensors are used to predict the rolling path and therefore the required wheel speed of each wheel as the steering angles change and steering modes change. The control system can then command the ideal flow from each of the two drive pumps, one for the right side of the machine and one for the left side. Two flow dividers, one for the right side, front to back and one for the left side, front to back absorb the variation in wheel speed, front to back.

3.7 GROUND CONTROL KEYSWITCH SYSTEM

The ground control keyswitch is used for selecting the active control of the machine between the platform or ground control stations and as another shut off switch for machine power. On the standard keyswitch, the key is removable only in the off position. This allows the ground control station to have ultimate priority over the platform control.

3.8 JIB LIFT END OF STROKE DAMPENING

The jib lift cylinder is outfitted with a linear position sensor and end of stroke dampening is achieved through the electronic control system. This system slows the jib speed within the last 5° before minimum and maximum jib elevation. This reduction in speed occurs only while approaching the end of stroke limits. Speeds in the opposite direction are not altered.

3.9 HYDRAULIC SYSTEM WARM UP

For optimal life and performance of the hydraulic system in extremely cold temperatures, the control system monitors the hydraulic system temperature and automatically limits the function speeds of the high demand functions.

While the system is cold and in the warm up mode, the main lift and main telescope functions are limited to creep speeds and is indicated to the operator by flashing the creep light on the platform control panel.

Operating the machine while in the warm up mode will generate sufficient heat to bring the hydraulic temperature up to allowable temperatures and the warm up mode will be automatically turned off.

This system is activated when the hydraulic oil temperature in the main valve is below 30°F (-1°C) and the engine coolant temperature is below 150°F (65°C). In warm up, the engine operates at mid engine speed and a valve is energized which loads the pump to build heat. This valve is active only when no function is selected. Warm up ends when the main valve temperature reaches 50°F (10°C) or the engine coolant reaches 150°F (65°C). Functions being operated when the warm up mode turns off will remain in the creep speed until the function is re-initiated.

3.10 FUNCTION SPEED CONTROL SYSTEM

The platform controls for the platform rotate, jib lift, main boom telescope and jib telescope functions are controlled through a common variable speed control knob. This knob allows a smooth ramp up, controlled maximum output speed, and ramp down. Each function has its own personality settings allowing the characteristics of each function to be modified using the standard analyzer. Not all functions will respond the same to the changes in the function speed knob position. Full counterclockwise rotation of this knob to the detent position places all functions into creep speed including lift, swing, and drive.

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

A screenshot of the "Search Manuals" form. The form has a title "Search Manuals" and a subtitle "Please provide information to help us locate the manual and/or parts you need." It includes fields for "Brand", "Model Number", "Year", "Serial", "Part Number", "Part Name", and "Quantity". There is a "Search" button at the bottom.

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

A screenshot of the "Parts Order Form". The form has a title "Parts Order Form" and a subtitle "Please fill in as much information as possible." It includes fields for "Manufacturer", "Model", "Year", "Serial", "Part Number", "Part Name", "Quantity", "Date Received", "Order Code", "Phone", "Fax", "E-mail", and "Name". There is a "Submit" button at the bottom.

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar




Figure 3-4. Axle Hose Routing - Sheet 1 of 2




Figure 3-5. Axle Hose Routing - Sheet 2 of 2




Figure 3-6. Steering/Axle Hydraulic Circuit




Figure 3-7. Drive System Hydraulic Circuit - Sheet 1 of 2




Figure 3-8. Drive System Hydraulic Circuit - Sheet 2 of 2






Figure 3-9. Turntable Hydraulic System

3.11 DRIVE ASSEMBLY



- | | | | |
|--------------|----------------|-----------|---------|
| 1. Drive Hub | 3. Drive motor | 5. Bolt | 7. Bolt |
| 2. O-Ring | 4. Washer | 6. Washer | |

3.12 DRIVE HUB




1001149921

- | | | | | | | |
|-----------|-------------------------|--------------------|-----------------|--------------------|------------------|--------------------|
| 1. Ring | 9. Pin | 17. Pinion | 25. Flange | 33. Seal | 41. Plastic Plug | 49. O-Ring |
| 2. Screw | 10. O-Ring | 18. Hub Housing | 26. O-Ring | 34. Coupling | 42. Input Shaft | 50. Brake Piston |
| 3. Cover | 11. Pinion | 19. Screw | 27. Ring Nut | 35. Spring | 43. Iron Disc | 51. Brake Spring |
| 4. Gasket | 12. Retaining Ring | 20. Screw | 28. Set Screw | 36. Retaining Ring | 44. Brake Disc | 52. Spacer |
| 5. Plug | 13. Gear Reduction Assy | 21. Plug | 29. Bearing | 37. Bearing | 45. Spacer | 53. Retaining Ring |
| 6. Cover | 14. Pinion | 22. Retaining Ring | 30. Hub Support | 38. Axle | 46. Seal | 54. O-Ring |
| 7. O-Ring | 15. Ring | 23. Bearing | 31. O-Ring | 39. Plug | 47. O-Ring | 55. Motor Support |
| 8. Shim | 16. Gear Reduction Assy | 24. Planet Wheel | 32. Bearing | 40. Plug | 48. Seal | 56. Screw |


Figure 3-10. Drive Hub

Disassembly


1. Remove plugs (5) and pour lubricant in a container. Reinstall plugs.
2. Remove six screws (56), motor flange(55), and O-Ring (54). Do not damage O-Ring.




3. Remove two screws (2), cover (3), and pin (9).




4. Remove, Ring (1), Cover (6), O-Ring (7), Shim (8) and O-Ring (10). Do not damage O-Rings. Check and remove Gasket (4) if damaged.




5. Remove Pinion (11), Gear Reduction Assembly (13) and Gear Reduction Assembly (16).




- 6.** Remove two Screws (19), Hub Housing (18) and O-Ring (26). Do not damage O-Ring.




- 8.** Remove three snap rings (22) and planet wheel (24) from spindles on Flange (25).



- 7.** Remove Coupling (34) and Spring (35).




- 9.** Remove two Set Screws (28) from Ring Nut (27). Remove Ring Nut from Flange (25).




SECTION 3 - CHASSIS & TURNTABLE


10. Remove Hub Support (30), Bearing (29), O-Ring (31), Bearing (32), and two Seals (33) from Axle (38).




11. Remove six screws (20), Plug (21), and Flange (25) from Axle (38).




12. Remove Snap Ring (53), Spacer (52), Seal (48), O-Ring (49), and Brake Piston (50) from Axle (38). Remove five Brake Springs (51) from Brake Piston (50). Use compressed air to remove Brake Piston from Axle.



13. Remove O-Ring (49), Seal (48), O-Ring (47), Seal (46), Spacer (45), nine Brake Discs (44) and eight Iron Discs (43) from Axle (38).




- 14.** Remove Split Ring (36), Input Shaft (42), and Bearing (37) from Axle (38).




Assembly

NOTE: Thoroughly clean and coat all parts with grease before assembling.


1. Check parts are free of damage, burrs, or other defects.
2. Install Bearing (37) in Axle (38). Install Input Shaft (42) in Axle and Bearing. Secure with Split Ring (36).



- 3.** Install Seal (46), O-Ring (47), Seal (48), and O-Ring (49) in Axle (38). Starting with Brake Disk (44) alternate with Iron Disk (43) until a total of eight Brake Disks and nine Iron Discs are installed on Input Shaft (42 - not shown) in Axle.




- 4.** Install Brake Piston (50) in Axle (38). Install five Brake Springs (51) Piston holes. Install O-Ring (49) and Seal (48) in Axle. Install Spacer (52) against Piston and secure with Split Ring (53).




SECTION 3 - CHASSIS & TURNTABLE

5. Install Flange (25) on Axle (38), with Plug (21) and six screws (20).




NOTE: Flat surface of bearings face toward inside of Hub Support.

6. Install two seals (33) on Axle (38). Install O-Ring (31) in Hub Support (30). Install Bearing (32) and Bearing (29) in Hub Support. Install assembled Hub Support on Axle as shown below.




NOTE: Install Ring Nut with convex part facing bearing.


7. Install Ring Nut (27) on Flange (25). Prevent Flange from turning and torque Ring Nut to 295 ft-lb (400 Nm). Tighten and back off two times to completely seat bearings. Tighten to final torque of 221 ft-lb (300 Nm). Check roll torque with seal is within 7 - 11 ft-lb (10 - 15 Nm). Apply JLG Threadlocking compound or equivalent to two Setscrews (28). Install and torque Setscrews to 7.4 ft-lb (10 Nm).




8. Install three planet wheel (24) on Flange spindles (25). Secure with Snap Rings (22). Lubricate planetary gear bearings.




- 9.** Install Spring (35) and Coupling (34).




- 10.** Install O-Ring (26). Install Planet wheel (18) with two Screws (19). Torque Screws to 36.8 ft-lb (50 Nm).



- 11.** Install Gear Reduction Assembly (16), Gear Reduction Assembly (13), and Pinion (11) in Planetary Housing. Lubricate all bearings.




- 12.** Install O-Ring (7) and O-Ring (10) in Cover (6). Liberally coat Shim (8) with grease and center on hole at center of Cover. Install Cover on Planetary Ring Assembly (18) and secure with Ring (1). Replace Gasket (4) as needed.




SECTION 3 - CHASSIS & TURNTABLE

13. Install O-Ring (54) and Motor Support (55). Apply JLG Threadlocking compound or equivalent to six Screws (56). Install and torque Screws to 177 ft-lb (240 Nm).



14. Check completed Drive Hub assembly rotates freely.

15. Install Pin (9) and Cover (3). Secure with two Screws (2). Torque to 7 ft-lb (10 Nm).



⚠ WARNING

FAILURE TO PROPERLY FILL DRIVE HUB WITH OIL BEFORE OPERATION WILL RESULT IN EQUIPMENT FAILURE AND COULD CAUSE DEATH, SERIOUS INJURY, OR DAMAGE TO PROPERTY AND EQUIPMENT.

16. Follow oil change procedures and refill Drive Hub before operating equipment.

3.13 FREE WHEELING OPTION

Disengage Drive Motors & Brakes for Towing, etc. (Free Wheel)

1. Chock wheels.
2. Removing screws and invert cover so center tip presses on disengagement pin in hub. Reinstall screws.
3. Remove chocks.

Engage Drive Motors & Brakes (Normal Operation)

1. Chock wheels.
2. Removing screws and invert cover so center tip faces out. Reinstall screws.
3. Remove chocks.




Figure 3-11. Disengaging Drive Hubs

3.14 GEAR HUB OIL SERVICE

Check Oil Level

1. Position hub as shown in Figure 3-12.
2. Remove Level Plug (3) and check oil is level with plug opening. Add oil as needed.
3. Reinstall plug.

Change Gear Hub Oil

NOTE: Change oil when reduction gear is hot.

1. Position hub as shown in Figure 3-12.
2. Place suitable tray underneath to collect waste oil.
3. Remove three plugs.
4. Flush gear hub with appropriate solvent.
5. Reinstall Drain Plug (2).
6. Fill with oil until level reaches level hole.
7. Reinstall Level Plug (3) and Fill Plug (1).





Figure 3-12. Gear Hub Oil Fill and Drain



3160339

- | | | | | | |
|------------------|---------------------|----------------------|------------------|-------------|-------------------------|
| 1. Bolt | 7. Needle Bearing | 13. Cylinder Block | 19. O-Ring | 25. Gasket | 31. Shaft |
| 2. Motor End cap | 8. Valve Plate | 14. Slipper Pin | 20. Servo Piston | 26. Plug | 32. Bearing |
| 3. Locating Pin | 9. Snap Ring | 15. Guide | 21. Spring | 27. O-Ring | 33. Snap Ring |
| 4. O-Ring | 10. Spring Retainer | 16. Slipper Retainer | 22. Pin | 28. Plug | 34. Snap Ring |
| 5. Plug | 11. Spring | 17. Cylinder Piston | 23. Swashplate | 29. O-Ring | 35. Seal |
| 6. Dowel Pin | 12. Washer | 18. Piston Ring | 24. Bearing Kit | 30. Housing | 36. Seal Support Washer |

Figure 3-13. Drive Motor


3.15 DRIVE MOTOR

NOTE: Drive motor servicing is similar for all Series 45 hydraulic motors. The physical appearance of your motor may be slightly different than shown.

Description

Drive motors are low to medium power, two-position axial piston motors incorporating an integral servo piston. They are designed for operation in open and closed circuit applications. The standard control is a direct acting single line hydraulic control. The integral servo piston controls motor displacement.

Motors are spring biased to maximum displacement and hydraulically shifted to minimum displacement. Minimum and maximum displacement can be set with fixed internal stops. The large diameter servo piston allows smooth acceleration and deceleration with relatively large circuit orificing.




- | | | |
|-----------------|---------------|--------------------|
| 1. Bias Spring | 5. Shaft Seal | 9. Valve Plate |
| 2. Servo Piston | 6. Bearing | 10. End Cap |
| 3. Swashplate | 7. Slipper | 11. Cylinder Block |
| 4. Output Shaft | 8. Piston | |

Figure 3-14. Drive Motor Cross Section

Shaft Seal Replacement

REMOVAL

1. Remove snap ring (1) retaining shaft seal, and support washer.



1. Snap Ring
2. Support Washer
3. Shaft Seal

Figure 3-15. Removing Shaft Seal

2. Remove support washer (2).
3. Carefully pry out shaft seal (3).

NOTE: To avoid damaging shaft during removal, install a large sheet metal screw in chuck of a slide hammer. Drive screw in seal surface and use slide hammer to pull seal.

4. Discard seal.

SECTION 3 - CHASSIS & TURNTABLE

INSPECTION

Inspect new seal, motor housing seal bore, and sealing area on shaft for rust, wear, and contamination. Polish shaft and clean housing if necessary.


INSTALLATION

1. Cover shaft splines with an installation sleeve to protect shaft seal during installation.
2. Install new shaft seal with cupped side facing motor. Press seal into housing until it bottoms out. Press evenly to avoid binding and damaging the seal.
3. Install seal support washer.
4. Install snap ring.
5. Remove installation sleeve.

Loop Flushing Valve

REMOVAL

1. Using a 11/16 in internal hex wrench remove plug (1) and (2).



- | | | |
|-----------|------------|--------------------|
| 1. Plug | 6. O-ring | 11. Washer |
| 2. Plug | 7. Spring | 12. Shift Spool |
| 3. Plug | 8. Spring | 13. Orifice Poppet |
| 4. O-ring | 9. Spring | |
| 5. O-ring | 10. Washer | |

Figure 3-16. Loop Flushing Spool

2. Using a 1/4 in hex wrench remove plug (3).
3. Remove O-rings (4, 5, and 6).
4. Using pliers, remove centering springs (7, 8, and 9).
5. Remove spring retaining washers (10 and 11).
6. Remove shift spool (12).
7. Remove orifice poppet (13).

INSPECTION

1. Inspect new O-rings and the sealing area for rust, wear, or contamination.
2. Check springs and poppet for wear.

INSTALLATION

1. Install orifice poppet (13).
2. Install shift spool (12).
3. Install spring retaining washers on springs (10 and 11).
4. Carefully install centering springs (7, 8, and 9).
5. Install new O-rings (6, 4, and 5).
6. Using a 1/4 in hex wrench torque plug (3) to 20 ft. lbs. (27 Nm).
7. Using a 11/16 in internal hex, torque plugs (2 and 1) to 27 ft. lbs. (37 Nm).

Troubleshooting

Table 3-2. Excessive Noise and/or Vibration

Item	Description	Action
Check oil level in reservoir and oil supply to motor.	Insufficient hydraulic fluid could lead to cavitation that would cause system noise.	Fill reservoir to proper level. Ensure oil supply to motor is adequate and lines are unobstructed.
Check for air in system.	Air trapped in system lines or motor could result in cavitation that would cause system noise.	Ensure all system lines and components are purged of air.
Inspect output shaft couplings.	A loose or incorrect shaft coupling will produce vibrations that could result in system noise.	Ensure correct coupling is used and that it fits properly on shaft.
Inspect output shaft alignment.	Misaligned shafts create excessive frictional vibration that could result in system noise.	Ensure shafts are properly aligned.
Hydraulic oil viscosity above limits.	Viscosity above acceptable limits will result in cavitation that would lead to system noise.	Replace hydraulic oil with appropriate fluid for operating conditions.

Table 3-3. System Operating Hot

Item	Description	Action
Check oil level in reservoir and oil supply to pump.	Insufficient amount of hydraulic fluid will not meet system cooling demands.	Fill reservoir to proper level.
Inspect heat exchanger, (if equipped).	If heat exchanger fails, or becomes obstructed, it may not meet system cooling demands.	Ensure heat exchanger is receiving adequate air flow and is in good operating condition. Repair or replace as necessary.
Check system relief valves.	If a system relief valve becomes unseated for an extended period of time or fails for any other reason, system could become overheated.	Repair or replace any malfunctioning relief valves as applicable and verify loads on machine are not excessive.

Table 3-4. Won't Shift or Slow to Start

Item	Description	Action
Check signal line to servo control port.	Obstructed or restricted flow through servo control signal lines could result in slow shift or no shift motor conditions.	Ensure signal lines are not obstructed or restricted and signal pressure is adequate to shift motor.
Check correct supply and drain orifices are properly installed and not obstructed.	Supply and drain orifices determine motor shift. The smaller the orifice, the longer the time it takes to shift the motor. Obstruction also increases shift times.	Ensure proper control orifices are installed in motor and not obstructed. Clean or replace as necessary.

Initial Start-up

Follow this procedure when starting-up a new motor or when installing a motor that has been removed.

NOTICE

INSPECT MOTOR FOR DAMAGE BEFORE INSTALLATION. MAKE CERTAIN ALL SYSTEM COMPONENTS (RESERVOIR, HOSES, VALVES, FITTINGS, HEAT EXCHANGER, ETC.) ARE CLEAN BEFORE FILLING WITH FLUID.

1. Fill reservoir with recommended hydraulic fluid. Always filter fluid through a 10 micron filter when pouring into the reservoir. Never reuse hydraulic fluid.
2. Fill inlet line leading from pump to reservoir. Check inlet line for properly tightened fittings and be certain it is free of restrictions and air leaks.
3. Fill pump and motor housing with clean hydraulic fluid. Pour filtered oil directly in upper most case drain port.
4. To ensure pump and motor stay filled with oil, install case drain lines in upper most case drain ports.
5. Install a 0 to 500 psi (0 to 35 bar) gauge in charge pressure gauge port of pump to monitor system pressure during start up.
6. Watching pressure gauge and run engine at lowest possible speed until system pressure builds to normal levels (minimum 160 psi [11 bar]). Once system pressure is established, increase to full operating speed. If system pressure is not maintained, shut down engine, determine cause, and take corrective action.
7. Operate hydraulic system for at least fifteen minutes under light load conditions.
8. Check and adjust control settings as necessary after installation.
9. Shut down engine and remove pressure gauge. Replace plug at charge pressure gauge port.
10. Check the fluid level in the reservoir; add clean filtered fluid if necessary.

Go to Discount-Equipment.com to order your parts

3.16 SWING DRIVE HUB

Removal

Prior to remove swing drive from turntable base plate, we need to remove drive hub pinion shield plate.

1. Remove bolts (2), washers (7) and nuts (3).
2. Remove pinion shield plate (8) from bottom of turntable base plate.
3. Gently loosen the setscrew (5). Do not remove.
4. Remove the bolts (1) and pivot spacers bar (9).
5. Remove the mounting bolts (8) securing swing drive hub to the turntable.

6. Using the suitable lifting device, remove the swing drive hub from mounting plate without damaging the swing gear.


7. Place swing drive hub in the clean area.

Assembly/Disassembly

For detail assembly/disassembly instructions, Refer Swing Drive Hub Manual or contact JLG service for more details.

Installation

Ensure mounting plate and mounting location of the base plate are clean and painted with a uniform coating of minimum thickness (no runs, drips, etc.).



1. Bolt 3/4x2-1/2 in. Grade 8
2. Bolt M10x50 in.
3. Nut M10

4. Nut 5/8 in.
5. Setscrew
6. Washer

7. Washer M10
8. Pinion Shield Plate
9. Pivot Spacers Bar

10. Swing Drive Hub Assembly
11. Shim

Figure 3-17. Swing Drive Installation


3.17 SWING DRIVE

NOTE: SERVICE INFORMATION NOT AVAILABLE AT TIME OF PUBLICATION.

Go to Discount-Equipment.com to order your parts

NOTE: SERVICE INFORMATION NOT AVAILABLE AT TIME OF PUBLICATION.

Go to Discount-Equipment.com to order your parts



1001153984-E
MAF31340E

Figure 3-18. Swing Motor - Sheet 1 of 2

- | | | | | |
|---------------------|--------------------|--------------------|------------------|-----------------|
| 1. Shaft | 11. O-Ring | 21. Reduction Gear | 31. Input Shaft | 41. O-Ring |
| 2. Ring | 12. Planetary Ring | 22. Pinion | 32. Steel Disc | 42. Cover |
| 3. Oil Seal | 13. Reduction Gear | 23. Ring | 33. Disc | 43. Screw |
| 4. Bearing | 14. Pinion | 24. Washer | 34. Seal | 44. O-Ring |
| 5. Plug with O-Ring | 15. Spacer | 25. Brake Housing | 35. O-Ring | 45. Lifting Lug |
| 6. Output Support | 16. Spring Pin | 26. Plug | 36. Spacer | 46. Lock Washer |
| 7. Plug with O-Ring | 17. Spacer | 27. Plug | 37. Seal | 47. Capscrew |
| 8. Bearing | 18. Capscrew | 28. Capscrew | 38. O-Ring | 48. Capscrew |
| 9. Washer | 19. O-Ring | 29. Plug | 39. Piston Brake | 49. Motor |
| 10. Nut Ring | 20. Planetary Ring | 30. Washer | 40. Spring Brake | 50. O-Ring |

Figure 3-19. Swing Motor - Sheet 2 of 2

3.18 SWING BRAKE


NOTE: SERVICE INFORMATION NOT AVAILABLE AT TIME OF PUBLICATION.

Go to Discount-Equipment.com to order your parts


3.19 SETTING SWING GEAR BACKLASH

Set backlash 0.10 to 0.15" (0.254 to 0.381 mm) using the following procedure.

1. Place machine on firm, level ground.
2. Place shim between pinion and bearing on bearing high spot.




3. Apply High Strength Threadlocking Compound to bolt. Torque bolts to 340 ft. lbs. (461 Nm).




NOTE: Make sure turntable is properly supported during the following step. The turntable can swing a few degrees when turntable lock is removed if turntable is not balanced.

4. Remove turntable lock pin.


5. Apply High Strength Threadlocking Compound to the bolts. Pre-torque the five bolts to 45 ft. lbs. (61 Nm).




6. Tighten setscrew until pinion is completely snug against shim and bearing. Back off setscrew.



7. Torque setscrew to 50 ft. lbs. (68 Nm).
8. Apply High Strength Threadlocking Compound. Tighten jam nut.
9. Torque bolts to 340 ft. lbs. (461 Nm).



10. Discard shim.



11. Rotate bearing high spot 15 degree to the second drive hub. Repeat step 1 thru 10 for backlash setting.

Turntable Bearing Mounting Bolt Condition Check

NOTICE

THE SWING BEARING IS ONE OF THE MOST CRITICAL POINTS ON A MOBILE ELEVATING WORK PLATFORM. IT IS HERE THAT THE STRESSES OF LIFTING ARE CONCENTRATED, AT THE CENTER OF ROTATION. BECAUSE OF THIS, PROPER MAINTENANCE OF THE SWING BEARING BOLTS IS A MUST FOR SAFE OPERATION.

NOTE: This check is designed to replace the existing bearing bolt torque checks on JLG Lifts in service. This check must be performed after the first 50 hours of machine operation and every 600 hours of machine operation thereafter. If during this check any bolts are found to be missing or loose, replace missing or loose bolts with new bolts and torque to the value specified in the torque chart, after applying High Strength Threadlocking Compound to the bolt threads. After replacing and retorquing bolt or bolts recheck all existing bolts for looseness.

1. Check the frame to bearing attach bolts as follows:
 - a. Fully elevate the main boom. See Position 2, Figure 3-22.
 - b. At the position indicated on Figure 3-22., try to insert a 0.0015 in. feeler gauge between the bolt and hardened washer at the arrow indicated position.

- c. Ensure that the 0.0015 in. feeler gauge will not penetrate under the bolt head to the bolt shank.
- d. Swing the turntable 90 degrees, and check some selected bolts at the new position.
- e. Continue rotating the turntable at 90 degree intervals until a sampling of bolts have been checked in all quadrants.

2. Check the turntable to bearing attach bolts as follows:
 - a. Elevate the fully retracted main boom to full elevation.
 - b. At the position indicated on Figure 3-20. try to insert the 0.0015 in. feeler gauge between the bolt head and hardened washer at the arrow indicated position.
 - c. Lower the boom to horizontal and fully extend the boom.
 - d. At the position indicated on Position 1, Figure 3-22., try and insert the 0.0015 in. feeler gauge between the bolt head and hardened washer at the arrow indicated position.




Figure 3-20. Swing Bolt Feeler Gauge Check

3.20 SWING BEARING TORQUE VALUES

1. Outer Race - 708 ft.lbs. (960 Nm) w/ High Strength Threadlocking Compound.
2. Inner Race - 708 ft.lbs. (960 Nm) w/ High Strength Threadlocking Compound.

3. See Figure 3-21. Swing Bearing Torquing Sequence.

⚠ WARNING

CHECK THE INNER AND OUTER SWING BEARING BOLTS FOR MISSING OR LOOSENESS AFTER FIRST 50 HOURS OF OPERATION, AND EVERY 600 HOURS THEREAFTER.





Figure 3-21. Swing Bearing Torquing Sequence

3.21 SWING BEARING WEAR TOLERANCE

See Figure 3-22., *Swing Bearing Wear Tolerance*.

1. Position the machine as follows and as seen in Figure 3-22., *Swing Bearing Wear Tolerance*, Position 1:
 - a. Ensure the axles are extended
 - b. The turntable needs to be centered between the rear wheels
 - c. Fully elevate the tower boom
 - d. Lower the main boom to be horizontal
 - e. Extend the main boom until it stops
 - f. Lower the jib to horizontal
 - g. Keep the jib and platform centered and unloaded
2. Set up a dial indicator as follows:
 - a. The dial indicator location is to be at the front center of the machine, next to the bearing, opposite of the tower pivot pin.
 - b. The magnetic base of the indicator should be positioned on the frame



- c. The indicator point needs positioned to measure the turntable base plate 2.5 inches from the root of the gear tooth. Refer to Figure 3-22., *Swing Bearing Wear Tolerance*.
3. Zero the dial indicator.
4. Check dial indicator accuracy once positioned, using a feeler gauge and ensure the dial indicator reading, is the same as the feeler gauge thickness.

5. Position the machine as follows and as seen in Figure 3-30., *Swing Bearing Wear Tolerance*, Position 2:
 - a. Do not rotate the turntable
 - b. The tower boom needs to be stowed
 - c. Raise the main boom to be fully elevated and retracted
 - d. Raise the jib to be fully elevated and centered
 - e. Center the platform and keep it unloaded
6. Verify the dial indicator has not shifted. Record the value for bearing play.
7. Return the machine to Figure 3-22., *Swing Bearing Wear Tolerance*, Position 1. The dial indicator should to return to zero. If the dial indicator does not return to zero, take corrective action and repeat the test.
8. If the measurement is more than 0.165 in. (4.2 mm), replace the bearing. If the measurement is less than 0.165 in. (4.2 mm), and any of the following conditions exist, the bearing should be removed, disassembled, and inspected.
 - a. Metal particles in the grease.
 - b. Increased drive power required.
 - c. Noise.
 - d. Rough rotation.
9. If bearing inspection shows no defects, reassemble and return to service.




Figure 3-22. Swing Bearing Wear Tolerance




Figure 3-23. Swing Bearing Removal - Sheet 1 of 4




Figure 3-24. Swing Bearing Removal - Sheet 2 of 4




Figure 3-25. Swing Bearing Removal - Sheet 3 of 4