



An Oshkosh Corporation Company



www.Discount-Equipment.com

Service and Maintenance Manual

Models 660SJC

PVC 2001

PN-31215037


December 26, 2019 - Rev A

ANSI

CE



AS/NZS



PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your information and we will search our manual library for you.

* Brand:

* Model:

* Serial:

* Part Number:

SEARCH

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information:

| | |
|------------------------|----------------------|
| Manufacturer: | <input type="text"/> |
| Model: | <input type="text"/> |
| Description: | <input type="text"/> |
| Part Number: | <input type="text"/> |
| Quantity: | <input type="text"/> |
| Part Name: | <input type="text"/> |
| Part Description: | <input type="text"/> |
| Part Location: | <input type="text"/> |
| Part Condition: | <input type="text"/> |
| Part Status: | <input type="text"/> |
| Part Material: | <input type="text"/> |
| Part Color: | <input type="text"/> |
| Part Weight: | <input type="text"/> |
| Part Length: | <input type="text"/> |
| Part Width: | <input type="text"/> |
| Part Height: | <input type="text"/> |
| Part Diameter: | <input type="text"/> |
| Part Thickness: | <input type="text"/> |
| Part Volume: | <input type="text"/> |
| Part Area: | <input type="text"/> |
| Part Perimeter: | <input type="text"/> |
| Part Circumference: | <input type="text"/> |
| Part Surface Area: | <input type="text"/> |
| Part Volume: | <input type="text"/> |
| Part Weight: | <input type="text"/> |
| Part Density: | <input type="text"/> |
| Part Specific Gravity: | <input type="text"/> |
| Part Melting Point: | <input type="text"/> |
| Part Boiling Point: | <input type="text"/> |
| Part Freezing Point: | <input type="text"/> |
| Part Boiling Point: | <input type="text"/> |
| Part Freezing Point: | <input type="text"/> |
| Part Boiling Point: | <input type="text"/> |
| Part Freezing Point: | <input type="text"/> |

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION A. INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS

A GENERAL

This section contains general safety precautions which must be observed during mobile elevating work platform maintenance. It is of utmost importance that maintenance personnel pay strict attention to these warnings and precautions to avoid possible injury to themselves or others, or damage to the equipment. A maintenance program must be followed to ensure the machine is safe to operate.

⚠ WARNING

MODIFICATION OR ALTERATION OF A MOBILE ELEVATING WORK PLATFORM SHALL BE MADE ONLY WITH WRITTEN PERMISSION FROM THE MANUFACTURER.

The specific precautions to be observed during maintenance are inserted at the appropriate point in the manual. These precautions are, for the most part, those that apply when servicing hydraulic and larger machine component parts.

Your safety, and that of others, is the first consideration when engaging in maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure adequate support is provided.

⚠ WARNING

SINCE THE MACHINE MANUFACTURER HAS NO DIRECT CONTROL OVER THE FIELD INSPECTION AND MAINTENANCE, SAFETY IN THIS AREA RESPONSIBILITY OF THE OWNER/OPERATOR.

B HYDRAULIC SYSTEM SAFETY

It should be noted the machines hydraulic systems operate at extremely high potentially dangerous pressures. Every effort should be made to relieve any system pressure prior to disconnecting or removing any portion of the system.

Do not use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks. Wear gloves to help protect hands from spraying fluid.



C MAINTENANCE

⚠ WARNING

FAILURE TO COMPLY WITH SAFETY PRECAUTIONS LISTED IN THIS SECTION COULD RESULT IN MACHINE DAMAGE, PERSONNEL INJURY OR DEATH AND IS A SAFETY VIOLATION.

- USE ONLY REPLACEMENT PARTS OR COMPONENTS THAT ARE APPROVED BY JLG. TO BE CONSIDERED APPROVED, REPLACEMENT PARTS OR COMPONENTS MUST BE IDENTICAL OR EQUIVALENT TO ORIGINAL PARTS OR COMPONENTS.
- ENSURE REPLACEMENT PARTS OR COMPONENTS ARE IDENTICAL OR EQUIVALENT TO ORIGINAL PARTS OR COMPONENTS.
- NO SMOKING IS MANDATORY. NEVER REFUEL DURING ELECTRICAL STORMS. ENSURE THAT FUEL CAP IS CLOSED AND SECURE AT ALL OTHER TIMES.
- REMOVE ALL RINGS, WATCHES AND JEWELRY WHEN PERFORMING ANY MAINTENANCE.
- DO NOT WEAR LONG HAIR UNRESTRAINED, OR LOOSE-FITTING CLOTHING AND NECKTIES WHICH ARE APT TO BECOME CAUGHT ON OR ENTANGLED IN EQUIPMENT.
- OBSERVE AND OBEY ALL WARNINGS AND CAUTIONS ON MACHINE AND IN SERVICE MANUAL.
- KEEP OIL, GREASE, WATER, ETC. WIPED FROM STANDING SURFACES AND HAND HOLDS.
- USE CAUTION WHEN CHECKING A HOT, PRESSURIZED COOLANT SYSTEM.
- NEVER WORK UNDER AN ELEVATED BOOM UNTIL BOOM HAS BEEN SAFELY RESTRAINED FROM ANY MOVEMENT BY BLOCKING OR OVERHEAD SLING, OR BOOM SAFETY PROP HAS BEEN ENGAGED.
- BEFORE MAKING ADJUSTMENTS, LUBRICATING OR PERFORMING ANY OTHER MAINTENANCE, SHUT OFF ALL POWER CONTROLS.
- ALWAYS DISCONNECT BATTERY DURING REPLACEMENT OF ELECTRICAL COMPONENTS.
- KEEP ALL SUPPORT EQUIPMENT AND ATTACHMENTS STOWED IN THEIR PROPER PLACE.
- USE ONLY APPROVED, NONFLAMMABLE CLEANING SOLVENTS.

REVISION LOG

Original Issue

A - December 26, 2019

Go to Discount-Equipment.com to order your parts

| SECTION NO. | TITLE | PAGE NO. |
|--|---|-----------------|
| SECTION A - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS | | |
| A | General | A-1 |
| B | Hydraulic System Safety | A-1 |
| C | Maintenance | A-1 |
| SECTION 1 - SPECIFICATIONS | | |
| 1.1 | Operating Specifications | 1-1 |
| | Machine Specifications | 1-1 |
| 1.2 | Dimensional Data | 1-1 |
| 1.3 | Capacities | 1-1 |
| 1.4 | Engine Data | 1-1 |
| 1.5 | Critical Stability Weights | 1-2 |
| 1.6 | Hydraulic Oil | 1-2 |
| 1.7 | Torque Requirements | 1-3 |
| 1.8 | Maintenance and Lubrication | 1-6 |
| 1.9 | Thread Locking Compound | 1-10 |
| 1.10 | Torque Charts | 1-11 |
| | SAE Fastener Torque Chart | 1-11 |
| | Metric Fastener Torque Chart | 1-17 |
| SECTION 2 - GENERAL | | |
| 2.1 | Machine Preparation, Inspection and Maintenance | 2-1 |
| | General | 2-1 |
| | Preparation, Inspection and Maintenance | 2-1 |
| | Pre-Start Inspection | 2-1 |
| | Pre-Delivery Inspection and Frequent Inspection | 2-1 |
| | Annual Machine Inspection | 2-1 |
| | Preventive Maintenance | 2-1 |
| 2.2 | Service and Guidelines | 2-2 |
| | General | 2-2 |
| | Safety and Workmanship | 2-2 |
| | Cleanliness | 2-2 |
| | Components Removal and Installation | 2-2 |
| | Component Disassembly and Reassembly | 2-3 |
| | Pressure-Fit Parts | 2-3 |
| | Bearings | 2-3 |
| | Gaskets | 2-3 |
| | Bolt Usage and Torque Application | 2-3 |
| | Hydraulic Lines and Electrical Wiring | 2-3 |
| | Hydraulic System | 2-3 |
| | Lubrication | 2-4 |
| | Battery | 2-4 |
| | Lubrication and Servicing | 2-4 |
| 2.3 | Lubrication and Information | 2-4 |
| | Hydraulic System | 2-4 |
| | Hydraulic Oil | 2-4 |
| | Changing Hydraulic Oil | 2-4 |
| | Lubrication Specifications | 2-4 |
| 2.4 | Cylinder Drift | 2-5 |
| | Theory | 2-5 |
| | Cylinder Leakage Test | 2-5 |
| | Cylinder Thermal Drift | 2-5 |
| 2.5 | Pins and Composite Bearing Repair Guidelines | 2-6 |
| 2.6 | Welding on JLG Equipment | 2-6 |
| | Do the Following When Welding on JLG Equipment: | 2-6 |
| | Do NOT Do the Following When Welding on JLG Equipment | 2-6 |

TABLE OF CONTENTS

| SECTION NO. | TITLE | PAGE NO. |
|--|--|----------|
| SECTION 3 - CHASSIS & TURNTABLE | | |
| 3.1 | Chassis Tilt Indicator System | 3-1 |
| 3.2 | Auxiliary Power System | 3-1 |
| 3.3 | Drive Orientation System | 3-1 |
| 3.4 | Chassis Components and Servicing | 3-2 |
| | Service Notes | 3-3 |
| | Track and Chain | 3-5 |
| | Replace Track | 3-6 |
| | Track tensioning | 3-7 |
| | Rubber Track Pad Installation | 3-7 |
| | Rollers | 3-10 |
| | Idler Roller Assembly | 3-11 |
| 3.5 | Swing Drive Hub | 3-14 |
| | Removal | 3-14 |
| | Assembly/Disassembly | 3-14 |
| | Installation | 3-14 |
| | Procedure For Setting Swing Gear Backlash | 3-15 |
| | Swing Drive Lubrication | 3-15 |
| 3.6 | Swing Bearing | 3-16 |
| | Turntable Bearing Mounting Bolt Condition Check | 3-16 |
| | Wear Tolerance | 3-16 |
| | Swing Bearing Replacement | 3-18 |
| | Swing Bearing Torque Values | 3-19 |
| 3.7 | Rotary Coupling | 3-22 |
| | Assembly/Disassembly | 3-22 |
| 3.8 | Deutz TD2.9 L4 Engine | 3-24 |
| | Check Oil Level | 3-28 |
| | Change Engine Oil | 3-28 |
| | Change Oil Filter | 3-28 |
| | Change Fuel Filters | 3-29 |
| | Spark Arrester Cleaning Instructions | 3-29 |
| | Glow Plugs | 3-29 |
| | Replacing the Fuel Pre-Filter | 3-30 |
| | Water in Fuel Sensing System (Optional) | 3-30 |
| | Draining Water | 3-30 |
| | Auxiliary Fuel Filter | 3-31 |
| 3.9 | Deutz D2011L04 Engine | 3-53 |
| | Checking Oil Level | 3-57 |
| | Changing Engine Oil | 3-57 |
| | Changing Oil Filter | 3-58 |
| | Replace Fuel Filter | 3-58 |
| | Clean Fuel Strainer | 3-59 |
| 3.10 | Spark Arrester Cleaning Instructions | 3-59 |
| 3.11 | Glow Plugs | 3-59 |
| 3.12 | Deutz TD 2.9 L4 GUO III Engine | 3-64 |
| 3.13 | Counterweight | 3-68 |
| 3.14 | Generator | 3-70 |
| | Every 250 hours | 3-70 |
| | Every 500 hours | 3-70 |
| | Overload Protection | 3-70 |
| | Inspecting Brushes, Replacing Brushes, and Cleaning Slip Rings | 3-71 |
| | Troubleshooting | 3-72 |
| | Generator Disassembly and Assembly | 3-73 |
| | Lead Connection List for Generator | 3-80 |

| SECTION NO. | TITLE | PAGE NO. |
|--|---|-----------------|
| SECTION 4 - BOOM & PLATFORM | | |
| 4.1 | Transport Position Sensing System | 4-1 |
| 4.2 | Beyond Transport - Drive Speed Cutback System | 4-1 |
| 4.3 | Dual Capacity System | 4-1 |
| 4.4 | Platform Load Sensing System | 4-1 |
| 4.5 | Electronic Platform Leveling | 4-1 |
| 4.6 | Fuel level Cutout System | 4-2 |
| 4.7 | Ground Control Keyswitch System | 4-2 |
| 4.8 | Function Speed Control System | 4-2 |
| 4.9 | Platform | 4-2 |
| | Support Removal | 4-2 |
| | Support Installation | 4-3 |
| 4.10 | Rotator and Slave Cylinder | 4-6 |
| | Removal | 4-6 |
| | Assembly/Disassembly | 4-6 |
| | Installation | 4-6 |
| 4.11 | Main Boom Assembly | 4-8 |
| | Removal | 4-8 |
| | Boom Disassembly | 4-10 |
| | Assembly | 4-13 |
| | Installation | 4-16 |
| 4.12 | Main Boom Lift Cylinder | 4-17 |
| | Removal | 4-17 |
| | Installation | 4-17 |
| 4.13 | Main Boom Powertrack | 4-18 |
| | Installation | 4-18 |
| 4.14 | Wire Rope | 4-20 |
| | Inspection | 4-20 |
| | Three Month Inspection | 4-21 |
| | Additional Inspection Required If: | 4-21 |
| | 12 Year or 7000 Hour Replacement | 4-21 |
| | Additional Replacement Criteria | 4-21 |
| 4.15 | Wire Rope Tensioning Adjustment | 4-21 |
| | Wire Rope Tensioning Procedure | 4-21 |
| 4.16 | Wire rope Service indicator | 4-22 |
| 4.17 | Jib Assembly | 4-22 |
| 4.18 | Boom Cleanliness Guidelines | 4-23 |
| 4.19 | Foot Switch Adjustment | 4-24 |
| 4.20 | Platform Control Enable System | 4-24 |
| 4.21 | Powertrack Maintenance | 4-25 |
| | Remove Link | 4-25 |
| | Install New Link | 4-28 |
| | Replace Fixed End Brackets | 4-31 |
| | Replace Moving End Brackets | 4-32 |
| 4.22 | Skyguard | 4-34 |
| | Operation | 4-34 |
| | Function Test | 4-34 |
| | Diagnostics & Troubleshooting | 4-35 |

TABLE OF CONTENTS

| SECTION NO. | TITLE | PAGE NO. |
|------------------|---|----------|
| SECTION 5 | - BASIC HYDRAULICS INFORMATION & SCHEMATICS | |
| 5.1 | Lubricating O-rings In The Hydraulic System | 5-1 |
| | Cup and Brush | 5-1 |
| | Dip Method | 5-2 |
| | Spray Method | 5-2 |
| | Brush-on Method..... | 5-2 |
| 5.2 | Hydraulic Connection Assembly and Torque Specification | 5-3 |
| | Tapered Thread Types | 5-3 |
| | Straight Thread Types, Tube and Hose Connections | 5-3 |
| | Straight Thread Types, Port Connections | 5-4 |
| | Flange Connection Types | 5-4 |
| | Tightening Methods..... | 5-4 |
| | Assembly And Torque Specifications | 5-5 |
| | Assembly Instructions for American Standard Pipe Thread Tapered (NPTF) Connections..... | 5-6 |
| | Assembly Instructions for British Standard Pipe Thread Tapered (BSPT) Connections..... | 5-7 |
| | Assembly Instructions for 37° (JIC) Flare Fittings | 5-8 |
| | Assembly Instructions for 45° SAE Flare Fittings..... | 5-12 |
| | Assembly Instructions for O-Ring Face Seal (ORFS) Fittings..... | 5-14 |
| | Assembly Instructions for DIN 24° Flare Bite Type Fittings (MBTL and MBTS) | 5-16 |
| | Assembly Instructions for Bulkhead (BH) Fittings | 5-18 |
| | Assembly Instructions for O-Ring Boss (ORB) Fittings | 5-22 |
| | Assembly Instructions for Adjustable Port End Metric (MFF) Fittings..... | 5-30 |
| | Assembly Instructions for Metric ISO 6149 (MPP) Port Assembly Stud Ends | 5-38 |
| | Assembly instructions for Adjustable Port End (BSPP) Fittings | 5-40 |
| | Assembly Instructions for Flange Connections: (FL61 and FL62) | 5-48 |
| | Double Wrench Method | 5-51 |
| | FFWR and TFFT Methods..... | 5-52 |
| | Adjustable Stud End Assembly..... | 5-52 |
| | O-ring Installation (Replacement) | 5-53 |
| | Cylinder Locations..... | 5-54 |
| | Main Lift Cylinder..... | 5-55 |
| | Telescope Cylinder | 5-60 |
| | Platform Level Cylinder..... | 5-65 |
| | Jib Lift Cylinder..... | 5-70 |
| 5.3 | Hydraulic Pump (Gear)..... | 5-71 |
| | Removal | 5-71 |
| | Assembly/Disassembly | 5-71 |
| | Installation | 5-71 |
| 5.4 | Variable Pump | 5-72 |
| | Removal | 5-72 |
| | Assembly/Disassembly | 5-72 |
| | Installation | 5-72 |
| 5.5 | Main Valve Block Pressure Setting Procedure | 5-73 |
| | Load Sense Compensator | 5-73 |
| | Main Relief Valve | 5-73 |
| | Load Sense Relief Valve | 5-73 |
| | Turntable Swing Relief Valve | 5-73 |
| 5.6 | Platform Valve Block Pressure Setting Procedure | 5-75 |
| | Main High Pressure Relief Valve | 5-75 |
| | Low Pressure Relief Valve | 5-75 |
| | Platform Jib Down Relief Valve..... | 5-75 |
| 5.7 | Hydraulic Schematics..... | 5-82 |

| SECTION NO. | TITLE | PAGE NO. |
|---|---|-----------------|
| SECTION 6 - JLG CONTROL SYSTEM | | |
| 6.1 | JLG Control System Analyzer Kit Instructions | 6-1 |
| | Connect JLG Control System Analyzer | 6-2 |
| | Using Analyzer | 6-2 |
| | Changing Access Level | 6-3 |
| | Adjust Parameters | 6-4 |
| | Machine Setup | 6-5 |
| | Level Vehicle Description | 6-5 |
| 6.2 | Machine Personality Settings | 6-37 |
| 6.3 | Machine Orientation When Setting Function Speeds | 6-40 |
| | Test Notes | 6-40 |
| 6.4 | CANBUS Communications | 6-41 |
| 6.5 | System Test | 6-42 |
| | Test from the Platform | 6-42 |
| 6.6 | System Test Messages | 6-47 |
| 6.7 | Machine Diagnostics Parameters | 6-49 |
| 6.8 | Calibrating Tilt Sensor | 6-62 |
| 6.9 | Calibrating Boom Angle | 6-66 |
| 6.10 | Calibrating Level Up Crackpoint | 6-71 |
| 6.11 | Calibrating Level Down Crackpoint | 6-73 |
| 6.12 | Calibrating Platform Angle Sensor | 6-75 |
| 6.13 | Resetting The MSSO System | 6-79 |
| 6.14 | LSS System | 6-81 |
| | Diagnostic Menu | 6-82 |
| | Calibration Procedure | 6-83 |
| | Testing & Evaluation | 6-87 |
| | LSS Service Mode | 6-88 |
| | LSS Service Mode Event Log | 6-88 |
| | Troubleshooting | 6-89 |
| 6.15 | Machine Fault Codes | 6-90 |
| SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS | | |
| 7.1 | General | 7-1 |
| 7.2 | Multimeter Basics | 7-1 |
| | Grounding | 7-1 |
| | Backprobing | 7-1 |
| | Min/Max | 7-1 |
| | Polarity | 7-1 |
| | Scale | 7-1 |
| | Voltage Measurement | 7-1 |
| | Resistance Measurement | 7-2 |
| | Continuity Measurement | 7-2 |
| | Current Measurement | 7-3 |
| 7.3 | Applying Silicone Dielectric Compound to Electrical Connections | 7-3 |
| 7.4 | Dielectric Grease Application | 7-4 |
| | Installation | 7-4 |
| | AMP Mate-N-Lok | 7-4 |
| | AMP Faston | 7-4 |
| | AMP Micro-Fit | 7-4 |
| | AMP Mini Fit Jr | 7-5 |
| | Mini Fit Sr | 7-5 |
| | DIN Connectors | 7-5 |
| | Exceptions | 7-5 |
| | Enclosures | 7-5 |
| | Carling Switch Connectors | 7-5 |

TABLE OF CONTENTS

| SECTION NO. | TITLE | PAGE NO. |
|--------------------|-------------------------------------|-----------------|
| 7.5 | AMP Connector | 7-6 |
| | Assembly | 7-6 |
| | Disassembly | 7-8 |
| | Wedge Lock | 7-8 |
| | Service - Voltage Reading | 7-8 |
| 7.6 | Deutsch Connectors | 7-10 |
| | DT/DTP Series Assembly | 7-10 |
| | DT/DTP Series Disassembly | 7-10 |
| | HD30/HDP20 Series Assembly | 7-11 |
| | HD30/HDP20 Series Disassembly | 7-11 |
| 7.7 | Telematics Gateway | 7-12 |
| | Telematics-Ready (TCU) Plug | 7-13 |
| 7.8 | Wiring Harness | 7-17 |
| | Connector Labels | 7-17 |
| | Component Labels | 7-17 |
| 7.9 | Wiring Harness | 7-19 |
| 7.10 | Electrical Schematics | 7-129 |

Go to Discount-Equipment.com to order your parts

| FIGURE NO. | TITLE | PAGE NO. |
|------------|--|----------|
| 1-1. | Maintenance and Lubrication Diagram - Deutz D2011L04 | 1-4 |
| 1-2. | Maintenance and Lubrication Diagram - Deutz TD 2.9 and TD 2.9 L4 GUO III..... | 1-5 |
| 2-1. | Engine Operating Temperature Specifications - Deutz D2011L04 | 2-10 |
| 2-2. | Engine Operating Temperature Specifications - Deutz TD2.9..... | 2-11 |
| 2-3. | Hydraulic Oil Operating Temperature Specifications..... | 2-12 |
| 3-1. | Chassis Assembly | 3-2 |
| 3-2. | Chassis Service Notes - 1 of 2 | 3-3 |
| 3-3. | Chassis Service Notes - 2 of 2 | 3-4 |
| 3-4. | Bottom Track Roller Assembly | 3-8 |
| 3-5. | Upper Carrier Track Roller Assembly | 3-9 |
| 3-6. | Idler Assembly | 3-11 |
| 3-7. | Spring & Shock Assembly..... | 3-12 |
| 3-8. | Swing Drive Installation | 3-14 |
| 3-9. | Swing Bearing Bolt Feeler Gauge Check..... | 3-16 |
| 3-10. | Swing Bearing Tolerance Measuring Point | 3-16 |
| 3-11. | Swing Bearing Tolerance Measurement Location & Boom Placement | 3-17 |
| 3-12. | Swing Bearing Torque Sequence | 3-19 |
| 3-13. | Swing Bearing Removal | 3-20 |
| 3-14. | Rotary Coupling Installation | 3-22 |
| 3-15. | Rotary Coupling - Drive Orientation..... | 3-23 |
| 3-16. | Deutz TD2.9 L4 Engine Installation..... | 3-24 |
| 3-17. | Deutz TD2.9 L4 Engine and Pumps Sub-Assembly..... | 3-25 |
| 3-18. | Deutz TD2.9 L4 Engine Assembly - Sheet 1 of 2..... | 3-26 |
| 3-19. | Deutz TD2.9 L4 Engine Assembly - Sheet 2 of 2..... | 3-27 |
| 3-20. | Deutz 2.9 T4F Dipstick Markings | 3-28 |
| 3-21. | Engine Oil Viscosity | 3-28 |
| 3-22. | Location of Fuel Pre-Filter | 3-30 |
| 3-23. | Components of Fuel Pre-Filter | 3-30 |
| 3-24. | Components of Auxiliary Fuel Filter..... | 3-31 |
| 3-25. | Deutz D2011 Engine Installation..... | 3-53 |
| 3-26. | Deutz D2011 Engine and Pumps Sub-Assembly | 3-54 |
| 3-27. | Deutz D2011 Engine Assembly - Sheet 1 of 2..... | 3-55 |
| 3-28. | Deutz D2011 Engine Assembly - Sheet 2 of 2..... | 3-56 |
| 3-29. | Deutz Dipstick Markings..... | 3-57 |
| 3-30. | Engine Oil Viscosity | 3-57 |
| 3-31. | Deutz TD 2.9 L4 GUO III Engine Installation..... | 3-64 |
| 3-32. | Deutz TD 2.9 L4 GUO III Engine and Pumps Sub-Assembly | 3-65 |
| 3-33. | Deutz TD 2.9 L4 GUO III Engine Assembly - Sheet 1 of 2..... | 3-66 |
| 3-34. | Deutz TD 2.9 L4 GUO III Engine Assembly - Sheet 2 of 2..... | 3-67 |
| 3-35. | Counterweight Bolt Torque | 3-68 |
| 3-36. | Counterweight Bolt Torque | 3-69 |
| 3-37. | Generator Belt Tension | 3-70 |
| 3-38. | Generator Brushes and Slip Rings..... | 3-70 |
| 3-39. | Generator Cleaning | 3-70 |
| 3-40. | Generator Circuit Breaker Location (If Equipped with 2500W and 4000W)..... | 3-70 |
| 3-41. | Generator Circuit Breaker Location (If Equipped with 7500W)..... | 3-70 |
| 3-42. | Inspecting Generator Brushes, Replacing Brushes, and Cleaning Slip Rings | 3-71 |
| 3-43. | Generator Disassembly and Assembly | 3-73 |
| 3-44. | Generator Troubleshooting Circuit Diagram (Sheet 1 of 2)..... | 3-74 |
| 3-45. | Generator Troubleshooting Circuit Diagram (Sheet 2 of 2)..... | 3-75 |
| 3-46. | Generator Electrical Circuit Diagram | 3-76 |
| 3-47. | Power Board PC1 Electrical Circuit Diagram | 3-77 |
| 3-48. | Power Board PC2 Electrical Circuit Diagram (Sheet 1 of 2)..... | 3-78 |
| 3-49. | Power Board PC2 Electrical Circuit Diagram (Sheet 2 of 2)..... | 3-79 |
| 4-1. | Platform Support Torque Values | 4-5 |
| 4-2. | Removal of Components - Rotator and Platform Level Cylinder | 4-7 |
| 4-3. | Boom Assembly Removal and Installation..... | 4-9 |

| FIGURE NO. | TITLE | PAGE NO. |
|-------------------|--|-----------------|
| 4-4. | Main Boom Lift Cylinder Removal and Installation | 4-17 |
| 4-5. | Powertrack Components | 4-18 |
| 4-6. | Boom Sensors Installation | 4-19 |
| 4-7. | Wire Rope Wire Breaks | 4-20 |
| 4-8. | Wire Rope Kink | 4-20 |
| 4-9. | Sheave Groove Wear | 4-20 |
| 4-10. | Dimensions of Boom Sections | 4-21 |
| 4-11. | Clamping Wire Ropes | 4-21 |
| 4-12. | Foot Switch Adjustment | 4-24 |
| 5-1. | NPTF Thread | 5-3 |
| 5-2. | BSPT Thread | 5-3 |
| 5-3. | JIC Thread | 5-3 |
| 5-4. | SAE Thread | 5-3 |
| 5-5. | ORFS Thread | 5-3 |
| 5-6. | MTBL-MBTS Thread | 5-3 |
| 5-7. | Bulkhead Thread | 5-3 |
| 5-8. | ORB-MPP Thread | 5-4 |
| 5-9. | MFF-BSPP Thread | 5-4 |
| 5-10. | FL61-FL62 | 5-4 |
| 5-11. | Torque Wrench Angle | 5-5 |
| 5-12. | Double Wrench Method | 5-51 |
| 5-13. | FFWR Method | 5-52 |
| 5-14. | Adjustable Stud End Assembly | 5-53 |
| 5-15. | Hydraulic Cylinder Locations | 5-54 |
| 5-16. | Cylinder Barrel Support | 5-55 |
| 5-17. | Cylinder Head Removal | 5-55 |
| 5-18. | Cylinder Rod Support | 5-55 |
| 5-19. | Main Lift Cylinder | 5-56 |
| 5-20. | Piston Disassembly | 5-57 |
| 5-21. | Cylinder Head Disassembly | 5-57 |
| 5-22. | Composite Bushing Installation | 5-58 |
| 5-23. | Cylinder Head Assembly | 5-58 |
| 5-24. | Piston Assembly | 5-59 |
| 5-25. | Cylinder Head Installation | 5-59 |
| 5-26. | Cylinder Barrel Support | 5-60 |
| 5-27. | Capscrew Removal | 5-60 |
| 5-28. | Cylinder Rod Support | 5-60 |
| 5-29. | Telescope Cylinder | 5-61 |
| 5-30. | Piston Disassembly | 5-62 |
| 5-31. | Cylinder Head Disassembly | 5-62 |
| 5-32. | Composite Bushing Installation | 5-63 |
| 5-33. | Rod Seal Installation | 5-63 |
| 5-34. | Cylinder Head Assembly | 5-64 |
| 5-35. | Piston Assembly | 5-64 |
| 5-36. | Cylinder Barrel Support | 5-65 |
| 5-37. | Marking Cylinder for Alignment | 5-65 |
| 5-38. | Cylinder Rod Support | 5-65 |
| 5-39. | Platform Level Cylinder | 5-66 |
| 5-40. | Piston Disassembly | 5-67 |
| 5-41. | Cylinder Head Disassembly | 5-67 |
| 5-42. | Composite Bushing Installation | 5-68 |
| 5-43. | Cylinder Head Seal Installation | 5-68 |
| 5-44. | Cylinder Head Assembly | 5-68 |
| 5-45. | Piston Seal Installation | 5-69 |
| 5-46. | Piston Assembly | 5-69 |
| 5-47. | Cylinder Head Installation | 5-69 |
| 5-48. | Jib Lift Cylinder Assembly | 5-70 |

| FIGURE NO. | TITLE | PAGE NO. |
|------------|--|----------|
| 5-49. | Hydraulic Pump Installation | 5-71 |
| 5-50. | Variable Pump Installation..... | 5-72 |
| 5-51. | Main Control Valve Block | 5-74 |
| 5-52. | Platform Control Valve Block | 5-76 |
| 5-53. | Main Control Valve..... | 5-77 |
| 5-54. | Main Control Valve Torque Values - Sheet 1 of 2..... | 5-78 |
| 5-55. | Main Control Valve Torque Values - Sheet 2 of 2..... | 5-79 |
| 5-56. | Platform Valve Torque Values..... | 5-80 |
| 5-57. | Hydraulic Schematic - Sheet 1 of 2..... | 5-82 |
| 5-58. | Hydraulic Schematic - Sheet 1 of 2..... | 5-83 |
| 6-1. | Hand Held Analyzer | 6-1 |
| 6-2. | ADE Block Diagram..... | 6-8 |
| 6-3. | Analyzer Software P2.14 - Sheet 1 of 14 | 6-9 |
| 6-4. | Analyzer Software P2.14 - Sheet 2 of 14 | 6-10 |
| 6-5. | Analyzer Software P2.14 - Sheet 3 of 14 | 6-11 |
| 6-6. | Analyzer Software P2.14 - Sheet 4 of 14 | 6-12 |
| 6-7. | Analyzer Software P2.14 - Sheet 5 of 14 | 6-13 |
| 6-8. | Analyzer Software P2.14 - Sheet 6 of 14 | 6-14 |
| 6-9. | Analyzer Software P2.14 - Sheet 7 of 14 | 6-15 |
| 6-10. | Analyzer Software P2.14 - Sheet 8 of 14 | 6-16 |
| 6-11. | Analyzer Software P2.14 - Sheet 9 of 14 | 6-17 |
| 6-12. | Analyzer Software P2.14 - Sheet 10 of 14 | 6-18 |
| 6-13. | Analyzer Software P2.14 - Sheet 11 of 14 | 6-19 |
| 6-14. | Analyzer Software P2.14 - Sheet 12 of 14 | 6-20 |
| 6-15. | Analyzer Software P2.14 - Sheet 13 of 14 | 6-21 |
| 6-16. | Analyzer Software P2.14 - Sheet 14 of 14 | 6-22 |
| 6-17. | Control Module Locations | 6-23 |
| 6-18. | Ground Control Module Pin Connections | 6-24 |
| 6-19. | Platform Control Module Pin Connections | 6-28 |
| 6-20. | System Test Flow Chart - Platform Tests (Sheet 1 of 2) | 6-43 |
| 6-21. | System Test Flow Chart - Platform Tests (Sheet 2 of 2) | 6-44 |
| 6-22. | System Test Flow Chart - Ground Station Tests | 6-46 |
| 7-1. | Voltage Measurement (DC) | 7-1 |
| 7-2. | Resistance Measurement | 7-2 |
| 7-3. | Continuity Measurement | 7-2 |
| 7-4. | Current Measurement (DC) | 7-3 |
| 7-5. | Connector Assembly Figure 1 | 7-6 |
| 7-6. | AMP Connector | 7-6 |
| 7-7. | Connector Assembly Figure 2 | 7-7 |
| 7-8. | Connector Assembly Figure 3 | 7-7 |
| 7-9. | Connector Assembly Figure 4 | 7-7 |
| 7-10. | Connector Disassembly | 7-8 |
| 7-11. | Connector Installation..... | 7-9 |
| 7-12. | DT/DTP Contact Installation | 7-10 |
| 7-13. | DT/DTP Contact Removal..... | 7-10 |
| 7-14. | HD/HDP Contact Installation | 7-11 |
| 7-15. | HD/HDP Locking Contacts Into Position..... | 7-11 |
| 7-16. | HD/HDP Contact Removal | 7-11 |
| 7-17. | HD/HDP Unlocking Contacts | 7-11 |
| 7-18. | Telematics Gateway Harness - Sheet 1 of 3 | 7-14 |
| 7-19. | Telematics Gateway Harness - Sheet 2 of 3 | 7-15 |
| 7-20. | Telematics Gateway Harness - Sheet 3 of 3 | 7-16 |
| 7-21. | Platform Box Harness - Sheet 1 of 6 | 7-19 |
| 7-22. | Platform Box Harness - Sheet 2 of 6 | 7-20 |
| 7-23. | Platform Box Harness - Sheet 3 of 6 | 7-24 |
| 7-24. | Platform Box Harness - Sheet 4 of 6 | 7-28 |
| 7-25. | Platform Box Harness - Sheet 5 of 6 | 7-32 |

LIST OF FIGURES

| FIGURE NO. | TITLE | PAGE NO. |
|------------|---|----------|
| 7-26. | Platform Box Harness - Sheet 6 of 6 | 7-35 |
| 7-27. | Main Boom Harness (With Jib) | 7-36 |
| 7-28. | Main Boom Harness (TT) | 7-37 |
| 7-29. | Proximity Switch Harness (Telescope In) | 7-38 |
| 7-30. | Boom Sensor Cable | 7-40 |
| 7-31. | Turntable Harness - Sheet 1 of 7 | 7-42 |
| 7-32. | Turntable Harness - Sheet 2 of 7 | 7-44 |
| 7-33. | Turntable Harness - Sheet 3 of 7 | 7-48 |
| 7-34. | Turntable Harness - Sheet 4 of 7 | 7-50 |
| 7-35. | Turntable Harness - Sheet 5 of 7 | 7-54 |
| 7-36. | Turntable Harness - Sheet 6 of 7 | 7-58 |
| 7-37. | Turntable Harness - Sheet 7 of 7 | 7-60 |
| 7-38. | Universal Ground Control Module Harness | 7-62 |
| 7-39. | Boom Angle Sensor Harness | 7-64 |
| 7-40. | Ground Control Harness - Sheet 1 of 2 | 7-66 |
| 7-41. | Ground Control Harness - Sheet 2 of 2 | 7-68 |
| 7-42. | Lift Cylinder Harness | 7-70 |
| 7-43. | Deutz D2011L04 Engine Harness - Sheet 1 of 3 | 7-72 |
| 7-44. | Deutz D2011L04 Engine Harness - Sheet 2 of 3 | 7-74 |
| 7-45. | Deutz D2011L04 Engine Harness - Sheet 3 of 3 | 7-76 |
| 7-46. | Deutz T4F Engine Harness - Sheet 1 of 5 | 7-78 |
| 7-47. | Deutz T4F Engine Harness - Sheet 2 of 5 | 7-80 |
| 7-48. | Deutz T4F Engine Harness - Sheet 3 of 5 | 7-84 |
| 7-49. | Deutz T4F Engine Harness - Sheet 4 of 5 | 7-88 |
| 7-50. | Deutz T4F Engine Harness - Sheet 5 of 5 | 7-91 |
| 7-51. | Chassis Head and Tail Lights Harness - Sheet 1 of 2 | 7-92 |
| 7-52. | Chassis Head and Tail Lights Harness - Sheet 2 of 2 | 7-94 |
| 7-53. | Chassis Work Lights Harness - Sheet 1 of 2 | 7-96 |
| 7-54. | Chassis Work Lights Harness - Sheet 2 of 2 | 7-98 |
| 7-55. | ClearSky Harness | 7-100 |
| 7-56. | Platform Valve w/Jib Harness - Sheet 1 of 3 | 7-102 |
| 7-57. | Platform Valve w/Jib Harness - Sheet 2 of 3 | 7-104 |
| 7-58. | Platform Valve w/Jib Harness - Sheet 3 of 3 | 7-106 |
| 7-59. | Skyguard GEN2 Platform Interface Harness | 7-108 |
| 7-60. | Boom Sensor Harness | 7-110 |
| 7-61. | Main Lift Harness | 7-112 |
| 7-62. | LSS Harness | 7-114 |
| 7-63. | Crawler Main Valve Harness - Sheet 1 of 4 | 7-116 |
| 7-64. | Crawler Main Valve Harness - Sheet 2 of 4 | 7-118 |
| 7-65. | Crawler Main Valve Harness - Sheet 3 of 4 | 7-122 |
| 7-66. | Crawler Main Valve Harness - Sheet 4 of 4 | 7-124 |
| 7-67. | Crawler Turntable Adapter Harness | 7-126 |
| 7-68. | Electrical Schematic - Sheet 2 of 19 | 7-130 |
| 7-69. | Electrical Schematic - Sheet 3 of 19 | 7-131 |
| 7-70. | Electrical Schematic - Sheet 4 of 19 | 7-132 |
| 7-71. | Electrical Schematic - Sheet 5 of 19 | 7-133 |
| 7-72. | Electrical Schematic - Sheet 6 of 19 | 7-134 |
| 7-73. | Electrical Schematic - Sheet 7 of 19 | 7-135 |
| 7-74. | Electrical Schematic - Sheet 8 of 19 | 7-136 |
| 7-75. | Electrical Schematic - Sheet 9 of 19 | 7-137 |
| 7-76. | Electrical Schematic - Sheet 10 of 19 | 7-138 |
| 7-77. | Electrical Schematic - Sheet 11 of 19 | 7-139 |
| 7-78. | Electrical Schematic - Sheet 12 of 19 | 7-140 |
| 7-79. | Electrical Schematic - Sheet 13 of 19 | 7-141 |
| 7-80. | Electrical Schematic - Sheet 14 of 19 | 7-142 |
| 7-81. | Electrical Schematic - Sheet 15 of 19 | 7-143 |
| 7-82. | Electrical Schematic - Sheet 16 of 19 | 7-144 |

| FIGURE NO. | TITLE | PAGE NO. |
|-------------------|---|-----------------|
| 7-83. | Electrical Schematic - Sheet 17 of 19 | 7-145 |
| 7-84. | Electrical Schematic - Sheet 18 of 19 | 7-146 |
| 7-85. | Electrical Schematic - Sheet 19 of 19 | 7-147 |

Go to Discount-Equipment.com to order your parts

| TABLE NO. | TITLE | PAGE NO. |
|------------------|--|-----------------|
| 1-1 | Deutz TD2.9 L4 | 1-1 |
| 1-2 | Deutz D2011L04 Specifications | 1-1 |
| 1-3 | Deutz TD 2.9 L4 GUO III Specifications | 1-2 |
| 1-4 | Mobilfluid 424 | 1-2 |
| 1-5 | Mobil DTE 10 Excel 32 | 1-2 |
| 1-6 | Quintolubric 888-46 | 1-3 |
| 1-7 | Mobil EAL 224 H | 1-3 |
| 1-8 | Mobil EAL EnviroSyn H 46 | 1-3 |
| 1-9 | Exxon Univis HVI 26 Specs | 1-3 |
| 1-10 | Lubrication Specifications | 1-6 |
| 2-1 | Inspection and Maintenance | 2-2 |
| 2-2 | Cylinder Drift | 2-5 |
| 2-3 | Inspection and Preventive Maintenance Schedule | 2-7 |
| 3-1 | Deutz Trouble Codes (TD2.9 L4 Engine) | 3-32 |
| 3-2 | Deutz Trouble Codes (D2011L04 Engine) | 3-60 |
| 3-3 | Troubleshooting | 3-72 |
| 3-4 | Lead Connection List for Generator | 3-80 |
| 4-1 | SkyGuard Function Table | 4-35 |
| 5-1 | NPTF Pipe Thread | 5-6 |
| 5-2 | BSPT Pipe Thread | 5-7 |
| 5-3 | 37° Flare (JIC) Thread - Steel | 5-9 |
| 5-4 | 37° Flare (JIC) Thread - Aluminum/Brass | 5-10 |
| 5-5 | 45° Flare (SAE) - Steel | 5-13 |
| 5-6 | 45° Flare (SAE) - Aluminum/Brass | 5-13 |
| 5-7 | O-ring Face Seal (ORFS) - Steel | 5-14 |
| 5-8 | O-ring Face Seal (ORFS) - Aluminum/Brass | 5-15 |
| 5-9 | DIN 24° Cone (MBTL & MBTS) | 5-17 |
| 5-10 | Bulkhead Fittings (BH) - INCH | 5-19 |
| 5-11 | Bulkhead Fittings (BH) - METRIC | 5-20 |
| 5-12 | O-ring Boss (ORB) - Table 1 of 6 | 5-23 |
| 5-13 | O-ring Boss (ORB) - Table 2 of 6 | 5-24 |
| 5-14 | O-ring Boss (ORB) - Table 3 of 6 | 5-25 |
| 5-15 | O-ring Boss (ORB) - Table 4 of 6 | 5-26 |
| 5-16 | O-ring Boss (ORB) - Table 5 of 6 | 5-27 |
| 5-17 | O-ring Boss (ORB) - Table 6 of 6 | 5-28 |
| 5-18 | Metric Flat Face Port (MFF) - L Series - Table 1 of 3 | 5-31 |
| 5-19 | Metric Flat Face Port (MFF) - L Series - Table 2 of 3 | 5-32 |
| 5-20 | Metric Flat Face Port (MFF) - L Series - Table 3 of 3 | 5-33 |
| 5-21 | Metric Flat Face Port (MFF) - S Series - Table 1 of 3 | 5-34 |
| 5-22 | Metric Flat Face Port (MFF) - S Series - Table 2 of 3 | 5-35 |
| 5-23 | Metric Flat Face Port (MFF) - S Series - Table 3 of 3 | 5-36 |
| 5-24 | Metric Pipe Parallel O-Ring Boss (MPP) | 5-39 |
| 5-25 | British Standard Parallel Pipe Port (BSPP) - L Series - Table 1 of 3 | 5-41 |
| 5-26 | British Standard Parallel Pipe Port (BSPP) - L Series - Table 2 of 3 | 5-42 |
| 5-27 | British Standard Parallel Pipe Port (BSPP) - L Series - Table 3 of 3 | 5-43 |
| 5-28 | British Standard Parallel Pipe Port (BSPP) - S Series - Table 1 of 3 | 5-44 |
| 5-29 | British Standard Parallel Pipe Port (BSPP) - S Series - Table 2 of 3 | 5-45 |
| 5-30 | British Standard Parallel Pipe Port (BSPP) - S Series - Table 3 of 3 | 5-46 |
| 5-31 | Flange Code (FL61 & FL62) -Inch Fasteners | 5-49 |
| 5-32 | Flange Code (FL61 & FL62) - Metric Fasteners | 5-50 |
| 6-1 | Analyzer Abbreviations | 6-6 |
| 6-2 | Machine Configuration Programming Information- Version P2.14 | 6-31 |
| 6-3 | Machine Configuration Programming Settings- Version P2.14 | 6-36 |
| 6-4 | Machine Personality Settings and Function Speed (Software Version P2.14) | 6-37 |
| 6-5 | System Test Messages | 6-47 |
| 6-6 | Machine Diagnostics Parameters | 6-49 |
| 6-7 | Diagnostic Menu Descriptions | 6-82 |

| TABLE NO. | TITLE | PAGE NO. |
|------------------|--------------------------------------|-----------------|
| 6-8 | Accessory Weights | 6-84 |
| 6-9 | SkyGlazier Capacity Reductions..... | 6-86 |
| 6-10 | Pipe Rack Capacity Reductions | 6-86 |
| 6-11 | LSS Service Mode | 6-88 |
| 6-12 | LSS Troubleshooting Chart | 6-89 |
| 6-13 | Diagnostic Trouble Codes | 6-90 |
| 7-1 | Wiring Harness Connector Labels..... | 7-17 |

Go to Discount-Equipment.com to order your parts

LIST OF TABLES

TABLE NO.

TITLE

PAGE NO.

Go to Discount-Equipment.com to order your parts

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your information to search our manual library for parts manuals.

* Brand:

* Model:

* Serial:

* Part Number:

* Class:

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information to request help finding a part or manual.

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Part Name:

Part Location:

Part Drawing:

Part Photo:

Part Notes:

Part Status:

Part Category:

Part Subcategory:

Part Material:

Part Finish:

Part Color:

Part Weight:

Part Dimensions:

Part Price:

Part Lead Time:

Part Availability:

Part Comments:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 1. SPECIFICATIONS

1.1 OPERATING SPECIFICATIONS

Machine Specifications

| | |
|---|--------------------------------------|
| Maximum Work Load (Capacity)* Unrestricted: Restricted: | 550 lb (250 kg) 750 lb (340 kg) |
| Maximum Travel Grade (Gradeability) | 55% |
| Maximum Travel Grade (Side Slope) | 5° |
| Maximum Operating Slope | 5° |
| Maximum Manual Force | 90 lbs. (445 N) |
| Maximum Wind Speed | 28 mph (12.5 m/s) |
| Ground Bearing Pressure | 11.28 psi (0.79 kg/cm ²) |
| Maximum Drive Speed | 1.6 MPH (2.57 Km/hr.) |
| Electrical System | 12VDC |
| Gross Machine Weight (Approximate) | 27620 lb (12528 kg) |
| *Maximum Work Load (Capacity) can be affected by the addition of the Soft Touch option. If equipped with Soft Touch, refer to Section 6 and the decal on your machine for these values. | |

1.2 DIMENSIONAL DATA

| | |
|--|--|
| Machine Height (Stowed) | 8 ft. 1.2 in. (2.47 m) |
| Machine Length (Stowed) | 35 ft. 4.7 in. (10.79 m) |
| Machine Width | 8 ft. 1.6 in. (2.48 m) |
| Wheelbase | 8 ft. 9.9 in. (2.69 m) |
| Ground Clearance | 1 ft. 4.7 in. (0.42 m) |
| Platform Height | 65 ft. 7 in. (19.99 m) |
| Horizontal Reach | 57 ft. 0.6 in. (17.39 m) |
| Horizontal Reach from center of rotation - 550 lb (250 kg) Zone 750 lb (340 kg) Zone | 57 ft. 0.6 in. (17.39 m) 47 ft. 11.5 in. (14.618 m) |
| Horizontal Reach over end 550 lb (250 kg) Zone 750 lb (340 kg) Zone | 51 ft. 5.4 in. (15.68 m) 42 ft. 4.3 in. (12.91 m) |
| Horizontal Reach over side 550 lb (250 kg) Zone 750 lb (340 kg) Zone | 52 ft. 11.6 in. (16.14 m) 43 ft. 10.5 in. (13.37 m) |
| Tail Swing | 4 ft. (1.22 m) |

| | |
|-------------|-----------------------|
| Track Width | 1 ft. 7.7 in. (0.5 m) |
|-------------|-----------------------|

1.3 CAPACITIES

| | |
|---|---|
| Fuel Tank | 31 Gallons (117 L) |
| Hydraulic Oil Tank | 25 Gallons (94.6 L) |
| Hydraulic System (Including Tank) | 40 Gallons (151.4 L) |
| Final Drive | 2.1 Gallons (7.9 L) |
| Engine Crankcase Deutz D2011L04 Deutz 2.9 L | 10 quarts (9.4 L) 9.6 quarts (9.1 L) |
| NOTE: Fill torque hubs half (1/2) full of lubricant. | |

1.4 ENGINE DATA

Table 1-1. Deutz TD2.9 L4

| | |
|---------------------------|--|
| Fuel | Ultra Low Sulfur Diesel (15 ppm allowable sulfur content) |
| Max Output (Power) | 67 hp (50kW) @ 2600 RPM |
| Max Output (Torque) | 173 ft. lbs. (234 Nm) @ 1800 RPM |
| Engine Oil Capacity | 2.11 gal (8.0 L) w/filter |
| Coolant Capacity (System) | 0.92 gal (3.5 L) |
| Average Fuel Consumption | 2.7 GPH (10.24 lph) |
| Low RPM | 1200 ± 50 RPM |
| High RPM | 2600 ± 50 RPM |
| Alternator | 95 Amp |

Table 1-2. Deutz D2011L04 Specifications

| | |
|--|---|
| Fuel | Diesel |
| Max Output (Power) | 61.6 hp (46kw) @ 2600 RPM |
| Engine Oil Capacity Cooling System Crankcase Total Capacity | 5 Quarts (4.7 L) 11 Quarts (10.4 L) w/Filter 16 Quarts (15.1 L) |
| Idle RPM | 1000 ± 50 RPM |
| High RPM | 2600 ± 50 RPM |
| Alternator | 60 Amp |
| Battery | 950 Cold Cranking Amps, 205 Minutes Reserve Capacity, 12 VDC |
| Fuel Consumption | 1.93 gph (7.32 Lph) |

SECTION 1 - SPECIFICATIONS

Table 1-3. Deutz TD 2.9 L4 GUO III Specifications

| | |
|---------------------------|--|
| Fuel | Low Sulfur Diesel (500 ppm allowable sulfur content) |
| Max Output (Power) | 67 hp (50 kW) |
| Max Output (Torque) | 173 ft. lbs. (234 Nm) @ 1800 RPM |
| Engine Oil Capacity | 8.5 Quarts (8.0 L) w/filter |
| Coolant Capacity (System) | 3.7 Quarts (3.5 L) |
| Average Fuel Consumption | 1.06 GPH (4.02 lph) |
| Low RPM | 1200 ± 50 RPM |
| High RPM | 2600 ± 50 RPM |
| Alternator | 95 Amp |

1.5 CRITICAL STABILITY WEIGHTS

⚠ WARNING

DO NOT REPLACE ITEMS CRITICAL TO STABILITY WITH ITEMS OF DIFFERENT WEIGHT OR SPECIFICATION (FOR EXAMPLE: BATTERIES, COUNTERWEIGHT, ENGINE AND PLATFORM) DO NOT MODIFY UNIT IN ANY WAY TO AFFECT STABILITY.

| Components | | LB | KG |
|--|---------------------------|-------|------|
| Engine (Complete tray including pump) | Deutz TD2.9L4 | 1433 | 650 |
| | Deutz D2011L04 | 983 | 445 |
| Counterweight | Chassis | 3175 | 1440 |
| | Turntable | 4910 | 2227 |
| Platform Only (No Control Box or Footswitch) | 4 ft. (M) Swing Gate | 132 | 60 |
| | 5 ft. (M) Swing Gate | 145.5 | 66 |
| | 6 ft. (M) Swing Gate | 159 | 72 |
| | 8 ft. (2.44 M) Swing Gate | 230 | 104 |
| | 6 ft. (M) Shipyard Option | 247 | 112 |

1.6 HYDRAULIC OIL

| Hydraulic System Operating Temperature Range | S.A.E. Viscosity Grade |
|--|------------------------|
| +0° to +180° F (-18° to +83° C) | 10W |
| +0° to +210° F (-18° to +99° C) | 10W-20, 10W-30 |
| +50° to +210° F (+10° to +99° C) | 20W-20 |

NOTE: Hydraulic oils require anti-wear qualities at least API Service Classification GL-3, and sufficient chemical stability for mobile hydraulic system service.

NOTE: When temperatures remain below 20°F (-7°C), JLG Industries recommends the use of Premium Hydraulic Fluid.

NOTE: Aside from JLG recommendations, it is not advisable to mix oils of different brands or types. They may not contain required additives or be of comparable viscosities.

Table 1-4. Mobilfluid 424

| SAE Grade | 10W-30 |
|-------------------------|---------------|
| ISO | 55 |
| Gravity, API | 29.0 |
| Density, Lb/Gal. 60°F | 7.35 |
| Pour Point, Max | -46°F (-43°C) |
| Flash Point, Min. | 442°F (228°C) |
| Viscosity | |
| Brookfield, cP at -18°C | 2700 |
| at 40° C | 55 cSt |
| at 100° C | 9.3 cSt |
| Viscosity Index | 152 |

Table 1-5. Mobil DTE 10 Excel 32

| ISO Viscosity Grade | #32 |
|---------------------|---------------|
| Specific Gravity | 0.877 |
| Pour Point, Max | -40°F (-40°C) |
| Flash Point, Min. | 330°F (166°C) |
| Viscosity | |
| at 40° C | 32.7 cSt |
| at 100° C | 6.6 cSt |
| at 100° F | 169 SUS |
| at 210° F | 48 SUS |
| cp at -20° F | 6200 |
| Viscosity Index | 164 |

Table 1-6. Quintolubric 888-46

| Density | 0.92 @ 15°C (59°F) |
|---------------------------|--------------------|
| Pour Point | <-20°F (<-30°C) |
| Flash Point | 275°F (300°C) |
| Fire Point | 325°F (360°C) |
| Auto Ignition Temperature | 450°F (842°C) |
| Viscosity | |
| at 0°C (32°F) | 360 cSt |
| at 20°C (104°F) | 102 cSt |
| at 40°C (104°F) | 46 cSt |
| at 100°C (150°F) | 10 cSt |
| Viscosity Index | 220 |

Table 1-7. Mobil EAL 224 H

| Type | Synthetic Biodegradable |
|---|--|
| ISO Viscosity Grade | 32/46 |
| Specific Gravity | 0.922 |
| Pour Point | -25°F (-32°C) |
| Flash Point | 428°F (220°C) |
| Operating Temp. | 0 to 180°F (-17 to 82°C) |
| Weight | 7.64 lb per gal. (0.9 kg per liter) |
| Viscosity | |
| at 40°C | 37 cSt |
| at 100°C | 8.4 cSt |
| Viscosity Index | 213 |
| NOTE: Must be stored above 32°F (14°C) | |

Table 1-8. Mobil EAL Envirosyn H 46

| Type | Synthetic Biodegradable |
|---------------------|---------------------------|
| ISO Viscosity Grade | 46 |
| Specific Gravity | 0.910 |
| Density | 0.874 @ 15°C (59°F) |
| Pour Point | -44°F (-42°C) |
| Flash Point | 500°F (260°C) |
| Operating Temp. | 0 to 180°F (-17 to 162°C) |
| Viscosity | |
| at 40°C | 48.8 cSt |
| at 100°C | 7.8 cSt |
| Viscosity Index | 145 |

Table 1-9. Exxon Univis HVI 26 Specs

| Specific Gravity | 32.1 |
|--|---------------|
| Pour Point | -76°F (-60°C) |
| Flash Point | 217°F (103°C) |
| Viscosity | |
| at 40°C | 25.8 cSt |
| at 100°C | 9.3 cSt |
| Viscosity Index | 376 |
| NOTE: Mobil/Exxon recommends this oil be checked on a yearly basis for viscosity. | |

1.7 TORQUE REQUIREMENTS

| Description | Torque Value (Dry) | Interval Hours |
|--|---|----------------|
| Bearing To Chassis | 190 ft.lbs (260 Nm) | |
| Bearing To Turntable | 190 ft.lbs (260 Nm) | |
| Wire Rope | 15 ft. lbs (20 Nm) | 150 |
| Engine Mounting Bolts M12 M16 | 84.8 ft.lbs (115 Nm) 206.5 ft.lbs (280 Nm) | |
| NOTE: Check swing bearing bolts after first 50 hours of operation and every 600 hours thereafter. (See Section 3.6, Swing Bearing). | | |




Figure 1-1. Maintenance and Lubrication Diagram - Deutz D2011L04




Figure 1-2. Maintenance and Lubrication Diagram - Deutz TD 2.9 and TD 2.9 L4 GUO III

1.8 MAINTENANCE AND LUBRICATION

NOTE: The following numbers correspond to those in Figure 1-1. and Figure 1-2.


Table 1-10. Lubrication Specifications.

| KEY | SPECIFICATIONS |
|------|---|
| MPG | Multipurpose Grease having a minimum dripping point of 350°F (177°C). Excellent water resistance and adhesive qualities, and being of extreme pressure type. (Timken OK 40 pounds minimum.) |
| EPGL | Extreme Pressure Gear Lube (oil) meeting API service classification GL-5 or MIL-Spec MIL-L-2105 |
| HO | Hydraulic Oil. Refer Section 1.6, Hydraulic Oil. |
| EO | Engine (crankcase) Oil. Gas - API SF, SH, SG class, MIL-L-2104. Diesel - API CC/CD class, MIL-L-2104B/MIL-L-2104C |

NOTICE


LUBRICATION INTERVALS ARE BASED ON MACHINE OPERATION UNDER NORMAL CONDITIONS. FOR MACHINES USED IN MULTI-SHIFT OPERATIONS AND/OR EXPOSED TO HOSTILE ENVIRONMENTS OR CONDITIONS, LUBRICATION FREQUENCIES MUST BE INCREASED ACCORDINGLY.

1. Swing Bearing




Lube Point(s) - 1 Grease Fittings
 Capacity - A/R
 Lube - MPG
 Interval - Every 3 months or 150 hrs of operation
 Comments - Remote Access. Apply grease and rotate in 90 degree intervals until bearing is completely lubricated.

2. Swing Drive Hub



Lube Point(s) - Level/Fill Plug
 Capacity - 32 oz. (0.95 L)
 Lube - 80w90 Gear Oil
 Interval - Check level every 3 months or 150 hrs of operation; change every 2 years or 1200 hours of operation.

3. Drive Hub



MAE25190


Lube Point(s) - Level/Fill Plug
 Capacity - 24 oz. (0.7 L)
 Lube - 80w90 Gear Oil
 Interval - Check level every 3 months or 150 hrs of operation; change every 2 years or 1200 hours of operation.

4. Hydraulic Charge Filter



Interval - Change after first 50 hrs. and every 6 months or 300 hrs.

5. Hydraulic Return Filter



Interval - Change after first 50 hrs. and every 6 months or 300 hrs.


6. Hydraulic Tank Breather



Interval - Change after first 50 hrs. and every 6 months or 300 hrs. thereafter.

Comments - Remove wing nut and cover to replace. Under certain conditions, it may be necessary to replace on a more frequent basis.

7. Hydraulic Tank



Lube Point(s) - Fill Cap Capacity - 21 gal tank (79.5 L) 40.0 gal system (151 L) Lube - HO Interval - Check Level daily; Change every 2 years or 1200 hours of operation

Comments - On new machines, those recently overhauled, or after changing hydraulic oil, operate all systems a minimum of two complete cycles and recheck oil level in reservoir.

8. Oil Change w/Filter - Deutz D2011



Lube Point(s) - Fill Cap/Spin-on Element Capacity - 11 Quarts (10.4 L) Crankcase; 5 Quarts (4.7 L) Cooler

Type - Deutz approved engine oil.

Lube - EO

Interval - Every Year or 1200 hours of operation

Comments - Check level daily/Change in accordance with engine manual. Use Deutz approved engine oil type.


SECTION 1 - SPECIFICATIONS

9. Fuel Filter - Deutz D2011L04




Lube Point(s) - Replaceable Element
Interval - Every Year or 600 hours of operation.

10. Oil Change w/Filter - Deutz TD2.9



Lube Point(s) - Fill Cap/Spin-on Element
Capacity - 9.6 Quarts (9.1 L) Crankcase;
Type - Deutz approved engine oil
Lube - EO
Interval - Every Year or 600 hours of operation
Comments - Check level daily/Change in accordance with engine manual.

11. Fuel Filter - Deutz TD2.9



Lube Point(s) - Replaceable Element
Interval - Every Year or 600 hours of operation

12. Fuel Pre-Filter - Deutz TD2.9




Lube Point(s) - Replaceable Element
Interval - Drain water daily;
Filter must be replaced every year or 600 hours of operation (whichever comes first).


13. Engine Coolant - Deutz TD2.9

Lube Point(s) - Fill Cap
Capacity - 13.2 Quarts (12.5 L)
Type - Deutz approved engine coolant
Lube - Anti-Freeze
Interval - Check level daily; change every 1000 hours or two years, whichever comes first.

14. A. Air Filter - Deutz TD2.9L




B. Air Filter - Deutz D2011L04




Lube Point(s) - Replaceable Element
Interval - Every 6 months or 300 hours of operation or as indicated by the condition indicator.

15. Platform Filter




Lube Point - Replaceable Element
Interval - Change after first 50 hours and then every year or 600 hours of operation, whichever comes first.

16. A. Optional Fuel Filter - Deutz 2011



B. Fuel Filter/Water Separator - Deutz 2.9L



Lube Point(s) - Replaceable Element Interval - Drain water daily; Every year or 600 hours of operation

SECTION 1 - SPECIFICATIONS

1.9 THREAD LOCKING COMPOUND

| JLG PN | Loctite® | ND Industries | Description |
|------------|----------|-----------------|------------------------------|
| 0100011 | 242™ | Vibra-TITE™ 121 | Medium Strength (Blue) |
| 1001095650 | 243™ | Vibra-TITE™ 122 | Medium Strength (Blue) |
| 0100019 | 271™ | Vibra-TITE™ 140 | High Strength (Red) |
| 0100071 | 262™ | Vibra-TITE™ 131 | Medium - High Strength (Red) |

NOTE: Loctite® 243™ can be substituted in place of Loctite® 242™. Vibra-TITE™ 122 can be substituted in place of Vibra-TITE™ 121.

Go to Discount-Equipment.com to order your parts

1.10 TORQUE CHARTS

SAE Fastener Torque Chart

| Values for Zinc Yellow Chromate Fasteners (Ref 4150707) | | | | | | | | | | | | |
|---|-----|-----------|---------------------|------------|--------------|--------------|-------------------|--------------|--|--------------|---|--------------|
| SAE GRADE 5 BOLTS & GRADE 2 NUTS | | | | | | | | | | | | |
| Size | TPI | Bolt Dia | Tensile Stress Area | Clamp Load | Torque (Dry) | | Torque Lubricated | | Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) | | Torque (Loctite® 262™ or Vibra-TITE™ 111) | |
| | | | | | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] |
| 4 | 40 | 0.1120 | 0.00604 | 380 | 8 | 0.9 | 6 | 0.7 | | | | |
| | 48 | 0.1120 | 0.00661 | 420 | 9 | 1.0 | 7 | 0.8 | | | | |
| 6 | 32 | 0.1380 | 0.00909 | 580 | 16 | 1.8 | 12 | 1.4 | | | | |
| | 40 | 0.1380 | 0.01015 | 610 | 18 | 2.0 | 13 | 1.5 | | | | |
| 8 | 32 | 0.1640 | 0.01400 | 900 | 30 | 3.4 | 22 | 2.5 | | | | |
| | 36 | 0.1640 | 0.01474 | 940 | 31 | 3.5 | 23 | 2.6 | | | | |
| 10 | 24 | 0.1900 | 0.01750 | 1120 | 43 | 4.8 | 32 | 3.5 | | | | |
| | 32 | 0.1900 | 0.02000 | 1285 | 49 | 5.5 | 36 | 4 | | | | |
| 1/4 | 20 | 0.2500 | 0.0318 | 2020 | 96 | 10.8 | 75 | 9 | 105 | 12 | | |
| | 28 | 0.2500 | 0.0364 | 2320 | 120 | 13.5 | 86 | 10 | 135 | 15 | | |
| | | In | Sq In | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 5/16 | 18 | 0.3125 | 0.0524 | 3340 | 17 | 23 | 13 | 18 | 19 | 26 | 16 | 22 |
| | 24 | 0.3125 | 0.0580 | 3700 | 19 | 26 | 14 | 19 | 21 | 29 | 17 | 23 |
| 3/8 | 16 | 0.3750 | 0.0775 | 4940 | 30 | 41 | 23 | 31 | 35 | 48 | 28 | 38 |
| | 24 | 0.3750 | 0.0878 | 5600 | 35 | 47 | 25 | 34 | 40 | 54 | 32 | 43 |
| 7/16 | 14 | 0.4375 | 0.1063 | 6800 | 50 | 68 | 35 | 47 | 55 | 75 | 45 | 61 |
| | 20 | 0.4375 | 0.1187 | 7550 | 55 | 75 | 40 | 54 | 60 | 82 | 50 | 68 |
| 1/2 | 13 | 0.5000 | 0.1419 | 9050 | 75 | 102 | 55 | 75 | 85 | 116 | 68 | 92 |
| | 20 | 0.5000 | 0.1599 | 10700 | 90 | 122 | 65 | 88 | 100 | 136 | 80 | 108 |
| 9/16 | 12 | 0.5625 | 0.1820 | 11600 | 110 | 149 | 80 | 108 | 120 | 163 | 98 | 133 |
| | 18 | 0.5625 | 0.2030 | 12950 | 120 | 163 | 90 | 122 | 135 | 184 | 109 | 148 |
| 5/8 | 11 | 0.6250 | 0.2260 | 14400 | 150 | 203 | 110 | 149 | 165 | 224 | 135 | 183 |
| | 18 | 0.6250 | 0.2560 | 16300 | 170 | 230 | 130 | 176 | 190 | 258 | 153 | 207 |
| 3/4 | 10 | 0.7500 | 0.3340 | 21300 | 260 | 353 | 200 | 271 | 285 | 388 | 240 | 325 |
| | 16 | 0.7500 | 0.3730 | 23800 | 300 | 407 | 220 | 298 | 330 | 449 | 268 | 363 |
| 7/8 | 9 | 0.8750 | 0.4620 | 29400 | 430 | 583 | 320 | 434 | 475 | 646 | 386 | 523 |
| | 14 | 0.8750 | 0.5090 | 32400 | 470 | 637 | 350 | 475 | 520 | 707 | 425 | 576 |
| 1 | 8 | 1.0000 | 0.6060 | 38600 | 640 | 868 | 480 | 651 | 675 | 918 | 579 | 785 |
| | 12 | 1.0000 | 0.6630 | 42200 | 700 | 949 | 530 | 719 | 735 | 1000 | 633 | 858 |
| 1 1/8 | 7 | 1.1250 | 0.7630 | 42300 | 800 | 1085 | 600 | 813 | 840 | 1142 | 714 | 968 |
| | 12 | 1.1250 | 0.8560 | 47500 | 880 | 1193 | 660 | 895 | 925 | 1258 | 802 | 1087 |
| 1 1/4 | 7 | 1.2500 | 0.9690 | 53800 | 1120 | 1518 | 840 | 1139 | 1175 | 1598 | 1009 | 1368 |
| | 12 | 1.2500 | 1.0730 | 59600 | 1240 | 1681 | 920 | 1247 | 1300 | 1768 | 1118 | 1516 |
| 1 3/8 | 6 | 1.3750 | 1.1550 | 64100 | 1460 | 1979 | 1100 | 1491 | 1525 | 2074 | 1322 | 1792 |
| | 12 | 1.3750 | 1.3150 | 73000 | 1680 | 2278 | 1260 | 1708 | 1750 | 2380 | 1506 | 2042 |
| 1 1/2 | 6 | 1.5000 | 1.4050 | 78000 | 1940 | 2630 | 1460 | 1979 | 2025 | 2754 | 1755 | 2379 |
| | 12 | 1.5000 | 1.5800 | 87700 | 2200 | 2983 | 1640 | 2224 | 2300 | 3128 | 1974 | 2676 |

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS

5000059K

2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%

3. * ASSEMBLY USES HARDENED WASHER

SECTION 1 - SPECIFICATIONS

| Values for Zinc Yellow Chromate Fasteners (Ref 4150707) | | | | | | | | | | |
|---|-----|----------|---------------------|------------|-------------------------------------|-------|---|-------|--|-------|
| SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS* | | | | | | | | | | |
| Size | TPI | Bolt Dia | Tensile Stress Area | Clamp Load | Torque (Dry or Loctite® 263) K=0.20 | | Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.18 | | Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15 | |
| | | | | | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] |
| | | In | Sq In | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 4 | 40 | 0.1120 | 0.00604 | | | | | | | |
| | 48 | 0.1120 | 0.00661 | | | | | | | |
| 6 | 32 | 0.1380 | 0.00909 | | | | | | | |
| | 40 | 0.1380 | 0.01015 | | | | | | | |
| 8 | 32 | 0.1640 | 0.01400 | | | | | | | |
| | 36 | 0.1640 | 0.01474 | 1320 | 43 | 5 | | | | |
| 10 | 24 | 0.1900 | 0.01750 | 1580 | 60 | 7 | | | | |
| | 32 | 0.1900 | 0.02000 | 1800 | 68 | 8 | | | | |
| 1/4 | 20 | 0.2500 | 0.0318 | 2860 | 143 | 16 | 129 | 15 | | |
| | 28 | 0.2500 | 0.0364 | 3280 | 164 | 19 | 148 | 17 | | |
| | | In | Sq In | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 5/16 | 18 | 0.3125 | 0.0524 | 4720 | 25 | 35 | 20 | 25 | 20 | 25 |
| | 24 | 0.3125 | 0.0580 | 5220 | 25 | 35 | 25 | 35 | 20 | 25 |
| 3/8 | 16 | 0.3750 | 0.0775 | 7000 | 45 | 60 | 40 | 55 | 35 | 50 |
| | 24 | 0.3750 | 0.0878 | 7900 | 50 | 70 | 45 | 60 | 35 | 50 |
| 7/16 | 14 | 0.4375 | 0.1063 | 9550 | 70 | 95 | 65 | 90 | 50 | 70 |
| | 20 | 0.4375 | 0.1187 | 10700 | 80 | 110 | 70 | 95 | 60 | 80 |
| 1/2 | 13 | 0.5000 | 0.1419 | 12750 | 105 | 145 | 95 | 130 | 80 | 110 |
| | 20 | 0.5000 | 0.1599 | 14400 | 120 | 165 | 110 | 150 | 90 | 120 |
| 9/16 | 12 | 0.5625 | 0.1820 | 16400 | 155 | 210 | 140 | 190 | 115 | 155 |
| | 18 | 0.5625 | 0.2030 | 18250 | 170 | 230 | 155 | 210 | 130 | 175 |
| 5/8 | 11 | 0.6250 | 0.2260 | 20350 | 210 | 285 | 190 | 260 | 160 | 220 |
| | 18 | 0.6250 | 0.2560 | 23000 | 240 | 325 | 215 | 290 | 180 | 245 |
| 3/4 | 10 | 0.7500 | 0.3340 | 30100 | 375 | 510 | 340 | 460 | 280 | 380 |
| | 16 | 0.7500 | 0.3730 | 33600 | 420 | 570 | 380 | 515 | 315 | 430 |
| 7/8 | 9 | 0.8750 | 0.4620 | 41600 | 605 | 825 | 545 | 740 | 455 | 620 |
| | 14 | 0.8750 | 0.5090 | 45800 | 670 | 910 | 600 | 815 | 500 | 680 |
| 1 | 8 | 1.0000 | 0.6060 | 51500 | 860 | 1170 | 770 | 1045 | 645 | 875 |
| | 12 | 1.0000 | 0.6630 | 59700 | 995 | 1355 | 895 | 1215 | 745 | 1015 |
| 1 1/8 | 7 | 1.1250 | 0.7630 | 68700 | 1290 | 1755 | 1160 | 1580 | 965 | 1310 |
| | 12 | 1.1250 | 0.8560 | 77000 | 1445 | 1965 | 1300 | 1770 | 1085 | 1475 |
| 1 1/4 | 7 | 1.2500 | 0.9690 | 87200 | 1815 | 2470 | 1635 | 2225 | 1365 | 1855 |
| | 12 | 1.2500 | 1.0730 | 96600 | 2015 | 2740 | 1810 | 2460 | 1510 | 2055 |
| 1 3/8 | 6 | 1.3750 | 1.1550 | 104000 | 2385 | 3245 | 2145 | 2915 | 1785 | 2430 |
| | 12 | 1.3750 | 1.3150 | 118100 | 2705 | 3680 | 2435 | 3310 | 2030 | 2760 |
| 1 1/2 | 6 | 1.5000 | 1.4050 | 126500 | 3165 | 4305 | 2845 | 3870 | 2370 | 3225 |
| | 12 | 1.5000 | 1.5800 | 142200 | 3555 | 4835 | 3200 | 4350 | 2665 | 3625 |

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER

5000059K

| Values for Magni Coating Fasteners (Ref 4150701) | | | | | | | | | | |
|--|-----|----------|---------------------|------------|---------------------|-------|---|-------|--|-------|
| SAE GRADE 5 BOLTS & GRADE 2 NUTS | | | | | | | | | | |
| Size | TPI | Bolt Dia | Tensile Stress Area | Clamp Load | Torque (Dry) K=0.17 | | Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.16 | | Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15 | |
| | | | | | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] |
| 4 | 40 | 0.1120 | 0.00604 | 380 | 7 | 0.8 | | | | |
| | 48 | 0.1120 | 0.00661 | 420 | 8 | 0.9 | | | | |
| 6 | 32 | 0.1380 | 0.00909 | 580 | 14 | 1.5 | | | | |
| | 40 | 0.1380 | 0.01015 | 610 | 14 | 1.6 | | | | |
| 8 | 32 | 0.1640 | 0.01400 | 900 | 25 | 2.8 | | | | |
| | 36 | 0.1640 | 0.01474 | 940 | 26 | 2.9 | | | | |
| 10 | 24 | 0.1900 | 0.01750 | 1120 | 36 | 4.1 | | | | |
| | 32 | 0.1900 | 0.02000 | 1285 | 42 | 4.7 | | | | |
| 1/4 | 20 | 0.2500 | 0.0318 | 2020 | 86 | 9.7 | 80 | 9 | | |
| | 28 | 0.2500 | 0.0364 | 2320 | 99 | 11.1 | 95 | 11 | | |
| | | In | Sq In | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 5/16 | 18 | 0.3125 | 0.0524 | 3340 | 15 | 20 | 14 | 19 | 15 | 20 |
| | 24 | 0.3125 | 0.0580 | 3700 | 15 | 20 | 15 | 21 | 15 | 20 |
| 3/8 | 16 | 0.3750 | 0.0775 | 4940 | 25 | 35 | 25 | 34 | 25 | 34 |
| | 24 | 0.3750 | 0.0878 | 5600 | 30 | 40 | 28 | 38 | 25 | 34 |
| 7/16 | 14 | 0.4375 | 0.1063 | 6800 | 40 | 55 | 40 | 54 | 35 | 48 |
| | 20 | 0.4375 | 0.1187 | 7550 | 45 | 60 | 44 | 60 | 40 | 54 |
| 1/2 | 13 | 0.5000 | 0.1419 | 9050 | 65 | 90 | 60 | 82 | 55 | 75 |
| | 20 | 0.5000 | 0.1599 | 10700 | 75 | 100 | 71 | 97 | 65 | 88 |
| 9/16 | 12 | 0.5625 | 0.1820 | 11600 | 90 | 120 | 87 | 118 | 80 | 109 |
| | 18 | 0.5625 | 0.2030 | 12950 | 105 | 145 | 97 | 132 | 90 | 122 |
| 5/8 | 11 | 0.6250 | 0.2260 | 14400 | 130 | 175 | 120 | 163 | 115 | 156 |
| | 18 | 0.6250 | 0.2560 | 16300 | 145 | 195 | 136 | 185 | 125 | 170 |
| 3/4 | 10 | 0.7500 | 0.3340 | 21300 | 225 | 305 | 213 | 290 | 200 | 272 |
| | 16 | 0.7500 | 0.3730 | 23800 | 255 | 345 | 238 | 324 | 225 | 306 |
| 7/8 | 9 | 0.8750 | 0.4620 | 29400 | 365 | 495 | 343 | 466 | 320 | 435 |
| | 14 | 0.8750 | 0.5090 | 32400 | 400 | 545 | 378 | 514 | 355 | 483 |
| 1 | 8 | 1.0000 | 0.6060 | 38600 | 545 | 740 | 515 | 700 | 480 | 653 |
| | 12 | 1.0000 | 0.6630 | 42200 | 600 | 815 | 563 | 765 | 530 | 721 |
| 1 1/8 | 7 | 1.1250 | 0.7630 | 42300 | 675 | 920 | 635 | 863 | 595 | 809 |
| | 12 | 1.1250 | 0.8560 | 47500 | 755 | 1025 | 713 | 969 | 670 | 911 |
| 1 1/4 | 7 | 1.2500 | 0.9690 | 53800 | 955 | 1300 | 897 | 1219 | 840 | 1142 |
| | 12 | 1.2500 | 1.0730 | 59600 | 1055 | 1435 | 993 | 1351 | 930 | 1265 |
| 1 3/8 | 6 | 1.3750 | 1.1550 | 64100 | 1250 | 1700 | 1175 | 1598 | 1100 | 1496 |
| | 12 | 1.3750 | 1.3150 | 73000 | 1420 | 1930 | 1338 | 1820 | 1255 | 1707 |
| 1 1/2 | 6 | 1.5000 | 1.4050 | 78000 | 1660 | 2260 | 1560 | 2122 | 1465 | 1992 |
| | 12 | 1.5000 | 1.5800 | 87700 | 1865 | 2535 | 1754 | 2385 | 1645 | 2237 |

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER

5000059K

SECTION 1 - SPECIFICATIONS

| Values for Magni Coating Fasteners (Ref 4150701) | | | | | | | | | | |
|--|-----|----------|---------------------|------------|--|-------|--|-------|---|-------|
| SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS* | | | | | | | | | | |
| Size | TPI | Bolt Dia | Tensile Stress Area | Clamp Load | Torque (Dry or Loctite® 263) K=0.17 | | Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.16 | | Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15 | |
| | | | | | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] |
| 4 | 40 | 0.1120 | 0.00604 | | | | | | | |
| | 48 | 0.1120 | 0.00661 | | | | | | | |
| 6 | 32 | 0.1380 | 0.00909 | | | | | | | |
| | 40 | 0.1380 | 0.01015 | | | | | | | |
| 8 | 32 | 0.1640 | 0.01400 | | | | | | | |
| | 36 | 0.1640 | 0.01474 | 1320 | 37 | 4 | | | | |
| 10 | 24 | 0.1900 | 0.01750 | 1580 | 51 | 6 | | | | |
| | 32 | 0.1900 | 0.02000 | 1800 | 58 | 7 | | | | |
| 1/4 | 20 | 0.2500 | 0.0318 | 2860 | 122 | 14 | 114 | 13 | | |
| | 28 | 0.2500 | 0.0364 | 3280 | 139 | 16 | 131 | 15 | | |
| | | In | Sq In | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 5/16 | 18 | 0.3125 | 0.0524 | 4720 | 20 | 25 | 20 | 25 | 20 | 25 |
| | 24 | 0.3125 | 0.0580 | 5220 | 25 | 35 | 20 | 25 | 20 | 25 |
| 3/8 | 16 | 0.3750 | 0.0775 | 7000 | 35 | 50 | 35 | 50 | 35 | 50 |
| | 24 | 0.3750 | 0.0878 | 7900 | 40 | 55 | 40 | 55 | 35 | 50 |
| 7/16 | 14 | 0.4375 | 0.1063 | 9550 | 60 | 80 | 55 | 75 | 50 | 70 |
| | 20 | 0.4375 | 0.1187 | 10700 | 65 | 90 | 60 | 80 | 60 | 80 |
| 1/2 | 13 | 0.5000 | 0.1419 | 12750 | 90 | 120 | 85 | 115 | 80 | 110 |
| | 20 | 0.5000 | 0.1599 | 14400 | 100 | 135 | 95 | 130 | 90 | 120 |
| 9/16 | 12 | 0.5625 | 0.1820 | 16400 | 130 | 175 | 125 | 170 | 115 | 155 |
| | 18 | 0.5625 | 0.2030 | 18250 | 145 | 195 | 135 | 185 | 130 | 175 |
| 5/8 | 11 | 0.6250 | 0.2260 | 20350 | 180 | 245 | 170 | 230 | 160 | 220 |
| | 18 | 0.6250 | 0.2560 | 23000 | 205 | 280 | 190 | 260 | 180 | 245 |
| 3/4 | 10 | 0.7500 | 0.3340 | 30100 | 320 | 435 | 300 | 410 | 280 | 380 |
| | 16 | 0.7500 | 0.3730 | 33600 | 355 | 485 | 335 | 455 | 315 | 430 |
| 7/8 | 9 | 0.8750 | 0.4620 | 41600 | 515 | 700 | 485 | 660 | 455 | 620 |
| | 14 | 0.8750 | 0.5090 | 45800 | 570 | 775 | 535 | 730 | 500 | 680 |
| 1 | 8 | 1.0000 | 0.6060 | 51500 | 730 | 995 | 685 | 930 | 645 | 875 |
| | 12 | 1.0000 | 0.6630 | 59700 | 845 | 1150 | 795 | 1080 | 745 | 1015 |
| 1 1/8 | 7 | 1.1250 | 0.7630 | 68700 | 1095 | 1490 | 1030 | 1400 | 965 | 1310 |
| | 12 | 1.1250 | 0.8560 | 77000 | 1225 | 1665 | 1155 | 1570 | 1085 | 1475 |
| 1 1/4 | 7 | 1.2500 | 0.9690 | 87200 | 1545 | 2100 | 1455 | 1980 | 1365 | 1855 |
| | 12 | 1.2500 | 1.0730 | 96600 | 1710 | 2325 | 1610 | 2190 | 1510 | 2055 |
| 1 3/8 | 6 | 1.3750 | 1.1550 | 104000 | 2025 | 2755 | 1905 | 2590 | 1785 | 2430 |
| | 12 | 1.3750 | 1.3150 | 118100 | 2300 | 3130 | 2165 | 2945 | 2030 | 2760 |
| 1 1/2 | 6 | 1.5000 | 1.4050 | 126500 | 2690 | 3660 | 2530 | 3440 | 2370 | 3225 |
| | 12 | 1.5000 | 1.5800 | 142200 | 3020 | 4105 | 2845 | 3870 | 2665 | 3625 |

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER

5000059K

| Values for Magni Coating Fasteners (Ref 4150701) | | | | | | | | | | |
|--|-----|----------|---------------------|--------------------------|------------------------|-------|---|-------|---|-------|
| SOCKET HEAD CAPSCREWS | | | | | | | | | | |
| Size | TPI | Bolt Dia | Tensile Stress Area | Clamp Load See Note 4 | Torque (Dry) K=0.17 | | Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) or Precoat® 85 K=0.16 | | Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15 | |
| | | | | | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] |
| | | In | Sq In | LB | | | | | | |
| 4 | 40 | 0.1120 | 0.00604 | | | | | | | |
| | 48 | 0.1120 | 0.00661 | | | | | | | |
| 6 | 32 | 0.1380 | 0.00909 | | | | | | | |
| | 40 | 0.1380 | 0.01015 | | | | | | | |
| 8 | 32 | 0.1640 | 0.01400 | | | | | | | |
| | 36 | 0.1640 | 0.01474 | | | | | | | |
| 10 | 24 | 0.1900 | 0.01750 | | | | | | | |
| | 32 | 0.1900 | 0.02000 | | | | | | | |
| 1/4 | 20 | 0.2500 | 0.0318 | 2860 | 122 | 14 | 114 | 13 | | |
| | 28 | 0.2500 | 0.0364 | 3280 | 139 | 16 | 131 | 15 | | |
| | | In | Sq In | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 5/16 | 18 | 0.3125 | 0.0524 | 4720 | 20 | 25 | 20 | 25 | 20 | 25 |
| | 24 | 0.3125 | 0.0580 | 5220 | 25 | 35 | 20 | 25 | 20 | 25 |
| 3/8 | 16 | 0.3750 | 0.0775 | 7000 | 35 | 50 | 35 | 50 | 35 | 50 |
| | 24 | 0.3750 | 0.0878 | 7900 | 40 | 55 | 40 | 55 | 35 | 50 |
| 7/16 | 14 | 0.4375 | 0.1063 | 9550 | 60 | 80 | 55 | 75 | 50 | 70 |
| | 20 | 0.4375 | 0.1187 | 10700 | 65 | 90 | 60 | 80 | 60 | 80 |
| 1/2 | 13 | 0.5000 | 0.1419 | 12750 | 90 | 120 | 85 | 115 | 80 | 110 |
| | 20 | 0.5000 | 0.1599 | 14400 | 100 | 135 | 95 | 130 | 90 | 120 |
| 9/16 | 12 | 0.5625 | 0.1820 | 16400 | 130 | 175 | 125 | 170 | 115 | 155 |
| | 18 | 0.5625 | 0.2030 | 18250 | 145 | 195 | 135 | 185 | 130 | 175 |
| 5/8 | 11 | 0.6250 | 0.2260 | 20350 | 180 | 245 | 170 | 230 | 160 | 220 |
| | 18 | 0.6250 | 0.2560 | 23000 | 205 | 280 | 190 | 260 | 180 | 245 |
| 3/4 | 10 | 0.7500 | 0.3340 | 30100 | 320 | 435 | 300 | 415 | 280 | 380 |
| | 16 | 0.7500 | 0.3730 | 33600 | 355 | 485 | 335 | 455 | 315 | 430 |
| 7/8 | 9 | 0.8750 | 0.4620 | 41600 | 515 | 700 | 485 | 660 | 455 | 620 |
| | 14 | 0.8750 | 0.5090 | 45800 | 570 | 775 | 535 | 730 | 500 | 680 |
| 1 | 8 | 1.0000 | 0.6060 | 51500 | 730 | 995 | 685 | 930 | 645 | 875 |
| | 12 | 1.0000 | 0.6630 | 59700 | 845 | 1150 | 795 | 1080 | 745 | 1015 |
| 1 1/8 | 7 | 1.1250 | 0.7630 | 68700 | 1095 | 1490 | 1030 | 1400 | 965 | 1310 |
| | 12 | 1.1250 | 0.8560 | 77000 | 1225 | 1665 | 1155 | 1570 | 1085 | 1475 |
| 1 1/4 | 7 | 1.2500 | 0.9690 | 87200 | 1545 | 2100 | 1455 | 1980 | 1365 | 1855 |
| | 12 | 1.2500 | 1.0730 | 96600 | 1710 | 2325 | 1610 | 2190 | 1510 | 2055 |
| 1 3/8 | 6 | 1.3750 | 1.1550 | 104000 | 2025 | 2755 | 1905 | 2590 | 1785 | 2430 |
| | 12 | 1.3750 | 1.3150 | 118100 | 2300 | 3130 | 2165 | 2945 | 2030 | 2760 |
| 1 1/2 | 6 | 1.5000 | 1.4050 | 126500 | 2690 | 3660 | 2530 | 3440 | 2370 | 3225 |
| | 12 | 1.5000 | 1.5800 | 142200 | 3020 | 4105 | 2845 | 3870 | 2665 | 3625 |

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 1 - SPECIFICATIONS

| Values for Zinc Yellow Chromate Fasteners (Ref 4150707)* | | | | | | | | | | |
|--|-----|----------|---------------------|-----------------------|---------------------|-------|--|-------|--|-------|
| SOCKET HEAD CAPSCREWS | | | | | | | | | | |
| Size | TPI | Bolt Dia | Tensile Stress Area | Clamp Load See Note 4 | Torque (Dry) K=0.17 | | Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) or Precoat® 85 K=0.16 | | Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15 | |
| | | | | | IN-LB | [N.m] | IN-LB | [N.m] | IN-LB | [N.m] |
| 4 | 40 | 0.1120 | 0.00604 | | | | | | | |
| | 48 | 0.1120 | 0.00661 | | | | | | | |
| 6 | 32 | 0.1380 | 0.00909 | | | | | | | |
| | 40 | 0.1380 | 0.01015 | | | | | | | |
| 8 | 32 | 0.1640 | 0.01400 | | | | | | | |
| | 36 | 0.1640 | 0.01474 | | | | | | | |
| 10 | 24 | 0.1900 | 0.01750 | | | | | | | |
| | 32 | 0.1900 | 0.02000 | | | | | | | |
| 1/4 | 20 | 0.2500 | 0.0318 | 2860 | 122 | 14 | 114 | 13 | | |
| | 28 | 0.2500 | 0.0364 | 3280 | 139 | 16 | 131 | 15 | | |
| | | In | Sq In | LB | FT-LB | [N.m] | FT-LB | [N.m] | FT-LB | [N.m] |
| 5/16 | 18 | 0.3125 | 0.0524 | 4720 | 20 | 25 | 20 | 25 | 20 | 25 |
| | 24 | 0.3125 | 0.0580 | 5220 | 25 | 35 | 20 | 25 | 20 | 25 |
| 3/8 | 16 | 0.3750 | 0.0775 | 7000 | 35 | 50 | 35 | 50 | 35 | 50 |
| | 24 | 0.3750 | 0.0878 | 7900 | 40 | 55 | 40 | 55 | 35 | 50 |
| 7/16 | 14 | 0.4375 | 0.1063 | 9550 | 60 | 80 | 55 | 75 | 50 | 70 |
| | 20 | 0.4375 | 0.1187 | 10700 | 65 | 90 | 60 | 80 | 60 | 80 |
| 1/2 | 13 | 0.5000 | 0.1419 | 12750 | 90 | 120 | 85 | 115 | 80 | 110 |
| | 20 | 0.5000 | 0.1599 | 14400 | 100 | 135 | 95 | 130 | 90 | 120 |
| 9/16 | 12 | 0.5625 | 0.1820 | 16400 | 130 | 175 | 125 | 170 | 115 | 155 |
| | 18 | 0.5625 | 0.2030 | 18250 | 145 | 195 | 135 | 185 | 130 | 175 |
| 5/8 | 11 | 0.6250 | 0.2260 | 20350 | 180 | 245 | 170 | 230 | 160 | 220 |
| | 18 | 0.6250 | 0.2560 | 23000 | 205 | 280 | 190 | 260 | 180 | 245 |
| 3/4 | 10 | 0.7500 | 0.3340 | 30100 | 320 | 435 | 300 | 415 | 280 | 380 |
| | 16 | 0.7500 | 0.3730 | 33600 | 355 | 485 | 335 | 455 | 315 | 430 |
| 7/8 | 9 | 0.8750 | 0.4620 | 41600 | 515 | 700 | 485 | 660 | 455 | 620 |
| | 14 | 0.8750 | 0.5090 | 45800 | 570 | 775 | 535 | 730 | 500 | 680 |
| 1 | 8 | 1.0000 | 0.6060 | 51500 | 730 | 995 | 685 | 930 | 645 | 875 |
| | 12 | 1.0000 | 0.6630 | 59700 | 845 | 1150 | 795 | 1080 | 745 | 1015 |
| 1 1/8 | 7 | 1.1250 | 0.7630 | 68700 | 1095 | 1490 | 1030 | 1400 | 965 | 1310 |
| | 12 | 1.1250 | 0.8560 | 77000 | 1225 | 1665 | 1155 | 1570 | 1085 | 1475 |
| 1 1/4 | 7 | 1.2500 | 0.9690 | 87200 | 1545 | 2100 | 1455 | 1980 | 1365 | 1855 |
| | 12 | 1.2500 | 1.0730 | 96600 | 1710 | 2325 | 1610 | 2190 | 1510 | 2055 |
| 1 3/8 | 6 | 1.3750 | 1.1550 | 104000 | 2025 | 2755 | 1905 | 2590 | 1785 | 2430 |
| | 12 | 1.3750 | 1.3150 | 118100 | 2300 | 3130 | 2165 | 2945 | 2030 | 2760 |
| 1 1/2 | 6 | 1.5000 | 1.4050 | 126500 | 2690 | 3660 | 2530 | 3440 | 2370 | 3225 |
| | 12 | 1.5000 | 1.5800 | 142200 | 3020 | 4105 | 2845 | 3870 | 2665 | 3625 |

- NOTES:
1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

Metric Fastener Torque Chart

| Values for Zinc Yellow Chromate Fasteners (Ref 4150707)* | | | | | | | |
|--|-------|---------------------|--------------------------|----------------------------------|---------------|---|--|
| CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS | | | | | | | |
| Size | Pitch | Tensile Stress Area | Clamp Load See Note 4 | Torque (Dry or Loctite® 263™) | Torque (Lube) | Torque (Loctite® 262™ or 271™ or Vibra-TITE™ 131) | Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 141) |
| | | Sq mm | KN | [N.m] | | [N.m] | [N.m] |
| 3 | 0.5 | 5.03 | 2.19 | 1.3 | 1.0 | 1.2 | 1.4 |
| 3.5 | 0.6 | 6.78 | 2.95 | 2.1 | 1.6 | 1.9 | 2.3 |
| 4 | 0.7 | 8.78 | 3.82 | 3.1 | 2.3 | 2.8 | 3.4 |
| 5 | 0.8 | 14.20 | 6.18 | 6.2 | 4.6 | 5.6 | 6.8 |
| 6 | 1 | 20.10 | 8.74 | 11 | 7.9 | 9.4 | 12 |
| 7 | 1 | 28.90 | 12.6 | 18 | 13 | 16 | 19 |
| 8 | 1.25 | 36.60 | 15.9 | 26 | 19 | 23 | 28 |
| 10 | 1.5 | 58.00 | 25.2 | 50 | 38 | 45 | 55 |
| 12 | 1.75 | 84.30 | 36.7 | 88 | 66 | 79 | 97 |
| 14 | 2 | 115 | 50.0 | 140 | 105 | 126 | 154 |
| 16 | 2 | 157 | 68.3 | 219 | 164 | 197 | 241 |
| 18 | 2.5 | 192 | 83.5 | 301 | 226 | 271 | 331 |
| 20 | 2.5 | 245 | 106.5 | 426 | 320 | 383 | 469 |
| 22 | 2.5 | 303 | 132.0 | 581 | 436 | 523 | 639 |
| 24 | 3 | 353 | 153.5 | 737 | 553 | 663 | 811 |
| 27 | 3 | 459 | 199.5 | 1080 | 810 | 970 | 1130 |
| 30 | 3.5 | 561 | 244.0 | 1460 | 1100 | 1320 | 1530 |
| 33 | 3.5 | 694 | 302.0 | 1990 | 1490 | 1790 | 2090 |
| 36 | 4 | 817 | 355.5 | 2560 | 1920 | 2300 | 2690 |
| 42 | 4.5 | 1120 | 487.0 | 4090 | 3070 | 3680 | 4290 |

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 1 - SPECIFICATIONS

| Values for Zinc Yellow Chromate Fasteners (Ref 4150707)* | | | | | | |
|---|-------|---------------------|-----------------------|--------------------------------------|---|--|
| CLASS 10.9 METRIC (HEX HEAD) BOLTS, CLASS 10 METRIC NUTS CLASS 12.9 SOCKET HEAD CAPSCREWS M3 - M5* | | | | | | |
| Size | Pitch | Tensile Stress Area | Clamp Load See Note 4 | Torque (Dry or Loctite® 263™) K=0.20 | Torque (Lube or Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.18 | Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15 |
| | | Sq mm | KN | [N.m] | [N.m] | [N.m] |
| 3 | 0.5 | 5.03 | 3.13 | | | |
| 3.5 | 0.6 | 6.78 | 4.22 | | | |
| 4 | 0.7 | 8.78 | 5.47 | | | |
| 5 | 0.8 | 14.20 | 8.85 | | | |
| 6 | 1 | 20.10 | 12.5 | | | |
| 7 | 1 | 28.90 | 18.0 | 25 | 23 | 19 |
| 8 | 1.25 | 36.60 | 22.8 | 37 | 33 | 27 |
| 10 | 1.5 | 58.00 | 36.1 | 70 | 65 | 55 |
| 12 | 1.75 | 84.30 | 52.5 | 125 | 115 | 95 |
| 14 | 2 | 115 | 71.6 | 200 | 180 | 150 |
| 16 | 2 | 157 | 97.8 | 315 | 280 | 235 |
| 18 | 2.5 | 192 | 119.5 | 430 | 385 | 325 |
| 20 | 2.5 | 245 | 152.5 | 610 | 550 | 460 |
| 22 | 2.5 | 303 | 189.0 | 830 | 750 | 625 |
| 24 | 3 | 353 | 222.0 | 1065 | 960 | 800 |
| 27 | 3 | 459 | 286.0 | 1545 | 1390 | 1160 |
| 30 | 3.5 | 561 | 349.5 | 2095 | 1885 | 1575 |
| 33 | 3.5 | 694 | 432.5 | 2855 | 2570 | 2140 |
| 36 | 4 | 817 | 509.0 | 3665 | 3300 | 2750 |
| 42 | 4.5 | 1120 | 698.0 | 5865 | 5275 | 4395 |

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

| Values for Magni Coated Fasteners (Ref 4150701)* | | | | | | |
|--|-------|---------------------|--------------------------|--|--|---|
| CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS | | | | | | |
| Size | Pitch | Tensile Stress Area | Clamp Load See Note 4 | Torque (Dry or Loctite® 263™) K=0.17 | Torque (Lube or Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.16 | Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15 |
| | | Sq mm | KN | [N.m] | [N.m] | [N.m] |
| 3 | 0.5 | 5.03 | 2.19 | 1.1 | 1.1 | 1.0 |
| 3.5 | 0.6 | 6.78 | 2.95 | 1.8 | 1.7 | 1.5 |
| 4 | 0.7 | 8.78 | 3.82 | 2.6 | 2.4 | 2.3 |
| 5 | 0.8 | 14.20 | 6.18 | 5.3 | 4.9 | 4.6 |
| 6 | 1 | 20.10 | 8.74 | 9 | 8.4 | 7.9 |
| 7 | 1 | 28.90 | 12.6 | 15 | 14 | 13 |
| 8 | 1.25 | 36.60 | 15.9 | 22 | 20 | 19 |
| 10 | 1.5 | 58.00 | 25.2 | 43 | 40 | 38 |
| 12 | 1.75 | 84.30 | 36.7 | 75 | 70 | 66 |
| 14 | 2 | 115 | 50.0 | 119 | 110 | 105 |
| 16 | 2 | 157 | 68.3 | 186 | 175 | 165 |
| 18 | 2.5 | 192 | 83.5 | 256 | 240 | 225 |
| 20 | 2.5 | 245 | 106.5 | 362 | 340 | 320 |
| 22 | 2.5 | 303 | 132.0 | 494 | 465 | 435 |
| 24 | 3 | 353 | 153.5 | 627 | 590 | 555 |
| 27 | 3 | 459 | 199.5 | 916 | 860 | 810 |
| 30 | 3.5 | 561 | 244.0 | 1245 | 1170 | 1100 |
| 33 | 3.5 | 694 | 302.0 | 1694 | 1595 | 1495 |
| 36 | 4 | 817 | 355.5 | 2176 | 2050 | 1920 |
| 42 | 4.5 | 1120 | 487.0 | 3477 | 3275 | 3070 |

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 1 - SPECIFICATIONS

| Values for Magni Coated Fasteners (Ref 4150701)* | | | | | | |
|--|-------|------------------------|--------------------------|--|--|---|
| CLASS 10.9 METRIC (HEX HEAD) BOLTS CLASS 10 METRIC NUTS, CLASS 12.9 SOCKET HEAD CAPSCREWS M6 AND ABOVE* | | | | | | |
| Size | Pitch | Tensile Stress Area | Clamp Load See Note 4 | Torque (Dry or Loctite® 263™) K=0.17 | Torque (Lube or Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.18 | Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15 |
| | | Sq mm | KN | [N.m] | [N.m] | [N.m] |
| 3 | 0.5 | 5.03 | 3.13 | | | |
| 3.5 | 0.6 | 6.78 | 4.22 | | | |
| 4 | 0.7 | 8.78 | 5.47 | | | |
| 5 | 0.8 | 14.20 | 8.85 | | | |
| 6 | 1 | 20.10 | 12.5 | 13 | 12 | 11 |
| 7 | 1 | 28.90 | 18.0 | 21 | 20 | 19 |
| 8 | 1.25 | 36.60 | 22.8 | 31 | 29 | 27 |
| 10 | 1.5 | 58.00 | 36.1 | 61 | 58 | 55 |
| 12 | 1.75 | 84.30 | 52.5 | 105 | 100 | 95 |
| 14 | 2 | 115 | 71.6 | 170 | 160 | 150 |
| 16 | 2 | 157 | 97.8 | 265 | 250 | 235 |
| 18 | 2.5 | 192 | 119.5 | 365 | 345 | 325 |
| 20 | 2.5 | 245 | 152.5 | 520 | 490 | 460 |
| 22 | 2.5 | 303 | 189.0 | 705 | 665 | 625 |
| 24 | 3 | 353 | 222.0 | 905 | 850 | 800 |
| 27 | 3 | 459 | 286.0 | 1315 | 1235 | 1160 |
| 30 | 3.5 | 561 | 349.5 | 1780 | 1680 | 1575 |
| 33 | 3.5 | 694 | 432.5 | 2425 | 2285 | 2140 |
| 36 | 4 | 817 | 509.0 | 3115 | 2930 | 2750 |
| 42 | 4.5 | 1120 | 698.0 | 4985 | 4690 | 4395 |

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 2. GENERAL

2.1 MACHINE PREPARATION, INSPECTION AND MAINTENANCE

General

This section provides the necessary information needed by those personnel that are responsible to place the machine in operation readiness and maintain its safe operating condition. For maximum service life and safe operation, ensure that all the necessary inspections and maintenance have been completed before placing the machine into service. With proper care, maintenance and inspections performed per JLG's recommendations with any and all discrepancies corrected, this product will be fit for continued use.

Preparation, Inspection and Maintenance

It is important to establish and conform to a comprehensive inspection and preventive maintenance program. The following table outlines periodic machine inspections and maintenance recommended by JLG Industries, Inc. Consult your national, regional, or local regulations for further requirements for mobile elevating work platforms. Frequency of inspections and maintenance must be increased as environment, severity and frequency of usage requires.

Pre-Start Inspection

It is the User's or Operator's primary responsibility to perform a Pre-Start Inspection of the machine prior to use daily or at each change of operator. Reference the Operation and Safety Manual for completion procedures for the Pre-Start Inspection. The Operation and Safety Manual must be read in its entirety and understood prior to performing the Pre-Start Inspection.

Pre-Delivery Inspection and Frequent Inspection

The Pre-Delivery Inspection and Frequent Inspection shall be performed by a qualified JLG equipment mechanic.

JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

The Pre-Delivery Inspection and Frequent Inspection procedures are performed in the same manner, but at different times. The Pre-Delivery Inspection shall be performed prior to each sale, lease, or rental delivery.

The Frequent Inspection shall be accomplished for each machine in service for 3 months or 150 hours (whichever comes first); out of service for a period of more than 3 months; or when purchased used. Frequency of this inspection must

be increased as environment, severity and frequency of usage requires.

Reference the JLG Pre-Delivery and Frequent Inspection Form and the Inspection and Preventive Maintenance Schedule for items requiring inspection during the performance of these inspections.

Reference the appropriate areas of this manual for servicing and maintenance procedures.

Annual Machine Inspection

The Annual Machine Inspection must be performed on an annual basis, no later than thirteen (13) months from the date of the prior Annual Machine Inspection. JLG Industries recommends this task be performed by a Factory-Trained Service Technician. JLG Industries, Inc. recognizes a Factory-Trained Service Technician as a person who has successfully completed the JLG Service Training School for the subject JLG product model. Reference the machine Service and Maintenance Manual and appropriate JLG inspection form for performance of this inspection.

Reference the JLG Annual Machine Inspection Form and Inspection and Preventive Maintenance Schedule for items requiring inspection. Reference appropriate areas of this manual for servicing and maintenance procedures.

For the purpose of receiving safety-related bulletins, it is important that JLG Industries, Inc. has updated ownership information for each machine. When performing each Annual Machine Inspection, notify JLG Industries, Inc. of current machine ownership.

Preventive Maintenance

In conjunction with specified inspections, maintenance shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

Reference the Preventive Maintenance Schedule and the appropriate areas of this manual for servicing and maintenance procedures. The frequency of service and maintenance must be increased as environment, severity and frequency of usage requires.

Table 2-1. Inspection and Maintenance

| Type | Frequency | Primary Responsibility | Service Qualification | Reference |
|---------------------------|---|------------------------|--|--|
| Pre-Start Inspection | Prior to use each day; or at each Operator change. | User or Operator | User or Operator | Operation and Safety Manual |
| Pre-Delivery Inspection | Prior to each sale, lease, or rental delivery. | Owner, Dealer, or User | Qualified JLG Mechanic | Service and Maintenance Manual and applicable JLG inspection form. |
| Frequent Inspection | In service for 3 months or 150 hours, whichever comes first; or out of service for a period of more than 3 months; or purchased used. | Owner, Dealer, or User | Qualified JLG Mechanic | Service and Maintenance Manual and applicable JLG inspection form. |
| Annual Machine Inspection | Annually, no later than 13 months from date of prior inspection. | Owner, Dealer, or User | Factory-Trained Service Technician (Recommended) | Service and Maintenance Manual and applicable JLG inspection form. |
| Preventive Maintenance | At intervals as specified in Service and Maintenance Manual. | Owner, Dealer, or User | Qualified JLG Mechanic | Service and Maintenance Manual |

2.2 SERVICE AND GUIDELINES

General

The following information is provided to assist you in the use and application of servicing and maintenance procedures contained in this book.

Safety and Workmanship

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

Cleanliness

1. The most important single item in preserving the long service life of a machine is to keep dirt and foreign materials out of the vital components. Precautions have been taken to safeguard against this. Shields, covers, seals, and filters are provided to keep air, fuel, and oil supplies clean; however, these items must be maintained on a scheduled basis in order to function properly.

2. At any time when air, fuel, or oil lines are disconnected, clear adjacent areas as well as the openings and fittings themselves. As soon as a line or component is disconnected, cap or cover all openings to prevent entry of foreign matter.
3. Clean and inspect all parts during servicing or maintenance. Ensure all passages and openings are unobstructed. Cover all parts to keep them clean. Make sure all parts are clean before they are installed. New parts should remain in their containers until ready to be used.

Components Removal and Installation

1. Use adjustable lifting devices, whenever possible, if mechanical assistance is required. All slings (chains, cables, etc.) should be parallel to each other and as near perpendicular as possible to top of part being lifted.
2. Should it be necessary to remove a component on an angle, keep in mind the capacity of an eyebolt or similar bracket lessens, as the angle between the supporting structure and component becomes less than 90 degrees.
3. If a part resists removal, check to see if all nuts, bolts, cables, brackets, wiring, etc., have been removed and no adjacent parts are interfering.

Component Disassembly and Reassembly

When disassembling or reassembling a component, complete the procedural steps in sequence. Do not partially disassemble or assemble one part, then start on another. Always recheck your work to assure that nothing has been overlooked. Do not make any adjustments, other than those recommended, without obtaining proper approval.

Pressure-Fit Parts

When assembling pressure-fit parts, use an anti-seize or molybdenum disulfide base compound to lubricate the mating surface.

Bearings

1. When a bearing is removed, cover it to keep out dirt and abrasives. Clean bearings in nonflammable cleaning solvent and allow to drip dry. Compressed air can be used, but do not spin the bearing.
2. Discard bearings if races and balls (or rollers) are pitted, scored, or burned.
3. If bearing is found to be serviceable, apply a light coat of oil and wrap it in clean (waxed) paper. Do not unwrap reusable or new bearings until they are ready to install.
4. Lubricate new or used serviceable bearings before installation. When pressing a bearing into a retainer or bore, apply pressure to the outer race. If the bearing is to be installed on a shaft, apply pressure to the inner race.

Gaskets

Check that holes in gaskets align with openings in the mating parts. If it becomes necessary to hand-fabricate a gasket, use gasket material or stock of equivalent material and thickness. Be sure to cut holes in the right location, as blank gaskets can cause serious system damage.

Bolt Usage and Torque Application

NOTICE

SELF LOCKING FASTENERS, SUCH AS NYLON INSERT AND THREAD DEFORMING LOCKNUTS, ARE NOT INTENDED TO BE REINSTALLED AFTER REMOVAL.

1. Use bolts of proper length. A bolt which is too long will bottom before the head is tight against its related part. If a bolt is too short, there will not be enough thread area to engage and hold the part properly. When replacing bolts, use only those having the same specifications of the original, or one which is equivalent.
2. Unless specific torque requirements are given within the text, standard torque values should be used on heat-treated bolts, studs, and steel nuts, in accordance with recommended shop practices. (See Section 1.10 - Torque Charts.)

Hydraulic Lines and Electrical Wiring

Clearly mark or tag hydraulic lines and electrical wiring, as well as their receptacles, when disconnecting or removing them from the unit. This will assure that they are correctly reinstalled.

Hydraulic System

1. Keep the system clean. If evidence of metal or rubber particles are found in the hydraulic system, drain and flush the entire system.
2. Disassemble and reassemble parts on clean work surface. Clean all metal parts with non-flammable cleaning solvent. Lubricate components, as required, to aid assembly.

Lubrication

Service applicable components with the amount, type, and grade of lubricant recommended in this manual at the specified intervals. When recommended lubricants are not available, consult your local supplier for an equivalent that meets or exceeds the specifications listed.

Battery

Clean battery using a non-metallic brush and a solution of baking soda and water. Rinse with clean water. After cleaning, thoroughly dry battery and coat terminals with an anti corrosion compound.

Lubrication and Servicing

Components and assemblies requiring lubrication and servicing are shown in the Lubrication Chart in Section 1.

2.3 LUBRICATION AND INFORMATION

Hydraulic System

1. The primary enemy of a hydraulic system is contamination. Contaminants enter the system by various means, e.g., using inadequate hydraulic oil, allowing moisture, grease, filings, sealing components, sand, etc., to enter when performing maintenance, or by permitting the pump to cavitate due to insufficient system warm-up or leaks in the pump supply (suction) lines.
2. The design and manufacturing tolerances of the component working parts are very close, therefore, even the smallest amount of dirt or foreign matter entering a system can cause wear or damage to the components and generally results in faulty operation. Every precaution must be taken to keep hydraulic oil clean, including reserve oil in storage. Hydraulic system filters should be checked, cleaned, and/or replaced as necessary, at the specified intervals required in the Lubrication Chart in Section 1. Always examine filters for evidence of metal particles.
3. Cloudy oils indicate high moisture content which permits organic growth and causes oxidation or corrosion. If this condition occurs, the system must be drained, flushed, and refilled with clean oil.
4. It is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. Good grade mineral oils, with viscosities suited to the ambient temperatures in which the machine is operating, are recommended for use.

NOTE: *Metal particles may appear in the oil or filters of new machines due to the wear-in of meshing components.*

Hydraulic Oil

1. Refer to Section 1 for recommendations for viscosity ranges.
2. JLG recommends Standard UTTO Fluid, which has an SAE viscosity of 10W and a viscosity index of 140.

NOTE: *Start-up of hydraulic system with oil temperatures below -20 degrees F (-29 degrees C) is not recommended. If it is necessary to start the system in a sub-zero environment, it will be necessary to heat the oil with a low density, 100VAC heater to a minimum temperature of -20 degrees F (-29 degrees C).*

Changing Hydraulic Oil

1. Filter elements must be changed after the first 50 hours of operation and every 300 hours thereafter. If it is necessary to change the oil, use only those oils meeting or exceeding the specifications appearing in this manual. If unable to obtain the same type of oil supplied with the machine, consult local supplier for assistance in selecting the proper equivalent. Avoid mixing petroleum and synthetic base oils.
2. Use every precaution to keep the hydraulic oil clean. If the oil must be poured from the original container into another, be sure to clean all possible contaminants from the service container. Always clean the mesh element of the filter and replace the cartridge any time the system oil is changed.
3. While the unit is shut down, a good preventive maintenance measure is to make a thorough inspection of all hydraulic components, lines, fittings, etc., as well as a functional check of each system, before placing machine back in service.

Lubrication Specifications

Specified lubricants, as recommended by the component manufacturers, are always the best choice, however, multi-purpose greases usually have the qualities which meet a variety of single purpose grease requirements. Should any question arise, regarding the use of greases in maintenance stock, consult your local supplier for evaluation. Refer to Section 1 for an explanation of the lubricant key designations appearing in the Lubrication Chart.

2.4 CYLINDER DRIFT

Theory

When a hydraulic cylinder is supporting a load, cylinder drift may occur as a result of any of the circumstances below:

- Normal leakage of load holding valves or malfunction of load holding valves. See Cylinder Leakage Test and Section 2-2 - Cylinder Drift below for evaluation.
- Damaged or worn piston seals.
- Normal thermal expansion or contraction of the hydraulic oil within cylinders (See Cylinder Thermal Drift below).

The first two circumstances may result in cylinder movement due to oil leaking out of the cylinder externally or by leaking back to tank or due to oil leaking internally from one cylinder chamber to the other.

Thermal expansion or contraction of oil in hydraulic cylinders is a normal occurrence and does not result in oil leaking out of the cylinder or leaking internally from one cylinder chamber to the other. Thermal expansion or contraction is the tendency for materials to change size in response to a change in temperature.

Cylinder Leakage Test

Cylinder oil must be at stabilized ambient temperature before beginning this test.

Measure drift at cylinder rod with a calibrated dial indicator.

In an area free of obstructions, cylinder must have load applied and appropriately positioned to detect drift.

Cylinder leakage is acceptable if it passes this test.

Table 2-2. Cylinder Drift

| Cylinder Bore Diameter | | Max. Acceptable Drift in 10 Minutes | |
|------------------------|-------|-------------------------------------|------|
| inches | mm | inches | mm |
| 3 | 76.2 | 0.026 | 0.66 |
| 3.5 | 89 | 0.019 | 0.48 |
| 4 | 101.6 | 0.015 | 0.38 |
| 5 | 127 | 0.009 | 0.22 |
| 6 | 152.4 | 0.006 | 0.15 |
| 7 | 177.8 | 0.005 | 0.13 |
| 8 | 203.2 | 0.004 | 0.10 |
| 9 | 228.6 | 0.003 | 0.08 |

NOTE: This information is based on 6 drops per minute cylinder leakage.

Cylinder Thermal Drift

The oil in all hydraulic cylinders will expand or contract due to thermal effects over time and may result in changes to the boom and/or platform position while the machine is stationary. These effects occur as the cylinder oil changes temperature, usually from a higher oil temperature as it cools and approaches the ambient air temperature. Results of these effects are related to several factors including cylinder length and change in temperature over the time the cylinder remains stationary.

2.5 PINS AND COMPOSITE BEARING REPAIR GUIDELINES

Filament wound bearings.

1. Pinned joints should be disassembled and inspected if the following occurs:
 - a. Excessive sloppiness in joints.
 - b. Noise originating from joint during operation.
2. Filament wound bearings should be replaced if any of the following is observed:
 - a. Frayed or separated fibers on the liner surface.
 - b. Cracked or damaged liner backing.
 - c. Bearings that have moved or spun in their housing.
 - d. Debris embedded in liner surface.
3. Pins should be replaced if any of the following is observed (Clean pin before inspection):
 - a. Detectable bearing area wear.
 - b. Flaking, peeling, scoring, or scratches on pin surface.
 - c. Rusting of pin in bearing area.
4. Re-assembly of pinned joints using filament wound bearings:
 - a. Blow out housing using compressed air to remove all dirt and debris. Bearings and bearing housings must be free of all contamination.
 - b. Clean bearings and pins with solvent to remove all grease and oil.
 - c. Inspect pin to ensure it is free of burrs, nicks, and scratches which can damage bearing during installation and operation.

2.6 WELDING ON JLG EQUIPMENT

NOTE: This instruction applies to repairs, or modifications to the machine and to welding performed from the machine on an external structure, or component.

Do the Following When Welding on JLG Equipment:

- Disconnect the battery.
- Ground only to structure being welded.
- Unplug all pressure transducers (Refer to Section 6 - JLG Control System).

Do NOT Do the Following When Welding on JLG Equipment

- Ground on frame and weld on any other area than the chassis.
- Ground on turntable and weld on any other area than the turntable.
- Ground on the platform/support and weld on any other area than the platform/support.
- Ground on a specific boom section and weld on any other area than that specific boom section.
- Allow pins, wear pads, wire ropes, bearings, gearing, seals, valves, electrical wiring, or hoses to be between the grounding position and the welded area.

NOTICE

FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY RESULT IN COMPONENT DAMAGE (I.E. ELECTRONIC MODULES, SWING BEARING, COLLECTOR RING, BOOM WIRE ROPES ETC.)

Table 2-3. Inspection and Preventive Maintenance Schedule

| AREA | INTERVAL | |
|---|---|---|
| | Pre-Delivery ¹ or Frequent ² Inspection | Annual ³ (Yearly) Inspection |
| Boom Assembly | | |
| Boom Weldments | 1,2,4 | 1,2,4 |
| Hose/Cable Carrier Installations | 1,2,9,12 | 1,2,9,12 |
| Pivot Pins and Pin Retainers | 1,2 | 1,2 |
| Sheaves, Sheave Pins | 1,2 | 1,2 |
| Bearings | 1,2 | 1,2 |
| Wear Pads | 1,2 | 1,2 |
| Covers or Shields | 1,2 | 1,2 |
| Extend/Retract Chain or Cable Systems | 1,2,3 | 1,2,3 |
| Boom Assembly | 14 | 14 |
| Platform Assembly | | |
| Platform | 1,2 | 1,2 |
| Railing | 1 | 1,2 |
| Gate | 1,5 | 1,5 |
| Floor | 1 | 1,2 |
| Rotator | 9,5,15 | 9,5,15 |
| Lanyard Anchorage Point | 1,2,10 | 1,2,10 |
| Turntable Assembly | | |
| Swing Bearing | 1,2,14 | 1,2,3,13,14 |
| Oil Coupling | 9 | 9 |
| Swing Drive System | 11 | 11 |
| Turntable Lock | 1,2,5 | 1,2,5 |
| Hood, Hood Props, Hood Latches | 5 | 1,2,5 |
| Chassis Assembly | | |
| Spindle Thrust Bearing/Washers | 1,2 | 1,2 |
| Drive Hubs | 11 | 11 |
| Functions/Controls | | |
| Platform Controls | 5,6 | 5,6 |
| Ground Controls | 5,6 | 5,6 |
| Function Control Locks, Guards, or Detents | 1,5 | 1,5 |
| Footswitch | 5 | 5 |
| Emergency Stop Switches (Ground & Platform) | 5 | 5 |
| Function Limit or Cutout Switch Systems | 5 | 5 |

Table 2-3. Inspection and Preventive Maintenance Schedule

| AREA | INTERVAL | |
|--|---|---|
| | Pre-Delivery ¹ or Frequent ² Inspection | Annual ³ (Yearly) Inspection |
| Swing Brakes | 5 | 5 |
| Auxiliary Power | 5 | 5 |
| Power System | | |
| Engine Idle, Throttle, and RPM | 3 | 3 |
| Engine Fluids (Oil, Coolant, Fuel) | 9,11 | 9,11 |
| Air/Fuel Filter | 1,7 | 1,7 |
| Exhaust System | 1,9 | 1,9 |
| Batteries | 1,9 | 1,9,19 |
| Battery Fluid | 11 | 11 |
| Battery Charger | 5 | 5 |
| Fuel Reservoir, Cap, and Breather | 1,2,5 | 1,2,5 |
| Hydraulic/Electric System | | |
| Hydraulic Pumps | 1,2,9 | 1,2,9 |
| Hydraulic Cylinders | 1,2,7,9 | 1,2,7,9 |
| Cylinder Attachment Pins and Pin Retainers | 1,2,9 | 1,2,9 |
| Hydraulic Hoses, Lines, and Fittings | 1,2,9,12 | 1,2,9,12 |
| Hydraulic Reservoir, Cap, and Breather | 1,2,5,9 | 1,2,5,9,24 |
| Hydraulic Filter | 1,7,9 | 1,7,9 |
| Hydraulic Fluid | 7,11 | 7,11 |
| Electrical Connections | 1,20 | 1,20 |
| Instruments, Gauges, Switches, Lights, Horn | 5,23 | 5,23 |
| General | | |
| Operation and Safety Manuals in Storage Box | 21 | 21 |
| ANSI Manual of Responsibilities and AEM Safety Manual in Storage Box (ANSI Only) | 21 | 21 |
| Capacity Decals Installed, Secure, Legible | 21 | 21 |
| All Decals/Placards Installed, Secure, Legible | 21 | 21 |
| Annual Machine Inspection Due | 21 | 21 |
| No Unauthorized Modifications or Additions | 21 | 21 |
| All Relevant Safety Publications Incorporated | 21 | 21 |
| General Structural Condition and Welds | 2,4 | 2,4 |
| All Fasteners, Pins, Shields, and Covers | 1,2 | 1,2 |
| Grease and Lubricate to Specifications | 22 | 22 |
| Function Test of All Systems | 21,22 | 21,22 |
| Paint and Appearance | 7 | 7 |

Table 2-3. Inspection and Preventive Maintenance Schedule

| AREA | INTERVAL | |
|---|---|---|
| | Pre-Delivery ¹ or Frequent ² Inspection | Annual ³ (Yearly) Inspection |
| Stamp Inspection Date on Frame | | 22 |
| Notify JLG of Machine Ownership | | 22 |
| Footnotes: ¹ Prior to use each day; or at each Operator change ² Prior to each sale, lease, or delivery ³ In service for 3 months or 150 Hours; or Out of service for 3 months or more; or Purchased used | | |
| Performance Codes: 1 - Check for proper and secure installation 2 - Visual inspection for damage, cracks, distortion or excessive wear 3 - Check for proper adjustment 4 - Check for cracked or broken welds 5 - Operates Properly 6 - Returns to neutral or "off" position when released 7 - Clean and free of debris 8 - Interlocks function properly 9 - Check for signs of leakage 10 - Decals installed and legible 11 - Check for proper fluid level 12 - Check for chafing and proper routing 13 - Check for proper tolerances 14 - Properly lubricated 15 - Torqued to proper specification 16 - No gouges, excessive wear, or cords showing 17 - Properly inflated and seated around rim 18 - Proper and authorized components 19 - Fully charged 20 - No loose connections, corrosion, or abrasions 21 - Verify 22 - Perform 23 - Sealed Properly 24 - Drain, Clean, Refill | | |




Figure 2-1. Engine Operating Temperature Specifications - Deutz D2011L04





Figure 2-2. Engine Operating Temperature Specifications - Deutz TD2.9

SECTION 2 - GENERAL



| Fluid | Properties | | Base | | | | Classifications | | | |
|-----------------------|-------------|-----------------------------------|-----------------|--------------|----------------|-----------|----------------------|------------------------|-----------------------|-------------------|
| | Description | Viscosity at 40° C (cSt, typical) | Viscosity Index | Mineral Oils | Vegetable Oils | Synthetic | Synthetic Polyesters | Readily Biodegradable* | Virtually Non-toxic** | Fire Resistant*** |
| Mobilfluid 424 | | 55 | 145 | X | | | | | | |
| Mobil DTE 10 Excel 32 | | 32 | 141 | X | | | | | | |
| Univis HVI 26 | | 26 | 376 | X | | | | | | |
| Mobil EAL 224 H | | 36 | 212 | | X | | X | X | | |
| Mobil EnviroSyn H46 | | 49 | 145 | | | X | X | X | | |
| Quintolubric 888-46 | | 50 | 185 | | | | X | X | X | X |

* Readily biodegradable classification indicates one of the following:

CO2 Conversion > 60% per EPA 560/6-82-003

CO2 Conversion > 80% per CEC-L-33-A-93

** Virtually Non-toxic classification indicates an LC50 > 5000 ppm per OECD 203

*** Fire Resistant classification indicates Factory Mutual Research Corp. (FMRC) Approval

Figure 2-3. Hydraulic Oil Operating Temperature Specifications

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

A screenshot of the "Search Manuals" form. The form has a title "Search Manuals" and a subtitle "Please provide information to help us locate the manual and/or parts you need." It includes fields for "Brand", "Model", "Serial", "Part Number", and "Quantity". There is a "Search" button at the bottom.

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

A screenshot of the "Parts Order Form". The form has a title "Parts Order Form" and a subtitle "Please fill in as much information as possible." It includes fields for "Manufacturer", "Model", "Description", "Part Number", "Quantity", and "Comments". There is a "Submit" button at the bottom.

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 3. CHASSIS & TURNTABLE

3.1 CHASSIS TILT INDICATOR SYSTEM

The Chassis Tilt Indicator System measures the turntable angle with respect to level ground. The control system reads the reading and compares it to a preset turntable tilt angle value. When the machine is in transport position, it can travel at up to maximum speed until it tilts more than 8.0°, then the system will limit the drive speed to maximum displacement mode (slow drive speed). However, when the machine is out of transport position and the turntable tilts more than the preset value, the boom functions can only operate in creep speed mode, and the drive function is disabled. The operator has to return the machine into transport mode in order to continue to drive the machine. For machine setup see section 6.

3.2 AUXILIARY POWER SYSTEM

The Auxiliary Power System is intended as a secondary means to bring an operator from work height down to the ground in the event of primary power loss. This system uses an electric motor/pump unit powered by a 12V battery. It is not intended to be used as the main power source. All functions can be retracted or lowered and the jib can be lifted up. The auxiliary system levels the platform when lifting down. The drive function is excluded from the auxiliary system.

3.3 DRIVE ORIENTATION SYSTEM

The Drive Orientation System (DOS) indicates the conditions that could make the direction of movement of the chassis different than the direction of movement of the drive/steer control handle to the operator.


The system indicates to the operator the need to match the black and white directional arrows on the platform control panel to the arrows on the chassis. The system uses a proximity switch mounted on the hydraulic swivel, an indicator light and a spring return override switch on the platform display panel. The proximity switch trips when the turntable is swung ± 45 degrees off center of the normal driving position.

This occurs roughly when the main boom is swung beyond the rear of the machine. When the turntable is in the normal drive position with the boom at the rear of the machine, no indications or interlocks are made. When the machine is actively driving when the turntable is swung beyond the switch point, the system is ignored until drive/steer is released.

When drive is initiated with the boom swung beyond the switch point, the DOS indicator will flash and the drive/steer functions will be disabled. The operator must engage the DOS override switch to enable Drive/steer (high drive will remain disabled).

When the DOS is enabled, the DOS indicator will be illuminated continuously and a 3-second enable timer will be started and will continue for 3 seconds after the end of the last drive/steer command. If the timer expires, the DOS override switch must be re-engaged to enable drive/steer.


3.4 CHASSIS COMPONENTS AND SERVICING



- | | | | | |
|-------------------------|-----------------|--------------------------|---------------------|-------------------|
| 1. Track Chain Assembly | 7. Flanged Bolt | 13. Carrier Track Roller | 19. Grease Fitting | 25. Nut |
| 2. Undercarriage | 8. Cover Plate | 14. Bottom Track Roller | 20. Seal | 26. Flat Washer |
| 3. Bolt | 9. Lock washer | 15. Bolt | 21. Shock Assembly | 27. Bolt |
| 4. Flat Washer | 10. Bolt | 16. Flat Washer | 22. Spring Assembly | 28. Counterweight |
| 5. Drive Assembly | 11. Bolt | 17. Bolt | 23. Capscrew | |
| 6. Drive Sprocket | 12. Locknut | 18. Lock washer | 24. Idler Assembly | |

Figure 3-1. Chassis Assembly

Service Notes



MAE31660


Figure 3-2. Chassis Service Notes - 1 of 2

SECTION 3 - CHASSIS & TURNTABLE

| | |
|----|---|
| 1 | Track tension adjustment to be made between the idler and carrier roller: 0.781 in (19.8 mm) |
| 2 | Anti-Seize Compound to be used on master link pin before assembly. Torque Pad bolts over master link to 65 ft-lbs +6,-6 then tighten 1/3 (120°) turn further. |
| 3 | Fill Plug |
| 4 | Check oil level of left & right crawler drives (0.69 Gal [2.6L] grade 90 Gear Oil) |
| 5 | Drain Plug |
| 6 | Torque to 200 ft-lb, +15 -0 (280 Nm, +21 -0) |
| 7 | Use Gradall 8381-3109 Large Button Head Grease Fitting Adapter to Adjust Tracks |
| 8 | Torque to 65 ft-lb, +10 -0 (91 Nm, +15 -0) |
| 9 | Torque to 340 ft-lb, +25 -0 (476 Nm, +35 -0) |
| 10 | Offset in Idler Spring from center line of Idler to be oriented down. |
| 11 | Torque to 165 ft-lb, +15 -0 (231 Nm, +21 -0) |
| 12 | Apply Anti-Seize Compound to both mounting pilots Drive Motors |
| 13 | Torque to 230 ft-lb, +15 -0 (322 Nm, +21 -0) |
| 14 | Torque to 93 ft-lb, +10 -0 (130 Nm, +14 -0) |
| 15 | Torque to 53 ft-lb, +5 -0 (74 Nm, +7 -0) |

Figure 3-3. Chassis Service Notes - 2 of 2

Track and Chain



- | | | | |
|-------------------|-------------------|---------------------|----------|
| 1. Track Assembly | 4. Bushing | 7. Splice Hinge Pin | 10. Bolt |
| 2. Left Link | 5. Hinge Pin | 8. Spacer | 11. Nut |
| 3. Right Link | 6. Splice Bushing | 9. Track Cleat | |

TRACK SHOES

1. Visually check for loose or missing bolts at the start of each operating shift.
2. Check bolt torque approximately every 100 hours. Torque track shoe bolts to 65 ft-lb, +6 (91 Nm, +8.4), then tighten 1/3 turn (120°) further.

TRACK PIN

The track pin is pressed in the right and left link of the chain. It is also installed through bushing at each end of the link. Outside diameter (O.D.) of pin wears against inside diameter (I.D.) of bushing with which it is making contact. Once pin reaches allowable wear limit it may be rotated 180 degrees for extended life.

TRACK BUSHING (BEARING)

Track bushings fit in the counterbore of each link. There is one bushing per link set. The O.D. of the bushing contacts drive sprocket teeth during travel and results in bushing wear at sprocket side only. This wear and pin wear is a major factor in looseness and damage to the chain by increasing pitch length.

Replace Track

REMOVE TRACK



WARNING

UNCONTROLLED TRACK MOVEMENT CAN CAUSE SERIOUS INJURY. KEEP CLEAR OF TRACK WHEN REMOVING PIN.

1. Use wood blocking, a come-along, or other device to prevent track and chain assembly from falling uncontrolled to ground.



2. Remove four bolts (10), nuts (11), and track cleat (9) from chain assembly. Repeat with adjacent track cleat.

3. Use a portable press to push pin (5) out. Remove bushing (4).



LINKS, PIN, AND BUSHING WEAR MEASUREMENT

To establish average wear measurement, choose a length of 4 sections of link assembly on top of the undercarriage in a well tensioned zone.

When wear measurement reaches 100% limit turn pins 180° for extended life. If this operation has been previously performed, worn parts must be replaced.

INSTALL TRACK

NOTE: Chain must be installed with pin end of links facing back of machine at ground level.

1. Align chain and C-clamp spacer in two places on chain. Hammer in chain link aligning pin hole.
2. Insert alignment pin through hole to temporarily hold track together.
3. Position wood blocks to frame rail for tracks to lay onto when connecting track ends to get proper extension for connecting end links.



NOTICE

PINS AND BUSHINGS MUST BE WELL LUBRICATED DURING ASSEMBLY.

4. Apply anti-seize compound to pin. Line up end links, start pin in hole by driving with a hammer.
5. Place portable power pin press over track and pin. place washers in press ends. Carefully press in track pin.



6. Re-assemble four track shoes to assembled links.
7. Torque track shoe bolts to 65 ft-lb, +6 (91 Nm, +8.4), then tighten 1/3 turn (120°) further.

Track tensioning


1. Using special grease fitting tool (PN 83813109), pump in grease to add tension to track.




2. Check for 0.781 in (19.8 mm) tension between idler & carrier roller with level and gage. Remove special fitting.



Rubber Track Pad Installation




1. Seat rubber track pad over center rib of steel track.
2. Apply Medium Strength Threadlocking Compound to retaining plate bolts. Install bolts and flat washers to end of rubber pad.
3. Torque bolts to 70 ft-lb (97 Nm).



- | | | |
|----------------|------------|--------------------|
| 1. GuideRoller | 4. Bearing | 7. MountingBracket |
| 2. Shaft | 5. Ring | 8. O-ring |
| 3. Plug | 6. Seal | 9. RollPin |

Figure 3-4. Bottom Track Roller Assembly



- | | | | |
|-------------------|-------------------|------------------|----------------|
| 1. Guide Roller | 5. Washer | 9. Tension Ring | 13. Cover |
| 2. Shaft | 6. Roller Bearing | 10. Collar | 14. Cover Seal |
| 3. Internal Cover | 7. Not Used | 11. Packing Ring | 15. Lockwasher |
| 4. Bolt | 8. Seal Ring | 12. Seal Ring | 16. Bolt |

Figure 3-5. Upper Carrier Track Roller Assembly

Rollers

Rollers are "lifetime" lubricated and under normal working conditions no further lubrication is required. Idlers should be randomly checked while working to protect against destruction should a seal be damaged.

ROLLER SEALS

NOTICE

USED SEALS WILL MOST LIKELY FAIL SHORTLY AFTER REBUILD. ALWAYS USE NEW SEALS WHEN REASSEMBLING TRACK ROLLER.

NOTE: *Mating surface where seals contact must be dry and clean; free of dirt, nicks, and burrs.*

1. Install O-ring on roller shaft.
2. Install seal group into roller shell seat. Remove plastic band holding rings together.
3. Press collar on roller shaft and lock in place with dowel.
4. Invert roller assembly and perform steps 1 through 4.
5. Fill roller with lube.

TRACK ROLLER DISASSEMBLY

1. Remove lube fill plug and dump lube into a container.
2. Press dowel pin out of collar.
3. Remove seals and shaft.
4. Press out bushings.

TRACK ROLLER ASSEMBLY


1. Install bushings in roller shell.
2. Install collar to roller shaft.
3. Install dowel pin through collar and shaft.
4. Install O-ring in roller shaft.
5. Install seal group in roller shell seal seat.
6. Insert collar and shaft into shell until collar bottoms to the seal group.
7. Invert roller 180°.
8. Complete component assembly as in steps 2 through 6.
9. Fill Roller with lube.

BOTTOM TRACK ROLLER INSTALLATION

1. Blow out roller mounting holes With air gun. Wipe mounting surfaces clean with rag. Threads must be clean of grease and oil.
2. Apply Medium Strength Threadlocking Compound to four bolts. Align roller on frame and secure with four washers and bolts.
3. Torque bolts to 200 ft-lb +15-0 (280 Nm, +21 -0).
4. Use a low pressure pump with a nozzle that will fit through idler body fill hole. Fill with SAE 30 or SAE 40 oil at capacities for your machine.


Idler Roller Assembly

The idler roller assembly is located at the front of each side frame and acts as a shock absorber for the track system. Compensation is accomplished by a tensioning spring and hydraulic cylinder.



- | | | |
|-------------|---------------------|-------------|
| 1. Idler | 5. Mounting Bracket | 9. Not Used |
| 2. Shaft | 6. Seal | 10. O-ring |
| 3. Bearing | 7. Seal | 11. Plug |
| 4. Roll Pin | 8. Seal Holder | 12. Bracket |

Figure 3-6. Idler Assembly



- | | | |
|--------------------|---------------|-------------|
| 1. Mounting Flange | 5. Roll Pin | 9. Seal |
| 2. Spring | 6. Piston/Rod | 10. Seal |
| 3. Base Plate | 7. Wiper | 11. Fitting |
| 4. Locknut | 8. Barrel | |

Figure 3-7. Spring & Shock Assembly

TRACK TENSION AND IDLER ROLLER DISASSEMBLY

1. Relieve all pressure from track tensioning cylinder.
2. Carefully separate track chain and lay it on the ground.
3. Remove recoil device group.
4. Remove track tension group.
5. Remove two (slide brackets) support groups and idler pin from side frame.
6. Remove idler roller from machine.
7. Examine all fasteners and seals for damage. Replace damaged components.

TRACK TENSION AND IDLER ROLLER REASSEMBLY

1. Clean, lubricate, and check all components for damage.
2. Reassemble idler roller with support group and fork and install into side frame.
3. Install track tension group.
4. Torque all fasteners to correct value.
5. Reassemble track chain to side frame and lack master pin and bushing as required.
6. Pressurize tensioning cylinder to achieve the correct track adjustment.
7. Install cover over opening in side frame for valve used for tensioning cylinder adjustment.

IDLER ROLLER DISASSEMBLY

NOTE: Remove recoil components to access idler roller.

1. Remove one of the dowel pins that fasten the bracket to the shaft.
2. Remove remaining components which are now free of shaft.
3. Press out bushing. (Bushing can only be removed by a vertical press with correct tooling.)
4. If necessary, remove remaining dowel pins and bracket.

IDLER ROLLER ASSEMBLY

1. Press bushings into idler shell.
2. Mount a bracket on shaft.
3. Insert seal group into idler shell seal seat.
4. Install O-ring on shaft.
5. Insert complete sub assembly in idler shell to point where it bottoms the seal group.
6. Invert idler and assemble components as in steps 1 through 4.
7. After loose assembly press tightly together using a vertical press.

NOTE: Seal group is assembled same as in bottom rollers.

IDLER ROLLER AND TRACK TENSIONER REMOVAL AND REPLACEMENT TO SIDE FRAME**⚠ WARNING**

SERIOUS INJURY COULD RESULT IF THE PRESSURE IS NOT RELIEVED FROM TENSIONER AND RECOIL SYSTEM.

1. To remove pressure from cylinder, carefully back off one or two turns on the fill fitting. As soon as lube starts to come out vent hole **STOP backing off fitting.**
2. Once pressure is relieved it is safe to remove roller and tensioner assembly.
3. Assemble fitting and fitting seal in end of each shock assembly. Torque to chart specifications.

INSTALL SHOCK

1. Assemble shock assembly in position. Secure with bolts, washers, and Medium Strength Threadlocking Compound. Torque to 65 ft-lb +10-0 (91 Nm, +15 -0).
2. Using an adequate lifting device, pick up spring assembly upright onto idler assembly. Install using bolts, washers, and Medium Strength Threadlocking Compound. Torque to 165 ft-lb +15-0 (231 Nm, +21 -0).
3. Reference offset in idler spring from centerline of idler (to be oriented down). Using gantry crane and sling, pick up and slide spring/idler assembly into pre-greased slider area. Use nylon sledge hammer lightly to assemble.
4. Push idler assembly against seat. Using special adapter, pump in grease to expand shock assembly just enough to inspect for proper assembly.

3.5 SWING DRIVE HUB

Removal

1. Gently loosen the jack bolt (4). Do not remove.
2. Remove the pivot bolt (7).
3. Remove the mounting bolts (9) securing swing drive hub to the turntable.
4. Using the suitable lifting device, remove the swing drive hub from mounting plate without damaging the swing gear.


5. Place swing drive hub in the clean area.
6. Refer to Section 3-8., Swing Drive Installation, for swing drive maintenance.

Assembly/Disassembly

For detail assembly/disassembly instructions, Refer Swing Drive Hub Manual (PN 3128853).

Installation

Ensure mounting plate and mounting location of the base plate are clean and painted with a uniform coating of minimum thickness (no runs, drips, etc.).



1001185842-B
MAE22620


- | | | |
|------------------------|--------------|---------------|
| 1. Motor Control Valve | 4. Jack Bolt | 7. Pivot Bolt |
| 2. Swing Motor | 5. Nut | 8. Spacer |
| 3. Swing Hub Assembly | 6. Washer | 9. Bolt |

Figure 3-8. Swing Drive Installation

Procedure For Setting Swing Gear Backlash

Set backlash to 0.010 inch to 0.015 inch (0.254 mm - 0.381 mm) using the following procedure:


1. Place the machine on firm, level ground.
2. Place shim between pinion and bearing at bearing high spot (shown below).



3. Apply High Strength Threadlocking Compound and torque pivot bolt to 205 ft. lbs. (280 Nm).


NOTE: Make sure the turntable is properly supported during the following step. The turntable can swing a few degrees when the turntable lock is removed if the turntable is not balanced properly.

4. Remove turntable lock pin.
5. Apply High Strength Threadlocking Compound and pre-torque swing drive mounting bolts to 30 ft. lbs. (40 Nm).




6. Tighten jack bolt until pinion is completely snug against shim and bearing then loosen jack bolt.

7. Apply High Strength Threadlocking Compound and torque jack bolt 50 ft. lbs. (68 Nm).
8. Apply High Strength Threadlocking Compound and tighten jam nut.
9. Torque mounting bolts to 340 ft. lbs. (Nm).




10. Remove shim and discard.



Swing Drive Lubrication

Fill Swing Drive Gearbox with 32 oz (0.946 L) 80w90 gear oil with EP additives. Oil should cover the ring gear. Torque pipe plug to 23-25 ft.lbs (31- 33 Nm).



MAE22610

3.6 SWING BEARING

Turntable Bearing Mounting Bolt Condition Check

NOTE: This check is designed to replace existing bearing bolt torque checks on JLG Lifts in service. This check must be performed after first 50 hours of machine operation and every 600 hours of machine operation thereafter. If during this check any bolts are found to be missing or loose, replace missing or loose bolts with new bolts and torque to the value specified in the torque chart, after lubricating the bolt threads with High Strength Threadlocking Compound. After replacing and retorquing bolt or bolts recheck all existing bolts for looseness.

1. Check frame to bearing. Attach bolts as follows:
 - a. Elevate fully retracted main boom to 70 degrees (full elevation).
 - b. At the positions indicated on (See Figure 3-9.), try and insert the 0.0015 inch (0.0381 mm) feeler gauge between the bolt head and hardened washer at the arrow indicated position.
 - c. Assure that the 0.0015 inch (0.0381 mm) feeler gauge will not penetrate under the bolt head to the bolt shank.
 - d. Swing turntable 90 degrees and check some selected bolts are at the new position.
 - e. Continue rotating turntable at 90 degrees intervals until a sampling of bolts have been checked in all quadrants.
2. Check the turntable to bearing. Attach bolts as follows:
 - a. Elevate the fully retracted boom to 70 degrees (full elevation).
 - b. Try and insert the 0.0015" feeler gauge between bolt head and hardened washer at position shown in (See Figure 3-9.).
 - c. Lower the boom to horizontal and fully extend the boom.
 - d. Try and insert the 0.0015" feeler gauge between bolt head and hardened washer at position shown in (See Figure 3-9.).




Figure 3-9. Swing Bearing Bolt Feeler Gauge Check

Wear Tolerance

1. From underside of the machine, at rear center, with the boom fully elevated and fully retracted, as shown in Figure 3-11., Swing Bearing Tolerance Measurement Location & Boom Placement A, using a magnetic base dial indicator, measure and record distance between swing bearing and turntable as shown in Figure 3-10., Swing Bearing Tolerance Measuring Point.
2. At the same point, with the boom horizontal and fully extended, as shown in the Figure 3-11., Swing Bearing Tolerance Measurement Location & Boom Placement B, using a magnetic base dial indicator, measure and record distance between swing bearing and turntable as shown in Figure 3-10., Swing Bearing Tolerance Measuring Point.
3. If difference is greater than 0.079 inch (2.00 mm), is determined, the swing bearing should be replaced.
4. If a difference less than 0.079 inch (2.00 mm) is determined, and any of the following conditions exist, the bearing should be removed, disassembled, and inspected for the following:
 - a. Metal particles in grease.
 - b. Increased drive power required.
 - c. Noise.
 - d. Rough rotation.
5. If bearing inspection shows no defects, reassemble and return to service.

NOTICE

THE SWING BEARING IS ONE OF THE MOST CRITICAL POINTS ON AN MOBILE ELEVATING WORK PLAFORM. IT IS HERE THAT THE STRESSES OF LIFTING ARE CONCENTRATED, AT THE CENTER OF ROTATION. BECAUSE OF THIS, PROPER MAINTENANCE OF THESWING BEARING BOLTS IS A MUST FOR SAFE OPERATION.




Figure 3-10. Swing Bearing Tolerance Measuring Point




Figure 3-11. Swing Bearing Tolerance Measurement Location & Boom Placement

Swing Bearing Replacement

REMOVAL

1. From Ground Control station, place the boom in a level position.

⚠ WARNING

NEVER WORK BENEATH THE BOOM WITHOUT FIRST ENGAGING BOOM SAFETY PROP OR PROVIDING ADEQUATE OVERHEAD SLING SUPPORT AND/OR BLOCKING.

2. Adequately secure the boom to the rear of the turntable, as shown in Figure 3-13., Swing Bearing Removal.
3. Using the front lifting eyes in the turntable and a location on the boom equidistant from the center of gravity, as shown in Figure 3-13., Swing Bearing Removal, secure the turntable assembly with adequate lifting equipment.
4. From inside turntable, remove mounting hardware attaching rotary coupling retaining yoke brackets to turntable.

NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID THE ENTRY OF CONTAMINANTS INTO THE SYSTEM.

5. Tag and disconnect hydraulic lines from the fittings on the top of the rotary coupling. Use a suitable container to retain any residual hydraulic fluid. Immediately cap lines and ports.
6. Use a suitable tool to scribe a line on the inner race of the swing bearing and on the underside of the turntable. This will aid in aligning the bearing upon installation. Remove the bolts and washers which attach the turntable to the bearing inner race. Discard the bolts.
7. Use the lifting equipment to carefully lift the complete turntable assembly from the bearing. Ensure that no damage occurs to the turntable, bearing or frame-mounted components.
8. Carefully place the turntable on a suitably supported trestle.
9. Use a suitable tool to scribe a line on the outer race of the swing bearing and the frame. This line will aid in aligning the bearing upon installation. Remove the bolts and washers which attach the outer race of the bearing to the frame. Discard the bolts. Use suitable lifting equipment to remove the bearing from the frame, then move the bearing to a clean, suitably supported work area.

INSTALLATION

1. Using suitable lifting equipment, carefully lower the swing bearing into position on the frame. Ensure the scribed line of the outer race of the bearing aligns with the scribed line on the frame. If a new swing bearing is used, ensure that the filler plug fitting is at 90 degrees from the fore and aft center line of the frame.

⚠ CAUTION

JLG INDUSTRIES RECOMMENDS ALL REMOVED BEARING BOLTS BE DISCARDED AND REPLACED WITH NEW BOLTS. SINCE THE SWING BEARING IS THE ONLY STRUCTURAL LINK BETWEEN THE FRAME AND TURNTABLE, IT IS IMPERATIVE SUCH REPLACEMENT HARDWARE MEETS JLG SPECIFICATIONS. USE OF GENUINE JLG HARDWARE IS HIGHLY RECOMMENDED.

2. Apply a light coating of High Strength Threadlocking Compound to the new bearing bolts, and loosely install the bolts and washers through the frame and outer race of bearing.

⚠ CAUTION

IF COMPRESSED AIR OR ELECTRICALLY OPERATED IMPACT WRENCH IS USED FOR TIGHTENING THE BEARING ATTACHMENT BOLTS, THE TORQUE SETTING ACCURACY OF THE TOOL SHOULD BE CHECKED PRIOR TO USE.

3. Refer to the Torque Sequence diagram as shown in Figure 3-12., Swing Bearing Torque Sequence, Swing Bearing Torque Sequence Clean any residue off the new bearing bolts, then apply a light coating of High Strength Threadlocking Compound and install the bolts and washers through the frame and outer race of the bearing. Tighten the bolts to an initial torque of 190 ft. lbs. (260 Nm) w/Threadlocking compound.
4. Remove the lifting equipment from the bearing.
5. Using suitable lifting equipment, carefully position the turntable assembly above the machine frame.
6. Carefully lower the turntable onto the swing bearing, ensuring that the scribed line of the inner race of the bearing aligns with scribed line on the turntable. If a new swing bearing is used, ensure that the filler plug fitting is at 90 degrees from the fore and aft center line of the turntable.
7. Clean any residue off the new bearing bolts, then apply a light coating of High Strength Threadlocking Compound and install the bolts and washers through the turntable and inner race of the bearing.
8. Following the Torque Sequence diagram shown in Figure 3-12., Swing Bearing Torque Sequence, tighten the bolts to a torque of 190 ft. lbs. (260 Nm) w/Threadlocking Compound.
9. Install the rotary coupling retaining yoke brackets, apply a light coating of High Strength Threadlocking Compound to the attaching bolts and secure the yoke to the turntable with the mounting hardware.

10. Connect the hydraulic lines to the rotary coupling as tagged prior to removal.
11. Remove the lifting equipment.
12. Unsecure the boom from rear of turntable.
13. At ground control station, use boom lift control to lower boom to stowed position.
14. Using all applicable safety precautions, activate the hydraulic system and check the swing system for proper and safe operation.

Swing Bearing Torque Values

1. Outer Race - 190 ft-lb (260 Nm) w/Threadlocking Compound.
2. Inner Race - 190 ft-lb (260 Nm) w/Threadlocking Compound.
3. See Figure 3-12., Swing Bearing Torque Sequence.

⚠ WARNING

CHECK INNER AND OUTER SWING BEARING BOLTS FOR MISSING OR LOOSENESS AFTER FIRST 50 HOURS OF OPERATION AND EVERY 600 HOURS THEREAFTER.




Figure 3-12. Swing Bearing Torque Sequence





Figure 3-13. Swing Bearing Removal

3.7 ROTARY COUPLING


Assembly/Disassembly

For detail assembly/disassembly instructions and seal replacement of rotary coupling, contact JLG dealer.



- | | | |
|---------|-----------|-----------|
| 1. Bolt | 3. Washer | 5. Spacer |
| 2. Bolt | 4. Washer | 6. Mount |


Figure 3-14. Rotary Coupling Installation



- | | | |
|---------|---------------------|------------|
| 1. Bolt | 3. Proximity Switch | 5. Bracket |
| 2. Nut | 4. Washer | |


Figure 3-15. Rotary Coupling - Drive Orientation

3.8 DEUTZ TD2.9 L4 ENGINE




1. Fuel Tank 2. Deutz TD2.9 L4 Engine and Pump Assembly 3. Fuel Filter 4. Fuel Supply Pump

Figure 3-16. Deutz TD2.9 L4 Engine Installation



- | | | | |
|--------------------------------|---------------------------------|-----------------------------------|------------|
| 1. Gear Pump Assembly | 3. Piston Pump Assembly - Front | 5. Deutz TD2.9 L4 Engine Assembly | 7. Support |
| 2. Piston Pump Assembly - Rear | 4. Exhaust Pipe | 6. Hydraulic Oil Cooler | |

Figure 3-17. Deutz TD2.9 L4 Engine and Pumps Sub-Assembly



MAE26690

- | | | | |
|---------------|-------------------------|-------------|------------------|
| 1. Radiator | 5. Support | 9. Adapter | 13. Tray |
| 2. Bracket | 6. Pump Coupling | 10. Fan | 14. Bracket |
| 3. Surge Tank | 7. Bracket | 11. Pulley | 15. Engine Mount |
| 4. Air Filter | 8. Deutz TD2.9L4 Engine | 12. Adapter | 16. Engine Mount |

Figure 3-18. Deutz TD2.9 L4 Engine Assembly - Sheet 1 of 2




Figure 3-19. Deutz TD2.9 L4 Engine Assembly - Sheet 2 of 2

NOTE: Refer to engine manufacturer's manual for detailed operating and maintenance instructions.

Check Oil Level

1. Make sure machine and engine are level and switch engine OFF before checking oil level.
2. Remove oil dipstick and wipe with clean cloth.
3. Insert dipstick to the stop and remove again.
4. Check oil level. Top oil level as shown in figure below with an approved grade and type of oil outlined in engine manufacturer's operator's manual.




Figure 3-20. Deutz 2.9 T4F Dipstick Markings

5. Replace dipstick until fully seated.

Change Engine Oil

1. Allow engine to warm up. Engine oil should reach approximately 176° F (80° C).
2. Make sure machine and engine are level and switch off engine.
3. Place oil tray under engine.

CAUTION

HOT ENGINE OIL CAN CAUSE BURNS. AVOID CONTACT WITH HOT OIL WHEN DRAINING.

NOTICE

COLLECT USED OIL IN A CONTAINER SUITABLE FOR DISPOSAL OR RECYCLING. DISPOSE OF USED ENGINE OIL IN ACCORDANCE WITH ENVIRONMENTAL REGULATIONS.

4. Open oil drain valve and drain oil.
5. Close oil drain valve.

6. Pour in new engine oil. Refer to Section 1 for capacity and Figure 3-21., Engine Oil Viscosity.





Figure 3-21. Engine Oil Viscosity


Change Oil Filter

1. Wipe area around filter to clean any dirt from area.
2. Using a suitable oil filter removal tool, loosen lube oil filter cartridge and spin off.



3. Catch any escaping oil.
4. Clean any dirt from filter carrier sealing surface.
5. Lightly coat new oil filter rubber gasket with clean oil.
6. Screw in new filter by hand until gasket is flush.

- Hand-tighten filter another half-turn.




- Check oil level.
- Check oil pressure.
- Check oil filter cartridge for leaks.

Change Fuel Filters

⚠ WARNING


FUEL IS FLAMMABLE AND CAN CAUSE DEATH OR SERIOUS INJURY. MAKE SURE NO OPEN FLAMES OR SPARKS ARE IN THE AREA WHEN WORKING ON FUEL SYSTEM. DO NOT SMOKE WHEN WORKING ON FUEL SYSTEM.

- Wipe area around filter to clean any dirt from area.
- Disconnect water sensor connector (Pre-filter Only).
- Remove fuel filter cartridge. Catch any escaping fuel.



- Clean dirt from filter carrier sealing surface.
- Apply light film of oil or diesel fuel to rubber gasket of new filter cartridge.

- Screw in new filter by hand until gasket is flush. Hand-tighten filter another half-turn.



- Connect water sensor connector (Pre-filter Only).
- Open fuel shut-off valve.
- Check for leaks.

Spark Arrester Cleaning Instructions

- Remove cleanout plug in bottom of spark arrester (muffler).
- Without causing deformation (or any type of damage to spark arrester) repeatedly tap on arrester near cleanout plug. This may be enough to begin spark trap drainage.
- An industrial vacuum cleaner can do a complete job at this point.
 - Or, IN A SAFE AREA, start engine. Alternate between low idle and high idle for two to three minutes.
 - Or, operate engine as required by application for two to three minutes.
- Install cleanout plug.

Glow Plugs

If glow plug option is enabled in the JLG Control System, glow plug and indicator lamp will be energized when Power/Emergency Stop switch is pulled on if ambient air temperature is less than 50° F (10° C) and engine coolant temperature is less than 140° F (60° C).

This determination occurs one second after the Power/Emergency Stop switch has been pulled on. Lamp and glow plugs remain energized for period of time specified by setting in the JLG Control System. Engine start is disabled during this period.

On Deutz engines, glow plugs continue (post glow) after engine has started three times the machine digit setting.

Replacing the Fuel Pre-Filter





Figure 3-22. Location of Fuel Pre-Filter

NOTE: Refer Figure 3-23., Components of Fuel Pre-Filter.



- | | |
|---------------------------------|---|
| 1. Fuel Supply Flow to the Pump | 3. Electrical Connection for Water Level Sensor |
| 2. Venting Screw | 4. Drain Plug |
| | 5. Filter Element |

Figure 3-23. Components of Fuel Pre-Filter

⚠ WARNING

WHEN WORKING ON THE FUEL SYSTEM, MAKE SURE THERE ARE NO OPEN FLAMES OR SPARKS IN THE AREA. DO NOT SMOKE WHEN WORKING ON THE FUEL SYSTEM.

1. Switch off the engine.
2. Fuel supply from the fuel tank may need to be blocked to prevent fuel flow from the tank.
3. Place suitable collecting container under drain plug.
4. Disconnect electrical connections from water sensor.
5. Loosen drain plug and drain liquid.
6. Remove filter element.
7. Catch any escaping fuel.
8. Clean any dirt of the sealing surfaces of the new filter element and opposite side of filter head.
9. Wet the sealing surfaces of new filter element slightly with fuel.
10. Install new filter onto the filter head in clockwise direction. Torque to 12.5-13.3 ft. lbs. (17-18 Nm).
11. Install the drain plug and tighten to torque 1-1.4 ft. lbs. (1.3-1.9 Nm).
12. Connect electrical connection to water sensor.
13. Check for leaks after starting engine.

Water in Fuel Sensing System (Optional)

The Water in Fuel Sensing System detects when there is an excessive amount of water in the fuel and sets a DTC code in the JLG Control System to alert the operator and/or service technician.

When Water in Fuel condition occurs, the machine will respond in the following way:

- The engine will shut down automatically.
- The JLG Control System will set DTC 4375 - Water in Fuel.
- An alarm will sound from the active control station (ground or platform).
- If in platform mode, the Low Fuel Indicator will flash.
- Engine Restart will be permitted after the machine senses the Water in Fuel condition, but will only run for 2 minutes and the engine will shut down again. This restart process will continue until the Water in Fuel condition is corrected.

Draining Water

Frequency of water draining is determined by the contamination level of the fuel. Inspect or drain the collection bowl of water daily or as necessary. The collection bowl must be drained before contaminants reach the top of the turbine or


when the Water Detection Module (optional) indicates it's time to drain water.

Pressure Applications / Installations:

1. Open the drain plug on the bottom of the bowl to evacuate water and contaminants with a suitable collection container in place.
2. Close the drain after all the water and contaminants have been evacuated.

NOTE: Do not leave the drain open too long as it may completely drain the entire filter assembly of water and fuel.

Auxiliary Fuel Filter



- | | |
|-------------------|---------------|
| 1. T-handle | 3. Lid |
| 2. Filter Element | 4. Drain Plug |

Figure 3-24. Components of Auxiliary Fuel Filter

⚠ WARNING

WHEN WORKING ON THE FUEL SYSTEM, MAKE SURE THERE ARE NO OPEN FLAMES OR SPARKS IN THE AREA. DO NOT SMOKE WHEN WORKING ON THE FUEL SYSTEM.

ELEMENT REPLACEMENT

Frequency of element replacement is determined by the contamination level of the fuel. Replace the elements every 500 hours, if power loss is noticed or annually, whichever comes first.

1. Switch off the engine.
2. Fuel supply from the fuel tank may need to be blocked to prevent fuel flow from the tank.

3. Wipe the area around the filter to clean any dirt from the area.
4. Remove the T-handle and lid.
5. Remove the element by holding the bail handles and slowly pulling upward with a twisting motion. Dispose of properly.
6. Replace old lid gasket and T-handle O-ring with new seals (supplied with new element). Lubricate both seals with motor oil or diesel fuel before installation.
7. Refer to Priming of auxiliary fuel filter or fill the unit with clean fuel, then replace the lid and T-handle then tighten snugly by hand only.

NOTE: Do not use any tool for removal and installation of T-handle.

PRIMING OF AUXILIARY FUEL FILTER

1. Remove the T-handle and lid from the top of the filter assembly.
2. Fill the filter assembly with clean fuel.
3. Lubricate lid gasket and T-handle O-ring with clean fuel or motor oil.
4. Replace the lid and T-handle and tighten snugly by hand only.

NOTE: Do not use any tool for removal and installation of T-handle.

5. Start engine and check for fuel system leaks.
6. Correct as necessary with engine off and pressure relieved from filter assembly.

DRAINING WATER

Frequency of water draining is determined by the contamination level of the fuel. Inspect or drain the collection bowl of water daily or as necessary. The collection bowl must be drained before contaminants reach the top of the turbine or when the Water Detection Module (optional) indicates it's time to drain water.

Pressure Applications / Installations:

1. Open the self-venting drain plug on the bottom of the bowl to evacuate water and contaminants with a suitable collection container in place. Head pressure will push any water and contaminants out of the drain while keeping the filter primed.
2. Close the drain after all the water and contaminants have been evacuated.
3. If necessary, follow priming of auxiliary fuel filter.

NOTE: Do not leave the drain open too long as it may completely drain the entire filter assembly of water and fuel.

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|-----|-----|---|
| 16 | 0 | No detail information |
| 16 | 0 | BusOff error CAN No detail information |
| 29 | 3 | Hand throttle idle validation switch; short circuit to battery |
| 29 | 4 | Hand throttle; short circuit to ground |
| 29 | 2 | Plausibility error between sensor and idle switch, Acceleration Pedal Detection. In case of Hand Throttle with Low Idle Switch, it is the plausibility check between hand throttle and idle switch. |
| 51 | 5 | Intake Throttle Flap, H-Bridge, wiring harness broken at connected actuator |
| 51 | 6 | Intake Throttle Flap, H-Bridge, current above maximum threshold |
| 51 | 3 | Intake Throttle Flap, H-Bridge, short circuit to battery (A02) |
| 51 | 3 | Intake Throttle Flap, H-Bridge, short circuit to battery (A67) |
| 51 | 4 | Intake Throttle Flap, H-Bridge, short circuit to ground (A02) |
| 51 | 4 | Intake Throttle Flap, H-Bridge, short circuit to ground (A67) |
| 51 | 7 | Intake Throttle Flap, H-Bridge, position of actuator not plausible (deviation from set point more than 7%) |
| 51 | 3 | Intake Throttle Flap, H-Bridge, short circuit to battery oder broken wiring harness |
| 51 | 4 | Intake Throttle Flap, H-Bridge, short circuit to ground |
| 91 | 3 | Sensor error accelerator pedal. signal range check high. |
| 91 | 4 | Sensor error accelerator pedal. Signal is below the range. |
| 91 | 11 | Plausibility error between APP1 and APP2 or APP1 and idle switch. |
| 94 | 3 | Sensor error low fuel pressure; signal range check high |
| 94 | 4 | Sensor error low fuel pressure; signal range check low |
| 94 | 1 | Low fuel pressure; warning threshold exceeded |
| 94 | 1 | Low fuel pressure; shut off threshold exceeded |
| 97 | 3 | Sensor error water in fuel; signal range check high |
| 97 | 4 | Sensor error water in fuel; signal range check low. |
| 97 | 12 | Water in fuel level prefilter; maximum value exceeded |
| 98 | 2 | Plausibility Check; No detail information |
| 100 | 3 | Sensor error oil pressure; signal range check high |
| 100 | 4 | Sensor error oil pressure sensor; signal range check low |
| 100 | 0 | High oil pressure; warning threshold exceeded. |
| 100 | 0 | High oil pressure; shut off threshold exceeded |
| 100 | 1 | Low oil pressure; warning threshold exceeded |
| 100 | 1 | Low oil pressure; shut off threshold exceeded |
| 102 | 2 | Charged air pressure above warning threshold. |
| 102 | 2 | Charged air pressure above shut off threshold. |
| 102 | 2 | Pressure downstream charge air cooler, plausibility error |
| 102 | 1 | Pressure downstream charge air cooler, pressure below lower physical threshold |
| 102 | 3 | Pressure downstream charge air cooler, short circuit to battery or open load |
| 102 | 4 | Pressure downstream charge air cooler, short circuit to ground |
| 105 | 1 | Charged Air cooler down stream temperature. Temperature below lower physical threshold. |
| 105 | 3 | Electrical error charged air temperature. Signal range check high.(SRC) |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|-----|-----|--|
| 105 | 4 | Electrical error charged air temperature. Signal range check low. |
| 105 | 0 | Charged air cooler temperature. System reaction initiated. High charged air cooler temperature. Warning threshold exceeded. |
| 105 | 0 | High charged air cooler temperature. Shut off threshold exceeded. |
| 105 | 11 | Diagnostic fault check for charged air cooler downstream temperature sensor No detail information |
| 107 | 3 | Sensor error air filter differential pressure; short circuit to battery |
| 107 | 0 | Sensor error air filter differential pressure; short circuit to ground |
| 107 | 0 | Air filter differential pressure; air filter clogged. |
| 108 | 11 | DFC for CAN message |
| 108 | 3 | Sensor error ambient air pressure; signal range check high |
| 108 | 4 | Sensor error ambient air pressure; signal range check low |
| 110 | 2 | Defect fault check for Absolute plausibility test. No detail information |
| 110 | 0 | Physical Range Check high for Coolant temperature |
| 110 | 1 | Physical Range Check low for Coolant temperature. |
| 110 | 3 | Sensor error coolant temperature; signal range check high |
| 110 | 4 | Sensor error coolant temperature; signal range check low |
| 110 | 0 | High coolant temperature; warning threshold exceeded |
| 110 | 0 | Coolant temperature; system reaction initiated |
| 111 | 1 | Coolant level too low |
| 132 | 1 | The air mass flow AFS_dm is greater than or equal to AFS_PhysRng_Min_C Physical Range Check low for air mass flow sensor. No detail information |
| 157 | 0 | Rail pressure raw value is intermittent. No detail information |
| 157 | 1 | Rail pressure raw value is above maximum offset. No detail information |
| 157 | 3 | Sensor error rail pressure. Sensor voltage above upper limit. |
| 157 | 4 | Sensor error rail pressure. Sensor voltage below lower limit. |
| 164 | 2 | Rail pressure safety function is not executed correctly. |
| 168 | 3 | Sensor error battery voltage; signal range check high. |
| 168 | 4 | Sensor error battery voltage; signal range check low |
| 168 | 2 | High battery voltage; warning threshold exceeded |
| 168 | 2 | High battery voltage; shot off threshold exceeded |
| 168 | 0 | Physical range check high for battery voltage |
| 168 | 1 | Physical range check low for battery voltage |
| 171 | 0 | Environment temperature sensor, temperature above upper physical threshold |
| 171 | 1 | Environment Temperature Physical Range Check low |
| 171 | 3 | Sensor error SCR-System environment temperature; DPF-System air inlet temperature; signal range check high |
| 171 | 4 | Sensor error SCR-System environment temperature; DPF-System air inlet temperature; signal range check low |
| 172 | 2 | Air inlet filter temperature, plausibility error |
| 172 | 3 | Air flow temperature sensor; short circuit to battery or open load. |
| 172 | 4 | Air flow temperature sensor; short circuit to ground |
| 172 | 1 | Air inlet filter sensor out of physical range check |
| 172 | 0 | air temperature within air filter box above maximum physical value |

SECTION 3 - CHASSIS & TURNTABLE

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|-----|-----|---|
| 174 | 11 | DFC for fuel temperature plausibility check function. No detail information |
| 175 | 3 | Sensor error oil temperature; signal range check high |
| 175 | 4 | Sensor error oil temperature; signal range check low |
| 175 | 0 | High oil temperature; warning threshold exceeded |
| 175 | 0 | High oil temperature; shut off threshold exceeded |
| 175 | 2 | Customer oil temperature: signal unplausible |
| 190 | 0 | Engine speed above warning threshold Over speed detection in component engine protection |
| 190 | 0 | Engine speed above warning threshold (FOC-Level 1) |
| 190 | 11 | Engine speed above warning threshold (FOC-Level 2) |
| 190 | 14 | Engine speed above warning threshold (Overrun Mode) |
| 190 | 8 | Sensor camshaft speed; disturbed signal |
| 190 | 12 | Sensor camshaft detection; out of range, signal disrupted; no signal |
| 190 | 2 | Offset angle between crank- and camshaft sensor is too large. |
| 190 | 8 | Sensor crankshaft detection; out of range, signal disrupted; disturbed signal |
| 190 | 12 | Speed detection; out of range, signal disrupted Sensor crankshaft speed; no signal |
| 190 | 14 | Camshaft- and Crankshaft speed sensor signal not available on CAN |
| 411 | 4 | Physical range check low for EGR differential pressure |
| 411 | 0 | Delta pressure across venturi in EGR line above physical high limit |
| 411 | 0 | Plausibility Check fault for deviation of desired and actual EGR-mass flow, where the latter is calculated out of EGR Delta Pressure Sensor |
| 411 | 3 | Sensor error differential pressure Venturiunit (EGR), signal range check low. |
| 411 | 4 | Sensor error differential pressure Venturiunit (EGR), signal range check high. |
| 412 | 3 | Electrical error EGR cooler downstream temperature. Signal range check high. |
| 412 | 4 | electrical error EGR cooler downstream temperature. Signal range check low. |
| 520 | 9 | Timeout Error of CAN-Receive-Frame TSC1TR; control signal |
| 598 | 2 | Plausibility check for Clutch. No detail information |
| 624 | 5 | SVS lamp; open load |
| 624 | 12 | SVS lamp; power stage over temperature |
| 624 | 3 | SVS lamp; short circuit to battery |
| 624 | 4 | SVS lamp; short circuit to ground |
| 630 | 12 | Access error EEPROM memory (delete) |
| 630 | 12 | Access error EEPROM memory (read) |
| 630 | 12 | Access error EEPROM memory (write) |
| 639 | 14 | CAN-Bus 0 "BusOff-Status" |
| 651 | 5 | Injector 1 (in firing order); interruption of electric connection |
| 651 | 3 | Injector 1 (in firing order); short circuit |
| 652 | 5 | Injector 2 (in firing order); interruption of electric connection |
| 652 | 3 | Injector 2 (in firing order); short circuit |
| 653 | 5 | Injector 3 (in firing order); interruption of electric connection |
| 653 | 3 | Injector 3 (in firing order); short circuit |
| 654 | 5 | Injector 4 (in firing order); interruption of electric connection |
| 654 | 3 | Injector 4 (in firing order); short circuit |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|------|-----|--|
| 655 | 5 | Injector 5 (in firing order); interruption of electric connection |
| 655 | 3 | Injector 5 (in firing order); short circuit |
| 655 | 4 | High side to low side short circuit in the injector 5 (in firing order) |
| 656 | 5 | Injector 6 (in firing order); interruption of electric connection |
| 656 | 3 | Injector 6 (in firing order); short circuit |
| 656 | 4 | High side to low side short circuit in the injector 6 (in firing order) |
| 676 | 11 | Cold start device relay error |
| 676 | 11 | Cold start aid relay open load |
| 677 | 3 | Starter relay high side. Short circuit to battery. |
| 677 | 4 | Starter relay high side short circuit to ground. |
| 677 | 5 | Starter relay low side no load error. |
| 677 | 12 | Starter relay power stage over temperature. |
| 677 | 3 | Starter relay low side short circuit to battery. |
| 677 | 4 | Starter relay low side short circuit to ground. |
| 729 | 5 | Cold start aid relay open load |
| 729 | 12 | Cold start aid relay; over temperature error |
| 729 | 3 | Intake Air Heater Device; Short circuit to battery |
| 729 | 4 | Air intake heater; Short circuit to ground error for power stage on CJ945. |
| 898 | 9 | Timeout Error of CAN-Receive-Frame TSC1TE; Set point |
| 975 | 5 | PWM-Signal Fan, Open load or short-circuit ground |
| 975 | 3 | PWM-Signal Fan, short-circuit to plus |
| 975 | 4 | PWM-Signal Fan, open load or short circuit to ground |
| 1079 | 13 | Failure of sensor supply voltage 1. |
| 1080 | 13 | Failure of sensor supply voltage 2. |
| 1109 | 2 | Engine shut off demand ignored |
| 1136 | 0 | Physical range check high for ECU temperature |
| 1176 | 0 | Pressure sensor upstream turbine, Physical Range Check high. |
| 1176 | 1 | Pressure sensor upstream turbine, Physical Range Check low. |
| 1176 | 3 | Pressure sensor upstream turbine, signal range check (SRC) high. |
| 1176 | 4 | Pressure sensor upstream turbine, signal range check (SRC) low. |
| 1180 | 3 | Sensor error exhaust gas temperature upstream turbine; signal range check high |
| 1180 | 4 | Sensor error exhaust gas temperature upstream turbine; signal range check low |
| 1180 | 0 | Physical range check high for exhaust gas temperature upstream turbine |
| 1180 | 1 | Physical range check low for exhaust gas temperature upstream turbine |
| 1188 | 11 | Wastegate actuator; internal error |
| 1188 | 11 | Wastegate actuator; EOL calibration not performed correctly |
| 1188 | 13 | Wastegate actuator calibration deviation too large, re-calibration required |
| 1188 | 2 | Wastegate; status message from ECU missing |
| 1188 | 7 | Wastegate actuator; blocked |
| 1188 | 11 | Wastegate actuator; over temperature (> 135°C) |
| 1188 | 11 | Wastegate actuator; operating voltage error |
| 1188 | 7 | Turbocharger wastegate, mechanical blocking detected. |
| 1188 | 2 | Turbocharger wastegate, CAN Error |

SECTION 3 - CHASSIS & TURNTABLE

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|------|-----|--|
| 1188 | 13 | Turbocharger wastegate, EOL calibration error. |
| 1188 | 12 | Turbocharger wastegate, internal electrical error |
| 1188 | 13 | Turbocharger wastegate, learning process aborted. |
| 1188 | 6 | Turbocharger wastegate, current above maximum threshold. |
| 1188 | 3 | Turbocharger wastegate, supply voltage above maximum threshold. |
| 1188 | 4 | Turbocharger wastegate, supply voltage below minimum threshold. |
| 1188 | 13 | Turbocharger wastegate, learning process out of range. |
| 1188 | 7 | Turbocharger wastegate, broken spring detected. |
| 1188 | 0 | Turbocharger wastegate, temperature critical high. |
| 1231 | 14 | CAN-Bus 1 "BusOff-Status" |
| 1235 | 14 | CAN-Bus 2 = CAN_C reports Bus-error (for engines <8L and CV52 it is the engine-CAN@250kbaud) CAN Bus error passive; warning CAN C - engine CAN |
| 1235 | 14 | CAN-Bus 2 = engine bus "BusOff-Status" |
| 1237 | 2 | Override switch; plausibility error. |
| 1322 | 12 | N/A |
| 1323 | 12 | Too many recognized misfires in cylinder 1 (in firing order) |
| 1323 | 12 | N/A |
| 1323 | 12 | N/A |
| 1323 | 12 | N/A |
| 1323 | 12 | N/A |
| 1323 | 12 | N/A |
| 1346 | 0 | Misfire detection monitoring No detail information |
| 1638 | 2 | Hydraulic oil temperature check for Shut off condition |
| 1639 | 12 | Fan speed sensor; electrical error or signal disturbed or very low fan speed |
| 1639 | 0 | Sensor error fan speed; signal range check high or engine speed respective fan speed too high |
| 1639 | 1 | Sensor error fan speed; signal range check low or fan speed too low |
| 1761 | 14 | DEF tank level; warning threshold exceeded |
| 1761 | 0 | DEF tank, DEF level above upper physical threshold |
| 1761 | 1 | DEF tank, DEF level below lower physical threshold |
| 1761 | 14 | Urea Tank Signal to HMI for indicating the Urea Tank -Level (Urea tank volume ratio low threshold 1) |
| 1761 | 14 | DEF tank, DEF level below first warning threshold |
| 1761 | 14 | DEF tank, DEF level below second warning threshold |
| 1761 | 2 | DEF tank level, plausibility error |
| 1761 | 14 | DEF tank, DEF level below third warning threshold |
| 2634 | 12 | Early opening defect of main relay No detail information |
| 2634 | 12 | DFC for stuck main relay error No detail information |
| 2659 | 2 | Exhaust Gas Recirculation AGS Sensor; signal not plausible |
| 2659 | 0 | Exhaust Gas Recirculation AGS Sensor; Sensed exhaust mass value above maximum physical value |
| 2659 | 1 | Exhaust Gas Recirculation AGS Sensor; Sensed exhaust mass value below minimum physical value |
| 2659 | 12 | Exhaust Gas Recirculation AGS Sensor; plausibility error, AGS sensor has not passed the burn off process |
| 2659 | 2 | Exhaust Gas Recirculation AGS Sensor; Temperature of EGR mass not plausible |
| 2791 | 12 | Actuator EGR Valve; power stage over temperature |
| 2791 | 7 | EGR actuator, actuator blocked |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|------|-----|--|
| 2791 | 2 | EGR actuator, CAN error |
| 2791 | 13 | EGR actuator, EOL calibration error |
| 2791 | 12 | EGR Actuator, internal electrical fault |
| 2791 | 13 | EGR actuator, learning process aborted |
| 2791 | 6 | EGR actuator current is above maximum threshold |
| 2791 | 3 | EGR actuator supply voltage is above the maximum threshold |
| 2791 | 4 | EGR actuator supply voltage is below minimum threshold. |
| 2791 | 13 | EGR actuator, learning process out of range |
| 2791 | 7 | EGR actuator, broken spring detected. |
| 2791 | 16 | EGR actuator, temperature high. |
| 2791 | 0 | EGR actuator, temperature critical high |
| 2797 | 4 | Timeout of Short-Circuit Ground Diagnosis Cyl. Bank 0;_IVDiaShCirGndToutBnk_0 |
| 2797 | 4 | Injector diagnostic; Short circuit to ground cylinder bank 0 |
| 2798 | 4 | Timeout of Short-Circuit Ground Diagnosis Cyl. Bank 1;_IVDiaShCirGndToutBnk_1 |
| 2798 | 4 | Injector diagnostic; Short circuit to ground cylinder bank 1 |
| 3031 | 0 | DEF tank, DEF temperature in DEF tank is to high. |
| 3031 | 1 | DEF tank, DEF temperature below lower physical threshold |
| 3031 | 2 | Urea tank temperature outside of plausible thresholds |
| 3219 | 2 | DFC SAE J1939 error No detail information |
| 3224 | 2 | DLC Error of CAN-Receive-Frame AT11G1 NOX Sensor (SCR-system upstream cat; DPF-system downstream cat); length of frame incorrect |
| 3224 | 9 | Timeout Error of CAN-Receive-Frame AT11G1; NOX sensor upstream |
| 3224 | 2 | DLC Error of CAN-Receive-Frame AT11G1Vol NOX sensor. |
| 3224 | 9 | Timeout Error of CAN-Receive-Frame AT11G1Vol; NOX sensor. |
| 3224 | 1 | DFC for plausibility error Max for NOx sensor upstream of SCR Cat |
| 3226 | 2 | Nox feed back fault detection No detail information |
| 3227 | 2 | DFC SAE J1939 error No detail information |
| 3234 | 2 | DLC Error of CAN-Receive-Frame AT101 No detail information |
| 3234 | 9 | Timeout Error of CAN-Receive-Frame AT10G1; NOX sensor (SCR-system downstream cat; DPF-system downstream cat) |
| 3234 | 2 | DLC Error of CAN-Receive-Frame AT101Vol NOX |
| 3234 | 9 | Timeout Error of CAN-Receive-Frame AT10G1Vol. |
| 3234 | 11 | DFC for plausibility error Min for NOx sensor downstream of SCR Cat. |
| 3241 | 0 | Sensor SCR catalyst upstream temperature too high; plausibility error. |
| 3248 | 4 | Sensor error particle filter downstream temperature; signal range check low |
| 3251 | 0 | Differential pressure DPF maximum value is exceeded |
| 3251 | 0 | Differential pressure sensor across DPF exceeds warning high limit |
| 3251 | 1 | Differential pressure DPF, pressure below lower shutoff threshold. |
| 3251 | 1 | Differential pressure DPF, pressure below lower warning threshold. |
| 3253 | 2 | Differential pressure DPF, plausibility error |
| 3253 | 3 | Electrical error differential pressure B58 (DPF). (signal range check high) |
| 3253 | 4 | Electrical error differential pressure (DPF). signal range check low. |
| 3253 | 2 | Sensor differential pressure (DPF); plausibility error |
| 3361 | 7 | DEF dosing valve blocked (SCR) |

SECTION 3 - CHASSIS & TURNTABLE

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|------|-----|---|
| 3361 | 6 | DEF dosing valve; power at the end of injection too high |
| 3361 | 3 | DEF dosing valve; short circuit to battery on low side |
| 3361 | 3 | DEF dosing valve; short circuit to battery or open load on high side |
| 3361 | 4 | Urea dosing valve; short circuit to ground or open load on low side |
| 3361 | 4 | DEF dosing valve; short circuit on high side |
| 3519 | 12 | DEF tank temperature, temperature too high |
| 3519 | 3 | DEF quality sensor, internal temperature sensor short circuit to battery or open load |
| 3519 | 4 | DEF quality sensor, internal temperature sensor short circuit to ground |
| 3519 | 13 | Temperature at UQS invalid |
| 3520 | 3 | DEF quality sensor, short circuit to battery or open load |
| 3520 | 4 | DEF quality sensor, short circuit to ground |
| 3520 | 2 | DEF quality sensor, bad DEF quality detected or no DEF measuring possible. |
| 3520 | 13 | Urea quality at UQS invalid |
| 3532 | 3 | Sensor error DEF tank level; signal range check high |
| 3532 | 4 | Sensor error DEF tank level; signal range check low |
| 3532 | 3 | The DEF Level at UQS out of max. physical range |
| 3532 | 4 | Quality at UQS out of min. physical range |
| 3699 | 2 | Passive regeneration of DPF; plausibility error DPF differential pressure sensor and a further sensor or actuator CRT system defective |
| 3699 | 2 | Passive regeneration of DPF; DOC error Temperature sensor us. and ds. DOC simultaneously defect |
| 3699 | 0 | Maximum standstill time reached; oil exchange request ignored |
| 3711 | 12 | Temperature during stand-still main phase too low or too high |
| 3936 | 14 | Standstill request ignored too long. |
| 3936 | 14 | Standstill time based escalation requests Inducement step 2 |
| 4171 | 2 | Dynamic temperature check of temp before SCR |
| 4243 | 11 | SCR heater; Pressure line heater error and temperature condition to perform an afterrun (Group error diagnosis heater) SCR system heater diagnostic reports error; shut off SCR-system |
| 4334 | 0 | Supply module DEF, DEF pressure above upper physical threshold |
| 4334 | 1 | Urea supply module pressure sensor; physical range check low (defect pressure sensor) |
| 4334 | 0 | Urea pump pressure sensor; high signal not plausible |
| 4334 | 1 | Urea pump pressure sensor; low signal not plausible |
| 4334 | 2 | DEF supply module pressure, plausibility error |
| 4341 | 5 | SCR heater relay DEF supply line secondary side; open load |
| 4341 | 5 | SCR heater relay DEF supply line primary side; open load |
| 4341 | 3 | SCR-heater DEF supply line; short circuit to battery |
| 4341 | 4 | SCR-heater DEF supply line; short circuit to ground |
| 4343 | 11 | SCR Monitoring; Pressure stabilization error, general pressure check error (SCR) |
| 4343 | 5 | SCR heater relay DEF pressure line secondary side; open load |
| 4343 | 5 | SCR heater relay DEF pressure line primary side; open load |
| 4343 | 12 | Over Temperature error No detail information |
| 4343 | 3 | SCR heater DEF pressure line; short circuit to battery |
| 4343 | 4 | SCR heater DEF pressure line; short circuit to ground |
| 4345 | 11 | Sensor back flow line pressure (SCR); plausibility error |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|------|-----|--|
| 4345 | 5 | SCR heater relay DEF return line secondary side; open load |
| 4345 | 5 | SCR heater relay DEF return line primary side; open load |
| 4345 | 12 | Over Temperature error No detail information |
| 4345 | 3 | SCR heater DEF return line; short circuit to battery |
| 4345 | 4 | SCR heater DEF return line; short circuit to ground |
| 4360 | 0 | Exhaust temperature upstream SCR-Cat, temperature above upper physical threshold |
| 4360 | 1 | Sensed exhaust temperature before SCR-Cat is < physical low limit |
| 4360 | 2 | Exhaust temperature sensor upstream SCR, plausibility error |
| 4361 | 2 | Signal error for CAN message No detail information |
| 4361 | 3 | Sensor error DEF catalyst exhaust gas temperature upstream; signal range check high |
| 4361 | 4 | Sensor error DEF catalyst exhaust gas temperature upstream; signal range check low |
| 4365 | 0 | DEF tank temperature too high. |
| 4365 | 2 | Tank temperature signal error for CAN message |
| 4365 | 3 | Sensor error urea tank temperature: short circuit to battery |
| 4365 | 4 | Sensor error urea tank temperature; short circuit to ground. |
| 4365 | 3 | DEF quality sensor, tank temperature; Short circuit to battery or open load |
| 4365 | 4 | DEF quality sensor, tank temperature; Short circuit to ground |
| 4366 | 5 | SCR main relay (secondary side): open load |
| 4366 | 5 | SCR main relay (secondary side); Shortcut to battery |
| 4366 | 5 | SCR main relay (secondary side), heat relay (secondary side), heating elements or heating valve short to ground. |
| 4366 | 5 | SCR Tank heating valve secondary side: open load |
| 4366 | 5 | SCR tank heating valve primary side; open load |
| 4366 | 12 | SCR-heater relay urea tank power stage output; over temperature |
| 4366 | 3 | SCR Tank heating valve; short circuit to battery |
| 4366 | 4 | SCR Tank heating valve; short circuit to ground |
| 4374 | 13 | Pressure stabilization error dosing valve (SCR) |
| 4375 | 5 | Urea pump motor; open load |
| 4375 | 3 | Urea pump motor; short circuit to battery |
| 4375 | 4 | Urea pump motor; short circuit to ground |
| 4376 | 5 | SCR reversal valve; open load |
| 4376 | 12 | SCR reversing valve; over temperature |
| 4376 | 3 | SCR reversal valve; short circuit to battery |
| 4376 | 4 | SCR reversing valve; short circuit to ground |
| 4376 | 5 | SCR reverting valve; open load |
| 4376 | 12 | SCR reverting valve; over temperature |
| 4376 | 4 | eSCR reverting valve; short circuit to ground |
| 4765 | 0 | Temperature upstream DOC, temperature above upper shutoff threshold |
| 4765 | 0 | Temperature upstream DOC, temperature above upper warning threshold |
| 4766 | 0 | Temperature downstream DOC, temperature above upper shutoff threshold |
| 4766 | 0 | Temperature downstream DOC, temperature above upper warning threshold |
| 4768 | 2 | Temperature upstream DOC, plausibility error |
| 4768 | 3 | Electrical error exhaust gas temperature upstream (DOC); signal range check high |
| 4768 | 4 | Electrical error exhaust gas temperature upstream (DOC); signal range check low |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|--|
| 4768 | 2 | Exhaust gas temperature sensors up and downstream DOC are physically swapped |
| 4769 | 2 | Temperature downstream DOC, plausibility error |
| 4769 | 3 | Sensor error exhaust gas temperature downstream (DOC); signal range check high |
| 4769 | 4 | Sensor error exhaust gas temperature downstream (DOC); signal range check low |
| 4769 | 2 | Sensor exhaust gas temperature OxiCat downstream (normal operation); plausibility error |
| 4769 | 2 | Sensor exhaust gas temperature OxiCat downstream (regeneration); plausibility error |
| 5763 | 6 | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8). Signal range check high. |
| 5763 | 7 | Actuator position for EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8) not plausible. |
| 5763 | 6 | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); signal range check high |
| 5763 | 5 | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); signal range check low |
| 5763 | 3 | Position sensor error of actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8). Signal range check high. |
| 5763 | 4 | Position sensor error actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8). Signal range check low. |
| 5763 | 5 | Actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); open load |
| 5763 | 6 | Actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); over current |
| 5763 | 3 | EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to battery |
| 5763 | 3 | EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to battery |
| 5763 | 4 | EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to ground |
| 5763 | 4 | EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to ground |
| 5763 | 6 | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); Overload by short-circuit |
| 5763 | 11 | Power stage over temperature due to high current. |
| 5763 | 4 | Actuator AGR valve (2.9;3.6) throttle valve (4.1;6.1;7.8); Voltage below threshold. |
| 5763 | 0 | Warning threshold for an internal actuator error exceeded, < 4L EGR.actuator und >4L Air Intake Flap |
| 5763 | 1 | Shut off threshold for an internal actuator error exceeded, < 4L EGR.actuator und >4L Air Intake Flap |
| 520521 | 5 | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); signal range check low. |
| 523008 | 1 | Manipulation control was triggered |
| 523008 | 2 | Timeout error in Manipulation control |
| 523009 | 9 | The pressure relief valve (PRV) has reached the number of allowed activations. |
| 523009 | 10 | Open time of Pressure Relief Valve (PRV) for wear out monitoring had exceeded |
| 523090 | 2 | Engine Brake Pre-Selection switch; Plausibility Error |
| 523211 | 9 | Timeout Error of CAN-Receive-Frame EBC1 |
| 523212 | 9 | Timeout Error of CAN-Receive-Frame ComEngPrt; Engine Protection |
| 523213 | 12 | Timeout Error of CAN-Transmit-Frame ERC1 No detail information |
| 523216 | 9 | Timeout Error of CAN-Receive-Frame PrHtEnCmd; pre-heat command, engine command |
| 523240 | 9 | Timeout CAN-message FunModCtl; Function Mode Control |
| 523330 | 14 | Immobilizer status; fuel blocked |
| 523330 | 14 | DFC to block the fuel by Sia No detail information |
| 523330 | 14 | DFC to indicate that TEN-code or UC-code received if ECU is learned. No detail information |
| 523330 | 14 | DFC to indicate that no code is received via CAN. No detail information |
| 523330 | 14 | DFC to indicate that wrong code is received. No detail information |
| 523350 | 4 | Injector cylinder-bank 1; short circuit |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|--|
| 523352 | 4 | Injector cylinder-bank 2; short circuit |
| 523354 | 12 | Injector power stage output defect |
| 523470 | 2 | Pressure relief valve is forced to open, perform pressure increase. |
| 523470 | 2 | Pressure Relief Valve (PRV) forced to open. Performed by pressure increase. |
| 523470 | 12 | Pressure Relief Valve (PRV) forced to open. Shutoff conditions. |
| 523470 | 12 | Pressure Relief Valve (PRV) forced to open. Warning conditions. |
| 523470 | 14 | Open Pressure Relief Valve (PRV) |
| 523470 | 11 | Pressure Relief Valve (PRV) error; Rail pressure out of tolerance range. |
| 523470 | 11 | Rail pressure out of tolerance range. The PRV can not be opened at this operating point with a pressure shock. |
| 523470 | 7 | Maximum rail pressure exceeded (PRV). |
| 523550 | 12 | Terminal 50 was operated too long |
| 523580 | 2 | Data set variant with the desired number not found Invalid variant data set Identifier error No detail information |
| 523580 | 11 | An error has occurred in the switch over to the desired data set variant in the code word. Variant data set switching error No detail information |
| 523580 | 11 | The code word could not be read correctly from the EEPROM Variant dataset switching error; No detail information |
| 523601 | 13 | Failure of sensor supply voltage 3. |
| 523602 | 0 | High fan speed; warning threshold exceeded |
| 523602 | 0 | High fan speed; shut off threshold exceeded |
| 523603 | 9 | Timeout Error of CAN-Receive-Frame AMB; Ambient Temperature Sensor |
| 523605 | 9 | Timeout Error of CAN-Receive-Frame TSC1AE; Traction Control |
| 523606 | 9 | Timeout Error of CAN-Receive-Frame TSC1AR; Retarder |
| 523612 | 12 | Internal software error ECU; injection cut off |
| 523612 | 12 | Internal ECU monitoring detection reported error |
| 523612 | 12 | ECU reported internal software error Internal ECU monitoring detection reported error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error. |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | Injection system, electrical error injectors |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | ECU reported internal software error |
| 523612 | 12 | Diagnostic fault check to report the accelerator pedal position error |
| 523612 | 12 | Diagnostic fault check to report the engine speed error |
| 523612 | 12 | Error in the plausibility of the injection energizing time |
| 523612 | 12 | Error in the plausibility of the start of energizing angles |
| 523612 | 12 | Diagnostic fault check to report the error due to non plausibility in ZFC |

SECTION 3 - CHASSIS & TURNTABLE

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|--|
| 523612 | 12 | Diagnosis fault check to report the demand for normal mode due to an error in the Pol2 quantity |
| 523612 | 12 | Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol2 shut-off |
| 523612 | 12 | Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol3 efficiency factor |
| 523612 | 12 | Internal ECU monitoring detection reported error |
| 523612 | 12 | Monitoring of Fuel Quantity Correction |
| 523612 | 12 | Diagnostic fault check to report the plausibility error in rail pressure monitoring |
| 523612 | 12 | Diagnostic fault check to report the error due to torque comparison |
| 523612 | 12 | Diagnosis of curr path limitation forced by ECU monitoring level 2 |
| 523612 | 12 | Diagnosis of lead path limitation forced by ECU monitoring level 2 |
| 523612 | 12 | Diagnosis of set path limitation forced by ECU monitoring level 2. |
| 523612 | 3 | Reported Over Voltage of Supply |
| 523612 | 4 | Reported Under Voltage of Supply |
| 523612 | 12 | Diagnostic fault check to report WDA active due to errors in query-/response communication |
| 523612 | 12 | Diagnostic fault check to report ABE active due to under voltage detection |
| 523612 | 12 | Diagnostic fault check to report ABE active due to overvoltage detection |
| 523612 | 12 | Diagnostic fault check to report WDA/ABE active due to unknown reason |
| 523612 | 14 | Software reset CPU SWReset_0 |
| 523612 | 14 | Software reset CPU SWReset_1 |
| 523612 | 14 | Software reset CPU SWReset_2 |
| 523612 | 12 | Internal software error ECU |
| 523612 | 12 | Engine starter, plausibility error of starter release condition |
| 523613 | 0 | Rail pressure metering unit, Positive governor deviation. |
| 523613 | 0 | Rail pressure metering unit, Rail pressure disrupted. Maximum positive deviation of rail pressure exceeded. |
| 523613 | 0 | Rail pressure metering unit, Rail pressure disrupted. Maximum positive deviation of rail pressure in metering unit exceeded (RailMeUn1). |
| 523613 | 0 | Rail pressure metering unit, Rail pressure below the target range (RailMeUn2) Rail system leakage detected. (RailMeUn10) |
| 523613 | 1 | Rail pressure metering unit, Minimum rail pressure exceeded (RailMeUn3) Negative deviation of rail pressure second stage (RailMeUn22) |
| 523613 | 0 | Rail pressure metering unit, Maximum rail pressure exceeded. |
| 523613 | 2 | Rail pressure metering unit, Set point of metering unit in overrun mode not plausible. |
| 523613 | 0 | Set point of metering unit in overrun mode not plausible |
| 523615 | 5 | Metering unit (Fuel-System); open load |
| 523615 | 12 | Metering unit (Fuel-System); power stage over temperature |
| 523615 | 3 | Metering unit (Fuel-System); short circuit to battery high side |
| 523615 | 4 | Metering unit (Fuel-System); short circuit to ground high side |
| 523615 | 3 | Metering unit (Fuel-System); short circuit to battery low side |
| 523615 | 4 | Metering Unit (Fuel-System); short circuit to ground low side |
| 523615 | 3 | Metering unit, short circuit to battery |
| 523615 | 4 | Metering unit, short circuit to ground |
| 523618 | 3 | Gearbox oil temperature; Short circuit to battery or broken harness |
| 523618 | 4 | Gearbox oil temperature; Short circuit to ground |
| 523619 | 2 | Physical range check high for exhaust gas temperature up stream (SCR-CAT) |
| 523632 | 16 | Pump pressure SCR metering unit too high. |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|---|
| 523632 | 18 | Pump pressure SCR metering unit too low |
| 523632 | 0 | Pressure overload of SCR-System. |
| 523632 | 1 | Pressure build-up error SCR-System. |
| 523632 | 11 | Pump motor not available for actuation |
| 523632 | 2 | Signal error for CAN message No detail information |
| 523632 | 3 | Sensor error urea pump pressure; signal range check high |
| 523632 | 4 | Sensor error urea pump pressure; signal range check low |
| 523633 | 11 | Long term adoption factor below threshold |
| 523633 | 11 | Nox conversion rate insufficient (SCR-Cat defect, bad DEF quality) |
| 523633 | 11 | Nox conversion rate insufficient (SCR-Cat defect, bad DEF quality); temperature range 1 |
| 523698 | 11 | Shut off request from supervisory monitoring function |
| 523699 | 3 | Boost pressure control; negative governor deviation below limit |
| 523699 | 4 | learning value too high No detail information |
| 523704 | 12 | Timeout Error of CAN-Transmit-Frame EEC3 |
| 523706 | 12 | Timeout Error of CAN-Transmit-Frame FIEco No detail information |
| 523717 | 12 | Timeout Error of CAN-Transmit-Frame AmbCon; Weather environments |
| 523718 | 5 | tank heating valve; open load |
| 523718 | 12 | SCR main relay (primary side); power stage over temperature |
| 523718 | 3 | SCR main relay (primary side); short circuit to battery |
| 523718 | 4 | SCR main relay (primary side); short circuit to ground |
| 523718 | 5 | SCR main relay; open load (only CV56B) |
| 523718 | 3 | SCR main relay; short circuit to battery (only CV56B) |
| 523718 | 4 | SCR main relay; short circuit to ground (only CV56B) |
| 523719 | 5 | SCR heater relay DEF supply module secondary side; open load |
| 523719 | 5 | SCR heater relay DEF supply module primary side; open load |
| 523719 | 12 | Over Temperature error No detail information |
| 523719 | 3 | SCR heater DEF supply module; short circuit to battery |
| 523719 | 4 | SCR heater DEF supply module; short circuit to ground |
| 523720 | 2 | DEF supply module heater temperature; plausibility error (normal condition). |
| 523720 | 2 | Sensor DEF supply module heater temperature; plausibility error (cold start condition) |
| 523720 | 8 | DEF supply module heater temperature; duty cycle in failure range. |
| 523720 | 8 | DEF supply module heater temperature; duty cycle in invalid range. |
| 523721 | 2 | Sensor DEF supply module temperature; plausibility error (normal condition) |
| 523721 | 2 | Sensor DEF supply module temperature; plausibility error (cold start condition) |
| 523721 | 11 | Urea supply module temperature measurement not available. |
| 523721 | 8 | DEF supply module temperature; duty cycle in failure range. |
| 523721 | 8 | Urea supply module temperature; duty cycle in invalid range. |
| 523722 | 8 | DEF supply module PWM signal; period outside valid range. |
| 523722 | 8 | Detect faulty PWM signal from Supply Module. |
| 523741 | 14 | Engine shut off request through CAN No detail information |
| 523752 | 0 | Plausibility error during Rich to Lean switch over No detail information |
| 523752 | 0 | Monitoring of Nox signal readiness No detail information |
| 523756 | 14 | special pattern for special cases No detail information |

SECTION 3 - CHASSIS & TURNTABLE

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|---|
| 523757 | 14 | special pattern for special cases No detail information |
| 523758 | 14 | special pattern for special cases No detail information |
| 523759 | 14 | special pattern for special cases No detail information |
| 523760 | 14 | special pattern for special cases No detail information |
| 523766 | 9 | Timeout Error of CAN-Receive-Frame Active TSC1AE |
| 523767 | 9 | Timeout Error of CAN-Receive-Frame Passive TSC1AE |
| 523768 | 9 | Timeout Error of CAN-Receive-Frame Active TSC1AR |
| 523769 | 9 | Timeout Error of CAN-Receive-Frame Passive TSC1AR |
| 523776 | 9 | Timeout Error of CAN-Receive-Frame TSC1TE - active |
| 523777 | 9 | Passive Timeout Error of CAN-Receive-Frame TSC1TE; Set point |
| 523778 | 9 | Timeout Error of CAN-Receive-Frame TSC1TR |
| 523779 | 9 | Passive Timeout Error of CAN-Receive-Frame TSC1TR |
| 523788 | 12 | Timeout Error of CAN-Transmit-Frame TrbCH; Status Waste gate |
| 523788 | 0 | Waste gate plausibility error off CAN transmit message. |
| 523788 | 0 | Timeout Error of CAN-Receive-Frame ComTrbChActr; Wastegate |
| 523793 | 9 | Timeout Error of CAN-Receive-Frame UAA10; AGS sensor service message |
| 523794 | 9 | Timeout Error of CAN-Receive-Frame UAA11; AGS sensor data |
| 523803 | 9 | Timeout error of CAN Receive Message RxEngPres; Status Burner Air Pump |
| 523858 | 12 | Timeout Error of CAN-Transmit-Frame UAA11 |
| 523867 | 12 | Timeout Error of CAN-Transmit-Frame UAA1 on CAN 2. Control burner air pump; |
| 523889 | 3 | Over temperature of device driver of pressure control valve No detail information |
| 523891 | 14 | When AirHt_ctDefSRCLoOn_mp is less than AirHt_ctMaxDef_C. DFC to SRC Low error when heater is On No detail information |
| 523895 | 13 | Check of missing injector adjustment value programming (IMA) injector 1 (in firing order). |
| 523896 | 13 | Check of missing injector adjustment value programming (IMA) injector 2 (in firing order). |
| 523897 | 13 | Check of missing injector adjustment value programming (IMA) injector 3 (in firing order). |
| 523898 | 13 | Check of missing injector adjustment value programming (IMA) injector 4 (in firing order). |
| 523899 | 13 | Check of missing injector adjustment value programming (IMA) injector 5 (in firing order). |
| 523900 | 13 | Check of missing injector adjustment value programming (IMA) injector 6 (in firing order). |
| 523906 | 5 | Electrical fuel pre - supply pump; open load |
| 523906 | 12 | Electrical fuel pre - supply pump. ECU powerstage over temperature. |
| 523906 | 3 | Electrical fuel pre - supply pump; short circuit to battery |
| 523906 | 4 | Electrical fuel pre - supply pump. Short circuit to ground. |
| 523910 | 14 | Air pump doesn't achieve air mass flow setpoint Burner Control - burner air pump |
| 523910 | 9 | Burner Control; Air Pump - CAN Lost Air Pump; CAN communication lost |
| 523910 | 7 | Air pump; CAN communication interrupted no purge function available |
| 523910 | 12 | Air Pump; internal error |
| 523910 | 0 | Air Pump; operating voltage error |
| 523910 | 6 | Burner Control Air Pump; over current Air pump electrically overloaded |
| 523911 | 0 | Burner dosing valve (DV2); over current at the end of the injection phase |
| 523911 | 12 | Burner dosing valve (DV2); power stage over temperature |
| 523911 | 3 | Burner dosing valve (DV2); short circuit to battery |
| 523911 | 4 | Burner dosing valve (DV2); short circuit to ground |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|---|
| 523911 | 11 | Burner dosing valve (DV2); short circuit high side power stage |
| 523912 | 2 | Burner dosing valve (DV2) downstream pressure sensor; plausibility error |
| 523912 | 0 | Physical range check high for burner dosing valve (DV2) downstream pressure; shut off regeneration |
| 523912 | 1 | Physical range check low for burner dosing valve (DV2) downstream pressure; shut off regeneration. When burner injector is actuated, the measured pressure does not rise above ca. 1250mbar abs (expected: ca. 2400mbar). |
| 523912 | 3 | Sensor error burner dosing valve (DV2) downstream pressure sensor; signal range check high |
| 523912 | 4 | @ engines < 4l: Throttle valve error, Open Load or Short cut to Battery, blocked valve or wrong control signal for valve. @ engines with Burner T4i: Pressure Sensor error after valve (DV2), lower limit reached |
| 523913 | 3 | Sensor error glow plug control diagnostic line voltage; signal range check high |
| 523913 | 4 | Sensor error glow plug control diagnostic line voltage; signal range check low |
| 523914 | 5 | Glow plug control; open load water pump control (PWM) |
| 523914 | 12 | Glow plug control; power stage over temperature |
| 523914 | 3 | Glow plug control; short circuit to battery water pump control (PWM) |
| 523914 | 4 | Glow plug control; short circuit to ground water pump control (PWM) |
| 523915 | 0 | HCl dosing valve (DV1); over current at the end of the injection phase |
| 523915 | 12 | HCl dosing valve (DV1); power stage over temperature |
| 523915 | 3 | HCl dosing valve (DV1); short circuit to battery |
| 523915 | 3 | HCl dosing valve (DV1); short circuit to battery high side |
| 523915 | 4 | HCl dosing valve (DV1); short circuit to ground |
| 523915 | 11 | HCl dosing valve (DV1); short circuit high side power stage |
| 523915 | 7 | HCl dosing valve (DV1); blocked open |
| 523916 | 2 | Sensor HCl dosing valve (DV1) downstream pressure; plausibility error |
| 523916 | 0 | Physical range check high for HCl dosing valve (DV1) downstream pressure; shut off regeneration |
| 523916 | 1 | Physical range check low for HCl dosing valve (DV1) downstream pressure; shut off regeneration |
| 523916 | 3 | Sensor error HCl dosing valve (DV1) downstream pressure; signal range check high |
| 523916 | 4 | Sensor error HCl dosing valve (DV1) downstream pressure; signal range check low |
| 523917 | 3 | Sensor error DV1 & DV2 upstream pressure; signal range check high |
| 523917 | 4 | Sensor error DV1 & DV2 upstream pressure; signal range check low |
| 523918 | 3 | Sensor error DV1 & DV2 upstream temperature; signal range check high |
| 523918 | 4 | Sensor error DV1 & DV2 upstream temperature; signal range check low |
| 523919 | 2 | DPF burner air pump pressure sensor, plausibility error |
| 523919 | 0 | DPF burner air pump pressure sensor, pressure above upper shutoff threshold |
| 523919 | 1 | DPF burner air pump pressure sensor, pressure below lower shutoff threshold |
| 523919 | 3 | DPF burner air pump pressure sensor, short circuit to battery or open load |
| 523919 | 4 | DPF burner air pump pressure sensor, short circuit to ground |
| 523919 | 2 | Sensor air pump air pressure; plausibility error |
| 523920 | 2 | Exhaust gas pressure upstream burner, plausibility error |
| 523920 | 0 | Exhaust gas pressure upstream burner, pressure above upper shutoff threshold |
| 523920 | 3 | Exhaust gas pressure upstream burner, short circuit to battery or open load |
| 523920 | 4 | Exhaust gas pressure upstream burner, short circuit to ground |
| 523920 | 2 | Sensor exhaust gas back pressure burner; plausibility error |
| 523921 | 3 | Sensor error burner temperature; signal range check high |
| 523921 | 4 | Sensor error burner temperature; signal range check low |

SECTION 3 - CHASSIS & TURNTABLE

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|---|
| 523921 | 0 | Burner temperature, temperature above upper shutoff threshold |
| 523921 | 1 | Burner temperature, temperature below lower shutoff threshold |
| 523921 | 2 | Burner temperature sensor; Plausibility Check for burner temperature sensor Sensor burner temperature; plausibility error |
| 523922 | 3 | Burner shut of valve; short circuit to battery |
| 523922 | 7 | Burner Control; Shut-off Valve - Blocked closed Burner Shut Off Valve; blocked closed |
| 523922 | 7 | Burner Shut Off Valve; blocked open |
| 523922 | 5 | Burner Shut Off Valve; open load |
| 523922 | 12 | Burner Shut Off Valve; power stage over temperature |
| 523922 | 4 | Burner Shut Off Valve; short circuit to ground |
| 523923 | 3 | UB1; Short circuit to battery error of actuator relay 1 |
| 523923 | 4 | Short circuit to ground error No detail information |
| 523924 | 3 | UB2; Short circuit to battery error of actuator relay 2 |
| 523924 | 4 | UB2; Short circuit to ground actuator relay 2 |
| 523925 | 3 | UB3; Short circuit to battery error of actuator relay 3. |
| 523925 | 4 | UB3; Short circuit to ground actuator relay 3 |
| 523926 | 4 | UB4; Short circuit to ground actuator relay 4. |
| 523927 | 3 | UB5; Short circuit to battery error of actuator relay 5. |
| 523935 | 12 | Timeout Error of CAN-Transmit-Frame EEC3VOL1; Engine send messages |
| 523936 | 12 | Timeout Error of CAN-Transmit-Frame EEC3VOL2; Engine send messages |
| 523937 | 9 | Timeout DFC for NOxSensGlbReqTx. No detail information |
| 523938 | 9 | Timeout Error (BAM to packet) for CAN-Receive-Frame AT11GCVol1. |
| 523939 | 9 | Broadcast Announce Message of the calibration message of the upstream catalytic NOx sensor has failed. |
| 523940 | 9 | Timeout Error (PCK2PCK) for CAN-Receive-Frame AT11GCVol1 |
| 523941 | 9 | Timeout Error (BAM to packet) for CAN-Receive-Frame AT10GCVol2. |
| 523942 | 9 | Calibration message 1 of the after catalyst NOx sensor has failed. |
| 523943 | 9 | Timeout Error (PCK2PCK) for CAN-Receive-Frame AT10GCVol2. |
| 523946 | 0 | Zerofuel calibration injector 1 (in firing order); maximum value exceeded |
| 523946 | 1 | Zerofuel calibration injector 1 (in firing order); minimum value exceeded |
| 523947 | 0 | Zerofuel calibration injector 2 (in firing order); maximum value exceeded |
| 523947 | 1 | Zerofuel calibration injector 2 (in firing order); minimum value exceeded |
| 523948 | 0 | Zerofuel calibration injector 3 (in firing order); maximum value exceeded |
| 523948 | 1 | Zerofuel calibration injector 3 (in firing order); minimum value exceeded |
| 523949 | 0 | Zerofuel calibration injector 4 (in firing order); maximum value exceeded |
| 523949 | 1 | Zerofuel calibration injector 4 (in firing order); minimum value exceeded |
| 523950 | 0 | Zerofuel calibration injector 5 (in firing order); maximum value exceeded |
| 523950 | 1 | Zerofuel calibration injector 5 (in firing order); minimum value exceeded |
| 523951 | 0 | Zerofuel calibration injector 6 (in firing order); maximum value exceeded |
| 523953 | 2 | Healing takes place if the condition for error detection is not present. Air temperature monitoring plausibility check array No detail information |
| 523955 | 2 | Healing takes place if the condition for error detection is not present. Air temperature monitoring plausibility check array No detail information |
| 523960 | 0 | Physical range check high for EGR cooler downstream temperature. |
| 523960 | 1 | Physical range check low for EGR cooler downstream temperature. |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|--|
| 523960 | 0 | High exhaust gas temperature EGR cooler downstream; warning threshold exceeded. |
| 523969 | 11 | Fault entry for override control mode. No detail information |
| 523973 | 14 | SCR Tamper detection; derating timer below limit 1 |
| 523974 | 14 | SCR Tamper detection; derating timer below limit 2 |
| 523975 | 14 | Urea quality; derating timer below limit 1 |
| 523976 | 14 | Urea quality; derating timer below limit 2 |
| 523977 | 14 | Urea tank level; derating timer below limit 1 |
| 523978 | 14 | Urea tank level; derating timer below limit 2 |
| 523981 | 11 | SCR plausibility, OBD and diagnosis; Stuck in range check of DEF tank temperature sensor DEF-tank without heating function (heating phase) |
| 523982 | 0 | Power stage diagnosis disabled; high battery voltage |
| 523982 | 1 | Power stage diagnosis disabled; low battery voltage |
| 523984 | 3 | UB7; Short circuit to battery error of actuator relay 7 |
| 523986 | 4 | UB6; Short circuit to ground actuator relay 6 |
| 523987 | 4 | UB7; Short circuit to ground actuator relay 7 |
| 523992 | 9 | N/A |
| 523993 | 9 | N/A |
| 523995 | 13 | Check of missing injector adjustment value programming (IMA) injector 7 (in firing order) |
| 523996 | 13 | check of missing injector adjustment value programming (IMA) injector 8 (in firing order) |
| 523997 | 4 | Injector cylinder bank 1 slave; short circuit |
| 523998 | 4 | Injector cylinder bank 2 slave; short circuit |
| 523999 | 12 | Injector power stage output Slave defect |
| 524000 | 5 | Injector 7 (in firing order); interruption of electric connection |
| 524000 | 3 | Injector 7 (in firing order); short circuit |
| 524001 | 5 | Injector 8 (in firing order); interruption of electric connection |
| 524001 | 3 | Injector 8 (in firing order); short circuit |
| 524013 | 7 | Burner Control; burner Flame; Burner does not start after x trials (burner flame lost detection) Burner flame unintentional deleted |
| 524013 | 7 | Burner Control; Flame lost max Burner operation is interrupted too often |
| 524014 | 1 | Air inlet EPV - pressure too low Air pressure glow plug flush line; below limit |
| 524016 | 11 | Burner Control; HFM - Electrical Fault HFM sensor; electrical fault |
| 524016 | 2 | Burner Control; HFM - Plausibility error1 Amount of air is not plausible to pump speed |
| 524018 | 14 | HMI engine derate service state DPF wasn't regenerated, power reduction phase 1 (manual regeneration request) |
| 524019 | 11 | Burner Control; Air Line - Blocked Air Pump; air lines blocked |
| 524020 | 14 | Burner Control: power reduction due to low lambda. Engine power; Not enough oxygen for regeneration. |
| 524021 | 11 | Burner Control; Fuel line ShutOff downstream - broken Burner fuel line pipe leak behind Shut Off Valve |
| 524022 | 14 | HMI engine derate stop state DPF wasn't regenerated, power reduction phase 2 (manual regeneration request) |
| 524024 | 11 | Deviation of the exhaust gas temperature set point to actual value downstream (DOC) too high |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|---|
| 524025 | 14 | Particulate filter regeneration. Regeneration after time X is not successful (The error occurs when the regeneration times (3x) over the max. has been aborted allowed recovery time) |
| 524025 | 5 | DPF system; operating voltage error |
| 524025 | 14 | The standstill-regeneration mode time exceeds the long-limit. Vehicle was too long or too often in standstill mode. Make oil change and reset counter. |
| 524025 | 14 | The standstill-regeneration mode time exceeds the short-limit. Vehicle was too long or too often within a short time in standstill mode. Make oil change and reset counter. |
| 524025 | 8 | Max. launch time for stand still exceeded (60min). |
| 524028 | 2 | CAN message PROEGRActr; plausibility error |
| 524029 | 2 | Timeout Error of CAN-Receive-Frame ComEGRActr - exhaust gas recirculation positioner |
| 524030 | 7 | EGR actuator; internal error |
| 524031 | 13 | EGR actuator, calibration error |
| 524032 | 2 | EGR actuator; status message "EGRCust" is missing |
| 524033 | 7 | EGR actuator; due to overload in Save Mode |
| 524034 | 5 | Disc Separator; open load |
| 524034 | 12 | Disc Separator; power stage over temperature |
| 524034 | 3 | Disc separator; short circuit to battery |
| 524034 | 4 | Disc separator; short circuit to ground |
| 524035 | 12 | Injector diagnostics; time out error in the SPI communication |
| 524036 | 12 | Injector diagnostics Slave; time out error in the SPI communication |
| 524038 | 9 | Timeout error of CAN-Receive-Frame ComMS_Sys1T0 (error memory Slave); Master-Slave internal CAN message |
| 524039 | 9 | Timeout error of CAN-Receive-Frame ComMS_Sys2T0 (error memory Slave); Master-Slave internal CAN message |
| 524040 | 9 | Timeout error of CAN-Receive-Frame ComMS_Sys3T0 (error memory Slave); Master-Slave internal CAN message |
| 524041 | 9 | Timeout error of CAN-Receive-Frame ComMS_Sys4T0 (error memory Slave); Master-Slave internal CAN message |
| 524042 | 9 | Timeout error of CAN-Receive-Frame ComMS_Sys5T0 (error memory Slave); Master-Slave internal CAN message |
| 524043 | 9 | Timeout error of CAN-Receive-Frame ComMS_Sys6T0 (error memory Slave); Master-Slave internal CAN message |
| 524044 | 9 | CAN message ComMS_Sys7 not received from slave |
| 524045 | 9 | Master Slave, Error of message counter CAN receive message ComMSMoFOvR; ComMSMoFOvR1CNT |
| 524046 | 9 | Master-Slave CAN; Error Checksum of CAN-Receive Message |
| 524047 | 9 | Master-Slave CAN; Error of message length of CAN receive message ComMSMoFOvR;_ComMSMoFOvR1DLC |
| 524048 | 9 | Timeout error CAN message ComMSMoFOvR1T0 error memory Slave |
| 524052 | 11 | Error memory Slave reports FID MSMonFC2 (collective error) |
| 524052 | 11 | Error memory Slave reports FID MSMonFC3 (collective error) |
| 524052 | 11 | Master ECU and Slave ECU data sets or software are not identical |
| 524057 | 2 | Fuel low pressure pump; error pressure build up |
| 524058 | 2 | Particulate filter; regeneration not successful |
| 524063 | 5 | Relay Urea back flow line heater: broken wiring detected (open load) Row engine: SCR-back flow line (K29) V-engine: Master: SCR-suction / back flow line (K32.1) Slave: SCR-suction / back flow line (K32.2) |
| 524063 | 5 | SCR main relay not connected |
| 524063 | 5 | SCR heater pressure line; open load |
| 524063 | 3 | SCR heater main relay; short circuit to battery |

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|--|
| 524063 | 4 | SCR heater main relay load side (K31) on heating valve (Y31), Short cut to ground. |
| 524063 | 5 | Relay Urea suction line: broken wiring detected (open load) Row engine: SCR suction line (K28) V-engine: Master: common SCR-suction line (K28) Slave: common SCR back flow line (K29) |
| 524063 | 5 | SCR heater supply module; open load |
| 524063 | 5 | SCR heater tank; open load |
| 524063 | 12 | DEF supply module, time for defrosting too long |
| 524063 | 12 | DEF tank, time for defrosting too long |
| 524065 | 0 | Pressure sensor upstream SCR-CAT, pressure above upper physical threshold |
| 524065 | 1 | Pressure sensor upstream SCR-CAT, pressure below lower physical threshold |
| 524065 | 3 | Pressure sensor upstream SCR-CAT; short circuit battery or open load |
| 524065 | 4 | Pressure sensor upstream SCR-CAT; short circuit ground |
| 524065 | 2 | Pressure sensor upstream SCR-CAT, plausibility error |
| 524066 | 3 | SCR measurement heater output stage; short circuit battery or open load |
| 524067 | 0 | DEF supply module, heater temperature above upper physical threshold |
| 524067 | 1 | DEF supply module, heater temperature below lower physical threshold |
| 524067 | 0 | DEF supply module, temperature above upper physical threshold |
| 524067 | 1 | DEF supply module, temperature below lower physical threshold |
| 524067 | 2 | Supply module heater temperature, plausibility error |
| 524067 | 2 | Supply module temperature, plausibility error |
| 524068 | 2 | Master ECU and Slave ECU have been identified as the same types |
| 524069 | 9 | Timeout Error of CAN-Receive-Frame MSMon_FidFCCTO; Master-Slave CAN communication faulty |
| 524070 | 2 | (Upstream NOx-Sensor) Diagnostic Fault Check for invalid upstream NOx value (Sensor self diagnostic DFC set by Deutz-SW) NOx-Sensor before SCR-Cat: Invalid upstream NOx value |
| 524071 | 2 | (Downstream NOx-Sensor) Diagnostic Fault Check for invalid downstream lambda value (Sensor self diagnostic DFC set by Deutz-SW) |
| 524072 | 2 | (Upstream NOx-Sensor) Diagnostic Fault Check for invalid upstream lambda value (Sensor self diagnostic DFC set by Deutz-SW) |
| 524073 | 2 | (Downstream NOx-Sensor) Diagnostic Fault Check for invalid downstream NOx value (Sensor self diagnostic DFC set by Deutz-SW) |
| 524074 | 9 | NOx sensor downstream SCR-CAT, sensor internally open load |
| 524074 | 2 | NOx-Sensor after SCR-Cat: Nox-Sensor dew point problem or plausibility problem |
| 524075 | 11 | NOx sensor downstream SCR-CAT, sensor internally short circuit |
| 524076 | 9 | NOx sensor upstream SCR-CAT, sensor internally open line |
| 524076 | 2 | NOx-Sensor before SCR-Cat: Nox-Sensor dew point problem or plausibility problem |
| 524077 | 11 | NOx sensor upstream SCR-CAT, sensor internally short circuit |
| 524078 | 9 | NOx sensor downstream SCR-CAT, lambda value above upper physical threshold |
| 524079 | 9 | NOx sensor downstream SCR-CAT, lambda value below lower physical threshold |
| 524080 | 9 | NOx sensor upstream SCR-CAT, lambda value above upper physical threshold |
| 524081 | 9 | NOx sensor upstream SCR-CAT, lambda value below lower physical threshold |
| 524082 | 9 | (Downstream NOx-Sensor) Diagnostic Fault Check for downstream NOx value over maximum limit (DFC set by Deutz-SW) |
| 524083 | 9 | NOx-Sensor downstream SCR-CAT, NOx value below minimum value. |

SECTION 3 - CHASSIS & TURNTABLE

Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|---|
| 524084 | 9 | NOx-Sensor upstream SCR-CAT, NOx value above maximum value. |
| 524085 | 9 | NOx sensor upstream SCR-CAT, NOx value below lower physical threshold |
| 524087 | 5 | Urea Error Lamp; open load |
| 524087 | 12 | Urea Error Lamp; temperature over limit |
| 524087 | 3 | Urea Error Lamp; short circuit battery |
| 524087 | 4 | Urea Error Lamp; short circuit ground |
| 524096 | 14 | Control of the SCR system; If the start stop counter (EPA-Counter) exceeds the threshold SCRctl_ctEngStrtStopThresh_C. This counter will increment only once in each driving cycle in case of an SCR error. If the counter reaches the threshold, the DFC will be set to inhibit the engine start. Engine will not be started, because of EPA-Counter |
| 524097 | 9 | Timeout error of CAN-Transmit-Frame DPFBnAirPmpCtl |
| 524098 | 9 | Timeout error of CAN-Transmit-Frame ComDPFBnPT |
| 524099 | 9 | Timeout error of CAN-Transmit-Frame ComDPFC1 |
| 524100 | 9 | Timeout error of CAN-Transmit-Frame ComDPFHisDat. |
| 524101 | 9 | Timeout error of CAN-Transmit-Frame ComDPFtstMon |
| 524102 | 9 | Timeout error of CAN-Receive-Frame ComRxDPFBnAirPmpCtl |
| 524103 | 9 | Timeout error of CAN-Receive-Frame ComRxDPFBnAirPmp |
| 524104 | 9 | Timeout error of CAN-Receive-Frame ComRxDPFCtl. |
| 524105 | 9 | Timeout error of CAN-Transmit-Frame ComEGRMsFlw (EGR Steller) |
| 524106 | 9 | Timeout error of CAN-Receive-Frame ComRxEGRMsFlw1 (EGR actuator) |
| 524107 | 9 | Timeout error of CAN-Receive-Frame ComRxEGRMsFlw2 (EGR actuator) |
| 524108 | 9 | Timeout error of CAN-Transmit-Frame ComEGRTVActr (EGR actuator) |
| 524109 | 9 | Timeout error of CAN-Receive-Frame ComRxEGRTVActr (EGR actuator) |
| 524110 | 9 | Timeout error of CAN-Transmit-Frame ComETVActrTO. |
| 524111 | 9 | Timeout error of CAN-Receive-Frame ComRxETVActr |
| 524112 | 9 | Timeout ComIntake Throttle Valve Actr. |
| 524113 | 9 | Timeout error of CAN-Receive-Frame ComRxITVActr |
| 524114 | 9 | Timeout error of CAN-Transmit-Frame A1DOC |
| 524115 | 9 | Timeout error of CAN-Transmit-Frame AT1S |
| 524116 | 9 | Timeout error of CAN-Transmit-Frame SCR2 |
| 524117 | 9 | Timeout error of CAN-Transmit-Frame SCR3 |
| 524118 | 9 | Timeout error of CAN-Receive-Frame ComRxCM1 |
| 524119 | 9 | Timeout error of CAN-Receive-Frame ComRxCustSCR3 |
| 524120 | 9 | Timeout error of CAN-Receive-Frame ComRxSCRHtDiag |
| 524121 | 9 | Timeout error of CAN-Receive-Frame ComRxTrbChActr (wastegate actuator) |
| 524122 | 9 | Timeout error of CAN-Receive-Frame ComRxUQSens (Urea quality) |
| 524123 | 9 | Timeout error of CAN-Receive-Frame ComSCRHtCtl |
| 524124 | 9 | Timeout error of CAN-Receive-Frame ComTxAT1IMG |
| 524125 | 9 | Timeout error of CAN-Receive-Frame ComTxTrbChActr (Wastegate actuator) |
| 524132 | 2 | Fuel low pressure upstream fuel low pressure pump not plausible |
| 524132 | 0 | Fuel low pressure upstream fuel low pressure pump, pressure above maximum warning threshold |
| 524132 | 0 | Fuel low pressure upstream fuel low pressure pump, pressure above maximum shut off threshold |
| 524132 | 1 | Fuel low pressure upstream fuel low pressure pump, pressure below minimum shut off threshold |
| 524132 | 1 | Fuel low pressure upstream fuel low pressure pump, pressure below minimum warning threshold |


Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)

| SPN | FMI | Error Identification |
|--------|-----|--|
| 524133 | 2 | HMI system; set if restore button blocked |
| 524134 | 0 | DPF, ash load exceeds the shutoff threshold |
| 524134 | 0 | DPF, ash load exceeds the warning threshold |
| 524135 | 0 | DPF, soot load exceeds the shutoff threshold |
| 524135 | 14 | DPF, soot load exceeds the service request threshold |
| 524135 | 0 | DPF, soot load exceeds the warning threshold |
| 524141 | 7 | DEF dosing valve, dosing valve blocked |
| 524147 | 13 | SCR System, pressure build up not possible |
| 524147 | 7 | SCR-System, reverting valve blocked |
| 524147 | 13 | Set together with DFC_SCRCoBldUpLoPres. DFC_SCRCoBldUpLoPresRst is only used for inducement purposes. It ensures that legal inducement is working correctly. |
| 524149 | 2 | Plausibility error between pressure downstream turbine (PTrbnDs) and ambient air pressure (EnvP) |
| 524149 | 2 | Pressure downstream turbine, plausibility error |
| 524152 | 2 | Urea Quality Sensor; Timeout CAN message |
| 524153 | 2 | Urea tank level & urea tank temperature via CAN bus, timeout of CAN message |
| 524156 | 9 | Timeout error of CAN-Receive-Frame ComRxEBC2. |
| 524157 | 9 | Fan control; time out for fan governing |
| 524159 | 0 | Fan; short circuit battery or open load |
| 524159 | 1 | Fan; short circuit ground |
| 524160 | 5 | Fan; in/outlet valve 1; open load |
| 524160 | 3 | Fan; in/outlet valve 1; short circuit battery |
| 524160 | 4 | Fan; in/outlet valve 1; open load ground |
| 524161 | 5 | Fan; in/outlet valve 2; open load |
| 524161 | 3 | Fan; in/outlet valve 2; short circuit battery |
| 524161 | 4 | Fan; in/outlet valve 2; open load ground |
| 524162 | 12 | Fan; fan control; angle sensor defect |
| 524163 | 12 | Fan; fan control; fan or valve defect |
| 524175 | 0 | SCR-CAT, Nox emissions above maximum threshold |
| 524177 | 7 | SCR System, DEF suction line blocked |
| 524178 | 7 | SCR System, DEF pressure out of range |
| 524189 | 9 | Master / Slave Can disturbed. |
| 524190 | 14 | Inducement level 1 active |
| 524191 | 14 | Inducement level 2 active |
| 524193 | 8 | The standstill-regeneration mode time exceeds the long limit threshold. Vehicle was too long or too often in standstill mode. Change oil and reset counter. |
| 524194 | 8 | The standstill-regeneration mode time exceeds the short-limit. Vehicle was too long or too often within a short time in standstill mode. Change oil and reset counter. |
| 524195 | 14 | Standstill request due to crystallization ignored too long |
| 524196 | 13 | Variant handling, address error |
| 524196 | 2 | Variant handling, Synchronisation error |
| 524202 | 11 | SCR error code in master ECU active. |
| 524203 | 11 | DEF tank level failure is in master ECU active. |
| 524204 | 11 | SCR after run failure is in master ECU active. |

SECTION 3 - CHASSIS & TURNTABLE**Table 3-1. Deutz Trouble Codes (TD2.9 L4 Engine)**

| SPN | FMI | Error Identification |
|--------|-----|---|
| 524205 | 11 | SCR Co2off failure is in master ECU active. |
| 524206 | 11 | SCR disable DEF dosing failure is in master ECU active. |
| 524230 | 11 | Inducement HW Failure Slave. |
| 524231 | 11 | Inducement SCR Tamp. Slave |
| 524232 | 11 | Inducement DEF Quality in Slave ECU |
| 524239 | 11 | SCR regeneration failure is in slave ECU active. |
| 524248 | 11 | NOX sensor downstream error in slave ECU |
| 524249 | 11 | DEF dosing valve error in slave ECU |
| 524251 | 11 | DEF pressure problems in slave ECU |
| 524252 | 11 | Reverting valve error in slave ECU |
| 524253 | 11 | DEF back flow line heater error on slave ECU |
| 524254 | 11 | Error NOx-Tailpipe emissions exceeded on Slave ECU |
| 524255 | 11 | DEF suction line heater error on slave ECU |
| 524256 | 11 | DEF supply module heater error on slave ECU |
| 524257 | 11 | Error Exhaust pressure upstream SCR on Slave ECU |
| 524258 | 11 | Error Exhaust temperature upstream SCR on Slave ECU |
| 524259 | 11 | DEF pressure line heater error on slave ECU |
| 524260 | 11 | Error Urea pump temperature on Slave ECU |
| 524261 | 11 | Error DEF heater relays on Slave ECU |
| 524267 | 14 | Announcement triggers the Inducement Level 2 |


3.9 DEUTZ D2011L04 ENGINE



1. Fuel Tank


2. Deutz D2011 Engine and Pumps Sub-Assembly

Figure 3-25. Deutz D2011 Engine Installation



- | | | | |
|--------------------------------|---------------------------------|-------------------------------|------------|
| 1. Gear Pump Assembly | 3. Piston Pump Assembly - Front | 5. DeutzD2011 Engine Assembly | 7. Support |
| 2. Piston Pump Assembly - Rear | 4. Exhaust Pipe | 6. Hydraulic Oil Cooler | |

Figure 3-26. Deutz D2011 Engine and Pumps Sub-Assembly



MAE25230

- | | | | |
|-----------------------|------------------|----------------------|------------------|
| 1. Deutz D2011 Engine | 4. Support | 7. Glow Plug Harness | 10. Tray |
| 2. Radiator | 5. Pump Coupling | 8. Adapter | 11. Bracket |
| 3. Air Filter | 6. Bracket | 9. Fan | 12. Engine Mount |
| | | | 13. Engine Mount |

Figure 3-27. Deutz D2011 Engine Assembly - Sheet 1 of 2




Figure 3-28. Deutz D2011 Engine Assembly - Sheet 2 of 2

NOTE: Refer to engine manufacturer's manual for detailed operating and maintenance instructions.

Checking Oil Level

1. Make sure machine and engine are level and switch engine OFF before checking oil level.
2. Remove oil dipstick and wipe with clean cloth.
3. Insert dipstick to the stop and remove again.
4. Check oil level. Top oil level as shown in figure below with an approved grade and type of oil outlined in engine manufacturer's operator's manual.




Figure 3-29. Deutz Dipstick Markings

5. Replace dipstick until fully seated.

Changing Engine Oil

1. Allow engine to warm up. Engine oil should reach approximately 176° F (80° C).
2. Make sure machine and engine are level and switch off engine.
3. Place oil tray under engine.

CAUTION

HOT ENGINE OIL CAN CAUSE BURNS. AVOID CONTACT WITH HOT OIL WHEN DRAINING.

NOTICE

COLLECT USED OIL IN A CONTAINER SUITABLE FOR DISPOSAL OR RECYCLING. DISPOSE OF USED ENGINE OIL IN ACCORDANCE WITH ENVIRONMENTAL REGULATIONS.

4. Open oil drain valve and drain oil.
5. Close oil drain valve.
6. Pour in new engine oil. Refer to Section 1 for capacity and Figure 3-30., Engine Oil Viscosity.






Figure 3-30. Engine Oil Viscosity

Changing Oil Filter


1. Wipe area around filter to clean any dirt from area.
2. Using a suitable oil filter removal tool, loosen lube oil filter cartridge and spin off.



3. Catch any escaping oil.
4. Clean any dirt from filter carrier sealing surface.
5. Lightly coat new oil filter rubber gasket with clean oil.



6. Screw in new filter by hand until gasket is flush.



7. Hand-tighten filter another half-turn.
8. Check oil level.
9. Check oil pressure.


10. Check oil filter cartridge for leaks.

Replace Fuel Filter


⚠ WARNING

FUEL IS FLAMMABLE AND CAN CAUSE DEATH OR SERIOUS INJURY. MAKE SURE NO OPEN FLAMES OR SPARKS ARE IN THE AREA WHEN WORKING ON FUEL SYSTEM. DO NOT SMOKE WHEN WORKING ON FUEL SYSTEM.

1. Wipe area around filter to clean any dirt from area.
2. Remove fuel filter cartridge. Catch any escaping fuel.



3. Clean dirt from filter carrier sealing surface.
4. Apply light film of oil or diesel fuel to rubber gasket of new filter cartridge.
5. Screw in new filter by hand until gasket is flush. Hand-tighten filter another half-turn.




6. Open fuel shut-off valve.
7. Check for leaks.

Clean Fuel Strainer

⚠ WARNING

FUEL IS FLAMMABLE AND CAN CAUSE DEATH OR SERIOUS INJURY. MAKE SURE NO OPEN FLAMES OR SPARKS ARE IN THE AREA WHEN WORKING ON FUEL SYSTEM. DO NOT SMOKE WHEN WORKING ON FUEL SYSTEM.

1. Unscrew hexagonal nut (1).



2. Remove fuel strainer cover (2).
3. Clean fuel strainer with diesel fuel and replace as needed.
4. Place seal (3) in position.
5. Install fuel strainer cover (2). Tighten screw (1).
6. Check for leaks.

3.10 SPARK ARRESTER CLEANING INSTRUCTIONS

1. Remove cleanout plug in bottom of spark arrester (muffler).
2. Without causing deformation (or any type of damage to spark arrester) repeatedly tap on arrester near cleanout plug. This may be enough to begin spark trap drainage.
3. An industrial vacuum cleaner can do a complete job at this point.
 - a. Or, IN A SAFE AREA, start engine. Alternate between low idle and high idle for two to three minutes.
 - b. Or, operate engine as required by application for two to three minutes.
4. Install cleanout plug.

3.11 GLOW PLUGS

If glow plug option is enabled in the JLG Control System, glow plug and indicator lamp will be energized when Power/Emergency Stop switch is pulled on if ambient air temperature is less than 50° F (10° C) and engine coolant temperature is less than 140° F (60° C).

This determination occurs one second after the Power/Emergency Stop switch has been pulled on. Lamp and glow plugs remain energized for period of time specified by setting in the JLG Control System. Engine start is disabled during this period.

On Deutz engines, glow plugs continue (post glow) after engine has started three times the machine digit setting.

SECTION 3 - CHASSIS & TURNTABLE

Table 3-2. Deutz Trouble Codes (D2011L04 Engine)

| FAULT GROUP | FAULT NO. (IN SERDIA) | FAULT LOCALITY/ FAULT DESCRIPTION | SPN | FMI | CAUSE | REMARKS | HELP |
|--------------------------------|-----------------------|-----------------------------------|-------------|-----|---|---|--|
| Zero error display | - | No faults | 5 2 4 2 8 7 | 3 1 | No active faults present | | |
| Revolutions/ speed acquisition | 01 | Speed sensor 1 | 1 9 0 | 8 | Sensor failure. Distance from gear too far. Additional fault impulses. Cable joint interrupted. | Governor in emergency operation (if sensor 2 available). Emergency switch-off (if sensor 2 not available or failed). Governor in emergency operation (with sensor 1) Emergency switch-off (if sensor 1 not available or failed). | Check distance. Check cable connection. Check sensor and replace if required. |
| | 3 | Speed sensor | 8 4 | 8 | Tacho failed. Additional fault impulses. Cable connection interrupted. | Governor in emergency operation. | Check cable connection and Tacho. Replace if required. |
| | 4 | Excess speed switch-off | 1 9 0 | 0 | Speed was/is in excess of limit.e. Check PID setting. Check rods. Check actuator and replace if required. Check cable to actuator (impulse on incorrect speed). Check No. of teeth. For vehicles check for possible thrust mode. | Engine stop. | Check parameter (21). Check speed settings. |
| Sensors | 07 | Charge air pressure | 1 0 2 | 2 | Fault at corresponding sensor entry (e.g. short circuit or cable break). | With failure of the sensor, the associated monitoring function is de-activated. | Check sensor cable. Check sensor and replace if required. Check fault limits for sensor. |
| | 08 | Oil pressure | 1 0 0 | 2 | | | |
| | 09 | Coolant temperature | 1 1 0 | 2 | | | |
| | 10 | Charge air temperature | 1 0 5 | 2 | | | |
| | 11 | Fuel temperature | 1 7 4 | 2 | | | |

Table 3-2. Deutz Trouble Codes (D2011L04 Engine)

| FAULT GROUP | FAULT NO. (IN SERDIA) | FAULT LOCALITY/ FAULT DESCRIPTION | SPN | FMI | CAUSE | REMARKS | HELP |
|------------------------------|-----------------------|---|---------|-----|--|---|--|
| Functional fault warning | 30 | Oil pressure warning | 100 | 1 | Oil pressure below speed-dependent warning line characteristic | Fault message (disappears when oil pressure is again above recovery limit). After a delay time - fill limitation. | Check engine (oil level, oil pump). Check oil pressure sensor and cable. Check oil pressure warning line characteristic. |
| | 31 | Coolant temperature warning | 110 | 0 | Coolant temperature has exceeded warning level. | Fault message (disappears when coolant temperature again drops below recovery level). After a delay time - fill limitation. | Check coolant. Check coolant temperature sensor and cable. |
| | 32 | Charge air temperature warning | 105 | 0 | Charge air temperature has exceeded warning level. | Fault message (disappears when charge air temperature gain drops below recovery level). After a delay time - fill limitation. | Check charge air. Check charge air-temperature sensor and cable. |
| | 34 | Coolant level warning | 111 | 1 | Switch input "Low coolant level" is active. | Fault message. | Check coolant level. Check coolant level sensor and cable. |
| | 35 | Speed warning (with thrust mode operation). | SID 190 | 14 | revolutions was/is above (top) revolution speed limit. "Thrust mode" function is active. | | Check parameters. Check speed settings. |
| | | | | | Check PID setting. Check rods. Check actuator and replace if required. Check cable to actuator. Check speed sensor (impulses on incorrect speed). Check No. of teeth. For vehicles check for possible thrust mode. | | |
| | 36 | Fuel temperature warning | 174 | 0 | Fuel-temperature has exceeded warning level. | Fault message (disappears when fuel temperature again drops below recovery level). | Check fuel. Check fuel temperature sensor and cable. |
| Functional fault, switch-off | 42 | Charge air temperature switch-off | 105 | 0 | Charge air temperature has exceeded switch-off limit. | Emergency stop | Check charge air. Check charge air-temperature sensor and cable. Check switch-off limit. |
| | 44 | Coolant level switch-off | 111 | 1 | Switch input "Low coolant level" is active. | Emergency stop. Start lock. | Check coolant level. Check coolant level sensor and cable. |

SECTION 3 - CHASSIS & TURNTABLE

Table 3-2. Deutz Trouble Codes (D2011L04 Engine)


| FAULT GROUP | FAULT NO. (IN SERDIA) | FAULT LOCALITY/ FAULT DESCRIPTION | SPN | FMI | CAUSE | REMARKS | HELP |
|--------------------------|-----------------------|---|----------|-----|---|---|---|
| Actuator | 50 | Feedback | S ID 24 | 1 2 | Actuator not connected. Fault in actuator confirmation. | Emergency switch-off. Actuator cannot be operated. | Check actuator, replace if required. Check cable, check fault limits for "Confirmation". |
| | 52 | Reference feedback | S ID 24 | 1 3 | | | Check actuator, replace if required. Check cable, check fault limits for "Rifeness confirmation". |
| | 53 | Control travel difference | DI 23 | 7 | Injection pump/actuator jammed or not connected. Difference between nominal/actual control travel is > 10% of the overall control path. | Fault message (disappears when difference is < 10%). | Check actuator/actuator rods / injection pump, replace if required. Check actuator cable. |
| | 59 | Auto calibration BOSCH-EDC pumps faulty operation | S ID 23 | 1 3 | No automatic actuator equalization possible. Incorrect input of the actuator reference values. | Engine stop / start lock. Governor cannot be taken into use. EDC actuator calibration required. | Check actuator and replaced if required. Check feedback cable. Check fault limits and reference values of the feedback. Program the fault limits for feedback, save values. Switch ignition off and on again. Check again. If faulty, inform DEUTZ-Service and carry out automatic equalization again. Set fault limits again. |
| Hardware inputs/ outputs | 60 | Digital output 3 (Switch-off solenoid, pin M 2) | S ID 51 | 2 | Fault (short circuit / cable break) at digital output. | Driver level is switched off. | Check cable of digital output (cable break or short circuit). |
| | 62 | Digital output 6, pin M 7 | S ID 60 | 2 | | Fault message. | |
| | 63 | Excess voltage switch-off solenoid | S ID 51 | 6 | | | |
| | 67 | Error Hand Setp1 | 9 1 | 1 1 | | | |
| | 68 | Error CAN Step 1 | 8 9 8 | 2 | | | |
| Communication | 70 | CAN-Bus controller | S ID 231 | 1 2 | CAN-controller for CAN-bus is faulty. Fault removal despite re- initializing continuously not possible | Application-dependent. | Check CAN connection, terminating resistor (see Chapter 12.4), Check control unit. |
| | 71 | CAN interface SAE J 1939 | S ID 231 | 9 | Overflow in input buffer or a transmission cannot be placed on the bus. | | |
| | 74 | Cable break, short circuit or bus-error | S ID 231 | 1 4 | | | Check CAN connection, cable connection. Check sensor and replace if required. |

Table 3-2. Deutz Trouble Codes (D2011L04 Engine)

| FAULT GROUP | FAULT NO. (IN SERDIA) | FAULT LOCALITY/ FAULT DESCRIPTION | SPN | FMI | CAUSE | REMARKS | HELP |
|-----------------------|-----------------------|--|----------|-----|---|---|--|
| Memory | 76 | Parameter programming (write EEPROM) | S ID 253 | 1 2 | Fault in parameter programming in the governor fixed value memory. | Emergency switch-off. engine cannot be started. | Switch ignition off and on again. Check again. If faulty inform DEUTZ Service |
| | 77 | Cyclic program test | S ID 240 | 1 2 | Constant monitoring of program memory shows error (so-called "Flash-test"). | | |
| | 78 | Cyclic RAM test | S ID 254 | 2 | Constant monitoring of working memory shows error. | | |
| Control unit hardware | 80 | Power supply (Actuator) | S ID 254 | 2 | Power supply for actuator not in the permissible range. | Fault message (disappears when power again in the normal range). | Switch ignition off and on again. Check again. If faulty inform DEUTZ Service. |
| | 83 | Reference voltage 1 | S ID 254 | 2 | Reference voltage for actuator not in the permissible range. | Fault message (disappears when power again in the normal range). Auxiliary value 5 V | Check voltage supply. Switch ignition off and on again. Check again. If faulty inform DEUTZ Service. |
| | 84 | Reference voltage 2 | S ID 254 | 2 | | | |
| | 85 | Reference voltage 4 | S ID 254 | 2 | | | |
| | 86 | Internal temperature | 171 | 12 | Internal temperature for control unit not in permissible range. | Fault message (disappears when power again in the normal range). | Switch ignition off and on again. Check again. If faulty inform DEUTZ Service. |
| | 87 | Atmospheric pressure | 108 | 12 | Atmospheric pressure not in permissible range. | Fault message (disappears when power again in normal range). Atmospheric pressure monitoring function de-activated. | |
| Program logic | 90 | Parameter fault (EEPROM retrieval or checksum faulty). | S ID 253 | 2 | No data found or checksum of data is faulty (note: fault only occurs during setting of parameter / saving or reset.). | Engine cannot be started. | Check data for correct settings. Save parameters. Switch ignition off and on again. Check again. If faulty inform DEUTZ Service. |
| | 93 | Stack overflow | S ID 240 | 2 | Internal calculation fault (so-called "Stack overflow" fault). | Emergency switch-off. Engine cannot be started. | Note parameters (3897 and 3898). Switch ignition off and on again. Check again. If faulty inform DEUTZ Service. |
| | 94 | Internal fault | S ID 254 | 2 | | | |


NOTE: SID is equal to 512. To get SPN #, add 512 + number. For example, SID 254 would be 512+254 or an SPN of 766.

3.12 DEUTZ TD 2.9 L4 GUO III ENGINE



- | | |
|---|---------------------|
| 1. Fuel Tank | 3. Fuel Filter |
| 2. Deutz TD2.9L4 Engine and Pump Assembly | 4. Fuel Supply Pump |


Figure 3-31. Deutz TD 2.9 L4 GUO III Engine Installation



- | | | |
|---------------------------------|--|------------|
| 1. Gear Pump Assembly | 4. Exhaust Pipe | 7. Support |
| 2. Piston Pump Assembly - Rear | 5. Deutz TD2.9L4 GUO III Engine Assembly | |
| 3. Piston Pump Assembly - Front | 6. Hydraulic Oil Cooler | |

Figure 3-32. Deutz TD 2.9 L4 GUO III Engine and Pumps Sub-Assembly

SECTION 3 - CHASSIS & TURNTABLE



MAE26800

- | | | | |
|---------------|---------------------------------|-------------|------------------|
| 1. Radiator | 5. Support | 9. Adapter | 13. Tray |
| 2. Bracket | 6. Pump Coupling | 10. Fan | 14. Bracket |
| 3. Surge Tank | 7. Bracket | 11. Pulley | 15. Engine Mount |
| 4. Air Filter | 8. Deutz TD2.9L4 GUO III Engine | 12. Adapter | 16. Engine Mount |

Figure 3-33. Deutz TD 2.9 L4 GUO III Engine Assembly - Sheet 1 of 2




Figure 3-34. Deutz TD 2.9 L4 GUO III Engine Assembly - Sheet 2 of 2

3.13 COUNTERWEIGHT

If the counterweight has been removed, ensure the retaining bolts are torqued to the proper value as shown in Figure 3-35., Counterweight Bolt Torque.





Figure 3-35. Counterweight Bolt Torque



MAE26210

*Torque the bolts to 795 - 845 ft-lb (1078 - 1146 Nm)

Figure 3-36. Counterweight Bolt Torque

3.14 GENERATOR

Every 250 hours

Check drive belt tension every 250 hours of operation.




Figure 3-37. Generator Belt Tension

Every 500 hours

Service generator brushes and slip rings every 500 hours of operation. Hostile environments may require more frequent service.




Figure 3-38. Generator Brushes and Slip Rings

Blow out inside of generator every 500 hours of service. If operating in a hostile environment, clean monthly.




Figure 3-39. Generator Cleaning

Overload Protection

CAUTION

STOP ENGINE WHENEVER CHECKING OR INSPECTING CIRCUIT BREAKER.

The circuit breaker protects generator windings from overload. Generator output stops if circuit breaker opens.

If circuit breaker continues to open, check for faulty equipment connected to platform receptacles.




Figure 3-40. Generator Circuit Breaker Location (If Equipped with 2500W and 4000W)




Figure 3-41. Generator Circuit Breaker Location (If Equipped with 7500W)

Inspecting Brushes, Replacing Brushes, and Cleaning Slip Rings

INSPECTING BRUSH POSITION

Inspect brush alignment with slip rings. View alignment through air vents in stator barrel. Brushes must ride completely on slip rings.

INSPECTING BRUSHES

1. Remove end panel. Inspect wires.
2. Remove brush holder assembly. Pull brushes from holders.

3. Replace brushes if damaged, or if brush is at or near minimum length.

CLEANING SLIP RINGS

1. Visually inspect the slip rings. Under normal use, the rings turn dark brown.
2. If slip rings are corroded or their surface is uneven, remove belt to turn shaft by hand for cleaning.
3. Clean rings with 220 grit emery paper. Remove as little material as possible. If rings are deeply pitted and do not clean up, consult generator factory service.
4. Reinstall belt, brush holder assembly, and end panel.




Figure 3-42. Inspecting Generator Brushes, Replacing Brushes, and Cleaning Slip Rings

Troubleshooting

Table 3-3. Troubleshooting

| Trouble | Remedy |
|---|---|
| No generator output at platform AC receptacles. | Be sure generator control switch is turned on at platform. |
| | Check and secure electrical connections at platform, generator, and control box. |
| | Be sure all equipment is turned off when starting unit. |
| | Reset circuit breaker CB1. |
| | Check plug PLG3 connection and/or connections at receptacles RC3 and RC5. |
| | Be sure + 12 volts DC input voltage is being supplied to control box. |
| | Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. |
| | Disconnect leads 12 and 13 from brushes, and check continuity across slip rings (nominal reading is 26 ohms). Replace generator if rotor is open. |
| | Disconnect stator weld leads 1, 2, and 3 from circuit breaker CB1, and check continuity between leads. Replace generator if necessary. |
| | Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. |
| | Check power board PC1 and connections, and replace if necessary. |
| | Check control board PC2 and connections, and replace if necessary. |
| Low generator output at platform AC receptacles. | Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). |
| | Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. |
| | Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. |
| | Disconnect stator weld leads 1, 2, and 3 from circuit breaker CB1, and check continuity between leads. Replace generator if necessary. |
| | Disconnect plug PLG4 and check continuity between exciter leads 5 and 6. Replace generator if necessary. |
| | Check power board PC1 and connections, and replace if necessary. |
| | Check control board PC2 and connections, and replace if necessary. |
| High generator output at platform AC receptacles. | Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). |
| | Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. |
| | Check power board PC1 and connections, and replace if necessary. |
| | Check control board PC2 and connections, and replace if necessary. |
| Erratic generator output at platform AC receptacles. | Check and secure electrical connections at platform, generator, and control box. |
| | Verify generator is running at 3600 rpm (60 Hz) or 3000 rpm (50 Hz). |
| | Check slip rings, wiring to brushes, and brush position on slip rings. Install new brushes if necessary. |
| | Disconnect leads 12 and 13 from brushes, and check continuity across slip rings nominal reading is 26 ohms). Replace generator if rotor is open. |
| | Check power board PC1 and connections, and replace if necessary |
| Check control board PC2 and connections, and replace if necessary | |

Generator Disassembly and Assembly

Refer to Figure 3-60. and Figure 3-61. to determine if trouble is in stator, rotor, control box, or combination of these components.

1. Rotor
2. Stator Assembly

CAUTION

DO NOT DAMAGE ROTOR OR STATOR WINDINGS DURING DISASSEMBLY AND ASSEMBLY PROCEDURE.

DISASSEMBLY

1. Mark and disconnect all electrical leads, secure using cable ties.

2. Remove brush holder assembly.
3. Disassemble generator parts shown in Figure 3-59.
4. Clean all parts with approved solvent and dry with compressed air, if applicable.

ASSEMBLY

1. Assemble generator parts using torque values in table.
2. Reconnect all leads. Use cable ties to secure leads away from moving or hot parts.




Figure 3-43. Generator Disassembly and Assembly




Figure 3-44. Generator Troubleshooting Circuit Diagram (Sheet 1 of 2)




Figure 3-45. Generator Troubleshooting Circuit Diagram (Sheet 2 of 2)




Figure 3-46. Generator Electrical Circuit Diagram




Figure 3-47. Power Board PC1 Electrical Circuit Diagram

SECTION 3 - CHASSIS & TURNTABLE




Figure 3-48. Power Board PC2 Electrical Circuit Diagram (Sheet 1 of 2)




Figure 3-49. Power Board PC2 Electrical Circuit Diagram (Sheet 2 of 2)

Lead Connection List for Generator

NOTE: Apply small amount of dielectric grade, non conductive electric grease to connectors where factory-applied grease had been present.

NOTE: Table shows physical lead connections and should be used with circuit diagram (table replaces wiring diagram).

Table 3-4. Lead Connection List for Generator

| Leads | Connections |
|-------|---|
| 1A | STATOR TO CB1 |
| 2A | STATOR TO CB1 |
| 3A | STATOR TO CB1 |
| 4A | STATOR TO TE1 (C) |
| 5A | STATOR TO RC4 (3) |
| 5B | PLG2 (C) TO PLG4 (3) |
| 5C | RC2 (C) PLG31 (8) |
| 6A | STATOR TO RC4 (4) |
| 6B | PLG2 (D) TO PLG4 (4) |
| 6C | RC2 (D) PLG31 (9) |
| 9A | RC5 (B) TO PLG3 (B) (Customer Supplied) |
| 9B | RC3 (B) PLG1 (8) |
| 12A | PLG2 (E) TO PLG4 (5) |
| 12B | RC2 (E) PLG1 (9) |
| 12C | RC4 (5) TO BRUSH |
| 13A | PLG2 (F) TO PLG4 (6) |
| 13B | RC2 (F) PLG31 (4) |
| 13C | RC4 (6) TO BRUSH |
| 15A | PLG1 (6) TO PLG31 (6) |
| 16A | PLG1 (3) TO PLG31 (1) |
| 17A | PLG1 (4) TO PLG31 (2) |
| 21A | CB1 TO TE1 (F) |
| 21B | PLG2 (A) TO PLG4 (1) |
| 21C | PLG1 (1) TO RC2 (A) |
| 21D | RC4 (1) TO CB1 |
| 22A | CB1 TO TE1 (E) |
| 22B | PLG2 (B) TO PLG4 (2) |
| 22C | PLG1 (2) TO RC2 (B) |
| 22D | RC4 (2) TO CB1 |
| 23A | CB1 TO TE1 (D) |
| 42A | RC5 (C) TO PLG3 (C) (Customer Supplied) |
| 42B | RC3 (C) TO CONNECTION POINT 1 |
| 42C | PLG31 (7) TO CONNECTION POINT 1 |
| 42D | PLG1 (5) TO CONNECTION POINT 1 |
| 42F | END BELL SHROUD TO ENGINE MOUNT |
| 42G | CHASSIS TO TE1 (B) |
| 43A | RC5 (A) TO PLG3 (A) (Customer Supplied) |
| 43B | RC3 (A) TO CONNECTION POINT 2 |
| 43C | PLG31 (3) TO CONNECTION POINT 2 |
| 43D | PLG1 (7) TO CONNECTION POINT 2 |

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

A screenshot of the "Search Manuals" form. The form has a title "Search Manuals" and a subtitle "Please provide information to help us locate the manual and/or parts you need." It includes several input fields: "Brand" (a dropdown menu), "Serial Number" (a text field), "Model" (a dropdown menu), "Part Number" (a text field), "Part Description" (a text field), and "Comments" (a text area). A "Search" button is located at the bottom of the form.

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

A screenshot of the "Parts Order Form". The form has a title "Parts Order Form" and a subtitle "Please fill in as much information as possible." It includes several input fields: "Manufacturer" (a dropdown menu), "Model" (a dropdown menu), "Part Number" (a text field), "Part Description" (a text field), "Quantity" (a text field), "Comments" (a text area), and "Requester Name" (a text field). A "Submit" button is located at the bottom of the form.

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 4. BOOM & PLATFORM

⚠ WARNING

CRUSH HAZARD. DO NOT SUPPORT THE BOOM WITH A BOOM PROP OR CRANE OR ALLOW THE PLATFORM TO REST ON THE GROUND WHEN SERVICING BOOM COMPONENTS. BOOM MUST BE ON BOOM REST OR COMPLETELY REMOVED FROM MACHINE WHEN SERVICING. FAILURE TO COMPLY COULD RESULT IN DEATH OR SERIOUS INJURY.

4.1 TRANSPORT POSITION SENSING SYSTEM

The transport position sensing system consists of a boom angle sensor (this sensor is a hall effect sensor with built-in redundancy) mounted at the pivot point between the main boom and tension link. The system uses this sensor to sense if the boom is in the position associated with high speed travel. The control circuit reads two redundant angular sensor signals from the boom angle sensor. Above transport angle is recognized when one angular sensor signal from the boom angle sensor reads more than 5° greater than horizontal (with respect to the turntable) and resets to within transport position when both angular sensor signals read less than 3° greater than horizontal (with respect to the turntable). The position of the articulated jib is not considered. This system is used to control the following systems:

Beyond Transport - Drive Speed Cutback System
Drive/Steer - Boom Function Interlock System

4.2 BEYOND TRANSPORT - DRIVE SPEED CUTBACK SYSTEM

When the boom is positioned beyond the transport position, the drive motors are automatically restricted to their maximum displacement position (slow speed). See the Tilt Indicator System for interaction with the tilt sensor.

4.3 DUAL CAPACITY SYSTEM

The dual capacity selection and indicator system consists of a capacity mode toggle switch at the platform control box, a set of redundant proximity sensors to detect boom extension, and a main boom angle sensor.

The control system obtains the platform load from Platform Load Sensing System (LSS) and determines the working zone:

- 660SJC: 550 lb (250 kg) unrestricted, 750 lb (340 kg) restricted.

The light indicator in the platform control box will change to match the selected mode, unless there is a system DTC that forces the machine into the restricted mode. The system uses the boom extension proximity sensors and boom angle sensor to prevent the platform from entering the unrestricted zone if the restricted mode is selected.

When the dual capacity switch is in the restricted position, the platform will move but stop at the boundaries of the restricted zone. The platform will not be able to enter the unrestricted

zone. When the machine control system senses the platform is already on the boundaries of the restricted zone, it only allows the retraction of the boom or lifting up of the boom as these movements place the platform further away from the unrestricted zone.

In case the platform is already inside the restricted zone and the dual capacity switch is flipped to the unrestricted position at that time, the machine will only allow the boom to retract and will only allow the boom to lift up, as these movements will bring the platform towards the restricted zone.

When the dual capacity switch is in the unrestricted position, the platform can go anywhere within the whole boundaries.

4.4 PLATFORM LOAD SENSING SYSTEM

The Platform Load Sensing System consists of a single load cell mounted within the platform support. This system compares the capacity mode recognized by the triple capacity system to the measured weight in the platform. When the platform capacity is exceeded or when there is a fault in the system, the platform overload indicator will flash, the platform alarm will sound at the rate of 5 sec on / 2 sec off and all platform function controls (except auxiliary power) will be disabled. The ground controls are unaffected unless configured otherwise in the machine setup selection.

4.5 ELECTRONIC PLATFORM LEVELING

The Electronic Platform Leveling System simulates a conventional master/slave cylinder arrangement by adjusting the leveling cylinder stroke based on the boom angle changes during the lift operation. The system uses two rotary angle sensors (Internally Redundant Hall Effect Sensors), one to measure the main boom angle relative to the tension link and one to measure the platform angle relative to the main boom.

The first angle sensor is mounted concentric with the pin that connects the base boom to the tension link. As the boom rises or lowers the sensor sends a signal to the UGM which determines, through an algorithm that considers the boom linkage geometry, the required angle at the second sensor.

For 660SJC, the sensor is mounted with the pin between fly boom and jib pivot. As the level cylinder in the fly boom is activated to adjust the angle between the platform and the fly boom the angle sensor signal is sent to the UGM. Once the required platform to fly boom angle (as determined by the UGM based on the first sensors input) is reached the movement of the level cylinder is stopped. This leveling system operates like a conventional master/slave cylinder system, meaning that it will not correct level relative to gravity but maintain the platform angle relative to gravity as it was manually set by the operator prior to activation of the lift function.

4.6 FUEL LEVEL CUTOUT SYSTEM

The Fuel Shutoff System senses when the fuel level is getting low and automatically shuts the engine down before the fuel tank is emptied. When the fuel level gets below 1.2 gallons, the fault light will flash at the platform controls and the control system will report fault 0/0 "FUEL LEVEL LOW – ENGINE SHUT-DOWN" on the analyzer. There is an analyzer personality setting in the control system to control the machines response to this fault. With the "RESTART" setting, the operator will be able to start the engine and run for 2 minutes. After 2 minutes, the engine will shut off and a power cycle will allow the engine to run for 2 more minutes. With the "ENGINE STOP" setting, the machine will remain in this fault mode until the fuel level is returned to a level above 1.2 gallons. With the "ONE RESTART" setting, the operator will be able to start the engine and run for 2 minutes. After 2 minutes, the engine will shut off for a second time and the machine will return to the "Engine Shut-down" fault mode. The machine will then stay in this mode until the fuel level is returned to a level above 1.2 gallons.

4.7 GROUND CONTROL KEYSWITCH SYSTEM

The ground control keyswitch is used for selecting the active control of the machine between the platform or ground control stations and as another shut off switch for machine power. On the standard keyswitch, the key is removable only in the off position. This allows the ground control station to have ultimate priority over the platform control.

4.8 FUNCTION SPEED CONTROL SYSTEM


The platform controls for the platform rotate, platform level, jib lift, telescope, and tower lift functions are controlled through a common variable speed control knob. This knob provides a common control signal allowing a smooth ramp up, controlled maximum output speed, and ramp down. Each function has its own personality settings allowing the characteristics of each function to be modified using the standard analyzer. Not all functions will respond the same to the changes in the function speed knob position.

The variable speed control knob when turned counterclockwise and into the detent position (shown with a snail on the control panel decal), will place all functions, including proportional functions, in creep.

4.9 PLATFORM

Support Removal

1. Disconnect electrical cables from control console.
2. Tag and disconnect the hydraulic lines from the rotator. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
3. Remove the bolts securing the platform to the platform support, then remove the platform.




MAE17160


4. Using a suitable lifting device, support the platform support.

NOTE: The platform support weighs approximately 125 lb (56.7 kg).

5. Remove the bolts and washers securing the support to the rotator.



6. Using a suitable brass drift and hammer, remove the rotator shaft, then remove the support from the rotator.




Support Installation


1. Using a suitable lifting device, support the platform support and position it on the rotator.

NOTE: The platform support weighs approximately 125 lb (56.7 kg).

NOTE: Install the rotator center bolt.




2. Apply Medium Strength Threadlocking Compound to the bolts and washers securing the support to the rotator and install the bolts and washers.




SECTION 4 - BOOM & PLATFORM

3. Torque the nut on the rotator center bolt to 586 ft. lbs. (795 Nm). Torque the retaining bolts to 40 ft. lbs. (55 Nm).
4. Position the platform on the platform support and install the bolts securing the platform to the platform support.



5. Remove tag and reconnect the hydraulic lines to the rotator.
6. Connect the electrical cables to the platform control console.

Go to Discount-Equipment.com to order your parts



A - Torque to 40 ft-lb (55 Nm)

B - Medium Strength Threadlocking Compound

C - Torque to 586 ft-lb (795 Nm)

D - Check torque every 150 hours of operation

E - Torque to 65 ft-lb (88 Nm)

NOTE: If any rotator bolts are replaced, all bolts on the rotator should be retorqued.

Figure 4-1. Platform Support Torque Values

4.10 ROTATOR AND SLAVE CYLINDER

NOTE: Refer Figure 4-2., Removal of Components - Rotator and Platform Level Cylinder.

Removal

1. Tag and disconnect hydraulic lines from the rotator. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
2. Supporting the rotator, remove hardware from pin (1). Using a suitable brass drift and hammer remove pin (1) from the jib assembly.
3. Remove the hardware from pin (2). Using a suitable brass drift and hammer, remove pin (2) from the jib assembly and remove the rotator.
4. Telescope the fly section out approximately 20 in. (50.8 cm) to gain access to the slave leveling cylinder.
5. Remove the hardware from pin (3). Using a suitable brass drift and hammer remove pin (3) from the jib assembly.
6. Supporting the slave cylinder, remove the hardware from pin (4). Using a suitable brass drift and hammer remove pin (4) from the fly boom.

Assembly/Disassembly

For detail assembly/disassembly instruction, Refer Rotary Actuator Manual (PN 3128848).

Installation

1. Telescope the fly section out approximately 20 in. (50.8 cm) to gain access to the slave leveling cylinder.
2. Support the slave cylinder. Using a suitable brass drift and hammer, install pin (4) to the fly boom.
3. Using a suitable brass drift and hammer, install pin (3) to the jib assembly.
4. Support the rotator. Using a suitable brass drift and hammer, install pin (2) to the fly boom and install the rotator.
5. Using a suitable brass drift and hammer, install pin (1) to the rotator.
6. Remove tag and reconnect the hydraulic lines to the rotator and the slave cylinder.




Figure 4-2. Removal of Components - Rotator and Platform Level Cylinder

4.11 MAIN BOOM ASSEMBLY

Removal

NOTE: Refer to Figure 4-3., Boom Assembly Removal and Installation.

1. Level the boom and support boom assembly and tower link with adequate lifting equipment as shown below.
2. Use a ratchet strap to bind the tower link to boom.

NOTE: The boom alone weighs approximately 2792 lb (1269 kg). Including the powertrack, slave cylinder, rotator, jib, platform and platform support the assembly weighs approximately 7500 lb (3400 kg).

3. Tag and disconnect all electrical connections from the boom assembly.
4. Tag, disconnect and cap hydraulic lines from telescope cylinder and boom lift cylinder. Use an adequate container to catch any residual hydraulic fluid.

NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID ENTRY OF CONTAMINANTS INTO SYSTEM.

5. Tag and disconnect hydraulic lines from boom to the main control valve. Use an adequate container to catch any residual hydraulic fluid. Cap or plug all open hydraulic lines and ports.
6. Remove retaining bolt, keeper pin, and pin (1) securing the tower link to the turntable.
7. Lift and move forward the boom assembly with tower link and boom lift cylinder to gain the access to boom pivot pin (2). Ensure tension link pivot pin is above the turntable lifting point.
8. Insert an adequate metal rod into the lifting eye holes to support the tension link.
9. Remove retaining bolt, keeper pin, and pin securing the main boom pivot pin (2) to the tension link.
10. Remove complete boom assembly and lift cylinder with tower link and lift cylinder from the machine and place it on a suitable support.

11. Support the boom lift cylinder and remove retaining bolts, keeper pins, and pins (3 and 4) securing the lift cylinder and tower link to the boom assembly.
12. Remove the boom assembly.
13. If required, remove retaining bolt, keeper pin, and pin (5) securing tension link to the turntable and place it on an adequate support.

NOTE: The tension link weighs approximately 419 lb (190 kg).





Figure 4-3. Boom Assembly Removal and Installation

Boom Disassembly

1. Tag and disconnect the hoses and electrical harnesses that run to the platform. Cap or plug all openings.
2. Remove hardware securing the cover plate and sheave blocks on the bottom front of the base boom section. Remove the cover plate and sheave blocks.


NOTE: Do not allow wire rope to rotate. This may damage the wire rope. Clamp both threaded ends of wire rope to prevent rotation.



3. Clamp both threaded ends of wire rope to prevent rotation.


NOTE: Do not clamp on threads. Remove jam nuts and nuts which secure the wire rope adjustments to the bottom front of the base boom section.

4. Remove the hardware securing base boom cover plate and base boom. Remove base boom cover plate from the end of the boom section.




MAE22920

5. Remove the hardware securing spring mounting plate and spring to the cable block. Remove the spring mounting plate and spring from the end of the boom section.




MAE22930

6. Remove hardware securing cable block to boom section. Remove cable block.




MAE22940


- 7.** Remove hardware securing valve to telescope cylinder. Remove the valve assembly.



- 8.** Remove the four bolts, shims, and block that secure the telescope cylinder rod to the boom base section.




- 9.** Attach an auxiliary hydraulic power source to the telescope cylinder and extend the cylinder rod enough to turn the trunnion in a vertical position.




- 10.** Pull the mid and fly boom sections from the base boom section. Use additional lifting device and lifting straps as necessary as the sections are withdrawn. It will be helpful during this step to pull the mid retract cable out from the front of the boom section as the other sections are being pulled out. This will prevent the cables from tangling as the sections are withdrawn.

- 11.** Remove the trunnion blocks that secure the telescope cylinder barrel to the inner mid boom section.




SECTION 4 - BOOM & PLATFORM

12. Remove the hardware that secure rope extend block to the fly boom section.




MAE23020

13. Attach a lifting device to the telescope cylinder, pull the cylinder along with the extend cables, sheave assembly and sheave guard out of the fly boom section. Reposition the lifting device as necessary to balance the cylinder.
14. Remove extent block and cable from the telescope cylinder.
15. Remove the pin that secures sheave assembly to telescope cylinder.




MAE23000

16. Remove spacer and hardware that secure sheave guard to the telescope cylinder.



MAE23010

17. Remove the sheave assembly by adjusting the sheave guard then remove the bracket and cable.
18. Remove the cable retainer plate, cable retainer block, bushing and sheave.




MAE23030

19. Remove the top, bottom and side wear pads from the front mid boom sections.
20. Attach a lifting device to the fly boom section, pull the fly boom from mid boom.
- NOTE:** When removing fly boom section from mid boom section, retract wire rope must be dragged along with fly boom section.
21. Remove the top, bottom and side wear pads from the rear end fly boom sections.
22. Remove the fly boom retract cables from the bottom of the fly boom sections.
23. Thoroughly clean the boom sections.

Assembly


NOTE: When installing fly section wear pads, install same number and thickness of shims as were removed during disassembly.

1. Measure inside dimensions of the base and mid sections to determine the number of shims required for proper lift.
2. Install side, top and bottom wear pads to the rear end of fly section; shim evenly to the measurements of the inside of mid section. Torque the bolts to 40.6 ft. lbs. (55 Nm).
3. Install retract wire ropes into rear end of fly section, route wire ropes through holes in side of fly boom section and pull into slot.
4. Install side, top and bottom wear pads to the rear end of mid section, shim evenly to the measurements of the inside of mid section. Torque the bolts to 40.6 ft. lbs. (55 Nm).
5. Using Super Lube, lubricate all wear surfaces on the outside of fly boom and inside of the mid boom.
6. Slide fly boom section into mid boom section.
7. Install wear pads into the front end of the mid boom section. Torque the bolts to 40.6 ft. lbs. (55Nm).
8. Apply a thin coat of moly paste lubricant to the inside diameter of the sheave composite bearings. Install the fly retract sheaves and bushings while guiding the wire ropes into the sheave grooves. Apply moly paste lubricant on the inside diameter of the sheave bushing cup. Ensure the sheaves move freely.




MAE23030

9. Install sheave on the telescope cylinder secure with pin and bolts.



MAE23010

10. Route the cables around the sheave on the cylinder and install the sheave guard.




MAE23000

11. Using an adequate lifting device, insert the cylinder and cables part way into the inner fly boom.


SECTION 4 - BOOM & PLATFORM

12. Install end of the extend cables into the extend rope block.



MAE23020


13. Install the bolts and washers securing the extend rope block to the fly boom. Torque the bolts to 40.6 ft. lbs. (55 Nm).
14. Install the cylinder trunnion block and shims that secure the telescope cylinder barrel to the mid boom section. Torque the bolts to 40.6 ft. lbs. (55 Nm).



MAE22990

15. Turn the trunnion of Rod in a vertical position.
16. Using Super Lube, lubricate all wear surfaces on the inside of the base section and the outside of the mid boom.


17. Insert the mid, fly and Tele cylinder assembly way into the boom base section enough to be able to pull the outer mid retract cables out through the hole at the bottom front of the boom base section.
18. Install the front lower wear pads into the boom base section. Torque the bolts to 40.6 ft. lbs. (55 Nm).
19. Push the mid boom assembly the rest of the way into the boom base section, adjusting the lifting device as necessary to keep the weight balanced.
20. Install the side and upper wear pads into the boom base section. Torque the bolts to 40.6 ft. lbs. (55 Nm).
21. Install hardware securing valve to telescope cylinder. Install the valve assembly. Torque the bolts to 42.8 ft. lbs. (58 Nm).




MAE22950

22. Attach an auxiliary hydraulic power source to the telescope cylinder, extend cylinder enough so the trunnion of Rod out of base boom, turn rod trunnion to horizontal position. Retract cylinder so the trunnion of rod slide into the slot on base boom.


- 23.** Install the four bolts, shims, and bars that secure the telescope cylinder rod to the boom base section. Torque the bolts to 40.6 ft. lbs. (55 Nm).



- 24.** Route extend cable through cable block and install the cable block on base boom.




- 25.** Install the hardware securing spring mounting plate and spring to the cable block.



- 26.** Install base boom cover plate to base boom at the end of the boom section.

- 27.** Install the cover plate and sheave blocks.



- 28.** Connect the hydraulic hoses to the telescope cylinder as tagged during removal.

- 29.** Adjust the boom cables. Refer to Section 4.15, Wire Rope Tensioning Adjustment.

- 30.** Install jam nuts and nuts which secure the wire rope.

Installation

NOTE: Refer to Figure 4-3., Boom Assembly Removal and Installation.

NOTE: The boom alone weighs approximately 2792 lb (1269 kg). Including the powertrack, slave cylinder, rotator, jib, platform and platform support the assembly weighs approximately 7500 lb (3400 kg).

1. If tension link is removed, insert an adequate metal rod into the turntable lifting eye holes to support the tension link.
2. Using an adequate lifting device, position the tension link on turntable so that the pivot holes of tension link and turntable holes are aligned.

NOTE: The tension link weighs approximately 419 lb (190 kg).

3. Install pin, keeper pin, and retaining bolt (5) securing tension link to the turntable. Apply Medium Strength Threadlocking Compound and torque to 346 ft.lbs. (469 Nm).

NOTE: Steps 1, 2, and 3 are only necessary if the tension link has been removed.

4. Place the tower link with boom lift cylinder on the proper support.
5. Use an adequate lifting device, lift the boom assembly and install pin, keeper pin, and retaining bolt (4) securing the tower link to the boom assembly. Apply Medium Strength Threadlocking Compound and torque to 346 ft.lbs. (469 Nm).
6. Install pin, keeper pin, and retaining bolt (3) securing lift cylinder rod end pin to main boom assembly. Apply Medium Strength Threadlocking Compound and torque to 346 ft.lbs. (469 Nm).
7. Using an adequate lifting device, lift and position the boom assembly with tower link and boom lift cylinder on turntable so that the pivot holes of boom assembly and tension link are aligned.
8. Install boom pivot pin, keeper pin, and retaining bolt (2), ensuring that location of hole in pin is aligned with attach point on tension link.

9. Lift and move forward the boom and tower link assembly.
10. Remove metal rod from the turntable lifting eye holes and level the boom assembly to normal position.
11. Install pin, keeper pin, and retaining bolt (1) securing tower link to turntable. Apply Medium Strength Threadlocking Compound and torque to 346 ft.lbs. (469 Nm).
12. Reconnect all hydraulic lines as tagged during removal.
13. Reconnect all electrical connections to the boom assembly as tagged during removal.
14. If necessary, adjust retract and extend cables to the proper torque. Refer to Section 4.15, Wire Rope Tensioning Adjustment for wire rope torque procedures.
15. Using all applicable safety precautions, raise and extend boom fully, then retract and lower boom. Check for proper operation and hydraulic leaks.

4.12 MAIN BOOM LIFT CYLINDER

Removal

NOTE: Refer to Figure 4-4., Main Boom Lift Cylinder Removal and Installation.

1. Remove main boom assembly with tower link and lift cylinder from the machine and place it on a suitable support. Refer to Section 4.11, Main Boom Assembly for removal procedure.
2. Place blocking under the lift cylinder to prevent it from falling when the attaching hardware is removed.
3. Attach an adequate lifting device and sling to the main lift cylinder.

NOTE: The Main Lift Cylinder weighs approximately 557 lb (253 kg).

4. Remove trunnion pins (1), hardware and bearings (if necessary) securing boom lift cylinder to the tower link.
5. Carefully lift the cylinder clear of the tower link and lower to the ground or suitably supported work area.

Installation

1. Using an adequate lifting device, position the lift cylinder in tower link in the same manner that it was removed.
2. Install trunnion pins (1), hardware and bearings securing boom lift cylinder to the tower link.
3. Install main boom assembly with tower link and lift cylinder to the turntable. Refer to Section 4.11, Main Boom Assembly for Install procedure.




Figure 4-4. Main Boom Lift Cylinder Removal and Installation

4.13 MAIN BOOM POWERTRACK

Removal

1. Disconnect wiring harness from ground control box.

NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID ENTRY OF CONTAMINANTS INTO SYSTEM.

2. Tag and disconnect hydraulic lines from boom to control valve. Use a suitable container for residual hydraulic fluid. Cap hydraulic lines and ports.
3. Remove hydraulic lines and electrical cables from the powertrack.
4. Using a suitable lifting equipment, adequately support powertrack weight along entire length.
5. Remove bolts (1) securing push tube on fly boom section.

6. Remove bolts (2) securing push tube on mid boom section.
7. With powertrack support and using all applicable safety precautions, remove bolts (3) securing rail to the base boom section. Remove powertrack from boom section.

Installation

1. With powertrack supported and using all applicable safety precautions, install hardware (3) securing rail to the base boom.
2. With adequate support and lifting device align, place mid boom push tube on the boom section to get access to install hardware (2).
3. Install the hardware (1) securing powertrack to fly boom push tube.
4. Connect all hydraulic lines and electrical cables to powertrack as tagged during removal.
5. Connect wiring harness to ground control box.





Figure 4-5. Powertrack Components



MAE26860

- | | | | |
|---------------------|-------------------------------|-------------------------------|---------------|
| 1. Bolt | 6. Bracket | 11. Boom Angle Sensor (Upper) | 16. Tie-Strap |
| 2. Screw | 7. Proximity Sensor | 12. Plate | 17. Plate |
| 3. Screw | 8. Plate | 13. Clip | |
| 4. Washer | 9. Shield | 14. Nut | |
| 5. Proximity Sensor | 10. Boom Angle Sensor (Lower) | 15. Bolt | |

Figure 4-6. Boom Sensors Installation

4.14 WIRE ROPE

⚠ WARNING

IF DELAYED MOVEMENT IS DETECTED IN WIRE ROPE OPERATION, LOWER PLATFORM TO STOWED POSITION, SHUT DOWN MACHINE, AND HAVE WIRE ROPES INSPECTED/SERVICED BY A QUALIFIED JLG MECHANIC. LOOSE OR MIS-ADJUSTED WIRE ROPES COULD RESULT IN SERIOUS INJURY OR DEATH.

⚠ CAUTION

WIRE ROPE CAN HAVE SHARP EDGES AND CAUSE SERIOUS INJURY. NEVER HANDLE WIRE ROPE WITH BARE HANDS.

Each day before using machine:

1. Raise main boom approximately horizontal.
2. Extend and retract the boom sections.
3. Check for delayed movement of fly section which indicates loose wire ropes.

Inspection

NOTE: Pictures in this paragraph are samples to show rope replacement criteria.

1. Inspect ropes for broken wires, particularly valley wire breaks and breaks at end terminations.

NOTE: Flexing a wire rope can often expose broken wires hidden in valleys between strands.




Figure 4-7. Wire Rope Wire Breaks

2. Inspect ropes for corrosion.

3. Inspect ropes for kinks or abuse.

NOTE: A kink is caused by pulling down a loop in a slack line during improper handling, installation, or operation.




Figure 4-8. Wire Rope Kink

4. Inspect sheaves for condition of bearings/pins. (See Dimension Of Sheaves for proper dimension.) Inspect sheaves for condition of flanges. (See Dimension Of Sheaves for proper dimension.)
5. Inspect sheaves with a groove wearout gauge for excessive wear.

NOTE: Check groove so that it may be clearly seen if gauge contour matches sheave groove contour.




Figure 4-9. Sheave Groove Wear

6. Ropes passing inspection should be lubricated with wire rope lubricant before reassembly.

Three Month Inspection

1. Remove boom covers and visually (with flashlight) inspect the ropes for rust, broken wires, frays, abuse, or any signs of abnormalities.
2. Check wire rope tension by deflecting wire ropes by hand. Properly tensioned ropes should have little or no movement.

Additional Inspection Required If:

1. Machine is exposed to hostile environment or conditions.
2. Erratic boom operation or unusual noise exists.
3. Machine is idle for an extended period.
4. Boom is overloaded or sustained a shock load.
5. Boom exposed to electrical arc. Wires may be fused internally.

12 Year or 7000 Hour Replacement

1. Mandatory wire rope and sheave replacement.

Additional Replacement Criteria

NOTE: Sheaves and wire rope must be replaced as sets.


1. Rusted or corroded wire ropes.
2. Kinked, "bird caged", or crushed ropes.
3. Ropes at end of adjustment range.
4. Sheaves failing wearout gage inspection.
5. Ropes with 6 total broken wires in one rope lay, 3 in one strand in one rope lay, 1 valley break, or 1 break at any end termination.

4.15 WIRE ROPE TENSIONING ADJUSTMENT

Wire Rope Tensioning Procedure

1. Position boom in fully down and retracted position.

| | |
|--------|------------|
| Model | 660SJC |
| Dim. A | 17" (44cm) |
| Dim. B | 9" (23cm) |



MAE22840

Figure 4-10. Dimensions of Boom Sections

NOTICE

DO NOT CLAMP ON THREADS OR THREADS MAY BE DAMAGED.

DO NOT ALLOW WIRE ROPE TO ROTATE OR WIRE ROPE MAY BE DAMAGED. CLAMP THREADED ENDS OF WIRE ROPE TO PREVENT ROTATION.




Figure 4-11. Clamping Wire Ropes

2. Install adjusting nuts (or remove nylon collar locknuts if re-adjusting) to both retract and extend wire ropes.
3. Torque retract adjusting nuts (platform end) to 15 ft-lb (20 Nm) alternating between the two wire ropes and keeping approximately the same amount of thread beyond the adjusting nut.
4. Repeat torque procedure in step #3 to extend wire ropes (turntable end).
5. Extend boom 2 - 3 feet using telescope function. Repeat step #3.
6. Retract boom 1 - 2 feet using telescope function. Do not bottom out telescope cylinder. Repeat step #4.
7. Extend boom approximately 2 - 3 feet again and check torque on retract wire ropes.
8. Retract boom without bottoming out telescope cylinder. Check torque on extend wire ropes.

NOTE: Step #7 and #8 may need to be repeated to equalize the torque on all 4 wire ropes.

9. After all wire ropes are properly torqued, install nylon collar locknuts. Remove all clamping devices and install all covers and guards. Check boom for proper function.

4.16 WIRE ROPE SERVICE INDICATOR

The wire rope service indicator is integrated into the mounting block that the extension wire ropes mount to at the end of the base boom. More specifically, the smaller diameter wire rope mounts to a spring loaded block that also contains a proxy sensor. In the event that the rope breaks, the block with the proxy sensor is pushed away from the main mounting block through the spring which causes a warning light to be lit in the platform control box. All boom functions are still operable.

4.17 JIB ASSEMBLY

NOTE: Using a suitable lifting device, support the jib.

Removal

1. For platform and support removal see Section 4.9 - Platform.
2. Position the articulating jib boom level with ground.


NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID ENTRY OF CONTAMINANTS INTO SYSTEM.

3. Tag and disconnect hydraulic lines from level cylinder and lift cylinder. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
4. Remove mounting hardware from slave leveling cylinder pin (1). Using a suitable brass drift and hammer, remove the cylinder pin from jib assembly.
5. Remove mounting hardware from jib assembly boom pivot pin (2). Using a suitable brass drift and hammer, remove the pivot pin from boom assembly.

Disassembly

1. Remove mounting hardware from articulating jib boom pivot pins (3) and (4). Using a suitable brass drift and hammer, remove the pins from articulating jib boom pivot weldment.
2. Remove mounting hardware from rotator support pins (5) and (6). Using a suitable brass drift and hammer, remove the pins from rotator support.
3. Remove mounting hardware from lift cylinder pin (7). Using a suitable brass drift and hammer, remove the cylinder pin from articulating jib boom.



Inspection

NOTE: When inspecting pins and bearings Refer to Section 2.5, Pins and Composite Bearing Repair Guidelines.


1. Inspect fly boom pivot pin for wear, scoring, tapering and ovality, or other damage. Replace pins as necessary.
2. Inspect fly boom pivot attach points for scoring, tapering and ovality, or other damage. Replace pins as necessary.
3. Inspect inner diameter of fly boom pivot bearings for scoring, distortion, wear, or other damage. Replace bearings as necessary.
4. Inspect lift cylinder attach pin for wear, scoring, tapering and ovality, or other damage. Ensure pin surfaces are protected prior to installation. Replace pins as necessary.
5. Inspect inner diameter of rotator attach point bearings for scoring, distortion, wear, or other damage.
6. Inspect all threaded components for damage such as stretching, thread deformation, or twisting. Replace as necessary.
7. Inspect structural units of jib boom assembly for bending, cracking, separation of welds, or other damage. Replace boom sections as necessary.

Assembly

1. Align lift cylinder with attach holes in jib assembly. Using a soft head mallet, install cylinder pin (7) into jib and secure with mounting hardware.
2. Align rotator support with attach hole in jib assembly. Using a soft head mallet, install rotator support pin (6) into jib and secure with mounting hardware.
3. Align bottom tubes with attach holes in rotator support. Using a soft head mallet, install rotator support pin (5) into jib assembly and secure with mounting hardware.
4. Align jib assembly with attach hole in jib boom pivot weldment. Using a soft head mallet, install rotator support pin (4) into jib assembly and secure with mounting hardware.
5. Align bottom tubes with attach holes in jib boom pivot weldment. Using a soft head mallet, install rotator support pin (3) into jib boom pivot weldment and secure with mounting hardware.

Installation

1. Align jib boom pivot weldment with attach holes in fly boom assembly. Using a soft head mallet, install pivot pin (2) into fly boom assembly and secure with mounting hardware.
2. Align the slave leveling cylinder with attach holes in jib boom pivot weldment. Using a soft head mallet, install slave leveling cylinder pin (1) into articulating jib boom pivot weldment and secure with mounting hardware.



4.18 BOOM CLEANLINESS GUIDELINES

The following are guidelines for internal boom cleanliness for machines used in excessively dirty environments.

1. JLG recommends use of JLG Hostile Environment Package to keep internal portions of a boom cleaner and help prevent dirt and debris from entering the boom. This package reduces the amount of contamination which can enter the boom, but does not eliminate the need for more frequent inspections and maintenance when used in these types of environments.
2. JLG recommends you follow all guidelines for servicing your equipment in accordance with instruction in the JLG Service & Maintenance Manual for your machine. Periodic maintenance and inspection is vital to proper operation of the machine. Frequency of service and maintenance must be increased as environment, severity, and frequency of usage requires.
3. Debris and contamination inside the boom can cause premature failure of components and should be removed. Methods to remove debris should always be done using all applicable safety precautions outlined in the JLG Operation & Safety Manual and the JLG Service & Maintenance Manuals.

4. The first attempt to remove debris from inside the boom must be to utilize pressurized air to blow the debris toward the nearest exiting point from the boom. Make sure that all debris is removed before operating the machine.
5. If pressurized air cannot dislodge debris, then water with mild solvents applied with a pressure washer can be used. Wash debris toward the nearest exiting point from the boom. Make sure all debris is removed, no "puddling" of water has occurred, and boom internal components are dry before operating machine. Make sure you comply with all federal and local laws for disposing of wash water and debris.
6. If pressurized air or washing boom does not dislodge and remove debris, disassemble boom following instructions outlined in the JLG Service & Maintenance Manual to remove debris.

4.19 FOOT SWITCH ADJUSTMENT

Adjust foot switch to operate functions when pedal is at center of travel. Adjust if switch operates within last 1/4 in. (6.35 mm) of top or bottom travel.

⚠ WARNING

ELECTRIC SHOCK OR UNCONTROLLED MACHINE MOVEMENT CAN CAUSE DEATH OR SERIOUS INJURY. DISCONNECT INPUT POWER BEFORE PERFORMING INSTALLATION OR MAINTENANCE.

NOTE: For models with two switches, both switches can be independently adjusted.

1. Remove four socket head capscrews and cover from foot switch assembly.
2. To increase travel before switch is activated, turn Adjustment Screw clockwise.
3. To decrease travel before switch is activated, turn Adjustment Screw counterclockwise.




Figure 4-12. Foot Switch Adjustment

4. Install cover and secure with four socket head capscrews. Torque to 18-22 in-lb (2-3 Nm).

4.20 PLATFORM CONTROL ENABLE SYSTEM

The platform controls use a time dependant enable circuit to limit the time availability of "live" or enabled controls. When the footswitch is depressed, the controls are enabled and the operator has 7 seconds to operate any control. The controls will remain enabled as long as the operator continues to use any function and will remain enabled 7 seconds after the last function has been used. While the controls are "live", the enabled light will be illuminated in the platform display panel. When the time limit has been reached, the enabled light will turn off and the controls will be disabled. To continue use of the machine the controls must be re-enabled to start the timer system over again. This is done by releasing all functions, then releasing and re-depressing the footswitch.

4.21 POWERTRACK MAINTENANCE

Remove Link


NOTE: Hoses shown in powertrack are for example only. Actual hose and cable arrangements are different.



1. Clamp bar and poly roller tightly so they do not spin when removing screw. With a small ¼" ratchet and a T-20 Torx bit, remove 8-32 x 0.500 screw from one side.



2. Repeat step 1 and remove screw from other side of track. Remove bar/poly roller from powertrack.




NOTICE


REPOSITION CABLES/HOSES. KEEP COVERED DURING GRINDING TO PREVENT DAMAGE.

SECTION 4 - BOOM & PLATFORM

3. To remove a link, rivets holding links together must be removed. Use a right-angle pneumatic die grinder with a 1/4" ball double cut bur attachment.




4. insert tool into rolled over end of rivet. Grind out middle of rivet until rolled over part of rivet falls off. Repeat for all rivets to be removed.




5. After grinding it may be necessary to use a center punch with a hammer to remove rivet.

NOTE: It may be necessary to loosen fixed end brackets from machine to move track section enough to disconnect links.



6. Insert flat head screwdriver between links. Twist and pull links apart.



7. Remove link from other section of powertrack using screwdriver.





Install New Link


1. Squeeze cut-out end of new link into half-shear (female) end of track section.




2. Spread half-shear (female) end of new link and slide cut-out end of track section into it. Use screwdriver if necessary.




3. Round half-shears will not fit properly in cut-outs after new link is installed.



4. Pull moving end over track so new connection is positioned in curve of powertrack. Round half-shears will rotate into cut-outs.



5. Parts shown below connect new link to powertrack.



6. Push pin through center hole. Slide washer on pin.



7. Install snap ring in groove on pin. Repeat pin installation steps for all center holes with rivets removed.



SECTION 4 - BOOM & PLATFORM


NOTE: Make sure snap rings are seated in pin groove and closed properly.



1. Install new 8-32 x 0.500 self-threading Torx head screw in end of new aluminum round bar. Torque to 18-20 in-lb (2-2.25 Nm).



2. Pull up on other end of round bar. Slide new poly roller on bar.




3. Install new 8-32 x 0.500 self threading screw on other side. Torque to 18-20 in-lb (2-2.25 Nm).



NOTE: When tightening screws make sure screw head is seated against link with no space in between link and underside of screw head.



Replace Fixed End Brackets



NOTICE

REPOSITION CABLES/HOSES. KEEP COVERED DURING GRINDING TO PREVENT DAMAGE.

1. Remove rivets as shown in link removal instructions.



2. Parts used: Bracket Center Pin and Center Pin Snap Ring.




3. Take new bracket and install bracket center pin and snap ring. Repeat on other bracket if replacing it.



NOTE: Ensure snap rings are seated in pin groove and closed properly.




Replace Moving End Brackets




NOTICE

REPOSITION CABLES AND HOSES. KEEP COVERED DURING GRINDING TO PREVENT DAMAGE.


1. Remove existing pins and center rivet. Remove rivet as shown in link removal instructions on page 4-25. Repeat on other bracket if replaced.



2. Install center pin with snap ring in new bracket.



NOTE: Ensure snap rings are seated in pin groove and closed properly.



3. Install radius pins and snap rings in original locations. Repeat with other moving end if replaced.



4. Make sure both brackets rotate correctly.




4.22 SKYGUARD


Operation

SkyGuard provides enhanced control panel protection. When the SkyGuard sensor is activated, functions in use at the time of actuation will reverse or cutout. The SkyGuard Function Table provides more details on these functions.


Consult the following illustrations to determine which type of SkyGuard the machine is equipped with. Regardless of the type, SkyGuard function according to the SkyGuard Function Table does not change.



SkyGuard



SkyGuard SkyLine™



SkyGuard SkyEye™

⚠ WARNING

THE MACHINE OPERATOR IS REQUIRED TO PERFORM A DAILY FUNCTION TEST TO ENSURE PROPER OPERATION OF THE SKYGUARD SYSTEM.

Function Test

SKYGUARD ONLY

Perform this function test if **SkyGuard only** is selected in machine setup (refer to Table 6-2).

From the Platform Control Console in an area free from obstructions:

1. Operate the telescope out function, then activate SkyGuard sensor.
2. Once sensor has been activated, ensure telescope out function stops then telescope in function operates for a short duration. Additionally, verify Soft Touch/SkyGuard indicator light flashes and horn sounds. If machine is equipped with SkyGuard beacon, ensure it flashes when sensor activates.
3. With SkyGuard sensor still engaged, press and hold yellow Soft Touch/SkyGuard override button. Operate a function to verify operation can be resumed.
4. Disengage SkyGuard sensor, release controls, and recycle footswitch. Ensure normal operation available.

In Ground Mode:

Operation is allowed regardless of SkyGuard activation.

SOFT TOUCH ONLY

If **Soft Touch only** is selected in machine setup (refer to Table 6-2), machine will treat the Soft Touch/SkyGuard override switch as if it is a Soft Touch switch.

SKYGUARD NOT SELECTED IN MACHINE SETUP

If the SkyGuard system is installed on the machine, but no option is selected in the machine setup (refer to Table 6-2), SkyGuard sensor status will be ignored. No function cutout or reversal will be implemented.

Diagnostics & Troubleshooting

If SkyGuard does not function when the sensor is engaged, first verify the configuration under the MACHINE SETUP: SKYGUARD OPTION menu using the handheld Analyzer. Ensure the selected configuration matches the actual system installed on the machine. If not, select the correct configuration, then verify operation.

Additionally, use the handheld analyzer to navigate to the DIAGNOSTICS: FEATURES → SKYGUARD INPUTS menu to determine additional SkyGuard fault information.

Engage the SkyGuard sensor and observe the Analyzer to determine if the switch/relay closes.

If the status of the switch/relay remains OPEN while the SkyGuard sensor is actively engaged, it is possible the sensor has failed and should be replaced immediately.

If the status of the switch/relay remains CLOSED while the SkyGuard sensor is actively engaged, a power or ground wire may not be making good contact or may be loose or broken. Additionally, there is a low probability that both relays may have failed.

If the switch/relay status is in disagreement, then one may have failed or is not installed correctly. In this case, the machine will be inoperable.

FAULT CODES

Refer to Table 6-13 for more fault code information

- **0039** - SkyGuard switch activation fault
- **2563** - switch disagreement fault

Table 4-1. SkyGuard Function Table

| Drive Forward | Drive Reverse | Steer | Swing | Boom Lift Up | Boom Lift Down | Boom Tele Out | Boom Tele In | Jib Lift | Basket Level | Basket Rotate |
|---|---------------|-------|-------|--------------|----------------|---------------|--------------|----------|--------------|---------------|
| C | C | C | R | R | R | R | C | C | C | C |
| R= Indicates Reversal is Activated | | | | | | | | | | |
| C= Indicates Cutout is Activated | | | | | | | | | | |
| *DOS (Drive Orientation System) Enabled | | | | | | | | | | |
| **DOS Not Enabled, Machine is driving straight without steering, and any other hydraulic function is active | | | | | | | | | | |

SECTION 5. BASIC HYDRAULICS INFORMATION & SCHEMATICS

5.1 LUBRICATING O-RINGS IN THE HYDRAULIC SYSTEM

When assembling connectors in the hydraulic that use o-ring fittings, it is necessary to lubricate all fittings with hydraulic oil prior to assembly. To lubricate the fittings, use one of the following procedures.

NOTE: All O-ring fittings must be pre-lubricated with hydraulic oil prior to assembly.

Cup and Brush

The following is needed to correctly oil the o-ring in this manner:

- Small container for hydraulic oil
- Small paint brush



1. Hold the fitting in one hand while using the brush with the other hand to dip into the container. Remove excess hydraulic oil from the brush so an even film of oil is applied on the o-ring.



2. Holding the fitting over the hydraulic oil container, brush an even film of oil around the entire o-ring in the fitting, making sure the entire o-ring is completely saturated.



3. Turn the o-ring on the other side of the fitting and repeat the previous step, ensuring the entire o-ring is coated with hydraulic oil.



Dip Method

NOTE: This method works best with Face Seal o-rings, but will work for all o-ring fitting types.

The following is needed to correctly oil the o-ring in this manner:

- A small leak proof container
 - Sponge cut to fit inside container
 - A small amount of hydraulic oil to saturate sponge.
1. Place sponge inside container and add hydraulic oil to the sponge until fully saturated.
 2. Dip the fitting into the sponge using firm pressure. Upon lifting the fitting, a small droplet will form and drip from the bottom of the fitting. This should signify an even coating of oil on the fitting.



3. O-ring Boss type fittings will require more pressure in able to immerse more of the fitting into the saturated sponge. This will also cause more oil to be dispersed from the sponge.



Spray Method

This method requires a pump or trigger spray bottle.

1. Fill the spray bottle with hydraulic oil.
2. Hold the fitting over suitable catch can.
3. Spray entire o-ring surface with a medium coat of oil.



Brush-on Method

This method requires a sealed bottle brush.

1. Fill the bottle with hydraulic oil.
2. Using slight pressure to the body of the spray bottle, invert the bottle so the brush end is in the downward position.
3. Brush hydraulic oil on the entire o-ring, applying an even coat of oil.



5.2 HYDRAULIC CONNECTION ASSEMBLY AND TORQUE SPECIFICATION

Tapered Thread Types

NPTF = national tapered fuel (Dry Seal) per SAE J476/J512




Figure 5-1. NPTF Thread

BSPT = British standard pipe tapered per ISO7-1




Figure 5-2. BSPT Thread

Straight Thread Types, Tube and Hose Connections

JIC = 37° flare per SAE J514




Figure 5-3. JIC Thread

SAE = 45° flare per SAE J512




Figure 5-4. SAE Thread

ORFS = o-ring face seal per SAE J1453




Figure 5-5. ORFS Thread

MBTL = metric flareless bite type fitting, pressure rating L (medium) per ISO 8434, DIN 2353

MBTS = metric flareless bite type fitting, pressure rating S (high) per ISO 8434, DIN 2353




Figure 5-6. MTBL-MBTS Thread

BH = bulkhead connection – JIC, ORFS, MBTL, or MBTS types




Figure 5-7. Bulkhead Thread

Straight Thread Types, Port Connections

ORB = o-ring boss per SAE J1926, ISO 11926

MPP = metric pipe parallel o-ring boss per SAE J2244, ISO 6149, DIN 3852




Figure 5-8. ORB-MPP Thread

MFF = metric flat face port per ISO 9974-1

BSPP = British standard parallel pipe per ISO 1179-1, DIN 3852-2




Figure 5-9. MFF-BSPP Thread

Flange Connection Types

FL61 = code 61 flange per SAE J518, ISO 6162

FL62 = code 62 flange per SAE J518, ISO 6162




Figure 5-10. FL61-FL62

Tightening Methods

Torque = Application of a twisting force to the applicable connection by use of a precise measurement instrument (i.e. torque wrench).

Finger Tight = The point where the connector will no longer thread onto the mating part when tightened by hand or fingers. Finger Tight is relative to user strength and will have some variance. The average torque applied by this method is 3 ft-lbs [4 N-m]. Also referred to as 'Hand Tight.'

TFFT = Turns From Finger Tight; Application of a preload to a connection by first tightening the connection by hand (fingers) and applying an additional rotation counted by a defined number of turns by use of a tool.

FFWR = Flats from Wrench Resistance; Application of a preload to a connection by tightening to the point of initial wrench resistance and turning the nut a described number of 'flats'. A 'flat' is one side of the hexagonal tube nut and equates to 1/6 of a turn. Also referred to as the 'Flats Method.'

Assembly And Torque Specifications

Prior to selecting the appropriate torque from the tables within this section, it is necessary to properly identify the connector being installed. Refer to the Figures and Tables in this section.

GENERAL TUBE TYPE FITTING ASSEMBLY INSTRUCTIONS

1. Take precautions to ensure that fittings and mating components are not damaged during storage, handling or assembly. Nicks and scratches in sealing surfaces can create a path for leaks which could lead to component contamination and/or failure.
2. When making a connection to tubing, compression or flare, inspect the tube in the area of the fitting attachment to ensure that the tube has not been damaged.
3. The assembly process is one of the leading causes for contamination in air and hydraulic systems. Contamination can prevent proper tightening of fittings and adapters from occurring.
 - a. Avoid using dirty or oily rags when handling fittings.
 - b. If fittings are disassembled, they should be cleaned and inspected for damage. Replace fittings as necessary before re-installing.
 - c. Sealing compounds should be applied where specified; however, care should be taken not to introduce sealant into the system.
 - d. Avoid applying sealant to the area of the threads where the sealant will be forced into the system. This is generally the first two threads of a fitting.
 - e. Sealant should only be applied to the male threads.
 - f. Straight thread fittings do not require sealants. O-rings or washers are provided for sealing.
 - g. When replacing or installing an O-ring, care is to be taken while transferring the O-ring over the threads as it may become nicked or torn. When replacing an O-ring on a fitting, the use of a thread protector is recommended.
 - h. When installing fittings with O-rings, lubrication shall be used to prevent scuffing or tearing of the O-ring. See O-ring Installation (Replacement) in this section.
4. Take care to identify the material of parts to apply the correct torque values.
 - a. Verify the material designation in the table headings.
 - b. If specifications are given only for steel fittings and components, the values for alternate materials shall be as follows: Aluminum and Brass- reduce steel values by 35%; Stainless Steel - Use the upper limit for steel.
5. To achieve the specified torque, the torque wrench is to be held perpendicular to the axis of rotation.




Figure 5-11. Torque Wrench Angle

6. Refer to the appropriate section in this manual for more specific instructions and procedures for each type of fitting connection.

Assembly Instructions for American Standard Pipe Thread Tapered (NPTF) Connections.

1. Inspect components to ensure male and female port threads are free of rust, splits, dirt, foreign matter, or burrs.
2. Apply a suitable thread sealant, such as High Strength Threadlocking Compound, to the male pipe threads if not already applied. Ensure the first 1 to 2 threads are uncovered to prevent system contamination.
3. Assemble connection hand tight.
4. Mark fittings, male and female.

CAUTION

OVER TIGHTENING MAY CAUSE DEFORMATION OF THE PIPE FITTING AND DAMAGE TO THE JOINING FITTING, FLANGE OR COMPONENT MAY OCCUR.


NEVER BACK OFF (LOOSEN) PIPE THREADED CONNECTORS TO ACHIEVE ALIGNMENT. MEET THE MINIMUM REQUIRED TURNS AND USE THE LAST TURN FOR ALIGNMENT.

5. Rotate male fitting the number of turns per Table 5-1, NPTF Pipe Thread. See FFWR and TFFT Methods for TFFT procedure requirements.

NOTE: TFFT values provided in Table 5-1, NPTF Pipe Thread are applicable for the following material configurations:

- a. STEEL fittings with STEEL mating components.
- b. STEEL fittings with ALUMINUM or BRASS mating components.
- c. ALUMINUM or BRASS fittings with STEEL mating components.
- d. ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

Table 5-1. NPTF Pipe Thread



| TYPE/FITTING IDENTIFICATION | | | | | Turns From Finger Tight (TFFT)** |
|---|-----------|--------------|------|-------|----------------------------------|
| Material | Dash Size | Thread Size | ØA* | | |
| | | (UNF) | (in) | (mm) | |
| STEEL, ALUMINUM, OR BRASS FITTINGS WITH STEEL, ALUMINUM, OR BRASS MATING COMPONENTS | 2 | 1/8-27 | 0.40 | 10.24 | 2 to 3 |
| | 4 | 1/4-18 | 0.54 | 13.61 | 2 to 3 |
| | 6 | 3/8-18 | 0.67 | 17.05 | 2 to 3 |
| | 8 | 1/2-14 | 0.84 | 21.22 | 2 to 3 |
| | 12 | 3/4-14 | 1.05 | 26.56 | 2 to 3 |
| | 16 | 1-11 1/2 | 1.31 | 33.22 | 1.5 to 2.5 |
| | 20 | 1 1/4-11 1/2 | 1.65 | 41.98 | 1.5 to 2.5 |
| | 24 | 1 1/2-11 1/2 | 1.89 | 48.05 | 1.5 to 2.5 |
| | 32 | 2-11 1/2 | 2.37 | 60.09 | 1.5 to 2.5 |

* ØA thread dimension for reference only.
 ** See FFWR and TFFT Methods for TFFT procedure requirements.

Assembly Instructions for British Standard Pipe Thread Tapered (BSPT) Connections

1. Inspect components to ensure male and female port threads are free of rust, splits, dirt, foreign matter, or burrs.
2. Apply a suitable thread sealant, such as High Strength Threadlocking Compound, to the male pipe threads if not already applied. Ensure the first 1 to 2 threads are uncovered to prevent system contamination.
3. Assemble connection hand tight.
4. Mark fittings, male and female.

⚠ CAUTION

OVER TIGHTENING MAY CAUSE DEFORMATION OF THE PIPE FITTING AND DAMAGE TO THE JOINING FITTING, FLANGE OR COMPONENT MAY OCCUR.


NEVER BACK OFF (LOOSEN) PIPE THREADED CONNECTORS TO ACHIEVE ALIGNMENT. MEET THE MINIMUM REQUIRED TURNS AND USE THE LAST TURN FOR ALIGNMENT.

5. Rotate male fitting the number of turns per Table 5-2, BSPT Pipe Thread. See FFWR and TFFT Methods for TFFT procedure requirements.

NOTE: TFFT values provided in Table 5-2, BSPT Pipe Thread are applicable for the following material configurations:

- a. STEEL fittings with STEEL mating components.
- b. STEEL fittings with ALUMINUM or BRASS mating components.
- c. ALUMINUM or BRASS fittings with STEEL mating components.
- d. ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

Table 5-2. BSPT Pipe Thread



| TYPE/FITTING IDENTIFICATION | | | | | Turns From Finger Tight (TFFT)** |
|---|-----------|-------------|------|-------|----------------------------------|
| MATERIAL | Dash Size | Thread Size | ØA* | | |
| | | (BSPT) | (in) | (mm) | |
| STEEL, ALUMINUM, OR BRASS FITTINGS WITH STEEL, ALUMINUM, OR BRASS MATING COMPONENTS | 2 | 1/8-28 | 0.38 | 9.73 | 2 to 3 |
| | 4 | 1/4-19 | 0.52 | 13.16 | 2 to 3 |
| | 6 | 3/8-19 | 0.66 | 16.66 | 2 to 3 |
| | 8 | 1/2-14 | 0.83 | 20.96 | 2 to 3 |
| | 12 | 3/4-14 | 1.04 | 26.44 | 2 to 3 |
| | 16 | 1-11 | 1.31 | 33.25 | 1.5 to 2.5 |
| | 20 | 1 1/4-11 | 1.65 | 41.91 | 1.5 to 2.5 |
| | 24 | 1 1/2-11 | 1.88 | 47.80 | 1.5 to 2.5 |
| | 32 | 2-11 | 2.35 | 59.61 | 1.5 to 2.5 |

* ØA thread dimension for reference only.

** See FFWR and TFFT Methods for TFFT procedure requirements.

Assembly Instructions for 37° (JIC) Flare Fittings

1. Inspect the flare for obvious visual squareness and concentricity issues with the tube OD. Ensure surface is smooth, free of rust, weld and brazing splatter, splits, dirt, foreign matter, or burrs. If necessary replace fitting or adapter.

⚠ CAUTION

DO NOT FORCE A MISALIGNED OR SHORT HOSE/TUBE INTO ALIGNMENT. IT PUTS UNDESIRABLE STRAIN ONTO THE JOINT EVENTUALLY LEADING TO LEAKAGE.

2. Align tube to fitting and start threads by hand.

⚠ CAUTION

THE TORQUE METHOD SHOULD NOT BE USED ON LUBRICATED OR OILY FITTINGS. NO LUBRICATION OR SEALANT IS REQUIRED. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.


3. Torque assembly to value listed in Table 5-3, 37° Flare (JIC) Thread - Steel or Table 5-4, 37° Flare (JIC) Thread - Aluminum/Brass while using the Double Wrench Method per Double Wrench Method. Refer to FFWR and TFFT Methods for procedure requirements if using the FFWR method.

NOTE: *Torque values provided in Table 5-3, 37° Flare (JIC) Thread - Steel and Table 5-4, 37° Flare (JIC) Thread - Aluminum/Brass are segregated based on the material configuration of the connection.*

'ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- a. STEEL fittings with ALUMINUM or BRASS mating components.
- b. ALUMINUM or BRASS fittings with STEEL mating components.
- c. ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

Table 5-3. 37° Flare (JIC) Thread - Steel




| TYPE/FITTING IDENTIFICATION | | | | | | | Torque | | | | | | Flats from Wrench Resistance (F.F.W.R)** |
|---|-----------|-------------|-------|-------|-------|-------|---------|-----|-----|-------|-----|----------|--|
| MATERIAL | Dash Size | Thread Size | ØA* | | ØB* | | [Ft-Lb] | | | [N-m] | | | |
| | | | (UNF) | (in) | (mm) | (in) | (mm) | Min | Nom | Max | Min | Nom | |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.28 | 7.00 | 0.31 | 7.75 | 6 | 7 | 7 | 8 | 9 | 10 | -- |
| | 3 | 3/8-24 | 0.34 | 8.60 | 0.37 | 9.50 | 8 | 9 | 10 | 11 | 12 | 14 | -- |
| | 4 | 7/16-20 | 0.39 | 10.00 | 0.44 | 11.10 | 13 | 14 | 14 | 18 | 19 | 19 | 1-1/2 to 1-3/4 |
| | 5 | 1/2-20 | 0.46 | 11.60 | 0.50 | 12.70 | 14 | 15 | 15 | 19 | 20 | 21 | 1 to 1-1/2 |
| | 6 | 9/16-18 | 0.51 | 13.00 | 0.56 | 14.30 | 22 | 23 | 24 | 30 | 31 | 33 | 1 to 1-1/2 |
| | 8 | 3/4-16 | 0.69 | 17.60 | 0.75 | 19.10 | 42 | 44 | 46 | 57 | 60 | 63 | 1-1/2 to 1-3/4 |
| | 10 | 7/8-14 | 0.81 | 20.50 | 0.87 | 22.20 | 60 | 63 | 66 | 81 | 85 | 89 | 1 to 1-1/2 |
| | 12 | 1 1/16-12 | 0.97 | 24.60 | 1.06 | 27.00 | 84 | 88 | 92 | 114 | 120 | 125 | 1 to 1-1/2 |
| | 14 | 1 3/16-12 | 1.11 | 28.30 | 1.19 | 30.10 | 100 | 105 | 110 | 136 | 142 | 149 | 1 to 1-1/2 |
| | 16 | 1 5/16-12 | 1.23 | 31.30 | 1.31 | 33.30 | 118 | 124 | 130 | 160 | 168 | 176 | 3/4 to 1 |
| | 20 | 1 5/8-12 | 1.54 | 39.20 | 1.63 | 41.30 | 168 | 176 | 185 | 228 | 239 | 251 | 3/4 to 1 |
| | 24 | 1 7/8-12 | 1.80 | 45.60 | 1.87 | 47.60 | 195 | 205 | 215 | 264 | 278 | 291 | 3/4 to 1 |
| 32 | 2 1/2-12 | 2.42 | 61.50 | 2.50 | 63.50 | 265 | 278 | 292 | 359 | 377 | 395 | 3/4 to 1 | |

* ØA and ØB thread dimensions for reference only.

** See FFWR and TFFT Methods for FFWR procedure requirements.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-4. 37° Flare (JIC) Thread - Aluminum/Brass



| TYPE/FITTING IDENTIFICATION | | | | | | | Torque | | | | | | Flats from Wrench Resistance (F.F.W.R)** |
|--|-----------|----------------------|-------|-------|-------|-------|---------|-----|-----|-------|-----|----------|--|
| MATERIAL | Dash Size | Thread Size (UNF) | ØA* | | ØB* | | [Ft-Lb] | | | [N-m] | | | |
| | | | (in) | (mm) | (in) | (mm) | Min | Nom | Max | Min | Nom | Max | |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.28 | 7.00 | 0.31 | 7.75 | 4 | 4 | 5 | 5 | 6 | 7 | -- |
| | 3 | 3/8-24 | 0.34 | 8.60 | 0.37 | 9.50 | 5 | 6 | 7 | 7 | 8 | 9 | -- |
| | 4 | 7/16-20 | 0.39 | 10.00 | 0.44 | 11.10 | 8 | 9 | 9 | 11 | 12 | 13 | 1-1/2 to 1-3/4 |
| | 5 | 1/2-20 | 0.46 | 11.60 | 0.50 | 12.70 | 9 | 10 | 10 | 12 | 13 | 14 | 1 to 1-1/2 |
| | 6 | 9/16-18 | 0.51 | 13.00 | 0.56 | 14.30 | 14 | 15 | 16 | 19 | 20 | 21 | 1 to 1-1/2 |
| | 8 | 3/4-16 | 0.69 | 17.60 | 0.75 | 19.10 | 27 | 29 | 30 | 37 | 39 | 41 | 1-1/2 to 1-3/4 |
| | 10 | 7/8-14 | 0.81 | 20.50 | 0.87 | 22.20 | 39 | 41 | 43 | 53 | 56 | 58 | 1 to 1-1/2 |
| | 12 | 11/16-12 | 0.97 | 24.60 | 1.06 | 27.00 | 55 | 57 | 60 | 74 | 78 | 81 | 1 to 1-1/2 |
| | 14 | 13/16-12 | 1.11 | 28.30 | 1.19 | 30.10 | 65 | 68 | 72 | 88 | 93 | 97 | 1 to 1-1/2 |
| | 16 | 15/16-12 | 1.23 | 31.30 | 1.31 | 33.30 | 77 | 81 | 84 | 104 | 109 | 114 | 3/4 to 1 |
| | 20 | 15/8-12 | 1.54 | 39.20 | 1.63 | 41.30 | 109 | 115 | 120 | 148 | 155 | 163 | 3/4 to 1 |
| | 24 | 17/8-12 | 1.80 | 45.60 | 1.87 | 47.60 | 127 | 133 | 139 | 172 | 180 | 189 | 3/4 to 1 |
| 32 | 21/2-12 | 2.42 | 61.50 | 2.50 | 63.50 | 172 | 181 | 189 | 234 | 245 | 257 | 3/4 to 1 | |

* ØA and ØB thread dimensions for reference only.

** See FFWR and TFFT Methods for FFWR procedure requirements.

Assembly Instructions for 45° SAE Flare Fittings

1. Inspect the flare for obvious visual squareness and concentricity issues with the tube OD. Ensure surface is smooth, free of rust, weld and brazing splatter, splits, dirt, foreign matter, or burrs. If necessary replace fitting or adapter.

⚠ CAUTION

DO NOT FORCE A MISALIGNED OR SHORT HOSE/TUBE INTO ALIGNMENT. IT PUTS UNDESIRABLE STRAIN ONTO THE JOINT EVENTUALLY LEADING TO LEAKAGE.

2. Align tube to fitting.
3. Tighten fitting by hand until hand tight.

⚠ CAUTION

THE TORQUE METHOD SHOULD NOT BE USED ON LUBRICATED OR OILY FITTINGS. NO LUBRICATION OR SEALANT IS REQUIRED. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.


4. Torque fitting to value listed in Table 5-5, 45° Flare (SAE) - Steel and Table 5-6, 45° Flare (SAE) - Aluminum/Brass while using the Double Wrench Method outlined in this section. Refer to FFWR and TFFT Methods for procedure requirements if using the TFFT method.

NOTE: *Torque values provided in Table 5-5, 45° Flare (SAE) - Steel and Table 5-6, 45° Flare (SAE) - Aluminum/Brass are segregated based on the material configuration of the connection.*

'ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- a. STEEL fittings with ALUMINUM or BRASS mating components.
- b. ALUMINUM or BRASS fittings with STEEL mating components.
- c. ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.


Table 5-5. 45° Flare (SAE) - Steel



| TYPE/FITTING IDENTIFICATION | | | | | | | Torque | | | | | | Turns From Finger Tight (TFFT)** |
|--|-----------|-------------|------|-------|------|-------|---------|-----|-----|-------|-----|-----|----------------------------------|
| MATERIAL | Dash Size | Thread Size | ØA* | | ØB* | | [Ft-Lb] | | | [N-m] | | | |
| | | (UNF) | (in) | (mm) | (in) | (mm) | Min | Nom | Max | Min | Nom | Max | |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | 4 | 7/16-20 | 0.39 | 9.90 | 0.44 | 11.10 | 13 | 14 | 14 | 18 | 19 | 19 | 1/4 to 1/2 |
| | 6 | 5/8-18 | 0.56 | 14.30 | 0.63 | 15.90 | 22 | 23 | 24 | 30 | 31 | 33 | 1/4 to 1/2 |
| | 8 | 3/4-16 | 0.69 | 17.50 | 0.75 | 19.10 | 42 | 44 | 46 | 57 | 60 | 62 | 1/4 to 1/2 |
| | 10 | 7/8-14 | 0.81 | 20.60 | 0.87 | 22.20 | 60 | 63 | 66 | 81 | 85 | 89 | 1/4 to 1/2 |
| | 12 | 1 1/16-14 | 0.98 | 25.00 | 1.06 | 27.00 | 84 | 88 | 92 | 114 | 119 | 125 | 1/4 to 1/2 |

* ØA and ØB thread dimensions for reference only.
 ** See FFWR and TFFT Methods for TFFT procedure requirements.

Table 5-6. 45° Flare (SAE) - Aluminum/Brass



| TYPE/FITTING IDENTIFICATION | | | | | | | Torque | | | | | | Turns From Finger Tight (TFFT)** |
|--|-----------|-------------|------|-------|------|-------|---------|-----|-----|-------|-----|-----|----------------------------------|
| MATERIAL | Dash Size | Thread Size | ØA* | | ØB* | | [Ft-Lb] | | | [N-m] | | | |
| | | (UNF) | (in) | (mm) | (in) | (mm) | Min | Nom | Max | Min | Nom | Max | |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | 4 | 7/16-20 | 0.39 | 9.90 | 0.44 | 11.10 | 8 | 9 | 9 | 11 | 12 | 12 | 1/4 to 1/2 |
| | 6 | 5/8-18 | 0.56 | 14.30 | 0.63 | 15.90 | 14 | 15 | 15 | 19 | 20 | 20 | 1/4 to 1/2 |
| | 8 | 3/4-16 | 0.69 | 17.50 | 0.75 | 19.10 | 27 | 29 | 30 | 37 | 39 | 41 | 1/4 to 1/2 |
| | 10 | 7/8-14 | 0.81 | 20.60 | 0.87 | 22.20 | 39 | 41 | 43 | 53 | 56 | 58 | 1/4 to 1/2 |
| | 12 | 1 1/16-14 | 0.98 | 25.00 | 1.06 | 27.00 | 55 | 58 | 61 | 75 | 79 | 83 | 1/4 to 1/2 |

* ØA and ØB thread dimensions for reference only.
 ** See FFWR and TFFT Methods for TFFT procedure requirements.

Assembly Instructions for O-Ring Face Seal (ORFS) Fittings

1. Ensure proper O-ring is installed. If O-ring is missing install per O-ring Installation (Replacement).
2. Ensure surface is smooth, free of rust, weld and brazing splatter, splits, dirt, foreign matter, or burrs. If necessary replace fitting or adapter.

CAUTION

CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. Place the tube assembly against the fitting body so that the flat face comes in contact with the O-ring. Hand thread the nut onto the fitting body.


5. Torque nut to value listed in Table 5-7, O-ring Face Seal (ORFS) - Steel or Table 5-8, O-ring Face Seal (ORFS) - Aluminum/Brass while using the Double Wrench Method. Refer to FFWR and TFFT Methods for procedure requirements if using the FFWR method.

NOTE: Torque values provided in Table 5-7, O-ring Face Seal (ORFS) - Steel and Table 5-8, O-ring Face Seal (ORFS) - Aluminum/Brass are segregated based on the material configuration of the connection.

'ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- a. STEEL fittings with ALUMINUM or BRASS mating components.
- b. ALUMINUM or BRASS fittings with STEEL mating components.
- c. ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

Table 5-7. O-ring Face Seal (ORFS) - Steel




| TYPE/FITTING IDENTIFICATION | | | | | | | Torque | | | | | | Flats from Wrench Resistance (F.F.W.R)** | |
|--|-----------|-------------|-------|-------|-------|-------|---------|-----|-----|-------|-----|------------|--|--------------------|
| MATERIAL | Dash Size | Thread Size | ØA* | | ØB* | | [Ft-Lb] | | | [N-m] | | | Tube Nuts | Swivel & Hose Ends |
| | | (UNF) | (in) | (mm) | (in) | (mm) | Min | Nom | Max | Min | Nom | Max | | |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | 4 | 9/16-18 | 0.51 | 13.00 | 0.56 | 14.20 | 18 | 19 | 20 | 25 | 26 | 27 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 6 | 11/16-16 | 0.63 | 15.90 | 0.69 | 17.50 | 30 | 32 | 33 | 40 | 43 | 45 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 8 | 13/16-16 | 0.75 | 19.10 | 0.81 | 20.60 | 40 | 42 | 44 | 55 | 57 | 60 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 10 | 1-14 | 0.94 | 23.80 | 1.00 | 25.40 | 60 | 63 | 66 | 81 | 85 | 89 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 12 | 13/16-12 | 1.11 | 28.20 | 1.19 | 30.10 | 85 | 90 | 94 | 115 | 122 | 127 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 16 | 17/16-12 | 1.34 | 34.15 | 1.44 | 36.50 | 110 | 116 | 121 | 149 | 157 | 164 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 20 | 111/16-12 | 1.59 | 40.50 | 1.69 | 42.90 | 150 | 158 | 165 | 203 | 214 | 224 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 24 | 2-12 | 1.92 | 48.80 | 2.00 | 50.80 | 230 | 242 | 253 | 312 | 328 | 343 | 1/4 to 1/2 | 1/2 to 3/4 |
| 32 | 21/2-12 | 2.43 | 61.67 | 2.50 | 63.50 | 375 | 394 | 413 | 508 | 534 | 560 | 1/4 to 1/2 | 1/2 to 3/4 | |

* ØA and ØB thread dimensions for reference only.

** See FFWR and TFFT Methods for FFWR procedure requirements.

Table 5-8. O-ring Face Seal (ORFS) - Aluminum/Brass



| TYPE/FITTING IDENTIFICATION | | | | | | | Torque | | | | | | Flats from Wrench Resistance (F.F.W.R)** | |
|--|-----------|-------------------|------|-------|------|-------|---------|-----|-----|-------|-----|-----|--|--------------------|
| MATERIAL | Dash Size | Thread Size (UNF) | ØA* | | ØB* | | [Ft-Lb] | | | [N-m] | | | Tube Nuts | Swivel & Hose Ends |
| | | | (in) | (mm) | (in) | (mm) | Min | Nom | Max | Min | Nom | Max | | |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | 4 | 9/16-18 | 0.51 | 13.00 | 0.56 | 14.20 | 12 | 13 | 13 | 16 | 18 | 18 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 6 | 11/16-16 | 0.63 | 15.90 | 0.69 | 17.50 | 20 | 21 | 22 | 27 | 28 | 30 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 8 | 13/16-16 | 0.75 | 19.10 | 0.81 | 20.60 | 26 | 28 | 29 | 35 | 38 | 39 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 10 | 1-14 | 0.94 | 23.80 | 1.00 | 25.40 | 39 | 41 | 43 | 53 | 56 | 58 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 12 | 13/16-12 | 1.11 | 28.20 | 1.19 | 30.10 | 55 | 58 | 61 | 75 | 79 | 83 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 16 | 17/16-12 | 1.34 | 34.15 | 1.44 | 36.50 | 72 | 76 | 79 | 98 | 103 | 107 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 20 | 1 11/16-12 | 1.59 | 40.50 | 1.69 | 42.90 | 98 | 103 | 108 | 133 | 140 | 146 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 24 | 2-12 | 1.92 | 48.80 | 2.00 | 50.80 | 12 | 13 | 13 | 16 | 18 | 18 | 1/4 to 1/2 | 1/2 to 3/4 |
| | 32 | 2 1/2-12 | 2.43 | 61.67 | 2.50 | 63.50 | 20 | 21 | 22 | 27 | 28 | 30 | 1/4 to 1/2 | 1/2 to 3/4 |

* ØA and ØB thread dimensions for reference only.

** See FFWR and TFFT Methods for FFWR procedure requirements.

Assembly Instructions for DIN 24° Flare Bite Type Fittings (MBTL and MBTS)

⚠ CAUTION

A NON-SQUARE TUBE END CAN CAUSE IMPROPERLY SEATED FITTINGS AND LEAKAGE.

1. Inspect the components to ensure free of contamination, external damage, rust, splits, dirt, foreign matter, or burrs. Ensure tube end is visibly square. If necessary replace fitting or tube.
2. Lubricate thread and cone of fitting body or hardened pre-assembly tool, as well as the progressive ring and nut threads.
3. Slip nut and progressive ring over tube, assuring that they are in the proper orientation.
4. Push the tube end into the coupling body.
5. Slide collet into position and tighten until finger tight. Mark nut and tube in the finger-tight position. Tighten nut to the number of flats listed in Table 5-9, DIN 24° Cone (MBTL & MBTS) while using the Double Wrench Method. The tube must not turn with the nut.

Go to Discount-Equipment.com to order your parts

Table 5-9. DIN 24° Cone (MBTL & MBTS)

| TYPE/FITTING IDENTIFICATION | | | | | | | | DIN 24° CONE FLARELESS BITE FITTING (With or Without O-Ring) | | | | | | | |
|---|--|--|---------------|---------------|-------|-------------|-------------|---|---|-----|-------|-------|-----|--|--|
| MATERIAL | TYPE | Tube O.D. | Thread M Size | ØA* | ØB* | C* | ØD* | Torque | | | | | | Flats from Wrench Resistance (F.F.W.R)** | |
| | | (mm) | (Metric) | (mm) | (mm) | (mm) | (mm) | [Ft-Lb] | | | [N-m] | | | | |
| | | | | | | | | Min | Nom | Max | Min | Nom | Max | | |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS | DIN 24° CONE FLARELESS BITE (MBTL) FITTING | 6 | M12x1.5 | 10.50 | 12.00 | 7.00 | 6.20 | FFWR is the recommended method of fitting assembly. Torque values are application specific due to variability in the fitting supplier, coating, lubrication, and other physical characteristics of the connection. Refer to the specific procedure in the | | | | | | 1.5 to 1.75 | |
| | | 8 | M14x1.5 | 12.50 | 14.00 | 7.00 | 8.20 | | | | | | | 1.5 to 1.75 | |
| | | 10 | M16x1.5 | 14.50 | 16.00 | 7.00 | 10.20 | | | | | | | 1.5 to 1.75 | |
| | | 12 | M18x1.5 | 16.50 | 18.00 | 7.00 | 12.20 | | | | | | | 1.5 to 1.75 | |
| | | 15 | M22x1.5 | 20.50 | 22.00 | 7.00 | 15.20 | | | | | | | 1.5 to 1.75 | |
| | | 18 | M26x1.5 | 24.50 | 26.00 | 7.50 | 18.20 | | | | | | | 1.5 to 1.75 | |
| | | 22 | M30x2 | 27.90 | 30.00 | 7.50 | 22.20 | | | | | | | 1.5 to 1.75 | |
| | | 28 | M36x2 | 33.90 | 36.00 | 7.50 | 28.20 | | | | | | | 1.5 to 1.75 | |
| | | 35 | M45x2 | 42.90 | 45.00 | 10.50 | 35.30 | | | | | | | 1.5 to 1.75 | |
| | | 42 | M52x2 | 49.90 | 52.00 | 11.00 | 42.30 | | | | | | | 1.5 to 1.75 | |
| | DIN 24° CONE FLARELESS BITE (MBTS) FITTING | TYPE | Tube O.D. | Thread M Size | ØA* | ØB* | C* | ØD* | Torque | | | | | | Flats from Wrench Resistance (F.F.W.R)** |
| | | | (mm) | (Metric) | (mm) | (mm) | (mm) | (mm) | [Ft-Lb] | | | [N-m] | | | |
| | | | | | | | | | Min | Nom | Max | Min | Nom | Max | |
| | | DIN 24° CONE FLARELESS BITE (MBTS) FITTING | 6 | M14x1.5 | 12.50 | 14.00 | 7.00 | 6.20 | FFWR is the recommended method of fitting assembly. Torque values are application specific due to variability in the fitting supplier, coating, lubrication, and other physical characteristics of the connection. Refer to the specific procedure in the | | | | | | 1.5 to 1.75 |
| | | | 8 | M16x1.5 | 14.50 | 16.00 | 7.00 | 8.20 | | | | | | | 1.5 to 1.75 |
| | | | 10 | M18x1.5 | 16.50 | 18.00 | 7.50 | 10.20 | | | | | | | 1.5 to 1.75 |
| | | | 12 | M20x1.5 | 18.50 | 20.00 | 7.50 | 12.20 | | | | | | | 1.5 to 1.75 |
| | | | 14 | M22x1.5 | 20.50 | 22.00 | 8.00 | 14.20 | | | | | | | 1.5 to 1.75 |
| | | | 16 | M24x1.5 | 22.50 | 24.00 | 8.50 | 16.20 | | | | | | | 1.5 to 1.75 |
| | | | 20 | M30x2 | 27.90 | 30.00 | 10.50 | 20.20 | | | | | | | 1.5 to 1.75 |
| 25 | M36x2 | | 33.90 | 36.00 | 12.00 | 25.20 | 1.5 to 1.75 | | | | | | | | |
| 30 | M42x2 | 39.90 | 42.00 | 13.50 | 30.20 | 1.5 to 1.75 | | | | | | | | | |
| 38 | M52x2 | 49.90 | 52.00 | 16.00 | 38.30 | 1.5 to 1.75 | | | | | | | | | |

* ØA, ØB, C, & ØD thread dimensions for reference only.


** See FFWR and TFFT Methods for FFWR procedure requirements.

Assembly Instructions for Bulkhead (BH) Fittings

1. Ensure threads and surface are free of rust, weld and brazing splatter, splits, burrs or other foreign material. If necessary replace fitting or adapter.
2. Remove the locknut from the bulkhead assembly.
3. Insert the bulkhead side of the fitting into the panel or bulkhead bracket opening.
4. Hand thread the locknut onto the bulkhead end of the fitting body.
5. Torque nut onto fitting per Table 5-10, Bulkhead Fittings (BH) - INCH and Table 5-11, Bulkhead Fittings (BH) - METRIC while using the Double Wrench Method.

Go to Discount-Equipment.com to order your parts


Table 5-10. Bulkhead Fittings (BH) - INCH



| TYPE/FITTING IDENTIFICATION | | | | FASTENING JAM NUT for Bulkhead Connectors | | | | | | |
|-----------------------------|--|-----------|-------------|--|---------|-----|-------|-------|-----|--|
| MATERIAL | TYPE | Dash Size | Thread Size | Torque | | | | | | |
| | | | | [Ft-Lb] | | | [N-m] | | | |
| | | | (UNF) | Min | Nom | Max | Min | Nom | Max | |
| STEEL FITTINGS | O-RING FACE SEAL (ORFS) BULKHEAD FITTING | 4 | 9/16-18 | 15 | 16 | 17 | 20 | 22 | 23 | |
| | | 6 | 11/16-16 | 25 | 27 | 28 | 34 | 37 | 38 | |
| | | 8 | 13/16-16 | 55 | 58 | 61 | 75 | 79 | 83 | |
| | | 10 | 1-14 | 85 | 90 | 94 | 115 | 122 | 127 | |
| | | 12 | 13/16-12 | 135 | 142 | 149 | 183 | 193 | 202 | |
| | | 14 | 15/16-12 | 170 | 179 | 187 | 230 | 243 | 254 | |
| | | 16 | 17/16-12 | 200 | 210 | 220 | 271 | 285 | 298 | |
| | | 20 | 111/16-12 | 245 | 258 | 270 | 332 | 350 | 366 | |
| | 24 | 2-12 | 270 | 284 | 297 | 366 | 385 | 403 | | |
| | 37° FLARE (JIC) BULKHEAD FITTING | TYPE | Dash Size | Thread Size | Torque | | | | | |
| | | | | | [Ft-Lb] | | | [N-m] | | |
| | | (UNF) | Min | Nom | Max | Min | Nom | Max | | |
| | | 3 | 3/8-24 | 8 | 9 | 9 | 11 | 12 | 12 | |
| | | 4 | 7/16-20 | 13 | 14 | 14 | 18 | 19 | 19 | |
| | | 5 | 1/2-20 | 20 | 21 | 22 | 27 | 28 | 30 | |
| | | 6 | 9/16-18 | 25 | 27 | 28 | 34 | 37 | 38 | |
| | | 8 | 3/4-16 | 50 | 53 | 55 | 68 | 72 | 75 | |
| | | 10 | 7/8-14 | 85 | 90 | 94 | 115 | 122 | 127 | |
| | | 12 | 11/16-12 | 135 | 142 | 149 | 183 | 193 | 202 | |
| | | 14 | 13/16-12 | 170 | 179 | 187 | 230 | 243 | 254 | |
| | | 16 | 15/16-12 | 200 | 210 | 220 | 271 | 285 | 298 | |
| | | 20 | 15/8-12 | 245 | 258 | 270 | 332 | 350 | 366 | |
| 24 | | 17/8-12 | 270 | 284 | 297 | 366 | 385 | 403 | | |
| 32 | 2 1/2-12 | 310 | 326 | 341 | 420 | 442 | 462 | | | |

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-11. Bulkhead Fittings (BH) - METRIC



| TYPE/FITTING IDENTIFICATION | | | | FASTENING JAM NUT for Bulkhead Connectors | | | | | |
|-----------------------------|--|-------------------------|---------------|--|-----|-----|-------|-----|-----|
| MATERIAL | TYPE | Connecting Tube O.D. | Thread M Size | Torque | | | | | |
| | | | | [Ft-Lb] | | | [N-m] | | |
| | | (mm) | (metric) | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS | DIN 24° CONE FLARELESS BITE (MBTL) BULKHEAD FITTING | 6 | M12x1.5 | 14 | 15 | 16 | 19 | 20 | 22 |
| | | 8 | M14x1.5 | 17 | 18 | 19 | 23 | 24 | 26 |
| | | 10 | M16x1.5 | 22 | 23 | 24 | 30 | 31 | 33 |
| | | 12 | M18x1.5 | 35 | 37 | 39 | 47 | 50 | 53 |
| | | 15 | M22x1.5 | 44 | 47 | 50 | 60 | 64 | 68 |
| | | 18 | M26x1.5 | 70 | 75 | 80 | 95 | 102 | 108 |
| | | 22 | M30x2 | 115 | 120 | 125 | 156 | 163 | 169 |
| | | 28 | M36x2 | 150 | 157 | 164 | 203 | 213 | 222 |
| | | 35 | M45x2 | 155 | 162 | 169 | 210 | 220 | 229 |
| | | 42 | M52x2 | 220 | 230 | 240 | 298 | 312 | 325 |
| | DIN 24° CONE FLARELESS BITE (MBTS) BULKHEAD FITTING | Connecting Tube O.D. | Thread M Size | Torque | | | | | |
| | | (mm) | (metric) | [Ft-Lb] | | | [N-m] | | |
| | | | | Min | Nom | Max | Min | Nom | Max |
| | | 6 | M14x1.5 | 17 | 15 | 16 | 23 | 20 | 22 |
| | | 8 | M16x1.5 | 22 | 18 | 19 | 30 | 24 | 26 |
| | | 10 | M18x1.5 | 35 | 23 | 24 | 47 | 31 | 33 |
| | | 12 | M20x1.5 | 40 | 35 | 37 | 54 | 47 | 50 |
| | | 14 | M22x1.5 | 44 | 47 | 50 | 60 | 64 | 68 |
| | | 16 | M24x1.5 | 70 | 75 | 80 | 95 | 102 | 108 |
| | | 20 | M30x2 | 115 | 120 | 125 | 156 | 163 | 169 |
| 25 | M36x2 | 150 | 157 | 164 | 203 | 213 | 222 | | |
| 30 | M42x2 | 155 | 162 | 169 | 210 | 220 | 229 | | |
| 38 | M52x2 | 220 | 230 | 240 | 298 | 312 | 325 | | |

Assembly Instructions for O-Ring Boss (ORB) Fittings

1. Inspect components to ensure that male and female port threads are free of rust, splits, dirt, foreign matter, or burrs.
2. Ensure proper O-ring is installed. If O-ring is missing install per O-ring Installation (Replacement).

CAUTION

CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. For Non-Adjustable and Plugs, thread the fitting by hand until contact.
5. For Adjustable fittings, refer to Adjustable Stud End Assembly for proper assembly.

6. Torque the fitting or nut to value listed in Table 5-12 thru Tables 5-17, O-RING BOSS (ORB) while using the Double Wrench Method.

NOTE: *The table headings identify the straight thread O-ring port and the type on the other side of the fitting. The torque will be applied to the straight thread O-ring port.*


NOTE: *Torque values provided in Table 5-12 thru Table 5-17, O-RING BOSS (ORB) are segregated based on the material configuration of the connection.*

'ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- a. STEEL fittings with ALUMINUM or BRASS mating components.
- b. ALUMINUM or BRASS fittings with STEEL mating components.
- c. ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

7. Inspect to ensure the O-ring is not pinched and the washer is seated flat on the counterbore of the port.

Table 5-12. O-ring Boss (ORB) - Table 1 of 6




| TYPE/FITTING IDENTIFICATION | | | | | HEX TYPE PLUGS & STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | |
|--|-----------|-------------|-------|-------|--|-------|-------|-------|-----|-----|
| MATERIAL | Dash Size | Thread Size | ØA* | | Torque | | | | | |
| | | | | | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | (UNF) | (in) | (mm) | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | (85) | (90) | (94) | 10 | 10 | 11 |
| | 3 | 3/8-24 | 0.37 | 9.52 | (155) | (163) | (171) | 18 | 18 | 19 |
| | 4 | 7/16-20 | 0.44 | 11.11 | 22 | 23 | 24 | 29 | 31 | 33 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 23 | 25 | 26 | 32 | 34 | 35 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 29 | 31 | 32 | 40 | 42 | 43 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 52 | 55 | 57 | 70 | 75 | 77 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 85 | 90 | 94 | 115 | 122 | 127 |
| | 12 | 1 1/16-12 | 1.06 | 27.00 | 135 | 142 | 149 | 185 | 193 | 202 |
| | 14 | 1 3/16-12 | 1.19 | 30.10 | 175 | 184 | 193 | 235 | 249 | 262 |
| | 16 | 1 5/16-12 | 1.31 | 33.30 | 200 | 210 | 220 | 270 | 285 | 298 |
| | 20 | 1 5/8-12 | 1.63 | 41.30 | 250 | 263 | 275 | 340 | 357 | 373 |
| | 24 | 1 7/8-12 | 1.87 | 47.60 | 305 | 321 | 336 | 415 | 435 | 456 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 375 | 394 | 413 | 510 | 534 | 560 | |
| TYPE/FITTING IDENTIFICATION | | | | | HEX TYPE PLUGS & STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | |
| MATERIAL | Dash Size | Thread Size | ØA* | | Torque | | | | | |
| | | | | | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | (UNF) | (in) | (mm) | Min | Nom | Max | Min | Nom | Max |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | (55) | (58) | (61) | 6 | 7 | 7 |
| | 3 | 3/8-24 | 0.37 | 9.52 | (101) | (106) | (111) | 11 | 12 | 13 |
| | 4 | 7/16-20 | 0.44 | 11.11 | 14 | 15 | 16 | 19 | 20 | 22 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 15 | 16 | 17 | 20 | 22 | 23 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 19 | 20 | 21 | 26 | 27 | 28 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 34 | 36 | 37 | 46 | 49 | 50 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 55 | 58 | 61 | 75 | 79 | 83 |
| | 12 | 1 1/16-12 | 1.06 | 27.00 | 88 | 93 | 97 | 119 | 126 | 132 |
| | 14 | 1 3/16-12 | 1.19 | 30.10 | 114 | 120 | 126 | 155 | 163 | 171 |
| | 16 | 1 5/16-12 | 1.31 | 33.30 | 130 | 137 | 143 | 176 | 186 | 194 |
| | 20 | 1 5/8-12 | 1.63 | 41.30 | 163 | 171 | 179 | 221 | 232 | 243 |
| | 24 | 1 7/8-12 | 1.87 | 47.60 | 198 | 208 | 218 | 268 | 282 | 296 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 244 | 256 | 268 | 331 | 347 | 363 | |

* ØA Thread OD dimension for reference only.

***Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-13. O-ring Boss (ORB) - Table 2 of 6




| TYPE/FITTING IDENTIFICATION | | | | | STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end | | | | | |
|--|-----------|-------------|-------|-------|--|------|------|-------|-----|-----|
| MATERIAL | Dash Size | Thread Size | ØA* | | Torque | | | | | |
| | | | | | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | | | (UNF) | (in) | (mm) | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | -- | -- | -- | -- | -- | -- |
| | 3 | 3/8-24 | 0.37 | 9.52 | -- | -- | -- | -- | -- | -- |
| | 4 | 7/16-20 | 0.44 | 11.11 | 26 | 27 | 28 | 35 | 37 | 38 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 30 | 32 | 33 | 40 | 43 | 45 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 35 | 37 | 39 | 46 | 50 | 53 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 60 | 63 | 66 | 80 | 85 | 89 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 100 | 105 | 110 | 135 | 142 | 149 |
| | 12 | 1 1/16-12 | 1.06 | 27.00 | 135 | 142 | 149 | 185 | 193 | 202 |
| | 14 | 1 3/16-12 | 1.19 | 30.10 | 175 | 184 | 193 | 235 | 249 | 262 |
| | 16 | 1 5/16-12 | 1.31 | 33.30 | 200 | 210 | 220 | 270 | 285 | 298 |
| | 20 | 1 5/8-12 | 1.63 | 41.30 | 250 | 263 | 275 | 340 | 357 | 373 |
| | 24 | 1 7/8-12 | 1.87 | 47.60 | 305 | 321 | 336 | 415 | 435 | 456 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 375 | 394 | 413 | 510 | 534 | 560 | |
| TYPE/FITTING IDENTIFICATION | | | | | STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end | | | | | |
| MATERIAL | Dash Size | Thread Size | ØA* | | Torque | | | | | |
| | | | | | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | | | (UNF) | (in) | (mm) | Min | Nom | Max |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | -- | -- | -- | -- | -- | -- |
| | 3 | 3/8-24 | 0.37 | 9.52 | -- | -- | -- | -- | -- | -- |
| | 4 | 7/16-20 | 0.44 | 11.11 | 17 | 18 | 18 | 23 | 24 | 24 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 20 | 21 | 21 | 27 | 28 | 28 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 23 | 24 | 24 | 31 | 33 | 33 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 39 | 41 | 43 | 53 | 56 | 58 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 65 | 69 | 72 | 88 | 94 | 98 |
| | 12 | 1 1/16-12 | 1.06 | 27.00 | 88 | 93 | 97 | 119 | 126 | 132 |
| | 14 | 1 3/16-12 | 1.19 | 30.10 | 114 | 120 | 126 | 155 | 163 | 171 |
| | 16 | 1 5/16-12 | 1.31 | 33.30 | 130 | 137 | 143 | 176 | 186 | 194 |
| | 20 | 1 5/8-12 | 1.63 | 41.30 | 163 | 171 | 179 | 221 | 232 | 243 |
| | 24 | 1 7/8-12 | 1.87 | 47.60 | 198 | 208 | 218 | 268 | 282 | 296 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 244 | 256 | 268 | 331 | 347 | 363 | |

* ØA Thread OD dimension for reference only.

**Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-14. O-ring Boss (ORB) - Table 3 of 6




| TYPE/FITTING IDENTIFICATION | | | | | ADJUSTABLE STUD END with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | |
|--|-----------|----------------------|-------|-------|---|-------|-------|-------|-----|-----|
| MATERIAL | Dash Size | Thread Size (UNF) | ØA* | | Torque | | | | | |
| | | | (in) | (mm) | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | | | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | (60) | (63) | (66) | 7 | 7 | 7 |
| | 3 | 3/8-24 | 0.37 | 9.52 | (100) | (105) | (110) | 11 | 12 | 12 |
| | 4 | 7/16-20 | 0.44 | 11.11 | 15 | 16 | 17 | 20 | 22 | 23 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 21 | 22 | 23 | 28 | 30 | 31 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 29 | 31 | 32 | 40 | 42 | 43 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 52 | 55 | 57 | 70 | 75 | 77 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 85 | 90 | 94 | 115 | 122 | 127 |
| | 12 | 1 1/16-12 | 1.06 | 27.00 | 135 | 142 | 149 | 185 | 193 | 202 |
| | 14 | 1 3/16-12 | 1.19 | 30.10 | 175 | 184 | 193 | 235 | 249 | 262 |
| | 16 | 1 5/16-12 | 1.31 | 33.30 | 200 | 210 | 220 | 270 | 285 | 298 |
| | 20 | 1 5/8-12 | 1.63 | 41.30 | 250 | 263 | 275 | 340 | 357 | 373 |
| | 24 | 1 7/8-12 | 1.87 | 47.60 | 305 | 321 | 336 | 415 | 435 | 456 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 375 | 394 | 413 | 510 | 534 | 560 | |
| TYPE/FITTING IDENTIFICATION | | | | | ADJUSTABLE STUD END with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | |
| MATERIAL | Dash Size | Thread Size (UNF) | ØA* | | Torque | | | | | |
| | | | (in) | (mm) | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | | | Min | Nom | Max | Min | Nom | Max |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | (39) | (41) | (43) | 4 | 5 | 5 |
| | 3 | 3/8-24 | 0.37 | 9.52 | (65) | (69) | (72) | 7 | 8 | 8 |
| | 4 | 7/16-20 | 0.44 | 11.11 | 10 | 11 | 11 | 14 | 15 | 15 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 14 | 15 | 15 | 19 | 20 | 20 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 19 | 20 | 21 | 26 | 27 | 28 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 34 | 36 | 37 | 46 | 49 | 50 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 55 | 58 | 61 | 75 | 79 | 83 |
| | 12 | 1 1/16-12 | 1.06 | 27.00 | 88 | 93 | 97 | 119 | 126 | 132 |
| | 14 | 1 3/16-12 | 1.19 | 30.10 | 114 | 120 | 126 | 155 | 163 | 171 |
| | 16 | 1 5/16-12 | 1.31 | 33.30 | 130 | 137 | 143 | 176 | 186 | 194 |
| | 20 | 1 5/8-12 | 1.63 | 41.30 | 163 | 171 | 179 | 221 | 232 | 243 |
| | 24 | 1 7/8-12 | 1.87 | 47.60 | 198 | 208 | 218 | 268 | 282 | 296 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 244 | 256 | 268 | 331 | 347 | 363 | |

* ØA Thread OD dimension for reference only.

***Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-15. O-ring Boss (ORB) - Table 4 of 6




| TYPE/FITTING IDENTIFICATION | | | | | ADJUSTABLE STUD END with (ORFS) or S series DIN (MBTS) opposite end | | | | | |
|--|-----------|-------------|-------|-------|--|------|------|-------|-----|-----|
| MATERIAL | Dash Size | Thread Size | ØA* | | Torque | | | | | |
| | | | | | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | | | (UNF) | (in) | (mm) | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | -- | -- | -- | -- | -- | -- |
| | 3 | 3/8-24 | 0.37 | 9.52 | -- | -- | -- | -- | -- | -- |
| | 4 | 7/16-20 | 0.44 | 11.11 | 15 | 16 | 17 | 20 | 22 | 23 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 30 | 32 | 33 | 40 | 43 | 45 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 35 | 37 | 39 | 46 | 50 | 53 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 60 | 63 | 66 | 80 | 85 | 89 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 100 | 105 | 110 | 135 | 142 | 149 |
| | 12 | 1 1/16-12 | 1.06 | 27.00 | 135 | 142 | 149 | 185 | 193 | 202 |
| | 14 | 1 3/16-12 | 1.19 | 30.10 | 175 | 184 | 193 | 235 | 249 | 262 |
| | 16 | 1 5/16-12 | 1.31 | 33.30 | 200 | 210 | 220 | 270 | 285 | 298 |
| | 20 | 1 5/8-12 | 1.63 | 41.30 | 250 | 263 | 275 | 340 | 357 | 373 |
| | 24 | 1 7/8-12 | 1.87 | 47.60 | 305 | 321 | 336 | 415 | 435 | 456 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 375 | 394 | 413 | 510 | 534 | 560 | |
| TYPE/FITTING IDENTIFICATION | | | | | ADJUSTABLE STUD END with (ORFS) or S series DIN (MBTS) opposite end | | | | | |
| MATERIAL | Dash Size | Thread Size | ØA* | | Torque | | | | | |
| | | | | | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | | | (UNF) | (in) | (mm) | Min | Nom | Max |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | -- | -- | -- | -- | -- | -- |
| | 3 | 3/8-24 | 0.37 | 9.52 | -- | -- | -- | -- | -- | -- |
| | 4 | 7/16-20 | 0.44 | 11.11 | 10 | 11 | 11 | 14 | 15 | 15 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 20 | 21 | 21 | 27 | 28 | 28 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 23 | 24 | 24 | 31 | 33 | 33 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 39 | 41 | 43 | 53 | 56 | 58 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 65 | 69 | 72 | 88 | 94 | 98 |
| | 12 | 1 1/16-12 | 1.06 | 27.00 | 88 | 93 | 97 | 119 | 126 | 132 |
| | 14 | 1 3/16-12 | 1.19 | 30.10 | 114 | 120 | 126 | 155 | 163 | 171 |
| | 16 | 1 5/16-12 | 1.31 | 33.30 | 130 | 137 | 143 | 176 | 186 | 194 |
| | 20 | 1 5/8-12 | 1.63 | 41.30 | 163 | 171 | 179 | 221 | 232 | 243 |
| | 24 | 1 7/8-12 | 1.87 | 47.60 | 198 | 208 | 218 | 268 | 282 | 296 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 244 | 256 | 268 | 331 | 347 | 363 | |

* ØA Thread OD dimension for reference only.

**Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-16. O-ring Boss (ORB) - Table 5 of 6




| TYPE/FITTING IDENTIFICATION | | | | | HOLLOW HEX PLUGS | | | | | |
|--|-----------|-------------|-------|-------|------------------|------|------|-------|-----|-----|
| MATERIAL | Dash Size | Thread Size | ØA* | | Torque | | | | | |
| | | | | | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | (UNF) | (in) | (mm) | Min | Nom | Max | Min | Nom |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | (30) | (32) | (33) | 3 | 4 | 4 |
| | 3 | 3/8-24 | 0.37 | 9.52 | (55) | (58) | (61) | 6 | 7 | 7 |
| | 4 | 7/16-20 | 0.44 | 11.11 | 10 | 11 | 11 | 14 | 15 | 15 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 14 | 15 | 16 | 19 | 20 | 22 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 34 | 36 | 38 | 46 | 49 | 52 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 60 | 63 | 66 | 80 | 85 | 89 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 100 | 105 | 110 | 135 | 142 | 149 |
| | 12 | 11/16-12 | 1.06 | 27.00 | 135 | 142 | 149 | 185 | 193 | 202 |
| | 14 | 13/16-12 | 1.19 | 30.10 | 175 | 184 | 193 | 235 | 249 | 262 |
| | 16 | 15/16-12 | 1.31 | 33.30 | 200 | 210 | 220 | 270 | 285 | 298 |
| | 20 | 15/8-12 | 1.63 | 41.30 | 250 | 263 | 275 | 340 | 357 | 373 |
| | 24 | 17/8-12 | 1.87 | 47.60 | 305 | 321 | 336 | 415 | 435 | 456 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 375 | 394 | 413 | 510 | 534 | 560 | |
| TYPE/FITTING IDENTIFICATION | | | | | HOLLOW HEX PLUGS | | | | | |
| MATERIAL | Dash Size | Thread Size | ØA* | | Torque | | | | | |
| | | | | | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | (UNF) | (in) | (mm) | Min | Nom | Max | Min | Nom |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | (20) | (21) | (21) | 2 | 2 | 2 |
| | 3 | 3/8-24 | 0.37 | 9.52 | (36) | (38) | (40) | 4 | 4 | 5 |
| | 4 | 7/16-20 | 0.44 | 11.11 | 6 | 7 | 7 | 8 | 9 | 9 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 9 | 10 | 10 | 12 | 14 | 14 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 22 | 24 | 25 | 30 | 33 | 34 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 39 | 41 | 43 | 53 | 56 | 58 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 65 | 69 | 72 | 88 | 94 | 98 |
| | 12 | 11/16-12 | 1.06 | 27.00 | 88 | 93 | 97 | 119 | 126 | 132 |
| | 14 | 13/16-12 | 1.19 | 30.10 | 114 | 120 | 126 | 155 | 163 | 171 |
| | 16 | 15/16-12 | 1.31 | 33.30 | 130 | 137 | 143 | 176 | 186 | 194 |
| | 20 | 15/8-12 | 1.63 | 41.30 | 163 | 171 | 179 | 221 | 232 | 243 |
| | 24 | 17/8-12 | 1.87 | 47.60 | 198 | 208 | 218 | 268 | 282 | 296 |
| 32 | 2 1/2-12 | 2.50 | 63.50 | 244 | 256 | 268 | 331 | 347 | 363 | |

* ØA Thread OD dimension for reference only.

*** Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-17. O-ring Boss (ORB) - Table 6 of 6



| TYPE/FITTING IDENTIFICATION | | | | | ZERO LEAK GOLD® HOLLOW HEX PLUGS | | | | | |
|---|-----------|----------------------|-------|-------|--|-----|-----|-------|-----|-----|
| MATERIAL | Dash Size | Thread Size (UNF) | ØA* | | Torque** | | | | | |
| | | | (in) | (mm) | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | | | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | 2 | 3 | 4 | 3 | 4 | 5 |
| | 3 | 3/8-24 | 0.37 | 9.52 | 3 | 4 | 5 | 4 | 5 | 7 |
| | 4 | 7/16-20 | 0.44 | 11.11 | 7 | 8 | 9 | 9 | 11 | 12 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 9 | 10 | 11 | 12 | 14 | 15 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 11 | 12 | 13 | 15 | 16 | 18 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 28 | 30 | 32 | 38 | 41 | 43 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 46 | 48 | 50 | 62 | 65 | 68 |
| | 12 | 11/16-12 | 1.06 | 27.00 | 51 | 54 | 57 | 69 | 73 | 77 |
| | 14 | 13/16-12 | 1.19 | 30.10 | Fitting size greater than -12 not typically specified on JLG applications. Consult specific service procedure if encountered. | | | | | |
| | 16 | 15/16-12 | 1.31 | 33.30 | | | | | | |
| | 20 | 15/8-12 | 1.63 | 41.30 | | | | | | |
| | 24 | 17/8-12 | 1.87 | 47.60 | | | | | | |
| 32 | 2 1/2-12 | 2.50 | 63.50 | | | | | | | |
| TYPE/FITTING IDENTIFICATION | | | | | ZERO LEAK GOLD® HOLLOW HEX PLUGS | | | | | |
| MATERIAL | Dash Size | Thread Size (UNF) | ØA* | | Torque** | | | | | |
| | | | (in) | (mm) | Ft-Lb or (in-lb) | | | [N-m] | | |
| | | | | | Min | Nom | Max | Min | Nom | Max |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | 2 | 5/16-24 | 0.31 | 7.93 | 2 | 3 | 4 | 3 | 4 | 5 |
| | 3 | 3/8-24 | 0.37 | 9.52 | 3 | 4 | 5 | 4 | 5 | 7 |
| | 4 | 7/16-20 | 0.44 | 11.11 | 7 | 8 | 9 | 9 | 11 | 12 |
| | 5 | 1/2-20 | 0.50 | 12.70 | 9 | 10 | 11 | 12 | 14 | 15 |
| | 6 | 9/16-18 | 0.56 | 14.28 | 11 | 12 | 13 | 15 | 16 | 18 |
| | 8 | 3/4-16 | 0.75 | 19.10 | 28 | 30 | 32 | 38 | 41 | 43 |
| | 10 | 7/8-14 | 0.87 | 22.22 | 46 | 48 | 50 | 62 | 65 | 68 |
| | 12 | 11/16-12 | 1.06 | 27.00 | 51 | 54 | 57 | 69 | 73 | 77 |
| | 14 | 13/16-12 | 1.19 | 30.10 | Fitting size greater than -12 not typically specified on JLG applications. Consult specific service procedure if encountered. | | | | | |
| | 16 | 15/16-12 | 1.31 | 33.30 | | | | | | |
| | 20 | 15/8-12 | 1.63 | 41.30 | | | | | | |
| | 24 | 17/8-12 | 1.87 | 47.60 | | | | | | |
| 32 | 2 1/2-12 | 2.50 | 63.50 | | | | | | | |

* ØA Thread OD dimension for reference only.

**Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.

Assembly Instructions for Adjustable Port End Metric (MFF) Fittings

1. Inspect components to ensure that male and female threads and surfaces are free of rust, splits, dirt, foreign matter, or burrs.
2. If O-ring is not pre-installed, install proper size, taking care not to damage it. See O-ring Installation (Replacement) for instructions.

CAUTION

CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. For Non-Adjustable Fittings and Plugs, thread the fitting by hand until contact.
5. For Adjustable fittings, refer to Adjustable Stud End Assembly for proper assembly.

6. Torque the fitting or nut to value listed in Table 5-18, Table 5-19, Table 5-20, Metric Flat Face Port (MFF) - L Series and Table 5-21, Table 5-22, Table 5-23, Metric Flat Face Port (MFF) - S Series while using the Double Wrench Method.

NOTE: *The table headings identify the Metric port and the type on the other side of the fitting. The torque will be applied to the Metric port.*

NOTE: *Torque values provided in Table 5-18, Table 5-19, Table 5-20, Metric Flat Face Port (MFF) - L Series and Table 5-21, Table 5-22, and Table 5-23, Metric Flat Face Port (MFF) - S Series are segregated based on the material configuration of the connection.*

'ALUMINUM/BRASS FITTINGS' OR 'ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- a. STEEL fittings with ALUMINUM or BRASS mating components.
- b. ALUMINUM or BRASS fittings with STEEL mating components.
- c. ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

7. Inspect to ensure the O-ring is not pinched and the washer is seated flat on the counterbore of the port.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-18. Metric Flat Face Port (MFF) - L Series - Table 1 of 3

| TYPE/FITTING IDENTIFICATION | | | FORM A (SEALING WASHER) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | | FORM B (CUTTING FACE) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | |
|--|---------------|----------------------|--|-----|-----|-------|-----|-----|--|-----|-----|-------|-----|-----|
| MATERIAL | Thread M Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | (metric) | (mm) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 7 | 8 | 8 | 9 | 11 | 11 | 13 | 14 | 14 | 18 | 19 | 19 |
| | M12x1.5 | 8 | 15 | 16 | 17 | 20 | 22 | 23 | 22 | 23 | 24 | 30 | 31 | 33 |
| | M14x1.5 | 10 | 26 | 28 | 29 | 35 | 38 | 39 | 33 | 35 | 36 | 45 | 47 | 49 |
| | M16x1.5 | 12 | 33 | 35 | 36 | 45 | 47 | 49 | 48 | 51 | 53 | 65 | 69 | 72 |
| | M18x1.5 | 15 | 41 | 43 | 45 | 55 | 58 | 61 | 59 | 62 | 65 | 80 | 84 | 88 |
| | M22x1.5 | 18 | 48 | 51 | 53 | 65 | 69 | 72 | 103 | 108 | 113 | 140 | 146 | 153 |
| | M27x2 | 22 | 66 | 70 | 73 | 90 | 95 | 99 | 140 | 147 | 154 | 190 | 199 | 209 |
| | M33x2 | 28 | 111 | 117 | 122 | 150 | 159 | 165 | 251 | 264 | 276 | 340 | 358 | 374 |
| | M42x2 | 35 | 177 | 186 | 195 | 240 | 252 | 264 | 369 | 388 | 406 | 500 | 526 | 550 |
| | M48x2 | 42 | 214 | 225 | 235 | 290 | 305 | 319 | 465 | 489 | 512 | 630 | 663 | 694 |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 4 | 5 | 5 | 5 | 7 | 7 | 8 | 9 | 9 | 11 | 12 | 12 |
| | M12x1.5 | 8 | 10 | 11 | 11 | 14 | 15 | 15 | 14 | 15 | 16 | 19 | 20 | 22 |
| | M14x1.5 | 10 | 17 | 18 | 19 | 23 | 24 | 26 | 21 | 22 | 23 | 28 | 30 | 31 |
| | M16x1.5 | 12 | 21 | 22 | 23 | 28 | 30 | 31 | 31 | 33 | 34 | 42 | 45 | 46 |
| | M18x1.5 | 15 | 27 | 28 | 29 | 37 | 38 | 39 | 38 | 40 | 42 | 52 | 54 | 57 |
| | M22x1.5 | 18 | 31 | 33 | 34 | 42 | 45 | 46 | 67 | 70 | 73 | 91 | 95 | 99 |
| | M27x2 | 22 | 43 | 45 | 47 | 58 | 61 | 64 | 91 | 96 | 100 | 123 | 130 | 136 |
| | M33x2 | 28 | 72 | 76 | 79 | 98 | 103 | 107 | 163 | 171 | 179 | 221 | 232 | 243 |
| | M42x2 | 35 | 115 | 121 | 127 | 156 | 164 | 172 | 240 | 252 | 264 | 325 | 342 | 358 |
| | M48x2 | 42 | 139 | 146 | 153 | 188 | 198 | 207 | 302 | 318 | 332 | 409 | 431 | 450 |

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-19. Metric Flat Face Port (MFF) - L Series - Table 2 of 3

| TYPE/FITTING IDENTIFICATION | | | FORM A (SEALING WASHER) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | | FORM B (CUTTING FACE) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | |
|--|---------------|----------------------|--|-----|-----|-------|-----|-----|--|-----|-----|-------|-----|-----|
| MATERIAL | Thread M Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | (metric) | (mm) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 13 | 14 | 14 | 18 | 19 | 19 | 13 | 14 | 15 | 18 | 19 | 20 |
| | M12x1.5 | 8 | 18 | 19 | 20 | 25 | 26 | 27 | 18 | 19 | 20 | 25 | 26 | 28 |
| | M14x1.5 | 10 | 33 | 35 | 36 | 45 | 47 | 49 | 30 | 31 | 32 | 40 | 42 | 44 |
| | M16x1.5 | 12 | 41 | 43 | 45 | 55 | 58 | 61 | 41 | 43 | 45 | 55 | 58 | 61 |
| | M18x1.5 | 15 | 52 | 55 | 57 | 70 | 75 | 77 | 52 | 54 | 57 | 70 | 74 | 77 |
| | M22x1.5 | 18 | 92 | 97 | 101 | 125 | 132 | 137 | 66 | 70 | 73 | 90 | 95 | 99 |
| | M27x2 | 22 | 133 | 140 | 146 | 180 | 190 | 198 | 133 | 139 | 146 | 180 | 189 | 198 |
| | M33x2 | 28 | 229 | 241 | 252 | 310 | 327 | 342 | 229 | 240 | 252 | 310 | 326 | 341 |
| | M42x2 | 35 | 332 | 349 | 365 | 450 | 473 | 495 | 332 | 348 | 365 | 450 | 473 | 495 |
| | M48x2 | 42 | 398 | 418 | 438 | 540 | 567 | 594 | 398 | 418 | 438 | 540 | 567 | 594 |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 8 | 9 | 9 | 11 | 12 | 12 | 8 | 9 | 9 | 11 | 12 | 12 |
| | M12x1.5 | 8 | 12 | 13 | 13 | 16 | 18 | 18 | 12 | 13 | 13 | 16 | 18 | 18 |
| | M14x1.5 | 10 | 21 | 22 | 23 | 28 | 30 | 31 | 19 | 20 | 21 | 26 | 27 | 29 |
| | M16x1.5 | 12 | 27 | 28 | 29 | 37 | 38 | 39 | 26 | 28 | 29 | 36 | 38 | 39 |
| | M18x1.5 | 15 | 34 | 36 | 37 | 46 | 49 | 50 | 34 | 35 | 37 | 46 | 48 | 50 |
| | M22x1.5 | 18 | 60 | 63 | 66 | 81 | 85 | 89 | 43 | 45 | 47 | 59 | 61 | 64 |
| | M27x2 | 22 | 86 | 91 | 95 | 117 | 123 | 129 | 86 | 91 | 95 | 117 | 123 | 129 |
| | M33x2 | 28 | 149 | 157 | 164 | 202 | 213 | 222 | 149 | 157 | 164 | 202 | 213 | 222 |
| | M42x2 | 35 | 216 | 227 | 237 | 293 | 308 | 321 | 216 | 227 | 237 | 293 | 308 | 321 |
| | M48x2 | 42 | 259 | 272 | 285 | 351 | 369 | 386 | 259 | 272 | 285 | 351 | 369 | 386 |

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-20. Metric Flat Face Port (MFF) - L Series - Table 3 of 3

| TYPE/FITTING IDENTIFICATION | | | BANJO FITTINGS with L series DIN (MBTL) opposite end | | | | | | HIGH PRESSURE BANJO FITTINGS with L series DIN (MBTL) opposite end | | | | | | FORM E (EOLASTIC SEALING RING) HOLLOW HEX PLUGS | | | | | |
|---|------------------|-------------------------|---|-----|-----|-------|-----|-----|---|-----|-----|-------|-----|-----|--|-----|-----|-------|-----|-----|
| MATERIAL | Thread M Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | | Torque | | | | | |
| | (metric) | (mm) | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | | | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 13 | 14 | 14 | 18 | 19 | 19 | 13 | 14 | 14 | 18 | 19 | 19 | 9 | 10 | 10 | 12 | 14 | 14 |
| | M12x1.5 | 8 | 26 | 28 | 29 | 35 | 38 | 39 | 33 | 35 | 36 | 45 | 47 | 49 | 18 | 19 | 20 | 25 | 26 | 27 |
| | M14x1.5 | 10 | 37 | 39 | 41 | 50 | 53 | 56 | 41 | 43 | 45 | 55 | 58 | 61 | 26 | 28 | 29 | 35 | 38 | 39 |
| | M16x1.5 | 12 | 44 | 46 | 48 | 60 | 62 | 65 | 59 | 62 | 65 | 80 | 84 | 88 | 41 | 43 | 45 | 55 | 58 | 61 |
| | M18x1.5 | 15 | 59 | 62 | 65 | 80 | 84 | 88 | 74 | 78 | 81 | 100 | 106 | 110 | 48 | 51 | 53 | 65 | 69 | 72 |
| | M22x1.5 | 18 | 89 | 94 | 98 | 120 | 127 | 133 | 103 | 108 | 113 | 140 | 146 | 153 | 66 | 70 | 73 | 90 | 95 | 99 |
| | M27x2 | 22 | 96 | 101 | 106 | 130 | 137 | 144 | 236 | 248 | 260 | 320 | 336 | 353 | 100 | 105 | 110 | 135 | 142 | 149 |
| | M33x2 | 28 | -- | -- | -- | -- | -- | -- | 266 | 280 | 293 | 360 | 380 | 397 | 166 | 175 | 183 | 225 | 237 | 248 |
| | M42x2 | 35 | -- | -- | -- | -- | -- | -- | 398 | 418 | 438 | 540 | 567 | 594 | 266 | 280 | 293 | 360 | 380 | 397 |
| | M48x2 | 42 | -- | -- | -- | -- | -- | -- | 516 | 542 | 568 | 700 | 735 | 770 | 266 | 280 | 293 | 360 | 380 | 397 |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 8 | 9 | 9 | 11 | 12 | 12 | 8 | 9 | 9 | 11 | 12 | 12 | 6 | 7 | 7 | 8 | 9 | 9 |
| | M12x1.5 | 8 | 17 | 18 | 19 | 23 | 24 | 26 | 21 | 22 | 23 | 28 | 30 | 31 | 12 | 13 | 13 | 16 | 18 | 18 |
| | M14x1.5 | 10 | 24 | 26 | 27 | 33 | 35 | 37 | 27 | 28 | 29 | 37 | 38 | 39 | 17 | 18 | 19 | 23 | 24 | 26 |
| | M16x1.5 | 12 | 29 | 30 | 31 | 39 | 41 | 42 | 38 | 40 | 42 | 52 | 54 | 57 | 27 | 28 | 29 | 37 | 38 | 39 |
| | M18x1.5 | 15 | 38 | 40 | 42 | 52 | 54 | 57 | 48 | 51 | 53 | 65 | 69 | 72 | 31 | 33 | 34 | 42 | 45 | 46 |
| | M22x1.5 | 18 | 58 | 61 | 64 | 79 | 83 | 87 | 67 | 70 | 73 | 91 | 95 | 99 | 43 | 45 | 47 | 58 | 61 | 64 |
| | M27x2 | 22 | 62 | 66 | 69 | 84 | 89 | 94 | 153 | 161 | 169 | 207 | 218 | 229 | 65 | 69 | 72 | 88 | 94 | 98 |
| | M33x2 | 28 | -- | -- | -- | -- | -- | -- | 173 | 182 | 190 | 235 | 247 | 258 | 108 | 114 | 119 | 146 | 155 | 161 |
| | M42x2 | 35 | -- | -- | -- | -- | -- | -- | 259 | 272 | 285 | 351 | 369 | 386 | 173 | 182 | 190 | 235 | 247 | 258 |
| | M48x2 | 42 | -- | -- | -- | -- | -- | -- | 335 | 352 | 369 | 454 | 477 | 500 | 173 | 182 | 190 | 235 | 247 | 258 |

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-21. Metric Flat Face Port (MFF) - S Series - Table 1 of 3

| TYPE/FITTING IDENTIFICATION | | | FORM A (SEALING WASHER) STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end | | | | | | FORM B (CUTTING FACE) STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end | | | | | |
|--|---------------|----------------------|--|-----|-----|-------|-----|-----|--|-----|-----|-------|-----|-----|
| MATERIAL | Thread M Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | |
| | (metric) | (mm) | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | | | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | M12x1.5 | 6 | 15 | 16 | 17 | 20 | 22 | 23 | 26 | 28 | 29 | 35 | 38 | 39 |
| | M14x1.5 | 8 | 26 | 28 | 29 | 35 | 38 | 39 | 41 | 43 | 45 | 55 | 58 | 61 |
| | M16x1.5 | 10 | 33 | 35 | 36 | 45 | 47 | 49 | 52 | 55 | 57 | 70 | 75 | 77 |
| | M18x1.5 | 12 | 41 | 43 | 45 | 55 | 58 | 61 | 81 | 85 | 89 | 110 | 115 | 121 |
| | M20x1.5 | 14 | 41 | 43 | 45 | 55 | 58 | 61 | 111 | 117 | 122 | 150 | 159 | 165 |
| | M22x1.5 | 16 | 48 | 51 | 53 | 65 | 69 | 72 | 125 | 132 | 138 | 170 | 179 | 187 |
| | M27x2 | 20 | 66 | 70 | 73 | 89 | 95 | 99 | 199 | 209 | 219 | 270 | 283 | 297 |
| | M33x2 | 25 | 111 | 117 | 122 | 150 | 159 | 165 | 302 | 317 | 332 | 410 | 430 | 450 |
| | M42x2 | 30 | 177 | 186 | 195 | 240 | 252 | 264 | 398 | 418 | 438 | 540 | 567 | 594 |
| | M48x2 | 38 | 214 | 225 | 235 | 290 | 305 | 319 | 516 | 542 | 568 | 700 | 735 | 770 |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | M12x1.5 | 6 | 10 | 11 | 11 | 14 | 15 | 15 | 17 | 18 | 19 | 23 | 24 | 26 |
| | M14x1.5 | 8 | 17 | 18 | 19 | 23 | 24 | 26 | 27 | 28 | 29 | 37 | 38 | 39 |
| | M16x1.5 | 10 | 21 | 22 | 23 | 28 | 30 | 31 | 34 | 36 | 37 | 46 | 49 | 50 |
| | M18x1.5 | 12 | 27 | 28 | 29 | 37 | 38 | 39 | 53 | 56 | 58 | 72 | 76 | 79 |
| | M20x1.5 | 14 | 27 | 28 | 29 | 37 | 38 | 39 | 72 | 76 | 79 | 98 | 103 | 107 |
| | M22x1.5 | 16 | 31 | 33 | 34 | 42 | 45 | 46 | 81 | 86 | 90 | 110 | 117 | 122 |
| | M27x2 | 20 | 43 | 45 | 47 | 58 | 61 | 64 | 129 | 136 | 142 | 175 | 184 | 193 |
| | M33x2 | 25 | 72 | 76 | 79 | 98 | 103 | 107 | 196 | 206 | 216 | 266 | 279 | 293 |
| | M42x2 | 30 | 115 | 121 | 127 | 156 | 164 | 172 | 259 | 272 | 285 | 351 | 369 | 386 |
| | M48x2 | 38 | 139 | 146 | 153 | 188 | 198 | 207 | 335 | 352 | 369 | 454 | 477 | 500 |

Table 5-22. Metric Flat Face Port (MFF) - S Series - Table 2 of 3

| TYPE/FITTING IDENTIFICATION | | | FORM E (EOLASTIC SEALING RING) STUD ENDS AND HEX TYPE PLUGS with (ORFS) or S series DIN (MBTS) opposite end | | | | | | FORM G/H (O-RING W/ RETAINING RING) STUD ENDS & ADJUSTABLE STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end | | | | | |
|---|---------------------------|------------------------------|---|-----|-----|-------|-----|-----|---|-----|-----|-------|-----|-----|
| MATERIAL | Thread M Size (metric) | Connecting Tube O.D. (mm) | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | | | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 26 | 28 | 29 | 35 | 38 | 39 | 26 | 28 | 29 | 35 | 38 | 39 |
| | M12x1.5 | 8 | 33 | 35 | 36 | 45 | 47 | 49 | 41 | 43 | 45 | 55 | 58 | 61 |
| | M14x1.5 | 10 | 52 | 55 | 57 | 70 | 75 | 77 | 52 | 55 | 57 | 70 | 75 | 77 |
| | M16x1.5 | 12 | 66 | 70 | 73 | 90 | 95 | 99 | 66 | 70 | 73 | 90 | 95 | 99 |
| | M18x1.5 | 15 | 92 | 97 | 101 | 125 | 132 | 137 | 92 | 97 | 101 | 125 | 132 | 137 |
| | M22x1.5 | 18 | 100 | 105 | 110 | 135 | 142 | 149 | 100 | 105 | 110 | 135 | 142 | 149 |
| | M27x2 | 22 | 133 | 140 | 146 | 180 | 190 | 198 | 133 | 140 | 146 | 180 | 190 | 198 |
| | M33x2 | 28 | 229 | 241 | 252 | 310 | 327 | 342 | 229 | 241 | 252 | 310 | 327 | 342 |
| | M42x2 | 35 | 332 | 349 | 365 | 450 | 473 | 495 | 332 | 349 | 365 | 450 | 473 | 495 |
| | M48x2 | 42 | 398 | 418 | 438 | 540 | 567 | 594 | 398 | 418 | 438 | 540 | 567 | 594 |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 17 | 18 | 19 | 23 | 24 | 26 | 17 | 18 | 19 | 23 | 24 | 26 |
| | M12x1.5 | 8 | 21 | 23 | 23 | 29 | 31 | 32 | 27 | 28 | 29 | 37 | 38 | 39 |
| | M14x1.5 | 10 | 34 | 36 | 37 | 46 | 49 | 50 | 34 | 36 | 37 | 46 | 49 | 50 |
| | M16x1.5 | 12 | 43 | 45 | 47 | 58 | 61 | 64 | 43 | 45 | 47 | 58 | 61 | 64 |
| | M18x1.5 | 15 | 60 | 63 | 66 | 81 | 85 | 89 | 60 | 63 | 66 | 81 | 85 | 89 |
| | M22x1.5 | 18 | 65 | 69 | 72 | 88 | 94 | 98 | 65 | 69 | 72 | 88 | 94 | 98 |
| | M27x2 | 22 | 86 | 91 | 95 | 117 | 123 | 129 | 86 | 91 | 95 | 117 | 123 | 129 |
| | M33x2 | 28 | 149 | 157 | 164 | 202 | 213 | 222 | 149 | 157 | 164 | 202 | 213 | 222 |
| | M42x2 | 35 | 216 | 227 | 237 | 293 | 308 | 321 | 216 | 227 | 237 | 293 | 308 | 321 |
| | M48x2 | 42 | 259 | 272 | 285 | 351 | 369 | 386 | 259 | 272 | 285 | 351 | 369 | 386 |

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-23. Metric Flat Face Port (MFF) - S Series - Table 3 of 3

| TYPE/FITTING IDENTIFICATION | | | BANJO FITTINGS with S series DIN (MBTS) opposite end | | | | | | HIGH PRESSURE BANJO FITTINGS with S series DIN (MBTS) opposite end | | | | | | FORM E (EOLASTIC SEALING RING) HOLLOW HEX PLUGS | | | | | |
|---|------------------|-------------------------|---|-----|-----|-------|-----|-----|---|-----|-----|-------|-----|-----|--|-----|-----|-------|-----|-----|
| MATERIAL | Thread M Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | (metric) | (mm) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 26 | 28 | 29 | 35 | 38 | 39 | 33 | 35 | 36 | 45 | 47 | 49 | -- | -- | -- | -- | -- | -- |
| | M12x1.5 | 8 | 37 | 39 | 41 | 50 | 53 | 56 | 41 | 43 | 45 | 55 | 58 | 61 | -- | -- | -- | -- | -- | -- |
| | M14x1.5 | 10 | 44 | 46 | 48 | 60 | 62 | 65 | 59 | 62 | 65 | 80 | 84 | 88 | -- | -- | -- | -- | -- | -- |
| | M16x1.5 | 12 | 59 | 62 | 65 | 80 | 84 | 88 | 74 | 78 | 81 | 100 | 106 | 110 | -- | -- | -- | -- | -- | -- |
| | M18x1.5 | 15 | 81 | 85 | 89 | 110 | 115 | 121 | 92 | 97 | 101 | 125 | 132 | 137 | 59 | 62 | 65 | 80 | 84 | 88 |
| | M22x1.5 | 18 | 89 | 94 | 98 | 120 | 127 | 133 | 100 | 105 | 110 | 135 | 142 | 149 | -- | -- | -- | -- | -- | -- |
| | M27x2 | 22 | 100 | 105 | 110 | 135 | 142 | 149 | 236 | 248 | 260 | 320 | 336 | 353 | -- | -- | -- | -- | -- | -- |
| | M33x2 | 28 | -- | -- | -- | -- | -- | -- | 266 | 280 | 293 | 360 | 380 | 397 | -- | -- | -- | -- | -- | -- |
| | M42x2 | 35 | -- | -- | -- | -- | -- | -- | 398 | 418 | 438 | 540 | 567 | 594 | -- | -- | -- | -- | -- | -- |
| | M48x2 | 42 | -- | -- | -- | -- | -- | -- | 516 | 542 | 568 | 700 | 735 | 770 | -- | -- | -- | -- | -- | -- |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | M10x1 | 6 | 17 | 18 | 19 | 23 | 24 | 26 | 21 | 22 | 23 | 28 | 30 | 31 | -- | -- | -- | -- | -- | -- |
| | M12x1.5 | 8 | 24 | 26 | 27 | 33 | 35 | 37 | 27 | 28 | 29 | 37 | 38 | 39 | -- | -- | -- | -- | -- | -- |
| | M14x1.5 | 10 | 29 | 30 | 31 | 39 | 41 | 42 | 38 | 40 | 42 | 52 | 54 | 57 | -- | -- | -- | -- | -- | -- |
| | M16x1.5 | 12 | 38 | 40 | 42 | 52 | 54 | 57 | 48 | 51 | 53 | 65 | 69 | 72 | -- | -- | -- | -- | -- | -- |
| | M18x1.5 | 15 | 53 | 56 | 58 | 72 | 76 | 79 | 60 | 63 | 66 | 81 | 85 | 89 | 38 | 40 | 42 | 52 | 54 | 57 |
| | M22x1.5 | 18 | 58 | 61 | 64 | 79 | 83 | 87 | 65 | 69 | 72 | 88 | 94 | 98 | -- | -- | -- | -- | -- | -- |
| | M27x2 | 22 | 65 | 69 | 72 | 88 | 94 | 98 | 153 | 161 | 169 | 207 | 218 | 229 | -- | -- | -- | -- | -- | -- |
| | M33x2 | 28 | -- | -- | -- | -- | -- | -- | 173 | 182 | 190 | 235 | 247 | 258 | -- | -- | -- | -- | -- | -- |
| | M42x2 | 35 | -- | -- | -- | -- | -- | -- | 259 | 272 | 285 | 351 | 369 | 386 | -- | -- | -- | -- | -- | -- |
| | M48x2 | 42 | -- | -- | -- | -- | -- | -- | 335 | 352 | 369 | 454 | 477 | 500 | -- | -- | -- | -- | -- | -- |

Assembly Instructions for Metric ISO 6149 (MPP) Port Assembly Stud Ends

1. Inspect components to ensure that male and female threads and surfaces are free of rust, splits, dirt, foreign matter, or burrs.
2. If O-ring is not preinstalled, install proper size, taking care not to damage it. See O-ring Installation (Replacement) for instructions.

CAUTION

CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. For Non-Adjustable Fittings and Plugs, thread the fitting by hand until contact.
5. For Adjustable fittings, refer to Adjustable Stud End Assembly for proper assembly.

6. Torque the fitting or nut to value listed in Table 5-24, Metric Pipe Parallel O-ring Boss (MPP) while using the Double Wrench Method.

NOTE: *The table headings identify the Metric port and the type on the other side of the fitting. The torque will be applied to the Metric port.*

NOTE: *Torque values provided in Table 5-24, Metric Pipe Parallel O-ring Boss (MPP) are segregated based on the material configuration of the connection.*

'ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- a. STEEL fittings with ALUMINUM or BRASS mating components.
 - b. ALUMINUM or BRASS fittings with STEEL mating components.
 - c. ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.
7. Inspect to ensure the O-ring is not pinched and the washer is seated flat on the counterbore of the port.

Table 5-24. Metric Pipe Parallel O-Ring Boss (MPP)

| TYPE/FITTING IDENTIFICATION | | | STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | | STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end | | | | | |
|---|------------------|-------------------------|---|-----|-----|-------|-----|-----|--|-----|-----|-------|-----|-----|
| MATERIAL | Thread M Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | (metric) | (mm) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | M8x1 | 4 | 6 | 7 | 7 | 8 | 9 | 9 | 8 | 9 | 9 | 10 | 12 | 12 |
| | M10x1 | 6 | 11 | 12 | 12 | 15 | 16 | 16 | 15 | 16 | 17 | 20 | 22 | 23 |
| | M12x1.5 | 8 | 18 | 19 | 20 | 25 | 26 | 27 | 26 | 28 | 29 | 35 | 38 | 39 |
| | M14x1.5 | 10 | 26 | 28 | 29 | 35 | 38 | 39 | 33 | 35 | 36 | 45 | 47 | 49 |
| | M16x1.5 | 12 | 30 | 32 | 33 | 40 | 43 | 45 | 41 | 43 | 45 | 55 | 58 | 61 |
| | M18x1.5 | 15 | 33 | 35 | 36 | 45 | 47 | 49 | 52 | 55 | 57 | 70 | 75 | 77 |
| | M20x1.5 | -- | -- | -- | -- | -- | -- | -- | 59 | 62 | 65 | 80 | 84 | 88 |
| | M22x1.5 | 18 | 44 | 46 | 48 | 60 | 62 | 65 | 74 | 78 | 81 | 100 | 106 | 110 |
| | M27x2 | 22 | 74 | 78 | 81 | 100 | 106 | 110 | 125 | 132 | 138 | 170 | 179 | 187 |
| | M30x2 | -- | 95 | 100 | 105 | 130 | 136 | 142 | 175 | 184 | 193 | 237 | 249 | 262 |
| | M33x2 | 25 | 120 | 126 | 132 | 160 | 171 | 179 | 230 | 242 | 253 | 310 | 328 | 343 |
| M38x2 | -- | 135 | 142 | 149 | 183 | 193 | 202 | 235 | 247 | 259 | 319 | 335 | 351 | |
| M42x2 | 30 | 155 | 163 | 171 | 210 | 221 | 232 | 245 | 258 | 270 | 330 | 350 | 366 | |
| M48x2 | 38 | 190 | 200 | 209 | 260 | 271 | 283 | 310 | 326 | 341 | 420 | 442 | 462 | |
| M60x2 | 50 | 230 | 242 | 253 | 315 | 328 | 343 | 370 | 389 | 407 | 500 | 527 | 552 | |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | M8x1 | 4 | 4 | 5 | 5 | 5 | 7 | 7 | 5 | 6 | 6 | 7 | 8 | 8 |
| | M10x1 | 6 | 7 | 8 | 8 | 9 | 11 | 11 | 10 | 11 | 11 | 14 | 15 | 15 |
| | M12x1.5 | 8 | 12 | 13 | 13 | 16 | 18 | 18 | 17 | 18 | 19 | 23 | 24 | 26 |
| | M14x1.5 | 10 | 17 | 18 | 19 | 23 | 24 | 26 | 21 | 22 | 23 | 28 | 30 | 31 |
| | M16x1.5 | 12 | 20 | 21 | 21 | 27 | 28 | 28 | 27 | 28 | 29 | 37 | 38 | 39 |
| | M18x1.5 | 15 | 21 | 22 | 23 | 28 | 30 | 31 | 34 | 36 | 37 | 46 | 49 | 50 |
| | M20x1.5 | -- | -- | -- | -- | -- | -- | -- | 30 | 40 | 42 | 41 | 54 | 57 |
| | M22x1.5 | 18 | 29 | 30 | 31 | 39 | 41 | 42 | 48 | 51 | 53 | 65 | 69 | 72 |
| | M27x2 | 22 | 48 | 51 | 53 | 65 | 69 | 72 | 81 | 86 | 90 | 110 | 117 | 122 |
| | M30x2 | -- | 62 | 65 | 68 | 84 | 88 | 92 | 114 | 120 | 125 | 155 | 163 | 169 |
| | M33x2 | 25 | 78 | 82 | 86 | 106 | 111 | 117 | 150 | 157 | 164 | 203 | 213 | 222 |
| | M38x2 | -- | 88 | 93 | 97 | 119 | 126 | 132 | 153 | 161 | 168 | 207 | 218 | 228 |
| | M42x2 | 30 | 101 | 106 | 111 | 137 | 144 | 150 | 159 | 168 | 176 | 216 | 228 | 239 |
| M48x2 | 38 | 124 | 130 | 136 | 168 | 176 | 184 | 202 | 212 | 222 | 274 | 287 | 301 | |
| M60x2 | 50 | 150 | 157 | 164 | 203 | 213 | 222 | 241 | 253 | 265 | 327 | 343 | 359 | |

Assembly instructions for Adjustable Port End (BSPP) Fittings

1. Inspect components to ensure that male and female threads and surfaces are free of rust, splits, dirt, foreign matter, or burrs.
2. If O-ring is not pre-installed, install proper size, taking care not to damage it. See O-ring Installation (Replacement) for instructions.

⚠ CAUTION

CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. For Non-Adjustable Fittings and Plugs, thread the fitting by hand until contact.
5. For Adjustable fittings, refer to Adjustable Stud End Assembly for proper assembly.

6. Torque the fitting or nut to value listed in Table 5-25, Table 5-26, Table 5-27, British Standard Parallel Pipe Port (BSPP) - L Series and Table 5-28, Table 5-29, Table 5-30, British Standard Parallel Pipe Port (BSPP) - S Series while using the Double Wrench Method.

NOTE: *The table headings identify the BSPP port and the type on the other side of the fitting. The torque will be applied to the BSPP port.*

NOTE: *Torque values provided in Table 5-25, Table 5-26, Table 5-27, British Standard Parallel Pipe Port (BSPP) - L Series and Table 5-28, Table 5-29, Table 5-30, British Standard Parallel Pipe Port (BSPP) - S Series are segregated based on the material configuration of the connection.*

'ALUMINUM/BRASS FITTINGS' OR 'ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- a. STEEL fittings with ALUMINUM or BRASS mating components.
- b. ALUMINUM or BRASS fittings with STEEL mating components.
- c. ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

7. Inspect to ensure the O-ring is not pinched and the washer is seated flat on the counterbore of the port.

Table 5-25. British Standard Parallel Pipe Port (BSPP) - L Series - Table 1 of 3

| TYPE/FITTING IDENTIFICATION | | | FORM A** (SEALING WASHER) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | | FORM B** (CUTTING FACE) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | |
|--|--------------------|----------------------|--|-----|-----|-------|-----|-----|--|-----|-----|-------|-----|-----|
| MATERIAL | BSPP Thread G Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | (metric) | (mm) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | G1/8A | 6 | 7 | 8 | 8 | 9 | 11 | 11 | 13 | 14 | 14 | 18 | 19 | 19 |
| | G1/4A | 8 | 26 | 28 | 29 | 35 | 38 | 39 | 26 | 28 | 29 | 35 | 38 | 39 |
| | G1/4A | 10 | 26 | 28 | 29 | 35 | 38 | 39 | 26 | 28 | 29 | 35 | 38 | 39 |
| | G3/8A | 12 | 33 | 35 | 36 | 45 | 47 | 49 | 52 | 55 | 57 | 70 | 75 | 77 |
| | G1/2A | 15 | 48 | 51 | 53 | 65 | 69 | 72 | 103 | 108 | 113 | 140 | 146 | 153 |
| | G1/2A | 18 | 48 | 51 | 53 | 65 | 69 | 72 | 74 | 78 | 81 | 100 | 106 | 110 |
| | G3/4A | 22 | 66 | 70 | 73 | 90 | 95 | 99 | 133 | 140 | 146 | 180 | 190 | 198 |
| | G1A | 28 | 111 | 117 | 122 | 150 | 159 | 165 | 243 | 255 | 267 | 330 | 346 | 362 |
| | G1-1/4A | 35 | 177 | 186 | 195 | 240 | 252 | 264 | 398 | 418 | 438 | 540 | 567 | 594 |
| | G1-1/2A | 42 | 214 | 225 | 235 | 290 | 305 | 319 | 465 | 489 | 512 | 630 | 663 | 694 |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | G1/8A | 6 | 4 | 5 | 5 | 5 | 7 | 7 | 8 | 9 | 9 | 11 | 12 | 12 |
| | G1/4A | 8 | 17 | 18 | 19 | 23 | 24 | 26 | 17 | 18 | 19 | 23 | 24 | 26 |
| | G1/4A | 10 | 17 | 18 | 19 | 23 | 24 | 26 | 17 | 18 | 19 | 23 | 24 | 26 |
| | G3/8A | 12 | 21 | 22 | 23 | 28 | 30 | 31 | 34 | 36 | 37 | 46 | 49 | 50 |
| | G1/2A | 15 | 31 | 33 | 34 | 42 | 45 | 46 | 67 | 70 | 73 | 91 | 95 | 99 |
| | G1/2A | 18 | 31 | 33 | 34 | 42 | 45 | 46 | 48 | 51 | 53 | 65 | 69 | 72 |
| | G3/4A | 22 | 42 | 45 | 47 | 57 | 61 | 64 | 86 | 91 | 95 | 117 | 123 | 129 |
| | G1A | 28 | 72 | 76 | 79 | 98 | 103 | 107 | 158 | 166 | 174 | 214 | 225 | 236 |
| | G1-1/4A | 35 | 115 | 121 | 127 | 156 | 164 | 172 | 259 | 272 | 285 | 351 | 369 | 386 |
| | G1-1/2A | 42 | 139 | 146 | 153 | 188 | 198 | 207 | 302 | 318 | 333 | 409 | 431 | 451 |

* Typical for JLG Straight Male Stud Fittings.
 ** Non typical for JLG Straight Male Stud Fittings, reference only.
 *** Typical for JLG Adjustable Fittings.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS




Table 5-26. British Standard Parallel Pipe Port (BSPP) - L Series - Table 2 of 3

| TYPE/FITTING IDENTIFICATION | | | FORM E* (EOLASTIC SEALING RING) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | | FORM G/H*** (O-RING W/ RETAINING RING) STUD ENDS & ADJUSTABLE STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end | | | | | | | |
|--|--------------------|----------------------|---|-----|-----|-------|-----|-----|---|-----|-----|--------|-----|-----|--|--|
| MATERIAL | BSPP Thread G Size | Connecting Tube O.D. | Torque | | | | | | | | | Torque | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | | | |
| | (metric) | (mm) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | | |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | G1/8A | 6 | 13 | 14 | 14 | 18 | 19 | 19 | 13 | 14 | 14 | 18 | 19 | 19 | | |
| | G1/4A | 8 | 26 | 28 | 29 | 35 | 38 | 39 | 26 | 28 | 29 | 35 | 38 | 39 | | |
| | G1/4A | 10 | 26 | 28 | 29 | 35 | 38 | 39 | 26 | 28 | 29 | 35 | 38 | 39 | | |
| | G3/8A | 12 | 52 | 55 | 57 | 70 | 75 | 77 | 52 | 55 | 57 | 70 | 75 | 77 | | |
| | G1/2A | 15 | 66 | 70 | 73 | 90 | 95 | 99 | 66 | 70 | 73 | 90 | 95 | 99 | | |
| | G1/2A | 18 | 66 | 70 | 73 | 90 | 95 | 99 | 66 | 70 | 73 | 90 | 95 | 99 | | |
| | G3/4A | 22 | 133 | 140 | 146 | 180 | 190 | 198 | 133 | 140 | 146 | 180 | 190 | 198 | | |
| | G1A | 28 | 229 | 241 | 252 | 310 | 327 | 342 | 229 | 241 | 252 | 310 | 327 | 342 | | |
| | G1-1/4A | 35 | 332 | 349 | 365 | 450 | 473 | 495 | 332 | 349 | 365 | 450 | 473 | 495 | | |
| | G1-1/2A | 42 | 398 | 418 | 438 | 540 | 567 | 594 | 398 | 418 | 438 | 540 | 567 | 594 | | |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | G1/8A | 6 | 8 | 9 | 9 | 11 | 12 | 12 | 8 | 9 | 9 | 11 | 12 | 12 | | |
| | G1/4A | 8 | 17 | 18 | 19 | 23 | 24 | 26 | 17 | 18 | 19 | 23 | 24 | 26 | | |
| | G1/4A | 10 | 17 | 18 | 19 | 23 | 24 | 26 | 17 | 18 | 19 | 23 | 24 | 26 | | |
| | G3/8A | 12 | 34 | 36 | 37 | 46 | 49 | 50 | 34 | 36 | 37 | 46 | 49 | 50 | | |
| | G1/2A | 15 | 43 | 45 | 47 | 58 | 61 | 64 | 43 | 45 | 47 | 58 | 61 | 64 | | |
| | G1/2A | 18 | 43 | 45 | 47 | 58 | 61 | 64 | 43 | 45 | 47 | 58 | 61 | 64 | | |
| | G3/4A | 22 | 86 | 91 | 95 | 117 | 123 | 129 | 86 | 91 | 95 | 117 | 123 | 129 | | |
| | G1A | 28 | 149 | 157 | 164 | 202 | 213 | 222 | 149 | 157 | 164 | 202 | 213 | 222 | | |
| | G1-1/4A | 35 | 216 | 227 | 237 | 293 | 308 | 321 | 216 | 227 | 237 | 293 | 308 | 321 | | |
| | G1-1/2A | 42 | 259 | 272 | 285 | 351 | 369 | 386 | 259 | 272 | 285 | 351 | 369 | 386 | | |

*Typical for JLG Straight Male Stud Fittings.
 ** Non typical for JLG Straight Male Stud Fittings, reference only.
 ***Typical for JLG Adjustable Fittings.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-27. British Standard Parallel Pipe Port (BSPP) - L Series - Table 3 of 3

| | | |  | | | | | |  | | | | | |  | | | | | |
|---|--------------------------|-------------------------|---|-----|-----|-------|-----|-----|--|-----|-----|-------|-----|-----|---|-------|-----|-------|-----|-----|
| TYPE/FITTING IDENTIFICATION | | | BANJO FITTINGS with L series DIN (MBTL) opposite end | | | | | | HIGH PRESSURE BANJO FITTINGS with L series DIN (MBTL) opposite end | | | | | | FORM E (EOLASTIC SEALING RING) HOLLOW HEX PLUGS | | | | | |
| MATERIAL | BSPP Thread G Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | (metric) | (mm) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | G 1/8A | 6 | 13 | 14 | 14 | 18 | 19 | 19 | 13 | 14 | 14 | 18 | 19 | 19 | 10 | 11 | 11 | 13 | 15 | 15 |
| | G 1/4A | 8 | 30 | 32 | 33 | 40 | 43 | 45 | 33 | 35 | 36 | 45 | 47 | 49 | 22 | 23 | 24 | 30 | 31 | 33 |
| | G 1/4A | 10 | 30 | 32 | 33 | 40 | 43 | 45 | 33 | 35 | 36 | 45 | 47 | 49 | 22 | 23 | 24 | 30 | 31 | 33 |
| | G 3/8A | 12 | 48 | 51 | 53 | 65 | 69 | 72 | 52 | 55 | 57 | 70 | 75 | 77 | 44 | 46 | 48 | 60 | 62 | 65 |
| | G 1/2A | 15 | 66 | 70 | 73 | 90 | 95 | 99 | 89 | 94 | 98 | 120 | 127 | 133 | 59 | 62 | 65 | 80 | 84 | 88 |
| | G 1/2A | 18 | 66 | 70 | 73 | 90 | 95 | 99 | 89 | 94 | 98 | 120 | 127 | 133 | 59 | 62 | 65 | 80 | 84 | 88 |
| | G 3/4A | 22 | 92 | 97 | 101 | 125 | 132 | 137 | 170 | 179 | 187 | 230 | 243 | 254 | 103 | 108 | 113 | 140 | 146 | 153 |
| | G 1A | 28 | -- | -- | -- | -- | -- | -- | 236 | 248 | 260 | 320 | 336 | 353 | 148 | 156 | 163 | 200 | 212 | 221 |
| | G 1-1/4A | 35 | -- | -- | -- | -- | -- | -- | 398 | 418 | 438 | 540 | 567 | 594 | 295 | 313.5 | 332 | 400 | 425 | 450 |
| | G 1-1/2A | 42 | -- | -- | -- | -- | -- | -- | 516 | 542 | 568 | 700 | 735 | 770 | 332 | 349 | 365 | 450 | 473 | 495 |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | G 1/8A | 6 | 8 | 9 | 9 | 11 | 12 | 12 | 8 | 9 | 9 | 11 | 12 | 12 | 6 | 7 | 7 | 8 | 9 | 9 |
| | G 1/4A | 8 | 20 | 21 | 21 | 27 | 28 | 28 | 21 | 22 | 23 | 28 | 30 | 31 | 14 | 15 | 16 | 19 | 20 | 22 |
| | G 1/4A | 10 | 20 | 21 | 21 | 27 | 28 | 28 | 21 | 22 | 23 | 28 | 30 | 31 | 14 | 15 | 16 | 19 | 20 | 22 |
| | G 3/8A | 12 | 31 | 33 | 34 | 42 | 45 | 46 | 34 | 36 | 37 | 46 | 49 | 50 | 29 | 30 | 31 | 39 | 41 | 42 |
| | G 1/2A | 15 | 43 | 45 | 47 | 58 | 61 | 64 | 58 | 61 | 64 | 79 | 83 | 87 | 38 | 40 | 42 | 52 | 54 | 57 |
| | G 1/2A | 18 | 43 | 45 | 47 | 58 | 61 | 64 | 58 | 61 | 64 | 79 | 83 | 87 | 38 | 40 | 42 | 52 | 54 | 57 |
| | G 3/4A | 22 | 60 | 63 | 66 | 81 | 85 | 89 | 111 | 117 | 122 | 150 | 159 | 165 | 67 | 70 | 73 | 91 | 95 | 99 |
| | G 1A | 28 | -- | -- | -- | -- | -- | -- | 153 | 161 | 169 | 207 | 218 | 229 | 96 | 101 | 106 | 130 | 137 | 144 |
| | G 1-1/4A | 35 | -- | -- | -- | -- | -- | -- | 259 | 272 | 285 | 351 | 369 | 386 | 216 | 227 | 237 | 293 | 308 | 321 |
| | G 1-1/2A | 42 | -- | -- | -- | -- | -- | -- | 335 | 352 | 369 | 454 | 477 | 500 | 216 | 227 | 237 | 293 | 308 | 321 |

*Typical for JLG Straight Male Stud Fittings.
 ** Non typical for JLG Straight Male Stud Fittings, reference only.
 *** Typical for JLG Adjustable Fittings.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-28. British Standard Parallel Pipe Port (BSPP) - S Series - Table 1 of 3

| TYPE/FITTING IDENTIFICATION | | | FORM A** (SEALING WASHER) STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end | | | | | | FORM B** (CUTTING FACE) STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end | | | | | |
|--|--------------------|----------------------|---|-----|-----|-------|-----|-----|---|-----|-----|-------|-----|-----|
| MATERIAL | BSPP Thread G Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | (metric) | (mm) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | G1/4A | 6 | 26 | 28 | 29 | 35 | 38 | 39 | 41 | 43 | 45 | 55 | 58 | 61 |
| | G1/4A | 8 | 26 | 28 | 29 | 35 | 38 | 39 | 41 | 43 | 45 | 55 | 58 | 61 |
| | G3/8A | 10 | 33 | 35 | 36 | 45 | 47 | 49 | 66 | 70 | 73 | 90 | 95 | 99 |
| | G3/8A | 12 | 33 | 35 | 36 | 45 | 47 | 49 | 66 | 70 | 73 | 90 | 95 | 99 |
| | G1/2A | 14 | 48 | 51 | 53 | 65 | 69 | 72 | 111 | 117 | 122 | 150 | 159 | 165 |
| | G1/2A | 16 | 48 | 51 | 53 | 65 | 69 | 72 | 96 | 101 | 106 | 130 | 137 | 144 |
| | G3/4A | 20 | 66 | 70 | 73 | 90 | 95 | 99 | 199 | 209 | 219 | 270 | 283 | 297 |
| | G1A | 25 | 111 | 117 | 122 | 150 | 159 | 165 | 251 | 264 | 276 | 340 | 358 | 374 |
| | G1-1/4A | 30 | 177 | 186 | 195 | 240 | 252 | 264 | 398 | 418 | 438 | 540 | 567 | 594 |
| | G1-1/2A | 38 | 214 | 225 | 235 | 290 | 305 | 319 | 516 | 542 | 568 | 700 | 735 | 770 |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | G1/4A | 6 | 17 | 18 | 19 | 23 | 24 | 26 | 27 | 28 | 29 | 37 | 38 | 39 |
| | G1/4A | 8 | 17 | 18 | 19 | 23 | 24 | 26 | 27 | 28 | 29 | 37 | 38 | 39 |
| | G3/8A | 10 | 21 | 22 | 23 | 28 | 30 | 31 | 43 | 45 | 47 | 58 | 61 | 64 |
| | G3/8A | 12 | 21 | 22 | 23 | 28 | 30 | 31 | 43 | 45 | 47 | 58 | 61 | 64 |
| | G1/2A | 14 | 31 | 33 | 34 | 42 | 45 | 46 | 72 | 76 | 79 | 98 | 103 | 107 |
| | G1/2A | 16 | 31 | 33 | 34 | 42 | 45 | 46 | 62 | 66 | 69 | 84 | 89 | 94 |
| | G3/4A | 20 | 43 | 45 | 47 | 58 | 61 | 64 | 129 | 136 | 142 | 175 | 184 | 193 |
| | G1A | 25 | 72 | 76 | 79 | 98 | 103 | 107 | 163 | 171 | 179 | 221 | 232 | 243 |
| | G1-1/4A | 30 | 115 | 121 | 127 | 156 | 164 | 172 | 259 | 272 | 285 | 351 | 369 | 386 |
| | G1-1/2A | 38 | 139 | 146 | 153 | 188 | 198 | 207 | 335 | 352 | 369 | 454 | 477 | 500 |

*Typical for JLG Straight Male Stud Fittings.
 ** Non typical for JLG Straight Male Stud Fittings, reference only.
 ***Typical for JLG Adjustable Fittings.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-29. British Standard Parallel Pipe Port (BSPP) - S Series - Table 2 of 3

| TYPE/FITTING IDENTIFICATION | | | FORM E* (EOLASTIC SEALING RING) STUD ENDS AND HEX TYPE PLUGS with (ORFS) or S series DIN (MBTS) opposite end | | | | | | FORM G/H*** (O-RING W/ RETAINING RING) STUD ENDS & ADJUSTABLE STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end | | | | | |
|--|--------------------|----------------------|--|-----|-----|-------|-----|-----|---|-----|-----|-------|-----|-----|
| MATERIAL | BSPP Thread G Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | (metric) | (mm) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | G1/4A | 6 | 41 | 43 | 45 | 55 | 58 | 61 | 26 | 28 | 29 | 35 | 38 | 39 |
| | G1/4A | 8 | 41 | 43 | 45 | 55 | 58 | 61 | 26 | 28 | 29 | 35 | 38 | 39 |
| | G3/8A | 10 | 59 | 62 | 65 | 80 | 84 | 88 | 52 | 55 | 57 | 70 | 75 | 77 |
| | G3/8A | 12 | 59 | 62 | 65 | 80 | 84 | 88 | 52 | 55 | 57 | 70 | 75 | 77 |
| | G1/2A | 14 | 85 | 90 | 94 | 115 | 122 | 127 | 66 | 70 | 73 | 90 | 95 | 99 |
| | G1/2A | 16 | 85 | 90 | 94 | 115 | 122 | 127 | 66 | 70 | 73 | 90 | 95 | 99 |
| | G3/4A | 20 | 133 | 140 | 146 | 180 | 190 | 198 | 133 | 140 | 146 | 180 | 190 | 198 |
| | G1A | 25 | 229 | 241 | 252 | 310 | 327 | 342 | 229 | 241 | 252 | 310 | 327 | 342 |
| | G1-1/4A | 30 | 332 | 349 | 365 | 450 | 473 | 495 | 332 | 349 | 365 | 450 | 473 | 495 |
| | G1-1/2A | 38 | 398 | 418 | 438 | 540 | 567 | 594 | 398 | 418 | 438 | 540 | 567 | 594 |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | G1/4A | 6 | 27 | 28 | 29 | 37 | 38 | 39 | 17 | 18 | 19 | 23 | 24 | 26 |
| | G1/4A | 8 | 27 | 28 | 29 | 37 | 38 | 39 | 17 | 18 | 19 | 23 | 24 | 26 |
| | G3/8A | 10 | 38 | 40 | 42 | 52 | 54 | 57 | 34 | 36 | 37 | 46 | 49 | 50 |
| | G3/8A | 12 | 38 | 40 | 42 | 52 | 54 | 57 | 34 | 36 | 37 | 46 | 49 | 50 |
| | G1/2A | 14 | 55 | 58 | 61 | 75 | 79 | 83 | 43 | 45 | 47 | 58 | 61 | 64 |
| | G1/2A | 16 | 55 | 58 | 61 | 75 | 79 | 83 | 43 | 45 | 47 | 58 | 61 | 64 |
| | G3/4A | 20 | 86 | 91 | 95 | 117 | 123 | 129 | 86 | 91 | 95 | 117 | 123 | 129 |
| | G1A | 25 | 149 | 157 | 164 | 202 | 213 | 222 | 149 | 157 | 164 | 202 | 213 | 222 |
| | G1-1/4A | 30 | 216 | 227 | 237 | 293 | 308 | 321 | 216 | 227 | 237 | 293 | 308 | 321 |
| | G1-1/2A | 38 | 259 | 272 | 285 | 351 | 369 | 386 | 259 | 272 | 285 | 351 | 369 | 386 |

* Typical for JLG Straight Male Stud Fittings.
 ** Non typical for JLG Straight Male Stud Fittings, reference only.
 *** Typical for JLG Adjustable Fittings.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-30. British Standard Parallel Pipe Port (BSPP) - S Series - Table 3 of 3

| TYPE/FITTING IDENTIFICATION | | | BANJO FITTINGS with S series DIN (MBTS) opposite end | | | | | | HIGH PRESSURE BANJO FITTINGS with S series DIN (MBTS) opposite end | | | | | | JIS/BSPP O-RING ONLY | | | | | |
|---|--------------------------|-------------------------|---|-----|-----|-------|-----|-----|---|-----|-----|-------|-----|-----|---|-----|-----|-------|-----|-----|
| MATERIAL | BSPP Thread G Size | Connecting Tube O.D. | Torque | | | | | | Torque | | | | | | Torque | | | | | |
| | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | | | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS | G 1/4A | 6 | 30 | 32 | 33 | 40 | 43 | 45 | 33 | 35 | 36 | 45 | 47 | 49 | Fitting type not typically specified on JLG applications. Refer to the specific procedure in this Service Manual. | | | | | |
| | G 1/4A | 8 | 30 | 32 | 33 | 40 | 43 | 45 | 33 | 35 | 36 | 45 | 47 | 49 | | | | | | |
| | G 3/8A | 10 | 48 | 51 | 53 | 65 | 69 | 72 | 52 | 55 | 57 | 70 | 75 | 77 | | | | | | |
| | G 3/8A | 12 | 48 | 51 | 53 | 65 | 69 | 72 | 52 | 55 | 57 | 70 | 75 | 77 | | | | | | |
| | G 1/2A | 14 | 66 | 70 | 73 | 90 | 95 | 99 | 89 | 94 | 98 | 120 | 127 | 133 | | | | | | |
| | G 1/2A | 16 | 66 | 70 | 73 | 90 | 95 | 99 | 89 | 94 | 98 | 120 | 127 | 133 | | | | | | |
| | G 3/4A | 20 | 92 | 97 | 101 | 125 | 132 | 137 | 170 | 179 | 187 | 230 | 243 | 254 | | | | | | |
| | G 1A | 25 | -- | -- | -- | -- | -- | -- | 236 | 248 | 260 | 320 | 336 | 353 | | | | | | |
| | G 1-1/4A | 30 | -- | -- | -- | -- | -- | -- | 398 | 418 | 438 | 540 | 567 | 594 | | | | | | |
| G 1-1/2A | 38 | -- | -- | -- | -- | -- | -- | 516 | 542 | 568 | 700 | 735 | 770 | | | | | | | |
| ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS | G 1/4A | 6 | 20 | 21 | 21 | 27 | 28 | 28 | 22 | 22 | 23 | 30 | 30 | 31 | Fitting type not typically specified on JLG applications. Refer to the specific procedure in this Service Manual. | | | | | |
| | G 1/4A | 8 | 20 | 21 | 21 | 27 | 28 | 28 | 22 | 22 | 23 | 30 | 30 | 31 | | | | | | |
| | G 3/8A | 10 | 31 | 33 | 34 | 42 | 45 | 46 | 34 | 36 | 37 | 46 | 49 | 50 | | | | | | |
| | G 3/8A | 12 | 31 | 33 | 34 | 42 | 45 | 46 | 34 | 36 | 37 | 46 | 49 | 50 | | | | | | |
| | G 1/2A | 14 | 43 | 45 | 47 | 58 | 61 | 64 | 58 | 61 | 64 | 79 | 83 | 87 | | | | | | |
| | G 1/2A | 16 | 43 | 45 | 47 | 58 | 61 | 64 | 58 | 61 | 64 | 79 | 83 | 87 | | | | | | |
| | G 3/4A | 20 | 60 | 63 | 66 | 81 | 85 | 89 | 111 | 117 | 122 | 150 | 159 | 165 | | | | | | |
| | G 1A | 25 | -- | -- | -- | -- | -- | -- | 153 | 161 | 169 | 207 | 218 | 229 | | | | | | |
| | G 1-1/4A | 30 | -- | -- | -- | -- | -- | -- | 259 | 272 | 285 | 351 | 369 | 386 | | | | | | |
| G 1-1/2A | 38 | -- | -- | -- | -- | -- | -- | 335 | 352 | 368 | 454 | 477 | 499 | | | | | | | |

Note: BSPP O-ring only style (ISO 228-1) requires o-ring chamfer in the port, similar to ISO 11926 (SAE ORB), but is not interchangeable. Not typically used on JLG machines.

* Typical for JLG Straight Male Stud Fittings.
 ** Non typical for JLG Straight Male Stud Fittings, reference only.
 *** Typical for JLG Adjustable Fittings.


**Assembly Instructions for Flange Connections:
(FL61 and FL62)**

1. Make sure sealing surfaces are free of rust, splits, scratches, dirt, foreign matter, or burrs.
2. See O-ring Installation (Replacement) for O-ring installation instructions.
3. Pre-lubricate the O-ring with Hydraulic Oil.
4. Position flange and clamp halves.
5. Place lock washers on bolt and bolt through clamp halves.
6. Tighten all bolts by hand.
7. Torque bolts in diagonal sequence in two or more increments to the torque listed on Table 5-31, Flange Code (FL61 & FL62) - Inch Fasteners and Table 5-32, Flange Code (FL61 & FL62) - Metric Fasteners.

Go to Discount-Equipment.com to order your parts

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-31. Flange Code (FL61 & FL62) -Inch Fasteners

| | |  | | | | | | | | | | | | | | | | |
|-----------------------------|---------------------------|--|------|--------|--------|--|--|-----|-----|-------|-----|-----|--|-----|-----|-------|-----|-----|
| TYPE/FITTING IDENTIFICATION | | | | | | STEEL 4-BOLT FLANGE SAE J518 (INCH FASTENERS) | | | | | | | | | | | | |
| TYPE | Inch Flange SAE Dash Size | Flange Size | | A* | | Bolt Thread Size | Fastener Torque for Flanges Equipped with GRADE 5 Screws | | | | | | Fastener Torque for Flanges Equipped with GRADE 8 Screws | | | | | |
| | | (in) | (mm) | (in) | (mm) | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | | | | | | | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| CODE 61 SPLIT FLANGE (FL61) | 8 | 0.50 | 13 | 1.50 | 38.10 | 5/16-18 | 18 | 19 | 19 | 24 | 25 | 26 | 24 | 25 | 26 | 32 | 34 | 35 |
| | 12 | 0.75 | 19 | 1.88 | 47.75 | 3/8-16 | 32 | 33 | 35 | 43 | 45 | 47 | 44 | 46 | 49 | 60 | 63 | 66 |
| | 16 | 1.00 | 25 | 2.06 | 52.32 | 3/8-16 | 32 | 33 | 35 | 43 | 45 | 47 | 44 | 46 | 49 | 60 | 63 | 66 |
| | 20 | 1.25 | 32 | 2.31 | 58.67 | 7/16-14 | 52 | 54 | 57 | 70 | 74 | 77 | 68 | 71 | 75 | 92 | 97 | 101 |
| | 24 | 1.50 | 38 | 2.75 | 69.85 | 1/2-13 | 77 | 81 | 85 | 105 | 110 | 116 | 111 | 116 | 122 | 150 | 158 | 165 |
| | 32 | 2.00 | 51 | 3.06 | 77.72 | 1/2-13 | 77 | 81 | 85 | 105 | 110 | 116 | 111 | 116 | 122 | 150 | 158 | 165 |
| | 40 | 2.50 | 64 | 3.50 | 88.90 | 1/2-13 | 77 | 81 | 85 | 105 | 110 | 116 | 111 | 116 | 122 | 150 | 158 | 165 |
| | 48 | 3.00 | 76 | 4.19 | 106.43 | 5/8-11 | 155 | 163 | 170 | 210 | 221 | 231 | 218 | 228 | 239 | 295 | 310 | 325 |
| | 56 | 3.50 | 89 | 4.75 | 120.65 | 5/8-11 | 155 | 163 | 170 | 210 | 221 | 231 | 218 | 228 | 239 | 295 | 310 | 325 |
| | 64 | 4.00 | 102 | 5.13 | 130.30 | 5/8-11 | 155 | 163 | 170 | 210 | 221 | 231 | 218 | 228 | 239 | 295 | 310 | 325 |
| 80 | 5.00 | 127 | 6.00 | 152.40 | 5/8-11 | 155 | 163 | 170 | 210 | 221 | 231 | 218 | 228 | 239 | 295 | 310 | 325 | |
| CODE 62 SPLIT FLANGE (FL62) | 8 | 0.50 | 13 | 1.59 | 40.39 | 5/16-18 | -- | -- | -- | -- | -- | -- | 24 | 25 | 26 | 32 | 34 | 35 |
| | 12 | 0.75 | 19 | 2.00 | 50.80 | 3/8-16 | -- | -- | -- | -- | -- | -- | 44 | 46 | 49 | 60 | 63 | 66 |
| | 16 | 1.00 | 25 | 2.25 | 57.15 | 7/16-14 | -- | -- | -- | -- | -- | -- | 68 | 71 | 75 | 92 | 97 | 101 |
| | 20 | 1.25 | 32 | 2.62 | 66.55 | 1/2-13 | -- | -- | -- | -- | -- | -- | 111 | 116 | 122 | 150 | 158 | 165 |
| | 20 | 1.25 | 32 | 2.62 | 66.55 | -- | -- | -- | -- | -- | -- | -- | -- | -- | -- | -- | -- | -- |
| | 24 | 1.50 | 38 | 3.12 | 79.25 | 5/8-11 | -- | -- | -- | -- | -- | -- | 218 | 228 | 239 | 295 | 310 | 325 |
| | 32 | 2.00 | 51 | 3.81 | 96.77 | 3/4-10 | -- | -- | -- | -- | -- | -- | 332 | 348 | 365 | 450 | 473 | 495 |

* A dimension for reference only.

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

Table 5-32. Flange Code (FL61 & FL62) - Metric Fasteners

| TYPE/FITTING IDENTIFICATION | | | | | | STEEL 4-BOLT FLANGE SAE J518 (INCH FASTENERS) | | | | | | | | | | | | |
|-----------------------------|---------------------------|-------------|------|--------|--------|--|--|-----|-----|-------|-----|-----|---|-----|-----|-------|-----|-----|
| TYPE | Inch Flange SAE Dash Size | Flange Size | | A* | | Bolt Thread Size (Metric) | Fastener Torque for Flanges Equipped with CLASS 8.8 Screws | | | | | | Fastener Torque for Flanges Equipped with CLASS 10.9 Screws | | | | | |
| | | (in) | (mm) | (in) | (mm) | | [Ft-Lb] | | | [N-m] | | | [Ft-Lb] | | | [N-m] | | |
| | | | | | | | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| CODE 61 SPLIT FLANGE (FL61) | 8 | 0.50 | 13 | 1.50 | 38.10 | (Metric) | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max | Min | Nom | Max |
| | 12 | 0.75 | 19 | 1.88 | 47.75 | M8x1.25 | 18 | 19 | 19 | 24 | 25 | 26 | 18 | 19 | 19 | 24 | 25 | 26 |
| | 16 | 1.00 | 25 | 2.06 | 52.32 | M10x1.5 | 37 | 39 | 41 | 50 | 53 | 55 | 37 | 39 | 41 | 50 | 53 | 55 |
| | 20 | 1.25 | 32 | 2.31 | 58.67 | M10x1.5 | 37 | 39 | 41 | 50 | 53 | 55 | 37 | 39 | 41 | 50 | 53 | 55 |
| | 24 | 1.50 | 38 | 2.75 | 69.85 | M10x1.5 | 37 | 39 | 41 | 50 | 53 | 55 | 37 | 39 | 41 | 50 | 53 | 55 |
| | 32 | 2.00 | 51 | 3.06 | 77.72 | M12x1.75 | 68 | 71 | 75 | 92 | 97 | 101 | 68 | 71 | 75 | 92 | 97 | 101 |
| | 40 | 2.50 | 64 | 3.50 | 88.90 | M12x1.75 | 68 | 71 | 75 | 92 | 97 | 101 | 68 | 71 | 75 | 92 | 97 | 101 |
| | 48 | 3.00 | 76 | 4.19 | 106.43 | M12x1.75 | 68 | 71 | 75 | 92 | 97 | 101 | 68 | 71 | 75 | 92 | 97 | 101 |
| | 56 | 3.50 | 89 | 4.75 | 120.65 | M16x2 | 155 | 163 | 170 | 210 | 221 | 231 | 155 | 163 | 170 | 210 | 221 | 231 |
| | 64 | 4.00 | 102 | 5.13 | 130.30 | M16x2 | 155 | 163 | 170 | 210 | 221 | 231 | 155 | 163 | 170 | 210 | 221 | 231 |
| 80 | 5.00 | 127 | 6.00 | 152.40 | M16x2 | 155 | 163 | 170 | 210 | 221 | 231 | 155 | 163 | 170 | 210 | 221 | 231 | |
| CODE 62 SPLIT FLANGE (FL62) | 8 | 0.50 | 13 | 1.59 | 40.39 | M8x1.25 | -- | -- | -- | -- | -- | -- | 24 | 25 | 26 | 32 | 34 | 35 |
| | 12 | 0.75 | 19 | 2.00 | 50.80 | M10x1.5 | -- | -- | -- | -- | -- | -- | 52 | 54 | 57 | 70 | 74 | 77 |
| | 16 | 1.00 | 25 | 2.25 | 57.15 | M12x1.75 | -- | -- | -- | -- | -- | -- | 96 | 101 | 105 | 130 | 137 | 143 |
| | 20 | 1.25 | 32 | 2.62 | 66.55 | M12x1.75 | -- | -- | -- | -- | -- | -- | 96 | 101 | 105 | 130 | 137 | 143 |
| | 20 | 1.25 | 32 | 2.62 | 66.55 | M14x2 | -- | -- | -- | -- | -- | -- | 133 | 139 | 146 | 180 | 189 | 198 |
| | 24 | 1.50 | 38 | 3.12 | 79.25 | M16x2 | -- | -- | -- | -- | -- | -- | 218 | 228 | 239 | 295 | 310 | 325 |
| | 32 | 2.00 | 51 | 3.81 | 96.77 | M20x2.5 | -- | -- | -- | -- | -- | -- | 406 | 426 | 446 | 550 | 578 | 605 |

* A dimension for reference only.

Double Wrench Method

To prevent undesired hose or connector rotation, two wrenches must be used; one torque wrench and one backup wrench. If two wrenches are not used, inadvertent component rotation may occur which absorbs torque and causes

improper joint load and leads to leaks. For hose connections, the 'layline' printed on the hose is a good indicator of proper hose installation. A twisted lay-line usually indicates the hose is twisted. See Figure 5-12. for double wrench method requirements.




Figure 5-12. Double Wrench Method

FFWR and TFFT Methods

FFWR (FLATS FROM WRENCH RESISTANCE METHOD)

1. Tighten the swivel nut to the mating fitting until no lateral movement of the swivel nut can be detected; finger tight condition.
2. Mark a dot on one of the swivel hex nut flats and another dot in line on the connecting tube adapter. See Figure 5-13.
3. Use the double wrench method, turn the swivel nut to tighten as shown in Figure 5-13. The nut is to be rotated clockwise the number of hex flats as defined by the applicable Table in Section 5.0.
4. After the connection has been properly tightened, mark a straight line across the connecting parts, not covering the dots, to indicate the connection has been properly tightened. See Figure 5-13.




Figure 5-13. FFWR Method

TFFT (TURNS FROM FINGER TIGHT METHOD)

1. Tighten the swivel nut to the mating fitting until no lateral movement of the swivel nut can be detected; finger tight condition.
2. Mark a dot on one of the swivel hex nut flats and another dot in line on the connecting tube adapter.
3. Use the double wrench method, turn the swivel nut to tighten. The nut is to be rotated clockwise the number of turns as defined by the applicable Table in Section 5.0.
4. After the connection has been properly tightened, mark a straight line across the connecting parts, not covering the dots, to indicate the connection has been properly tightened.

Adjustable Stud End Assembly

For Adjustable Stud End Connections; the following assembly steps are to be performed:

1. Lubricate the o-ring with a light coat of hydraulic oil.
2. Position #1 – The o-ring should be located in the groove adjacent to the face of the backup washer. The washer and o-ring should be positioned at the extreme top end of the groove as shown.
3. Position #2 – Position the locknut to just touch the backup washer as shown. The locknut in this position will eliminate potential backup washer damage during the next step.
4. Position #3 – Install the connector into the straight thread box port until the metal backup washer contacts the face of the port as shown.
5. Position #4 – Adjust the connector to the proper position by turning out (counterclockwise) up to a maximum of one turn as shown to provide proper alignment with the mating connector, tube assembly, or hose assembly.
6. Position #5 – Using two wrenches, use the backup wrench to hold the connector in the desired position and then use the torque wrench to tighten the locknut to the appropriate torque.
7. Visually inspect, where possible, the joint to ensure the o-ring is not pinched or bulging out from under the washer and that the backup washer is properly seated flat against the face of the port.





Figure 5-14. Adjustable Stud End Assembly

O-ring Installation (Replacement)

Care must be taken when installing O-rings over threads during replacement or installation. O-rings could become nicked or torn. A damaged O-ring could lead to leakage problems.

1. Inspect O-ring for tears or nicks. If any are found replace O-ring.
2. Ensure proper O-ring to be installed. Many O-rings look the same but are of different material, different hardness, or are slightly different diameters or widths.
3. Use a thread protector when replacing O-rings on fittings.
4. In ORB; ensure O-ring is properly seated in groove. On straight threads, ensure O-ring is seated all the way past the threads prior to installation.
5. Inspect O-ring for any visible nicks or tears. Replace if found.

Cylinder Locations



- 1. Main Lift Cylinder
- 2. Telescope Cylinder
- 3. Platform Level Cylinder
- 4. Jib Lift Cylinder

Figure 5-15. Hydraulic Cylinder Locations

Main Lift Cylinder

DISASSEMBLY

NOTE: Refer to Figure 5-19. Main Lift Cylinder.

NOTICE

CONTAMINATION MAY DAMAGE EQUIPMENT. DISASSEMBLE CYLINDER ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate hydraulic power source and extend cylinder. Shut down and disconnect power source. Adequately support cylinder rod, if applicable.
3. If applicable, remove cartridge-type counterbalance valve and fittings from cylinder port block. Discard O-rings.
4. Place cylinder barrel in a suitable holding fixture. Tap around outside of cylinder head retainer with a suitable hammer to break thread-locking compound.




Figure 5-16. Cylinder Barrel Support

5. Unscrew cylinder head collar (5) with pin-face spanner wrench.




Figure 5-17. Cylinder Head Removal

NOTICE

PULLING ROD OFF-CENTER CAN DAMAGE PISTON AND CYLINDER BARREL SURFACES. USE EXTREME CARE WHEN REMOVING CYLINDER ROD, HEAD, AND PISTON.

6. Clamp barrel securely. Pull rod assembly and cylinder head from barrel.
7. Protect cylinder rod from damage and clamp in a vise or holding fixture as close to piston as possible.





Figure 5-18. Cylinder Rod Support



1001250382-A
MAF23610A

- | | | | | |
|-----------|--------------------|--------------------|------------------|------------------|
| 1. Barrel | 7. Setscrew | 13. Solenoid Valve | 19. Bearing Ring | 25. O-Ring |
| 2. Rod | 8. Bushing | 14. Seal | 20. Seal | 26. Bearing Ring |
| 3. Head | 9. Solenoid Valve | 15. Spacer | 21. Bearing Ring | |
| 4. Piston | 10. Check Valve | 16. Retaining Ring | 22. Wiper | |
| 5. Collar | 11. Solenoid Valve | 17. O-Ring | 23. O-Ring | |
| 6. Ring | 12. Check Valve | 18. Backup Ring | 24. O-Ring | |

Figure 5-19. Main Lift Cylinder

NOTICE

REMOVE SEALS USING A BRASS OR PLASTIC PICK ONLY. DO NOT USE A KNIFE, SHARP OBJECT, OR SCREW DRIVER. NOTE SEAL ORIENTATION BEFORE REMOVING FOR PROPER INSTALLATION.

8. Loosen setscrew (7) in piston (4).
9. Screw piston counterclockwise and remove from rod.
10. Remove and discard O-ring (24), bearing rings (26) and seal (14).




Figure 5-20. Piston Disassembly

11. Remove rod from holding fixture.
12. Remove cylinder head assembly (3) from rod (2).
13. Remove and discard O-ring (17), backup ring (18), and O-ring (25) from cylinder head (3).

14. Remove and discard retaining ring (16), wiper (22), bearing ring (19), rod seal (20), and bearing ring (21) from cylinder head (3).




Figure 5-21. Cylinder Head Disassembly

CLEANING AND INSPECTION

1. Clean parts thoroughly with approved cleaning solvent.
2. Inspect cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect threaded portion of barrel for damage. Dress threads as necessary.
6. Inspect piston surface for damage, scoring, or distortion. Dress piston surface or replace piston as necessary.
7. Inspect threaded portion of piston for damage. Dress threads as necessary.
8. Inspect seal and O-ring grooves in piston for burrs and sharp edges. Dress surfaces as necessary.
9. Inspect cylinder head inside diameter for scoring or other damage, and for ovality and tapering. Replace as necessary.
10. Inspect threaded portion of head for damage. Dress threads as necessary.

11. Inspect seal and O-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
12. Inspect cylinder head outside diameter for scoring, damage, ovality, and tapering. Replace as necessary.
13. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of the steel bushing with WD40 prior to bearing installation.

NOTE: Lubrication is not required with nickel plated pins and bearings. Install pin in composite bushing dry.

- d. Press composite bushing into barrel or rod bushing with correct size arbor.




Figure 5-22. Composite Bushing Installation

14. Inspect travel limiting collar or spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
15. If applicable, inspect port block fittings and holding valve. Replace as necessary.
16. Inspect oil ports for blockage or presence of dirt or other foreign material. Repair as necessary.
17. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTICE

INCORRECT SEAL INSTALLATION CAN CAUSE CYLINDER LEAKS AND IMPROPER CYLINDER OPERATION. ENSURE ALL PISTON SEALS ARE CORRECTLY INSTALLED. REFER TO CROSS SECTION ILLUSTRATIONS FOR CORRECT SEAL ORIENTATION.

NOTE: Use proper cylinder seal kit for cylinder assembly. See your JLG Parts Manual.

Apply a light film of hydraulic oil to all components before assembly.

1. Support rod in holding fixture.
2. Install retaining ring (16), bearing ring (19), seal (20), and wiper (22) inside cylinder head (3).
3. Install O-ring (17), backup ring (18), and O-ring (19) on cylinder head.
4. Slide cylinder head assembly on rod (2) to rod end. Do not dislodge or damage seals.




Figure 5-23. Cylinder Head Assembly

5. Install two seals (14) and O-rings (24) on piston.
6. Apply Medium Strength Threadlocking Compound to piston threads. Install piston on rod. Torque to 1475 ft-lb (2000 Nm).
7. Install setscrew (7).




Figure 5-24. Piston Assembly

12. Apply anti-seize to cylinder head collar (5) threads. Screw in cylinder head. Torque to 1106 ft-lb (1500 Nm). Adjust cylinder head so screw hole is aligned between cylinder head and barrel. Secure cylinder head gland using washer ring and socket head bolts.




Figure 5-25. Cylinder Head Installation

8. Carefully install piston on cylinder rod. Do not damage or dislodge O-ring and backup rings.

NOTICE

INSERTING ROD OFF-CENTER CAN DAMAGE PISTON AND CYLINDER BARREL SURFACES. USE EXTREME CARE WHEN INSTALLING CYLINDER ROD, HEAD, AND PISTON.

9. Clamp barrel clamped securely and support rod. Insert piston end into barrel cylinder. Do not damage or dislodge piston loading O-ring and seal ring.
10. Remove cylinder rod from holding fixture.
11. Place cylinder barrel in suitable holding fixture.

Telescope Cylinder

DISASSEMBLY

NOTE: Refer to Figure 5-29. Telescope Cylinder.

NOTICE

CONTAMINATION MAY DAMAGE EQUIPMENT. DISASSEMBLE CYLINDER ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate hydraulic power source and extend cylinder. Shut down and disconnect power source. Adequately support cylinder rod, if applicable.
3. If applicable, remove cartridge-type counterbalance valve and fittings from cylinder port block. Discard O-rings.
4. Place cylinder barrel in a suitable holding fixture. Tap around outside of cylinder head retainer with a suitable hammer to break thread-locking compound.




Figure 5-26. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an Allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-27. Capscrew Removal

6. Attach a suitable pulling device to the cylinder rod end.

NOTICE

PULLING ROD OFF-CENTER CAN DAMAGE PISTON AND CYLINDER BARREL SURFACES. USE EXTREME CARE WHEN REMOVING CYLINDER ROD, HEAD, AND PISTON.

7. Clamp barrel securely. Pull rod assembly and cylinder head from barrel.
8. Protect cylinder rod from damage and clamp in a vise or holding fixture as close to piston as possible.





Figure 5-28. Cylinder Rod Support



- | | | | | | |
|-------------------|----------------|----------------|-----------------|-----------------|--------------------|
| 1. Barrel | 6. Rod Seal | 10A. Cartridge | 11. Backup Ring | 16. Backup Ring | 21. Capscrew |
| 2. Rod | 7. Backup Ring | 10B. Cartridge | 12. Piston | 17. O-ring | 22. Valve Assembly |
| 3. Head | 8. Buffer Ring | 10C. Cartridge | 13. Piston Seal | 18. Backup Ring | 23. Capscrew |
| 4. Wiper Seal | 9. Wear Ring | 10D. Seal | 14. Wear Ring | 19. Setscrew | 24. Plug |
| 5. Retaining Ring | 10. O-ring | 10E. Roll Pin | 15. O-ring | 20. Spacer | 25. Capscrew |
| | | | | | 26. Plug |

Figure 5-29. Telescope Cylinder

SECTION 5 - BASIC HYDRAULICS INFORMATION & SCHEMATICS

9. Using suitable protection, clamp cylinder rod in a vise or similar holding fixture as close to piston as possible.
10. Loosen and remove the setscrew (19) which is attached to the piston assembly.
11. Screw the piston (12) counterclockwise and remove the piston from cylinder rod (2).
12. Remove and discard o-ring (15) and backup ring (16) from inside of piston (12).
13. Remove and discard o-ring (17) and backup ring (18) from inside of piston (12).
14. Remove and discard piston seal (13) and wear ring (14) from outside grooves of piston (12).

NOTICE

REMOVE SEALS USING A BRASS OR PLASTIC PICK ONLY. DO NOT USE A KNIFE, SHARP OBJECT, OR SCREW DRIVER. MAKE NOTE OF SEAL ORIENTATION BEFORE REMOVING FOR PROPER INSTALLATION.




Figure 5-30. Piston Disassembly

15. Remove spacer (20) from rod (2).
16. Remove rod from holding fixture. Remove cylinder head gland.
17. Remove and discard wear ring (9) and wiper (4) from inside of cylinder head (3).
18. Remove and discard retaining ring (5), rod seal (6), backup ring (7) and buffer ring (8) from inside of cylinder head (3).

19. Remove and discard o-ring (10) and backup ring (11) from outside of cylinder head (3).




Figure 5-31. Cylinder Head Disassembly

CLEANING AND INSPECTION

1. Clean parts thoroughly with approved cleaning solvent.
2. Inspect cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect threaded portion of barrel for damage. Dress threads as necessary.
6. Inspect piston surface for damage, scoring, or distortion. Dress piston surface or replace piston as necessary.
7. Inspect threaded portion of piston for damage. Dress threads as necessary.
8. Inspect seal and O-ring grooves in piston for burrs and sharp edges. Dress surfaces as necessary.
9. Inspect cylinder head inside diameter for scoring or other damage, and for ovality and tapering. Replace as necessary.
10. Inspect threaded portion of head for damage. Dress threads as necessary.
11. Inspect seal and O-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
12. Inspect cylinder head outside diameter for scoring, damage, ovality, and tapering. Replace as necessary.

13. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of the steel bushing with WD40 prior to bearing installation.

NOTE: Lubrication is not required with nickel plated pins and bearings. Install pin in composite bushing dry.

- d. Press composite bushing into barrel or rod bushing with correct size arbor.




Figure 5-32. Composite Bushing Installation

14. Inspect travel limiting collar or spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
15. If applicable, inspect port block fittings and holding valve. Replace as necessary.
16. Inspect oil ports for blockage or presence of dirt or other foreign material. Repair as necessary.
17. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Use proper cylinder seal kit for cylinder assembly. See your JLG Parts Manual.

Apply a light film of hydraulic oil to all components before assembly.

NOTICE

IMPROPER SEAL INSTALLATION CAN CAUSE CYLINDER LEAKS AND IMPROPER CYLINDER OPERATION. WIPER SEAL ROUNDED SURFACE MUST FACE TOWARD PISTON AS NOTED DURING DISASSEMBLY.

1. Use seal tool to install new rod seal into applicable cylinder head gland groove.




Figure 5-33. Rod Seal Installation

2. Support rod in holding fixture.
3. Install rod seal (6), backup ring (7) and buffer ring (8) inside the cylinder head (3).
4. Install wear ring (9), wiper (4) and retaining ring (5) inside the cylinder head (3).
5. Install o-ring (10) and backup ring(11) on outside grooves of the cylinder head (3).




Figure 5-34. Cylinder Head Assembly

6. Slide cylinder head assembly on rod (2) to rod end. Do not dislodge or damage seals.
7. Carefully slide the spacer (20) onto rod (2).
8. Install o-ring (15) and backup ring (16) inside the piston (12).
9. Install o-ring (17) and backup ring (18) inside the piston (12).
10. Install Piston seal (13) and wear ring (14) on outside grooves of the piston (12).
11. Carefully thread piston (12) on cylinder rod (2) hand tight. Do not damaged or dislodge O-ring and backup rings.




Figure 5-35. Piston Assembly

11. Install setscrew (19) on the piston (12) and attach piston (12) to the rod (2).
12. Position cylinder barrel (1) in a suitable holding fixture.

NOTICE

INSERTING ROD OFF-CENTER CAN DAMAGE PISTON AND CYLINDER BARREL SURFACES. USE EXTREME CARE WHEN INSTALLING CYLINDER ROD, HEAD, AND PISTON.

13. Continue pushing rod in barrel until cylinder head (3) can be inserted into the barrel.
14. Secure the cylinder head gland using the washer ring and socket head bolts.
15. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the re-installation of any holding valve or valves.
16. Install the valve assembly, counterbalance valve if applicable.

Platform Level Cylinder

DISASSEMBLY

NOTE: Refer to Figure 5-39. Platform Level Cylinder.

NOTICE

CONTAMINATION MAY DAMAGE EQUIPMENT. DISASSEMBLE CYLINDER ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to cylinder port block fitting.

WARNING

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate hydraulic power source and extend cylinder. Shut down and disconnect power source. Adequately support cylinder rod, if applicable.
3. If applicable, remove cartridge-type counterbalance valve and fittings from cylinder port block. Discard O-rings.
4. Place cylinder barrel in a suitable holding fixture. Tap around outside of cylinder head retainer with a suitable hammer to break thread-locking compound.




Figure 5-36. Cylinder Barrel Support

5. Unscrew cylinder head with hook spanner wrench.




Figure 5-37. Marking Cylinder for Alignment

NOTICE

PULLING ROD OFF-CENTER CAN DAMAGE PISTON AND CYLINDER BARREL SURFACES. USE EXTREME CARE WHEN REMOVING CYLINDER ROD, HEAD, AND PISTON.

6. Clamp barrel securely. Pull rod assembly and cylinder head from barrel.
7. Protect cylinder rod from damage and clamp in a vise or holding fixture as close to piston as possible.





Figure 5-38. Cylinder Rod Support



- | | | | |
|-------------------|-----------------|-----------------|--------------------------|
| 1. Barrel | 7. Backup Ring | 13. Piston Seal | 19. Spacer |
| 2. Rod | 8. Bearing | 14. O-Ring | 20. Counterbalance Valve |
| 3. Head | 9. O-Ring | 15. Ball | 21. Counterbalance Valve |
| 4. Wiper | 10. Backup Ring | 16. Setscrew | |
| 5. Retaining Ring | 11. O-Ring | 17. Bearing | |
| 6. Rod Seal | 12. Piston | 18. Plug | |

Figure 5-39. Platform Level Cylinder

8. Loosen setscrew (16) retaining ball (15) in piston (12).
9. Screw piston counterclockwise and remove from rod.
10. Remove and discard O-ring (14) and seal (13).




Figure 5-40. Piston Disassembly

11. Remove rod from holding fixture.
12. Remove cylinder head assembly (3) from rod (2).
13. Remove and discard O-ring (9), backup ring (10), and O-ring (11) from cylinder head.
14. Remove and discard retaining ring (5), wiper (4), dry bearing (8), rod seal (7), and backup ring (6) from cylinder head (3).




Figure 5-41. Cylinder Head Disassembly

CLEANING AND INSPECTION

1. Clean parts thoroughly with approved cleaning solvent.
2. Inspect cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect threaded portion of barrel for damage. Dress threads as necessary.
6. Inspect piston surface for damage, scoring, or distortion. Dress piston surface or replace piston as necessary.
7. Inspect threaded portion of piston for damage. Dress threads as necessary.
8. Inspect seal and O-ring grooves in piston for burrs and sharp edges. Dress surfaces as necessary.
9. Inspect cylinder head inside diameter for scoring or other damage, and for ovality and tapering. Replace as necessary.
10. Inspect threaded portion of head for damage. Dress threads as necessary.
11. Inspect seal and O-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
12. Inspect cylinder head outside diameter for scoring, damage, ovality, and tapering. Replace as necessary.
13. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inside of the steel bushing with WD40 prior to bearing installation.
 - d. Press composite bushing into barrel or rod bushing with correct size arbor.

NOTE: Lubrication is not required with nickel plated pins and bearings. Install pin in composite bushing dry.




Figure 5-42. Composite Bushing Installation

14. Inspect travel limiting collar or spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
15. If applicable, inspect port block fittings and holding valve. Replace as necessary.
16. Inspect oil ports for blockage or presence of dirt or other foreign material. Repair as necessary.
17. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTICE

INCORRECT SEAL INSTALLATION CAN CAUSE CYLINDER LEAKS AND IMPROPER CYLINDER OPERATION. ENSURE ALL PISTON SEALS ARE CORRECTLY INSTALLED. REFER TO CROSS SECTION ILLUSTRATIONS FOR CORRECT SEAL ORIENTATION.

NOTE: Use correct cylinder seal kit for cylinder assembly. See your JLG Parts Manual.

Apply a light film of hydraulic oil to all components before assembly.

1. Support rod in holding fixture.
2. Install backup ring (6), rod seal (7), and dry bearing (8) in cylinder head (3).
3. Install wiper (4) and retaining ring (5) in cylinder head.
4. Install O-ring (11) on cylinder head.
5. Install backup ring (10) and O-ring (9) on cylinder head.
6. Slide cylinder head assembly on rod (2) to rod end. Do not dislodge or damage seals.




Figure 5-43. Cylinder Head Seal Installation




Figure 5-44. Cylinder Head Assembly

7. Install O-ring (14) in piston (12).
8. Install seal (16) on piston.
9. Apply Medium Strength Threadlocking Compound to piston threads. Install piston on rod.
10. Install ball (15) and setscrew (16).




Figure 5-45. Piston Seal Installation




Figure 5-46. Piston Assembly

11. Position cylinder barrel in a suitable holding fixture.

NOTICE

INSERTING ROD OFF-CENTER CAN DAMAGE PISTON AND CYLINDER BARREL SURFACES. USE EXTREME CARE WHEN INSTALLING CYLINDER ROD, HEAD, AND PISTON.

12. Clamp barrel securely and support rod. Insert piston end into barrel cylinder. Do not damage or dislodge seal.
13. Remove cylinder rod from holding fixture.
14. Place cylinder barrel in suitable holding fixture.

NOTICE

INSERTING ROD OFF-CENTER CAN DAMAGE PISTON AND CYLINDER BARREL SURFACES. USE EXTREME CARE WHEN INSTALLING CYLINDER ROD, HEAD, AND PISTON.

15. Clamp barrel securely and support rod. Insert piston end into barrel cylinder. Do not damage or dislodge piston O-rings and backup ring.
16. Continue pushing rod into barrel. Screw in cylinder head.




Figure 5-47. Cylinder Head Installation

Jib Lift Cylinder

NOTE: SERVICE INFORMATION NOT AVAILABLE AT TIME OF PUBLICATION.




Figure 5-48. Jib Lift Cylinder Assembly

5.3 HYDRAULIC PUMP (GEAR)

Removal

⚠ WARNING

ENSURE THE PRESSURE IS PROPERLY RELIEVED FROM THE HYDRAULIC SYSTEM BEFORE PROCEEDING TO REMOVAL OF THE PUMP MOTOR.

1. Disconnect the hydraulic hoses from inlet and outlet ports of the gear pump.

NOTICE

CAP ALL THE HYDRAULIC HOSES TO PREVENT ENTRAPPING OF THE DUST AND DIRT INTO IT.

2. Remove bolts and washers secured on the gear pump.
3. Carefully dislodge the gear pump shaft from the rear piston pump assembly.
4. Carefully place the gear pump on the clean working surface.

Assembly/Disassembly

For detail assembly/disassembly instructions, contact local JLG or JLG dealer for information.

Installation

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Check for gear teeth on shaft for scoring, pitting tapering and damage. If damaged need to be replaced with a new assembly completely.
2. Apply thin film of spline grease on the gear shaft.
3. Carefully insert the shaft into the piston pump and secure the gear pump using two bolts and washers. Medium Strength Threadlocking Compound to end of bolts. Torque bolts to 20-24 ft.lbs (27-33 Nm).
4. Remove cap from the hydraulic hoses and re-connect to their original locations.




Figure 5-49. Hydraulic Pump Installation

5.4 VARIABLE PUMP

Removal

⚠ WARNING

ENSURE THE PRESSURE IS PROPERLY RELIEVED FROM THE HYDRAULIC SYSTEM BEFORE PROCEEDING TO REMOVAL OF THE PUMP MOTOR.

1. Disconnect the hydraulic hoses from inlet and outlet ports of the front and rear variable pumps.

NOTICE

CAP ALL THE HYDRAULIC HOSES TO PREVENT ENTRAPPING OF THE DUST AND DIRT INTO IT.

2. Remove two bolts secured on the rear variable pump.
3. Carefully dislodge the rear variable pump shaft from the front variable pump assembly.
4. Carefully place the rear variable pump on the clean working surface.
5. Remove two bolts secured on the front variable pump.
6. Carefully dislodge the front variable pump shaft from the front engine assembly.
7. Carefully place the front variable pump on the clean working surface.

Assembly/Disassembly

For detail assembly/disassembly instructions, contact local JLG or JLG dealer for information.

Installation

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Check for gear teeth on shaft for scoring, pitting tapering and damage. If damaged need to be replaced with a new assembly completely.
2. Apply thin film of spline grease on the gear shaft.
3. Carefully insert the shaft of front variable pump into the engine and secure it using two bolts. Apply Medium Strength Threadlocking Compound to end of bolts. Torque bolts to 46-56 ft.lbs (62-76 Nm).
4. Carefully insert the shaft of rear variable pump into the front piston pump and secure it using two bolts. Apply Medium Strength Threadlocking Compound to end of bolts. Torque bolts to 46-56 ft.lbs (62-76 Nm).
5. Remove cap from the hydraulic hoses and re-connect to their original locations.




Figure 5-50. Variable Pump Installation

5.5 MAIN VALVE BLOCK PRESSURE SETTING PROCEDURE

Refer to Figure 5-51. Main Control Valve Block.

NOTICE

COLD TEMPERATURES HAVE A SIGNIFICANT IMPACT ON PRESSURE READINGS. JLG INDUSTRIES INC. RECOMMENDS OPERATING THE MACHINE UNTIL THE HYDRAULIC SYSTEM HAS WARMED TO NORMAL OPERATING TEMPERATURES PRIOR TO CHECKING PRESSURES. JLG INDUSTRIES INC. ALSO RECOMMENDS THE USE OF A CALIBRATED GAUGE. PRESSURE READINGS ARE ACCEPTABLE IF THEY ARE WITHIN $\pm 5\%$ OF SPECIFIED PRESSURES.

Load Sense Compensator

1. Install a pressure gauge at port MP1 of the main control valve capable of reading pressures up to 1000 psi (70 bar).
2. Start the Engine.
3. Adjust Load Sense Compensator (1) to 400 - 450 psi (27.5 - 31 bar). Turn adjuster clockwise to increase or counterclockwise to decrease pressure.

Main Relief Valve

1. Install a pressure gauge at port MP1 of the main control valve capable of reading pressures up to 5000 psi (345 bar).
2. Activate telescope in and hold.
3. Adjust main relief valve (2) to 3350 - 3400 psi (231 - 234.5 bar). Turn adjuster clockwise to increase or counterclockwise to decrease pressure.
4. If the pressure will not rise to 3350 psi, the load sense relief valve will have to increase. Locate the load sense relief valve. Increase this setting by 1 turn clockwise. Go back to the main relief valve and increase until the correct pressure is achieved.

Load Sense Relief Valve

1. Install a pressure gauge at port MJ of the main control valve capable of reading pressures up to 5000 psi (345 bar).
2. Activate telescope in and hold.
3. Adjust load sense relief valve (3) to 3200 - 3250 psi (220.6 - 224.1 bar). Turn adjuster clockwise to increase or counterclockwise to decrease pressure.

Turntable Swing Relief Valve

1. Install a pressure gauge at port MJ of the main control valve.
2. The turntable should be locked in place with the turntable lock pin. Activate swing right.
3. Adjust Relief Valve (8) to 1700 - 1750 psi (117 - 120.5 bar).
4. One adjustment will take care of both directions. Swing left will be approximately 50 - 100 psi (3.5 - 7 bar) lower. Turn adjuster clockwise to increase pressure or counterclockwise to decrease pressure.




Figure 5-51. Main Control Valve Block

5.6 PLATFORM VALVE BLOCK PRESSURE SETTING PROCEDURE

Refer to Figure 5-52. Platform Control Valve Block.

Main High Pressure Relief Valve


1. Install a pressure gauge at port MP1 of the platform control valve capable of reading pressures up to 5000 psi (345 bar).
2. Activate platform right or left to the end of stroke and hold.
3. Adjust Relief Valve (1) to 2950 - 3000 psi (204.5 - 207 bar). Turn adjuster clockwise to increase pressure or counterclockwise to decrease pressure.

Low Pressure Relief Valve

1. Install a pressure gauge at port MP1 of the platform control valve capable of reading pressures up to 5000 psi (345 bar).
2. To check or set this adjustment locate the dump directional valve (6) at the platform manifold. Flip the wires between the two solenoid coils. After the relief has been set, flip the wires back to their original place.
3. Activate rotate right or left to the end of stroke.
4. Adjust Relief Valve (2) to 2200 ± 50 psi (152 ± 3.5 bar). Turn adjuster clockwise to increase pressure or counterclockwise to decrease pressure.


Platform Jib Down Relief Valve

1. Install a pressure gauge at port M5-6 of the platform control valve capable of reading pressures up to 5000 psi (345 bar).
2. Activate jib down to the end of stroke and hold.
3. Adjust Relief Valve (7) to 1600 - 1650 psi (110 - 113.5 bar).
4. This one adjustment will take care of jib up and down. Jib up will automatically be approximately 50 - 100 psi (3.5 - 7 bar) higher than jib down. Turn adjuster clockwise to increase pressure or counterclockwise to decrease pressure.



- | | | |
|------------------------------------|---------------------------------|----------------------------------|
| 1. Main High Pressure Relief Valve | 3. Jib Relief Valve | 5. High Pressure Relief Solenoid |
| 2. Low Pressure Relief Valve | 4. Low Pressure Relief Solenoid | 6. Dump Directional Valve |

Figure 5-52. Platform Control Valve Block



- | | | | |
|--------------------------------|--------------------------------|--------------------------------|--------------------|
| 1. Load Sense Compensator | 6. Check Valve | 11. Pressure Compensator Valve | 16. Solenoid Valve |
| 2. Relief Valve | 7. Flow/Pressure Control Valve | 12. Solenoid Valve | 17. Orifice Plug |
| 3. Relief Valve | 8. Relief Valve | 13. Solenoid Valve | 18. Check Valve |
| 4. Solenoid Valve | 9. Shuttle Valve | 14. Solenoid Valve | |
| 5. Priority Flow Control Valve | 10. Pressure Compensator Valve | 15. Solenoid Valve | |

Figure 5-53. Main Control Valve




Figure 5-54. Main Control Valve Torque Values - Sheet 1 of 2




Figure 5-55. Main Control Valve Torque Values - Sheet 2 of 2




Figure 5-56. Platform Valve Torque Values

5.7 HYDRAULIC SCHEMATICS




Figure 5-57. Hydraulic Schematic - Sheet 1 of 2




Figure 5-58. Hydraulic Schematic - Sheet 1 of 2

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your information to search for a manual or part number. You can also search for a part number.

Brand:

Model:

Serial:

Part Number:

Category:

Search

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information:

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Part Name:

Part Description:

Part Category:

Part Location:

Part Status:

Part Condition:

Part Material:

Part Color:

Part Weight:

Part Dimensions:

Part Notes:

Part Attachments:

Part Images:

Part Videos:

Part Documents:

Part Links:

Part References:

Part Comments:

Part Status:

Part Condition:

Part Material:

Part Color:

Part Weight:

Part Dimensions:

Part Notes:

Part Attachments:

Part Images:

Part Videos:

Part Documents:

Part Links:

Part References:

Part Comments:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 6. JLG CONTROL SYSTEM

6.1 JLG CONTROL SYSTEM ANALYZER KIT
INSTRUCTIONS**NOTICE**

WHEN INSTALLING A NEW GROUND MODULE CONTROLLER IT IS NECESSARY TO PROGRAM THE CONTROLLER FOR PROPER MACHINE CONFIGURATION, INCLUDING OPTIONS.

NOTICE

AVOID PRESSURE-WASHING ELECTRICAL/ELECTRONIC COMPONENTS. IF PRESSURE-WASHING IS USED TO WASH AREAS CONTAINING ELECTRICAL/ELECTRONIC COMPONENTS, JLG INDUSTRIES, INC. RECOMMENDS A MAXIMUM PRESSURE OF 750 PSI (52 BAR) AT A MINIMUM DISTANCE OF 12 INCHES (30.5 CM) FROM THESE COMPONENTS. IF ELECTRICAL/ELECTRONIC COMPONENTS ARE SPRAYED, SPRAYING MUST NOT BE DIRECT AND FOR BRIEF TIME PERIODS TO AVOID HEAVY SATURATION.

The JLG designed Control System is a 12 volt based motor control unit installed on the boom lift.

The JLG Control System has reduced the need for exposed terminal strips, diodes and trimpots and provides simplicity in viewing and adjusting the various personality settings for smooth control of: acceleration, deceleration, creep, min

speed, and max.-speed for all boom, drive, and steering functions.

Upper lift, swing, and drive are controlled by individual joysticks. Steering is controlled by a rocker switch built in the top of the drive joystick. To activate Drive, Lift, and Swing; pull up the slide lock on the joystick and move the handle in the desired direction.

The control system provides voltage output to the valves and pump, as programmed, for smooth operation and maximum cycle time. Ground control speeds for all boom functions can also be programmed in the control system.

The JLG Control System controller has a built in LED to indicate any faults. The system stores recent faults which may be accessed for troubleshooting. Optional equipment includes a soft touch system, head and tail lights, and ground alarm. These options may be added later but must be programmed into the control system when installed.

The Control System may be accessed with a custom designed, direct connect hand held analyzer or wireless adapter using an app on your Android or iPhone/iPad device. The analyzer or wireless output displays two lines of information at a time, by scrolling through the program.

Each module has a label with JLG part number and a serial number containing a date code.




Figure 6-1. Hand Held Analyzer

Connect JLG Control System Analyzer


1. Connect the four pin end of the cable supplied with the analyzer, to the motor controller module located in the platform box or at the power module and connect the remaining end of the cable to the analyzer.

NOTE: The cable has a four pin connector at each end of the cable; the cable cannot be connected backwards.

2. Power up the Control System by turning the lower key to the platform or ground position and pulling both emergency stop buttons on.

Using Analyzer

With the machine power on and the analyzer connected properly, the analyzer will display the following:



**MENU:
HELP:PRESS ENTER**

Move between top level menu items using


RIGHT  and **LEFT**  arrow keys. To select a dis-


played menu item, press **ENTER** . To cancel a selected


menu item press **ESC** . Scroll using right and left arrow keys to select a different menu item.

Top level menus are as follows:

- HELP**
- DIAGNOSTICS**
- SYSTEM TEST**
- OPERATOR ACCESS**
- PERSONALITIES**
- MACHINE SETUP**
- CALIBRATIONS**

If you press **ENTER** , at the **HELP: PRESS ENTER** display, and a fault is present, the analyzer display will scroll the fault across the screen. If there was no fault detected, the display will read: **HELP: EVERYTHING OK**. If powered up at the ground station, the display shows: **GROUND OK**.

If **ENTER**  is pressed again, the display moves to the following display:





**LOGGED HELP
1: STARTUP (2/1)**

At this point, the analyzer will display the last fault the system has seen, if any are present. You may scroll through the fault logs to view what the last 25 faults were. Use the right and left arrow keys to scroll through the fault logs. To return to the

beginning, press **ESC**  two times. **STARTUP (2/1)** indicates a power up.


When a top level menu is selected, a new set of menu items may be offered: for example:

- DRIVE**
- BOOM**
- SYSTEM**
- DATALOG**
- VERSIONS**


Pressing **ENTER**  with any of the above displayed menus, displays additional sub-menus within the selected menu. In some cases, such as **DRIVE**, the next level is the parameter or information to be changed. Refer to the flow chart for what menus are available within the top level menus. You may only view the personality settings for selected menus while in access level 2. Remember, you may always cancel a selected menu item by pressing the **ESCAPE**  key.

Changing Access Level

When analyzer is first connected, you will be in access level 2 which enables you to only view most settings which cannot be changed until you enter a password to advance to a lower level. This ensures that a setting cannot be accidentally altered. To change access level, the correct password must be entered. To enter password, scroll to **ACCESS LEVEL** menu. For example:




**ACCESS LEVEL:
CODE 00000**


Press **ENTER**  to select the **ACCESS LEVEL** menu.

Using the **UP**  or **DOWN**  arrow keys, enter first digit of the password, 3.

Then using the **RIGHT**  arrow key, position cursor right one space to enter the second digit of the password.

Use the **UP**  or **DOWN**  arrow key to enter the second digit of the password which is 33271.


When correct password is displayed, press **ENTER** . The access level displays the following if password was entered correctly:




**MENU:
SERVICE ACCESS**

Repeat above steps if correct access level is not displayed or you can not adjust personality settings.


Adjust Parameters


Once you have gained access to level 1, and a personality item is selected, press the **UP**  or **DOWN**  arrow keys to adjust its value, for example:





MAF23930


**DRIVE:
ACCEL 1.05**

There will be a minimum and maximum for the value to ensure efficient operation. The Value will not increase if the **UP**  arrow is pressed at maximum value or decrease if the

DOWN  arrow is pressed at minimum value for any personality. If value does not change when pressing up and down arrows, check access level is at access level 1.

Machine Setup

When a machine digit item is selected, press **UP**  or **DOWN**  arrow keys to adjust its value, for example:



GROUND ALARM: 2 = DRIVE

The effect of the machine digit value is displayed along with its value. The above display would be selected if the machine was equipped with a ground alarm and you wanted it to sound when driving. There are certain settings allowed to install optional features or select the machine model.

When selection the machine model to match the size of the machine, the personality settings will all default to the factory recommended setting.

NOTE: Refer to *Personality Ranges/Defaults for the recommended factory settings.*

NOTE: Password 33271 allows access to level 1 to change machine personality settings.

There is a setting that JLG strongly recommends that you do not change. This setting is so noted below:

ELEVATION CUTBACK

WARNING

CHANGING ELEVATION CUTBACK SETTING MAY ADVERSELY AFFECT PERFORMANCE OF YOUR MACHINE.


NOTICE

AVOID PRESSURE-WASHING ELECTRICAL/ELECTRONIC COMPONENTS. IF PRESSURE-WASHING IS USED TO WASH AREAS CONTAINING ELECTRICAL/ELECTRONIC COMPONENTS, JLG INDUSTRIES INC. RECOMMENDS A MAXIMUM PRESSURE OF 750 PSI (52 BAR) AT A MINIMUM DISTANCE OF 12 INCHES (30.5CM) FROM THESE COMPONENTS. IF ELECTRICAL/ELECTRONIC COMPONENTS ARE SPRAYED, SPRAYING MUST NOT BE DIRECT AND FOR BRIEF TIME PERIODS TO AVOID HEAVY SATURATION.


Level Vehicle Description

WARNING

DO NOT LEVEL VEHICLE EXCEPT ON A LEVEL SURFACE.



LEVEL VEHICLE YES: ENTER, NO: ESC

Not available at password level 2. **ENTER**  confirms vehicle is currently level, and zeroes the tilt sensor measurements.

SECTION 6 - JLG CONTROL SYSTEM

Table 6-1. Analyzer Abbreviations

| ABBREVIATION | MEANING |
|--------------|--------------------------------|
| ACCEL | ACCELERATE |
| ACT | ACTIVE |
| A/D | ANALOG DIGITAL CONVERTER COUNT |
| AMB. | AMBIENT |
| ANG | ANGLE |
| AUX | AUXILIARY |
| BCS | BOOM CONTROL SYSTEM |
| BM | BOOM LENGTH ANGLE MODULE |
| BLAM | BOOM LENGTH ANGLE MODULE |
| BR | BROKEN |
| BSK | BASKET |
| CAL | CALIBRATION |
| CL | CLOSED |
| CM | CHASSIS MODULE |
| CNTL | CONTROL |
| CNTRL | CONTROL |
| C/O | CUT OUT |
| CONT(S) | CONTRACTOR(S) |
| COOR | COORDINATED |
| CRK PT | CRACK POINT |
| CRP | CREEP |
| CUT | CUTOUT |
| CYL | CYLINDER |
| DECEL | DECELERATE |
| D | DOWN |
| DN | DOWN |
| DWN | DOWN |
| DEG. | DEGREE |
| DOS | DRIVE ORIENTATION SYSTEM |
| DRV | DRIVE |
| E | ERROR |
| E&T | ELEVATED & TILTED |
| ELEV | ELEVATION |
| ENG | ENGINE |
| EXT | EXTEND |
| F | FRONT |
| FL | FLOW |
| FNT | FRONT |
| FOR | FORWARD |
| FWD | FORWARD |
| FSW | FOOT SWITCH |
| FUNC | FUNCTION |
| G | GROUND |


Table 6-1. Analyzer Abbreviations

| ABBREVIATION | MEANING |
|--------------|----------------------------|
| GND | GROUND |
| GRN | GREEN |
| GM | GROUND MODULE |
| H | HOURS |
| HW | HARDWARE |
| HWFS | HARDWARE FAILSAFE |
| I | IN or CURRENT |
| JOY | JOYSTICK |
| L | LEFT |
| LB | POUND |
| LEN | LENGTH |
| LIM | LIMIT |
| LT | LEFT |
| LVL | LEVEL |
| M | MINUTES |
| MIN | MINIMUM |
| MAX | MAXIMUM |
| M | MAIN |
| MN | MAIN |
| NO | NORMALLY OPEN or NO |
| NC | NORMALLY CLOSED |
| O | OUT |
| O/C | OPEN CIRCUIT |
| OP | OPEN |
| O/R | OVERRIDE or OUTRIGGER |
| O//R | OVERRIDE |
| OSC | OSCILLATING |
| OVRD | OVERRIDE |
| P | PLATFORM |
| P | PRESSURE |
| PCV | PROPORTIONAL CONTROL VALVE |
| PLAT | PLATFORM |
| PLT | PLATFORM |
| PM | PLATFORM MODULE |
| POT | POTENTIOMETER |
| PRES | PRESSURE |
| PRS | PRESSURE |
| PT | POINT |
| R | REAR or RIGHT |
| REV | REVERSE or REVISION |
| RET | RETRACT |
| ROT. | ROTATE |
| RT | RIGHT |

Table 6-1. Analyzer Abbreviations


| ABBREVIATION | MEANING |
|--------------|--------------------|
| S/C | SHORT CIRCUIT |
| SEL | SELECTOR |
| SN | SERIAL NUMBER |
| SPD | SPEED |
| STOW | STOWED |
| STOWD | STOWED |
| SW | SWITCH or SOFTWARE |
| TELE | TELESCOPE |
| TEMP | TEMPERATURE |
| TORQ. | TORQUE |
| TRN | TRANSPORT |
| T/T | TURNTABLE |
| T | TOWER |
| TURNTBL | TURNTABLE |
| TWR | TOWER |
| U | UPPER or UP |
| V | VOLT |
| VER | VERSION |
| VLV | VALVE |
| WIT | WITNESS |
| YEL | YELLOW |

Go to Discount-Equipment.com to order your parts



MAF26020

Figure 6-2. ADE Block Diagram




1001189583-I
MAF266601

NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-3. Analyzer Software P2.14 - Sheet 1 of 14


SECTION 6 - JLG CONTROL SYSTEM



1001189583-1
MAF266701

NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-4. Analyzer Software P2.14 - Sheet 2 of 14



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-5. Analyzer Software P2.14 - Sheet 3 of 14

SECTION 6 - JLG CONTROL SYSTEM



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-6. Analyzer Software P2.14 - Sheet 4 of 14



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-7. Analyzer Software P2.14 - Sheet 5 of 14

SECTION 6 - JLG CONTROL SYSTEM



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-8. Analyzer Software P2.14 - Sheet 6 of 14




Go to Discount-Equipment.com to order your parts

1001189583-I
MAF26720I

NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-9. Analyzer Software P2.14 - Sheet 7 of 14

SECTION 6 - JLG CONTROL SYSTEM



1001189583-I
MAF26730I

NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-10. Analyzer Software P2.14 - Sheet 8 of 14



1001189583-I
MAF26740I


NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-11. Analyzer Software P2.14 - Sheet 9 of 14



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-12. Analyzer Software P2.14 - Sheet 10 of 14



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-13. Analyzer Software P2.14 - Sheet 11 of 14

SECTION 6 - JLG CONTROL SYSTEM



NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.


Figure 6-14. Analyzer Software P2.14 - Sheet 12 of 14



1001189583-1
MAF267801

NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-15. Analyzer Software P2.14 - Sheet 13 of 14



1001189583-1
MAF26790I

NOTE: The layout shown includes all possible analyzer screens. Please note that some screens may not be available depending upon machine configuration and software versions.

Figure 6-16. Analyzer Software P2.14 - Sheet 14 of 14





Figure 6-17. Control Module Locations



1001187200-I
MAF21670I

Figure 6-18. Ground Control Module Pin Connections

| Connector | Pin | Function | Type |
|------------------------|-----|--|-----------------|
| J1 (Natural) | 1 | UNUSED (FUEL RACK ACTUATOR) | DIGITAL OUTPUT |
| | 2 | OSCILLATING AXLE VALVE #2 | DIGITAL OUTPUT |
| | 3 | DRIVE FORWARD / LEFT TRACK FORWARD VALVE | DIGITAL OUTPUT |
| | 4 | UNUSED | GROUND INPUT |
| | 5 | UNUSED | GROUND INPUT |
| | 6 | DRIVE REVERSE / LEFT TRACK REVERSE VALVE | DIGITAL OUTPUT |
| | 7 | OSCILLATING AXLE VALVE #1 | DIGITAL OUTPUT |
| | 8 | UNUSED | GROUND INPUT |
| | 9 | MSSO SWITCH GROUND | GROUND INPUT |
| | 10 | ECU POWER | DIGITAL OUTPUT |
| | 11 | ENGINE START | DIGITAL OUTPUT |
| | 12 | ENGINE GLOW PLUGS | DIGITAL OUTPUT |
| | 13 | APU ENABLE RELAY | DIGITAL OUTPUT |
| | 14 | UNUSED (ENGINE COOLANT TEMPERATURE SENSOR) | ANALOG INPUT |
| | 15 | UNUSED (ENGINE OIL PRESSURE SENSOR) | ANALOG INPUT |
| | 16 | UNUSED (ENGINE SPEED SENSOR) | FREQUENCY INPUT |
| | 17 | UNUSED (ENGINE SPEED SENSOR GROUND) | GROUND INPUT |
| | 18 | UNUSED (ENGINE GROUND) | GROUND INPUT |
| | 19 | UNUSED (ENGINE GROUND) | GROUND INPUT |
| | 20 | 2 SPEED VALVE | DIGITAL OUTPUT |
| | 21 | UNUSED (TOWER ELEVATION SWITCH #2) | DIGITAL INPUT |
| | 22 | GENERATOR ENABLE RELAY | DIGITAL OUTPUT |
| | 23 | BRAKE VALVE | DIGITAL OUTPUT |
| | 24 | UNUSED | N/C N/C |
| | 25 | UNUSED (RS-485 HIGH) | SERIAL I/O |
| | 26 | UNUSED (RS-485 LOW) | SERIAL I/O |
| | 27 | BRAKE / 2 SPEED VALVE GROUND | GROUND INPUT |
| | 28 | ANALYZER POWER | VOLTAGE OUTPUT |
| | 29 | ANALYZER RS-232 RX | SERIAL INPUT |
| | 30 | ANALYZER RS-232 TX | SERIAL OUTPUT |
| | 31 | ANALYZER GROUND | GROUND INPUT |
| | 32 | ALTERNATOR EXCITATION | DIGITAL OUTPUT |
| | 33 | UNUSED (RS-485 GROUND) | GROUND INPUT |
| | 34 | TELESCOPE RETRACTED SWITCH #2 | DIGITAL INPUT |
| | 35 | CAPACITY LENGTH SWITCH #2 | DIGITAL INPUT |

| Connector | Pin | Function | Type |
|----------------------|-----|---------------------------|---------------|
| J8 (Black) | 1 | MODULE GROUND | GROUND OUTPUT |
| | 2 | MODULE POWER | VBAT INPUT |
| | 3 | GROUND TO PLATFORM MODULE | GROUND INPUT |
| | 4 | POWER TO PLATFORM MODULE | VBAT OUTPUT |

| Connector | Pin | Function | Type |
|---------------------|-----|--|----------------|
| J2 (Gray) | 1 | STEER DUMP VALVE | DIGITAL OUTPUT |
| | 2 | GROUND ALARM | DIGITAL OUTPUT |
| | 3 | PLATFORM DUMP VALVE #1 | DIGITAL OUTPUT |
| | 4 | BYPASS DUMP VALVE | DIGITAL OUTPUT |
| | 5 | PLATFORM LEVEL UP VALVE | DIGITAL OUTPUT |
| | 6 | FUEL SENSOR GROUND | GROUND INPUT |
| | 7 | PLATFORM LEVEL DOWN VALVE | DIGITAL OUTPUT |
| | 8 | FRONT STEER RIGHT/RIGHTTRACK REVERSE VALVE | DIGITAL OUTPUT |
| | 9 | MAIN TELESCOPE IN VALVE | DIGITAL OUTPUT |
| | 10 | UNUSED (PLATFORM ROTATE LEFT VALVE) | DIGITAL OUTPUT |
| | 11 | MAIN LIFT UP VALVE | DIGITAL OUTPUT |
| | 12 | UNUSED (JIB LIFT UP VALVE) | DIGITAL OUTPUT |
| | 13 | MAIN DUMP VALVE | DIGITAL OUTPUT |
| | 14 | UNUSED (MAIN TELESCOPE VALVES GROUND) | GROUND INPUT |
| | 15 | UNUSED (TOWER TELESCOPE OUT VALVE) | DIGITAL OUTPUT |
| | 16 | USED (MAIN TELESCOPE OUT VALVE) | DIGITAL OUTPUT |
| | 17 | UNUSED (PLATFORM ROTATE / JIB LIFT VALVE GROUND) | GROUND INPUT |
| | 18 | STEER DUMP VALVE GROUND | GROUND INPUT |
| | 19 | FRONT LEFT STEER VALVE / RIGHT TRACK FORWARD VALVE | DIGITAL OUTPUT |
| | 20 | MAIN TELESCOPEOUT VALVE | DIGITAL OUTPUT |
| | 21 | AUX MAIN LIFT DOWN VALVE | DIGITAL OUTPUT |
| | 22 | MAIN LIFT DOWN VALVE | DIGITAL OUTPUT |
| | 23 | PLATFORM DUMP VALVE #2 | DIGITAL OUTPUT |
| | 24 | CONFIGURATION #2 | DIGITAL INPUT |
| | 25 | FUEL SENSOR | ANALOG INPUT |
| | 26 | HEAD / TAIL LIGHT ENABLE RELAY | DIGITAL OUTPUT |
| | 27 | GROUND ALARM / HORN | DIGITAL OUTPUT |
| | 28 | STEER VALVES GROUND | GROUND INPUT |
| | 29 | GROUND ALARM / HORN GROUND | GROUND INPUT |
| | 30 | MAIN/TELESCOPE IN/ BYPASS DUMP VALVE GROUND | GROUND INPUT |
| | 31 | TELESCOPE IN DUMP VALVE | DIGITAL OUTPUT |
| | 32 | REAR STEER RIGHT VALVE | DIGITAL OUTPUT |
| | 33 | REAR STEER LEFT VALVE | DIGITAL OUTPUT |
| | 34 | SWING LEFT VALVE | DIGITAL OUTPUT |
| | 35 | SWING RIGHT VALVE | DIGITAL OUTPUT |

SECTION 6 - JLG CONTROL SYSTEM

| Connector | Pin | Function | Type | |
|----------------------|-----|----------------------|-----------|-------|
| J12 (RED) | 1 | UNUSED | FREQUENCY | INPUT |
| | 2 | UNUSED | FREQUENCY | INPUT |
| | 3 | CAN2 HIGH | SERIAL | I/O |
| | 4 | CAN2 LOW | SERIAL | I/O |
| | 5 | UNUSED (CAN2 SHIELD) | GROUND | INPUT |
| | 6 | CAN2 TERMINATOR | TERM | I/O |
| | 7 | CAN2 TERMINATOR | TERM | I/O |
| | 8 | MSSO SWITCH | DIGITAL | INPUT |

| Connector | Pin | Function | Type | |
|-----------------------|-----|--|---------|--------|
| J3 (Black) | 1 | DRIVE/ LEFT TRACK DRIVE VALVES CURRENT FEEDBACK | GROUND | INPUT |
| | 2 | AUX DOWN / RIGHT TRACK VALVES CURRENT FEEDBACK | GROUND | INPUT |
| | 3 | WIRE ROPE SERVICE SWITCH GROUND | GROUND | INPUT |
| | 4 | SWING VALVES CURRENT FEEDBACK | GROUND | INPUT |
| | 5 | AUX DOWN VALVES CURRENT FEEDBACK | GROUND | INPUT |
| | 6 | TELESCOPE FLOW CONTROL VALVES CURRENT FEEDBACK | GROUND | INPUT |
| | 7 | GROUND ALARM POWER | VBAT | OUTPUT |
| | 8 | WIRE ROPE SERVICE SWITCH | DIGITAL | INPUT |
| | 9 | CRIBBING ENABLE SWITCH | DIGITAL | INPUT |
| | 10 | UNUSED | DIGITAL | INPUT |
| | 11 | CONFIGURATION #1 | DIGITAL | INPUT |
| | 12 | UNUSED | VOLTAGE | OUTPUT |
| | 13 | UNUSED | ANALOG | INPUT |
| | 14 | MAIN LIFT VALVES CURRENT FEEDBACK | GROUND | INPUT |

| Connector | Pin | Function | Type | |
|----------------------|-----|---|---------|--------|
| J4 (Blue) | 1 | CRIBBING ENGAGED INDICATOR | DIGITAL | OUTPUT |
| | 2 | SYSTEM DISTRESS INDICATOR | DIGITAL | OUTPUT |
| | 3 | GLOWPLUG INDICATOR | DIGITAL | OUTPUT |
| | 4 | ENGINE START SWITCH | DIGITAL | INPUT |
| | 5 | PLATFORM LEVEL DOWN SWITCH | DIGITAL | INPUT |
| | 6 | PLATFORM ROTATE LEFT SWITCH | DIGITAL | INPUT |
| | 7 | MAIN TELESCOPE IN SWITCH | DIGITAL | INPUT |
| | 8 | JIB LIFT DOWN SWITCH | DIGITAL | INPUT |
| | 9 | UNUSED (JIB LEFT SWITCH) | DIGITAL | INPUT |
| | 10 | UNUSED (TOWER LIFT UP SWITCH) | DIGITAL | INPUT |
| | 11 | UNUSED (TOWER TELESCOPE IN SWITCH) | DIGITAL | INPUT |
| | 12 | UNUSED (HOURMETER) | DIGITAL | OUTPUT |
| | 13 | LOW FUEL INDICATOR | DIGITAL | OUTPUT |
| | 14 | PLATFORM OVERLOADED INDICATOR | DIGITAL | OUTPUT |
| | 15 | UNUSED (UMS INDICATOR) | DIGITAL | OUTPUT |
| | 16 | AUXILIARY POWER / FUNCTION ENABLE | DIGITAL | INPUT |
| | 17 | PLATFORM LEVEL UP SWITCH | DIGITAL | INPUT |
| | 18 | PLATFORM ROTATE RIGHT SWITCH | DIGITAL | INPUT |
| | 19 | JIB LIFT UP SWITCH | DIGITAL | INPUT |
| | 20 | UNUSED (JIB RIGHT SWITCH) | DIGITAL | INPUT |
| | 21 | UNUSED (TOWER LIFT DOWN SWITCH) | DIGITAL | INPUT |
| | 22 | UNUSED (TOWER TELESCOPE OUT SWITCH) | DIGITAL | INPUT |
| | 23 | MAIN LIFT UP SWITCH | DIGITAL | INPUT |
| | 24 | UNUSED | VBAT | OUTPUT |
| | 25 | SWITCHES POWER | VBAT | OUTPUT |
| | 26 | BATTERY LOW / NOT CHARGING INDICATOR | DIGITAL | OUTPUT |
| | 27 | UNUSED | DIGITAL | OUTPUT |
| | 28 | UNUSED | DIGITAL | OUTPUT |
| | 29 | CHECK ENGINE INDICATOR | DIGITAL | OUTPUT |
| | 30 | MAIN TELESCOPE OUT SWITCH | DIGITAL | INPUT |
| | 31 | INDICATORS GROUND | GROUND | INPUT |
| | 32 | INDICATORS GROUND | GROUND | INPUT |
| | 33 | MAIN LIFT DOWN SWITCH | DIGITAL | INPUT |
| | 34 | SWING LEFT SWITCH | DIGITAL | INPUT |
| | 35 | SWING RIGHT SWITCH | DIGITAL | INPUT |

| Connector | Pin | Function | Type | |
|-----------------------------|-----|--|---------|--------|
| J7 (Black) | 1 | PLATFORM EMS | DIGITAL | INPUT |
| | 2 | PLATFORM MODE | DIGITAL | INPUT |
| | 3 | GROUND MODE | DIGITAL | INPUT |
| | 4 | BOOM ANGLE SENSOR #1 | ANALOG | INPUT |
| | 5 | UNUSED (ENGINE SPEED SENSOR) | VOLTAGE | OUTPUT |
| | 6 | CAN1 TERMINATOR | TERM | I/O |
| | 7 | BOOM ANGLE SENSOR #2 | ANALOG | INPUT |
| | 8 | UNUSED | ANALOG | INPUT |
| | 9 | BOOM ANGLE SENSOR GROUND | GROUND | INPUT |
| | 10 | TILT SENSOR GROUND | GROUND | INPUT |
| | 11 | UNUSED (TOWER ELEVATION SWITCH #1) | DIGITAL | INPUT |
| | 12 | UNUSED (OSCILLATING AXLE SWING SWITCH #1) | DIGITAL | PUT |
| | 13 | CAN1 HIGH | SERIAL | I/O |
| | 14 | GROUND MODE POWER TO PLATFORM | DIGITAL | INPUT |
| | 15 | FOOTSWITCH | DIGITAL | INPUT |
| | 16 | BOOM ANGLE SENSOR POWER | VOLTAGE | OUTPUT |
| | 17 | CAN1 TERMINATOR | TERM | I/O |
| | 18 | UNUSED (CAN1 SHIELD) | GROUND | INPUT |
| | 19 | IGNITION RELAY GROUND | GROUND | INPUT |
| | 20 | UNUSED (OSCILLATING AXLE SWING SWITCH #2) | ANALOG | INPUT |
| | 21 | TELESCOPE RETRACTED SWITCH #1 | DIGITAL | INPUT |
| | 22 | UNUSED | DIGITAL | INPUT |
| | 23 | CAPACITY LENGTH SWITCH #1 | DIGITAL | INPUT |
| | 24 | CAN1 LOW | SERIAL | I/O |
| | 25 | GROUND DISPLAY GROUND | GROUND | INPUT |
| | 26 | UNUSED | VOLTAGE | OUTPUT |
| | 27 | UNUSED | VOLTAGE | OUTPUT |
| | 28 | TELESCOPE RETRACTED SWITCH GROUND | GROUND | INPUT |
| | 29 | GROUND DISPLAY POWER | VBAT | OUTPUT |
| | 30 | UNUSED | VBAT | OUTPUT |
| | 31 | WIRE ROPE SERVICE SWITCH POWER | VBAT | OUTPUT |
| | 32 | TRANSPORT SWITCHES POWER | VBAT | OUTPUT |
| | 33 | TELESCOPE RETRACTED SWITCH POWER | VBAT | OUTPUT |
| | 34 | TILT SENSOR POWER | VBAT | OUTPUT |
| | 35 | DOS SWITCH | DIGITAL | INPUT |




Figure 6-19. Platform Control Module Pin Connections

| Connector | Pin | Assignment | Function |
|-------------------------|-----|---------------------------------------|----------------------|
| J1 (NATURAL) | 1 | UNUSED (TOWER LIFT UP SWITCH) | HS DIGITAL INPUT |
| | 2 | UNUSED (TOWER LIFT DOWN SWITCH) | HS DIGITAL INPUT |
| | 3 | UNUSED (TOWER TELESCOPE IN SWITCH) | HS DIGITAL INPUT |
| | 4 | UNUSED (TOWER TELESCOPE OUT SWITCH) | HS DIGITAL INPUT |
| | 5 | MAIN TELESCOPE IN SWITCH | HS DIGITAL INPUT |
| | 6 | MAIN TELESCOPE OUT SWITCH | HS DIGITAL INPUT |
| | 7 | PLATFORM ROTATE RIGHT SWITCH | HS DIGITAL INPUT |
| | 8 | PLATFORM ROTATE LEFT SWITCH | HS DIGITAL INPUT |
| | 9 | PLATFORM LEVEL UP SWITCH | HS DIGITAL INPUT |
| | 10 | PLATFORM LEVEL DOWN SWITCH | HS DIGITAL INPUT |
| | 11 | JIB LIFT UP SWITCH | HS DIGITAL INPUT |
| | 12 | JIB LIFT DOWN SWITCH | HS DIGITAL INPUT |
| | 13 | SPEED PUMP POTENTIOMETER GROUND | GROUND |
| | 14 | ENGINE START SWITCH | HS DIGITAL INPUT |
| | 15 | AUXILIARY POWER SWITCH | HS DIGITAL INPUT |
| | 16 | CRAB STEER SELECT SWITCH | HS DIGITAL INPUT |
| | 17 | COORDINATED STEER SELECT SWITCH | HS DIGITAL INPUT |
| | 18 | SWITCHES POWER | BATTERY VOLTAGE |
| | 19 | UNUSED | HS DIGITAL INPUT |
| | 20 | SOFT TOUCH SWITCH | HS DIGITAL INPUT |
| | 21 | CAPACITY SELECT SWITCH | HS DIGITAL INPUT |
| | 22 | UNUSED | HS DIGITAL INPUT |
| | 23 | SKYGUARD INPUT #2 SWITCH | HS DIGITAL INPUT |
| | 24 | UNUSED | HS DIGITAL INPUT |
| | 25 | PLATFORM ANGLE SENSOR #1 | HS DIGITAL INPUT |
| | 26 | PLATFORM ANGLE SENSOR #2 | HS DIGITAL INPUT |
| | 27 | MAX ENGINE SPEED SWITCH | HS DIGITAL INPUT |
| | 28 | MAX ENGINE TORQUE SWITCH | HS DIGITAL INPUT |
| | 29 | SOFT TOUCH / SKYGUARD OVERRIDE SWITCH | HS DIGITAL INPUT |
| | 30 | HEAD/TAIL LIGHT SWITCH | HS DIGITAL INPUT |
| | 31 | HORN | HS DIGITAL INPUT |
| | 32 | CREEP SWITCH | HS DIGITAL INPUT |
| | 33 | FUEL SELECT SWITCH | HS DIGITAL INPUT |
| | 34 | SPEED PUMP POTENTIOMETER POWER | +7 REFERENCE VOLTAGE |
| | 35 | SPEED PUMP POTENTIOMETER | ANALOG INPUT |

| Connector | Pin | Assignment | Function |
|----------------------|-----|-----------------------------------|------------------|
| J2 (BLUE) | 1 | UNUSED (JIB RIGHT SWITCH) | HS DIGITAL INPUT |
| | 2 | UNUSED (JIB LEFT SWITCH) | HS DIGITAL INPUT |
| | 3 | UNUSED | BATTERY VOLTAGE |
| | 4 | DOS OVERRIDE SWITCH | HS DIGITAL INPUT |
| | 5 | UNUSED | HS DIGITAL INPUT |
| | 6 | CHASSIS TILT INDICATOR | LAMP OUTPUT |
| | 7 | FUNCTION ENABLE INDICATOR | LAMP OUTPUT |
| | 8 | VEHICLE SYSTEM DISTRESS INDICATOR | LAMP OUTPUT |
| | 9 | CREEP SPEED INDICATOR | LAMP OUTPUT |
| | 10 | WIRE ROPE SERVICE INDICATOR | LAMP OUTPUT |
| | 11 | PLATFORM OVERLOADED INDICATOR | LAMP OUTPUT |
| | 12 | UNRESTRICTED CAPACITY INDICATOR | LAMP OUTPUT |
| | 13 | RESTRICTED CAPACITY INDICATOR | LAMP OUTPUT |
| | 14 | DOS INDICATOR | LAMP OUTPUT |
| | 15 | GENERATOR ON INDICATOR | LAMP OUTPUT |
| | 16 | SOFT TOUCH / SKYGUARD INDICATOR | LAMP OUTPUT |
| | 17 | GLOW PLUG ENGAGED INDICATOR | LAMP OUTPUT |
| | 18 | INDICATOR GROUND | GROUND |
| | 19 | LEVEL SYSTEM INDICATOR | LAMP OUTPUT |
| | 20 | DRIVE DISABLED INDICATOR | LAMP OUTPUT |
| | 21 | LOW FUEL INDICATOR | LAMP OUTPUT |
| | 22 | 1/4 FUEL LEVEL INDICATOR | LAMP OUTPUT |
| | 23 | 3/4 FUEL LEVEL INDICATOR | LAMP OUTPUT |
| | 24 | 1/2 FUEL LEVEL INDICATOR | LAMP OUTPUT |
| | 25 | INDICATOR GROUND | GROUND |
| | 26 | ANALYZER POWER | ANALYZER POWER |
| | 27 | ANALYZER GROUND | ANALYZER GROUND |
| | 28 | ANALYZER RX | ANALYZER RX |
| | 29 | ANALYZER TX | ANALYZER TX |
| | 30 | UNUSED | LAMP OUTPUT |
| | 31 | SOFT TOUCH POWER | DIGITAL OUTPUT |
| | 32 | LSS POWER | BATTERY VOLTAGE |
| | 33 | OPTION POWER | BATTERY VOLTAGE |
| | 34 | UNUSED | BATTERY VOLTAGE |
| | 35 | FULL FUEL INDICATOR | LAMP OUTPUT |

SECTION 6 - JLG CONTROL SYSTEM

| Connector | Pin | Assignment | Function |
|-------------------------|-----|-----------------------------------|----------------|
| J5 (NATURAL) | 1 | MAIN LIFT / SWING JOYSTICK POWER | SUPPLY VOLTAGE |
| | 2 | MAIN LIFT CENTER TAP | ANALOG INPUT |
| | 3 | MAIN LIFT SIGNAL | ANALOG INPUT |
| | 4 | SWING SIGNAL | ANALOG INPUT |
| | 5 | SWING CENTER TAP | ANALOG INPUT |
| | 6 | UNUSED | ANALOG INPUT |
| | 7 | MAIN LIFT / SWING JOYSTICK GROUND | GROUND |
| | 8 | UNUSED | GROUND |

| Connector | Pin | Assignment | Function |
|-----------------------|-----|--------------------------------|----------------|
| J6 (BLACK) | 1 | DRIVE / STEER JOYSTICK POWER | SUPPLY VOLTAGE |
| | 2 | DRIVE CENTER TAP | ANALOG INPUT |
| | 3 | DRIVE SIGNAL | ANALOG INPUT |
| | 4 | DRIVE ENABLE | ANALOG INPUT |
| | 5 | STEER LEFT / STEER SIGNAL | ANALOG INPUT |
| | 6 | STEER RIGHT / STEER CENTER TAP | ANALOG INPUT |
| | 7 | DRIVE / STEER JOYSTICK RETURN | GROUND |
| | 8 | UNUSED | GROUND |

| Connector | Pin | Assignment | Function |
|-----------|-----|---------------|-----------------|
| J8 | 1 | MODULE GROUND | GROUND |
| | 2 | MODULE POWER | BATTERY VOLTAGE |

| Connector | Pin | Assignment | Function |
|-----------------------|-----|---|-----------------------|
| J7 (BLACK) | 1 | GROUND MODE | GROUND MODE |
| | 2 | PLATFORM EMS | PLATFORM EMS |
| | 3 | PLATFORM EMS TO GROUND MODULE | PLATFORM MODE |
| | 4 | FOOTSWITCH (FUNCTION ENABLE SWITCH) POWER | BATTERY VOLTAGE |
| | 5 | PLATFORM ROTATE LEFT VALVE | ME DIGITAL OUTPUT |
| | 6 | PLATFORM ROTATE RIGHT VALVE | ME DIGITAL OUTPUT |
| | 7 | SKYGUARD POWER | BATTERY VOLTAGE |
| | 8 | FOOTSWITCH SIGNAL | DIGITAL INPUT |
| | 9 | GENERATOR SWITCH | DIGITAL INPUT |
| | 10 | UNUSED | +7 REFERENCE VOLTAGE |
| | 11 | PLATFORM ANGLE SENSOR POWER | +5V REFERENCE VOLTAGE |
| | 12 | UNUSED | +5V REFERENCE VOLTAGE |
| | 13 | UNUSED | ANALOG INPUT |
| | 14 | PLATFORM ANGLE SENSOR GROUND | GROUND |
| | 15 | PLATFORM LEVEL UP VALVE | HS DIGITAL OUTPUT |
| | 16 | PLATFORM LEVEL DOWN VALVE | HS DIGITAL OUTPUT |
| | 17 | UNUSED | HS DIGITAL INPUT |
| | 18 | SKYGUARD INPUT #1 SWITCH | HS DIGITAL INPUT |
| | 19 | PLATFORM ALARM | LAMP OUTPUT |
| | 20 | PLATFORM ALARM GROUND | GROUND |
| | 21 | SKYGUARD GROUND | GROUND |
| | 22 | LSS GROUND | GROUND |
| | 23 | VALVES GROUND | ANALOG INPUT |
| | 24 | UNUSED | DIGITAL OUTPUT |
| | 25 | JIB LIFT UP VALVE | ME DIGITAL OUTPUT |
| | 26 | JIB LIFT DOWN VALVE | ME DIGITAL OUTPUT |
| | 27 | UNUSED (JIB RIGHT VALVE) | ME DIGITAL OUTPUT |
| | 28 | UNUSED (JIB LEFT VALVE) | ME DIGITAL OUTPUT |
| | 29 | OPTIONS GROUND | GROUND |
| | 30 | CAN LOW | CAN LOW |
| | 31 | CAN HIGH | CAN HIGH |
| | 32 | UNUSED (CAN SHIELD) | CAN SHIELD |
| | 33 | UNUSED | GROUND |
| | 34 | UNUSED | GROUND |
| | 35 | UNUSED | ANALOG INPUT |

Table 6-2. Machine Configuration Programming Information- Version P2.14

| Configuration Digit | Number | Description | Default Number |
|--|---------------------------------|---|----------------|
| NOTE: The machine configuration must be completed before any personality settings can be changed. Changing personality settings first and then changing the model number of the machine configuration will cause personality settings to return to default. | | | |
| MODEL NUMBER: 1 | 0 1 2 | ????: Visible only on a Non-Configured UGM 600S: For 600S / 600S HC3 / 660SJ / 660SJ HC3 600SC: For 600SC / 660SJC | 1 |
| MARKET: 2* | 1 2 3 4 5 6 7 | ANSI USA ANSI EXPORT CSA CE AUSTRALIA JAPAN GB | 1 |
| * Certain model selections will limit market options. | | | |
| ENGINE: 3* | 1 2 3 4 5 6 | KUBOTA D1105 GM DUAL FUEL: GM/PSI 0.97L Duel Fuel (Tier 3) KUBOTA DUAL FUEL FORD DUAL FUEL DEUTZ EMR2: (Tier 4i) DEUTZ EMR4: (Tier 4f) | 5 |
| * Certain model selections will limit engine options. * Certain market selections will limit engine options. | | | |
| STARTER LOCKOUT: 4* | 1 2 | DISABLED: Automatic pre-glow time determined by ambient air temperature; engine start can be attempted at any time during pre-glow. ENABLED: Automatic pre-glow time determined by ambient air temperature; engine start is NOT permitted until pre-glow is finished. | 1 |
| * Only visible for diesel engine selections. | | | |
| ENGINE SHUTDOWN: 5 | 1 2 | DISABLED: No engine shutdown. ENABLED: Shutdown engine for high coolant temperature fault or low oil pressure fault | 2 |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-2. Machine Configuration Programming Information- Version P2.14

| Configuration Digit | Number | Description | Default Number |
|--|---|--|----------------|
| FUEL CUTOUT: 6* | 1 2 3 4 | ONE RESTART: One restart with limited run time when near Empty. ENGINE STOP: No starting permitted when near Empty. NONE RESTART: Restarts allowed with limited run time when near Empty | 4 |
| * Only visible for diesel engine selections. | | | |
| TILT: 7* | 1 2 3 4 5 6 7 8 9 | 5 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep. 4 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep. 3 DEGREES: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep. 5 DEGREES + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also disallows tower lift up, tower telescope out, drive, main telescope out and main lift up. 4 DEG + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also disallows tower lift up, drive, telescope out and lift up. 3 DEG + CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also disallows tower lift up, drive, telescope out and lift up. 5 DEG + DRV CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 5 degrees and above elevation; also reduces drive speed to creep when drive reversal is allowed, drive is disallowed otherwise. 4 DEG + DRV CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 4 degrees and above elevation; also reduces drive speed to creep when drive reversal is allowed, drive is disallowed otherwise. 3 DEG + DRV CUT: Reduces the maximum speed of all boom functions to creep when tilted more than 3 degrees and above elevation; also reduces drive speed to creep when drive reversal is allowed, drive is disallowed otherwise. | 7 |
| * Certain market selections will limit tilt options and alter default setting. | | | |
| 4 WHEEL STEER: 8* | 1 2 | NO: 4 Wheel Steer not installed. YES: 4 Wheel Steer installed. | 1 |
| * Certain model selections will limit visibility. | | | |

Table 6-2. Machine Configuration Programming Information- Version P2.14

| Configuration Digit | Number | Description | Default Number |
|--|------------------|---|----------------|
| JIB: 9* | 1 2 | NO: No Jib installed. YES: Jib installed which has up and down movements only. | 1 |
| * Certain model selections will limit visibility. | | | |
| SOFT TOUCH: 10* | 1 2 | NO: No Soft Touch system installed. YES: Soft Touch system installed. | 1 |
| * Certain model selections will limit visibility. | | | |
| SKYGUARD: 11 | 1 2 3 | NO: No SkyGuard system installed. BAR/SKYLINE: SkyGuard system installed. SKYEYE: SkyGuard system installed. | 2 |
| GEN SET/WELDER: 12 | 1 2 | NO: No generator installed. BELT DRIVE: Belt driven setup | 1 |
| GEN SET CUTOUT: 13* | 1 2 | MOTION ENABLED: Motion enabled when generator is ON. MOTION CUTOUT: Motion cutout in platform mode only. | 1 |
| * Only visible if gen set / welder selection is not NO. | | | |
| H & T LIGHTS: 14 | 1 2 | NO: No head and tail lights installed. YES: Head and tail lights installed. | 1 |
| LOAD SYSTEM: 15* | 1 2 3 4 | NO: No load sensor installed. WARN ONLY: Functions in creep, overload lamp lit, platform alarm beeps. CUTOUT PLATFORM: All functions cutout, overload lamp lit, platform alarm beeps (5 sec ON, 2 sec OFF). CUTOUT ALL: All functions cutout, flash overload light (500mS on, 500mS off), platform alarm beeps (5 sec ON, 2 sec OFF). | 3 |
| * Certain market selections will limit load system options or alter default setting. | | | |
| FUNCTION CUTOUT: 16* | 1 2 3 4 | NO: No drive cutout. BOOM CUTOUT: Boom function cutout while driving above elevation. DRIVE CUTOUT: Drive and steer cutout above elevation. DRIVE CUTE/T: Drive & steer cutout above elevation or telescoped. | 1 |
| * Certain market selections will limit function cutout options or alter default setting. | | | |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-2. Machine Configuration Programming Information- Version P2.14

| Configuration Digit | Number | Description | Default Number |
|---|--------|---|----------------|
| GROUND ALARM: 17 | 1 | NO: No ground alarm installed. | 4 |
| | 2 | DRIVE: Travel alarm sounds when the drive function is active. | |
| | 3 | DESCENT: Descent alarm sounds when lift down is active. | |
| | 4 | MOTION: Motion alarm sounds when any function is active. | |
| | | | |
| DRIVETYPE: 18* | 1 | 4WD: 4 wheel drive. | 1 |
| | 2 | 2WD: 2 wheel drive. | |
| * Certain model selections will limit visibility. | | | |
| | | | |
| DISPLAY UNITS: 19* | 1 | METRIC: Celsius, Kilograms, KiloPascal. | 2 |
| | 2 | IMPERIAL: Fahrenheit, Pounds, Pounds/in² | |
| * Certain market selections will alter default setting. | | | |
| | | | |
| CLEARSKY: 20 | 1 | NO: ClearSky (telematics) options is disabled. | 1 |
| | 2 | YES: ClearSky (telematics) option is enabled. | |
| | | | |
| CRIBBING OPTION: 21* | 1 | NO: Cribbing Option is disabled. | 1 |
| | 2 | YES: Cribbing Option is enabled. | |
| * Certain model selections will limit visibility. | | | |
| | | | |
| ALERT BECON: 22 | 1 | OFF FOR CREEP | 1 |
| | 2 | IN CREEP 20FPM | |
| | | | |
| TEMP CUTOUT: 23* | 1 | NO: No Low Temp Cutout system installed | 1 |
| | 2 | YES: Low Temp Cutout system installed | |
| * Only visible under certain market selections. | | | |
| | | | |
| PLAT LVL OVR CUT: 24 | 1 | NO: Platform Level functions above elevation | 1 |
| | 2 | YES: Platform Level does not function above elevation | |
| | | | |

Table 6-2. Machine Configuration Programming Information- Version P2.14

| Configuration Digit | Number | Description | Default Number |
|--|-------------|--|----------------|
| CAPACITY: 25* | 1 2 3 | SINGLE: Single Capacity system installed. DUAL: Dual Capacity system installed. TRIPLE: Triple Capacity system installed. | 2 |
| * Certain model selections will limit visibility. * Certain model selections will limit capacity options. * Certain market selections will limit capacity options. | | | |
| ALARM / HORN: 26 | 1 2 | SEPARATE: Ambient alarm installed. COMBINED: Single Horn / Alarm installed. | 2 |
| WATER IN FUELSENSOR: 27* | 1 2 | NO: Water in Fuel Sensor not installed. YES: Water in Fuel Sensor installed. | 1 |
| * Only visible if engine selection is Deutz EMR4. | | | |
| LIFT CYL WITH: 28* | 1 2 | AUX VALVE: Lift Down Aux Valve is installed. ENABLE VALVE: Lift Down Enable Valve is installed | 1 |
| * Certain model selections will limit visibility. | | | |

1001248688 - B

SECTION 6 - JLG CONTROL SYSTEM

**Table 6-3. Machine Configuration Programming Settings-
Version P2.14**

| 660SJC | ANSI USA | ANSI Export | CSA | CE | Australia | Japan | GB |
|--------------------|----------|-------------|-----|----|-----------|-------|----|
| Model Number | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Market | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| Engine | X | X | X | X | X | X | X |
| | X | X | X | X | X | X | X |
| | X | X | X | X | X | X | X |
| | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 5 | 5 | 5 | 5 | 5 | 5 | 5 |
| | 6 | 6 | 6 | 6 | 6 | 6 | 6 |
| Starter Lockout | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Engine Shutdown | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Fuel Cutout | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | X | X | X | X | X | X | X |
| | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| Tilt | X | X | X | X | X | X | X |
| | X | X | X | X | X | X | X |
| | X | X | X | X | X | X | X |
| | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | 5 | 5 | 5 | 5 | 5 | 5 | 5 |
| | 6 | 6 | 6 | 6 | 6 | 6 | 6 |
| | 7 | 7 | 7 | 7 | 7 | 7 | 7 |
| | 8 | 8 | 8 | 8 | 8 | 8 | 8 |
| | 9 | 9 | 9 | 9 | 9 | 9 | 9 |
| 4Wheel Steer | X | X | X | X | X | X | X |
| | X | X | X | X | X | X | X |
| Jib | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| SOFT TOUCH | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| SKYGUARD | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Gen Set /Welder | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Gen Set Cutout | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Head & Tail lights | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |

**Table 6-3. Machine Configuration Programming Settings-
Version P2.14**

| 660SJC | ANSI USA | ANSI Export | CSA | CE | Australia | Japan | GB |
|----------------------|----------|-------------|-----|----|-----------|-------|----|
| Load System | X | X | X | X | X | X | X |
| | X | X | X | X | X | X | X |
| | 3 | 3 | 3 | X | 3 | 3 | 3 |
| Function Cutout | 4 | 4 | 4 | 4 | X | 4 | 4 |
| | 1 | 1 | 1 | X | 1 | 1 | 1 |
| | X | 2 | 2 | 2 | 2 | 2 | 2 |
| | 3 | 3 | 3 | X | 3 | 3 | 3 |
| Ground Alarm | 4 | 4 | 4 | X | 4 | 4 | 4 |
| | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Drive Type | 4 | 4 | 4 | 4 | 4 | 4 | 4 |
| | X | X | X | X | X | X | X |
| | X | X | X | X | X | X | X |
| | X | X | X | X | X | X | X |
| Display Units | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Clearsky | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Cribbing Option | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | X | X | X | X | X | X |
| Alert Beacon | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Temp Cutout | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | X | 2 | X | 2 | X | X | 2 |
| PLAT LVL OVR CUT | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Capacity | X | X | X | X | X | X | X |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| | X | X | X | X | X | X | X |
| ALARM / HORN | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Water in Fuel Sensor | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| Water in Fuel Sensor | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| | 2 | 2 | 2 | 2 | 2 | 2 | 2 |

BOLD BLUE text indicates the default setting. Plain text indicates another available selection. **RED ITALIC** text indicates the default when option is factory installed. SHADED CELLS indicate hidden menu or selection.

1001248688-B

6.2 MACHINE PERSONALITY SETTINGS

NOTE: Personality settings can be adjusted within the adjustment range for optimum machine performance.

Table 6-4. Machine Personality Settings and Function Speed (Software Version P2.14)

| FUNCTION | | ADJUSTMENT RANGE | DEFAULT VALUES | TIME RANGE (IN SECONDS) |
|------------------------|----------|------------------|----------------|----------------------------|
| DRIVELEFTTRACK | | | | |
| | Accel | 0.0 - 5.0 s | 1.0 s | |
| | Decel | 0.0 - 5.0 s | 1.0 s | |
| FORWARD | Min | 0.0 - 250 mA | 50 mA | 85 - 97 |
| | Max | 0.0 - 250 mA | 185 mA | |
| | Elevated | 0.0 - 250 mA | 108 mA | |
| | Creep | 0.0 - 250 mA | 108 mA | |
| REVERSE | Min | 0.0 - 250 mA | 60 mA | 85 - 97 |
| | Max | 0.0 - 250 mA | 200 mA | |
| | Elevated | 0.0 - 250 mA | 125 mA | |
| | Creep | 0.0 - 250 mA | 125 mA | |
| DRIVERIGHTTRACK | | | | |
| | Accel | 0.0 - 5.0 s | 1.0 s | |
| | Decel | 0.0 - 5.0 s | 1.0 s | |
| FORWARD | Min | 0.0 - 250 mA | 70 mA | 85 - 97 |
| | Max | 0.0 - 250 mA | 193 mA | |
| | Elevated | 0.0 - 250 mA | 121 mA | |
| | Creep | 0.0 - 250 mA | 121 mA | |
| REVERSE | Min | 0.0 - 250 mA | 65 mA | 85 - 97 |
| | Max | 0.0 - 250 mA | 180 mA | |
| | Elevated | 0.0 - 250 mA | 115 mA | |
| | Creep | 0.0 - 250 mA | 115 mA | |
| SWING | | | | |
| | Accel | 0.0 - 3.0 s | 3.0 s | |
| | Decel | 0.0 - 2.0 s | 1.6 s | |
| LEFT | Min | 250 - 1000 mA | 430 mA | 79 - 99 |
| | Max | 250 - 1000 mA | 875 mA | |
| | Creep | 250 - 1000 mA | 675 mA | |
| RIGHT | Min | 250 - 1000 mA | 430 mA | 79 - 99 |
| | Max | 250 - 1000 mA | 900 mA | |
| | Creep | 250 - 1000 mA | 675 mA | |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-4. Machine Personality Settings and Function Speed (Software Version P2.14)

| FUNCTION | | ADJUSTMENT RANGE | DEFAULT VALUES | TIME RANGE (IN SECONDS) |
|------------------|--------------|------------------|----------------|----------------------------|
| LIFT | | | | |
| | Accel | 0.0 - 3.0 s | 2.5 s | |
| | Decel | 0.0 - 2.0 s | 1.2 s | |
| UP | Min | 250 - 1500 mA | 525 mA | 55 - 75 |
| | Max | 250 - 1500 mA | 1400 mA | |
| | Creep | 250 - 1500 mA | 1000 mA | |
| DOWN | Min | 250 - 1300 mA | 700 mA | 55 - 75 |
| | Max | 250 - 1300 mA | 1200 mA | |
| | Creep | 250 - 1300 mA | 1000 mA | |
| | Soft Down | 250 - 1500 mA | 900 mA | |
| | Soft Down | 250 - 1300 mA | 850 mA | |
| TELESCOPE | | | | |
| | Accel | 0.0 - 3.0 s | 0.7 s | |
| | Decel | 0.0 - 2.0 s | 0.5 s | |
| IN | Min | 250 - 1200 mA | 420 mA | 40 - 50 |
| | Max | 250 - 1200 mA | 1000 mA | |
| | Creep | 250 - 1200 mA | 650 mA | |
| OUT | Min | 250 - 1200 mA | 480 mA | 42 - 52 |
| | Max | 250 - 1200 mA | 1050 mA | |
| | Creep | 250 - 1200 mA | 710 mA | |
| JIB LIFT | | | | |
| | Accel | 0.0 - 3.0 s | 3.0 s | |
| | Decel | 0.0 - 2.0 s | 0.8 s | |
| UP | Min | 10 - 50% | 27% | 25 - 32 |
| | Max | 10 - 50% | 41% | |
| | Creep | 10 - 50% | 34% | |
| DOWN | Min | 10 - 50% | 27% | 22 - 28 |
| | Max | 10 - 50% | 40% | |
| | Creep | 10 - 50% | 35% | |
| | Up Cutback | 10 - 50% | 33% | |
| | Down Cutback | 10 - 50% | 33% | |

Table 6-4. Machine Personality Settings and Function Speed (Software Version P2.14)

| FUNCTION | | ADJUSTMENT RANGE | DEFAULT VALUES | TIME RANGE (IN SECONDS) | |
|-----------------------|-------|------------------|----------------|----------------------------|--|
| PLATFORM LEVEL | | | | | |
| | Accel | 0.0 - 3.0 s | 0.0 s | | |
| | Decel | 0.0 - 2.0 s | 0.0 s | | |
| UP | Min | 250 - 1500 mA | 800 mA | | |
| | Max | 250 - 1500 mA | 1300 mA | | |
| | Creep | 250 - 1500 mA | 1100 mA | | |
| DOWN | Min | 250 - 1500 mA | 850 mA | | |
| | Max | 250 - 1500 mA | 1400 mA | | |
| | Creep | 250 - 1500 mA | 1250 mA | | |
| GROUND MODE | | | | | |
| SWING | Left | 250 - 1000 mA | 670 mA | | |
| | Right | 250 - 1000 mA | 895 mA | | |
| Lift | Up | 250 - 1500 mA | 1395 mA | | |
| | Down | 250 - 1300 mA | 1195 mA | | |
| Telescope | In | 250 - 1200 mA | 995 mA | | |
| | Out | 250 - 1200 mA | 1045 mA | | |
| JIB | Up | 10 - 50% | 40% | | |
| | Down | 10 - 50% | 39% | | |
| Platform | Up | 250 - 1500 mA | 1295 mA | | |
| | Down | 250 - 1500 mA | 1395 mA | | |

1001198722-D

6.3 MACHINE ORIENTATION WHEN SETTING FUNCTION SPEEDS

Crawler Drive (Below Elevation): Test should be done on a smooth, level surface. The Drive Select Switch should be in the "Max Speed" position. Start approximately 25 ft. (7.6m) from starting point so the unit is at a maximum speed when starting the test. Results should be recorded for a 200 ft. (61m) course. Adjust the Left track/Right track drive FWD/REV maximums to achieve the best straight tracking performance introducing steer. Drive forward, "High Speed", record time. Drive reverse, "High Speed", record time.

Crawler Drive (Above Elevation): Test should be done on a smooth, level surface. The Drive Select Switch should be in the "Max Speed" position, the boom should be > 10° above horizontal to ensure the drive is operating in Max Torque mode. Result should be recorded for a 50 ft (15.2m) course. Adjust the Left track/Right track FWD/REV elevated drive maximum to achieve the best straight tracking without introducing steer. Drive forward, record time. Drive reverse, record time. Lower boom below < 5° and retract boom. Turn Platform Speed Control Knob fully counterclockwise to enter Creep mode; Creep light on panel must be energized. Verify that machine will Drive Forward and Reverse. If needed, Adjust the Left track/Right track drive FWD/REV creep drive maximums to achieve the best straight tracking performance. Return knob to fully clockwise.

SWING: Boom at full elevation, Telescope retracted. Swing Right until over rear axle or end stop (if equipped). Swing Left 360° or end stop (if equipped), record time. Swing Right 360° or end stop (if equipped), record time. Turn Platform Speed Control Knob fully counterclockwise to enter Creep mode; Creep light on Panel must be energized. Verify that machine will swing left and right. Return Knob to fully clockwise.

MAIN LIFT: Main Lift in stowed position, Telescope Retracted. Main Lift Up, record time. Main Lift Down, record time. Turn Platform Speed Control Knob fully counterclockwise to enter Creep mode; Creep light on Panel must be energized. Verify that machine will Lift Up and Down. Return Knob to fully clockwise.

TELESCOPE: Main Lift at full elevation, Telescope Retracted. Telescope Out, record time. Telescope In, record time. Turn Platform Speed Control Knob fully counterclockwise to enter Creep mode; Creep light on Panel must be energized. Verify that machine will Telescope In and Out. Return Knob to fully clockwise.

JIB LIFT: Platform level and centered with the boom. Jib Lift Down until stop. Jib Lift Up, record time. Jib Lift Down, record time. Turn Platform Speed Control Knob fully counterclockwise to enter Creep mode; Creep light on Panel must be energized. Verify that machine will Jib Lift Up and Down. Return Knob to fully clockwise.

PLATFORM ROTATE: Platform level, Rotate Platform Right until stop. Platform Left, record time. Platform Right, record time. Turn Platform Speed Control Knob fully counterclockwise to enter Creep mode; Creep light on Panel must be energized. Verify that machine will Platform Rotate Left and Right. Return Knob to fully clockwise.

NOTE: When the platform speed control knob is turned fully counterclockwise. The platform rotate may not work, this is acceptable.

Test Notes

1. Personality settings can be adjusted anywhere within the adjustment range for optimum machine performance.
2. Stop watch should be started with the function movement, not with actuation of the joystick or switch.
3. Drive speeds should be set to the values below regardless of the tire size.
4. All speed tests are run from the platform, these speeds do not reflect the ground control operation.
5. The Platform Speed Control knob must be at full speed (turned clockwise completely) unless noted.
6. Some flow control functions may not work with the Platform Speed Control knob clicked into the creep position.
7. Functional speeds may vary due to cold thick hydraulic oil. Test should be run with the oil temperature above 38° C (100° F).

6.4 CANBUS COMMUNICATIONS

CANbus: CAN (Control Area Network) is a two wire differential serial link between the Platform and Ground Modules providing bi-directional communications.

Two-wire: One wire (red) is driven high (5v) and the other low (black) (0v) to send a signal. Both wires "float" (2.5v) when no signal is being sent.

Differential: Any electrical line noise can affect the high or the low wires but never both, so communications is not corrupted.

Serial Link: Messages are being sent bit by bit along the wires; the high bus speed allow all modules to be constantly updated around 20 times per second. Typical traffic is 300 - 500 messages per second.

A complete CANbus circuit is approximately 60 ohms, which can be verified at the "T" fitting inside the ground station. Individual circuits are approximately 120 ohms.

The GROUND MODULE (UGM) is the master system controller. Most functions are dispatched and coordinated from this module. The PLATFORM MODULE handles sub-tasks. All characterized information (values) are stored in the ground module (i.e., Personalities or Calibrations).

Interlocks: Any device that sends an electrical input. (For an example a limit switch, proximity switch, etc;).

Platform Level: The GROUND MODULE stores default values and handles interlocks. The PLATFORM MODULE reads sensors mounted on the platform assembly and controls Level Up / Down valves to maintain setpoint sent from the GROUND MODULE.

Steer: The GROUND MODULE stores crack points, and sends desired drive direction, steering mode, and axle extend/retract commands. The PLATFORM MODULE reports steering switch position to the GROUND MODULE.


Lift, Tele, & Swing: The GROUND MODULE stores default values, and handles interlocks and calibration information. Lift, Telescope, and Swing commands depend on interlocks through out the machine. Boom angle, length, and swing are controlled by the GROUND MODULE.

6.5 SYSTEM TEST

The Control System Incorporates a built-in system test to check the system components and functions. To use this function, use the following procedures.

Test from the Platform

1. Position the Platform/Ground Select switch (1) to the Platform position.




2. Plug the analyzer into the connector at the base of the platform control box.




3. Before proceeding, ensure that the switches on the platform console are in the following positions:
 - a. Drive speed dial is in the slow position. (Turtle Icon).
 - b. Function speed potentiometer out of creep mode switch.
 - c. Generator (if equipped) switched to the off position.
 - d. Head and Tail lights (if equipped) switched to the off position.

4. Pull out the Emergency Stop switch and Start the engine.




MAE15700

5. The analyzer screen should read:




6. Use the arrow button to reach SYSTEM TEST. Hit Enter. The analyzer will prompt you asking if you want to activate the system test; hit Enter again to activate.
7. Follow the flow path in Figure 6-20., System Test Flow Chart - Platform Tests (Sheet 1 of 2) & Figure 6-21., System Test Flow Chart - Platform Tests (Sheet 2 of 2) and go through the component tests. Hit the ESC key during any part of the test to return to the main menu without completing all tests or wait until all tests are complete. During the TEST ALL INPUTS sequence, the analyzer allows control switches to be operated and shows if they are closed (CL) or open (OP).



MAE24070

Figure 6-20. System Test Flow Chart - Platform Tests (Sheet 1 of 2)




MAE24080

Figure 6-21. System Test Flow Chart - Platform Tests (Sheet 2 of 2)

Test from the Ground Station


1. Position the Platform/Ground select switch (1) to ground.




2. Plug the analyzer into the connector (2) inside the Ground control box.




3. Pull out the Emergency Stop switch (3) and Start the engine.



4. The analyzer screen should read:



5. Use the arrow button to reach SYSTEM TEST. Hit Enter. The analyzer will prompt you asking if you want to activate the system test; hit Enter again to activate.
6. Follow the flow path in Figure 6-22., System Test Flow Chart - Ground Station Tests and go through the component tests. Hit the ESC key during any part of the test to return to the main menu without completing all tests or wait until all tests are complete. During the TEST ALL INPUTS sequence, the analyzer allows control switches to be operated and shows if they are closed (CL) or open (OP).



MAE24090

Figure 6-22. System Test Flow Chart - Ground Station Tests

6.6 SYSTEM TEST MESSAGES

Table 6-5. System Test Messages

| Message Displayed on Analyzer | Message Displayed on Analyzer | Description |
|-------------------------------|-------------------------------|--|
| RUNNING | | Initial display when system test is run while running certain "critical" checks are made |
| | CHECK GROUND/ PLATFORM SELECT | The analyzer must be connected to the active control station to run the system test |
| | BATTERY VOLTAGE TOO LOW | The system test may not run properly with battery voltage below 11V |
| | BATTERY VOLTAGE TOO HIGH | The system test may not operate properly with the battery voltage above 16V |
| | CHECK CAN WIRING | The system test will not operate properly unless the CAN bus is functional |
| | ENGINE RUNNING? | The LOSS OF ENGINE SPEED SENSOR fault 4322 is active or CANBUS FAILURE – ENGINE CONTROL- LER fault 666 is active |
| | HIGH TILT ANGLE | The CHASSIS TILT SENSOR OUT OF RANGE fault 814 is active |
| | HOT ENGINE | The HIGH ENGINE TEMP fault 438 is active |
| | OPEN FOOTSWITCH | In platform mode, the footswitch must be open at the start of the test |
| | CLOSE FOOTSWITCH | In platform mode, the operator must close the footswitch when this message is displayed |
| | BAD FOOTSWITCH | The two footswitch signals are not changing together, probably because one is open circuit. Check footswitch and wiring |
| | OPEN FOOTSWITCH | In platform mode, the operator must open the footswitch when this message is displayed |
| | PLATFORM OVERLOADED | Load Sensing is configured and the ground module considers the platform to be overloaded |
| TESTING VALVES | | Indicates that the valve test is beginning. Each valve is alternately energized and de-energized; checks are made for open- and short- circuit valve coils NOTE: In platform mode, the footswitch must be closed NOTE: Tower lift valves are not tested if TOWER LIFT=NO. Tower telescope valves are not tested if TOWER TELE=NO. Jib valves are not tested if JIB = NO. Extendable axle valves are not tested if EXT AXLES=NO. Four wheel steer valves are not tested if 4WS=NO NOTE: Left/right jib valves are not tested unless JIB = SIDESWING Problems that can be reported include below messages |
| | CANT TEST VALVES | There is a wiring problem, which prevents the valve test from functioning correctly. Check valve wiring. Check ground alarm & hour meter wiring |
| | XXXXXXXX S/C | The named valve is drawing too much current so is presumed to be short-circuited. Check valve wiring |
| | XXXXXXXX O/C | The named valve is drawing too little current so is presumed to be open-circuit. Check valve wiring |
| CHECKING INPUTS | | Indicates that the inputs test is beginning. Every input is checked to ensure that it is in its "normal" position; function switches should be open, cutout switches should be closed, joysticks should be in neutral In platform mode any non-neutral platform switch or joystick is reported; any active cutouts are reported In ground mode any non-neutral ground switches is reported; any active cutouts are reported. NOTE: Switches, which are not in use (due to the settings of machine digits), are not checked. NOTE: The pump pot is checked only for a wire-off condition; it can be at any demand from creep to maximum Problems that can be reported include below messages |
| | CHECK XXXXXXXX | The named switch is not in its "normal" position. Check switch & wiring |
| | CHECK XXXXXXXX JOY | The named joystick appears to be faulty. Check joystick |

Table 6-5. System Test Messages

| Message Displayed on Analyzer | Message Displayed on Analyzer | Description |
|-------------------------------|-------------------------------|--|
| TESTING LAMPS | | Indicates that the lamps test is beginning. Each lamp is energized in turn; a prompt asks for confirmation that the lamp is lit ENTER must be pressed or clicked to continue the test NOTE: Lamps, which are not in use (due to the settings of machine digits), are not checked NOTE: Platform Lamps are only tested in platform mode NOTE: The GM overload lamp and 500# capacity lamp are not tested NOTE: Head and tail lamps are tested in both platform and ground mode if enabled by a machine digit |
| TESTING ALARMS | | Indicates that the alarms test is beginning. Each alarm is energized in turn; a prompt asks for confirmation that the alarm is sounding |
| | | ENTER must be pressed or clicked to continue the test |
| | | NOTE: The platform alarm and the horn are only tested in platform mode |
| | | NOTE: The ground alarm is not tested if GROUND ALARM = NO |
| TEST ALL INPUTS? | | Prompts whether to check every operator input. If ESC is pressed or clicked, the system test ends If ENTER is pressed or clicked, each operator input is prompted for in turn In platform mode every platform switch and joystick is tested In ground mode every ground switch is tested. NOTE: Tower lift switches are not tested if TOWER LIFT=NO. Tower telescope switches are not tested if TOWER TELE=NO. Jib switches are not tested if JIB = NO. Extendable axle switches are not tested if EXT AXLES=NO. Four wheel steer switches are not tested if 4WS=NO. NOTE: Left/right jib switches are not tested unless JIB = SIDESWING. Prompts displayed during the operator input test below messages. |
| | CLOSEXXXXXX | The named switch should be closed |
| | OPENXXXXXX | The named switch should be opened |
| | XXXXXX XXXXXX TO MAX | The named joystick should be pushed to its full extent in the named direction |
| | XXXXXX XXXXXX TO MIN | The named joystick should be returned to neutral from the named direction |
| | PUMP POT TO MAX | The pump pot should be turned to maximum |
| | PUMP POT TO MIN | The pump pot should be turned to minimum |
| | MULTIPLE CLOSURE | More than one operator input is closed; if only one has been operated, there could be a short between two inputs |
| TESTS COMPLETE | | Indicates that the system test is complete. Any problems reported should have been noted and should now be rectified. Press ESC/CANCEL to return to the RUN SYSTEM TEST Analyzer menu |

6.7 MACHINE DIAGNOSTICS PARAMETERS

Table 6-6. Machine Diagnostics Parameters

| Diagnosics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|---|--|--|--|
| DRIVE/STEER | DRIVE DEMAND | FORWARD/REVERSE XXX% | Direction and command percentage of Drive as reported by PM |
| | DRIVE OUTPUT | FORWARD/REVERSE XXX% | Direction and current output percentage |
| | DRIVE OUT mA | FORWARD/REVERSE XXXmA | Direction and current output command |
| | DRIVE FDBK mA | XXXmA | Current feedback measurement |
| | STEER DEMAND | LEFT/RIGHT XXX% | Direction and command percentage of Steer as reported by PM. |
| | STEER OUP TUT | LEFT/RIGHT XXX% | Direction and PWM output percentage |
| | LT TRACK DEMAND | FORWARD/REVERSE XXX% | Direction and command percentage of Left Track Drive as reported by PM |
| | LT TRACK OUTPUT | FORWARD/REVERSE XXX% | Direction and current Left Track output percentage |
| | LT TRACK OUT mA | FORWARD/REVERSE XXXmA | Direction and current Left Track output command |
| | LT TRACK FDBK mA | XXXmA | Left Track current feedback measurement |
| | RT TRACK DEMAND | FORWARD/REVERSE XXX% | Direction and command percentage of Right Track Drive as reported by PM |
| | RT TRACK OUTPUT | FORWARD/REVERSE XXX% | Direction and current Right Track output percentage |
| | RT TRACK OUT mA | FORWARD/REVERSE XXXmA | Direction and current Right Track output command |
| | RT TRACK FDBK mA | XXXmA | Right Track current feedback measurement |
| | DRV/ST JS ENABLE | CLOSED/OPEN | State of Drive / Steer Joystick Enable |
| | STEER TYPE | NORMAL/CRAB/COORDINATED | Steer Type Status (MACHINE SETUP → 4 WHEEL STEER = YES) |
| | BRAKES STATUS | LOCKED/RELEASED | Status of Brake Valve output |
| | 2SPEED OUTPUT | ON/OFF | Status of 2 Speed Valve output |
| | DRIVE MODE | MAX SPEED/MAX TORQUE/MID ENGINE | Drive Mode Status |
| | DRV ORIENTT SW | OPEN /CLOSED | State of DOS Switch |
| | DRV ORIENT MODE | INLINE/SWUNG | DOS state |
| | DRV ORIENT STATE | CONFIRMED/REQUIRED | InLine and DOS Active = Confirmed |
| DRV ORNT OVR SW | CLOSED/OPEN | State of Drive Orientation Override Switch | |
| CRIBBING MODE SW | CLOSED/OPEN | State of Cribbing Mode Switch; only displayed if MACHINE SETUP → CRIBBING = YES | |
| CRIBBING MODE | DISABLED/ENABLED | Reflects state of Cribbing Mode Switch; only displayed if MACHINE SETUP → CRIBBING = YES | |
| BOOM FUNCTIONS | SWING DEMAND | LEFT/RIGHT XXX% | Direction and percentage of input command from Swing Joystick or Ground% |
| | SWING OUTPUT | LEFT/RIGHT XXX% | Direction and current output percentage |
| | SWING OUTPUT mA | LEFT/RIGHT XXXmA | Direction and current output command |
| | SWING FDBK mA | XXXmA | Current feedback measurement |
| | LIFT DEMAND | UP/DOWN XXX% | Direction and percentage of Lift input command |
| | LIFT OUTPUT | UP/DOWN XXX% | Direction and current output percentage |

Table 6-6. Machine Diagnostics Parameters

| Diagnosics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|---|--|--|--|
| BOOM FUNCTIONS | LIFT OUTPUT mA | UP/DOWN XXXXmA | Direction and current output command |
| | LIFT FDBK mA | XXXXmA | Current feedback measurement |
| | LIFT DN AUX | ON/OFF | Status of Aux Lift Down |
| | TELE DEMAND | IN/OUT XXX%/CREEP | Direction and percentage of input command (or CREEP if selected) from Function Speed Pot or Ground% |
| | TELE OUTPUT | IN/OUT XXX% | Direction and current output percentage for Flow Control Valve mapped to Tele Personalities |
| | TELE OUTPUT mA | IN/OUT XXXXmA | Direction and current output command |
| | TELE FDBK mA | XXXXmA | Current feedback measurement |
| | JIB LIFT DEMAND | UP/DOWN XXX%/CREEP | Direction and percentage of input command (or CREEP if selected) from Function Speed Pot or Ground%; only displayed if MACHINE SETUP → JIB = YES |
| | JIB LIFT OUTPUT | UP/DOWN XXX% | For Up, direction and current output percentage for Flow Control mapped to Jib Lift Up Personality range; for Down, direction and PWM output percentage; only displayed if MACHINE SETUP → JIB = YES |
| | PLAT LVL DEMAND | UP/DOWN XXX%/CREEP | Direction and percentage of input command (or CREEP if selected) from Function Speed Pot or Ground% |
| | PLAT LVL OUTPUT | UP/DOWN XXX% | Direction and current output percentage for Flow Control mapped to Platform Level Personality range |
| | PLAT LVL OUT mA | UP/DOWN XXXXmA | Direction and current output command |
| | PLAT LVL UP FDBK | XXXXmA | Platform Level Up Current feedback measurement |
| | PLAT LVL DN FDBK | XXXXmA | Platform Level Down Current feedback measurement |
| | PLAT ROT DEMAND | LEFT/RIGHT XXX%/CREEP | Direction and percentage of input command (or CREEP if selected) from Function Speed Pot or Ground% value = 0% or 100% |
| | PLAT ROT OUTPUT | LEFT/RIGHT XXX% | Direction and current output percentage for Flow Control mapped to Platform Rotate Personality range; for 600SC value = 0% or 100% |
| | LF PRS REL OUTPT | ON/OFF | Status of Low Flow Pressure Release Valve; Only display if Low Flow Pressure Release is Configured |
| | MAIN DUMP OUTPUT | ON/OFF | Status of Main Dump Valve |
| | TELE IN DUMP | ON/OFF | Status of Telescope In Dump Valve |
| | FUNCTION SPEED | SETTING: XXX% | Displays the percentage demand from the Function Speed Potentiometer. |
| CREEP SW | OPEN/CLOSED | Status of Creep Switch Input | |
| CREEP MODE | ON/OFF | Displays status of Creep Mode | |

Table 6-6. Machine Diagnostics Parameters

| Diagnosics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|---|--|--|--|
| ENGINE | OPERATING STATE | STOPPED/CRANKING/STARTING/ RUNNING | Displays Engine State |
| | GLOW PLUG | NOT ACTIVE/ACTIVE | Display diagnostic if glow plugs configured: MACHINE SETUP → GLOW PLUG ≠ NO GLOW PLUGS |
| | COOLANT TEMP | XXC/XXF | Degrees For C displayed depending on Machine Setup Configuration |
| | ENGINE OIL PRESS | XXXXPSI/XXXXKPA | If Ford read > 10 PSI display OK, else LOW If Deutz, display transmitted value |
| | FUEL SELECTION | STATUS GAS/LP | MACHINE SETUP → ENGINE = FORD DUAL FUEL |
| | FUEL PRESS | XXXXPSI/XXXXKPA | MACHINE SETUP → ENGINE = EMR 4 |
| | AMBIENT TEMP | XXC/XXF | |
| | FUEL LEVEL | FULL; ¾; ½; ¼; LOW; EMPTY; OK; ERROR | MACHINE SETUP → FUEL LEVEL ≠ NONE |
| | ENGINE SPEED | ACTUAL XXXXRPM | RPM read from speed sensor if engine = over CAN2 for Deutz, Ford Dual Fuel |
| | ENGINE SPEED | TARGET XXXXRPM | UGM - commanded Target RPM |
| | SYSTEM | UGM BATTERY | XX.XV |
| PLATFORM MODULE | | BATTERY XX.XV | PM measured battery voltage |
| UGM TEMP | | XXC/XXF | UGM on-board temperature measurement |
| PLATFORM SELECT | | KEYSWITCH: OPEN KEYSWITCH: CLOSED | Displays whether Platform Keyswitch position is being selected |
| GROUND SELECT | | KEYSWITCH: OPEN KEYSWITCH: CLOSED | Displays whether Ground Keyswitch position is being selected |
| STATION CONTROL | | GROUND/PLATFORM | Displays Active control station per System Mode definition |
| FOOTSWITCH INPUT | | GROUND: OPEN GROUND: CLOSED | State of Footswitch input at UGM |
| FOOTSWITCH INPUT | | PLATFORM: OPEN PLATFORM: CLOSED | State of Footswitch input at PM (closed when footswitch not acti- vated) |
| PLATFORM ANGLE: | | XXX.XDEG | Platform Angle with respect to Chassis |
| PLAT ANGLE 1 RAW | | XX.X% | Platform Angle sensor #1 raw PWM% |
| PLAT ANGLE 2 RAW | | XX.X% | Platform Angle sensor #2 raw PWM% |
| ELEVATION MODE | | ABOVE/NOT ABOVE | Elevation State |
| CAPACITY MODE | | RESTRICTED/UNRESTRICTED/ERROR | Dual Capacity State; Dual Capacity is configured |
| TRANSPORT MODE | | IN TRANSPORT/OUT OF TRANSPORT | Transport Position |
| CREEP SW | | OPEN/CLOSED | Status of Creep Switch Input |
| CREEP MODE | | ON/OFF | Displays status of Creep Mode |
| CHASSIS TILT | | XX.XDEG | Combined X/Y Absolute Angle |
| CHASSIS TILT | | X-AXIS: XX.XDEG | X Angle with respect to sign |
| CHASSIS TILT | | Y-AXIS: XX.XDEG | Y Angle with respect to sign |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-6. Machine Diagnostics Parameters

| Diagnosics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|---|--|--|--|
| SYSTEM | GENSET/WELDER SW | OPEN/CLOSED | Platform Generator Enable switch; only displayed if MACHINE SETUP → GEN SET/ WELDER ≠ NO |
| | GENSET ENABLE | OUTPUT: ON/OFF | UGM Generator Relay Enable output; only displayed if MACHINE SETUP → GEN SET/ WELDER ≠ NO |
| | H&T LIGHTS SW | OPEN/CLOSED | Only displayed if in Platform Mode and MACHINE SETUP → H&T LIGHTS = YES |
| | H&T LIGHTS OUT | ON/OFF | UGM Nite Brite Relay Enable output; only displayed if in Platform Mode and MACHINE SETUP → H&T LIGHTS = YES |
| | SOFT TOUCH INPUT | OPEN/CLOSED | State of Soft Touch Platform Input (J1-20); closed when active; only displayed if Plat- form Mode and MACHINE SETUP → SOFT TOUCH = YES. |
| | SKYGUARD INPUTS | OPEN/CLOSED/DISAGREE | SkyGuard Input #1 (PLT J7-18) AND SkyGuard Input #2 (PLT J1-23) state; only displayed if in Platform Mode and MACHINE SETUP → SKYGUARD = YES. |
| | SKYGUARD INPUT 1 | OPEN/CLOSED | State of SkyGuard Platform Input #1 (J7-18); relay NC contacts – closed when active; only displayed if in Platform Mode and MACHINE SETUP → SKYGUARD = YES. |
| | SKYGUARD INPUT 2 | OPEN/CLOSED | State of SkyGuard Platform Input #2 (J1-23); relay NC contacts – closed when active; only displayed if in Platform Mode and MACHINE SETUP → SKYGUARD = YES. |
| | AMBIENT TEMP | XXXC/XXXF | Ambient Temperature sensor reading; Only displayed if MACHINE SETUP → TEMP CUTOUT = YES |
| | LOW TEMPERATURE | CUTOUT: ACTIVE/INACTIVE/FAULTY | Status of Low Temperature Cutout; Only displayed if MACHINE SETUP → TEMP CUTOUT = YES |
| | MSSO | ACTIVE/INACTIVE | Status of MSSO; Only displayed if MACHINE SETUP → MARKET = CE |
| | WIRE ROPE | SWITCH: OPEN/CLOSED | State of Wire Rope Service Switch input (J3-8); closed when active; MACHINE SETUP → CABLE SWITCH = YES |
| OPER CONTROLS | JOYSTICK DRIVE | FORWARD/REVERSE XXX% | Drive Joystick drive direction and command percentage as reported from PM; only dis- played if in Platform Mode |
| | JOYSTICK STEER | LEFT/RIGHT XXX% | Drive Joystick steer direction and percentage command as reported from PM; only dis- played if in Platform Mode |
| | JOYSTICK SWING | LEFT/RIGHT XXX% | Lift/Swing Joystick Swing direction and percentage command as reported from PM; only displayed if in Platform Mode |
| | JOYSTICK LIFT | UP/DOWN XXX% | Lift/Swing Joystick Lift direction and percentage command as reported from PM; only displayed if in Platform Mode |
| | DRV ORNT OVR SW | CLOSED/OPEN | State of Drive Orientation Override Switch if in Platform Mode |
| | FUEL SELECT SW | OPEN/CLOSED | Status of Platform Toggle Switch Input if in Platform Mode and MACHINE SETUP → ENGINE = FORD DUAL FUEL |
| | START SWITCH | OPEN/CLOSED | Status of Ground/Platform Toggle Switch Input |
| | SWING LEFT SW | OPEN/CLOSED | Status of Ground Toggle Switch Input if in Ground Mode |
| | SWING RIGHT SW | OPEN/CLOSED | Status of Ground Toggle Switch Input if in Ground Mode |

Table 6-6. Machine Diagnostics Parameters

| Diagnosics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|---|--|---|--|
| OPER CONTROLS | LIFT UP SW | OPEN/CLOSED | Status of Ground Toggle Switch Input if in Ground Mode |
| | LIFT DN SW | OPEN/CLOSED | Status of Ground Toggle Switch Input if in Ground Mode |
| | TELE IN SW | OPEN/CLOSED | Status of Ground/Platform Toggle Switch Input |
| | TELE OUT SW | OPEN/CLOSED | Status of Ground/Platform Toggle Switch Input |
| | JIB LIFT UP SW | OPEN/CLOSED | Status of Ground/Platform Toggle Switch Input; only displayed if MACHINE SETUP → JIB = YES |
| | JIB LIFT DN SW | OPEN/CLOSED | Status of Ground/Platform Toggle Switch Input; only displayed if MACHINE SETUP → JIB = YES |
| | PLAT LEVEL UP SW | OPEN/CLOSED | Status of Ground/Platform Toggle Switch Input |
| | PLAT LEVEL DN SW | OPEN/CLOSED | Status of Ground/Platform Toggle Switch Input |
| | PLAT ROT LEFT SW | OPEN/CLOSED | Status of Ground/Platform Toggle Switch Input |
| | PLAT ROT RIGHT SW | OPEN/CLOSED | Status of Ground/Platform Toggle Switch Input |
| | MAX SPEED SW | OPEN/CLOSED | Status of Platform Toggle Switch Input; only displayed if in Platform Mode |
| | MAX TORQUE SW | OPEN/CLOSED | Status of Platform Toggle Switch Input; only displayed if in Platform Mode |
| | CREEP SW | OPEN/CLOSED | Status of Creep Switch Input; only displayed if in Platform Mode |
| | HORN SW | OPEN/CLOSED | Status of Platform Switch Input; only displayed if in Platform Mode |
| | H&T LIGHT SW | OPEN/CLOSED | Status of Platform Toggle Switch Input; only displayed if in Platform Mode and MACHINE SETUP → H&T LIGHTS = YES |
| | GENSET/WELDER SW | OPEN/CLOSED | Status of Platform Toggle Switch Input; only displayed if MACHINE SETUP → GEN SET/WELDER ≠ NO |
| | SG OVERRIDE SW | OPEN/CLOSED | Status of Platform SkyGuard Override Switch Input; only displayed if in Platform Mode MACHINE SETUP → SOFT TOUCH = NO and MACHINE SETUP → SKYGUARD = YES |
| | ST OVERRIDE SW | OPEN/CLOSED | Status of Platform SkyGuard Override Switch Input; only displayed if in Platform Mode MACHINE SETUP → SOFT TOUCH = YES and MACHINE SETUP → SKYGUARD = NO |
| SG/ST OVRIDE SW | OPEN/CLOSED | Status of Platform SkyGuard Override Switch Input; only displayed if in Platform Mode and MACHINE SETUP → SOFT TOUCH = YES and MACHINE SETUP → SKYGUARD = YES | |
| MSSO SW | OPEN/CLOSED | Status of Ground MSSO Switch Input; only displayed if MACHINE SETUP → MARKET = CE | |
| CAPACITY SW | OPEN/CLOSED | Status of Platform Dual Capacity Switch Input; only displayed if Dual Capacity is configured | |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-6. Machine Diagnostics Parameters

| Diagnostics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|---|--|--|---|
| PLATFORM LOAD (DISPLAY ONLY IF MACHINE SETUP → LOAD SYSTEM ≠ NO) | PLATFORM LOAD | STATE: OK/OVERLOAD | LSS Status |
| | PLATFORM LOAD | ACTUAL: XXXIb | Platform Load??? if Platform Load == Unhealthy |
| | PLATFORM LOAD ² | GROSS: XXXIb | If 4-Cell LSS; Combined weight of all cells (accounting for sign) If 1-Cell LSS; Platform Gross used to calculate Platform Load ??? if (Platform Gross 1 == Unhealthy and Platform Gross 2 == Unhealthy) |
| | PLATFORM LOAD ² | OFFSET: XXXIb | If 4-Cell LSS; Stored Platform Empty weight |
| | PLATFORM LOAD ² | OFFSET 1: XXXIb | If 1-Cell LSS; Stored Unloaded Platform Weight of Strain Gauge 1 ??? if DTC 825 is active |
| | PLATFORM LOAD ² | OFFSET 2: XXXIb | If 1-Cell LSS; Stored Unloaded Platform Weight of Strain Gauge 2 ??? if DTC 825 is active |
| | PLATFORM LOAD ² | ACCESSORY XXXIb | Stored Accessory weight; ??? if DTC 825 is active |
| | PLATFORM LOAD ² | UNRESTRICT XXXIb | Stored Unrestricted Rated Load; ??? if DTC 825 is active |
| | PLATFORM LOAD ² | RSTRIC XXXIb | If Dual Capacity is Configured; Stored Restricted Rated Load; ??? if DTC 825 is active |
| | PLATFORM LOAD ² | CELL 1: XXXIb | If 4-Cell LSS; Gross weight reading of Cell 1 |
| | PLATFORM LOAD ² | CELL 2: XXXIb | If 4-Cell LSS; Gross weight reading of Cell 2 |
| | PLATFORM LOAD ² | CELL 3: XXXIb | If 4-Cell LSS; Gross weight reading of Cell 3 |
| | PLATFORM LOAD ² | CELL 4: XXXIb | If 4-Cell LSS; Gross weight reading of Cell 4 |
| | PLATFORM LOAD ² | RAW 1: XXXIb | If 1-Cell LSS; Platform Gross 1; ??? if Platform Gross 1 == Unhealthy |
| PLATFORM LOAD ² | RAW 2: XXXIb | If 1-Cell LSS; Platform Gross 2; ??? if Platform Gross 2 == Unhealthy | |
| CAN STATISTICS ² | CAN 1 STATISTICS | RX/SEC: XXX | |
| | CAN 1 STATISTICS | TX/SEC: XXX | |
| | CAN 1 STATISTICS | BUS OFF: XXX | |
| | CAN 1 STATISTICS | PASSIVE: XXX | |
| | CAN 1 STATISTICS | MSG ERROR: XXXX | |
| | CAN 2 STATISTICS | RX/SEC: XXX | |
| | CAN 2 STATISTICS | TX/SEC: XXX | |
| | CAN 2 STATISTICS | BUS OFF: XXX | |
| | CAN 2 STATISTICS | PASSIVE: XXX | |
| | CAN 2 STATISTICS | MSG ERROR: XXXX | |

Table 6-6. Machine Diagnostics Parameters

| Diagnostics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|--|--|--|--|
| DEBUGUGMI/0 ² | DEBUG DIAG DIGITAL INPUTS | DIG IN J1-21 HIGH/LOW DIG IN J1-34 HIGH/LOW DIG IN J1-35 HIGH/LOW DIG IN J2-24 HIGH/LOW DIG IN J3-8 HIGH/LOW DIG IN J3-9 HIGH/LOW DIG IN J3-10 HIGH/LOW DIG IN J3-11 HIGH/LOW DIG IN J4-4 HIGH/LOW DIG IN J4-5 HIGH/LOW DIG IN J4-6 HIGH/LOW DIG IN J4-7 HIGH/LOW DIG IN J4-8 HIGH/LOW DIG IN J4-9 HIGH/LOW DIG IN J4-10 HIGH/LOW DIG IN J4-11 HIGH/LOW DIG IN J4-16 HIGH/LOW DIG IN J4-17 HIGH/LOW DIG IN J4-18 HIGH/LOW DIG IN J4-19 HIGH/LOW DIG IN J4-20 HIGH/LOW DIG IN J4-21 HIGH/LOW DIG IN J4-22 HIGH/LOW DIG IN J4-23 HIGH/LOW DIG IN J4-30 HIGH/LOW DIG IN J4-33 HIGH/LOW DIG IN J4-34 HIGH/LOW DIG IN J4-35 HIGH/LOW DIG IN J7-2 HIGH/LOW DIG IN J7-3 HIGH/LOW DIG IN J7-12 HIGH/LOW DIG IN J7-15 HIGH/LOW DIG IN J7-21 HIGH/LOW DIG IN J12-8 HIGH/LOW | Left and Right arrow keys scroll through the inputs. 1 st Line = DIG IN |

Table 6-6. Machine Diagnostics Parameters

| Diagnostics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|--|--|--|---|
| | DEBUG DIAG DIGITAL OUTPUTS | DIG OUT J1-2 ON/OFF DIG OUT J1-7 ON/OFF DIG OUT J1-11 ON/OFF DIG OUT J1-12 ON/OFF DIG OUT J1-13 ON/OFF DIG OUT J1-23 ON/OFF DIG OUT J1-32 ON/OFF DIG OUT J2-2 ON/OFF DIG OUT J2-3 ON/OFF DIG OUT J2-4 ON/OFF DIG OUT J2-5 ON/OFF DIG OUT J2-7 ON/OFF DIG OUT J2-10 ON/OFF DIG OUT J2-12 ON/OFF DIG OUT J2-13 ON/OFF DIG OUT J2-15 ON/OFF DIG OUT J2-16 ON/OFF DIG OUT J2-21 ON/OFF DIG OUT J2-23 ON/OFF DIG OUT J2-32 ON/OFF DIG OUT J2-33 ON/OFF DIG OUT J4-1 ON/OFF DIG OUT J4-2 ON/OFF DIG OUT J4-3 ON/OFF DIG OUT J4-13 ON/OFF DIG OUT J4-14 ON/OFF DIG OUT J4-15 ON/OFF DIG OUT J4-26 ON/OFF DIG OUT J4-27 ON/OFF DIG OUT J4-28 ON/OFF DIG OUT J4-29 ON/OFF DIG OUT CS1GC ON/OFF ¹ DIG OUT CS2GC ON/OFF ¹ DIG OUT LED ON/OFF DIG OUT TP1 ¹ | Left and Right arrow keys scroll through the inputs. 1st Line = DIG OUT JX.XX and 2nd Line displays output value |

Table 6-6. Machine Diagnostics Parameters

| Diagnostics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|--|--|--|-------------|
| | DEBUG DIAG PWM OUTPUTS | PWM J1-1 XXX.XX% XXXHZ PWM J1-3 XXX.XX% XXXHZ PWM J1-6 XXX.XX% XXXHZ PWM J1-10 XXX.XX% XXXHZ PWM J1-20 XXX.XX% XXXHZ PWM J1-22 XXX.XX% XXXHZ PWM J2-8 XXX.XX% XXXHZ PWM J2-9 XXX.XX% XXXHZ PWM J2-11 XXX.XX% XXXHZ PWM J2-19 XXX.XX% XXXHZ PWM J2-20 XXX.XX% XXXHZ PWM J2-22 XXX.XX% XXXHZ PWM J2-26 XXX.XX% XXXHZ PWM J2-27 XXX.XX% XXXHZ PWM J2-31 XXX.XX% XXXHZ PWM J2-34 XXX.XX% XXXHZ PWM J2-35 XXX.XX% XXXHZ FET J3-1 XXX.XX% XXXHZ FET J3-2 XXX.XX% XXXHZ FET J3-4 XXX.XX% XXXHZ FET J3-5 XXX.XX% XXXHZ FET J3-6 XXX.XX% XXXHZ | |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-6. Machine Diagnostics Parameters

| Diagnostics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|--|--|--|---|
| | | FET J3-14 XXX.XX% XXXHZ PWM J4-12 XXX.XX% XXXHZ | |
| | ANALOG INPUTS | ADC J1-01 FB XXXX1 ADC J1-01 IS XXXX1 ADC J1-02 FB XXXX1 ADC J1-03 FB XXXX1 ADC J1-06 FB XXXX1 ADC J1-07 FB XXXX1 ADC J1-10 FB XXXX1 ADC J1-11 FB XXXX1 ADC J1-12 FB XXXX1 ADC J1-13 FB XXXX1 ADC J1-14 XXXX ADC J1-15 XXXX ADC J1-20 FB XXXX1 ADC J1-22 FB XXXX1 ADC J1-23 FB XXXX1 ADC J2-01 FB XXXX1 ADC J2-02 FB XXXX1 ADC J2-03 FB XXXX1 ADC J2-04 FB XXXX1 ADC J2-05 FB XXXX1 ADC J2-07 FB XXXX1 ADC J2-08 FB XXXX1 ADC J2-09 FB XXXX1 ADC J2-10 FB XXXX1 ADC J2-11 FB XXXX1 ADC J2-12 FB XXXX1 ADC J2-13 FB XXXX1 ADC J2-15 FB XXXX1 ADC J2-16 FB XXXX1 ADC J2-19 FB XXXX1 ADC J2-20 FB XXXX1 ADC J2-22 FB XXXX1 ADC J2-23 FB XXXX1 ADC J2-25 XXXX ADC J2-26 FB XXXX1 ADC J2-27 FB XXXX1 ADC J2-31 FB XXXX1 ADC J2-32 FB XXXX1 ADC J2-33 FB XXXX1 | Left and Right arrow keys scroll through the inputs. 1st Line = ADC |

Table 6-6. Machine Diagnostics Parameters

| Diagnosics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|---|--|---|--|
| | | ADC J2-34 FB XXXX1 ADC J2-35 FB XXXX1 ADC J3-01 IS XXXX1 ADC J3-02 IS XXXX1 ADC J3-04 IS XXXX1 ADC J3-05 IS XXXX1 ADC J3-06 IS XXXX1 ADC J3-13 XXXX ADC J3-14 IS XXXX1 ADC J4-12 FB XXXX1 ADC J7-2 XXXX ADC J7-04 XXXX ADC J7-07 XXXX ADC J7-08 XXXX ADC J7-20 XXXX ADC J8-02 XXXX ADC AMBIENT XXXX1 ADC VOFCS XXXX1 | |
| | FREQUENCY INPUTS | FREQ IN J1-16 XXXXX HZ FREQ IN J12-1 XXXXX HZ FREQ IN J12-2 XXXXX HZ | Left and Right arrow keys scroll through the inputs. 1st Line = FREQ IN JX.XX and 2nd Line displays frequency of measurement XXXXX Hz |
| DATALOG | DATALOG TIME | ON XXXXH XXM | *Controller On time |
| | DATALOG TIME | ENGINE XXXXH XXM | *Engine Running time |
| | DATALOG TIME | ENABLD XXXXH XXM | *Combined time for Machine Enabled in Platform Mode while ENGINE RUNNING + any function active while in Ground Mode (excludes APU/Emergency Descent) |
| | DATALOG TIME | AUX XXXXH XXM | Auxiliary Power/Emergency Descent Active time |
| | DATALOG TIME | DRIVE XXXXH XXM | Drive Forward + Reverse time |
| | DATALOG TIME | DRV MS XXXXH XXM | Max Speed Drive Forward + Reverse time |
| | DATALOG TIME | DRV MT XXXXH XXM | Max Torque Drive Forward + Reverse time |
| | DATALOG TIME | DRV ME XXXXH XXM | Mid Engine Drive Forward + Reverse time |
| | DATALOG TIME | DRV CP XXXXH XXM | Creep Drive Forward + Reverse time |
| | DATALOG TIME | STEER XXXXH XXM | Steer Left + Right time |
| | DATALOG TIME | SWING XXXXH XXM | Swing Left + Right time |
| | DATALOG TIME | LIFT XXXXH XXM | Lift Up + Down time |
| | DATALOG TIME | TELE XXXXH XXM | Tele In + Out time |
| | DATALOG TIME | JIB XXXXH XXM | Jib Lift Up + Down time (MACHINE SETUP → JIB = YES) |
| | DATALOG TIME | LEVEL XXXXH XXM | Platform Level Up + Down time |
| | DATALOG TIME | ROTATE XXXXH XXM | Platform Rotate Left + Right time |
| | DATALOG TIME | GEN XXXXH XXM | *Generator Enable Relay on time |

Table 6-6. Machine Diagnostics Parameters

| Diagnostics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|--|--|--|--|
| | For time logging of functions with 30-second resolution, the first 15 seconds of function run time shall be logged as a ½ minute increment and there after every 30 seconds of run time shall be logged as a ½ minute increment. *The functions annotated with an asterisk in the description are function timers with 60-second resolution, for which the timer in the rule above is doubled. | | |
| | DATALOG CYCLES | DRVE FWD XXXXXXXX | Number of times Drive Forward is commanded |
| | DATALOG CYCLES | DRVE REV XXXXXXXX | Number of times Drive Reverse is commanded |
| | DATALOG CYCLES | STEER LT XXXXXXXX | Number of times Steer Left Output is commanded |
| | DATALOG CYCLES | STEER RT XXXXXXXX | Number of times Steer Right Output is commanded |
| | DATALOG CYCLES | SWING LT XXXXXXXX | Number of times Swing Left output is commanded |
| | DATALOG CYCLES | SWING RT XXXXXXXX | Number of times Swing Right output is commanded |
| | DATALOG CYCLES | LIFT UP XXXXXXXX | Number of times Lift Up output is commanded |
| | DATALOG CYCLES | LIFT DN XXXXXXXX | Number of times Lift Down output is commanded |
| | DATALOG CYCLES | TELE IN XXXXXXXX | Number of times Tele In output is commanded |
| | DATALOG CYCLES | TELE OUT XXXXXXXX | Number of times Tele Out output is commanded |
| | DATALOG CYCLES | JIB UP XXXXXXXX | Number of times Jib Lift Up is commanded (MACHINE SETUP → JIB = YES) |
| | DATALOG CYCLES | JIB DOWN XXXXXXXX | Number of times Jib Lift Down is commanded (MACHINE SETUP → JIB = YES) |
| | DATALOG CYCLES | LEVEL UP XXXXXXXX | Number of times Level Up is commanded |
| | DATALOG CYCLES | LEVEL DN XXXXXXXX | Number of times Level Down is commanded |
| | DATALOG CYCLES | ROT LEFT XXXXXXXX | Number of times Rotate Left is commanded |
| | DATALOG CYCLES | ROT RGHT XXXXXXXX | Number of times Rotate Right is commanded |
| | DATALOG CYCLES | UGM ON XXXXXXXX | Number of times Power is applied |
| | DATALOG CYCLES | GND OPS XXXXXXXX | Number of times machine is in Ground Mode and any function is active (excludes APU/ Emergency Descent) |
| | DATALOG CYCLES | PLAT OPS XXXXXXXX | Number of times machine is Enabled from Platform Station (excludes APU/Emergency Descent) |
| | DATALOG CYCLES | AUX OPS XXXXXXXX | Number of times machine Auxiliary Power/Emergency Descent is Enabled |
| | DATALOG CYCLES | GEN ON XXXXXXXX | Number of times Generator Enable Relay is turned On; information logged and stored only if machine configured for generator. |
| | DATALOG CYCLES | BOOM TR XXXXXXXX | Number of times the Boom transitions from Below Elevation to Above Elevation |
| | DATALOG CYCLES | DUAL CAP XXXXXXXX | Number of times the Boom transitions from Restricted to Unrestricted mode (Dual Capacity is configured) |
| | Cycle counter shall increment up to a limit of 1,000,000, except Steer shall have a limit of 2,000,000 per direction. | | |
| | DATALOG: MAX | UGM TEMP XXXC/ UGM TEMP XXXF | Hottest Temp observed by UGM |
| | DATALOG: MIN | UGM TEMP XXXC/ UGM TEMP XXXF | Coldest Temp observed by UGM |

Table 6-6. Machine Diagnostics Parameters

| Diagnosics Submenu (Displayed on Analyzer 1 st Line) | Parameter (Displayed on Analyzer 1 st Line) | Parameter Value (Displayed on Analyzer 2 nd Line) | Description |
|---|--|--|--|
| | DATALOG: MAX | UGM VOLT XX.XV | Maximum input voltage observed by UGM |
| | DATALOG: MACHINE | RENTAL XXXXHXXM | *Stores Machine hours since last memory clear |
| | DATALOG: ERASE 2 | MACHINE RENTAL? | Erases stored machine rental hours |
| VERSIONS: | UGM | SOFTWARE PX.X | |
| | UGM | CNSTDATA PX.X | |
| | UGM | HARDWARE REV X | |
| | UGM | SN XXXXXX | |
| | ugm | PN XXXXXXXXXX | |
| | PLATFORM MODULE | SOFTWARE PX.X | |
| | PLATFORM MODULE | HARDWARE REV X | |
| | PLATFORM MODULE | SN XXXXXX | |
| | LSS MODULE | SOFTWARE PX.X | Displayed on if LSS is configured (4-Cell LSS) |
| | LSS MODULE | HARDWARE REV X | Display if LSS is configured (4-Cell LSS) |
| | TCU MODULE | SOFTWARE X.Xx | Displayed on if TCU is configured |
| | TCU MODULE | HARDWARE REV X | Displayed on if TCU is configured |
| | TCU MODULE | SN XXXXXX | Displayed on if TCU is configured |
| ANALYZER | ANALYZER vX.X | | |

6.8 CALIBRATING TILT SENSOR


NOTICE

A NEW TILT MODULE WILL ACT AS IF IT IS TILTED ALL OF THE TIME UNTIL THE FOLLOWING PROCEDURE IS PERFORMED.

WARNING

DO NOT CALIBRATE THE LEVEL SENSOR EXCEPT ON A LEVEL SURFACE.


1. Use the following procedure to calibrate the tilt sensor.
2. Before the tilt sensor can be calibrated, the following conditions must be met:
 - a. Turntable centered.
 - b. Boom fully retracted.
 - c. Boom angle is less than 45°.
 - d. Machine on firm, level ground.
3. Position the Platform/Ground select switch (1) to the Ground position.




4. Plug the analyzer into the connector (2) at the base of the Ground control box.



5. Pull out the Emergency Stop switch (3) and Start the engine.





6. The analyzer screen should read:




7. Use the arrow button to reach SERVICE ACCESS. Hit Enter.
 8. Enter the Access Code, 33271.
 9. Use the right Arrow key to reach CALIBRATIONS. Hit Enter.


10. Using the arrow keys, navigate to Calibrations Menu as

shown below and press **ENTER** .




11. Using the arrow keys, navigate to the Tilt Sensor calibration

as shown below and press **ENTER** .




MAE15450

12. Hit Enter. The screen will read:




MAE15540




MAF23950

13. UGM will confirm the position of the boom, then the screen will read:



MAF23940


14. When the sensor is calibrated in that position, the screen will read:






MAE15560


15. Swing the machine 180 degrees, making sure the boom is centered and in the transport position, and

NOTE: Screen appears only if the machine is on more than a 3 degree slope.

ENTER . The screen will read:



17. When the calibration is complete the screen will read as shown below. Return the machine to the travel position.




16. Hit Enter. The screen will read.

18. Hit ESC twice to go back to CALIBRATIONS.

6.9 CALIBRATING BOOM ANGLE


1. Use the following procedure to calibrate the boom angle sensor.
2. Before the tilt sensor can be calibrated, the following conditions must be met:
 - a. Tilt sensor previously calibrated.
 - b. Machine on firm, level ground.
3. Position the Platform/Ground select switch (1) to ground.




4. Plug the analyzer into the connector (2) at the base of the Ground control box.



5. Pull out the Emergency Stop switch (3) and Start the engine.




6. The analyzer screen should read:




7. Use the arrow button to reach SERVICE ACCESS. Hit Enter.
8. Enter the Access Code, 33271.
9. Use the right Arrow key to reach CALIBRATIONS. Hit Enter.


10. Use arrow keys to reach BOOM ANGLE. The Screen will read:




12. UGM will confirm the tilt sensor calibration. The screen will read.



11. Hit Enter. The screen will read.




13. Hit Enter. The screen will read.




SECTION 6 - JLG CONTROL SYSTEM


14. UGM will confirm the Boom In-Line position. The screen will read:




16. When the sensor is calibrated at lower position of the boom. The screen will read:




15. Hit Enter. The Screen will read:




17. Hit Enter. The Screen will read:




18. Hit Enter. The Screen will read:




20. When the sensor is calibrated at upper position of the boom. The screen will read:




19. UGM will confirm the position of the boom. Press Enter. The screen will read:




21. UGM will confirm the position of the boom. Press Enter. The screen will read:



22. Hit Enter. The Screen will read:




23. After few seconds. The screen will read:




24. Hit ESC twice to go back to CALIBRATIONS.

6.10 CALIBRATING LEVEL UP CRACKPOINT

1. Position the Platform/Ground select switch (1) to ground.




3. Pull out the Emergency Stop switch (3) and Start the engine.



2. Plug the analyzer into the connector (2) at the base of the Ground control box.




4. The analyzer screen should read:




5. Use the arrow button to reach SERVICE ACCESS. Hit Enter.
6. Enter the Access Code, 33271.
7. Use the right Arrow key to reach CALIBRATIONS. Hit Enter.


8. Use the arrow keys to reach LEVEL UP CRKPT. The screen will read.



9. Hit Enter. The screen will read.




10. Use arrow keys to increase the value until the function begins to move.



11. Engine RPM will reach to 1400 RPM.
 12. Using UP ARROW, increase the value until you see the basket up movement.

NOTE: Maximum Crack Point value is 1200mA. Calibration will fail if the value is increased to more than 1200mA.


13. Hit Enter. After few seconds, The screen will read:




14. Hit ESC twice to go back to CALIBRATIONS.

6.11 CALIBRATING LEVEL DOWN CRACKPOINT

1. Position the Platform/Ground select switch (1) to ground.




3. Pull out the Emergency Stop switch (3) and Start the engine.



2. Plug the analyzer into the connector (2) at the base of the Ground control box.




4. The analyzer screen should read:




5. Use the arrow button to reach SERVICE ACCESS. Hit Enter.
6. Enter the Access Code, 33271.
7. Use the right Arrow key to reach CALIBRATIONS. Hit Enter.

SECTION 6 - JLG CONTROL SYSTEM


8. Use the arrow keys to reach LEVEL DOWN CRKPT. The screen will read.



9. Hit Enter. The screen will read.



10. Use arrow keys to increase the value until the function begins to move.




11. Engine RPM will reach to 1400 RPM.

12. Using UP ARROW, increase the value until you see the basket up movement.

NOTE: Maximum Crack Point value is 1200mA. Calibration will fail if the value is increased to more than 1200mA.


13. Hit Enter. After few seconds, The screen will read:



14. Hit ESC twice to go back to CALIBRATIONS.

6.12 CALIBRATING PLATFORM ANGLE SENSOR


1. Position the Platform/Ground select switch (1) to ground.




2. Plug the analyzer into the connector (2) at the base of the Ground control box.



3. Pull out the Emergency Stop switch (3) and Start the engine.




4. The analyzer screen should read:




5. Use the arrow button to reach SERVICE ACCESS. Hit Enter.
6. Enter the Access Code, 33271.
7. Use the right Arrow key to reach CALIBRATIONS. Hit Enter.

SECTION 6 - JLG CONTROL SYSTEM


8. Use the arrow keys to reach PLATFORM ANGLE. The screen will read.




10. Hit Enter. The screen will read:




9. Hit Enter. The screen will read:




11. Hit Enter. The screen will read:




12. UGM will confirm Platform Angle Max sensor readings. The screen will read:




14. After few seconds. The screen will read:




13. Hit Enter. The screen will read:



15. UGM will confirm Platform Angle Min sensor readings. The screen will read:



16. After few seconds. The screen will read:




17. Hit ESC twice to go back to CALIBRATIONS.

Go to Discount-Equipment.com to order your parts

6.13 RESETTING THE MSSO SYSTEM

1. Position the Platform/Ground select switch (1) to the Platform position.



MAE27280

2. Plug the analyzer into the connector at the base of the platform control box.




MAE15680

3. Pull out the Emergency Stop switch and Start the engine.



MAE17820


4. The analyzer screen should read:




5. Use the arrow button to reach SERVICE ACCESS. Hit Enter.
6. Enter the Access Code, 33271.
7. Use the right Arrow key to reach CALIBRATIONS. Hit Enter.

SECTION 6 - JLG CONTROL SYSTEM

8. Use the arrow keys to reach MSSO. The screen will read:




9. Hit Enter. The screen will read:



Go to Discount-Equipment.com to order your parts

6.14 LSS SYSTEM

The JLG-designed Load Sensing System (LSS) measures platform load via a sensor mounted in the platform support structure. If the actual platform load exceeds the selected Rated Load, the following will occur:

1. The Overload Visual Warning Indicator will flash at the selected control position (platform or ground). 
2. The Platform and Ground Alarms will sound 5 seconds On, and 2 seconds Off.
3. All normal movement will be prevented from the platform control position (optional - ground control functions may be prevented).
4. Further movement is permitted by:
 - a. Removing the excess platform load until actual platform load is less than Rated Load.
 - b. Operation of the overriding emergency system (Auxiliary Power Unit).
 - c. By an authorized person at the ground control position (optional - ground control functions may be prevented).

NOTICE

THE LOAD SENSING SYSTEM MUST BE CALIBRATED WHEN ONE OR MORE OF THE FOLLOWING CONDITIONS OCCUR:

- d. LSS Sensor removal or replacement.
- e. Addition or removal of certain platform mounted accessories. (Refer to Calibration).
- f. Platform is removed, replaced, repaired or shows evidence of impact.




NOTICE



THE LOAD SENSING SYSTEM REQUIRES PERIODIC FUNCTION VERIFICATION NOT TO EXCEED 6 MONTHS FROM PREVIOUS VERIFICATION. REFER TO TESTING & EVALUATION.

All calibration procedures are menu driven through the use of a JLG Analyzer.

Diagnostic Menu

The Diagnostic Menu is another troubleshooting tool for the Load Sensing System. Sensor and status information is presented in real-time for the technician. Several sub-menus exist to organize the data.

To access the Diagnostic Menu, use the **LEFT**  and **RIGHT**  Arrow keys to select DIAGNOSTICS from the Top Level Menu. Press the **ENTER**  key to view the menu.

Press the **LEFT**  and **RIGHT**  Arrow keys to view the displays and select the various sub-menus. To access a sub-menu, press the ENTER key. Once in a sub-menu, press the

LEFT  and **RIGHT**  Arrow keys to view the various displays (just like a Top Level menu). To exit a sub-menu, press the **ESC**  key.

Table 6-7, Diagnostic Menu Descriptions details the structure of the Diagnostic Menu, and describes the meaning of each piece of information presented.

Table 6-7. Diagnostic Menu Descriptions


| Diagnosics Menu (Displayed on Analyzer 1st Line) | Parameter (Displayed on Analyzer 2nd Line) | Parameter Value (Displayed on Analyzer 2nd Line) | Description |
|---|---|---|--|
| PLATFORM LOAD | STATE: | OK / OVERLOAD | LSS Status. |
| PLATFORM LOAD | ACTUAL: | XXX.X KG | Calibrated weight of the platform. ??? if Platform Load is Unhealthy**. |
| PLATFORM LOAD (service*) | GROSS: | XXX.X KG | Gross weight of the platform. ??? if both Cells are Unhealthy**. |
| PLATFORM LOAD (service*) | OFFSET 1: | XXX.X KG | Stored offset weight of Cell 1. ??? if LSS is not calibrated. |
| PLATFORM LOAD (service*) | OFFSET 2: | XXX.X KG | Stored offset weight of Cell 1. ??? if LSS is not calibrated. |
| PLATFORM LOAD (service*) | ACCESSORY | XXX.X KG | Stored accessory weight. ??? if LSS is not calibrated. |
| PLATFORM LOAD (service*) | UNRESTRICT | XXX.X KG | UGM will set Unrestricted Rated Load as defined by Machine Configuration. |
| PLATFORM LOAD (service*) | RESTRICT | XXX.X KG | UGM will set Restricted Rated Load as defined by Machine Configuration. |
| PLATFORM LOAD (service*) | RAW 1: | XXX.X KG | Gross value from Cell 1. ??? if Unhealthy**. |
| PLATFORM LOAD (service*) | RAW 2: | XXX.X KG | Gross value from Cell 2. ??? if Unhealthy**. |
| * Indicates only visible in service view mode ** Typically indicates a DTC is active | | | |

Calibration Procedure


1. Remove everything from the platform, except permanently fixed JLG Accessories, to allow the Load Sensing System to record its' weight during calibration. This includes all tools, debris, and customer-installed devices.
2. Plug the JLG Analyzer into the Machine at the Ground Station and enter Service Access Password 33271.




3. The platform should be approximately level for calibration. Level the platform from ground control (if necessary) to within +/- 5°.
4. To access the Calibration Menu, use the LEFT and RIGHT Arrow keys to select CALIBRATION from the Top Level Menu. The screen will read:




NOTE: The Calibration Menu is not available in OPERATOR ACCESS.


5. Press the ENTER key  to view the menu. Upon entry to the Calibration Menu, the JLG Control System will link to the Analyzer and the screen will read:




6. Press Enter . The Screen will read:





NOTE: Calibration will auto fail if LSS DTC's are active (443, 444, 4479, 4480, 663, 821, 822, 823, 824, 8218, 8222 -> 8238, 991, 992, 993, 994 or 99285).

Pressing the ESC  key after starting calibration and before calibration is complete will display the CAL FAILED message. This will not disturb the prior calibration information.

7. Press ENTER . The analyzer screen will read:




8. If the platform is empty, press ENTER . The screen will read:



NOTE: Accessory weight will reset to 0 lb each time the machine is re-calibrated and will need to be re-entered.

NOTE: The Accessory weight will be temporarily stored in the Control System until calibration has been completed successfully.

Refer to Table 6-8, Accessory Weights. Use the up and down analyzer keys to enter the accessory weight(s) (in lb). When all

the accessory weights are entered, press ENTER . The screen will read:





Table 6-8. Accessory Weights


| Accessory | Weight |
|-----------------------------|--|
| SkyWelder (stick welder) | 70 lb (32 kg) |
| SkyWelder Prep | Prep only = 15 lb (7 kg) Full install = 70 lb (32 kg) |
| SkyCutter (plasma cutter) | 70 lb (32 kg) |
| SkyCutter / SkyWelder Combo | 140 lb (64 kg) |
| Fire Extinguisher | 45 lb (20 kg) |
| Overhead SoftTouch | 80 lb (36 kg) |
| Work Surface | 20 lb (9 kg) |


NOTE: Not all Accessories are available on every JLG model. Some Accessory combinations are prohibited due to excessive weight and/or load restriction. If any installed JLG Accessories are labeled with weight decals but are not listed in the table above, include their weight when entering the ACC WEIGHT value.

- The control system will calculate the load cell readings and ensure it is greater than 130 lb (59 kg), but less than 575 lb(261 kg).


If the platform weight is not within the allowed range, the calibration attempt will be unsuccessful and the Analyzer will show the following:




- Press ENTER . The control system will ask for installed accessories. The screen will show the following:




- Use the analyzer keys to select N for no or Y for yes. Press

ENTER . The screen will read:



- Use the analyzer keys to select N for no or Y for yes. Press

ENTER . The control system will default to an estimate of unrestricted capacity, which can be adjusted if necessary. Refer to Table 6-9, SkyGlazier Capacity Reductions and Table 6-10, Pipe Rack Capacity Reductions. The screen will read:




Table 6-9. SkyGlazier Capacity Reductions

| Capacity | PLATFORM OVRLD | PLATFORM OVRLD RESTRICT |
|------------------|-----------------|-------------------------|
| 500 lb (227 kg) | 400 lb (181 kg) | N/A |
| 550 lb (250 kg) | 400 lb (181 kg) | N/A |
| 600 lb (272 kg) | 400 lb (181 kg) | N/A |
| 750 lb (340 kg) | N/A | 590 lb (268 kg) |
| 1000 lb (454 kg) | N/A | 750 lb (340 kg) |


NOTE: If both SkyGlazier and Pipe Racks are configured, capacity will be the lower of the two values.


Table 6-10. Pipe Rack Capacity Reductions


| Capacity | PLATFORM OVRLD | PLATFORM OVRLD RESTRICT |
|------------------|-----------------|-------------------------|
| 500 lb (227 kg) | 400 lb (181 kg) | N/A |
| 550 lb (250 kg) | 450 lb (204 kg) | N/A |
| 600 lb (272 kg) | 500 lb (227 kg) | N/A |
| 750 lb (340 kg) | N/A | 650 lb (295 kg) |
| 1000 lb (454 kg) | N/A | 900 lb (408 kg) |


NOTE: If both SkyGlazier and Pipe Racks are configured, capacity will be the lower of the two values.

necessary. Refer to Table 6-9, SkyGlazier Capacity Reductions and Table 6-10, Pipe Rack Capacity Reductions.



13. Press ENTER . The following screen will be displayed for restricted capacity, which can be adjusted if

14. Press ENTER . If calibration is successful, the screen will read:



Testing & Evaluation

Refer to Troubleshooting if the Load Sensing System fails to meet these guidelines.

1. Connect the JLG Analyzer.
2. Level the Platform. The platform should be approximately level for analysis, or the guidelines below will not be applicable. Level the platform from Ground Control (if necessary) to within ± 5 degrees.
3. Observe the Empty Platform Weight. Proceed to the DIAGNOSTICS, PLTLOAD sub-menu and observe the measured platform load. All tools, debris, and customer installed devices shall be removed during evaluation. Ideally, the PLTLOAD should be zero but can vary ± 15 lb (± 7 kg). Further, the reading should be stable and should not vary by more than ± 2 lb (± 1 kg) (unless there is heavy influence from wind or vibration).
4. Use the Technician's Weight to Evaluate. The technician should enter the platform and record the PLTLOAD reading while standing in the center of the platform.
5. Confirm Control System Warnings and Interlocks. Using the keyswitch, select Platform Mode and power-up. Start the vehicle's engine and ensure that all controls are functional and the Load Sensing System's Overload Visual and Audible Warnings are not active. Simulate an Overload by unplugging the Shear Beam Load Cell. The Overload Visual Warning should flash, and the Audible Warning (at Platform and Ground) should sound for 5 seconds On, and 2 seconds Off. With the engine running, all control should be prevented. Cycle the Platform EMS to stop the engine and then power-up again. The Overload Visual and Audible Warning should continue. Confirm that controls are responsive when using the Auxiliary Power Unit for emergency movement. Reconnect the Load Cell. The Overload Visual and Audible Warnings should cease and normal control function should return. Switch the vehicle's keyswitch to Ground Mode and repeat the above procedure. The Overload Visual Warning at the Ground Controls should flash, and the Audible Warning (at Platform and Ground) should sound for 5 seconds On, 2 seconds Off. However, the controls should remain functional when using the engine and the Auxiliary Power Unit (if the Control System's MACHINE SETUP, LOAD is set to "2=CUTOUT PLT". If set to "3=CUTOUT ALL", then Ground Controls will be prevented when using the engine as in the platform).
6. Confirm Control System Capacity Indication (optional for vehicles with Dual Capacity Ratings). For vehicles equipped with a Capacity Select switch on the Platform Console Box, it is necessary to examine an additional interface between the Load Sensing System and the Control System. Using the keyswitch, select Platform Mode and power-up. If necessary, put the boom in the transport position (completely stowed) and center the Jib Plus (if equipped). Place the Capacity Select switch in the unrestricted position and ensure that the proper indicator illuminates on the Platform Console Box. Plug the JLG Analyzer into the Analyzer connection and proceed to the DIAGNOSTICS, SYSTEM submenu. Ensure that the CAPACITY displays indicate OFF. Place the Capacity Select switch in the unrestricted position (if so equipped) and ensure that the proper indicator illuminates on the Platform Console Box (but does not flash). For vehicles with unrestricted capacity, ensure that the unrestricted CAPACITY display indicates ON but the restricted CAPACITY indicates OFF. For vehicles with restricted capacity, ensure that the unrestricted CAPACITY display indicates OFF but the restricted CAPACITY indicates ON.
7. Confirm Load Sensing System Performance with Calibrated Weights. Operate the vehicle from Ground Control and place the boom in the transport position (fully stowed) for safety. Plug the JLG Analyzer into the control system connection and proceed to the DIAGNOSTICS, PLTLOAD display. Place 500lb (230kg) in the platform and ensure that PLTLOAD is with $\pm 5\%$ of the actual weight. For Dual Capacity vehicles, do the same for the alternate capacity (unrestricted or restricted).

LSS Service Mode

To facilitate the servicing and enabling of functions due to component faults, there is a need to override the normal operation of the machine. Service Mode shall become visible only after entering Service Access Level.

Table 6-11. LSS Service Mode

| Service Mode Submenu (Displayed on Analyzer 2nd Line) | Parameter (Displayed on Analyzer 1st Line) | Parameter Value (Displayed on Analyzer 2nd Line) | Transition and Software Checks |
|---|--|---|---|
| LSS? (NOT VISIBLE IF MACHINE SETUP? LOAD SYSTEM = NO) | LSS: | CODE: XXXXX | Operator uses Up and Down Arrow keys on Analyzer to input Service Mode Code; On ENTER, UGM to confirm code of 18171. If correct advance to next menu. If incorrect or on ESC, go to SERVICE MODE menu. |
| | LSS: | SERVICE ON | The UGM shall treat MACHINE SETUP --> LOAD SYSTEM as if it is set to WARN ONLY until: - Power is Cycled - Analyzer is disconnected - ESC is pressed On ESC, go to SERVICE MODE menu. |
| DRV CUT? (NOT VISIBLE IF MACHINE SETUP --> TILT = X DEGREES) | DRV CUT: | CODE: XXXXX | Operator uses Up and Down Arrow keys on Analyzer to input Service Mode Code; On ENTER, UGM to confirm code of 23732. If correct advance to next menu. If incorrect or on ESC, go to SERVICE MODE menu. |
| | DRV CUT: | SERVICE ON | UGM shall treat MACHINE SETUP --> TILT as if it is set to X DEGREES (where X is the currently selected tilt degree value) until: - Power is Cycled - Analyzer is disconnected - ESC is pressed On ESC, go to SERVICE MODE menu. |

LSS Service Mode Event Log

The Service Mode events listed below shall be stored in the Service Mode event log (DIAGNOSTICS --> DATALOG --> SERVICE LOG) if their corresponding conditions are met.

- SERVICE LSS – Logged when the LSS Service mode transitions from OFF to ON
- SERVICE DRV CUT – Logged when the LSS Service mode transitions from OFF to ON

Troubleshooting

The following tables are furnished to provide possible resolutions for common difficulties. Difficulties are classified as General, Calibration, Measurement Performance, and Host System Functionality.

Table 6-12. LSS Troubleshooting Chart

| Difficulty | Possible Resolution |
|--|---|
| <p>Empty Platform Weight (DIAGNOSTICS, PLAT-FORM LOAD) is not within $\pm 15\text{lb}$ ($\pm 7\text{kg}$) of zero.</p> <p>or</p> <p>Platform Load readings (DIAGNOSTICS, PLTLOAD) are unstable by more than $\pm 2\text{lb}$ ($\pm 1\text{kg}$) (without the influence of vibration or wind).</p> <p>or</p> <p>There are large variations in Platform Load (DIAGNOSTICS, PLTLOAD) based on the location of the load. Tolerance to variations is 20lb for an evaluation using the technician's weight, and +5% of Rated Load when using calibrated weights.</p> | <p>The LSS System is unable to properly measure the platform weight.</p> <ol style="list-style-type: none"> The Load Cell is not properly plugged into the LSS Harness. It is possible poor electrical contact is made. Wiring leading to the Load Cell is damaged. Carefully inspect sensor wiring where it passes through cable clamps for signs of damage. Inspect wiring where damage to the channel is apparent. The Load Cell was not assembled properly during installation. Examine the sensor's reading using the JLG Analyzer. Proceed to the DIAGNOSTICS, CELL, LOAD displays and determine if the readings are reasonable. It is often helpful to apply slight downward pressure above the sensor and observe that its output increases (increasing force measurement; decreasing means the sensor is mounted upside-down). The Load Cell is contaminated by debris or moisture. Examine the sensor's reading using the JLG Analyzer. Proceed to the DIAGNOSTICS, CELL, LOAD displays and determine if the readings are reasonable and stable (not changing by more than $\pm 2\text{lb}$ ($\pm 1\text{kg}$) (without the influence of vibration or wind). Lack of measurement stability is a key indication of contamination. Unplug the connector and inspect for dirt or moisture. Look carefully into the female connector on the sensor's cordset for evidence of contamination. Debris should be brushed away with a soft bristle brush (do not introduce any cleaners as they will leave conductive residue). Moisture should be allowed to evaporate or accelerated with a heat-gun (use low heat and be carefully to not melt connector materials). Moisture intrusion into the molded portion of the connector (capillary action into the wire bundle) or the Shear Beam Load Cell itself will require replacement of the sensor. The Load Cell has been mechanically damaged. If the Load Cell is physically deformed or has damage to the cover it should be replaced immediately. It is also possible to have invisible mechanical damage resulting from an extreme overload ($>6000\text{lb}$ [$>2722\text{kg}$]). |
| <p>The Visual and Audible Overload Warnings fail to sound when platform is loaded beyond Rated Load, or when simulated by unplugging the Load Cell. Controls remain functional at Platform and Ground Control positions.</p> | <p>The Control System is failing to regard the overload signal from the LSS System, or the signal is shorted.</p> <ol style="list-style-type: none"> The Load Sensing System must be enabled within the Control System. Plug the JLG Analyzer into the Control System, enter the Access Level 1 password (33271), and examine the MACHINE SETUP, LOAD sub-menu. The selection "2=CUTOUT PLT" should be displayed (platform controls prevented during overload, ground controls remain operational). In country- or customer-specific circumstance, the selection "3=CUTOUT ALL" is used (platform and ground controls prevented during overload). |
| <p>The Ground Audible Warning fails to sound, but the Platform Audible Warning sounds properly.</p> | <p>The Ground Alarm is missing or improperly installed. Verify that the device is mounted. Verify wiring from the Main Terminal Box and Ground Module.</p> |
| <p>Controls remain functional at the Ground Control position during an overload, or when simulated by unplugging the Load Cell. The Controls at the Platform Control position are prevented when using the engine, but not when using the Auxiliary Power Unit.</p> | <p>The JLG Control System is configured to prevent platform controls only in the event of overload. Alternately, the Host Control System can be configured to prevent ground and platform controls for country- or customer specific circumstances. Using the JLG Analyzer, enter the Access Level 1 password (33271). Proceed to the MACHINE SETUP, LOAD sub-menu. Set this parameter to "2=CUTOUT PLT" to prevent platform controls in the event of overload. Set this parameter to "3=CUTOUT ALL" to prevent platform and ground controls in the event of overload.</p> |

6.15 MACHINE FAULT CODES

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|--|--|--|
| 001 | EVERYTHING OK | Machine is in Platform Mode; The UGM determines no problems exist | |
| 002 | GROUND MODE OK | Machine is in Ground Mode; The UGM determines no problems exist | |
| 0010 | RUNNING AT CUTBACK – OUT OF TRANSPORT POSITION | Machine is in the Out of Transport position | Machine is not in the Out of Transport position |
| 0011 | FSW OPEN | Machine is in Platform Mode; Any of the following Platform inputs become active after power up, but before Machine Enabled: Drive joystick is not in the neutral position Steer; Lift and/or Swing joystick is not in the neutral position; Telescope; Platform Level; Platform Rotate; Jib Lift (if MACHINE SETUP → JIB = YES) | Controls initialized |
| 0012 | RUNNING AT CREEP - CREEP SWITCH OPEN | Machine is in Platform Mode; Platform Creep switch input = HIGH; DTC 0013 is not active | Platform Creep switch input = Low |
| 0013 | RUNNING AT CREEP - TILTED AND ABOVE ELEVATION | Machine is in Platform Mode; The Boom is Above Elevation; Machine chassis is considered Tilted | Not all of the trigger conditions are met |
| 0015 | LOAD SENSOR READING UNDER WEIGHT | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; UGM determines that the Platform Load < -50 lb for 2 seconds; Do not report if DTC (0030, 825 or 8211) is active or if Platform Load == Unhealthy | UGM determines that the Platform Load ≥ -50 lb for 5 seconds |
| 0031 | FUEL LEVEL LOW – ENGINE SHUT-DOWN | MACHINE SETUP → FUEL LEVEL ≠ NONE; Engine Shutdown has occurred due to Fuel Level = EMPTY condition. | Power Cycled |
| 0035 | APU ACTIVE | Auxiliary Power/Emergency Descent Mode is active | Auxiliary Power/Emergency Descent Mode is not active |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|---|---|---|
| 0036 | FUNCTION PREVENTED - FUNCTION SELECTED BEFORE GROUND ENABLE | Machine is in Ground Mode; (Jumper Configuration Status = 0) and Jumper Configuration Status < 2); Any of the following Ground inputs become active after power up, but before Machine Enabled: Lift; Swing; Telescope; Platform Level; Platform Rotate; Jib Lift (if MACHINE SETUP → JIB = YES) | Controls initialized |
| 0039 | SKYGUARD ACTIVE – FUNCTIONS CUTOFF | MACHINE SETUP → SKYGUARD = YES; Machine is in Platform Mode; SkyGuard Enabled | Not all of the trigger conditions are met |
| 212 | KEYSWITCH FAULTY | UGM Ground Mode input J7-3 input = High; UGM Platform Mode input J7-2 input = High | (J7-3 input = LOW) or (J7-2 input = LOW) |
| 213 | FSW FAULTY | The ground footswitch input and platform footswitch input have been both HIGH or both LOW for greater than or equal to 1 second | Power Cycled |
| 221 | FUNCTION PROBLEM - HORN PERMANENTLY SELECTED | Machine is in Platform Mode; The Horn switch input = High at Startup | The Horn switch input = Low |
| 224 | FUNCTION PROBLEM - STEER LEFT PERMANENTLY SELECTED | Machine is in Platform Mode; The Steer Left switch input = High at Startup | The Steer Left switch input = Low; Steer Left and Right and full Drive speed permitted after controls are initialized |
| 225 | FUNCTION PROBLEM - STEER RIGHT PERMANENTLY SELECTED | Machine is in Platform Mode; The Steer Right switch input = High at Startup | The Steer Right switch input = Low; Steer Left and Right and full Drive speed permitted after controls are initialized |
| 227 | STEER SWITCHES FAULTY | The Steer Left switch input = High; The Steer Right switch input = High; (detectable in Platform or Ground mode) | The Steer Left switch input = Low; The Steer Right switch input = Low; Steer and full Drive speed permitted after controls are initialized |
| 2211 | FSW INTERLOCK TRIPPED | Machine is in Platform Mode; The Footswitch is active for more than seven seconds with no Drive, Steer, or Boom commands | The footswitch is released |
| 2212 | DRIVE LOCKED - JOYSTICK MOVED BEFORE FOOTSWITCH | Machine is in Platform Mode; The UGM detects one of the following conditions: Drive joystick is not in the neutral position at Startup; Drive joystick is not in the neutral position when Footswitch becomes active or while DTC 2213, 2221 or 2223 is active | If triggered by the Drive joystick not being in the neutral position at Startup, then (Drive joystick is returned to its neutral position) and (Drive and Steer permitted after controls initialized) If triggered by the Drive joystick not being in the neutral position when Footswitch becomes active or while DTC 2213, 2221 or 2223, then controls initialized |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|--|---|---|
| 2213 | STEER LOCKED - SELECTED BEFORE FOOTSWITCH | Machine is in Platform Mode; A Steer input is active when Footswitch becomes active or while DTC 2212, 2221 or 2223 is active | Controls initialized |
| 2216 | D/S JOY. OUT OF RANGE HIGH | The PM detects that the Drive or Steer joystick signal voltage > 8.1V and reports the fault to the UGM. | The PM no longer reports the fault |
| 2217 | D/S JOY. CENTER TAP BAD | The PM detects that the Drive or Steer center tap voltage is not between 3.31 volts and 3.75 volts and reports the fault to the UGM | The PM detects that the drive/steer center tap voltage is between 3.31 and 3.75 volts and no longer reports the fault to the UGM |
| 2219 | L/S JOY. OUT OF RANGE HIGH | The PM detects that the Lift or Swing joystick signal voltage > 8.1V and reports the fault to the UGM. | The PM detects that the Lift and Swing joystick signal voltage is < 8.1V and no longer reports the fault to the UGM |
| 2220 | L/S JOY. CENTER TAP BAD | The PM detects that the Lift or Swing center tap voltage is not between 3.31 volts and 3.75 volts and reports the fault to the UGM | The PM detects that the lift/swing center tap voltage is between 3.31 and 3.75 volts and no longer reports the fault to the UGM |
| 2221 | LIFT/SWING LOCKED - JOYSTICK MOVED BEFORE FOOTSWITCH | Machine is in Platform Mode; The UGM detects one of the following conditions: Lift and/or Swing joystick is not in the neutral position at Startup; Lift and/or Swing joystick is not in the neutral position when Footswitch becomes active or while DTC 2212, 2213 or 2223 is active | If triggered by the Lift and/or Swing joystick not being in the neutral position at Startup, then (Lift and/or Swing joystick is returned to its neutral position) and (Lift and Swing permitted after controls initialized) If triggered by the Lift and/or Swing joystick is not in the neutral position when Footswitch becomes active or while DTC 2212, 2213 or 2223 is active, then controls initialized |
| 2222 | WAITING FOR FSW TO BE OPEN | Machine is in Platform Mode; Footswitch is active at Start Up | Controls initialized |
| 2223 | FUNCTION SWITCHES LOCKED - SELECTED BEFORE ENABLE | Machine is in Platform Mode; Any of the following Platform inputs are active when Footswitch becomes active or while DTC 2212, 2213 or 2221 is active: Tower Lift; Telescope; Platform Level; Platform Rotate; Jib Lift (if MACHINE SETUP → JIB = YES) | Controls initialized |
| 2224 | FOOTSWITCH SELECTED BEFORE START | Machine is in Platform Mode; The engine is stopped; Startup time has expired; The Footswitch is active before the Platform Engine Start switch input = High | The Platform Engine Start switch input = Low; |
| 2247 | FUNCTION PROBLEM - PLATFORM ROTATE LEFT PERMANENTLY SELECTED | Machine is in Platform Mode; The Platform Rotate Left switch input = High at Startup | The Platform Rotate Left switch input = Low; Platform Rotate Left and Right permitted after controls are initialized |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|--|---|---|
| 2248 | FUNCTION PROBLEM - PLATFORM ROTATE RIGHT PERMANENTLY SELECTED | Machine is in Platform Mode; The Platform Rotate Right switch input = High at Startup | The Platform Rotate Right switch input = Low; Platform Rotate Left and Right permitted after controls are initialized |
| 2249 | FUNCTION PROBLEM - JIB LIFT UP PERMANENTLY SELECTED | Machine is in Platform Mode; MACHINE SETUP → JIB = YES; The Jib Lift Up switch input = High at Startup | The Jib Lift Up switch input = Low; Jib Lift Up and Down permitted after controls are initialized |
| 2250 | FUNCTION PROBLEM - JIB LIFT DOWN PERMANENTLY SELECTED | Machine is in Platform Mode; MACHINE SETUP → JIB = YES; The Jib Lift Down switch input = High at Startup | The Jib Lift Down switch input = Low; Jib Lift Up and Down permitted after controls are initialized |
| 2251 | FUNCTION PROBLEM - TELESCOPE IN PERMANENTLY SELECTED | Machine is in Platform Mode; The Telescope In switch input = High at Startup | The Telescope In switch input = Low; Telescope permitted after controls are initialized |
| 2252 | FUNCTION PROBLEM - TELESCOPE OUT PERMANENTLY SELECTED | Machine is in Platform Mode; The Telescope Out switch input = High at Startup | The Telescope Out switch input = Low; Telescope permitted after controls are initialized |
| 2262 | FUNCTION PROBLEM - PLATFORM LEVEL UP PERMANENTLY SELECTED | Machine is in Platform Mode; The Platform Level Up switch input = High at Startup | The Platform Level Up switch input = Low; Platform Level Up and Down permitted after controls are initialized |
| 2263 | FUNCTION PROBLEM - PLATFORM LEVEL DOWN PERMANENTLY SELECTED | Machine is in Platform Mode; The Platform Level Down switch input = High at Startup | The Platform Level Down switch input = Low; Platform Level Up and Down permitted after controls are initialized |
| 2264 | FUNCTION PROBLEM - DOS OVERRIDE PERMANENTLY SELECTED | Machine is in Platform Mode; The DOS Override switch input = High at Startup | The DOS Override switch input = Low |
| 2286 | FUNCTION PROBLEM - SOFT TOUCH / SKYGUARD OVERRIDE PERMANENTLY SELECTED | [(MACHINE SETUP → SKYGUARD = YES) or (MACHINE SETUP → SOFT TOUCH = YES)]; Machine is in Platform Mode; The Soft Touch / SkyGuard Override switch input = High at Startup | The Soft Touch / SkyGuard Override switch input = Low |
| 2287 | PLATFORM ANGLE SENSOR - NOT CALIBRATED | The Platform Angle Sensor has not been calibrated | Platform angle sensor calibrated |
| 2289 | PLATFORM ANGLE SENSOR - NOT RESPONDING | The UGM detects the following conditions: The UGM detects < 1 deg change of Platform Angle; Platform Level Up or Platform Level Down output value ≥ Creep output value; Platform Level Up or Platform Level Down has been active longer than 5 seconds; Platform Angle < (Platform Angle Max - 1.5 deg); Platform Angle > (Platform Angle Min ± 1.5 deg); | Power Cycled |
| 2290 | PLATFORM ANGLE SENSOR DISAGREEMENT | The UGM detects that Platform Angle Sensor #1 and Platform Angle Sensor #2 readings disagree ≥ 2.5 deg for longer than 5 seconds; Do not report if DTC 2287 is active | Power Cycled |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|---|--|---|
| 2295 | PLATFORM ANGLE SENSOR - OUT OF RANGE HIGH | The UGM detects that Platform Angle Sensor #1 < 5% or Platform Angle Sensor #2 signal voltage > 95%. | Power Cycled |
| 2296 | PLATFORM ANGLE SENSOR - OUT OF RANGE LOW | The UGM detects that Platform Angle Sensor #1 > 95% or Platform Angle Sensor #2 signal voltage < 5%. | Power Cycled |
| 2297 | PLATFORM ANGLE SENSOR – FREQUENCY OUT OF RANGE | The UGM detects that Platform Angle Sensor #1 or Platform Angle Sensor #2 signal frequency is not within 100Hz +/- 5Hz | Power Cycled |
| 234 | FUNCTION SWITCHES FAULTY - CHECK DIAGNOSTICS/BOOM | The UGM detects one of the following conditions (continuous monitoring): The machine is in Ground Mode and both direction inputs of the following boom controls are engaged at the same time: Engine Start/Aux, Telescope, Platform Level, Platform Rotate, Jib Lift, Tower Lift, Lift, or Swing. The machine is in Platform Mode and both direction inputs of the following boom controls are engaged at the same time: Engine Start/Aux, Telescope, Platform Level, Platform Rotate, Jib Lift (MACHINE SETUP → JIB = YES) | None of the boom controls that trigger this fault have both of their direction inputs engaged at the same time |
| 235 | FUNCTION SWITCHES LOCKED - SELECTED BEFORE AUX POWER | The UGM detects one of the following conditions: The machine is in Ground Mode and the engine is stopped and the ground APU/Function Enable switch becomes engaged while a Ground control input is already engaged. The machine is in Platform Mode and the engine is stopped and the platform APU/Auxiliary Descents switch becomes engaged while a Platform control input is already engaged. | The applicable APU/Auxiliary Descent switch is disengaged or all applicable control inputs become disengaged or the engine state becomes ENGINE RUNNING |
| 236 | FUNCTION SWITCHES LOCKED - SELECTED BEFORE START SWITCH | The UGM detects one of the following conditions: The machine is in Ground Mode and the engine is stopped and any configured boom control is already engaged and the ground start switch changes from not engaged to engaged The machine is in Platform Mode and the engine is stopped and any drive/steer or configured boom control is already engaged and the footswitch is not engaged and the platform start switch changes from not engaged to engaged | The selected station's start switch is no longer engaged |
| 237 | START SWITCH LOCKED - SELECTED BEFORE KEYSWITCH | The start switch for the selected station is engaged during the UGM startup sequence | The selected station's start switch is no longer engaged |
| 2310 | FUNCTION PROBLEM - GROUND ENABLE PERMANENTLY SELECTED | Machine is in Ground Mode; (Jumper Configuration Status = 0) and Jumper Configuration Status < 2); The Ground Enable switch input = High at Startup | Controls initialized |
| 2343 | BOOM ANGLE SENSOR – NOT CALIBRATED | The Boom Angle Sensor has not been calibrated | Boom angle sensor calibrated |
| 2344 | BOOM ANGLE SENSOR - OUT OF RANGE HIGH | The UGM detects that Boom Angle Sensor #1 < 0.5V or Boom Angle Sensor #2 signal voltage > 4.5V. | Power Cycled |
| 2345 | BOOM ANGLE SENSOR - OUT OF RANGE LOW | The UGM detects that Boom Angle Sensor #1 > 4.5V or Boom Angle Sensor #2 signal voltage < 0.5V. | Power Cycled |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|-------|--|--|--|
| 2346 | BOOM ANGLE SENSOR – NOT RESPONDING | The UGM detects the following conditions: The UGM detects < 1 deg change of Boom Angle; Main Lift Up or Main Lift Down output value \geq Creep output value; Main Lift Up or Main Lift Down has been active longer than 5 seconds; Boom Angle < (Boom Angle Max -1.5 deg); Boom Angle > (Boom Angle Min \pm 1.5 deg); | Power Cycled |
| 2370 | FUNCTION PROBLEM - JIB LIFT UP PERMANENTLY SELECTED | Machine is in Ground Mode; MACHINE SETUP \rightarrow JIB = YES; The Jib Lift Up switch input = High at Startup | The Jib Lift Up switch input = Low; Jib Lift Up and Down permitted after controls are initialized |
| 2371 | FUNCTION PROBLEM - JIB LIFT DOWN PERMANENTLY SELECTED | Machine is in Ground Mode; MACHINE SETUP \rightarrow JIB = YES; The Jib Lift Down switch input = High at Startup | The Jib Lift Down switch input = Low; Jib Lift Up and Down permitted after controls are initialized |
| 2372 | FUNCTION PROBLEM - SWING LEFT PERMANENTLY SELECTED | Machine is in Ground Mode; The Swing Left switch input = High at Startup | The Swing Left switch input = Low; Swing Left and Right permitted after controls are initialized |
| 2373 | FUNCTION PROBLEM - SWING RIGHT PERMANENTLY SELECTED | Machine is in Ground Mode; The Swing Right switch input = High at Startup | The Swing Left switch input = Low; Swing Left and Right permitted after controls are initialized |
| 2396 | BOOM ANGLE SENSOR DISAGREEMENT | The UGM detects that Boom Angle Sensor #1 and Boom Angle Sensor #2 readings disagree \geq 2.5 deg for longer than 5 seconds; Do not report if DTC 2343 is active | Power Cycled |
| 23107 | FUNCTION PROBLEM - LIFT UP PERMANENTLY SELECTED | Machine is in Ground Mode; The Lift Up switch input = High at Startup | The Lift Up switch input = Low; Lift Up and Down permitted after controls are initialized |
| 23108 | FUNCTION PROBLEM - LIFT DOWN PERMANENTLY SELECTED | Machine is in Ground Mode; The Lift Down switch input = High at Startup | The Lift Down switch input = Low; Lift Up and Down permitted after controls are initialized |
| 23109 | FUNCTION PROBLEM - TELESCOPE IN PERMANENTLY SELECTED | Machine is in Ground Mode; The Telescope In switch input = High at Startup | The Telescope In switch input = Low; Telescope In and Out permitted after controls are initialized |
| 23110 | FUNCTION PROBLEM - TELESCOPE OUT PERMANENTLY SELECTED | Machine is in Ground Mode; The Telescope Out switch input = High at Startup | The Telescope Out switch input = Low; Telescope In and Out permitted after controls are initialized |
| 23111 | FUNCTION PROBLEM - PLATFORM LEVEL UP PERMANENTLY SELECTED | Machine is in Ground Mode; The Platform Level Up switch input = High at Startup | The Platform Level Up switch input = Low; Platform Level Up and Down permitted after controls are initialized |
| 23112 | FUNCTION PROBLEM - PLATFORM LEVEL DOWN PERMANENTLY SELECTED | Machine is in Ground Mode; The Platform Level Down switch input = High at Startup | The Platform Level Down switch input = Low; Platform Level Up and Down permitted after controls are initialized |
| 23113 | FUNCTION PROBLEM - PLATFORM ROTATE LEFT PERMANENTLY SELECTED | Machine is in Ground Mode; The Platform Rotate Left switch input = High at Startup | The Platform Rotate Left switch input = Low; Platform Rotate Left and Right permitted after controls are initialized |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|-------|---|--|--|
| 23114 | FUNCTION PROBLEM - PLATFORM ROTATE RIGHT PERMANENTLY SELECTED | Machine is in Ground Mode; The Platform Rotate Right switch input = High at Startup | The Platform Rotate Right switch input = Low; Platform Rotate Left and Right permitted after controls are initialized |
| 23154 | TELESCOPE RETRACT SWITCHES - DISAGREEMENT | The UGM detects the following conditions: Telescope Retracted Switch #1 and Telescope Retracted Switch #2 readings disagree for longer than 5 seconds; Telescope In or Telescope Out output value \geq Creep output value | Power Cycled |
| 23163 | FUNCTION PROBLEM - MSSO PERMANENTLY SELECTED | The MSSO switch input = Low at Startup | Power Cycled |
| 23170 | BOOM ANGLE SENSOR - SINGLE POINT CALIBRATION PERFORMED | Single point Boom Angle calibration is successfully completed | Fault shall be retentive through Power Cycled; Can be reset if CALIBRATIONS \rightarrow BOOM ANGLE is successfully completed |
| 23173 | CAPACITY LENGTH SWITCHES - DISAGREEMENT | Dual Capacity is configured; The UGM detects the following conditions: Capacity Length Switch #1 and Capacity Length Switch #2 readings disagree for longer than 5 seconds; Telescope In or Telescope Out output value \geq Creep output value | Power Cycled |
| 23239 | BOOM ANGLE SENSOR - ANGLE OUT OF RANGE HIGH | The UGM detects a Boom Angle \geq (Boom Angle Max + 1.5 deg); Do not report if Boom Angle == Unhealthy | Fault shall be retentive through Power Cycled; Can be reset by performing a Boom Angle Sensor Calibration |
| 23240 | BOOM ANGLE SENSOR - ANGLE OUT OF RANGE LOW | The UGM detects a Boom Angle $<$ (Boom Angle Min - 1.5 deg); Do not report if Boom Angle == Unhealthy | Fault shall be retentive through Power Cycled; Can be reset by performing a Boom Angle Sensor Calibration |
| 241 | AMBIENT TEMPERATURE SENSOR - OUT OF RANGE LOW | MACHINE SETUP \rightarrow TEMP CUTOUT = YES; Ambient Temperature sensor reading \leq -50C; Do not report if DTC 6657 is active | Ambient Temperature sensor reading $>$ -50C; Full Speed permitted after controls are initialized |
| 242 | AMBIENT TEMPERATURE SENSOR - OUT OF RANGE HIGH | MACHINE SETUP \rightarrow TEMP CUTOUT = YES; Ambient Temperature sensor reading \geq 85C; Do not report if DTC 6657 is active | Ambient Temperature sensor reading $<$ 85C; Full Speed permitted after controls are initialized |
| 259 | MODEL CHANGED - HYDRAULICS SUSPENDED - CYCLE EMS | The MACHINE SETUP \rightarrow MODEL NUMBER is changed using the analyzer | Power Cycled |
| 2513 | GENERATOR MOTION CUTOUT ACTIVE | MACHINE SETUP \rightarrow GEN SET = BELT DRIVE; MACHINE SETUP \rightarrow GEN SET CUTOUT = MOTION CUTOUT; The platform Generator Switch is engaged Footswitch State = Depressed The machine is in Platform mode | Not all of the trigger conditions are met |
| 2514 | BOOM PREVENTED - DRIVE SELECTED | MACHINE SETUP \rightarrow FUNCTION CUTOUT = BOOM CUTOUT; Drive or Steer is already engaged; The boom is Above Elevation The operator is attempting to activate one of the boom functions DTC 2514 supercedes DTC 2518 if drive/steer and boom functions are both active when machine transitions from Below Elevation to Above Elevation. | Not all of the trigger conditions are met |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|---|---|--|
| 2516 | DRIVE PREVENTED – ABOVE ELEVATION | MACHINE SETUP → FUNCTION CUTOUT = DRIVE CUTOUT The boom is Above Elevation The operator is attempting to activate Drive or Steer | Not all of the trigger conditions are met |
| 2517 | DRIVE PREVENTED – TILTED & ABOVE ELEVATION | MACHINE SETUP → FUNCTION CUTOUT = DRIVE CUT E&T The boom is Above Elevation The chassis is considered Tilted The operator is attempting to activate Drive or Steer | Not all of the trigger conditions are met |
| 2518 | DRIVE PREVENTED – BOOM SELECTED | MACHINE SETUP → FUNCTION CUTOUT = BOOM CUTOUT The boom is Above Elevation Any boom function is already active The operator attempts to activate Drive or Steer | Not all of the trigger conditions are met |
| 2519 | DRIVE PREVENTED - TILTED & EXTENDED OR HIGH ANGLE | Chassis Tilt is > 1.8 degrees and either the boom is above 55 degrees main boom angle and/or the boom is telescoped out beyond the drive disable switches. (Dual Cap Prox.) | Boom lifted below 55 degrees and/or the boom retracted to inside the drive disable length switches. (Dual Cap) |
| 2548 | SYSTEM TEST MODE ACTIVE | UGM determines that System Test Mode is active | Power Cycle |
| 2549 | DRIVE & BOOM PREVENTED - SOFT TOUCH ACTIVE | MACHINE SETUP → SOFT TOUCH = YES; Machine is in Platform Mode; Soft Touch State = Enabled | Not all of the trigger conditions are met |
| 2563 | SKYGUARD SWITCH – DISAGREEMENT | MACHINE SETUP → SKYGUARD = YES; Machine is in Platform Mode; [(SkyGuard input #1 Platform Module J7-18) ≠ (SkyGuard input #2 Platform Module J1-23)] > 160ms | [(SkyGuard inputs (Platform Module J7-18 = High) and (Platform Module J1-23 = High)) and (Footswitch State = Not Depressed)] |
| 2568 | TEMPERATURE CUTOUT ACTIVE – AMBIENT TEMPERATURE TOO LOW | Low Temperature Cutout = Active | Low Temperature Cutout = Inactive; Full Speed permitted after controls are initialized |
| 2576 | PLATFORM LEVEL PREVENTED – ABOVE ELEVATION | Platform Level Override Cutout = Enabled; The Platform Level Up or Down switch input = High; Footswitch is active If 600S: Auto Platform Level = Enabled | Controls initialized |
| 2587 | RUNNING AT CREEP – PLATFORM LEVELED UNDER | Platform Leveled Under State = Set | Platform Leveled Under State = Cleared |
| 331 | BRAKE – SHORT TO BATTERY | The UGM detects a short to battery at this output | Power Cycled |
| 332 | BRAKE – OPEN CIRCUIT | The UGM detects an open circuit at this output | Power Cycled |
| 334 | LIFT UP VALVE – OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit; Full speed Lift Up and Down permitted after controls are initialized |
| 336 | LIFT DOWN VALVE – OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit; Full speed Lift Up and Lift Down permitted after controls are initialized |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|--|--|--|
| 3311 | GROUND ALARM – SHORT TO BATTERY | MACHINE SETUP → ALARM / HORN = SEPARATE; The UGM detects a short to battery on J2-2 | Power Cycled |
| 3358 | MAIN DUMP VALVE – SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 3359 | MAIN DUMP VALVE – OPEN CIRCUIT | The UGM detects an open circuit at this output | Power Cycled |
| 3360 | MAIN DUMP VALVE – SHORT TO BATTERY | The UGM detects a short to battery at this output | Power Cycled |
| 3361 | BRAKE – SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 3362 | START SOLENOID – SHORT TO GROUND | UGM detects a short to ground at this output | Power Cycled |
| 3363 | START SOLENOID – OPEN CIRCUIT | UGM detects an open circuit at this output; if MACHINE SETUP → ENGINE = FORD DUAL FUEL only evaluate until first Start is attempted for each power cycle due to possibility of ECU opening ground solenoid return path to disable Start and causing erroneous diagnostics. | Power Cycled |
| 3364 | START SOLENOID – SHORT TO BATTERY | UGM detects a short to battery at this output | Power Cycled |
| 3368 | TWO SPEED VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 3369 | TWO SPEED VALVE - OPEN CIRCUIT | The UGM detects an open circuit at this output | Power Cycled |
| 3370 | TWO SPEED VALVE - SHORT TO BATTERY | The UGM detects a short to battery at this output | Power Cycled |
| 3371 | GROUND ALARM – SHORT TO GROUND | MACHINE SETUP → ALARM / HORN = SEPARATE; The UGM detects a short to ground on J2-2 | Power Cycled |
| 3372 | GROUND ALARM – OPEN CIRCUIT | MACHINE SETUP → ALARM / HORN = SEPARATE; The UGM detects an open circuit on J2-2 | Power Cycled |
| 3373 | GEN SET/WELDER – SHORT TO GROUND | MACHINE SETUP → GEN SET = BELT DRIVE and the UGM detects a short to ground at this output | Power Cycled |
| 3374 | GEN SET/WELDER – OPEN CIRCUIT | MACHINE SETUP → GEN SET = BELT DRIVE and the UGM detect an open circuit at this output | Power Cycled |
| 3375 | GEN SET/WELDER – SHORT TO BATTERY | MACHINE SETUP → GEN SET = BELT DRIVE and the UGM detects a short to battery at this output | Power Cycled |
| 3376 | HEAD TAIL LIGHT – SHORT TO GROUND | MACHINE SETUP → H & T LIGHTS = YES and the UGM detects a short to ground at this output | Power Cycled |
| 3377 | HEAD TAIL LIGHT – OPEN CIRCUIT | MACHINE SETUP → H & T LIGHTS = YES and the UGM detects an open circuit at this output | Power Cycled |
| 3378 | HEAD TAIL LIGHT – SHORT TO BATTERY | MACHINE SETUP → H & T LIGHTS = YES and the UGM detects a short to battery at this output | Power Cycled |
| 3385 | PLATFORM LEVEL UP OVERRIDE VALVE - SHORT TO GROUND | DTC 662 is active; The UGM detects a short to ground at this output | Power Cycled |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|-------|---|--|---|
| 3386 | PLATFORM LEVEL UP OVERRIDE VALVE - OPEN CIRCUIT | DTC 662 is active; The UGM detects an open circuit at this output | Power Cycled |
| 3387 | PLATFORM LEVEL UP OVERRIDE VALVE - SHORT TO BATTERY | DTC 662 is active; The UGM detects a short to battery at this output | Power Cycled |
| 3391 | PLATFORM DOWN OVERRIDE – SHORT TO GROUND | DTC 662 is active; The UGM detects a short to ground at this output | Power Cycled |
| 3392 | PLATFORM DOWN OVERRIDE – OPEN CIRCUIT | DTC 662 is active; The UGM detects an open circuit at this output | Power Cycled |
| 3393 | PLATFORM DOWN OVERRIDE – SHORT TO BATTERY | DTC 662 is active; The UGM detects a short to battery at this output | Power Cycled |
| 33118 | SWING RIGHT VALVE – SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33119 | SWING RIGHT VALVE – OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit; Full speed Swing Left and Right permitted after controls are initialized |
| 33122 | SWING LEFT VALVE – SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33182 | LIFT VALVES – SHORT TO BATTERY | The UGM detects a short to battery at either the Lift Up or Lift Down valve | Power Cycled |
| 33186 | TELESCOPE OUT VALVE – OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit; Full speed Telescope In and Out permitted after controls are initialized |
| 33187 | TELESCOPE VALVES – SHORT TO BATTERY | The UGM detects a short to battery at either the Tele In or Tele Out valve. | Power Cycled |
| 33188 | TELESCOPE OUT VALVE – SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33189 | TELESCOPE IN VALVE – OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit; Telescope Out permitted after controls are initialized; Full speed Telescope In permitted after controls are initialized |
| 33190 | TELESCOPE IN VALVE – SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33208 | HORN – SHORT TO BATTERY | The UGM detects a short to battery on J2-27 | Power Cycled |
| 33276 | APU PUMP RELAY - OPEN CIRCUIT | The UGM detects an open circuit at this output | Power Cycled |
| 33277 | APU PUMP RELAY - SHORT TO BATTERY | The UGM detects a short to battery at this output | Power Cycled |
| 33278 | APU PUMP RELAY - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33279 | GLOWPLUG – OPEN CIRCUIT | MACHINE SETUP → ENGINE ≠ DEUTZ EMR4, FORD DUAL FUEL; MACHINE SETUP → GLOW PLUG ≠ NO; The UGM detects an open circuit at this output | Power Cycled |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|-------|--|---|--|
| 33280 | GLOWPLUG – SHORT TO BATTERY | MACHINE SETUP → ENGINE ≠ DEUTZ EMR4, FORD DUAL FUEL; MACHINE SETUP → GLOW PLUG ≠ NO; The UGM detects a short to battery at this output | Power Cycled |
| 33281 | GLOWPLUG – SHORT TO GROUND | MACHINE SETUP → ENGINE ≠ DEUTZ EMR4, FORD DUAL FUEL; MACHINE SETUP → GLOW PLUG ≠ NO; The UGM detects a short to ground at this output | Power Cycled |
| 33287 | LIFT – CURRENT FEEDBACK READING TOO LOW | The Engine State = ENGINE RUNNING; The UGM commanded current > 250mA; The difference between the commanded current and the measured feedback current > [the larger of (125mA) or (15% of the commanded function Max)] for longer than 1 second | Power Cycled |
| 33288 | TELESCOPE – CURRENT FEEDBACK READING TOO LOW | The Engine State = ENGINE RUNNING; The UGM commanded current > 250mA; The difference between the commanded current and the measured feedback current > [the larger of (125mA) or (15% of the commanded function Max)] for longer than 1 second | Power Cycled |
| 33295 | SWING LEFT VALVE – OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit; Full speed Swing Left and Right permitted after controls are initialized |
| 33332 | LEFT TRACK - CURRENT FEEDBACK READING TOO LOW | The Engine State = ENGINE RUNNING; The UGM commanded current > 250mA; The difference between the commanded current and the measured feedback current > [the larger of (125mA) or (15% of the commanded function Max)] for longer than 1 second | Power Cycled |
| 33333 | RIGHT TRACK - CURRENT FEEDBACK READING TOO LOW | The Engine State = ENGINE RUNNING; The UGM commanded current > 250mA; The difference between the commanded current and the measured feedback current > [the larger of (125mA) or (15% of the commanded function Max)] for longer than 1 second | Power Cycled |
| 33406 | LIFT UP VALVE – SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33407 | LIFT DOWN VALVE – SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33408 | RIGHT TRACK - LOSS OF CURRENT FEEDBACK | Measured feedback current < 225mA while PWM output > 40% for a period of 100ms. | Power Cycled |
| 33409 | LEFT TRACK - LOSS OF CURRENT FEEDBACK | Measured feedback current < 225mA while PWM output > 40% for a period of 100ms. | Power Cycled |
| 33412 | SWING VALVES – SHORT TO BATTERY | The UGM detects a short to battery at either the Swing Right or Swing Left valve | Power Cycled |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|-------|--|---|--|
| 33414 | SWING – CURRENT FEEDBACK READING TOO LOW | The Engine State = ENGINE RUNNING; The UGM commanded current > 250mA; The difference between the commanded current and the measured feedback current > [the larger of (125mA) or (15% of the commanded function Max)] for longer than 1 second | Power Cycled |
| 33417 | LIFT – CURRENT FEEDBACK READING LOST | Measured feedback current < 225mA while PWM output > 40% for a period of 100ms. | Power Cycled |
| 33418 | SWING – CURRENT FEEDBACK READING LOST | Measured feedback current < 225mA while PWM output > 40% for a period of 100ms. | Power Cycled |
| 33443 | TELESCOPE – CURRENT FEEDBACK READING LOST | Measured feedback current < 225mA while PWM output > 40% for a period of 100ms. | Power Cycled |
| 33537 | AUXILIARY LIFT DOWN VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33538 | AUXILIARY LIFT DOWN VALVE - OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit |
| 33539 | AUXILIARY LIFT DOWN VALVE - SHORT TO BATTERY | The UGM detects a short to battery at this output | Power Cycled |
| 33567 | AUXILIARY VALVES - SHORT TO BATTERY | The UGM detects a short to battery at either the Aux Lift Down or Aux Tower Lift Down valve | Power Cycled |
| 33568 | AUXILIARY - CURRENT FEEDBACK READING LOST | Measured feedback current < 225mA while output is active for a period of 100ms. | Power Cycled |
| 33575 | ECM PULL DOWN RESISTOR - OPEN CIRCUIT | MACHINE SETUP → ENGINE = DEUTZ EMR4; Pull down resistor not detected | Power Cycled |
| 33633 | PLATFORM DUMP 1 VALVE - SHORT TO BATTERY | The UGM detects a short to battery at this output | Power Cycled |
| 33634 | PLATFORM DUMP 1 VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33635 | PLATFORM DUMP 1 VALVE - OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit |
| 33636 | PLATFORM DUMP 2 VALVE - SHORT TO BATTERY | The UGM detects a short to battery at this output | Power Cycled |
| 33637 | PLATFORM DUMP 2 VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33638 | PLATFORM DUMP 2 VALVE - OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit |
| 33639 | TELESCOPE IN DUMP VALVE - SHORT TO BATTERY | The UGM detects a short to battery at this output | Power Cycled |
| 33640 | TELESCOPE IN DUMP VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33641 | TELESCOPE IN DUMP VALVE - OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|-------|--|--|--|
| 33736 | BYPASS DUMP VALVE – SHORT TO BATTERY | The UGM detects a short to battery at this output | Power Cycled |
| 33737 | BYPASS DUMP VALVE – SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 33738 | BYPASS DUMP VALVE – OPEN CIRCUIT | The UGM detects an open circuit at this output | The UGM no longer detects open circuit |
| 343 | PLATFORM LEVEL UP VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 344 | PLATFORM LEVEL UP VALVE - SHORT TO BATTERY OR OPEN CIRCUIT | The UGM detects a short to battery or an open circuit at this output | Power Cycled |
| 347 | PLATFORM LEVEL DOWN VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 348 | PLATFORM LEVEL DOWN VALVE - SHORT TO BATTERY OR OPEN CIRCUIT | The UGM detects a short to battery or an open circuit at this output | Power Cycled |
| 349 | PLATFORM ROTATE LEFT VALVE – OPEN CIRCUIT | The PM detects an open circuit at this output and reports it to the UGM | The PM no longer detects open circuit; Full speed Platform Rotate Right and Left permitted after controls are initialized |
| 3410 | PLATFORM ROTATE LEFT VALVE – SHORT TO BATTERY | The PM detects a short to battery at this output and reports it to the UGM | Power Cycled |
| 3411 | PLATFORM ROTATE LEFT VALVE – SHORT TO GROUND | The PM detects a short to ground at this output and reports it to the UGM | Power Cycled |
| 3412 | PLATFORM ROTATE RIGHT VALVE – OPEN CIRCUIT | The PM detects an open circuit at this output and reports it to the UGM | The PM no longer detects open circuit; Full speed Platform Rotate Right and Left permitted after controls are initialized |
| 3413 | PLATFORM ROTATE RIGHT VALVE – SHORT TO BATTERY | The PM detects a short to battery at this output and reports it to the UGM | Power Cycled |
| 3414 | PLATFORM ROTATE RIGHT VALVE – SHORT TO GROUND | The PM detects a short to ground at this output and reports it to the UGM | Power Cycled |
| 3415 | JIB LIFT UP VALVE – OPEN CIRCUIT | MACHINE SETUP → JIB = YES The PM detects an open circuit at this output and reports it to the UGM | The PM no longer detects open circuit; Full speed Jib Lift Up and Down permitted after controls are initialized |
| 3416 | JIB LIFT UP VALVE – SHORT TO BATTERY | MACHINE SETUP → JIB = YES The PM detects a short to battery at this output and reports it to the UGM | Power Cycled |
| 3417 | JIB LIFT UP VALVE – SHORT TO GROUND | MACHINE SETUP → JIB = YES The PM detects a short to ground at this output and reports it to the UGM | Power Cycled |
| 3418 | JIB LIFT DOWN VALVE – OPEN CIRCUIT | MACHINE SETUP → JIB = YES The PM detects an open circuit at this output and reports it to the UGM | The PM no longer detects open circuit; Jib Lift Up permitted after controls are initialized Full speed Jib Lift Down permitted after controls are initialized |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|--|--|--|
| 3419 | JIB LIFT DOWN VALVE – SHORT TO BATTERY | MACHINE SETUP → JIB = YES The PM detects a short to battery at this output and reports it to the UGM | Power Cycled |
| 3420 | JIB LIFT DOWN VALVE – SHORT TO GROUND | MACHINE SETUP → JIB = YES The PM detects a short to ground at this output and reports it to the UGM; detection occurs for PWM output approximately ≤ 15% or for STG condition. | Power Cycled |
| 431 | FUEL SENSOR - SHORT TO BATTERY OR OPEN CIRCUIT | MACHINE SETUP → FUEL LEVEL = SENSOR; UGM fuel sensor analog input J2-25 detects a voltage higher than 2.50 volts (A/D > 512) | Power Cycled |
| 432 | FUEL SENSOR - SHORT TO GROUND | MACHINE SETUP → FUEL LEVEL = SENSOR; UGM fuel sensor analog input J2-25 detects a voltage less than or equal to 0.3 volts (A/D < 61) | Power Cycled |
| 437 | ENGINE TROUBLE CODE | An engine with a CAN engine controller is configured in MACHINE SETUP The engine controller reports a J1939 fault | Power Cycled |
| 438 | HIGH ENGINE TEMP | An engine with a CAN engine controller is <u>not</u> configured in MACHINE SETUP: <ul style="list-style-type: none"> - The Engine State = ENGINE RUNNING > 10 seconds - The coolant temperature is greater than or equal to the configured engines max allowed temperature. - The maximum allowed temperature > 110°C. An engine with a CAN engine controller is configured in MACHINE SETUP: <ul style="list-style-type: none"> - ECM transmits a J1939 DM1 message for an engine coolant high temperature critical fault (SPN:FMI 110:0) on CAN2 or uses the J1939 Transport Protocol every one second to send this information if multiple engine faults exist. | Power Cycled |
| 4310 | NO ALTERNATOR OUTPUT | The Engine State = ENGINE RUNNING > 10 seconds and UGM system voltage < 11.5 volts for 10 seconds | UGM system voltage > 11.7 volts |
| 4311 | LOW OIL PRESSURE | An engine with a CAN engine controller is <u>not</u> configured in MACHINE SETUP <ul style="list-style-type: none"> - The Engine State = ENGINE RUNNING > 10 seconds - The engine oil pressure is LOW (debounce 3s). An engine with a CAN engine controller is configured in MACHINE SETUP <ul style="list-style-type: none"> - ECM transmits a J1939 DM1 message for an engine oil low pressure critical fault (SPN:FMI 100:1) on CAN2 or uses the J1939 Transport Protocol every one second to send this information if multiple engine faults exist. | Power Cycled |
| 4334 | ENGINE COOLANT – LOW LEVEL | MACHINE SETUP → ENGINE = DEUTZ EMR4; ECM transmits a J1939 DM1 message for an engine coolant low level fault (SPN:FMI 111:1) on CAN2 or uses the J1939 Transport Protocol every one second to send this information if multiple engine faults exist. | Power Cycled |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|---|---|--|
| 4375 | WATER IN FUEL | MACHINE SETUP → ENGINE = DEUTZ EMR4; ECM transmits a J1939 DM1 message for a water in fuel fault (SPN 97) on CAN2 or uses the J1939 Transport Protocol every one second to send this information if multiple engine faults exist. | Power Cycled |
| 441 | BATTERY VOLTAGE TOO LOW – SYSTEM SHUTDOWN | The UGM detects that its supply voltage is less than 9 volts Engine State ≠ ENGINE CRANKING Auxiliary Power/Emergency Descent Mode is not active | Voltage is greater than 9.25 volts |
| 442 | BATTERY VOLTAGE TOO HIGH – SYSTEM SHUTDOWN | The UGM detects that its supply voltage > 16.0 volts | Power Cycled |
| 443 | LSS BATTERY VOLTAGE TOO HIGH | MACHINE SETUP → LOAD SYSTEM ≠ NO; The UGM determines that the LSS reports supply voltage > 16.0V | Not all of the trigger conditions are met |
| 444 | LSS BATTERY VOLTAGE TOO LOW | MACHINE SETUP → LOAD SYSTEM ≠ NO; Engine State ≠ ENGINE CRANKING or ENGINE STARTING; Auxiliary Power/Emergency Descent Mode is not active; If Load System is the 4-Cell LSS; The UGM determines that the LSS reports supply voltage < 9.0V If Load System is the 1-Cell LSS; The UGM determines that the LSS reports supply voltage < 8.0V or the LSS Supply Voltage reports Out of Range Low Error | Not all of the trigger conditions are met |
| 445 | BATTERY VOLTAGE LOW | The UGM detects that its supply voltage < 11 volts for 5 seconds. Engine State ≠ ENGINE CRANKING Auxiliary Power/Emergency Descent Mode is not active Glow Plugs are not energized | Voltage is greater than 11.25 volts |
| 4434 | ENGINE START FAILED - TOO MANY ATTEMPTS | MACHINE SETUP → ENGINE = FORD DUAL FUEL; Cumulative Crank Time > 24 seconds | Power Cycled |
| 4479 | LSS BATTERY VOLTAGE - INITIALIZATION ERROR | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; LSS Supply Voltage reports Initialization Error | Power Cycled |
| 4480 | LSS BATTERY VOLTAGE - NOT CALIBRATED | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; LSS Supply Voltage reports Not Calibrated Error | Power Cycled |
| 662 | CANBUS FAILURE – PLATFORM MODULE | UGM does not receive any CAN messages from the PM in 250ms | CAN messages are received from the PM |
| 663 | CANBUS FAILURE – LOAD SENSING SYSTEM MODULE | MACHINE SETUP → LOAD SYSTEM ≠ NO; UGM does not receive any CAN messages from the LSS module in 250ms; If Load System is the 1-Cell LSS; Engine State ≠ (ENGINE CRANKING or ENGINE STARTING) > 2 seconds; | Not all of the trigger conditions are met |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|--|---|--|
| 666 | CANBUS FAILURE – ENGINE CONTROLLER | An engine with a CAN engine controller is configured in MACHINE SETUP No CAN messages are received from the engine controller for more than 250ms | CAN messages are received from the engine controller; UGM shall require re-activation of Footswitch (Platform Mode) or Ground Enable (Ground Mode) to enable functions and resume operation. |
| 6613 | CANBUS FAILURE – EXCESSIVE CANBUS ERRORS | More than 22 error frames per second for 4 seconds or more than 500 Buss Off conditions since last power cycle. | Power Cycled |
| 6622 | CANBUS FAILURE – TCU MODULE | MACHINE SETUP → CLEARSKY = YES No CAN2 messages are received from the TCU module for more than 30 seconds | Not all of the trigger conditions are met |
| 6635 | CANBUS FAILURE – CHASSIS TILT SENSOR | UGM does not receive any CAN messages from the Chassis Tilt Sensor in 250ms | CAN messages are received from the Chassis tilt Sensor and controls are initialized |
| 6651 | CANBUS FAILURE - GROUND DISPLAY | UGM does not receive any CAN messages from the Ground Display in 250ms | CAN messages are received from the Ground Display |
| 6657 | CANBUS FAILURE – TEMPERATURE SENSOR | MACHINE SETUP → TEMP CUTOUT = YES; UGM does not receive any CAN messages from the Ambient Temperature sensor in 250ms | CAN messages are received from the Ambient Temperature sensor |
| 681 | REMOTE CONTRACT MANAGEMENT OVERRIDE – ALL FUNCTIONS IN CREEP | MACHINE SETUP → CLEARSKY = YES Value set by ClearSky TCU | Cleared by ClearSky TCU |
| 813 | CHASSIS TILT SENSOR NOT CALIBRATED | The UGM detects one of the follow conditions: The tilt sensor has not been calibrated; For 600S the Tilt Sensor source Address is 0xCO; For 600S the Tilt Sensor Serial number does not match | Tilt sensor calibrated |
| 814 | CHASSIS TILT SENSOR OUT OF RANGE | Fault CHASSIS TILT SENSOR NOT CALIBRATED (813) is not present and Tilt sensor measurement > 19° for 4 seconds (internal tilt sensor based machines) or > 35° (external tilt sensor based machines) Not to be reported during Tilt Sensor calibration. | Not all of the trigger conditions are met. |
| 818 | TILT SENSOR STAGNANT | The UGM detects the following conditions: The X axis or Y axis raw readings change by $\pm 0.05^\circ$ in 5 second; Drive Forward or Drive Reverse output value is \geq Creep output value; Do not report if DTC 6635, 813 or 814 are active | Power Cycled |
| 8112 | CHASSIS TILT SENSOR - SINGLE POINT CALIBRATION PERFORMED | Single point Chassis Tilt calibration is successfully completed | Fault shall be retentive through Power Cycled; Can be reset if CALIBRATIONS → TILT SENSOR is successfully completed |
| 821 | LSS CELL #1 ERROR | MACHINE SETUP → LOAD SYSTEM \neq NO; Load System is the 4-Cell LSS; The UGM detects that LSS is reporting error with Cell #1 | Not all of the trigger conditions are met |
| 822 | LSS CELL #2 ERROR | MACHINE SETUP → LOAD SYSTEM \neq NO; Load System is the 4-Cell LSS; The UGM detects that LSS is reporting error with Cell #2 | Not all of the trigger conditions are met |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|--|---|--|
| 823 | LSS CELL #3 ERROR | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 4-Cell LSS; The UGM detects that LSS is reporting error with Cell #3 | Not all of the trigger conditions are met |
| 824 | LSS CELL #4 ERROR | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 4-Cell LSS; The UGM detects that LSS is reporting error with Cell #4. | Not all of the trigger conditions are met |
| 825 | LSS HAS NOT BEEN CALIBRATED | MACHINE SETUP → LOAD SYSTEM ≠ NO If Load System is the 4-Cell LSS; The load sensor has not been calibrated, or DTC 992 (LSS EEPROM ERROR) is active, or DTC 9977 (LSS CORRUPT EEPROM) is active If Load System is the 1-Cell LSS; The LSS serial number does not match | Not all of the trigger conditions are met |
| 826 | RUNNING AT CREEP – PLATFORM OVERLOADED | Refer to Table 7-1 for trigger conditions and machine response requirements | Not all of the trigger conditions are met |
| 828 | LIFT UP & TELE OUT PREVENTED – PLATFORM OVERLOADED | Refer to Table 7-1 for trigger conditions and machine response requirements | Not all of the trigger conditions are met |
| 829 | FUNCTIONS CUTOUT – PLATFORM OVERLOADED | Refer to Table 7-1 for trigger conditions and machine response requirements | Not all of the trigger conditions are met |
| 8211 | LSS READING UNDERWEIGHT | MACHINE SETUP → LOAD SYSTEM ≠ NO; If Load System is the 4-Cell LSS; The load sensor has been calibrated and Gross Platform Weight < (0.5 * Empty Platform Weight); If Load System is the 1-Cell LSS; UGM determines that the Platform Load < (-1.5 * Unloaded Platform Weight); If Load System is the 1-Cell LSS; Drive Forward / Reverse or Lift Up output value is ≥ Creep output value; Platform Load is < -50 lb for the first 5 seconds of command; Do not report if DTC (0030 or 825) is active or if Platform Load == Unhealthy | If Load System is the 4-Cell LSS; Not all of the trigger conditions are met If Load System is the 1-Cell LSS; Power Cycled |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|---|---|---|
| 8218 | LSS SENSOR DISAGREEMENT | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; The UGM detects that (Platform Load 1 and Platform Load 2 disagree by 50 lb for longer than 3 seconds) or (that Platform Gross 1 and Platform Gross 2 disagree by 200 lb for longer than 3 seconds); Do not report if (DTC 8222 or 8223) is active or if Platform Load == Unhealthy, Platform Gross 1 == Unhealthy or Platform Gross 2 == Unhealthy | Power Cycled or CALIBRATIONS LOAD SENSING is successfully completed |
| 8222 | LSS STRAIN GAUGE 1 - STAGNANT | MACHINE SETUP → LOAD SYSTEM ≠ NO; Engine State ≠ (ENGINE CRANKING or ENGINE STARTING) > 2 seconds; Load System is the 1-Cell LSS; Strain Gauge 1 raw reading does change value for 5 seconds; Do not report if Platform Gross 1 == Unhealthy | Power Cycled |
| 8223 | LSS STRAIN GAUGE 2 - STAGNANT | MACHINE SETUP → LOAD SYSTEM ≠ NO; Engine State ≠ (ENGINE CRANKING or ENGINE STARTING) > 2 seconds; Load System is the 1-Cell LSS; Strain Gauge 2 raw reading does change value for 5 seconds; Do not report if DTC Platform Gross 2 == Unhealthy | Power Cycled |
| 8224 | LSS STRAIN GAUGE 1 - OUT OF RANGE LOW | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 1 reports an Out of Range Low error | Power Cycled |
| 8225 | LSS STRAIN GAUGE 2 - OUT OF RANGE LOW | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 2 reports an Out of Range Low error | Power Cycled |
| 8226 | LSS STRAIN GAUGE 1 - OUT OF RANGE HIGH | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 1 reports an Out of Range High error | Power Cycled |
| 8227 | LSS STRAIN GAUGE 2 - OUT OF RANGE HIGH | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 2 reports an Out of Range High error | Power Cycled |
| 8228 | LSS STRAIN GAUGE 1 - INITIALIZATION ERROR | MACHINE SETUP → LOAD SYSTEM ≠ NO; Engine State ≠ (ENGINE CRANKING or ENGINE STARTING) > 2 seconds; Load System is the 1-Cell LSS; Strain Gauge 1 reports an Initialization error | Power Cycled |
| 8229 | LSS STRAIN GAUGE 2 - INITIALIZATION ERROR | MACHINE SETUP → LOAD SYSTEM ≠ NO; Engine State ≠ (ENGINE CRANKING or ENGINE STARTING) > 2 seconds; Load System is the 1-Cell LSS; Strain Gauge 2 reports an Initialization error | Power Cycled |
| 8230 | LSS STRAIN GAUGE 1 - NOT CALIBRATED | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 1 reports a Not Calibrated error | Power Cycled |

SECTION 6 - JLG CONTROL SYSTEM

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|---|--|--|
| 8231 | LSS STRAIN GAUGE 2 - NOT CALIBRATED | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 2 reports a Not Calibrated error | Power Cycled |
| 8232 | LSS STRAIN GAUGE 1 - SENSOR DEFECT | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 1 reports a Sensor Defect error | Power Cycled |
| 8233 | LSS STRAIN GAUGE 2 - SENSOR DEFECT | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 2 reports a Sensor Defect error | Power Cycled |
| 8234 | LSS STRAIN GAUGE 1 - NOT INSTALLED | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 1 reports a Not Installed error | Power Cycled |
| 8235 | LSS STRAIN GAUGE 2 - NOT INSTALLED | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 2 reports a Not Installed error | Power Cycled |
| 8236 | LSS NOT DETECTING CHANGE | MACHINE SETUP → LOAD SYSTEM ≠ NO; Machine is in Platform Mode; Load System is the 1-Cell LSS; Drive Forward / Reverse or Lift Up output value is ≥ Creep output value; Platform Load does not change (peak to peak) by more than 1 lb within the first 5 seconds of the command; Do not report if Platform Load == Unhealthy | Power Cycled |
| 8237 | LSS STRAIN GAUGE 1 - A/D DEFECT | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 1 reports a A/D Defect error | Power Cycled |
| 8238 | LSS STRAIN GAUGE 2 - A/D DEFECT | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; Strain Gauge 2 reports a A/D Defect error | Power Cycled |
| 8652 | RIGHT TRACK FORWARD VALVE - OPEN CIRCUIT | The UGM detects an open circuit at this output | Power Cycled |
| 8654 | RIGHT TRACK FORWARD VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 8655 | RIGHT TRACK REVERSE VALVE - OPEN CIRCUIT | The UGM detects an open circuit at this output | Power Cycled |
| 8657 | RIGHT TRACK REVERSE VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 8658 | LEFT TRACK FORWARD VALVE - OPEN CIRCUIT | The UGM detects an open circuit at this output | Power Cycled |
| 8660 | LEFT TRACK FORWARD VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 8661 | LEFT TRACK REVERSE VALVE - OPEN CIRCUIT | The UGM detects an open circuit at this output | Power Cycled |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|--|---|---|
| 8663 | LEFT TRACK REVERSE VALVE - SHORT TO GROUND | The UGM detects a short to ground at this output | Power Cycled |
| 8690 | LEFT TRACK VALVES - SHORT TO BATTERY | The UGM detects a short to battery at either the Left Track Forward or Left Track Reverse valves | Power Cycled |
| 8691 | RIGHT TRACK VALVES - SHORT TO BATTERY | The UGM detects a short to battery at either the Right Track Forward or Right Track Reverse valves | Power Cycled |
| 873 | MACHINE SAFETY SYSTEM OVERRIDE OCCURRED | MSSO = Active | Fault shall be retentive through Power Cycled; Can be reset only with an Analyzer via the CALIBRATIONS → MSSO → MSSO RESET menu |
| 876 | WIRE ROPE SERVICE REQUIRED | MACHINE SETUP → CABLE SWITCH = YES; Wire Rope Service = Enabled | Power Cycled |
| 991 | LSS WATCHDOG RESET | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 4-Cell LSS; UGM detects LSS report of an anomaly exists that has caused a WatchDog Timer reset. | Power Cycled |
| 992 | LSS EEPROM ERROR | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 4-Cell LSS; UGM detects LSS report of an anomaly that exists in the LSS EEPROM | Power Cycled |
| 993 | LSS INTERNAL ERROR – PIN EXCITATION | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 4-Cell LSS; UGM detects LSS report of improper excitation voltage | Power Cycled |
| 994 | LSS INTERNAL ERROR – DRDY MISSING FROM A/D | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 4-Cell LSS; UGM detects LSS report of an anomaly that exists in the LSS A/D converter operations. | Power Cycled |
| 998 | EEPROM FAILURE - CHECK ALL SETTINGS | The UGM has detected an anomaly in EEPROM | Power Cycled |
| 9910 | FUNCTIONS LOCKED OUT - PLATFORM MODULE SOFTWARE VERSION IMPROPER | The UGM software version type is 'P' The UGM has received valid version information from the PM The PM software version type is 'P' The UGM software major version number does not match the major version number of the platform software | Not all of the trigger conditions are met |
| 9911 | FUNCTION LOCKED OUT - LSS MODULE SOFTWARE VERSION IMPROPER | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 4-Cell LSS; The UGM determines that the LSS software version is not compatible with existing code | Power Cycled |
| 9915 | CHASSIS TILT SENSOR NOT GAIN CALIBRATED | The tilt sensor gain calibration values recorded to flash memory during Phoenix International's manufacturing test are not present | Valid values are present |
| 9920 | PLATFORM SENSOR REF VOLTAGE OUT OF RANGE | The PM detects that its reference voltage is out of range and reports the fault to the UGM | Power Cycled |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|------|--|--|--|
| 9921 | GROUND MODULE FAILURE:HIGH SIDE DRIVER CUTOUT FAULTY | The engine is not running The engine is not cranking The UGM footswitch input J7-15 is LOW The machine is in Platform Mode The Main Dump output J2-13 is detected as HIGH via the analog feedback 300ms after it is attempted to be activated during the one time startup test of the UGM hardware shutoff circuitry | Power Cycled |
| 9922 | PLATFORM MODULE FAILURE: HWFS CODE 1 | The PM detects that its V(low) FET has failed and reports this fault to the UGM | Power Cycled |
| 9924 | FUNCTIONS LOCKED OUT - MACHINE NOT CONFIGURED | The machine is powered up and no model has been selected yet in the MACHINE SETUP menu | Power Cycled |
| 9927 | GROUND MODULE CONSTANT DATA UPDATE REQUIRED | The UGM detects one of the following conditions when software type is 'P' or 'B': The Version Verification Word #1 or the Version Verification Word #2 values located in the constant data sector of flash memory (found on constant data spreadsheet tab pstConstantDataVersion) do not match the values located in the code area of flash memory The Version Major value located in the constant data sector of flash memory (found on constant data spreadsheet tab pstConstantDataVersion) does not match the value located in the code area of flash memory | A different application code or constant data version is programmed so that the values match Power Cycled |
| 9944 | CURRENT FEEDBACK GAINS OUT OF RANGE | One or more of the current feedback gains that are calculated and written to flash memory during the PIC manufacturing test process are detected as being out of range | Power Cycled |
| 9945 | CURRENT FEEDBACK CALIBRATION CHECKSUM INCORRECT | The current feedback gains checksum that is calculated and written to flash memory during the PIC manufacturing test process is detected as being incorrect | Power Cycled |
| 9949 | MACHINE CONFIGURATION OUT OF RANGE – CHECK ALL SETTINGS | UGM has detected an anomaly in EEPROM with regard to the Machine Setup configuration. | Power Cycled and EEPROM data in associated area is changed |
| 9977 | LSS CORRUPT EEPROM | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 4-Cell LSS; and one of the following conditions: UGM determines LSS-stored values for Unloaded weight in Indirect 0x100 ≠ 0x108 or UGM determines LSS-stored values for Accessory weight in Indirect 0x102 ≠ 0x10A UGM determines LSS-stored checksum1 (0x10F) ≠ checksum 2 (0x107) | Power Cycled |
| 9979 | FUNCTIONS LOCKED OUT - GROUND MODULE SOFTWARE VERSION IMPROPER | Ground software has been installed on a UGM with a ST10F274 processor (Hardware Rev < 6), which does not have guaranteed flash storage in the sector where Constant Data is written. | Power Cycled |

Table 6-13. Diagnostic Trouble Codes

| DTC | Help Message | Fault Condition/Trigger (For configurable items, fault applies only if configured. All listed conditions to be met unless stated otherwise) | Conditions Required for Movement and/or to Clear Fault |
|-------|---------------------------------|--|--|
| 9986 | GROUND MODULE VLOW FET FAILURE | VLow FET determined to be failed because all Digital Inputs are high; UGM unable to read high-sensing inputs. | Power Cycled |
| 99285 | LSS - FACTORY CALIBRATION ERROR | MACHINE SETUP → LOAD SYSTEM ≠ NO; Load System is the 1-Cell LSS; LSS reports an Error Status (other than 0,1,2,8,30,31) | Power Cycled |

Go to Discount-Equipment.com to order your parts

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your information to search for parts manuals and lookup part numbers.

* Brand:

* Model:

* Serial:

* Part Number:

SEARCH

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the information below to request help finding a part or manual.

Manufacturer:

Model:

Description:

Part Number:

Quantity:

Submit

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 7. BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

7.1 GENERAL

This section contains basic electrical information and schematics for locating and correcting most electrical problems. If a problem develops which is not presented in this section or corrected by listed corrective actions, obtain technically qualified guidance before proceeding with any additional maintenance.

NOTE: Some procedures/connectors shown in this section may not apply to all models.

7.2 MULTIMETER BASICS

A wide variety of multimeters or Volt Ohm Meters (VOM) can be used for troubleshooting your equipment. This section shows diagrams of a common, digital VOM configured for several different circuit measurements. Instructions for your VOM may vary. Please consult the meter operator's manual for more information.

Grounding

"Grounding the meter" means to take the black lead (which is connected to the COM (common) or negative port) and touch it to a good path to the negative side of the Voltage source.

Backprobing

To "backprobe" means to take the measurement by accessing a connector's contact on the same side as the wires, the back of the connector. Readings can be done while maintaining circuit continuity this way. If the connector is the sealed type, great care must be taken to avoid damaging the seal around the wire. It is best to use probes or probe tips specifically designed for this technique, especially on sealed connectors. Whenever possible insert probes into the side of the connector such that the test also checks both terminals of the connection. It is possible to inspect a connection within a closed connector by backprobing both sides of a connector terminal and measuring resistance. Do this after giving each wire a gentle pull to ensure the wires are still attached to the contact and contacts are seated in the connector.

Min/Max

Use of the "Min/Max" recording feature of some meters can help when taking measurements of intermittent conditions while alone. For example, you can read voltage applied to a solenoid when it is only operational while a switch, far from the solenoid and meter, is held down.

Polarity

Getting a negative Voltage or current reading when expecting a positive reading frequently means the leads are reversed. Check what reading is expected, location of the signal and leads are correctly connected to the device under test. Also check the lead on the "COM" port goes to the ground or negative side of the signal and lead on the other port goes to the positive side of the signal.

Scale

M = Mega = 1,000,000 * (Displayed Number)

k = kilo = 1,000 * (Displayed Number)

m = milli = (Displayed Number) / 1,000

μ = micro = (Displayed Number) / 1,000,000

Example: 1.2 kW = 1200 W

Example: 50 mA = 0.05 A

Voltage Measurement




Figure 7-1. Voltage Measurement (DC)

- If meter is not auto ranging, set it to the correct range (See multimeter's operation manual)
- Use firm contact with meter leads

Resistance Measurement




Figure 7-2. Resistance Measurement

- First test meter and leads by touching leads together. Resistance should read a short circuit (very low resistance)
- Circuit power must be turned OFF before testing resistance
- Disconnect component from circuit before testing
- If meter is not auto ranging, set it to the correct range (See multimeter's operation manual)
- Use firm contact with meter leads

Continuity Measurement




Figure 7-3. Continuity Measurement

- Some meters require a separate button press to enable audible continuity testing
- Circuit power must be turned OFF before testing continuity
- Disconnect component from circuit before testing
- Use firm contact with meter leads
- First test meter and leads by touching leads together. Meter should produce an audible alarm, indicating continuity

Current Measurement




Figure 7-4. Current Measurement (DC)

- Set up meter for expected current range
- Be sure to connect meter leads to correct jacks for selected current range
- If meter is not auto ranging, set it to correct range (See multi meter's operation manual)
- Use firm contact with meter leads

7.3 APPLYING SILICONE DIELECTRIC COMPOUND TO ELECTRICAL CONNECTIONS

NOTE: This section is not applicable for battery terminals.

NOTICE

JLG PN 0100048 DIELECTRIC GREASE (NOVAGARD G661) IS THE ONLY MATERIAL APPROVED FOR USE AS A DIELECTRIC GREASE.

NOTE: Do NOT apply dielectric grease to the following connections:

- Main Boom Rotary sensor connections (on Celesco Sensor).
- LSS Modules connections.
- Deutz EMR 2 ECM connection.

Silicone Dielectric Compound must be used on all electrical connections except for those mentioned above for the following reasons:

- To prevent oxidation at the mechanical joint between male and female pins.
- To prevent electrical malfunction caused by low level conductivity between pins when wet.

Use the following procedure to apply Silicone Dielectric Compound to the electrical connectors. This procedure applies to all plug connections not enclosed in a box. Silicone grease should not be applied to connectors with external seals.

1. To prevent oxidation, silicone grease must be packed completely around male and female pins on the inside of the connector prior to assembly. This is most easily achieved by using a syringe.

NOTE: Over a period of time, oxidation increases electrical resistance at the connection, eventually causing circuit failure.

2. To prevent shorting, silicone grease must be packed around each wire where they enter the outside of the connector housing. Also, silicone grease must be applied at the joint where the male and female connectors come together. Any other joints (around strain reliefs, etc.) where water could enter the connector should also be sealed.

NOTE: This condition is especially common when machines are pressure washed since the washing solution is much more conductive than water.

- 3. Anderson connectors for the battery boxes and battery chargers should have silicone grease applied to the contacts only.

NOTE: *Curing-type sealants might also be used to prevent shorting and would be less messy, but would make future pin removal more difficult.*

When applied to electrical connections, dielectric grease helps to prevent corrosion of electrical contacts and improper conductivity between contacts from moisture intrusion. Open and sealed connectors benefit from the application of dielectric grease.

Dielectric grease shall be applied to all electrical connectors at the time of connection (except those noted under Exclusions).

7.4 DIELECTRIC GREASE APPLICATION

Dielectric grease helps to prevent corrosion of electrical contacts and improper conductivity between contacts from moisture intrusion. Non-waterproof connectors benefit from the application of dielectric grease.

Installation


The following is general guidance for the installation of dielectric grease in a connector system.

- Use dielectric grease in a tube for larger connection points or apply with a syringe for small connectors.
- Apply dielectric grease to plug/male connector housing which typically contains sockets contact/female terminals.
- Leave a layer of dielectric grease on the mating face of the connector, completely covering each connector terminal hole. Refer the pictures shown below.
- Assemble the connector system immediately to prevent moisture ingress or dust contamination.

The following connector systems are specifically addressed because of their widespread use at JLG. However, this guidance may be applied to similar devices.

AMP Mate-N-Lok

This connector system is widely used inside enclosures for general-purpose interconnect. Follow the general guidance for installation.



Improper

Proper

AMP Faston

This connector system is typically used on operator switches at JLG. Follow the general guidance for installation.




Improper

Proper

AMP Micro-Fit

This connector system is typically used on control modules at JLG. Follow the general guidance for installation.




Improper

Proper

AMP Mini Fit Jr

This connector system is typically used on control modules at JLG. Follow the general guidance for installation.




Improper



Proper

Mini Fit Sr

This connector system is typically used on control modules at JLG. Follow the general guidance for installation.




Improper



Proper

DIN Connectors

This connector is typically used on hydraulic valves. Follow the installation instructions



Improper



Proper

Exceptions

Some waterproof connector applications do benefit from dielectric grease, and some non waterproof connectors do not benefit from dielectric grease.

In the exceptions below, we have found dielectric grease is not needed for some applications, and in some cases can interfere with the intended connection. Dielectric grease shall be used as an exception in other applications.

Enclosures

Application of dielectric grease is not required in properly sealed enclosures. To meet criteria, the enclosure must be rated to at least IP56 (dust protected; protected from powerful jets of water).

Carling Switch Connectors

Carling switches may experience high impedance, or discontinuity, due to silicone dielectric grease ingress when switching inductive loads. Therefore, dielectric grease shall not be applied to Carling switch mating connectors unless specifically noted.

7.5 AMP CONNECTOR

Assembly

Check to be sure the wedge lock is in the open, or as-shipped, position (See Figure 7-5.). Proceed as follows:




Figure 7-5. Connector Assembly Figure 1

1. To insert a contact, push it straight into the appropriate circuit cavity as far as it will go (See Figure 7-7.).

2. Pull back on the contact wire with a force of 1 or 2 lb to be sure the retention fingers are holding the contact (See Figure 7-7.).




Figure 7-6. AMP Connector




Figure 7-7. Connector Assembly Figure 2

3. After all required contacts have been inserted, the wedge lock must be closed to its locked position. Release the locking latches by squeezing them inward (See Figure 7-8.).

4. Slide the wedge lock into the housing until it is flush with the housing (See Figure 7-9.).




Figure 7-8. Connector Assembly Figure 3




Figure 7-9. Connector Assembly Figure 4




Figure 7-10. Connector Disassembly

Disassembly

5. Insert a 4.8 mm (3/16") wide screwdriver blade between the mating seal and one of the red wedge lock tabs.
6. Pry open the wedge lock to the open position.
7. While rotating the wire back and forth over a half turn (1/4 turn in each direction), gently pull the wire until the contact is removed.

NOTE: *The wedge lock should never be removed from the housing for insertion or removal of the contacts.*

Wedge Lock

The wedge lock has slotted openings in the forward, or mating end. These slots accommodate circuit testing in the field, by using a flat probe such as a pocket knife. DO NOT use a sharp point such as an ice pick.

Service - Voltage Reading

NOTICE

DO NOT PIERCE WIRE INSULATION TO TAKE VOLTAGE READINGS.

It has been common practice in electrical troubleshooting to probe wires by piercing the insulation with a sharp point. This practice should be discouraged when dealing with the AMP-SEAL plug assembly, or any other sealed connector system. The resulting pinholes in the insulation will allow moisture to invade the system by traveling along the wire strands. This nullifies the effectiveness of the connector seals and could result in system failure.




Figure 7-11. Connector Installation

7.6 DEUTSCH CONNECTORS

DT/DTP Series Assembly




Figure 7-12. DT/DTP Contact Installation

1. Grasp crimped contact about 25mm behind the contact barrel.
2. Hold connector with rear grommet facing you.
3. Push contact straight into connector grommet until a click is felt. A slight tug will confirm that it is properly locked in place.
4. Once all contacts are in place, insert wedgelock with arrow pointing toward exterior locking mechanism. The wedgelock will snap into place. Rectangular wedges are not oriented. They may go in either way.

NOTE: The receptacle is shown - use the same procedure for plug.

DT/DTP Series Disassembly




Figure 7-13. DT/DTP Contact Removal

5. Remove wedgelock using needlenose pliers or a hook shaped wire to pull wedge straight out.
6. To remove the contacts, gently pull wire backwards, while at the same time releasing the locking finger by moving it away from the contact with a screwdriver.
7. Hold the rear seal in place, as removing the contact may displace the seal.

HD30/HDP20 Series Assembly




Figure 7-14. HD/HDP Contact Installation

8. Grasp contact about 25mm behind the contact crimp barrel.
9. Hold connector with rear grommet facing you.
10. Push contact straight into connector grommet until a positive stop is felt. A slight tug will confirm that it is properly locked in place.




Figure 7-15. HD/HDP Locking Contacts Into Position

NOTE: For unused wire cavities, insert sealing plugs for full environmental sealing.

HD30/HDP20 Series Disassembly




Figure 7-16. HD/HDP Contact Removal

11. With rear insert toward you, snap appropriate size extractor tool over the wire of contact to be removed.
12. Slide tool along into the insert cavity until it engages contact and resistance is felt.
13. Pull contact-wire assembly out of connector.





Figure 7-17. HD/HDP Unlocking Contacts

NOTE: Do Not twist or insert tool at an angle.

7.7 TELEMATICS GATEWAY


Personnel using machines equipped with an optional telematics gateway will be able to view the following data through their telematics device:

| JLG LABEL | DESCRIPTION | UNIT |
|---|--|----------------|
| Engine Speed | Actual engine speed. | RPM |
| DEF Tank Level (If Equipped) | Indicates the level of DEF (diesel exhaust fluid) within the DEF tank if the machine is equipped with DEF tank. <ul style="list-style-type: none"> • 0% = Empty • 100% = Full | Percentage (%) |
| JLG Machine Faults: Active / Not-Active | <ul style="list-style-type: none"> • 00 - No Machine Faults • 01 - Active Machine Fault • 10 - Error • 11 - Not available | Bit |
| Total Idle Fuel Used | Total amount of fuel used during vehicle operation during idle conditions. | Liters |
| Total Idle Hours | Total time of engine operation during idle conditions. | Seconds |
| Total Engine Hours | Total time of engine operation. | Seconds |
| Total Fuel Used | Total amount of fuel used during vehicle operation. | Liters |
| Fuel Rate | Amount of fuel consumed by engine per unit of time. | Liters/Hour |
| Fuel Level | Ratio of fuel volume to the total volume of the fuel storage container. When a low fuel limit switch is present, the fuel level will indicate "full" until the switch opens, which will then indicate 10% fuel remaining. When Fuel Level 2 (SPN38) is not used, Fuel Level 1 represents the total fuel in all fuel storage containers. When Fuel Level 2 is used, Fuel Level 1 represents the fuel level in the primary or left side fuel storage container. | Percentage (%) |
| DM1 Engine Faults | Shows actual engine fault codes. | N/A |



Telematics-Ready (TCU) Plug

The telematics-ready (TCU) plug is a standard 12-pin Deutsch connector. Pin-out locations are shown below:






Figure 7-18. Telematics Gateway Harness - Sheet 1 of 3

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X1609 (TCU) | | | | | |
|-------------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 1-0 BAT | 16 AWG | GXL | X1606 (B) |
| 2 | BLK | 0-0 GND | 16 AWG | GXL | S1615 (1) |
| 4 | ORN | 2-0 IGN | 16 AWG | GXL | S1614 (1) |
| 9 | GRN | CANL2 | 18 AWG | GXL | MS1619-2 (B) |
| 10 | YEL | CANH2 | 18 AWG | GXL | MS1619-2 (A) |

| MS1619-2 (CAN-T 2) | | | | | |
|--------------------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CANH2 | 18 AWG | GXL | X1609 (10) |
| B | GRN | CANL2 | 18 AWG | GXL | X1609 (9) |

| MS1619-3 (CAN-T 2) | | | | | |
|--------------------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CANH2 | 18 AWG | GXL | MS1620-2 (A) |
| B | GRN | CANL2 | 18 AWG | GXL | MS1620-2 (B) |

| CO1613-J1 (GATEWAY 1) | | | | | |
|-----------------------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 9 | GRN | CAN1 | 18 AWG | GXL | MS1618-2 (B) |
| 10 | YEL | CANH1 | 18 AWG | GXL | MS1618-2 (A) |
| 11 | BLK | 0-2 GND | 16 AWG | GXL | S1615 (2) |
| 12 | ORN | 2-2 IGN | 16 AWG | GXL | S1614 (2) |

| CO1613-J2 (GATEWAY 2) | | | | | |
|-----------------------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 9 | GRN | CANL2 | 18 AWG | GXL | MS1620-3 (B) |
| 10 | YEL | CANH2 | 18 AWG | GXL | MS1620-3 (A) |

| MS1620-2 (CAN-T 2) | | | | | |
|--------------------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CANH2 | 18 AWG | GXL | MS1619-3 (A) |
| B | GRN | CANL2 | 18 AWG | GXL | MS1619-3 (B) |

| MS1620-3 (CAN-T 2) | | | | | |
|--------------------|------------|------------|--------|--------|----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CANH2 | 18 AWG | GXL | CO1613-J2 (10) |
| B | GRN | CANL2 | 18 AWG | GXL | CO1613-J2 (9) |

| S1614 | | | | | |
|----------|------------|------------|--------|--------|----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | ORN | 2-0 IGN | 16 AWG | GXL | X1609 (4) |
| 2 | ORN | 2-1 IGN | 16 AWG | GXL | X1606 (H) |
| 2 | ORN | 2-2 IGN | 16 AWG | GXL | CO1613-J1 (12) |

| S1615 | | | | | |
|----------|------------|------------|--------|--------|----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-0 GND | 16 AWG | GXL | X1609 (2) |
| 2 | BLK | 0-1 GND | 16 AWG | GXL | X1606 (A) |
| 2 | BLK | 0-2 GND | 16 AWG | GXL | CO1613-J1 (11) |

| MS1618-2 (CAN-T 1) | | | | | |
|--------------------|------------|------------|--------|--------|----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CANH1 | 18 AWG | GXL | CO1613-J1 (10) |
| B | GRN | CANL1 | 18 AWG | GXL | CO1613-J1 (9) |

| MS1618-3 (CAN-T 1) | | | | | |
|--------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CANH1 | 18 AWG | GXL | X1606 (C) |
| B | GRN | CANL1 | 18 AWG | GXL | X1606 (D) |

| X1606 (DIAG) | | | | | |
|--------------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | BLK | 0-1 GND | 16 AWG | GXL | S1615 (2) |
| B | RED | 1-0 BAT | 16 AWG | GXL | X1609 (1) |
| C | YEL | CANH1 | 18 AWG | GXL | MS1618-3 (A) |
| D | GRN | CANL1 | 18 AWG | GXL | MS1618-3 (B) |
| H | ORN | 2-1 IGN | 16 AWG | GXL | S1614 (2) |

Figure 7-19. Telematics Gateway Harness - Sheet 2 of 3

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| | | | | | FROM | | TO | |
|----------|-------|------------|-------------|--------|-----------|-----|-----------|-----|
| WIRE NO. | COLOR | WIRE GAUGE | LENGTH (mm) | JACKET | REFERENCE | PIN | REFERENCE | PIN |
| CAN L2 | GRN | 18 AWG | 1151 | GXL | MS1619-3 | B | MS1620-2 | B |
| CAN L2 | GRN | 18 AWG | 151 | GXL | X1609 | 9 | MS1619-2 | B |
| CAN L1 | GRN | 18 AWG | 157 | GXL | MS1618-2 | B | CO1613-J1 | 9 |
| CAN L2 | GRN | 18 AWG | 225 | GXL | MS1620-3 | B | CO1613-J2 | 9 |
| CAN L1 | GRN | 18 AWG | 1076 | GXL | MS1618-3 | B | X1606 | D |
| CAN H2 | YEL | 18 AWG | 155 | GXL | X1609 | 10 | MS1619-2 | A |
| CAN H2 | YEL | 18 AWG | 233 | GXL | MS1620-3 | A | CO1613-J2 | 10 |
| CAN H1 | YEL | 18 AWG | 157 | GXL | MS1618-2 | A | CO1613-J1 | 10 |
| CAN H2 | YEL | 18 AWG | 1150 | GXL | MS1619-3 | A | MS1620-2 | A |
| CAN H1 | YEL | 18 AWG | 1079 | GXL | MS1618-3 | A | X1606 | C |
| 0-0 GND | BLK | 16 AWG | 1006 | GXL | X1609 | 2 | S1615 | 1 |
| 0-1 GND | BLK | 16 AWG | 1145 | GXL | X1606 | A | S1615 | 2 |
| 0-2 GND | BLK | 16 AWG | 223 | GXL | CO1613-J1 | 11 | S1615 | 2 |
| 1-0 BAT | RED | 16 AWG | 2150 | GXL | X1609 | 1 | X1606 | B |
| 2-0 IGN | ORN | 16 AWG | 939 | GXL | X1609 | 4 | S1614 | 1 |
| 2-1 IGN | ORN | 16 AWG | 1212 | GXL | S1614 | 2 | X1606 | H |
| 2-2 IGN | ORN | 16 AWG | 287 | GXL | CO1613-J1 | 12 | S1614 | 2 |

Figure 7-20. Telematics Gateway Harness - Sheet 3 of 3

7.8 WIRING HARNESS

Connector Labels

Connectors between harnesses are identified by the prefix “X” and a sequentially assigned number. An optional suffix (letters & numbers) may be added when multiple terminations occur at one device or when there are optional connections.

Examples:

X25 connects to X25 in another harness.

X65A, X65B connect to different portions of one device

X163 connects to X163A in ANSI and X163B in CE machines

Component Labels

Every component on the vehicle has a unique identification. A standard prefix letter is assigned according to the table below, followed by a unique sequential number. An optional suffix (letters & numbers) may be added when multiple terminations occur at one device.

Terminals that are not loaded into connectors are considered independent components and labeled in the same fashion.

Table 7-1. Wiring Harness Connector Labels

| Component | Category | Label |
|---------------------|-------------------|-------|
| Audible | Alarms | AH |
| | Horns | |
| Battery | Batteries | BT |
| | Battery Terminals | |
| Control Module | Ground | CO |
| | LSS | |
| | Platform | |
| Engine | Alternator | EC |
| | Cold Start | |
| | Controller | |
| | Coolant Temp | |
| | Fuel Pump | |
| | Fuel Solenoid | |
| | Glow Plugs | |
| | Oil Pressure | |
| | Starter | |
| Fuse & CB Fuse FC | Fuse | FC |
| | Fusible Link | FC |
| | Circuit Breaker | CB |
| Gauge & Display | Board | GD |
| | Cluster | |
| | Hour meter | |
| | LMI | |
| | Speedometer | |
| Inline | Resistor | R |
| | Diode | D |
| Joystick & Steering | Electronic | JS |
| | Hydraulic | |
| Lights | Dome | LB |
| | Headlights | |
| | Simple | |
| | Taillights | |
| Membrane Panel | | MP |
| Miscellaneous | Radio | MS |
| | Speakers | |
| | Splice Blocks | |
| | T-Connectors | |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

Table 7-1. Wiring Harness Connector Labels

| Component | Category | Label |
|----------------|--------------|-------|
| Other Switches | Disconnect | SW |
| | EMS | |
| | Foot | |
| | HVAC | WH |
| | Key | SW |
| | Park brake | |
| | Pump pot | |
| | Push | |
| | Shifter | |
| | Turn signal | |
| Relay | 5 Pin | RL |
| | 4 Pin | |
| | Contactors | |
| | Power module | |
| Rocker Switch | | SW |
| Sensor | Angle | SN |
| | Fuel | |
| | Length | |
| | Limit | |
| | Load | |
| | Pressure | |
| | Proximity | |
| | Speed | |
| | Temperature | |
| | Terminals | |
| Sockets | | |
| Male Blades | | |
| Female Blades | | |
| Rings | | |
| Forks | | |
| Toggle Switch | DPDT | SW |
| | DPST | |
| | SPDT | |
| | SPST | |
| | Special | |
| Valves | Simple | HV |
| | Suppression | |

Examples:

T67 is a ring terminal connected during installation.

C01-J3 is the J3 connector for a UGM control module.

EC9 is a glow plug supplied with the engine

7.9 WIRING HARNESS





Figure 7-21. Platform Box Harness - Sheet 1 of 6



Go to Discount-Equipment.com to order your parts

1001238409-E
MAF22000E

Figure 7-22. Platform Box Harness - Sheet 2 of 6

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X16 CAN 1 TAP | | | | | |
|---------------|------------|-------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CAN-ONEHIGH | 18 AWG | GXL | MS16 (11) |
| B | GRN | CAN-ONE LOW | 18 AWG | GXL | MS16 (5) |
| C | | | | | |

| X652 TO PLATFORM VALVE HARN | | | | | |
|--------------------------------|------------|-----------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 12-3-1 PLAT VLV- | 18 AWG | GXL | S664 (2) |
| 2 | | | | | |
| 3 | WHT | 90-1 HI PRS DUMP | 18 AWG | GXL | X103 (13) |
| 4 | WHT | 88-1-2 LEVEL UP | 18 AWG | GXL | S352 (2) |
| 5 | WHT | 89-1-2 LEVEL DOWN | 18 AWG | GXL | S654 (1) |
| 6 | | | | | |
| 7 | | | | | |
| 8 | WHT | 58-1 PLAT ANGLE 1 | 18 AWG | GXL | C001-J1 (25) |
| 9 | WHT | 58-0 PLAT ANGLE 2 | 18 AWG | GXL | C001-J1 (26) |
| 10 | WHT | 11-1-1 ANGLE SNSR 5V+ | 18 AWG | GXL | S356 (2) |
| 11 | WHT | 11-1-2 ANGLE SNSR 5V+ | 18 AWG | GXL | S356 (2) |
| 12 | WHT | 90-2 LOW PRS DUMP | 18 AWG | GXL | X103 (15) |
| 13 | WHT | 86-3 ROTATE LEFT | 18 AWG | GXL | C001-J7 (5) |
| 14 | WHT | 87-3 ROTATE RIGHT | 18 AWG | GXL | C001-J7 (6) |
| 15 | WHT | 82-3 JIB UP | 18 AWG | GXL | C001-J7 (25) |
| 16 | WHT | 83-3 JIB DOWN | 18 AWG | GXL | C001-J7 (26) |
| 17 | | | | | |
| 18 | | | | | |
| 19 | | | | | |
| 20 | BLK | 12-11-2 ANGLE SNSR- | 18 AWG | GXL | S355 (2) |
| 21 | BLK | 12-11-1 ANGLE SNSR- | 18 AWG | GXL | S355 (2) |

| X15 CAN 1 TAP | | | | | |
|---------------|------------|-------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CAN-ONEHIGH | 18 AWG | GXL | X103 (3) |
| B | GRN | CAN-ONE LOW | 18 AWG | GXL | X103 (2) |
| C | | | | | |

| X103 TO BOOM CABLE | | | | | |
|-----------------------|------------|--------------------------|--------|--------|---------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | GRN | CAN-ONE LOW | 18 AWG | GXL | X15 (B) |
| 3 | YEL | CAN-ONEHIGH | 18 AWG | GXL | X15 (A) |
| 4 | WHT | 9-0 PLAT MODE/GND ENABLE | 18 AWG | GXL | C001-J7 (3) |
| 5 | WHT | 88-1-1 LEVEL UP | 18 AWG | GXL | S352 (1) |
| 6 | | | | | |
| 7 | WHT | 89-1-1 LEVEL DOWN | 18 AWG | GXL | S654 (2) |
| 8 | | | | | |
| 9 | YEL | 4-0 | 18 AWG | GXL | SW715-1B (1B) |
| 10 | | | | | |
| 11 | WHT | 8-0 GND MODE/PLAT ENABLE | 18 AWG | GXL | C001-J7 (1) |
| 12 | YEL | 2-7 | 12 AWG | GXL | C001-J8 (2) |
| 13 | WHT | 90-1 HI PRS DUMP | 18 AWG | GXL | X652 (3) |
| 14 | | | | | |
| 15 | WHT | 90-2 LOW PRS DUMP | 18 AWG | GXL | X652 (12) |
| 16 | BLK | 0-7 | 12 AWG | GXL | C001-J8 (1) |
| 17 | | | | | |
| 18 | | | | | |
| 19 | | | | | |

| MS16 CAN 1 BUSS | | | | | |
|--------------------|------------|-------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | CAN-ONEHIGH | 20 AWG | CABLE | X687 (4) |
| 2 | YEL | CAN-ONEHIGH | 18 AWG | GXL | X303 (8) |
| 3 | YEL | CAN-ONEHIGH | 18 AWG | GXL | C001-J7 (31) |
| 4 | GRN | CAN-ONE LOW | 18 AWG | GXL | C001-J7 (30) |
| 5 | GRN | CAN-ONE LOW | 18 AWG | GXL | X16 (B) |
| 6 | GRY | CAN-ONE LOW | 20 AWG | CABLE | X687 (5) |
| 7 | GRN | CAN-ONE LOW | 18 AWG | GXL | X303 (9) |
| 8 | | | | | |
| 9 | GRN | CAN-ONE LOW | 20 AWG | TXL | GD14 (4) |
| 10 | YEL | CAN-ONEHIGH | 20 AWG | TXL | GD14 (1) |
| 11 | YEL | CAN-ONEHIGH | 18 AWG | GXL | X16 (A) |
| 12 | | | | | |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| S352 | | | | | |
|----------|------------|-----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 88-1 LEVEL UP | 18 AWG | GXL | C001-J7 (15) |
| 1 | WHT | 88-1-1 LEVEL UP | 18 AWG | GXL | X103 (5) |
| 2 | WHT | 88-1-2 LEVEL UP | 18 AWG | GXL | X652 (4) |

| S654 | | | | | |
|----------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 89-1-2 LEVEL DOWN | 18 AWG | GXL | X652 (5) |
| 2 | WHT | 89-1 LEVEL DOWN | 18 AWG | GXL | C001-J7 (16) |
| 2 | WHT | 89-1-1 LEVEL DOWN | 18 AWG | GXL | X103 (7) |

| S663 | | | | | |
|----------|------------|--------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 10-10 SKYG/GEN+ | 18 AWG | GXL | C001-J7 (7) |
| 1 | YEL | 10-10-2 SKY GUARD+ | 18 AWG | GXL | X5A (1) |
| 2 | YEL | 10-10-1 GEN+ | 18 AWG | GXL | X305A (2) |

| X687 SINGLE CELL LSS | | | | | |
|-------------------------|------------|-------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | YEL | 10-2 LSS+ | 20 AWG | CABLE | C001-J2 (32) |
| 3 | BLU | 12-4 LSS- | 20 AWG | CABLE | C001-J7 (22) |
| 4 | BLK | CAN-ONEHIGH | 20 AWG | CABLE | MS16 (1) |
| 5 | GRY | CAN-ONE LOW | 20 AWG | CABLE | MS16 (6) |

| X305A OPTIONS | | | | | |
|---------------|------------|--------------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 508-1 GENERATOR SW INPUT | 18 AWG | GXL | C001-J7 (9) |
| 2 | YEL | 10-10-1 GEN+ | 18 AWG | GXL | S663 (2) |
| 3 | | | | | |
| 4 | WHT | 7-2 FOOT SW N.C. | 18 AWG | GXL | C001-J7 (8) |
| 5 | YEL | 10-3 FOOT SW+ | 18 AWG | GXL | C001-J7 (4) |
| 6 | | | | | |
| 7 | | | | | |
| 8 | | | | | |
| 9 | YEL | 10-8-2 SOFT TOUCH+ | 18 AWG | GXL | S360 (2) |
| 10 | | | | | |
| 11 | | | | | |
| 12 | WHT | 504-1-2 SOFT TOUCH | 18 AWG | GXL | S12 (2) |
| 13 | | | | | |
| 14 | WHT | 1-551 | 18 AWG | GXL | X305A (15) |
| 15 | WHT | 1-551 | 18 AWG | GXL | X305A (14) |




Figure 7-23. Platform Box Harness - Sheet 3 of 6

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| S12 | | | | | |
|----------|------------|--------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 504-1 SOFT TOUCH | 18 AWG | GXL | CO01-J1 (20) |
| 2 | WHT | 504-1-1 SOFT TOUCH | 18 AWG | GXL | X5A (6) |
| 2 | WHT | 504-1-2 SOFT TOUCH | 18 AWG | GXL | X305A (12) |

| S356 | | | | | |
|----------|------------|-----------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 11-1 ANGLE SNSR 5V+ | 18 AWG | GXL | CO01-J7 (11) |
| 2 | WHT | 11-1-1 ANGLE SNSR 5V+ | 18 AWG | GXL | X652 (10) |
| 2 | WHT | 11-1-2 ANGLE SNSR 5V+ | 18 AWG | GXL | X652 (11) |

| S360 | | | | | |
|----------|------------|--------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 10-8 SOFT TOUCH+ | 18 AWG | GXL | CO01-J2 (34) |
| 2 | YEL | 10-8-1 SOFT TOUCH+ | 18 AWG | GXL | X5A (3) |
| 2 | YEL | 10-8-2 SOFT TOUCH+ | 18 AWG | GXL | X305A (9) |

| S353 | | | | | |
|----------|------------|----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 10-6 OPTION+ | 18 AWG | GXL | CO01-J2 (33) |
| 2 | YEL | 10-6-1 OPTION+ | 18 AWG | GXL | X303 (7) |
| 2 | YEL | 10-6-2 OPTION+ | 18 AWG | GXL | X303 (11) |

| S355 | | | | | |
|----------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 12-11 ANGLE SNSR- | 18 AWG | GXL | CO01-J7 (14) |
| 2 | BLK | 12-11-1 ANGLE SNSR- | 18 AWG | GXL | X652 (21) |
| 2 | BLK | 12-11-2 ANGLE SNSR- | 18 AWG | GXL | X652 (20) |

| AH712+ ALARM | | | | | |
|--------------|------------|----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 94-2 PLATALARM | 18 AWG | GXL | CO01-J7 (19) |

| X5A SG/ST | | | | | |
|-----------|------------|--------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 10-10-2 SKY GUARD+ | 18 AWG | GXL | S663 (1) |
| 2 | BLK | 12-10 SKY GUARD- | 18 AWG | GXL | CO01-J7 (21) |
| 3 | YEL | 10-8-1 SOFT TOUCH+ | 18 AWG | GXL | S360 (2) |
| 4 | WHT | 503-1 SKYG INPUT 1 | 18 AWG | GXL | CO01-J7 (18) |
| 5 | WHT | 503-2 SKYG INPUT 2 | 18 AWG | GXL | CO01-J1 (23) |
| 6 | WHT | 504-1-1 SOFT TOUCH | 18 AWG | GXL | S12 (2) |

| X303 OPTIONS | | | | | |
|--------------|------------|-----------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | | | | | |
| 3 | | | | | |
| 4 | | | | | |
| 5 | | | | | |
| 6 | BLK | 12-2-2 OPTION- | 18 AWG | GXL | S664 (2) |
| 7 | YEL | 10-6-1 OPTION+ | 18 AWG | GXL | S353 (2) |
| 8 | YEL | CAN-ONEHIGH | 18 AWG | GXL | MS16 (2) |
| 9 | GRN | CAN-ONE LOW | 18 AWG | GXL | MS16 (7) |
| 10 | | | | | |
| 11 | YEL | 10-6-2 OPTION+ | 18 AWG | GXL | S353 (2) |
| 12 | BLK | 12-3-2 DISPLAY- | 18 AWG | GXL | S664 (2) |

| X729 ANALYZER | | | | | |
|---------------|------------|----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 10-7 ANALYZER+ | 18 AWG | GXL | CO01-J2 (26) |
| 2 | WHT | 13-3 RECEIVE | 18 AWG | GXL | CO01-J2 (28) |
| 3 | WHT | 13-4 TRANSMIT | 18 AWG | GXL | CO01-J2 (29) |
| 4 | BLK | 12-6 ANALYZER- | 18 AWG | GXL | CO01-J2 (27) |

| S664 | | | | | |
|----------|------------|------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 12-3 PLAT VLV- | 18 AWG | GXL | CO01-J7 (29) |
| 2 | BLK | 12-3-1 PLAT VLV- | 18 AWG | GXL | X652 (1) |
| 2 | BLK | 12-3-2 DISPLAY | 18 AWG | GXL | X303 (12) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| C001-J7 BLACK | | | | | |
|---------------|------------|--------------------------|--------|--------|---------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 8-0 GND MODE/PLAT ENABLE | 18 AWG | GXL | X103 (11) |
| 2 | YEL | 5-0 | 18 AWG | GXL | SW715-2B (2B) |
| 3 | WHT | 9-0 PLAT MODE/GND ENABLE | 18 AWG | GXL | X103 (4) |
| 4 | YEL | 10-3 FOOT SW+ | 18 AWG | GXL | X305A (5) |
| 5 | WHT | 86-3 ROTATE LEFT | 18 AWG | GXL | X652 (13) |
| 6 | WHT | 87-3 ROTATE RIGHT | 18 AWG | GXL | X652 (14) |
| 7 | YEL | 10-10 SKYG/GEN+ | 18 AWG | GXL | S663 (1) |
| 8 | WHT | 7-2 FOOT SW N.C. | 18 AWG | GXL | X305A (4) |
| 9 | WHT | 508-1 GENERATOR SW INPUT | 18 AWG | GXL | X305A (1) |
| 10 | | | | | |
| 11 | WHT | 11-1 ANGLE SNSR 5V+ | 18 AWG | GXL | S356 (1) |
| 12 | | | | | |
| 13 | | | | | |
| 14 | BLK | 12-11 ANGLE SNSR- | 18 AWG | GXL | S355 (1) |
| 15 | WHT | 88-1 LEVEL UP | 18 AWG | GXL | S352 (1) |
| 16 | WHT | 89-1 LEVEL DOWN | 18 AWG | GXL | S654 (2) |
| 17 | | | | | |
| 18 | WHT | 503-1 SKYG INPUT 1 | 18 AWG | GXL | X5A (4) |
| 19 | WHT | 94-2 PLATALARM | 18 AWG | GXL | AH712+ (1) |
| 20 | BLK | 12-1 PLATALARM- | 18 AWG | GXL | AH712- (1) |
| 21 | BLK | 12-10 SKY GUARD- | 18 AWG | GXL | X5A (2) |
| 22 | BLU | 12-4 LSS- | 20 AWG | CABLE | X687 (3) |
| 23 | | | | | |
| 24 | | | | | |
| 25 | WHT | 82-3 JIB UP | 18 AWG | GXL | X652A (15) |
| 26 | WHT | 83-3 JIB DOWN | 18 AWG | GXL | X652A (16) |
| 27 | | | | | |
| 28 | | | | | |
| 29 | BLK | 12-3 PLAT VLV- | 18 AWG | GXL | S664 (1) |
| 30 | GRN | CAN-ONE LOW | 18 AWG | GXL | MS16 (4) |
| 31 | YEL | CAN-ONEHIGH | 18 AWG | GXL | MS16 (3) |
| 32 | | | | | |
| 33 | | | | | |
| 34 | BLK | 12-2 OPTION- | 18AWG | GXL | X303 (6) |
| 35 | | | | | |

| C001-J1 NATURAL | | | | | |
|-----------------|------------|-------------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | | | | | |
| 3 | | | | | |
| 4 | | | | | |
| 5 | WHT | 78-2 TELE IN | 18 AWG | GXL | SW707 (3) |
| 6 | WHT | 79-2 TELE OUT | 18 AWG | GXL | SW707 (1) |
| 7 | WHT | 87-2 ROTATE RIGHT | 18 AWG | GXL | SW708 (3) |
| 8 | WHT | 86-2 ROTATE LEFT | 18 AWG | GXL | SW708 (1) |
| 9 | WHT | 88-2 LEVEL UP | 18 AWG | GXL | SW709 (3) |
| 10 | WHT | 89-2 LEVEL DOWN | 18 AWG | GXL | SW709 (1) |
| 11 | WHT | 82-2 JIB UP | 18 AWG | GXL | SW718 (3) |
| 12 | WHT | 83-2 JIB DOWN | 18 AWG | GXL | SW718 (1) |
| 13 | BLK | 12-0 FUNCTION SPD- | 18 AWG | GXL | SW731 (5) |
| 14 | WHT | 100-2 START SWITCH | 18 AWG | GXL | SW710 (3) |
| 15 | WHT | 93-2 AUX POWER | 18 AWG | GXL | SW710 (1) |
| 16 | WHT | 17-1 CRAB STEER | 18 AWG | GXL | SW751 (3) |
| 17 | WHT | 17-0 COORD STEER | 18 AWG | GXL | SW751 (1) |
| 18 | YEL | 10-0 PLAT CNTRL + | 18 AWG | GXL | SW724 (2) |
| 19 | WHT | 54-5 FULL EXTENTION | 18 AWG | GXL | SW733 (1) |
| 20 | WHT | 504-1 SOFT TOUCH | 18 AWG | GXL | S12 (1) |
| 21 | WHT | 54-2 CAPACITY | 18 AWG | GXL | SW733 (3) |
| 22 | | | | | |
| 23 | WHT | 503-2 SKYG INPUT 2 | 18 AWG | GXL | X5A (5) |
| 24 | | | | | |
| 25 | WHT | 58-1 PLATANGLE 1 | 18 AWG | GXL | X652 (8) |
| 26 | WHT | 58-0 PLATANGLE 2 | 18 AWG | GXL | X652 (9) |
| 27 | WHT | 24-2 TWO SPEED | 18 AWG | GXL | SW724 (1) |
| 28 | WHT | 25-1 MAX TORQUE | 18 AWG | GXL | SW724 (3) |
| 29 | WHT | 504-0 SOFT/SKYG OVRIDE | 18 AWG | GXL | SW719-1 (1) |
| 30 | WHT | 500-3 HEAD LIGHTS | 18 AWG | GXL | SW726-1 (1) |
| 31 | WHT | 30-0 HORN | 18 AWG | GXL | SW711-1 (1) |
| 32 | WHT | 29-0 CREEP SW | 18 AWG | GXL | SW731 (2) |
| 33 | WHT | 107-0 FUEL SELECT | 18 AWG | GXL | SW727 (3) |
| 34 | WHT | 11-0 FUNCTION SPD 7V+ | 18 AWG | GXL | SW731 (4) |
| 35 | WHT | 69-0 FUNCTION SPD INPUT | 18 AWG | GXL | SW731 (6) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| C001-J2 BLUE | | | | | |
|--------------|------------|------------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | | | | | |
| 3 | YEL | 10-9 DISPLAY+ | 20 AWG | TXL | GD14 (3) |
| 4 | WHT | 51-2 DRV ORENTION SW | 18 AWG | GXL | SW728 (1) |
| 5 | | | | | |
| 6 | | | | | |
| 7 | | | | | |
| 8 | | | | | |
| 9 | | | | | |
| 10 | | | | | |
| 11 | | | | | |
| 12 | | | | | |
| 13 | | | | | |
| 14 | | | | | |
| 15 | | | | | |
| 16 | WHT | 504-2 SOFT TCH/SKYG LT | 18 AWG | GXL | LB732+ (1) |
| 17 | | | | | |
| 18 | BLK | 12-8 DISPLAY- | 20 AWG | TXL | GD14 (6) |
| 19 | | | | | |
| 20 | | | | | |
| 21 | | | | | |
| 22 | | | | | |
| 23 | | | | | |
| 24 | | | | | |
| 25 | BLK | 12-7 SKYG LT- | 18 AWG | GXL | LB732- (1) |
| 26 | YEL | 10-7 ANALYZER+ | 18 AWG | GXL | X729 (1) |
| 27 | BLK | 12-6 ANALYZER- | 18 AWG | GXL | X729 (4) |
| 28 | WHT | 13-3 RECEIVE | 18 AWG | GXL | X729 (2) |
| 29 | WHT | 13-4 TRANSMIT | 18 AWG | GXL | X729 (3) |
| 30 | | | | | |
| 31 | | | | | |
| 32 | YEL | 10-2 LSS+ | 20 AWG | CABLE | X687 (2) |
| 33 | YEL | 10-6 OPTION+ | 18 AWG | GXL | S353 (1) |
| 34 | YEL | 10-8 SOFT TOUCH+ | 18 AWG | GXL | S360 (1) |
| 35 | | | | | |

| AH712- ALARM | | | | | |
|--------------|------------|-----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 12-1 PLATALARM- | 18 AWG | GXL | C001-J7 (20) |

| C001-J8 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-7 | 12 AWG | GXL | X103 (16) |
| 2 | YEL | 2-7 | 12 AWG | GXL | X103 (12) |




Figure 7-24. Platform Box Harness - Sheet 4 of 6

1001238409-E
MAF22050E

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| SW709 LEVEL | | | | | |
|-------------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 89-2 LEVEL DOWN | 18 AWG | GXL | CO01-J1 (10) |
| 2 | YEL | 10-0-7 PLAT CNTRL + | 18 AWG | GXL | SW710 (2) |
| 2 | YEL | 10-0-8 PLAT CNTRL + | 18 AWG | GXL | SW708 (2) |
| 3 | WHT | 88-2 LEVEL UP | 18 AWG | GXL | CO01-J1 (9) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW708 PLATFORM ROTATE | | | | | |
|-----------------------|------------|---------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 86-2 ROTATE LEFT | 18 AWG | GXL | CO01-J1 (8) |
| 2 | YEL | 10-0-8 PLAT CNTRL + | 18 AWG | GXL | SW709 (2) |
| 2 | YEL | 10-0-9 PLAT CNTRL + | 18 AWG | GXL | SW733 (2) |
| 3 | WHT | 87-2 ROTATE RIGHT | 18 AWG | GXL | CO01-J1 (7) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW724 ENGINE SPEED | | | | | |
|--------------------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 24-2 TWO SPEED | 18 AWG | GXL | CO01-J1 (27) |
| 2 | YEL | 10-0 PLAT CNTRL + | 18 AWG | GXL | CO01-J1 (18) |
| 2 | YEL | 10-0-1 PLAT CNTRL + | 18 AWG | GXL | SW751 (2) |
| 3 | WHT | 25-1 MAX TORQUE | 18 AWG | GXL | CO01-J1 (28) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW731 PUMP POT | | | | | |
|----------------|------------|-------------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | WHT | 29-0 CREEP SW | 18 AWG | GXL | CO01-J1 (32) |
| 3 | YEL | 10-0-11 PLAT CNTRL + | 18 AWG | GXL | SW707 (2) |
| 3 | YEL | 10-0-12 PLAT CNTRL + | 18 AWG | GXL | SW711-2 (1) |
| 4 | WHT | 11-0 FUNCTION SPD 7V+ | 18 AWG | GXL | CO01-J1 (34) |
| 5 | BLK | 12-0 FUNCTION SPD - | 18 AWG | GXL | CO01-J1 (13) |
| 6 | WHT | 69-0 FUNCTION SPD INPUT | 18 AWG | GXL | CO01-J1 (35) |

| SW751 STEER SELECT | | | | | |
|--------------------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 17-0 COORD STEER | 18 AWG | GXL | CO01-J1 (17) |
| 2 | YEL | 10-0-1 PLAT CNTRL + | 18 AWG | GXL | SW724 (2) |
| 2 | YEL | 10-0-2 PLAT CNTRL + | 18 AWG | GXL | SW727 (2) |
| 3 | WHT | 17-1 CRAB STEER | 18 AWG | GXL | CO01-J1 (16) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW711-2 HORN | | | | | |
|--------------|------------|----------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 10-0-12 PLAT CNTRL + | 18 AWG | GXL | SW731 (3) |
| 1 | YEL | 10-0-13 PLAT CNTRL + | 18 AWG | GXL | SW719-2 (1) |

| SW727 FUEL SELECT | | | | | |
|-------------------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | YEL | 10-0-2 PLAT CNTRL + | 18 AWG | GXL | SW751 (2) |
| 2 | YEL | 10-0-3 PLAT CNTRL + | 18 AWG | GXL | SW726-2 (1) |
| 3 | WHT | 107-0 FUEL SELECT | 18 AWG | GXL | CO01-J1 (33) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW719-1 SOFT TCH/SKYG OVRD | | | | | |
|----------------------------|------------|------------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 504-0 SOFT/SKYG OVRIDE | 18 AWG | GXL | CO01-J1 (29) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| SW719-2 SOFT TCH/SKYG OVRD | | | | | |
|----------------------------|------------|----------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 10-0-13 PLAT CNTRL + | 18 AWG | GXL | SW711-2 (1) |

| SW711-1 HORN | | | | | |
|--------------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 30-0 HORN | 18 AWG | GXL | C001-J1 (31) |

Go to Discount-Equipment.com to order your parts




Figure 7-25. Platform Box Harness - Sheet 5 of 6

1001238409-E
MAF22070E

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| SW715-2B EMS | | | | | |
|--------------|------------|------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 2B | YEL | 5-0 | 18 AWG | GXL | C001-J7 (2) |

| LB732- SOFT TCH/SKYG WARN | | | | | |
|------------------------------|------------|---------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 12-7 SKYG LT- | 18 AWG | GXL | C001-J2 (25) |

| GD14 LED DISPLAY | | | | | |
|------------------|------------|---------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | CAN-ONEHIGH | 20 AWG | TXL | MS16 (10) |
| 2 | | | | | |
| 3 | YEL | 10-9 DISPLAY+ | 20 AWG | TXL | C001-J2 (3) |
| 4 | GRN | CAN-ONE LOW | 20 AWG | TXL | MS16 (9) |
| 5 | | | | | |
| 6 | BLK | 12-8 DISPLAY- | 20 AWG | TXL | C001-J2 (18) |

| SW707 BOOM TELE | | | | | |
|-----------------|------------|----------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 79-2 TELE OUT | 18 AWG | GXL | C001-J1 (6) |
| 2 | YEL | 10-0-10 PLAT CNTRL + | 18 AWG | GXL | SW733 (2) |
| 2 | YEL | 10-0-11 PLAT CNTRL + | 18 AWG | GXL | SW731 (3) |
| 3 | WHT | 78-2 TELE IN | 18 AWG | GXL | C001-J1 (5) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW715-1B EMS | | | | | |
|--------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1B | YEL | 4-0 | 18 AWG | GXL | X103 (9) |

| SW726-1 HEAD&TAIL LT | | | | | |
|----------------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 500-3 HEAD LIGHTS | 18 AWG | GXL | C001-J1 (30) |

| SW718 JIB LIFT | | | | | |
|----------------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 83-2 JIB DOWN | 18 AWG | GXL | C001-J1 (12) |
| 2 | YEL | 10-0-4 PLAT CNTRL + | 18 AWG | GXL | SW726-2 (1) |
| 2 | YEL | 10-0-5 PLAT CNTRL + | 18 AWG | GXL | SW728 (2) |
| 3 | WHT | 82-2 JIB UP | 18 AWG | GXL | C001-J1 (11) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW726-2 HEAD&TAIL LT | | | | | |
|----------------------|------------|---------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 10-0-3 PLAT CNTRL + | 18 AWG | GXL | SW727 (2) |
| 1 | YEL | 10-0-4 PLAT CNTRL + | 18 AWG | GXL | SW718 (2) |

| LB732+ SOFT TCH/SKYG WARN | | | | | |
|---------------------------|------------|------------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 504-2 SOFT TCH/SKYG LT | 18 AWG | GXL | C001-J2 (16) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| SW710 START AUX | | | | | |
|-----------------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 93-2 AUX POWER | 18 AWG | GXL | C001-J1 (15) |
| 2 | YEL | 10-0-6 PLAT CNTRL + | 18 AWG | GXL | SW728 (2) |
| 2 | YEL | 10-0-7 PLAT CNTRL + | 18 AWG | GXL | SW709 (2) |
| 3 | WHT | 100-2 START SWITCH | 18 AWG | GXL | C001-J1 (14) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW728 DRIVE ORNT OVRIDE | | | | | |
|-------------------------|------------|----------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 51-2 DRV ORENTION SW | 18 AWG | GXL | C001-J2 (4) |
| 2 | YEL | 10-0-5 PLAT CNTRL + | 18 AWG | GXL | SW718 (2) |
| 2 | YEL | 10-0-6 PLAT CNTRL + | 18 AWG | GXL | SW710 (2) |
| 3 | | | | | |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW733 CAPACITY | | | | | |
|----------------|------------|----------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 54-5 FULL EXTENTION | 18 AWG | GXL | C001-J1 (19) |
| 2 | YEL | 10-0-10 PLAT CNTRL + | 18 AWG | GXL | SW707 (2) |
| 2 | YEL | 10-0-9 PLAT CNTRL + | 18 AWG | GXL | SW708 (2) |
| 3 | WHT | 54-2 CAPACITY | 18 AWG | GXL | C001-J1 (21) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

Go to DiscountEquipment.com to order your parts






Figure 7-26. Platform Box Harness - Sheet 6 of 6

1001238409-E
MAF22090E

BACK VIEW OF CONNECTOR
SAME FOR BOTH ENDS




6 CONTACTS SIZE #12
13 CONTACTS SIZE #16



1001188534.C
MAE20530

Figure 7-27. Main Boom Harness (With Jib)



1001206082-C
MAEZ0540

Go to Discount-Equipment.com to order your parts

Figure 7-28. Main Boom Harness (TT)





Figure 7-29. Proximity Switch Harness (Telescope In)

1001189003-D
MAE20550D

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X616B TELE RETRACTED PROX SNSR | | | | | |
|---------------------------------------|-------------------|-------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | ORN/BLK | CABLE CABLE | 18 AWG | TFFN | SN465 (1) |
| 2 | BLK/RED | CABLE CABLE | 18 AWG | TFFN | SN465 (3) |
| 3 | BLU/RED | CABLE CABLE | 18 AWG | TFFN | SN465 (2) |
| 4 | YEL/BLK | CABLE CABLE | 18 AWG | TFFN | SN625 (1) |
| 5 | BRN/BLK | CABLE CABLE | 18 AWG | TFFN | SN625 (3) |
| 6 | BLU/BLK | CABLE CABLE | 18 AWG | TFFN | SN625 (2) |

| SN625 TELE PROX RIGHT | | | | | |
|------------------------------|-------------------|-------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL/BLK | CABLE CABLE | 18 AWG | TFFN | X616B (4) |
| 2 | BLU/BLK | CABLE CABLE | 18 AWG | TFFN | X616B (6) |
| 3 | BRN/BLK | CABLE CABLE | 18 AWG | TFFN | X616B (5) |

| SN465 TELE PROX LEFT | | | | | |
|-----------------------------|-------------------|-------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | ORN/BLK | CABLE CABLE | 18 AWG | TFFN | X616B (1) |
| 2 | BLU/RED | CABLE CABLE | 18 AWG | TFFN | X616B (3) |
| 3 | BLK/RED | CABLE CABLE | 18 AWG | TFFN | X616B (2) |

Go to Discount-Equipment.com to order your parts




Figure 7-30. Boom Sensor Cable

1001238191-C
MAF21640C

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| SN571 CAPACITY LENGTH NC 2 | | | | | |
|----------------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 7 | 18 AWG | GXL | MS07 (4) |
| 2 | BLU-BLK | 114 | 18 AWG | TFFN | X615B (6) |
| 3 | BLK | 5 | 18 AWG | GXL | MS08 (4) |

| X09 TO FULL EXTENSION | | | | | |
|-----------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 4 | 18 AWG | GXL | MS07 (2) |
| 2 | ORG-BLK | 110 | 18 AWG | TFFN | X615B (4) |
| 3 | BLK | 2 | 18 AWG | GXL | MS08 (2) |
| 4 | YEL | 3 | 18 AWG | GXL | MS07 (1) |
| 5 | BLK-RED | 112 | 18 AWG | TFFN | X615B (5) |
| 6 | BLK | 1 | 18 AWG | GXL | MS08 (1) |

| SN467 CAPACITY LENGTH NO 1 | | | | | |
|----------------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 8 | 18 AWG | GXL | MS07 (5) |
| 2 | BLU-RED | 111 | 18 AWG | TFFN | X615B (3) |
| 3 | BLK | 6 | 18 AWG | GXL | MS08 (5) |

| X615B CAP LENGTH PROX SENSOR | | | | | |
|------------------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL-BLK | 113 | 18 AWG | TFFN | MS07 (3) |
| 2 | BRN-BLK | 115 | 18 AWG | TFFN | MS08 (3) |
| 3 | BLU-RED | 111 | 18 AWG | TFFN | SN467 (2) |
| 4 | ORG-BLK | 110 | 18 AWG | TFFN | X09 (2) |
| 5 | BLK-RED | 112 | 18 AWG | TFFN | X09 (5) |
| 6 | BLU-BLK | 114 | 18 AWG | TFFN | SN571 (2) |

| MS08 GND BUSS | | | | | |
|---------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 1 | 18 AWG | GXL | X09 (6) |
| 2 | BLK | 2 | 18 AWG | GXL | X09 (3) |
| 3 | BRN-BLK | 115 | 18 AWG | TFFN | X615B (2) |
| 4 | BLK | 5 | 18 AWG | GXL | SN571 (3) |
| 5 | BLK | 6 | 18 AWG | GXL | SN467 (3) |
| 6 | | | | | |

| MS07 PWR BUSS | | | | | |
|---------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 3 | 18 AWG | GXL | X09 (4) |
| 2 | YEL | 4 | 18 AWG | GXL | X09 (1) |
| 3 | YEL-BLK | 113 | 18 AWG | TFFN | X615B (1) |
| 4 | YEL | 7 | 18 AWG | GXL | SN571 (1) |
| 5 | YEL | 8 | 18 AWG | GXL | SN467 (1) |
| 6 | | | | | |





Figure 7-31. Turntable Harness - Sheet 1 of 7

1001238405-F
MAF28240F

| LB87 STROBE LIGHT | | | | | |
|--------------------------|-------------------|-------------------|--------------|---------------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 2-11 | 18 AWG | GXL | FC155 (A4) |
| 2 | BLK | 0-11 | 18 AWG | GXL | X127 (1) |

Go to Discount-Equipment.com to order your parts



1001238405-F
MAF28250F

Figure 7-32. Turntable Harness - Sheet 2 of 7

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| FC155 FUSE BOX | | | | | |
|----------------|------------|-----------------------------|--------|--------|---------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A1 | YEL | 2-5 | 12 AWG | GXL | C073-J8 (2) |
| A10 | | | | | |
| A2 | YEL | 2-7 | 12 AWG | GXL | X102 (12) |
| A3 | YEL | 2-9 | 18 AWG | GXL | X183A (1) |
| A4 | YEL | 2-11 | 18 AWG | GXL | LB87 (1) |
| A5 | YEL | 2-15 | 18 AWG | GXL | X113 (1) |
| A6 | YEL | 2-13 | 18 AWG | GXL | X105 (H) |
| A7 | YEL | 2-14 | 18 AWG | GXL | X117 (3) |
| A8 | | | | | |
| A9 | | | | | |
| B1 | RED | 1-2 | 12 AWG | GXL | S125 (2) |
| B10 | | | | | |
| B2 | WHT | 6-3 IGN PWR ENABLE | 18 AWG | GXL | S120 (1) |
| B3 | RED | 1-4 | 12 AWG | GXL | S124 (2) |
| B4 | WHT | 6-4 IGN PWR ENABLE | 18 AWG | GXL | S120 (1) |
| B5 | | | | | |
| B8 | | | | | |
| C10 | WHT | 9-0-1 PLAT MODE/ GND ENABLE | 18 AWG | GXL | S85 (2) |
| C2 | | | | | |
| C4 | | | | | |
| C5 | | | | | |
| C6 | YEL | 4-2 PLAT STAT | 18 AWG | GXL | X117 (4) |
| C7 | RED | 1-0 | 18 AWG | GXL | S136 (2) |
| C8 | RED | 1-5 | 18 AWG | GXL | S135 (2) |
| C9 | YEL | 3-0 | 18 AWG | GXL | SW83-1 (1) |
| D1 | BLK | 0-1-1 | 18 AWG | GXL | S123 (2) |
| D10 | WHT | 6-1 IGN PWR ENABLE | 18 AWG | GXL | S120 (2) |
| D2 | YEL | 2-2 | 12 AWG | GXL | FC155-L1 (L1) |
| D3 | BLK | 0-1-3 | 18 AWG | GXL | S123 (2) |
| D4 | YEL | 2-4 | 12 AWG | GXL | FC155-L1 (L1) |
| D5 | | | | | |
| D6 | YEL | 4-1 | 18 AWG | GXL | SW83-3 (1) |
| D7 | RED | 1-1 | 18 AWG | GXL | SW84-2A (2A) |
| D8 | RED | 1-7 | 18 AWG | GXL | S578 (1) |
| D9 | WHT | 6-0 IGN PWR ENABLE | 18 AWG | GXL | S120 (2) |

| FC155-L1 FUSE BLK IGN | | | | | |
|-----------------------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| L1 | YEL | 2-2 | 12 AWG | GXL | FC155 (D2) |
| L1 | YEL | 2-4 | 12 AWG | GXL | FC155 (D4) |

| S123 | | | | | |
|----------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-1 | 18 AWG | GXL | X129 (1) |
| 2 | BLK | 0-1-1 | 18 AWG | GXL | FC155 (D1) |
| 2 | BLK | 0-1-3 | 18 AWG | GXL | FC155 (D3) |

| MS279 PROX BUSS | | | | | |
|-----------------|------------|--------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-1-3 TELE PROX + | 18 AWG | GXL | X616A (4) |
| 2 | YEL | 14-1-1 TELE PROX + | 18 AWG | GXL | X616A (1) |
| 3 | | | | | |
| 4 | BLK | 16-1-3 TELE PROX - | 18 AWG | GXL | X616A (5) |
| 5 | BLK | 16-1-1 TELE PROX - | 18 AWG | GXL | X616A (2) |
| 6 | | | | | |
| 7 | | | | | |
| 8 | BLK | 16-1 TELE PROX - | 18 AWG | GXL | C073-J7 (28) |
| 9 | BLK | 16-1-2 TELE PROX - | 18 AWG | GXL | X615A (2) |
| 10 | | | | | |
| 11 | YEL | 14-1 TELE PROX + | 18 AWG | GXL | C073-J7 (33) |
| 12 | YEL | 14-1-2 TELE PROX + | 18 AWG | GXL | X615A (1) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| MS147 CAN CHANNEL 1 | | | | | |
|---------------------|------------|-------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | | | | | |
| 3 | YEL | CAN-ONEHIGH | 18 AWG | GXL | X102A (3) |
| 4 | GRN | CAN-ONE LOW | 18 AWG | GXL | X102A (2) |
| 5 | GRN | CAN-ONE LOW | 18 AWG | GXL | C073-J7 (24) |
| 6 | | | | | |
| 7 | GRN | CAN-ONE LOW | 18 AWG | GXL | SN476 (4) |
| 8 | GRN | CAN-ONE LOW | 20 AWG | TXL | GD174 (4) |
| 9 | | | | | |
| 10 | YEL | CAN-ONEHIGH | 18 AWG | GXL | C073-J7 (13) |
| 11 | YEL | CAN-ONEHIGH | 20 AWG | TXL | GD174 (1) |
| 12 | YEL | CAN-ONEHIGH | 18 AWG | GXL | SN476 (3) |

| S578 | | | | | |
|----------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 1-7 | 18 AWG | GXL | FC155 (D8) |
| 2 | RED | 1-6 | 18 AWG | GXL | X105 (B) |
| 2 | RED | 1-7 | 18 AWG | GXL | X117 (1) |

| MS309 CAN CHANNEL 2 | | | | | |
|---------------------|------------|--------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | GRN | CAN-TWO LOW | 18 AWG | GXL | GD169 (4) |
| 3 | GRN | CAN-TWO LOW | 18 AWG | GXL | C073-J12 (4) |
| 4 | YEL | CAN-TWO HIGH | 18 AWG | GXL | GD169 (3) |
| 5 | YEL | CAN-TWO HIGH | 18 AWG | GXL | C073-J12 (3) |
| 6 | | | | | |
| 7 | | | | | |
| 8 | YEL | CAN-TWO HIGH | 18 AWG | GXL | X183A (3) |
| 9 | YEL | CAN-TWO HIGH | 18 AWG | GXL | X105 (C) |
| 10 | | | | | |
| 11 | GRN | CAN-TWO LOW | 18 AWG | GXL | X183A (4) |
| 12 | GRN | CAN-TWO LOW | 18 AWG | GXL | X105 (D) |

| C073-J12 UGM-J12 | | | | | |
|------------------|------------|------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | | | | | |
| 3 | YEL | CAN-TWO HIGH | 18 AWG | GXL | MS309 (5) |
| 4 | GRN | CAN-TWO LOW | 18 AWG | GXL | MS309 (3) |
| 5 | | | | | |
| 6 | WHT | 4-96 CAN2 TERM | 18 AWG | GXL | C073-J12 (7) |
| 7 | WHT | 4-96 CAN2 TERM | 18 AWG | GXL | C073-J12 (6) |
| 8 | WHT | 507-0 MSSO INPUT | 18 AWG | GXL | SW114-1 (1) |

| C073-J8 UGM J8 | | | | | |
|----------------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-5 | 12 AWG | GXL | X131 (1) |
| 2 | YEL | 2-5 | 12 AWG | GXL | FC155 (A1) |
| 3 | | | | | |
| 4 | | | | | |


| S120 | | | | | |
|----------|------------|--------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 6-3 IGN PWR ENABLE | 18 AWG | GXL | FC155 (B2) |
| 2 | WHT | 6-4 IGN PWR ENABLE | 18 AWG | GXL | FC155 (B4) |
| 3 | WHT | 6-0 IGN PWR ENABLE | 18 AWG | GXL | FC155 (D9) |
| 4 | WHT | 6-1 IGN PWR ENABLE | 18 AWG | GXL | FC155 (D10) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| C073-J7 UGM J7 | | | | | |
|----------------|------------|-----------------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 9-0-2 PLAT MODE/ GND ENABLE | 18 AWG | GXL | S85 (1) |
| 2 | WHT | 9-0-3 PLAT MODE/ GND ENABLE | 18 AWG | GXL | S85 (1) |
| 3 | YEL | 3-1 | 18 AWG | GXL | SW83-1 (1) |
| 4 | WHT | 60-0 ANGLE SNSR 1 | 18 AWG | GXL | X743 (3) |
| 5 | | | | | |
| 6 | WHT | 4-133 CAN1 TERM | 18 AWG | GXL | C073-J7 (17) |
| 7 | WHT | 60-1 ANGLE SNSR 2 | 18 AWG | GXL | X743 (4) |
| 8 | | | | | |
| 9 | BLK | 16-0 ANGLE SNSR- | 18 AWG | GXL | X743 (1) |
| 10 | BLK | 16-13TILT - | 18 AWG | GXL | SN476 (2) |
| 11 | | | | | |
| 12 | | | | | |
| 13 | YEL | CAN-ONEHIGH | 18 AWG | GXL | MS147 (10) |
| 14 | WHT | 8-0 GND MODE/PLAT ENABLE | 18 AWG | GXL | X102 (11) |
| 15 | WHT | 7-0 FOOT SW INPUT | 18 AWG | GXL | X102 (6) |
| 16 | WHT | 15-0 ANGLE SNSR 5V+ | 18 AWG | GXL | X743 (2) |
| 17 | WHT | 4-133 CAN1 TERM | 18 AWG | GXL | C073-J7 (6) |
| 18 | | | | | |
| 19 | | | | | |
| 20 | | | | | |
| 21 | WHT | 53-1 NO TRANSPORT LNTH | 18 AWG | GXL | X616 (3) |
| 22 | WHT | 108-1 WIF | 18 AWG | GXL | X181A (8) |
| 23 | WHT | 54-0 NO CAPACITY LNTH | 18 AWG | GXL | X615 (3) |
| 24 | GRN | CAN-ONELOW | 18 AWG | GXL | MS147 (5) |
| 25 | BLK | 16-5 DISPLAY - | 18 AWG | GXL | S148 (1) |
| 26 | | | | | |
| 27 | | | | | |
| 28 | BLK | 16-1 TELE PROX - | 18 AWG | GXL | MS279 (5) |
| 29 | YEL | 14-4 DISPLAY + | 18 AWG | GXL | S153 (1) |
| 30 | YEL | 14-8-3 WIF + | 18 AWG | GXL | X181A (7) |
| 31 | YEL | 14-11 SERVICE CABLE+ | 18 AWG | GXL | X171 (4) |
| 32 | YEL | 14-6 DOS + | 18 AWG | GXL | X112 (1) |
| 33 | YEL | 14-1 TELE PROX + | 18 AWG | GXL | MS279 (7) |
| 34 | YEL | 14-7TILT + | 18 AWG | GXL | SN476 (1) |
| 35 | WHT | 51-0 DOS SW | 18 AWG | GXL | X112 (2) |

| X102 BOOM CABLE CONNECTION | | | | | |
|-------------------------------|------------|----------------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | GRN | CAN-ONE LOW | 18 AWG | GXL | MS147 (4) |
| 3 | YEL | CAN-ONEHIGH | 18 AWG | GXL | MS147 (3) |
| 4 | WHT | 9-0 PLAT MODE / GND ENABLE | 18 AWG | GXL | S85 (2) |
| 5 | WHT | 88-1-1 LEVEL UP | 18 AWG | GXL | X701A (3) |
| 6 | WHT | 7-0 FOOT SW INPUT | 18 AWG | GXL | C073-J7 (15) |
| 7 | WHT | 89-1-1 LEVEL DOWN | 18 AWG | GXL | X701A (4) |
| 8 | | | | | |
| 9 | YEL | 4-0 | 18 AWG | GXL | SW83-1 (1) |
| 10 | | | | | |
| 11 | WHT | 8-0 GND MODE/PLAT ENABLE | 18 AWG | GXL | C073-J7 (14) |
| 12 | YEL | 2-7 | 12 AWG | GXL | FC155 (A2) |
| 13 | WHT | 90-1 HI PRS DUMP | 18 AWG | GXL | X701A (1) |
| 14 | | | | | |
| 15 | WHT | 90-2 LOW PRS DUMP | 18 AWG | GXL | X701A (2) |
| 16 | BLK | 0-7 | 12 AWG | GXL | X133 (1) |
| 17 | | | | | |
| 18 | | | | | |
| 19 | | | | | |

| X105 JLG DIAGNOSTIC | | | | | |
|------------------------|------------|--------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | BLK | 0-13 | 18 AWG | GXL | X127 (1) |
| B | RED | 1-6 | 18 AWG | GXL | S578 (2) |
| C | YEL | CAN-TWO HIGH | 18 AWG | GXL | MS309 (9) |
| D | GRN | CAN-TWO LOW | 18 AWG | GXL | MS309 (12) |
| E | | | | | |
| F | | | | | |
| G | | | | | |
| H | YEL | 2-13 | 18 AWG | GXL | FC155 (A6) |
| J | | | | | |



1001238405-F
MAF28260F

Figure 7-33. Turntable Harness - Sheet 3 of 7

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| S153 | | | | | |
|----------|------------|------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-4 DISPLAY + | 18 AWG | GXL | C073-J7 (29) |
| 2 | YEL | 14-4-1 DISPLAY + | 18 AWG | GXL | GD169 (2) |
| 2 | YEL | 14-4-2 DISPLAY + | 20 AWG | TXL | GD174 (3) |
| 2 | YEL | 14-4-3 DISPLAY + | 20 AWG | TXL | GD174 (2) |

| S148 | | | | | |
|----------|------------|------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 16-5 DISPLAY - | 18 AWG | GXL | C073-J7 (25) |
| 2 | BLK | 16-5-1 DISPLAY - | 18 AWG | GXL | GD169 (1) |
| 2 | BLK | 16-5-2 DISPLAY - | 20 AWG | TXL | GD174 (6) |

| X86 ANALYZER | | | | | |
|--------------|------------|-----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-2 ANALYZER + | 18 AWG | GXL | C073-J1 (28) |
| 2 | WHT | 13-1 RECEIVE | 18 AWG | GXL | C073-J1 (29) |
| 3 | WHT | 13-2 TRANSMIT | 18 AWG | GXL | C073-J1 (30) |
| 4 | BLK | 16-4 ANALYZER - | 18 AWG | GXL | C073-J1 (31) |

| SW84-1A E-STOP | | | | | |
|----------------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1A | YEL | 2-0 | 18 AWG | GXL | SW83-B (1) |

| SW83-3 PLAT MODE | | | | | |
|------------------|------------|------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 3-0 | 18 AWG | GXL | FC155 (C9) |
| 1 | YEL | 3-1 | 18 AWG | GXL | C073-J7 (3) |

| SW83-B KEY SW B+ | | | | | |
|------------------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 2-0 | 18 AWG | GXL | SW84-1A (1A) |

| GD174 | | | | | |
|----------|------------|------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | CAN-ONE HIGH | 20 AWG | TXL | MS147 (11) |
| 2 | YEL | 14-4-3 DISPLAY + | 20 AWG | TXL | S153 (2) |
| 3 | YEL | 14-4-2 DISPLAY + | 20 AWG | TXL | S153 (2) |
| 4 | GRN | CAN-ONE LOW | 20 AWG | TXL | MS147 (8) |
| 5 | | | | | |
| 6 | BLK | 16-5-2 DISPLAY - | 20 AWG | TXL | S148 (2) |

| SW84-2A E-STOP | | | | | |
|----------------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 2A | RED | 1-1 | 18 AWG | GXL | FC155 (D7) |

| SW114-2 MSSO | | | | | |
|--------------|------------|-------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 16-3 MSSO - | 18 AWG | GXL | C073-J1 (9) |

| SW114-1 MSSO | | | | | |
|--------------|------------|------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 507-0 MSSO INPUT | 18 AWG | GXL | C073-J12 (8) |

| GD169 KONGSBERG DISPLAY | | | | | |
|-------------------------|------------|------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 16-5-1 DISPLAY - | 18 AWG | GXL | S148 (2) |
| 2 | YEL | 14-4-1 DISPLAY + | 18 AWG | GXL | S153 (2) |
| 3 | YEL | CAN-TWO HIGH | 18 AWG | GXL | MS309 (4) |
| 4 | GRN | CAN-TWO LOW | 18 AWG | GXL | MS309 (2) |
| 5 | | | | | |
| 6 | | | | | |

| SW83-1 GROUND MODE | | | | | |
|--------------------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 4-0 | 18 AWG | GXL | X102A (9) |
| 1 | YEL | 4-1 | 18 AWG | GXL | FC155 (D6) |




Figure 7-34. Turntable Harness - Sheet 4 of 7

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| C073-J1 UGM J1 | | | | | |
|----------------|------------|------------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | WHT | 40-2 OSCAXL VLV 2 | 18 AWG | GXL | HV161 (1) |
| 3 | WHT | 27-1 DRIVE FORWARD | 18 AWG | GXL | HV159 (1) |
| 4 | | | | | |
| 5 | BLK | 16-2 BRK/2SPD VLV - | 18 AWG | GXL | S80 (2) |
| 6 | WHT | 28-1 DRIVE REVERSE | 18 AWG | GXL | HV160 (1) |
| 7 | WHT | 40-1 OSCAXL VLV 1 | 18 AWG | GXL | HV162 (1) |
| 8 | | | | | |
| 9 | BLK | 16-3 MSSO - | 18 AWG | GXL | SW114-2 (1) |
| 10 | WHT | 103-0 DELAYED ECU PWR | 18 AWG | GXL | X181A (1) |
| 11 | WHT | 100-1 START | 16 AWG | GXL | X183A (2) |
| 12 | WHT | 102-0 GLOW PLUG | 16 AWG | GXL | X181A (4) |
| 13 | WHT | 93-1 AUX PUMP | 18 AWG | GXL | X106 (1) |
| 14 | | | | | |
| 15 | | | | | |
| 16 | | | | | |
| 17 | | | | | |
| 18 | | | | | |
| 19 | | | | | |
| 20 | WHT | 24-1 TWO SPD | 18 AWG | GXL | HV78 (1) |
| 21 | WHT | 54-6 NC CAPACITY LNTH | 18 AWG | GXL | X615 (5) |
| 22 | WHT | 508-0 GEN ENABLE | 18 AWG | GXL | X113 (2) |
| 23 | WHT | 23-1 BRAKE | 18 AWG | GXL | HV79 (1) |
| 24 | | | | | |
| 25 | | | | | |
| 26 | | | | | |
| 27 | | | | | |
| 28 | YEL | 14-2 ANALYZER + | 18 AWG | GXL | X86 (1) |
| 29 | WHT | 13-1 RECEIVE | 18 AWG | GXL | X86 (2) |
| 30 | WHT | 13-2 TRANSMIT | 18 AWG | GXL | X86 (3) |
| 31 | BLK | 16-4 ANALYZER - | 18 AWG | GXL | X86 (4) |
| 32 | WHT | 101-0 ALT EXCITE | 16 AWG | GXL | X183A (5) |
| 33 | | | | | |
| 34 | WHT | 53-0 NC TRANSPORT LNTH | 18 AWG | GXL | X616A (6) |
| 35 | WHT | 54-1 NC CAPACITY LNTH | 18 AWG | GXL | X615A (6) |

| X701A TO MAIN VALVE HARN | | | | | |
|-----------------------------|------------|-------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 90-1 HI PRS DUMP | 18 AWG | GXL | X102A (13) |
| 2 | WHT | 90-2 LOW PRS DUMP | 18 AWG | GXL | X102A (15) |
| 3 | WHT | 88-1-1 LEVEL UP | 18 AWG | GXL | X102A (5) |
| 4 | WHT | 89-1-1 LEVEL DOWN | 18 AWG | GXL | X102A (7) |

| S85 | | | | | |
|----------|------------|-----------------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 9-0-2 PLAT MODE/ GND ENABLE | 18 AWG | GXL | C073-J7 (1) |
| 1 | WHT | 9-0-3 PLAT MODE/ GND ENABLE | 18 AWG | GXL | C073-J7 (2) |
| 2 | WHT | 9-0 PLAT MODE/ GND ENABLE | 18 AWG | GXL | X102A (4) |
| 2 | WHT | 9-0-1 PLAT MODE/ GND ENABLE | 18 AWG | GXL | FC155 (C10) |

| X130 GROUND STUD | | | | | |
|------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-15 | 18 AWG | GXL | X113 (3) |
| 1 | BLK | 0-9 | 18 AWG | GXL | X181A (2) |

| X117 UNI TELEM | | | | | |
|----------------|------------|---------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 1-7 | 18 AWG | GXL | S578 (2) |
| 2 | BLK | 0-2 | 18 AWG | GXL | X128 (1) |
| 3 | YEL | 2-14 | 18 AWG | GXL | FC155 (A7) |
| 4 | YEL | 4-2 PLAT STAT | 18 AWG | GXL | FC155 (C6) |

| X129 GROUND STUD | | | | | |
|------------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-1 | 18 AWG | GXL | S123 (1) |

| X132 GROUND STUD | | | | | |
|------------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-40 | 18 AWG | GXL | S164 (2) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X127 GROUND STUD | | | | | |
|------------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-11 | 18 AWG | GXL | LB87 (2) |
| 1 | BLK | 0-13 | 18 AWG | GXL | X105 (A) |

| X133 GROUND STUD | | | | | |
|------------------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-7 | 12 AWG | GXL | X102A (16) |

| X131 GROUND STUD | | | | | |
|------------------|------------|------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-5 | 12 AWG | GXL | C073-J8 (1) |


| X128 GROUND STUD | | | | | |
|------------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-2 | 18 AWG | GXL | X117 (2) |

| X743A MAIN BOOM ANGLE SENSOR | | | | | |
|------------------------------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 16-0 ANGLE SNSR- | 18 AWG | GXL | C073-J7 (9) |
| 2 | WHT | 15-0 ANGLE SNSR 5V+ | 18 AWG | GXL | C073-J7 (16) |
| 3 | WHT | 60-0 ANGLE SNSR 1 | 18 AWG | GXL | C073-J7 (4) |
| 4 | WHT | 60-1 ANGLE SNSR 2 | 18 AWG | GXL | C073-J7 (7) |

| X171 MAIN VALVE INTERFACE | | | | | |
|------------------------------|------------|-----------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 50-1 DRV RTN | 18 AWG | GXL | S163 (2) |
| 2 | | | | | |
| 3 | | | | | |
| 4 | YEL | 14-11 SERVICE CABLE+ | 18 AWG | GXL | C073-J7 (31) |
| 5 | WHT | 54-7 NO CAPACITY LNTH | 18 AWG | GXL | X615A (4) |
| 6 | | | | | |

| X616 TELESCOPE RETRACTED PROXIMITY SENSOR | | | | | |
|--|------------|------------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-1-1 TELE PROX + | 18 AWG | GXL | MS279 (2) |
| 2 | BLK | 16-1-1 TELE PROX - | 18 AWG | GXL | MS279 (5) |
| 3 | WHT | 53-1 NO TRANSPORT LNTH | 18 AWG | GXL | C073-J7 (21) |
| 4 | YEL | 14-1-3 TELE PROX + | 18 AWG | GXL | MS279 (1) |
| 5 | BLK | 16-1-3 TELE PROX - | 18 AWG | GXL | MS279 (3) |
| 6 | WHT | 53-0 NC TRANSPORT LNTH | 18 AWG | GXL | C073-J1 (34) |

| X615 DUAL/TRI CAP LENGTH | | | | | |
|--------------------------|------------|-----------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-1-2 TELE PROX + | 18 AWG | GXL | MS279 (12) |
| 2 | BLK | 16-1-2 TELE PROX - | 18 AWG | GXL | MS279 (9) |
| 3 | WHT | 54-0 NO CAPACITY LNTH | 18 AWG | GXL | C073-J7 (23) |
| 4 | WHT | 54-7 NO CAPACITY LNTH | 18 AWG | GXL | X171 (5) |
| 5 | WHT | 54-6 NC CAPACITY LNTH | 18 AWG | GXL | C073-J1 (21) |
| 6 | WHT | 54-1 NC CAPACITY LNTH | 18 AWG | GXL | C073-J1 (35) |



1001238405-F
MAF28280F

Figure 7-35. Turntable Harness - Sheet 5 of 7

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| SN476 TILT SENSOR | | | | | |
|-------------------|------------|--------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-7 TILT + | 18 AWG | GXL | C073-J7 (34) |
| 2 | BLK | 16-13 TILT - | 18 AWG | GXL | C073-J7 (10) |
| 3 | YEL | CAN-ONEHIGH | 18 AWG | GXL | MS147 (12) |
| 4 | GRN | CAN-ONE LOW | 18 AWG | GXL | MS147 (7) |

| X112 DRIVE ORNT | | | | | |
|-----------------|------------|-------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-6 DOS + | 18 AWG | GXL | C073-J7 (32) |
| 2 | WHT | 51-0 DOS SW | 18 AWG | GXL | C073-J7 (35) |

| X113 GENERATOR CONNECTOR | | | | | |
|--------------------------|------------|------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 2-15 | 18 AWG | GXL | FC155 (A5) |
| 2 | WHT | 508-0 GEN ENABLE | 18 AWG | GXL | C073-J1 (22) |
| 3 | BLK | 0-15 | 18 AWG | GXL | X130 (1) |

| S164 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-40-1 | 18 AWG | GXL | HV161 (2) |
| 1 | BLK | 0-40-2 | 18 AWG | GXL | HV162 (2) |
| 2 | BLK | 0-40 | 18 AWG | GXL | X132 (1) |

| S80 | | | | | |
|----------|------------|-----------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 16-2-1 BRK/2SPD VLV - | 18 AWG | GXL | HV79 (2) |
| 1 | BLK | 16-2-2 BRK/2SPD VLV - | 18 AWG | GXL | HV78 (2) |
| 2 | BLK | 16-2 BRK/2SPD VLV - | 18 AWG | GXL | C073-J1 (5) |

| HV78 2 SPEED | | | | | |
|-----------------|------------|-----------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 24-1 TWO SPD | 18 AWG | GXL | C073-J1 (20) |
| 2 | BLK | 16-2-2 BRK/2SPD VLV - | 18 AWG | GXL | S80 (1) |

| HV79 BRAKE | | | | | |
|------------|------------|-----------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 23-1 BRAKE | 18 AWG | GXL | C073-J1 (23) |
| 2 | BLK | 16-2-1 BRK/2SPD VLV - | 18 AWG | GXL | S80 (1) |

| HV161 OSC AXLE #2 | | | | | |
|-------------------|------------|-------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 40-2 OSCAXL VLV 2 | 18 AWG | GXL | C073-J1 (2) |
| 2 | BLK | 0-40-1 | 18 AWG | GXL | S164 (1) |

| HV162 OSC AXLE #1 | | | | | |
|-------------------|------------|-------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 40-1 OSCAXL VLV 1 | 18 AWG | GXL | C073-J1 (7) |
| 2 | BLK | 0-40-2 | 18 AWG | GXL | S164 (1) |

| X119 SYSTEM B+ | | | | | |
|----------------|------------|------------|--------|--------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | 03 | 20 AWG | FUSIBLE LINK | S136 (1) |
| 1 | | 04 | 20 AWG | FUSIBLE LINK | S135 (1) |

| X106 AUX PUMP COIL | | | | | |
|-----------------------|------------|---------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 93-1 AUX PUMP | 18 AWG | GXL | C073-J1 (13) |

| X88 SYSTEM B+ | | | | | |
|---------------|------------|------------|--------|--------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | 01 | 16 AWG | FUSIBLE LINK | S125 (1) |
| 1 | | 02 | 16 AWG | FUSIBLE LINK | S124 (1) |

| S124 | | | | | |
|----------|------------|------------|--------|--------------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | 02 | 16 AWG | FUSIBLE LINK | X88 (1) |
| 2 | RED | 1-4 | 12 AWG | GXL | FC155 (B3) |


SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| S125 | | | | | |
|----------|------------|------------|--------|--------------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | 01 | 16 AWG | FUSIBLE LINK | X88 (1) |
| 2 | RED | 1-2 | 12 AWG | GXL | FC155 (B1) |

| S135 | | | | | |
|----------|------------|------------|--------|--------------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | 04 | 20 AWG | FUSIBLE LINK | X119 (1) |
| 2 | RED | 1-5 | 18 AWG | GXL | FC155 (C8) |

| S136 | | | | | |
|----------|------------|------------|--------|--------------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | 03 | 20 AWG | FUSIBLE LINK | X119 (1) |
| 2 | RED | 1-0 | 18 AWG | GXL | FC155 (C7) |

Go to Discount-Equipment.com to order your parts



Go to Discount-Equipment.com to order your parts

1001238405-F
MAF28290F

Figure 7-36. Turntable Harness - Sheet 6 of 7

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| HV160 DRIVE REVERSE | | | | | |
|---------------------|------------|--------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 28-1 DRIVE REVERSE | 18 AWG | GXL | C073-J1 (6) |
| 2 | WHT | 50-1-1 DRV RTN | 18 AWG | GXL | S163 (1) |

| HV159 DRIVE FORWARD | | | | | |
|---------------------|------------|--------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 27-1 DRIVE FORWARD | 18 AWG | GXL | C073-J1 (3) |
| 2 | WHT | 50-1-2 DRV RTN | 18 AWG | GXL | S163 (1) |

| X181A ENGINE CONNETOR | | | | | |
|-----------------------|------------|-----------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 103-0 DELAYED ECU PWR | 18 AWG | GXL | C073-J1 (10) |
| 2 | BLK | 0-9 | 18 AWG | GXL | X130 (1) |
| 3 | | | | | |
| 4 | WHT | 102-0 GLOW PLUG | 16 AWG | GXL | C073-J1 (12) |
| 5 | | | | | |
| 6 | | | | | |
| 7 | YEL | 14-8-3 WIF + | 18 AWG | GXL | C073-J7 (30) |
| 8 | WHT | 108-1 WIF | 18 AWG | GXL | C073-J7 (22) |

| S163 | | | | | |
|----------|------------|----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 50-1-1 DRV RTN | 18 AWG | GXL | HV160 (2) |
| 1 | WHT | 50-1-2 DRV RTN | 18 AWG | GXL | HV159 (2) |
| 2 | WHT | 50-1 DRV RTN | 18 AWG | GXL | X171 (1) |

| X183A ENGINE CONNECTOR | | | | | |
|------------------------|------------|------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 2-9 | 18 AWG | GXL | FC155 (A3) |
| 2 | WHT | 100-1 START | 16 AWG | GXL | C073-J1 (11) |
| 3 | YEL | CAN-TWO HIGH | 18 AWG | GXL | MS309 (8) |
| 4 | GRN | CAN-TWO LOW | 18 AWG | GXL | MS309 (11) |
| 5 | WHT | 101-0 ALT EXCITE | 16 AWG | GXL | C073-J1 (32) |
| 6 | | | | | |




Figure 7-37. Turntable Harness - Sheet 7 of 7


1001238405-F
MAF28300F

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X281- 12V BATTERY STUD | | | | | |
|-------------------------------|-------------------|-------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 1 GND | 2 AWG | EPDM | X280 (1) |

| X280- 12V BATTERY STUD | | | | | |
|-------------------------------|-------------------|-------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 1 GND | 2 AWG | EPDM | X281 (1) |

Go to Discount-Equipment.com to order your parts



Go to Discount-Equipment.com to order your parts

Figure 7-39. Boom Angle Sensor Harness

1001189005-D
MAE20810D

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| S294 | | | | | |
|----------|------------|--------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 4-108 PWR 5V | 18 AWG | GXL | X743B (2) |
| 2 | ORN/BLK | 4-106 PWR 5V | 18 AWG | TFFN | SN471 (B) |
| 2 | YEL/BLK | 4-112 PWR 5V | 18 AWG | TFFN | SN471 (F) |

| S295 | | | | | |
|----------|------------|---------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-40-76 GND | 18 AWG | GXL | X743B (1) |
| 2 | BLK/RED | 000-40-78 GND | 18 AWG | TFFN | SN471 (A) |
| 2 | BRN/BLK | 000-40-79 GND | 18 AWG | TFFN | SN471 (E) |

| SN471 | | | | | |
|----------|------------|---------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | BLK/RED | 000-40-78 GND | 18 AWG | TFFN | S295 (2) |
| B | ORN/BLK | 4-106 PWR 5V | 18 AWG | TFFN | S294 (2) |
| C | BLU/BLK | 4-86 BM ANGLE SEN 1 | 18 AWG | TFFN | X743B (3) |
| D | BLU/RED | 4-87 BM ANGLE SEN 2 | 18 AWG | TFFN | X743B (4) |
| E | BRN/BLK | 000-40-79 GND | 18 AWG | TFFN | S295 (2) |
| F | YEL/BLK | 4-112 PWR 5V | 18 AWG | TFFN | S294 (2) |

| X743B | | | | | |
|----------|------------|---------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-40-76 GND | 18 AWG | GXL | S295 (1) |
| 2 | WHT | 4-108 PWR 5V | 18 AWG | GXL | S294 (1) |
| 3 | BLU/BLK | 4-86 BM ANGLE SEN 1 | 18 AWG | TFFN | SN471 (C) |
| 4 | BLU/RED | 4-87 BM ANGLE SEN 2 | 18 AWG | TFFN | SN471 (D) |




Figure 7-40. Ground Control Harness - Sheet 1 of 2

1001238408-B
MAF21700B

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| C069-J4 BLUE | | | | | |
|--------------|------------|---------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | | | | | |
| 3 | | | | | |
| 4 | WHT | 100-0 START | 18 AWG | GXL | SW179 (1) |
| 5 | WHT | 89-0 LEVEL DOWN | 18 AWG | GXL | SW178 (3) |
| 6 | WHT | 86-0 ROTATE LEFT | 18 AWG | GXL | SW176 (3) |
| 7 | WHT | 78-0 TELE IN | 18 AWG | GXL | SW177 (3) |
| 8 | WHT | 83-0 JIB DOWN | 18 AWG | GXL | SW180 (3) |
| 9 | WHT | 109-0 ENG REGEN | 18 AWG | GXL | SW293-2 (1) |
| 10 | | | | | |
| 11 | | | | | |
| 12 | | | | | |
| 13 | | | | | |
| 14 | | | | | |
| 15 | | | | | |
| 16 | WHT | 93-0 AUX PWR | 18 AWG | GXL | SW179 (3) |
| 17 | WHT | 88-0 LEVEL UP | 18 AWG | GXL | SW178 (1) |
| 18 | WHT | 87-0 ROTATE RIGHT | 18 AWG | GXL | SW176 (1) |
| 19 | WHT | 82-0 JIB UP | 18 AWG | GXL | SW180 (1) |
| 20 | | | | | |
| 21 | | | | | |
| 22 | | | | | |
| 23 | WHT | 76-0 BOOM LIFT UP | 18 AWG | GXL | SW181 (1) |
| 24 | | | | | |
| 25 | YEL | 14-0 GND CNTRL+ | 18 AWG | GXL | SW177 (2) |
| 26 | | | | | |
| 27 | | | | | |
| 28 | | | | | |
| 29 | | | | | |
| 30 | WHT | 79-0 TELE OUT | 18 AWG | GXL | SW177 (1) |
| 31 | | | | | |
| 32 | | | | | |
| 33 | WHT | 77-0 BOOM LIFT DOWN | 18 AWG | GXL | SW181 (3) |
| 34 | WHT | 70-0 SWING LEFT | 18 AWG | GXL | SW182 (3) |
| 35 | WHT | 71-0 SWING RIGHT | 18 AWG | GXL | SW182 (1) |




Figure 7-41. Ground Control Harness - Sheet 2 of 2

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| SW176 ROTATE | | | | | |
|--------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 87-0 ROTATE RIGHT | 18 AWG | GXL | C069-J4 (18) |
| 2 | YEL | 14-0-1 GND CNTRL+ | 18 AWG | GXL | SW177 (2) |
| 2 | YEL | 14-0-2 GND CNTRL+ | 18 AWG | GXL | SW178 (2) |
| 3 | WHT | 86-0 ROTATE LEFT | 18 AWG | GXL | C069-J4 (6) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW178 LEVEL | | | | | |
|-------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 88-0 LEVEL UP | 18 AWG | GXL | C069-J4 (17) |
| 2 | YEL | 14-0-2 GND CNTRL+ | 18 AWG | GXL | SW176 (2) |
| 2 | YEL | 14-0-3 GND CNTRL+ | 18 AWG | GXL | SW179 (2) |
| 3 | WHT | 89-0 LEVEL DOWN | 18 AWG | GXL | C069-J4 (5) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW180 JIB | | | | | |
|-----------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 82-0 JIB UP | 18 AWG | GXL | C069-J4 (19) |
| 2 | YEL | 14-0-4 GND CNTRL+ | 18 AWG | GXL | SW179 (2) |
| 2 | YEL | 14-0-5 GND CNTRL+ | 18 AWG | GXL | SW181 (2) |
| 3 | WHT | 83-0 JIB DOWN | 18 AWG | GXL | C069-J4 (8) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW177 BOOM TELE | | | | | |
|-----------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 79-0 TELE OUT | 18 AWG | GXL | C069-J4 (30) |
| 2 | YEL | 14-0 GND CNTRL+ | 18 AWG | GXL | C069-J4 (25) |
| 2 | YEL | 14-0-1 GND CNTRL+ | 18 AWG | GXL | SW176 (2) |
| 3 | WHT | 78-0 TELE IN | 18 AWG | GXL | C069-J4 (7) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW181 BOOM LIFT | | | | | |
|-----------------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 76-0 BOOM LIFT UP | 18 AWG | GXL | C069-J4 (23) |
| 2 | YEL | 14-0-5 GND CNTRL+ | 18 AWG | GXL | SW180 (2) |
| 2 | YEL | 14-0-6 GND CNTRL+ | 18 AWG | GXL | SW182 (2) |
| 3 | WHT | 77-0 BOOM LIFT DOWN | 18 AWG | GXL | C069-J4 (33) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW182 SWING | | | | | |
|-------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 71-0 SWING RIGHT | 18 AWG | GXL | C069-J4 (35) |
| 2 | YEL | 14-0-6 GND CNTRL+ | 18 AWG | GXL | SW181 (2) |
| 2 | YEL | 14-0-7 GND CNTRL+ | 18 AWG | GXL | SW293-1 (1) |
| 3 | WHT | 70-0 SWING LEFT | 18 AWG | GXL | C069-J4 (34) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW293-1 ENGINE REGENERATION | | | | | |
|--------------------------------|------------|-------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-0-7 GND CNTRL+ | 18 AWG | GXL | SW182 (2) |

| SW179 START/ AUX PWR | | | | | |
|----------------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 100-0 START | 18 AWG | GXL | C069-J4 (4) |
| 2 | YEL | 14-0-3 GND CNTRL+ | 18 AWG | GXL | SW178 (2) |
| 2 | YEL | 14-0-4 GND CNTRL+ | 18 AWG | GXL | SW180 (2) |
| 3 | WHT | 93-0 AUX PWR | 18 AWG | GXL | C069-J4 (16) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |

| SW293-2 ENGINE REGENERATION | | | | | |
|--------------------------------|------------|-----------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 109-0 ENG REGEN | 18 AWG | GXL | C069-J4 (9) |




Figure 7-42. Lift Cylinder Harness

1001205923-C
MAF22670C


SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| HV252 BOOM LIFT DOWN | | | | | |
|-----------------------------|-------------------|-------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 77-1 BOOM LIFT DN | 18 AWG | GXL | X745B (1) |
| 2 | WHT | 50-4-1 LIFT RTN | 18 AWG | GXL | X745B (3) |

| HV253 BOOM LIFT DN ENBL/AUX | | | | | |
|--|-------------------|-------------------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 77-2 BOOM LIFT DN ENBL/AUX | 18 AWG | GXL | X745B (2) |
| 2 | WHT | 50-5 LIFT DN ENBL/AUX RTN | 18 AWG | GXL | X745B (4) |

| X745B TO MAIN VALVE HARNESS | | | | | |
|--|-------------------|-------------------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 77-1 BOOM LIFT DN | 18 AWG | GXL | HV252 (1) |
| 2 | WHT | 77-2 BOOM LIFT DN ENBL/AUX | 18 AWG | GXL | HV253 (1) |
| 3 | WHT | 50-4-1 LIFT RTN | 18 AWG | GXL | HV252 (2) |
| 4 | WHT | 50-5 LIFT DN ENBL/ AUX RTN | 18 AWG | GXL | HV253 (2) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS



Go to Discount-Equipment.com to order your parts

Figure 7-43. Deutz D2011L04 Engine Harness - Sheet 1 of 3

1001188236-F
MAE21110F

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| EC566-D+ ALTERNATOR EXCITE | | | | | |
|----------------------------|------------|-----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 6-51 ALT EXCITE | 16 AWG | GXL | X183B (5) |

| X801 B- AT AUX PUMP RELAY | | | | | |
|---------------------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-6-1-3 | 10 AWG | GXL | S802 (2) |

| EC566-B+ ALTERNATOR B+ | | | | | |
|------------------------|------------|------------|--------|--------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | - | FUSE LINK | 12 AWG | FUSIBLE LINK | S480 (2) |

| EC562 ENGINE STARTER | | | | | |
|----------------------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 12AWG | 12 AWG | GXL | RL563-30 (1) |

| S480 | | | | | |
|----------|------------|------------|--------|--------------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 8 AWG | 8 AWG | GXL | RL564-87 (1) |
| 2 | - | FUSE LINK | 12 AWG | FUSIBLE LINK | EC566-B+ (1) |

| X239 | | | | | |
|----------|------------|-----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | WHT | 6-17 DIAGNOSTIC | 18 AWG | GXL | S240 (2) |
| B | BLK | 000-6-3 | 18 AWG | GXL | X206 (2) |
| K | WHT | 24-6 | 18 AWG | GXL | X206 (11) |
| L | WHT | 23-6 | 18 AWG | GXL | X206 (10) |

| X800 B+ AT AUX PUMP RELAY | | | | | |
|---------------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | FUSE LEAD | 12 AWG | GXL | IP803 (2) |

| IP803 5A | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 6-15-2 | 16 AWG | GXL | RL799 (1) |
| 2 | RED | FUSE LEAD | 12 AWG | GXL | X800 (1) |




Figure 7-44. Deutz D2011L04 Engine Harness - Sheet 2 of 3

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X481 | | | | | |
|----------|------------|--------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CABLE CAN HI | 18 AWG | CABLE | S484 (1) |
| B | GRN | CABLE CAN LO | 18 AWG | CABLE | S483 (2) |
| C | | | | | |

| S484 | | | | | |
|----------|------------|--------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | CABLE CAN HI | 18 AWG | CABLE | X183B (3) |
| 1 | YEL | CABLE CAN HI | 18 AWG | CABLE | X481 (A) |
| 2 | YEL | CABLE CAN HI | 18 AWG | CABLE | X206 (12) |

| RL799 | | | | | |
|----------|------------|-----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 6-15-2 | 16 AWG | GXL | IP803 (1) |
| 2 | WHT | 6-15 DIAGNOSTIC | 18 AWG | GXL | S240 (2) |
| 3 | | | | | |
| 4 | WHT | 6-15-3 | 18 AWG | GXL | X206 (14) |
| 5 | BLK | 000-6-1-2 | 18 AWG | GXL | S802 (1) |

| S483 | | | | | |
|----------|------------|--------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | GRN | CABLE CAN LO | 18 AWG | CABLE | X183B (4) |
| 2 | GRN | CABLE CAN LO | 18 AWG | CABLE | X481 (B) |
| 2 | GRN | CABLE CAN LO | 18 AWG | CABLE | X206 (13) |

| S240 | | | | | |
|----------|------------|-----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 6-16 | 18 AWG | GXL | X183B (1) |
| 2 | WHT | 6-15 DIAGNOSTIC | 18 AWG | GXL | RL799 (2) |
| 2 | WHT | 6-17 DIAGNOSTIC | 18 AWG | GXL | X239 (A) |

| S802 | | | | | |
|----------|------------|----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-6-1 GROUND | 16 AWG | TFFN | X206 (1) |
| 1 | BLK | 000-6-1-2 | 18 AWG | GXL | RL799 (5) |
| 2 | BLK | 000-6-1-3 | 10 AWG | GXL | X801 (1) |

| X206 | | | | | |
|----------|------------|----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-6-1 GROUND | 16 AWG | TFFN | S802 (1) |
| 2 | BLK | 000-6-3 | 18 AWG | GXL | X239 (B) |
| 3 | | | | | |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |
| 7 | | | | | |
| 8 | | | | | |
| 9 | | | | | |
| 10 | WHT | 6-23 | 18 AWG | GXL | X239 (L) |
| 11 | WHT | 6-24 | 18 AWG | GXL | X239 (K) |
| 12 | YEL | CABLE CAN HI | 18 AWG | CABLE | S484 (2) |
| 13 | GRN | CABLE CAN LO | 18 AWG | CABLE | S483 (2) |
| 14 | WHT | 6-15-3 | 18 AWG | GXL | RL799 (4) |
| 15 | | | | | |
| 16 | | | | | |
| 17 | | | | | |
| 18 | | | | | |
| 19 | | | | | |
| 20 | | | | | |
| 21 | | | | | |
| 22 | | | | | |
| 23 | | | | | |
| 24 | | | | | |
| 25 | | | | | |




Figure 7-45. Deutz D2011L04 Engine Harness - Sheet 3 of 3

1001188236-F
MAE21130F

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X183B | | | | | |
|----------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 6-16 | 18 AWG | GXL | S240 (1) |
| 2 | WHT | 6-25 ENGINE START | 14 AWG | GXL | RL563-86 (1) |
| 3 | YEL | CABLE CAN HI | 18 AWG | CABLE | S484 (1) |
| 4 | GRN | CABLE CAN LO | 18 AWG | CABLE | S483 (1) |
| 5 | RED | 6-51 ALT EXCITE | 16 AWG | GXL | EC566-D+ (1) |
| 6 | | | | | |

| RL564-87 | | | | | |
|----------|------------|------------|-------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 8 AWG | 8 AWG | GXL | S480 (1) |

| RL563-86 | | | | | |
|----------|------------|-------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 6-25 ENGINE START | 14 AWG | GXL | X183B (2) |

| X181B | | | | | |
|----------|------------|------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | | | | | |
| 3 | | | | | |
| 4 | WHT | 6-18 GLOW | 18 AWG | GXL | RL564-86 (1) |
| 5 | | | | | |
| 6 | | | | | |
| 7 | | | | | |
| 8 | | | | | |

| RL563-30 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 12AWG | 12 AWG | GXL | EC562 (1) |

| RL564-86 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 6-18 GLOW | 18 AWG | GXL | X181B (4) |




Figure 7-46. Deutz T4F Engine Harness - Sheet 1 of 5

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| IP809 ECM PWR 30A | | | | | |
|-------------------|------------|---------------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 1-148-135-2 ECM PWR | 12 AWG | GXL | S812 (1) |
| 2 | RED | 1-148-135-2 ECM PWR | 12 AWG | GXL | X808 (1) |


| T920 ENGINE GROUND | | | | | |
|--------------------|------------|---------------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-148-246 ECM GND | 8 AWG | GXL | S945 (1) |
| 1 | BLK | 000-48-1 ENG GND | 14 AWG | GXL | X941 (4) |
| 1 | BLK | 000-48-2 ENG GND | 18 AWG | GXL | X950 (B) |
| 1 | BLK | 000-48-3 GND | 18 AWG | GXL | X999 (2) |

| X808 BATTERY PWR | | | | | |
|------------------|------------|---------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 1-148-135-2 ECM PWR | 12 AWG | GXL | IP809 (2) |

| S951 | | | | | |
|----------|------------|-------------------------------|--------|----------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | CAN 1 HI CUSTOMER CAN HIGH | 20 AWG | J1939 CABLE | S953 (2) |
| 2 | YEL | CAN 1 HI CUSTOMER CAN HIGH | 20 AWG | J1939 CABLE | X901 (3) |
| 2 | YEL | CAN 1 HI CUSTOMER CAN HIGH | 20 AWG | J1939 CABLE | X950 (M) |

| S952 | | | | | |
|----------|------------|------------------------------|--------|----------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | GRN | CAN 1 LO CUSTOMER CAN LOW | 20 AWG | J1939 CABLE | S954 (2) |
| 2 | GRN | CAN 1 LO CUSTOMER CAN LO | 20 AWG | J1939 CABLE | X901 (4) |
| 2 | GRN | CAN 1 LO CUSTOMER CAN LO | 20 AWG | J1939 CABLE | X950 (F) |

| S812 | | | | | |
|----------|------------|---------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 1-148-135-2 ECM PWR | 12 AWG | GXL | IP809 (1) |
| 2 | RED | 1-148-135 ECM PWR | 8 AWG | GXL | S944 (1) |



Go to DiyMount-Equipment.com to order your parts

Figure 7-47. Deutz T4F Engine Harness - Sheet 2 of 5

1001233895-H
MAF22720H

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| ECM-J1 | | | | | |
|----------|------------|---------------------------------|----------------------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 148-1 ECM PWR | 2.5 mm ² | FLRYW | S944 (2) |
| 2 | BLK | 148-2 ECM GND | 2.5 mm ² | FLRYW | S945 (2) |
| 3 | RED | 148-3 ECM PWR | 2.5 mm ² | FLRYW | S944 (2) |
| 4 | BLK | 148-4 ECM GND | 2.5 mm ² | FLRYW | S945 (2) |
| 5 | RED | 148-5 ECM PWR | 2.5 mm ² | FLRYW | S944 (2) |
| 6 | BLK | 148-6 ECM GND | 2.5 mm ² | FLRYW | S945 (2) |
| 7 | | | | | |
| 8 | | | | | |
| 9 | | | | | |
| 10 | | | | | |
| 11 | | | | | |
| 12 | | | | | |
| 13 | BLK | 148-13 COOLANT LEVEL SIG | 0.75 mm ² | FLRYW | SN939 (3) |
| 14 | | | | | |
| 15 | BLK | 148-15-68 CLUTCH SWITCH | 0.75 mm ² | FLRYW | ECM-J1 (68) |
| 16 | | | | | |
| 17 | | | | | |
| 18 | | | | | |
| 19 | | | | | |
| 20 | | | | | |
| 21 | | | | | |
| 22 | | | | | |
| 23 | | | | | |
| 24 | | | | | |
| 25 | | | | | |
| 26 | BLK | 148-26 FUEL PUMP RELAY CTRL GND | 0.75 mm ² | FLRYW | RL930 (2) |
| 27 | | | | | |
| 28 | BLK | 148-28 START RTN | 0.75 mm ² | FLRYW | EIC (2) |
| 29 | BLK | 148-29 COOLANT LEVEL PWR | 0.75 mm ² | FLRYW | SN939 (1) |
| 30 | | | | | |
| 31 | | | | | |
| 32 | | | | | |
| 33 | | | | | |
| 34 | | | | | |
| 35 | BLK | 148-35-2 START | 0.75 mm ² | FLRYW | S1001 (1) |
| 36 | | | | | |
| 37 | | | | | |
| 38 | BLK | 148-38 THROTTLE FLAP 4 | 0.75 mm ² | FLRYW | EIC (52) |

| | | | | | |
|----|-----|----------------------------------|----------------------|-------------|-------------|
| 39 | | | | | |
| 40 | | | | | |
| 41 | | | | | |
| 42 | | | | | |
| 43 | | | | | |
| 44 | BLK | 148-44 EHXAUST GAS RECIRCULATION | 0.75 mm ² | FLRYW | EIC (50) |
| 45 | | | | | |
| 46 | | | | | |
| 47 | | | | | |
| 48 | | | | | |
| 49 | | | | | |
| 50 | | | | | |
| 51 | | | | | |
| 52 | | | | | |
| 53 | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | S968 (1) |
| 54 | YEL | CAN 1 HI CUSTOMER CAN HIGH | 20 AWG | J1939 CABLE | S953 (1) |
| 55 | | | | | |
| 56 | BLK | 148-56 AIR INLET TEMP | 0.75 mm ² | FLRYW | EIC (34) |
| 57 | BLK | 148-57 WATER IN FUEL SW RTN | 0.75 mm ² | FLRYW | X941 (2) |
| 58 | | | | | |
| 59 | | | | | |
| 60 | | | | | |
| 61 | BLK | 148-61 FUEL LOW PRESSURE | 0.75 mm ² | FLRYW | EIC (17) |
| 62 | | | | | |
| 63 | | | | | |
| 64 | BLK | 148-64 WATER IN FUEL SW | 0.75 mm ² | FLRYW | X941 (1) |
| 65 | | | | | |
| 66 | | | | | |
| 67 | | | | | |
| 68 | BLK | 148-15-68 CLUTCH SWITCH | 0.75 mm ² | FLRYW | ECM-J1 (15) |
| 69 | | | | | |
| 70 | | | | | |
| 71 | | | | | |
| 72 | BLK | 148-72 THROTTLE FLAP 3 | 0.75 mm ² | FLRYW | EIC (49) |
| 73 | BLK | 148-73 START SIGNAL | 0.75 mm ² | FLRYW | EIC (3) |
| 74 | | | | | |
| 75 | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | S969 (1) |
| 76 | GRN | CAN 1 LO CUSTOMER CAN LOW | 20 AWG | J1939 CABLE | S954 (1) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| | | | | | |
|----|------|----------------------------------|----------------------|-------------|-----------|
| 77 | | | | | |
| 78 | | | | | |
| 79 | | | | | |
| 80 | | | | | |
| 81 | | | | | |
| 82 | BLK | 148-82 EHXAUST GAS RECIRCULATION | 0.75 mm ² | FLRYW | EIC (51) |
| 83 | | | | | |
| 84 | | | | | |
| 85 | BLK | 148-85 EHXAUST GAS RECIRCULATION | 0.75 mm ² | FLRYW | EIC (46) |
| 86 | | | | | |
| 87 | BLK | 148-87 COOLANT LEVEL GND | 0.75 mm ² | FLRYW | SN939 (2) |
| 88 | BLK | 148-88 IGNITION | 0.75 mm ² | FLRYW | S946 (2) |
| 89 | | | | | |
| 90 | | | | | |
| 91 | | | | | |
| 92 | | | | | |
| 93 | | | | | |
| 94 | | | | | |
| NC | SHLD | CAN 1 SHLD CUSTOMER CAN SHIELD | 20 AWG | J1939 CABLE | X901 (6) |

| S954 | | | | | |
|----------|------------|---------------------------|--------|-------------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | GRN | CAN 1 LO CUSTOMER CAN LOW | 20 AWG | J1939 CABLE | ECM-J1 (76) |
| 2 | GRN | CAN 1 LO CUSTOMER CAN LOW | 20 AWG | J1939 CABLE | S952 (1) |
| 2 | GRN | CAN 1 LO CUSTOMER CAN LOW | 20 AWG | J1939 CABLE | X955 (B) |

| S953 | | | | | |
|----------|------------|----------------------------|--------|-------------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | CAN 1 HI CUSTOMER CAN HIGH | 20 AWG | J1939 CABLE | ECM-J1 (54) |
| 2 | YEL | CAN 1 HI CUSTOMER CAN HIGH | 20 AWG | J1939 CABLE | S951 (1) |
| 2 | YEL | CAN 1 HI CUSTOMER CAN HIGH | 20 AWG | J1939 CABLE | X955 (A) |

| ECM-J2 | | | | | |
|----------|------------|----------------------------------|----------------------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | BLK | 248-2 INJECTOR 3 | 1.5 mm ² | FLRYW | EIC (61) |
| 3 | BLK | 248-3 INJECTOR 2 | 1.5 mm ² | FLRYW | EIC (41) |
| 4 | BLK | 248-M4 PROP ACTUATOR | 1.5 mm ² | FLRYW | EIC (19) |
| 5 | BLK | 248-M5 PROP ACTUATOR | 1.5 mm ² | FLRYW | EIC (20) |
| 6 | | | | | |
| 7 | BLK | 248-7 RAIL PRESSURE FUEL | 0.75 mm ² | FLRYW | EIC (32) |
| 8 | | | | | |
| 9 | | | | | |
| 10 | | | | | |
| 11 | | | | | |
| 12 | | | | | |
| 13 | | | | | |
| 14 | | | | | |
| 15 | | | | | |
| 16 | BLK | 248-16 INJECTOR 1 | 1.5 mm ² | FLRYW | EIC (35) |
| 17 | | | | | |
| 18 | BLK | 248-18 INJECTOR 4 | 1.5 mm ² | FLRYW | EIC (37) |
| 19 | BLK | 248-19 EXHAUST GAS RECIRCULATION | 1.5 mm ² | FLRYW | EIC (47) |
| 20 | BLK | 248-20 EXHAUST GAS RECIRCULATION | 1.5 mm ² | FLRYW | EIC (48) |
| 21 | | | | | |
| 22 | | | | | |
| 23 | BLK | 248-23 GLOW SENSE | 0.75 mm ² | FLRYW | MS932 (E) |
| 24 | BLK | 248-24 BOOST PRESSURE / TEMP | 0.75 mm ² | FLRYW | EIC (22) |
| 25 | BLK | 248-25 RAIL PRESSURE FUEL | 0.75 mm ² | FLRYW | EIC (31) |
| 26 | BLK | 248-26 RAIL PRESSURE FUEL | 0.75 mm ² | FLRYW | EIC (25) |
| 27 | BLK | 248-27 BOOST PRESSURE / TEMP | 0.75 mm ² | FLRYW | EIC (29) |
| 28 | BLK | 248-28 COOLING TEMPERATURE | 0.75 mm ² | FLRYW | EIC (24) |
| 29 | BLK | 248-29 OIL PRESSURE | 0.75 mm ² | FLRYW | EIC (27) |
| 30 | | | | | |
| 31 | | | | | |
| 32 | BLK | 248-32 INJECTOR 3 | 1.5 mm ² | FLRYW | EIC (38) |
| 33 | BLK | 248-33 INJECTOR 1 | 1.5 mm ² | FLRYW | EIC (62) |
| 34 | | | | | |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| | | | | | |
|----|------|---------------------------------------|----------------------|-------|--------------|
| 35 | BLK | 248-35 GLOW RELAY CONTROL GND | 0.75 mm ² | FLRYW | RL553-85 (1) |
| 36 | | | | | |
| 37 | BLK | 248-37 ENGINE SPEED CAMSHAFT | 18 AWG | CABLE | EIC (14) |
| 38 | SHLD | 248-38 ENGINE SPEED CRANKSHAFT | 20 AWG | CABLE | EIC (1) |
| 39 | BLK | 248-39 ENGINE SPEED CRANKSHAFT | 18 AWG | CABLE | EIC (15) |
| 40 | BLK | 248-40 AIR INLET TEMP | 0.75 mm ² | FLRYW | EIC (28) |
| 41 | | | | | |
| 42 | | | | | |
| 43 | BLK | 248-43 OIL PRESSURE | 0.75 mm ² | FLRYW | EIC (23) |
| 44 | BLK | 248-44 OIL PRESSURE | 0.75 mm ² | FLRYW | EIC (26) |
| 45 | | | | | |
| 46 | BLK | 248-46 INJECTOR 2 | 1.5 mm ² | FLRYW | EIC (40) |
| 47 | | | | | |
| 48 | BLK | 248-48 INJECTOR 4 | 1.5 mm ² | FLRYW | EIC (42) |
| 49 | | | | | |
| 50 | | | | | |
| 51 | | | | | |
| 52 | WHT | 248-52 ENGINE SPEED CAMSHAFT | 18 AWG | CABLE | EIC (13) |
| 53 | SHLD | 248-5E3 ENGINE SPEED CAMSHAFT | 20 AWG | CABLE | EIC (9) |
| 54 | WHT | 248-54 ENGINE ENGINE SPEED CRANKSHAFT | 18 AWG | CABLE | EIC (21) |
| 55 | | | | | |
| 56 | | | | | |
| 57 | | | | | |
| 58 | | | | | |
| 59 | | | | | |
| 60 | | | | | |

| S969 | | | | | |
|----------|------------|------------------------|--------|-------------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | ECM-J1 (75) |
| 2 | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | S964 (1) |
| 2 | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | X965 (A) |

| S968 | | | | | |
|----------|------------|-----------------------|--------|-------------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | ECM-J1 (53) |
| 2 | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | S963 (1) |
| 2 | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | X965 (B) |

| S945 | | | | | |
|----------|------------|---------------------|---------------------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-148-246 ECM GND | 8 AWG | GXL | T920 (1) |
| 2 | BLK | 148-2 ECM GND | 2.5 mm ² | FLRYW | ECM-J1 (2) |
| 2 | BLK | 148-4 ECM GND | 2.5 mm ² | FLRYW | ECM-J1 (4) |
| 2 | BLK | 148-6 ECM GND | 2.5 mm ² | FLRYW | ECM-J1 (6) |

| S944 | | | | | |
|----------|------------|-------------------|---------------------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 1-148-135 ECM PWR | 8 AWG | GXL | S812 (2) |
| 2 | RED | 148-1 ECM PWR | 2.5 mm ² | FLRYW | ECM-J1 (1) |
| 2 | RED | 148-3 ECM PWR | 2.5 mm ² | FLRYW | ECM-J1 (3) |
| 2 | RED | 148-5 ECM PWR | 2.5 mm ² | FLRYW | ECM-J1 (5) |

| X955 | | | | | |
|----------|------------|----------------------------|--------|-------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CAN 1 HI CUSTOMER CAN HIGH | 20 AWG | J1939 CABLE | S953 (2) |
| B | GRN | CAN 1 LO CUSTOMER CAN LOW | 20 AWG | J1939 CABLE | S954 (2) |
| C | | | | | |

| X965 | | | | | |
|----------|------------|------------------------|--------|-------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | S969 (2) |
| B | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | S968 (2) |
| C | | | | | |




Figure 7-48. Deutz T4F Engine Harness - Sheet 3 of 5

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| EIC | | | | | |
|----------|------------|--------------------------------|----------------------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | SHLD | 248-38 ENGINE SPEED CRANKSHAFT | 20 AWG | CABLE | ECM-J2 (38) |
| 2 | BLK | 148-28 START RTN | 0.75 mm ² | FLRYW | ECM-J1 (28) |
| 3 | BLK | 148-73 START SIGNAL | 0.75 mm ² | FLRYW | ECM-J1 (73) |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |
| 7 | | | | | |
| 8 | | | | | |
| 9 | SHLD | 248-53 ENGINE SPEED CAMSHAFT | 20 AWG | CABLE | ECM-J2 (53) |
| 10 | | | | | |
| 11 | | | | | |
| 12 | | | | | |
| 13 | WHT | 248-52 ENGINE SPEED CAMSHAFT | 18 AWG | CABLE | ECM-J2 (52) |
| 14 | BLK | 248-37 ENGINE SPEED CAMSHAFT | 18 AWG | CABLE | ECM-J2 (37) |
| 15 | BLK | 248-39 ENGINE SPEED CRANKSHAFT | 18 AWG | CABLE | ECM-J2 (39) |
| 16 | | | | | |
| 17 | BLK | 148-61 FUEL LOW PRESSURE | 0.75 mm ² | FLRYW | ECM-J1 (61) |
| 18 | | | | | |
| 19 | BLK | 248-4M PROPACTUATOR | 1.5 mm ² | FLRYW | ECM-J2 (4) |
| 20 | BLK | 248-5M PROPACTUATOR | 1.5 mm ² | FLRYW | ECM-J2 (5) |
| 21 | WHT | 248-54 ENGINE SPEED CRANKSHAFT | 18 AWG | CABLE | ECM-J2 (54) |
| 22 | BLK | 248-24 BOOST PRESSURE / TEMP | 0.75 mm ² | FLRYW | ECM-J2 (24) |
| 23 | BLK | 248-43 OIL PRESSURE | 0.75 mm ² | FLRYW | ECM-J2 (43) |
| 24 | BLK | 248-28 COOLING TEMPERATURE | 0.75 mm ² | FLRYW | ECM-J2 (28) |
| 25 | BLK | 248-26 RAIL PRESSURE FUEL | 0.75 mm ² | FLRYW | ECM-J2 (26) |
| 26 | BLK | 248-44 OIL PRESSURE | 0.75 mm ² | FLRYW | ECM-J2 (44) |
| 27 | BLK | 248-29 OIL PRESSURE | 0.75 mm ² | FLRYW | ECM-J2 (29) |
| 28 | BLK | 248-40 AIR INLET TEMP | 0.75 mm ² | FLRYW | ECM-J2 (40) |
| 29 | BLK | 248-27 BOOST PRESSURE / TEMP | 0.75 mm ² | FLRYW | ECM-J2 (27) |
| 30 | | | | | |
| 31 | BLK | 248-25 RAIL PRESSURE FUEL | 0.75 mm ² | FLRYW | ECM-J2 (25) |

| | | | | | |
|----|-----|----------------------------------|----------------------|-------|-------------|
| 32 | BLK | 248-7 RAIL PRESSURE FUEL | 0.75 mm ² | FLRYW | ECM-J2 (7) |
| 33 | | | | | |
| 34 | BLK | 148-56 AIR INLET TEMP | 0.75 mm ² | FLRYW | ECM-J1 (56) |
| 35 | BLK | 248-16 INJECTOR 1 | 1.5 mm ² | FLRYW | ECM-J2 (16) |
| 36 | | | | | |
| 37 | BLK | 248-18 INJECTOR 4 | 1.5 mm ² | FLRYW | ECM-J2 (18) |
| 38 | BLK | 248-32 INJECTOR 3 | 1.5 mm ² | FLRYW | ECM-J2 (32) |
| 39 | | | | | |
| 40 | BLK | 248-46 INJECTOR 2 | 1.5 mm ² | FLRYW | ECM-J2 (46) |
| 41 | BLK | 248-3 INJECTOR 2 | 1.5 mm ² | FLRYW | ECM-J2 (3) |
| 42 | BLK | 248-48 INJECTOR 4 | 1.5 mm ² | FLRYW | ECM-J2 (48) |
| 43 | | | | | |
| 44 | | | | | |
| 45 | | | | | |
| 46 | BLK | 148-85 EHXAUST GAS RECIRCULATION | 0.75 mm ² | FLRYW | ECM-J1 (85) |
| 47 | BLK | 248-19 EHXAUST GAS RECIRCULATION | 1.5 mm ² | FLRYW | ECM-J2 (19) |
| 48 | BLK | 248-20 EHXAUST GAS RECIRCULATION | 1.5 mm ² | FLRYW | ECM-J2 (20) |
| 49 | BLK | 148-72 THROTTLE FLAP 3 | 0.75 mm ² | FLRYW | ECM-J1 (72) |
| 50 | BLK | 148-44 EHXAUST GAS RECIRCULATION | 0.75 mm ² | FLRYW | ECM-J1 (44) |
| 51 | BLK | 148-82 EHXAUST GAS RECIRCULATION | 0.75 mm ² | FLRYW | ECM-J1 (82) |
| 52 | BLK | 148-38 THROTTLE FLAP 4 | 0.75 mm ² | FLRYW | ECM-J1 (38) |
| 53 | | | | | |
| 54 | | | | | |
| 55 | | | | | |
| 56 | | | | | |
| 57 | | | | | |
| 58 | | | | | |
| 59 | | | | | |
| 60 | | | | | |
| 61 | BLK | 248-2 INJECTOR 3 | 1.5 mm ² | FLRYW | ECM-J2 (2) |
| 62 | BLK | 248-33 INJECTOR 1 | 1.5 mm ² | FLRYW | ECM-J2 (33) |

| S946 | | | | | |
|----------|------------|-----------------|----------------------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 2-48-1 IGNITION | 16 AWG | GXL | MS932 (H) |
| 1 | YEL | 2-48-2 IGNITION | 18 AWG | GXL | X950 (A) |
| 2 | BLK | 148-88 IGNITION | 0.75 mm ² | FLRYW | ECM-J1 (88) |
| 2 | YEL | 2-48-3 IGNITION | 18 AWG | GXL | RL553-86 (1) |
| 2 | YEL | 2-48-4 IGNITION | 18 AWG | GXL | RL930 (1) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS


| EC18 | | | | | |
|----------|------------|------------|-------|--------|----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 48-14 GLOW | 8 AWG | GXL | RL553-30 (1) |
| 2 | RED | 48-13 GLOW | 8 AWG | GXL | RL553-30-1 (1) |

| X950 DEUTZ DIAGNOSTIC | | | | | |
|--------------------------|------------|---------------------------|---------|-------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | 2-48-2 IGNITION | 18 AWG | GXL | S946 (1) |
| B | BLK | 000-48-2 ENG GND | 18 AWG | GXL | T920 (1) |
| C | | | | | |
| D | | | | | |
| E | | | | | |
| F | GRN | CAN 1 LO CUSTOMER CAN LO | 20 AWG | J1939 CABLE | S952 (2) |
| G | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | S963 (2) |
| H | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | S964 (1) |
| J | | | | | |
| K | | | | | |
| L | | | | | |
| M | YEL | CAN 1 HI CUSTOMER CAN HIG | H20 AWG | J1939 CABLE | S951 (2) |

| SN939 | | | | | |
|----------|------------|--------------------------|----------------------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 148-29 COOLANT LEVEL PWR | 0.75 mm ² | FLRYW | ECM-J1 (29) |
| 2 | BLK | 148-87 COOLANT LEVEL GND | 0.75 mm ² | FLRYW | ECM-J1 (87) |
| 3 | BLK | 148-13 COOLANT LEVEL SIG | 0.75 mm ² | FLRYW | ECM-J1 (13) |
| 4 | | | | | |

| MS932 | | | | | |
|----------|------------|---------------------|---------|--------|----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | | | | | |
| B | | | | | |
| C | | | | | |
| D | | | | | |
| E | BLK | 248-23 GLOW SENSE | 0.75 mm | FLRYW | ECM-J2 (23) |
| F | ORG | 248-23-1 GLOW SENSE | 18 AWG | GXL | RL553-30-2 (1) |
| G | YEL | 2-1-99 IGNITION | 18 AWG | GXL | X902 (1) |
| H | YEL | 2-48-1 IGNITION | 16 AWG | GXL | S946 (1) |

| EC555-D+ | | | | | |
|----------|------------|----------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 47-8 ALTEXCITE | 16 AWG | GXL | X901 (5) |



1001233895-H
MAF22740H

Figure 7-49. Deutz T4F Engine Harness - Sheet 4 of 5

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X941 | | | | | |
|----------|------------|-----------------------------|----------------------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 148-64 WATER IN FUEL SW | 0.75 mm ² | FLRYW | ECM-J1 (64) |
| 2 | BLK | 148-57 WATER IN FUEL SW RTN | 0.75 mm ² | FLRYW | ECM-J1 (57) |
| 3 | WHT | 48-96 FUEL PUMP | 14 AWG | GXL | RL930-1 (1) |
| 4 | BLK | 000-48-1 ENG GND | 14 AWG | GXL | T920 (1) |

| S964 | | | | | |
|----------|------------|------------------------|--------|-------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | S969 (2) |
| 1 | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | X950 (H) |
| 2 | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | X960 (A) |

| X902 | | | | | |
|----------|------------|-----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 2-1-99 IGNITION | 18 AWG | GXL | MS932 (G) |
| 2 | | | | | |
| 3 | | | | | |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |
| 7 | | | | | |
| 8 | | | | | |

| S1001 | | | | | |
|----------|------------|---------------|----------------------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 148-35-2START | 0.75 mm ² | FLRYW | ECM-J1 (35) |
| 1 | BLK | 148-35-3 | 18 AWG | GXL | X999 (1) |
| 2 | BLK | 148-35-1START | 18 AWG | GXL | X901 (2) |

| X901 | | | | | |
|----------|------------|--------------------------------|--------|-------------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | BLK | 148-35-1 START | 18 AWG | GXL | S1001 (2) |
| 3 | YEL | CAN 1 HI CUSTOMER CAN HIGH | 20 AWG | J1939 CABLE | S951 (2) |
| 4 | GRN | CAN 1 LO CUSTOMER CAN LO | 20 AWG | J1939 CABLE | S952 (2) |
| 5 | RED | 47-8 ALT EXCITE | 16 AWG | GXL | EC555-D+ (1) |
| 6 | SHLD | CAN 1 SHLD CUSTOMER CAN SHIELD | 20 AWG | J1939 CABLE | ECM-J1 (NC) |

| X999 | | | | | |
|----------|------------|--------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 148-35-3 | 18 AWG | GXL | S1001 (1) |
| 2 | BLK | 000-48-3 GND | 18 AWG | GXL | T920 (1) |

| RL553-85 | | | | | |
|----------|------------|------------------------------|----------------------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 248-35GLOW RELAY CONTROL GND | 0.75 mm ² | FLRYW | ECM-J2 (35) |

| RL553-30-2 | | | | | |
|------------|------------|---------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | ORG | 248-23-1 GLOW SENSE | 18 AWG | GXL | MS932 (F) |

| S963 | | | | | |
|----------|------------|-----------------------|--------|-------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | X960 (B) |
| 2 | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | S968 (2) |
| 2 | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | X950 (G) |

| RL553-30-1 | | | | | |
|------------|------------|------------|-------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 48-13 GLOW | 8 AWG | GXL | EC18 (2) |

| RL553-30 | | | | | |
|----------|------------|------------|-------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 48-14 GLOW | 8 AWG | GXL | EC18 (1) |

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS


| RL553-86 | | | | | |
|----------|------------|-----------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 2-48-3 IGNITION | 18 AWG | GXL | S946 (2) |

| RL930-1 | | | | | |
|----------|------------|-----------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 48-96 FUEL PUMP | 14 AWG | GXL | X941 (3) |

| RL930 | | | | | |
|----------|------------|---------------------------------|----------------------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 2-48-4 IGNITION | 18 AWG | GXL | S946 (2) |
| 2 | BLK | 148-26 FUEL PUMP RELAY CTRL GND | 0.75 mm ² | FLRYW | ECM-J1 (26) |


| X960 | | | | | |
|----------|------------|------------------------|--------|-------------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | CAN 2 HI DIAG CAN HIGH | 20 AWG | J1939 CABLE | S964 (2) |
| B | GRN | CAN 2 LO DIAG CAN LOW | 20 AWG | J1939 CABLE | S963 (1) |
| C | | | | | |

Go to Discount-Equipment.com to order your parts



1001233895-G
MAF22750G

Figure 7-50. Deutz T4F Engine Harness - Sheet 5 of 5



1001193592-D
MAE21350D

Figure 7-51. Chassis Head and Tail Lights Harness - Sheet 1 of 2

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS


| X505 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 4-145 | 18 AWG | GXL | RL673 (5) |

| LB670 FRONT RIGHT | | | | | |
|-------------------|------------|---------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-60-29 GND | 16 AWG | GXL | S672 (1) |
| 2 | WHT | 6-29 12V+ | 16 AWG | GXL | S671 (1) |

| LB495 FRONT LEFT | | | | | |
|------------------|------------|---------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-60-11 GND | 16 AWG | GXL | S672 (1) |
| 2 | WHT | 6-11 12V+ | 16 AWG | GXL | S671 (1) |

| X666 REAR LEFT | | | | | |
|----------------|------------|---------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | BLK | 000-60-12 GND | 16 AWG | GXL | S672 (2) |
| 3 | WHT | 6-13 12V+ | 16 AWG | GXL | S671 (2) |
| 4 | | | | | |

Go to Discount-Equipment.com to order your parts



1001193592-D
MAEZ1380

Go to Discount-Equipment.com to order your parts

Figure 7-52. Chassis Head and Tail Lights Harness - Sheet 2 of 2

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| IP629 10A | | | | | |
|-----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 4-146 | 14 AWG | GXL | X675 (1) |
| 2 | WHT | 4-146 | 14 AWG | GXL | RL673 (1) |

| X674 | | | | | |
|----------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 4-122 | 14 AWG | GXL | S672 (2) |

| RL673 HEAD AND TAIL LIGHTS | | | | | |
|----------------------------|------------|----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 4-146 | 14 AWG | GXL | IP629 (2) |
| 2 | BLK | 000-40-109 GND | 16 AWG | GXL | X676 (1) |
| 3 | | | | | |
| 4 | WHT | 6-8 12V+ | 14 AWG | GXL | S671 (2) |
| 5 | WHT | 4-145 | 18 AWG | GXL | X505 (1) |

| S671 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 6-11 12V+ | 16 AWG | GXL | LB495 (2) |
| 1 | WHT | 6-29 12V+ | 16 AWG | GXL | LB670 (2) |
| 2 | WHT | 6-13 12V+ | 16 AWG | GXL | X666 (3) |
| 2 | WHT | 6-30 12V+ | 16 AWG | GXL | X668 (3) |
| 2 | WHT | 6-8 12V+ | 14 AWG | GXL | RL673 (4) |

| X676 | | | | | |
|----------|------------|----------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-40-109 GND | 16 AWG | GXL | RL673 (2) |

| S672 | | | | | |
|----------|------------|---------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-60-11 GND | 16 AWG | GXL | LB495 (1) |
| 1 | BLK | 000-60-29 GND | 16 AWG | GXL | LB670 (1) |
| 2 | BLK | 000-60-12 GND | 16 AWG | GXL | X666 (2) |
| 2 | BLK | 000-60-30 GND | 16 AWG | GXL | X668 (2) |
| 2 | BLK | 4-122 | 14 AWG | GXL | X674 (1) |

| X675 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 4-146 | 14 AWG | GXL | IP629 (1) |

| X668 REAR RIGHT | | | | | |
|-----------------|------------|---------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | BLK | 000-60-30 GND | 16 AWG | GXL | S672 (2) |
| 3 | WHT | 6-30 12V+ | 16 AWG | GXL | S671 (2) |
| 4 | | | | | |




Figure 7-53. Chassis Work Lights Harness - Sheet 1 of 2

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS


| LB638 FRONT LEFT | | | | | |
|------------------|------------|--------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-60-3 GND | 16 AWG | GXL | S643 (1) |
| 2 | WHT | 6-4 12V+ | 16 AWG | GXL | S642 (1) |

| LB640 FRONT RIGHT | | | | | |
|-------------------|------------|--------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-60-5 GND | 16 AWG | GXL | S643 (1) |
| 2 | WHT | 6-6 12V+ | 16 AWG | GXL | S642 (1) |

| X680 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 4-28 | 16 AWG | GXL | RL168 (5) |

| LB639 REAR LEFT | | | | | |
|-----------------|------------|--------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-60-4 GND | 16 AWG | GXL | S643 (2) |
| 2 | WHT | 6-5 12V+ | 16 AWG | GXL | S642 (2) |

Go to Discount-Equipment.com to order your parts



Go to Discount-Equipment.com to order your parts

Figure 7-54. Chassis Work Lights Harness - Sheet 2 of 2

1001193593-C
MAE21370C

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X678 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 4-70 | 14 AWG | GXL | IP630 (1) |

| X677 | | | | | |
|----------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-40-17 | 14 AWG | GXL | S643 (2) |

| X679 | | | | | |
|----------|------------|--------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-40-9 GND | 16 AWG | GXL | RL168 (2) |

| S642 | | | | | |
|----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 6-4 12V+ | 16 AWG | GXL | LB638 (2) |
| 1 | WHT | 6-6 12V+ | 16 AWG | GXL | LB640 (2) |
| 2 | WHT | 6-5 12V+ | 16 AWG | GXL | LB639 (2) |
| 2 | WHT | 6-7 12V+ | 16 AWG | GXL | LB641 (2) |
| 2 | WHT | 6-8 12V+ | 14 AWG | GXL | RL168 (4) |

| RL168 HEAD AND TAIL LIGHTS | | | | | |
|----------------------------|------------|--------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 4-70 | 14 AWG | GXL | IP630 (2) |
| 2 | BLK | 000-40-9 GND | 16 AWG | GXL | X679 (1) |
| 3 | | | | | |
| 4 | WHT | 6-8 12V+ | 14 AWG | GXL | S642 (2) |
| 5 | WHT | 4-28 | 16 AWG | GXL | X680 (1) |

| LB641 REAR RIGHT | | | | | |
|------------------|------------|--------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-60-6 GND | 16 AWG | GXL | S643 (2) |
| 2 | WHT | 6-7 12V+ | 16 AWG | GXL | S642 (2) |

| IP630 20A | | | | | |
|-----------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 4-70 | 14 AWG | GXL | X678 (1) |
| 2 | WHT | 4-70 | 14 AWG | GXL | RL168 (1) |

| S643 | | | | | |
|----------|------------|--------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 000-60-3 GND | 16 AWG | GXL | LB638 (1) |
| 1 | BLK | 000-60-5 GND | 16 AWG | GXL | LB640 (1) |
| 2 | BLK | 000-40-17 | 14 AWG | GXL | X677 (1) |
| 2 | BLK | 000-60-4 GND | 16 AWG | GXL | LB639 (1) |
| 2 | BLK | 000-60-6 GND | 16 AWG | GXL | LB641 (1) |




Figure 7-55. ClearSky Harness

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| S406 | | | | | |
|----------|------------|-------------|--------|--------|-----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 0-100-1 GND | 16 AWG | GXL | TCU (16) |
| 1 | BLK | 0-100-2 GND | 16 AWG | GXL | DIAG_CONN (A) |
| 2 | BLK | 0-100-3 GND | 16 AWG | GXL | DIAG_CONN_1 (A) |

| S407 | | | | | |
|----------|------------|------------|--------|--------|-----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | 1-100-2 B+ | 16 AWG | GXL | DIAG_CONN (B) |
| 1 | RED | 1-100-3 B+ | 16 AWG | GXL | DIAG_CONN_1 (B) |
| 2 | RED | 1-100-1 B+ | 16 AWG | GXL | TCU (23) |

| S408 | | | | | |
|----------|------------|----------------|--------|--------|-----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 4-100-1 CAN HI | 18 AWG | GXL | TCU (7) |
| 1 | YEL | 4-100-3 CAN HI | 18 AWG | GXL | DIAG_CONN_1 (C) |
| 2 | YEL | 4-100-2 CAN HI | 18 AWG | GXL | DIAG_CONN (C) |

| S409 | | | | | |
|----------|------------|----------------|--------|--------|-----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | GRN | 3-100-1 CAN LO | 18 AWG | GXL | TCU (22) |
| 1 | GRN | 3-100-3 CAN LO | 18 AWG | GXL | DIAG_CONN_1 (D) |
| 2 | GRN | 3-100-2 CAN LO | 18 AWG | GXL | DIAG_CONN (D) |

| S410 | | | | | |
|----------|------------|-------------|--------|--------|-----------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL/RED | 2-100-2 IGN | 18 AWG | GXL | DIAG_CONN (H) |
| 2 | YEL/RED | 2-100-1 IGN | 18 AWG | GXL | TCU (15) |
| 2 | YEL/RED | 2-100-3 IGN | 18 AWG | GXL | DIAG_CONN_1 (H) |

| DIAG_CONN_1 | | | | | |
|-------------|------------|----------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | BLK | 0-100-3 GND | 16 AWG | GXL | S406 (2) |
| B | RED | 1-100-3 B+ | 16 AWG | GXL | S407 (1) |
| C | YEL | 4-100-3 CAN HI | 18 AWG | GXL | S408 (1) |
| D | GRN | 3-100-3 CAN LO | 18 AWG | GXL | S409 (1) |
| E | | | | | |
| F | | | | | |
| G | | | | | |
| H | YEL/RED | 2-100-3 IGN | 18 AWG | GXL | S410 (2) |
| J | | | | | |

| DIAG_CONN | | | | | |
|-----------|------------|----------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | BLK | 0-100-2 GND | 16 AWG | GXL | S406 (1) |
| B | RED | 1-100-2 B+ | 16 AWG | GXL | S407 (1) |
| C | YEL | 4-100-2 CAN HI | 18 AWG | GXL | S408 (2) |
| D | GRN | 3-100-2 CAN LO | 18 AWG | GXL | S409 (2) |
| E | | | | | |
| F | | | | | |
| G | | | | | |
| H | YEL/RED | 2-100-2 IGN | 18 AWG | GXL | S410 (1) |
| J | | | | | |

| TCU | | | | | |
|----------|------------|----------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | | | | | |
| 3 | | | | | |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |
| 7 | YEL | 4-100-1 CAN HI | 18 AWG | GXL | S408 (1) |
| 8 | | | | | |
| 9 | | | | | |
| 10 | | | | | |
| 11 | | | | | |
| 12 | | | | | |
| 13 | | | | | |
| 14 | | | | | |
| 15 | YEL/RED | 2-100-1 IGN | 18 AWG | GXL | S410 (2) |
| 16 | BLK | 0-100-1 GND | 16 AWG | GXL | S406 (1) |
| 17 | | | | | |
| 18 | | | | | |
| 19 | | | | | |
| 20 | | | | | |
| 21 | | | | | |
| 22 | GRN | 3-100-1 CAN LO | 18 AWG | GXL | S409 (1) |
| 23 | RED | 1-100-1 B+ | 16 AWG | GXL | S407 (2) |




Figure 7-56. Platform Valve w/Jib Harness - Sheet 1 of 3


1001189111-K
MAF22800K

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X652A | | | | | |
|----------|------------|-------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 12-3 PLAT VLV- | 18 AWG | GXL | MS218 (2) |
| 2 | | | | | |
| 3 | WHT | 90-1 HI PRS DUMP | 18 AWG | GXL | HV215 (1) |
| 4 | WHT | 88-1-2 LEVEL UP | 18 AWG | GXL | HV195 (1) |
| 5 | WHT | 89-1-2 LEVEL DOWN | 18 AWG | GXL | HV194 (1) |
| 6 | | | | | |
| 7 | | | | | |
| 8 | YEL-BLK | 18-6 1060780 | 18 AWG | CABLE | SN217 (C) |
| 9 | BRN-BLK | 18-6 1060780 | 18 AWG | CABLE | SN217 (D) |
| 10 | ORG-BLK | 18-6 1060780 | 18 AWG | CABLE | SN217 (B) |
| 11 | BLU-RED | 18-6 1060780 | 18 AWG | CABLE | SN217 (F) |
| 12 | WHT | 90-2 LOW PRS DUMP | 18 AWG | GXL | HV216 (1) |
| 13 | WHT | 86-3 ROTATE LEFT | 18 AWG | GXL | HV197 (1) |
| 14 | WHT | 87-3 ROTATE RIGHT | 18 AWG | GXL | HV196 (1) |
| 15 | WHT | 82-3 JIB UP | 18 AWG | GXL | HV183 (1) |
| 16 | WHT | 83-3 JIB DOWN | 18 AWG | GXL | HV184 (1) |
| 17 | | | | | |
| 18 | | | | | |
| 19 | | | | | |
| 20 | BLK-RED | 18-6 1060780 | 18 AWG | CABLE | SN217 (E) |
| 21 | BLU-BLK | 18-6 1060780 | 18 AWG | CABLE | SN217 (A) |

| SN217 PLATFORM ANGLE SNSR | | | | | |
|------------------------------|------------|--------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLU-BLK | 18-6 1060780 | 18 AWG | CABLE | X652A (21) |
| 2 | ORG-BLK | 18-6 1060780 | 18 AWG | CABLE | X652A (10) |
| 3 | YEL-BLK | 18-6 1060780 | 18 AWG | CABLE | X652A (8) |
| 4 | BRN-BLK | 18-6 1060780 | 18 AWG | CABLE | X652A (9) |
| 5 | BLK-RED | 18-6 1060780 | 18 AWG | CABLE | X652A (20) |
| 6 | BLU-RED | 18-6 1060780 | 18 AWG | CABLE | X652A (11) |

| MS218 VLV BANK GND BUSS | | | | | |
|----------------------------|------------|------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | BLK | 12-3 PLAT VLV- | 18 AWG | GXL | X652A (1) |
| 3 | BLK | 12-3-1 PLAT VLV- | 18 AWG | GXL | HV216 (2) |
| 4 | BLK | 12-3-2 PLAT VLV- | 18 AWG | GXL | HV215 (2) |
| 5 | BLK | 12-3-3 PLAT VLV- | 18 AWG | GXL | HV184 (2) |
| 6 | BLK | 12-3-4 PLAT VLV- | 18 AWG | GXL | HV183 (2) |
| 7 | BLK | 12-3-5 PLAT VLV- | 18 AWG | GXL | HV196 (2) |
| 8 | BLK | 12-3-6 PLAT VLV- | 18 AWG | GXL | HV197 (2) |
| 9 | BLK | 12-3-7 PLAT VLV- | 18 AWG | GXL | HV194 (2) |
| 10 | BLK | 12-3-8 PLAT VLV- | 18 AWG | GXL | HV195 (2) |
| 11 | | | | | |
| 12 | | | | | |



1001189111-K
MAF22810K

Figure 7-57. Platform Valve w/Jib Harness - Sheet 2 of 3

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| HV195 LEVEL UP | | | | | |
|----------------|------------|------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 88-1-2 LEVEL UP | 18 AWG | GXL | X652A (4) |
| 2 | BLK | 12-3-8 PLAT VLV- | 18 AWG | GXL | MS218 (10) |

| HV183 JIB UP | | | | | |
|--------------|------------|------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 82-3 JIB UP | 18 AWG | GXL | X652A (15) |
| 2 | BLK | 12-3-4 PLAT VLV- | 18 AWG | GXL | MS218 (6) |

| HV196 ROTATE RIGHT | | | | | |
|--------------------|------------|-------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 87-3 ROTATE RIGHT | 18 AWG | GXL | X652A (14) |
| 2 | BLK | 12-3-5 PLAT VLV- | 18 AWG | GXL | MS218 (7) |

| HV194 LEVEL DOWN | | | | | |
|------------------|------------|-------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 89-1-2 LEVEL DOWN | 18 AWG | GXL | X652A (5) |
| 2 | BLK | 12-3-7 PLAT VLV- | 18 AWG | GXL | MS218 (9) |

| HV215 HI PRS DUMP | | | | | |
|----------------------|------------|------------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 90-1 HI PRS DUMP | 18 AWG | GXL | X652A (3) |
| 2 | BLK | 12-3-2 PLAT VLV- | 18 AWG | GXL | MS218 (4) |

| HV216 LOW PRS DUMP | | | | | |
|-----------------------|------------|-------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 90-2 LOW PRS DUMP | 18 AWG | GXL | X652A (12) |
| 2 | BLK | 12-3-1 PLAT VLV- | 18 AWG | GXL | MS218 (3) |

| HV197 ROTATE LEFT | | | | | |
|-------------------|------------|------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 86-3 ROTATE LEFT | 18 AWG | GXL | X652A (13) |
| 2 | BLK | 12-3-6 PLAT VLV- | 18 AWG | GXL | MS218 (8) |

| HV184 JIB DOWN | | | | | |
|----------------|------------|------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 83-3 JIB DOWN | 18 AWG | GXL | X652A (16) |
| 2 | BLK | 12-3-3 PLAT VLV- | 18 AWG | GXL | MS218 (5) |





Figure 7-58. Platform Valve w/Jib Harness - Sheet 3 of 3



1001225580-D
MAF22490D

Figure 7-59. Skyguard GEN2 Platform Interface Harness

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X5B - INTERFACE | | | | | |
|-----------------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | P2 | 18 AWG | GXL | IP114 (1) |
| 2 | WHT | P6 | 18 AWG | GXL | X500 (2) |
| 3 | | | | | |
| 4 | WHT | P1 | 18 AWG | GXL | RL503 (87) |
| 5 | WHT | P3 | 18 AWG | GXL | RL502 (87) |
| 6 | | | | | |

| RL503 - SKYGUARD RELAY #1 | | | | | |
|---------------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 30 | WHT | P9-1 | 18 AWG | GXL | IP114 (1) |
| 85 | WHT | P5-1 | 18 AWG | GXL | S191 (1) |
| 86 | WHT | P4-1 | 18 AWG | GXL | S192 (1) |
| 87 | WHT | P1 | 18 AWG | GXL | X5B (4) |
| 87A | | | | | |

| RL502 - SKYGUARD RELAY #2 | | | | | |
|---------------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 30 | WHT | P9-2 | 18 AWG | GXL | IP114 (1) |
| 85 | WHT | P5-2 | 18 AWG | GXL | S191 (1) |
| 86 | WHT | P4-2 | 18 AWG | GXL | S192 (1) |
| 87 | WHT | P3 | 18 AWG | GXL | X5B (5) |
| 87a | | | | | |

| S192 | | | | | |
|----------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | P4-1 | 18 AWG | GXL | RL503 (86) |
| 1 | WHT | P4-2 | 18 AWG | GXL | RL502 (86) |
| 2 | WHT | P4 | 18 AWG | GXL | X500 (3) |

| S191 | | | | | |
|----------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | P5-1 | 18 AWG | GXL | RL503 (85) |
| 1 | WHT | P5-2 | 18 AWG | GXL | RL502 (85) |
| 2 | WHT | P5 | 18 AWG | GXL | X500 (4) |

| X500 - PLATE SENSOR | | | | | |
|---------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | P10 | 18 AWG | GXL | IP114 (2) |
| 2 | WHT | P6 | 18 AWG | GXL | X5B (2) |
| 3 | WHT | P4 | 18 AWG | GXL | S192 (2) |
| 4 | WHT | P5 | 18 AWG | GXL | S191 (2) |

| IP114 | | | | | |
|----------|------------|------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | P2 | 18 AWG | GXL | X5B (1) |
| 1 | WHT | P9-1 | 18 AWG | GXL | RL503 (30) |
| 1 | WHT | P9-2 | 18 AWG | GXL | RL502 (30) |
| 2 | WHT | P10 | 18 AWG | GXL | X500 (1) |





Figure 7-60. Boom Sensor Harness

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| SN02 CAPACITY LENGTH NO 1 | | | | | |
|---------------------------|------------|------------|--------|--------|---------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL-BLK | 1 | 18 AWG | TFFN | X10 (1) |
| 2 | ORG-BLK | 2 | 18 AWG | TFFN | X10 (2) |
| 3 | BRN-BLK | 3 | 18 AWG | TFFN | X10 (3) |

| SN571 CAPACITY LENGTH NC 2 | | | | | |
|----------------------------|------------|------------|--------|--------|---------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLU-RED | 4 | 18 AWG | TFFN | X10 (4) |
| 2 | BLU-RED | 5 | 18 AWG | TFFN | X10 (5) |
| 3 | BLU-BLK | 6 | 18 AWG | TFFN | X10 (6) |

| X10 FULL EXTENSION | | | | | |
|--------------------|------------|------------|--------|--------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL-BLK | 1 | 18 AWG | TFFN | SN02 (1) |
| 2 | ORG-BLK | 2 | 18 AWG | TFFN | SN02 (2) |
| 3 | BRN-BLK | 3 | 18 AWG | TFFN | SN02 (3) |
| 4 | BLU-RED | 4 | 18 AWG | TFFN | SN571 (1) |
| 5 | BLK-RED | 5 | 18 AWG | TFFN | SN571 (2) |
| 6 | BLU-BLK | 6 | 18 AWG | TFFN | SN571 (3) |



Go to Discount-Equipment.com to order your parts

1001205923-C
MAF23240C


Figure 7-61. Main Lift Harness

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| HV252 BOOM LIFT DOWN | | | | | |
|---------------------------------|-------------------|-------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 77-1 BOOM LIFT DN | 18 AWG | GXL | X745B (1) |
| 2 | WHT | 50-4-1 LIFT RTN | 18 AWG | GXL | X745B (3) |

| HV253 BOOM LIFT DN ENBL/AUX | | | | | |
|--|-------------------|----------------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 77-2 BOOM LIFT DN ENBL/AUX | 18 AWG | GXL | X745B (2) |
| 2 | WHT | 50-5 LIFT DN ENBL/AUX RTN | 18 AWG | GXL | X745B (4) |

| X745B TO MAIN VALVE HARNESS | | | | | |
|--|-------------------|----------------------------|--------------|---------------|-----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 77-1 BOOM LIFT DN | 18 AWG | GXL | HV252 (1) |
| 2 | WHT | 77-2 BOOM LIFT DN ENBL/AUX | 18 AWG | GXL | HV253 (1) |
| 3 | WHT | 50-4-1 LIFT RTN | 18 AWG | GXL | HV252 (2) |
| 4 | WHT | 50-5 LIFT DN ENBL/AUX RTN | 18 AWG | GXL | HV253 (2) |



1001175244-D
MAF15940D

Figure 7-62. LSS Harness

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X511 CAN SHIELD | | | | | |
|-----------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | SLR | SHLD | 22 AWG | SHLD | X510 (1) |

| X491 LSS CAN LO | | | | | |
|-----------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLU | CAN_LO | 24 AWG | GXL | X510 (5) |

| X489 LSS POWER | | | | | |
|----------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | RED | POWER | 22 AWG | GXL | X510 (2) |

| X490 LSS CAN HI | | | | | |
|-----------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | CAN_HI | 24 AWG | GXL | X510 (4) |

| X494 LSS GROUND | | | | | |
|-----------------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | V- | 22 AWG | GXL | X510 (3) |

| X510 | | | | | |
|----------|------------|------------|--------|--------|----------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 2 | RED | POWER | 22 AWG | GXL | X489 (1) |
| 4 | WHT | CAN_HI | 24 AWG | GXL | X490 (1) |
| 5 | BLU | CAN_LO | 24 AWG | GXL | X491 (1) |
| 3 | BLK | V- | 22 AWG | GXL | X494 (1) |
| 1 | SLR | SHLD | 22 AWG | SHLD | X511 (1) |




Figure 7-63. Crawler Main Valve Harness - Sheet 1 of 4

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS


| X745/A TO LIFT DOWN HARN | | | | | |
|-----------------------------|------------|--------------------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 77-1 BOOM LIFT DN | 18 AWG | GXL | C069-J2 (22) |
| 2 | WHT | 77-2 BOOM LIFT DN ENBL/ AUX | 18 AWG | GXL | C069-J2 (21) |
| 3 | WHT | 50-4-1 LIFT RTN | 18 AWG | GXL | S387 (1) |
| 4 | WHT | 50-5 LIFT DN ENBL/AUX RTN | 18 AWG | GXL | C069-J3 (5) |
| | | | | | |

| HV397 RIGHT TRACK DRIVE | | | | | |
|----------------------------|------------|------------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | WHT | 27-2 DRIVE FWD | 18 AWG | GXL | C069-J2 (19) |
| B | WHT | 50-6-2 RHT TRK DRV RTN | 18 AWG | GXL | S373 (1) |
| C | WHT | 50-6-1 RHT TRK DRV RTN | 18 AWG | GXL | S373 (1) |
| D | WHT | 28-2 DRIVE REV | 18 AWG | GXL | C069-J2 (8) |

| SN377 FUEL SENSOR | | | | | |
|----------------------|------------|------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 16-16 FUEL SNSR- | 18 AWG | GXL | C069-J2 (6) |

| SN376 FUEL SENSOR | | | | | |
|----------------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 104-0 FUEL SENSOR | 18 AWG | GXL | C069-J2 (25) |

| S373 | | | | | |
|----------|------------|------------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 50-6-1 RHT TRK DRV RTN | 18 AWG | GXL | HV397 (C) |
| 1 | WHT | 50-6-2 RHT TRK DRV RTN | 18 AWG | GXL | HV397 (B) |
| 2 | WHT | 50-6 RHT TRK DRV RTN | 18 AWG | GXL | C069-J3 (2) |



1001239613-B
MAF26080B

Figure 7-64. Crawler Main Valve Harness - Sheet 2 of 4

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| C069-J2 GRAY | | | | | |
|-----------------|------------|--------------------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | | | | | |
| 2 | | | | | |
| 3 | WHT | 90-1 HI PRS DUMP | 18 AWG | GXL | X701/B (1) |
| 4 | WHT | 90-3 BYPASS DUMP | 18 AWG | GXL | HV393 (1) |
| 5 | WHT | 88-1-1 LEVEL UP | 18 AWG | GXL | R001 (2) |
| 6 | WHT | 16-16 FUEL SNSR- | 18 AWG | GXL | SN377 (1) |
| 7 | WHT | 89-1-1 LEVEL DOWN | 18 AWG | GXL | R002 (2) |
| 8 | WHT | 28-2 DRIVE REV | 18 AWG | GXL | HV397 (D) |
| 9 | WHT | 78-1 BOOM TELE IN | 18 AWG | GXL | HV362 (1) |
| 10 | | | | | |
| 11 | WHT | 76-1 BOOM LIFT UP | 18 AWG | GXL | HV366 (1) |
| 12 | | | | | |
| 13 | WHT | 90-5 MAIN DUMP | 18 AWG | GXL | HV361 (1) |
| 14 | | | | | |
| 15 | | | | | |
| 16 | | | | | |
| 17 | | | | | |
| 18 | | | | | |
| 19 | WHT | 27-2 DRIVE FWD | 18 AWG | GXL | HV397 (A) |
| 20 | WHT | 79-1 BOOM TELE OUT | 18 AWG | GXL | HV363 (1) |
| 21 | WHT | 77-2 BOOM LIFT DN ENBL/ AUX | 18 AWG | GXL | X745/A (2) |
| 22 | WHT | 77-1 BOOM LIFT DN | 18 AWG | GXL | X745/A (1) |
| 23 | WHT | 90-2 LOW PRS DUMP | 18 AWG | GXL | X701/B (2) |
| 24 | WHT | 16-10-2 CONFIG - | 18 AWG | GXL | S394 (2) |
| 25 | WHT | 104-0 FUEL SENSOR | 18 AWG | GXL | SN376 (1) |
| 26 | WHT | 500-0 HEAD&TAIL LT | 18 AWG | GXL | X171/A (2) |
| 27 | WHT | 94-0 ALARM SIGNAL | 18 AWG | GXL | AH370 (B) |
| 28 | | | | | |
| 29 | BLK | 16-10 ALARM/CONFIG- | 18 AWG | GXL | S394 (2) |
| 30 | BLK | 16-14 DUMP- | 18 AWG | GXL | S383 (2) |
| 31 | WHT | 90-4 BOOM TELE DUMP | 18 AWG | GXL | HV382 (1) |
| 32 | | | | | |
| 33 | | | | | |
| 34 | WHT | 70-1 SWG LEFT | 18 AWG | GXL | HV368 (1) |
| 35 | WHT | 71-1 SWG RHT | 18 AWG | GXL | HV367 (1) |

| C069-J3 BLACK | | | | | |
|------------------|------------|---------------------------|--------|--------|------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 50-1 DRV RTN | 18 AWG | GXL | X171/A (1) |
| 2 | WHT | 50-6 RHT TRK DRV RTN | 18 AWG | GXL | S373 (2) |
| 3 | BLK | 16-12 SERVICE CABLE- | 18 AWG | GXL | X266-B (3) |
| 4 | WHT | 50-2 SWG RTN | 18 AWG | GXL | S371 (2) |
| 5 | WHT | 50-5 LIFT DN ENBL/AUX RTN | 18 AWG | GXL | X745/A (4) |
| 6 | WHT | 50-5 BOOM TELE RTN | 18 AWG | GXL | S369 (2) |
| 7 | YEL | 14-5 ALARM/CRIB+ | 18 AWG | GXL | S395 (2) |
| 8 | WHT | 95-0 SERVICE CABLE | 18 AWG | GXL | X266-B (2) |
| 9 | WHT | 506-0 CRIBBING | 18 AWG | GXL | X171/A (3) |
| 10 | WHT | 54-7 NO CAPCITY LNTH 18 | 18 AWG | GXL | X171/A (5) |
| 11 | | | | | |
| 12 | | | | | |
| 13 | | | | | |
| 14 | WHT | 50-4 LIFT RTN | 18 AWG | GXL | S387 (2) |

| X266-B SERVICE CABLE | | | | | |
|-------------------------|------------|----------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-11 SERVICE CABLE+ | 18 AWG | GXL | X171/A (4) |
| 2 | WHT | 95-0 SERVICE CABLE | 18 AWG | GXL | C069-J3 (8) |
| 3 | BLK | 16-12 SERVICE CABLE- | 18 AWG | GXL | C069-J3 (3) |

| S394 | | | | | |
|----------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 16-10-1 ALARM- | 18 AWG | GXL | AH370 (C) |
| 2 | BLK | 16-10 ALARM/CONFIG- | 18 AWG | GXL | C069-J2 (29) |
| 2 | BLK | 16-10-2 CONFIG - | 18 AWG | GXL | C069-J2 (24) |

| AH370 ALARM | | | | | |
|----------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | YEL | 14-5-1 ALARM+ | 18 AWG | GXL | S395 (1) |
| B | WHT | 94-0 ALARM SIGNAL | 18 AWG | GXL | C069-J2 (27) |
| C | BLK | 16-10-1 ALARM- | 18 AWG | GXL | S394 (1) |

| X701/B TO TURNTABLE HARN | | | | | |
|-----------------------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 90-1 HI PRS DUMP | 18 AWG | GXL | C069-J2 (3) |
| 2 | WHT | 90-2 LOW PRS DUMP | 18 AWG | GXL | C069-J2 (23) |
| 3 | WHT | 88-1-1 LEVEL UP | 18 AWG | GXL | R001 (1) |
| 4 | WHT | 89-1-1 LEVEL DOWN | 18 AWG | GXL | R002 (1) |

| R002 | | | | | |
|----------|------------|-------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 89-1-1 LEVEL DOWN | 18 AWG | GXL | X701/B (4) |
| 2 | WHT | 89-1-1 LEVEL DOWN | 18 AWG | GXL | C069-J2 (7) |

| R001 | | | | | |
|----------|------------|-----------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 89-1-1 LEVEL UP | 18 AWG | GXL | X701/B (3) |
| 2 | WHT | 89-1-1 LEVEL UP | 18 AWG | GXL | C069-J2 (5) |


SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| X171/A | | | | | |
|-------------------|------------|----------------------|--------|--------|--------------|
| TO TURNTABLE HARN | | | | | |
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 50-1 DRV RTN | 18 AWG | GXL | C069-J3 (1) |
| 2 | WHT | 500-0 HEAD&TAIL LT | 18 AWG | GXL | C069-J2 (26) |
| 3 | WHT | 506-0 CRIBBING | 18 AWG | GXL | C069-J3 (9) |
| 4 | YEL | 14-11 SERVICE CABLE+ | 18 AWG | GXL | X266-B (1) |
| 5 | WHT | 54-7 NO CAPCITY LNTH | 18 AWG | GXL | C069-J3 (10) |
| 6 | YEL | 14-5-2 CRIB+ | 18 AWG | GXL | S395 (1) |

| S387 | | | | | |
|----------|------------|-----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 50-4-1 LIFT RTN | 18 AWG | GXL | X745/A (3) |
| 1 | WHT | 50-4-2 LIFT RTN | 18 AWG | GXL | HV366 (2) |
| 2 | WHT | 50-4 LIFT RTN | 18 AWG | GXL | C069-J3 (14) |

| S395 | | | | | |
|----------|------------|------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | YEL | 14-5-1 ALARM+ | 18 AWG | GXL | AH370 (A) |
| 1 | YEL | 14-5-2 CRIB+ | 18 AWG | GXL | X171/A (6) |
| 2 | YEL | 14-5 ALARM/CRIB+ | 18 AWG | GXL | C069-J3 (7) |

Go to Discount-Equipment.com to order your parts



Go to Discount-Equipment.com to order your parts

1001239613-B
MAF26110B

Figure 7-65. Crawler Main Valve Harness - Sheet 3 of 4

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| HV393 BYPASS DUMP | | | | | |
|----------------------|------------|------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 90-3 BYPASS DUMP | 18 AWG | GXL | C069-J2 (4) |
| 2 | BLK | 16-14-1 DUMP | 18 AWG | GXL | S383 (1) |

| HV363 BOOM TELE OUT | | | | | |
|------------------------|------------|----------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 79-1 BOOM TELE OUT | 18 AWG | GXL | C069-J2 (20) |
| 2 | WHT | 50-5-1 BOOM TELE RTN | 18 AWG | GXL | S369 (1) |

| HV361 MAIN DUMP | | | | | |
|--------------------|------------|----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 90-5 MAIN DUMP | 18 AWG | GXL | C069-J2 (13) |
| 2 | BLK | 16-14-3 DUMP- | 18 AWG | GXL | S383 (1) |

| S369 | | | | | |
|----------|------------|----------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 50-5-1 BOOM TELE RTN | 18 AWG | GXL | HV363 (2) |
| 1 | WHT | 50-5-2 BOOM TELE RTN | 18 AWG | GXL | HV362 (2) |
| 2 | WHT | 50-5 BOOM TELE RTN | 18 AWG | GXL | C069-J3 (6) |

| HV367 SWING RIGHT | | | | | |
|----------------------|------------|----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 71-1 SWG RHT | 18 AWG | GXL | C069-J2 (35) |
| 2 | WHT | 50-2-1 SWG RTN | 18 AWG | GXL | S371 (1) |

| S371 | | | | | |
|----------|------------|----------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 50-2-1 SWG RTN | 18 AWG | GXL | HV367 (2) |
| 1 | WHT | 50-2-2 SWG RTN | 18 AWG | GXL | HV368 (2) |
| 2 | WHT | 50-2 SWG RTN | 18 AWG | GXL | C069-J3 (4) |


| HV366 BOOM LIFT UP | | | | | |
|-----------------------|------------|-------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 76-1 BOOM LIFT UP | 18 AWG | GXL | C069-J2 (11) |
| 2 | WHT | 50-4-2 LIFT RTN | 18 AWG | GXL | S387 (1) |

| S383 | | | | | |
|----------|------------|---------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | BLK | 16-14-1 DUMP- | 18 AWG | GXL | HV393 (2) |
| 1 | BLK | 16-14-2 DUMP- | 18 AWG | GXL | HV382 (2) |
| 1 | BLK | 16-14-3 DUMP- | 18 AWG | GXL | HV361 (2) |
| 2 | BLK | 16-14 DUMP- | 18 AWG | GXL | C069-J2 (30) |

| HV368 SWING LEFT | | | | | |
|---------------------|------------|----------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 70-1 SWG LEFT | 18 AWG | GXL | C069-J2 (34) |
| 2 | WHT | 50-2-2 SWG RTN | 18 AWG | GXL | S371 (1) |

| HV362 BOOM TELE IN | | | | | |
|-----------------------|------------|----------------------|--------|--------|-------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 78-1 BOOM TELE IN | 18 AWG | GXL | C069-J2 (9) |
| 2 | WHT | 50-5-2 BOOM TELE RTN | 18 AWG | GXL | S369 (1) |

| HV382 TELESCOPE DUMP | | | | | |
|-------------------------|------------|---------------------|--------|--------|--------------|
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| 1 | WHT | 90-4 BOOM TELE DUMP | 18 AWG | GXL | C069-J2 (31) |
| 2 | BLK | 16-14-2 DUMP- | 18 AWG | GXL | S383 (1) |



1001239613-B
MAF26120B

Figure 7-66. Crawler Main Valve Harness - Sheet 4 of 4




Figure 7-67. Crawler Turntable Adapter Harness

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS

| HV399 | | | | | |
|------------------|------------|----------------|--------|--------|------------|
| LEFT TRACK DRIVE | | | | | |
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | WHT | 27-1 DRV FWD | 18 AWG | GXL | HV159B (1) |
| B | WHT | 50-1-2 DRV RTN | 18 AWG | GXL | HV159B (2) |
| C | WHT | 50-1-1 DRV RTN | 18 AWG | GXL | HV160B (2) |
| D | WHT | 28-1 DRV REV | 18 AWG | GXL | HV160B (1) |

| HV160B | | | | | |
|-----------------|------------|----------------|--------|--------|-----------|
| TO HYD VLV HARN | | | | | |
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | WHT | 28-1 DRV REV | 18 AWG | GXL | HV399 (D) |
| B | WHT | 50-1-1 DRV RTN | 18 AWG | GXL | HV399 (C) |

| HV160B | | | | | |
|-----------------|------------|----------------|--------|--------|-----------|
| TO HYD VLV HARN | | | | | |
| CONN POS | WIRE COLOR | WIRE LABEL | GAUGE | JACKET | TO |
| A | WHT | 27-1 DRV FWD | 18 AWG | GXL | HV399 (A) |
| B | WHT | 50-1-2 DRV RTN | 18 AWG | GXL | HV399 (B) |

Go to Discount-Equipment.com to order your parts

Go to Discount-Equipment.com to order your parts

7.10 ELECTRICAL SCHEMATICS

SHEET 2: PLATFORM

Platform Box Harness

SHEET 3: PLATFORM AND BOOM COMPONENTS

LSS Harness 450/400
Boom Control Cable With Jib, TT
Tele in Prox Switches
Cable, Boom Sensor Cable Harness,
Boom Sensor Harness,
Boom Sensor Cable,
Boom Angle Sensor Cable

SHEET 4: CHASSIS, TURNTABLE

Turntable Harness
UGM Main Ground

SHEET 5: MAIN VALVE/GROUND CONTROLS

Ground Control Panel Harness
Platform Valve With Jib
Lift Cylinder Harness

SHEET 6: ENGINE SCHEMATIC DEUTZ - T4I

Deutz T4i Engine Harness
T4i Eng Pos, T4i Eng Neg
Pos Battery, Aux To Aux

SHEET 7: ENGINE SCHEMATIC DEUTZ - T4F

Deutz T4F Engine Harness
T4F Eng Pos, T4F Eng Neg

SHEET 8: NOT APPLICABLE

SHEET 9: OPTIONS

Chassis Head And Tail Lights
Chassis Work Lights, Clear Sky
Skyguard, GEN 2 Platform Interface

SHEET 10: NOT APPLICABLE

SHEET 11: CRAWLER

Crawler Main Valve Harness
Crawler Turntable Adapter

SHEET 12: GENERATOR HARNESS

SHEET 13: NOT APPLICABLE

SHEET 14: NOT APPLICABLE

SHEET 15: NOT APPLICABLE

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-68. Electrical Schematic - Sheet 2 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-69. Electrical Schematic - Sheet 3 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-70. Electrical Schematic - Sheet 4 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-71. Electrical Schematic - Sheet 5 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-72. Electrical Schematic - Sheet 6 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-73. Electrical Schematic - Sheet 7 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-74. Electrical Schematic - Sheet 8 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-75. Electrical Schematic - Sheet 9 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS





Figure 7-76. Electrical Schematic - Sheet 10 of 19



SHEET 6

1001238404-D

MAF28190D

Figure 7-77. Electrical Schematic - Sheet 11 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-78. Electrical Schematic - Sheet 12 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS




Figure 7-79. Electrical Schematic - Sheet 13 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS





Figure 7-80. Electrical Schematic - Sheet 14 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS



SHEET 9

1001238404-D

Figure 7-81. Electrical Schematic - Sheet 15 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS





Figure 7-82. Electrical Schematic - Sheet16 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS



SHEET 11

1001238404-D

MAF28220D

Figure 7-83. Electrical Schematic - Sheet 17 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS





Figure 7-84. Electrical Schematic - Sheet 18 of 19

SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS



SHEET 12

1001238404-D

MAF28230D

Figure 7-85. Electrical Schematic - Sheet 19 of 19

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter the information below to search our manual library for parts.

* Brand:

* Model:

* Serial:

* Part Number:

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the information below to request help finding a part or manual.

Manufacturer:

Model:

Description:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

JLG[®]

An Oshkosh Corporation Company

**Discount
Equipment**

www.Discount-Equipment.com

Go to Discount-Equipment.com to order your parts