



An Oshkosh Corporation Company



www.Discount-Equipment.com

Service and Maintenance Manual

Model

E450AJ

PVC 2001

31215013


November 26, 2019 - Rev A

ANSI

CE



AS/NZS



PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your information to search for manuals and parts.

* Brand:

* Model:

* Serial:

* Part Number:

SEARCH

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information:

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Part Name:

Part Description:

Part Location:

Part Condition:

Part Status:

Part Price:

Part Weight:

Part Dimensions:

Part Material:

Part Color:

Part Finish:

Part Notes:

Submit

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on once of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION A. INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS

A GENERAL

This section contains the general safety precautions which must be observed during maintenance of the Mobile Elevating Work Platform (MEWP). It is of utmost importance that maintenance personnel pay strict attention to these warnings and precautions to avoid possible injury to themselves or others, or damage to the equipment. A maintenance program must be followed to ensure that the machine is safe to operate.

⚠ WARNING

MODIFICATION OR ALTERATION OF AN MOBILE ELEVATING WORK PLATFORM SHALL BE MADE ONLY WITH WRITTEN PERMISSION FROM THE MANUFACTURER.

The specific precautions to be observed during maintenance are inserted at the appropriate point in the manual. These precautions are, for the most part, those that apply when servicing hydraulic and larger machine component parts.

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

⚠ WARNING

SINCE THE MACHINE MANUFACTURER HAS NO DIRECT CONTROL OVER THE FIELD INSPECTION AND MAINTENANCE, SAFETY IN THIS AREA RESPONSIBILITY OF THE OWNER/OPERATOR.

B HYDRAULIC SYSTEM SAFETY

It should be noted that the machines hydraulic systems operate at extremely high potentially dangerous pressures. Every effort should be made to relieve any system pressure prior to disconnecting or removing any portion of the system. Do not use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks. Wear gloves to help protect hands from spraying fluid.



C MAINTENANCE

⚠ WARNING

FAILURE TO COMPLY WITH SAFETY PRECAUTIONS LISTED IN THIS SECTION COULD RESULT IN MACHINE DAMAGE, PERSONNEL INJURY OR DEATH AND IS A SAFETY VIOLATION.

- USE ONLY REPLACEMENT PARTS OR COMPONENTS THAT ARE APPROVED BY JLG. TO BE CONSIDERED APPROVED, REPLACEMENT PARTS OR COMPONENTS MUST BE IDENTICAL OR EQUIVALENT TO ORIGINAL PARTS OR COMPONENTS.
- NO SMOKING IS MANDATORY. NEVER REFUEL DURING ELECTRICAL STORMS. ENSURE THAT FUEL CAP IS CLOSED AND SECURE AT ALL OTHER TIMES.
- REMOVE ALL RINGS, WATCHES AND JEWELRY WHEN PERFORMING ANY MAINTENANCE.
- DO NOT WEAR LONG HAIR UNRESTRAINED, OR LOOSE-FITTING CLOTHING AND NECKTIES WHICH ARE APT TO BECOME CAUGHT ON OR ENTANGLED IN EQUIPMENT.
- OBSERVE AND OBEY ALL WARNINGS AND CAUTIONS ON MACHINE AND IN SERVICE MANUAL.
- KEEP OIL, GREASE, WATER, ETC. WIPED FROM STANDING SURFACES AND HAND HOLDS.
- USE CAUTION WHEN CHECKING A HOT, PRESSURIZED COOLANT SYSTEM.
- NEVER WORK UNDER AN ELEVATED BOOM UNTIL BOOM HAS BEEN SAFELY RESTRAINED FROM ANY MOVEMENT BY BLOCKING OR OVERHEAD SLING, OR BOOM SAFETY PROP HAS BEEN ENGAGED.
- BEFORE MAKING ADJUSTMENTS, LUBRICATING OR PERFORMING ANY OTHER MAINTENANCE, SHUT OFF ALL POWER CONTROLS.
- BATTERY SHOULD ALWAYS BE DISCONNECTED DURING REPLACEMENT OF ELECTRICAL COMPONENTS.
- KEEP ALL SUPPORT EQUIPMENT AND ATTACHMENTS STOWED IN THEIR PROPER PLACE.
- USE ONLY APPROVED, NONFLAMMABLE CLEANING SOLVENTS.

REVISION LOG

Original Issue

A - November 26, 2019

Go to Discount-Equipment.com to order your parts

SECTION NO.	TITLE	PAGE NO.
SECTION A - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS		
A	General	A-1
B	Hydraulic System Safety	A-1
C	Maintenance	A-1
SECTION 1 - SPECIFICATIONS		
1.1	Operating Specifications	1-1
1.2	Tires	1-1
1.3	Capacities	1-1
1.4	Dimensional Data	1-1
1.5	Torque Specifications	1-2
1.6	Lubrication Specifications	1-2
	Hydraulic Oil	1-2
1.7	Critical Stability Weights	1-3
1.8	Major Component Weights	1-3
1.9	Serial Number Locations	1-3
1.10	Maintenance and Lubrication	1-5
1.11	Threadlocking Compound	1-8
1.12	Torque Charts	1-9
	SAE Fastener Torque Chart	1-9
	SAE Fastener Torque Chart (Continued)	1-10
	SAE Fastener Torque Chart (Continued)	1-11
	SAE Fastener Torque Chart (Continued)	1-12
	SAE Fastener Torque Chart (Continued)	1-13
	SAE Fastener Torque Chart (Continued)	1-14
	Metric Fastener Torque Chart	1-15
	Metric Fastener Torque Chart (Continued)	1-16
	Metric Fastener Torque Chart (Continued)	1-17
	Metric Fastener Torque Chart (Continued)	1-18
SECTION 2 - GENERAL		
2.1	Machine Preparation, Inspection, and Maintenance	2-1
	General	2-1
	Preparation, Inspection, and Maintenance	2-1
	Pre-Start Inspection	2-1
	Pre-Delivery Inspection and Frequent Inspection	2-1
	Annual Machine Inspection	2-1
	Preventative Maintenance	2-1
2.2	Service and Guidelines	2-2
	General	2-2
	Safety and Workmanship	2-2
	Cleanliness	2-2
	Components Removal and Installation	2-2
	Component Disassembly and Assembly	2-3
	Pressure-Fit Parts	2-3
	Bearings	2-3
	Gaskets	2-3
	Bolt Usage And Torque Application	2-3
	Hydraulic Lines and Electrical Wiring	2-3
	Hydraulic System	2-3
	Lubrication	2-3
	Battery	2-3
	Lubrication and Servicing	2-3

TABLE OF CONTENTS

SECTION NO.	TITLE	PAGE NO.
2.3	Lubrication and Information	2-4
	Hydraulic System	2-4
	Hydraulic Oil	2-4
	Changing Hydraulic Oil	2-4
	Lubrication Specifications	2-4
2.4	Cylinder Drift.....	2-5
	Theory	2-5
	Cylinder Leakage Test	2-5
	Cylinder Thermal Drift	2-5
2.5	Pins and Composite Bearing Repair Guidelines	2-6
2.6	Welding on JLG Equipment.....	2-6
	Do the Following When Welding on JLG Equipment	2-6
	Do NOT Do the Following When Welding on JLG Equipment.....	2-6
SECTION 3 - CHASSIS & TURNTABLE		
3.1	Tires & Wheels.....	3-1
	Tire Damage	3-1
	Tire Replacement.....	3-1
	Wheel Replacement	3-1
	Wheel Installation	3-1
3.2	Spindle	3-2
	Setting Wheel Bearing End Play	3-2
	Specifications	3-2
	Checking.....	3-2
	Greasing Requirements.....	3-2
3.3	Tilt Module.....	3-5
3.4	Speed Sensor	3-6
3.5	Drive Hub	3-13
	Roll and Leak Testing	3-13
	Tightening and Torquing Bolts.....	3-13
	Main Disassembly	3-14
	Output Carrier Disassembly.....	3-16
	Input Carrier Disassembly.....	3-18
	Hub-spindle Disassembly.....	3-19
	Cover Disassembly	3-20
	Input Carrier Assembly	3-21
	Output Planet Gear Assembly.....	3-21
	Output Carrier Assembly.....	3-22
	Hub-spindle Assembly.....	3-22
	Cover Assembly	3-23
	Main Assembly	3-23
3.6	Drive Motor	3-26
	Removal	3-26
	Disassembly.....	3-26
	Inspection.....	3-26
	Assembly	3-27
	Installation	3-27
3.7	Swing Bearing	3-29
	Turntable Bearing Mounting Bolt Condition Check	3-29
	Wear Tolerance.....	3-30
	Replacement of Swing Bearing.....	3-31
	Swing Bearing Torque Value	3-34
	Checking Worm Gear End Play	3-34
	Adjusting End Play	3-34

SECTION NO.	TITLE	PAGE NO.
3.8	Swing Motor	3-36
	Preparation Before Disassembly	3-39
	Disassembly and Inspection	3-39
	Assembly	3-46
	One Piece Stator Construction	3-52
	Two Piece Stator Construction	3-53
	Final Checks	3-53
3.9	Battery Maintenance and Charging	3-54
	Battery Maintenance, Quarterly	3-54
	Optional On Board Generator	3-54
	Battery Charging (On Board Charger)	3-54
3.10	Battery Charger	3-56
	Operating Instructions	3-56
	Maintenance Instructions	3-57
	Battery Charger Fault Codes	3-57
	Excessive Battery Watering Requirements or Strong Sulphur (Rotten Egg) Smell	3-60
	Checking/Changing the Battery Charger Algorithm	3-60
3.11	Generator	3-61
	Engine	3-61
	Alternator	3-61
	Dynamo and Dynamo Voltage Regulator	3-61
	Dynamo Output Fuse	3-61
	Control Fuse	3-61
	Start Battery	3-63
	Engine Starter	3-63
	Start Control Relay	3-63
	Fuel Control Relay	3-64
	Glow Plug Control Relay	3-64
	Glow Plug	3-64
	Fuel Pump	3-65
	Fuel Solenoid	3-65
	Engine Low Oil Pressure Switch	3-65
	Engine Oil Temperature Sensor	3-65
	Alternator Output Current Sensor	3-66
	Engine Speed Sensor	3-66
	RBS Engine/Generator Controller	3-66
	Warnings and Safety Precautions	3-67
	System Controls	3-67
	System Status and Performance Monitoring	3-67
	System Settings	3-67
	RBS Start	3-68
	RBS shutdown	3-68
	RBS Alarms and Flash Codes	3-69
	Resetting the RBS Controller	3-69
	Maintenance Schedule	3-69
	Troubleshooting	3-70
	APU Engine Start Battery Boosting	3-71
3.12	Supplementary Fuse for APU	3-72
	Tools And Material	3-72
	Procedure	3-72

TABLE OF CONTENTS

SECTION NO.	TITLE	PAGE NO.
SECTION 4 - BOOM & PLATFORM		
4.1	Platform	4-1
	Support Removal	4-1
	Support Installation	4-2
4.2	Rotator and Platform Level Cylinder Removal	4-4
	Removal	4-4
	Installation	4-4
4.3	Main Boom Powertrack	4-5
	Removal	4-5
	Installation	4-5
4.4	Boom Maintenance	4-6
	Removal	4-6
	Disassembly	4-7
	Inspection	4-7
	Assembly	4-7
	Installation	4-8
4.5	Wear Pads	4-9
4.6	Boom Limit Switches	4-9
4.7	Boom Cleanliness Guidelines	4-9
4.8	Articulating Jib Boom	4-11
	Removal	4-11
	Disassembly	4-11
	Inspection	4-11
	Assembly	4-11
4.9	Boom Synchronizing Procedure	4-12
4.10	Foot Switch Adjustment	4-12
4.11	Rotary actuator	4-13
	Theory Of Operation	4-13
	Tools Required for Assembly/Disassembly	4-13
	Disassembly	4-16
	Inspection	4-19
	Assembly	4-20
	Installing Counterbalance Valve	4-24
	Greasing Thrust Washers	4-25
	Testing the Actuator	4-25
	Installation and Bleeding	4-26
	Troubleshooting	4-27
4.12	Powertrack Maintenance	4-28
	Removing a Link	4-28
	Installing a New Link	4-31
	Replacing Fixed End Brackets	4-36
	Replacing Moving End Brackets	4-38
4.13	Skyguard	4-40
	Operation	4-40
	Function Test	4-40
	Diagnostics & Troubleshooting	4-41

SECTION NO.	TITLE	PAGE NO.
SECTION 5 - BASIC HYDRAULIC INFORMATION & SCHEMATICS		
5.1	Lubricating O-Rings in the Hydraulic System	5-1
	Cup and Brush	5-1
	Dip Method	5-2
	Spray Method	5-2
	Brush-on Method	5-2
5.2	Hydraulic Connection Assembly and Torque Specification	5-3
	Tapered Thread Types	5-3
	Straight Thread Types, Tube and Hose Connections	5-3
	Straight Thread Types, Port Connections	5-4
	Flange Connection Types	5-4
	Tightening Methods	5-4
	Assembly And Torque Specifications	5-5
	Assembly Instructions for American Standard Pipe Thread Tapered (NPTF) Connections	5-6
	Assembly Instructions for British Standard Pipe Thread Tapered (BSPT) Connections	5-7
	Assembly Instructions for 37° (JIC) Flare Fittings	5-8
	Assembly Instructions for 45° SAE Flare Fittings	5-12
	Assembly Instructions for O-Ring Face Seal (ORFS) Fittings	5-14
	Assembly Instructions for DIN 24° Flare Bite Type Fittings (MBTL and MBTS)	5-16
	Assembly Instructions for Bulkhead (BH) Fittings	5-18
	Assembly Instructions for O-Ring Boss (ORB) Fittings	5-22
	Assembly Instructions for Adjustable Port End Metric (MFF) Fittings	5-30
	Assembly Instructions for Metric ISO 6149 (MPP) Port Assembly Stud Ends	5-38
	Assembly instructions for Adjustable Port End (BSPP) Fittings	5-40
	Assembly Instructions for Flange Connections: (FL61 and FL62)	5-48
	Double Wrench Method	5-51
	FFWR and TFFT Methods	5-52
	Adjustable Stud End Assembly	5-52
	O-ring Installation (Replacement)	5-53
5.3	Hydraulic Cylinders	5-54
	Platform Level Cylinder	5-54
	Jib Lift Cylinder	5-60
	Lower Lift Cylinder	5-66
	Mid Lift Cylinder	5-73
	Upper Lift Cylinder	5-80
	Master Cylinder	5-87
	Steer Cylinder	5-93
	Telescope Cylinder	5-98
5.4	Cylinder Removal And Installation	5-106
	Main Boom Lift Cylinder Removal	5-106
	Main Boom Lift Cylinder Installation	5-106
	Mid Boom Lift Cylinder Removal	5-107
	Mid Boom Lift Cylinder Installation	5-107
	Lower Boom Lift Cylinder Removal	5-108
	Lower Boom Lift Cylinder Installation	5-108
	Main Boom Telescope Cylinder Removal	5-109
	Main Boom Telescope Cylinder Installation	5-109
5.5	Lower Lift Cylinder Bleeding Procedure	5-110

TABLE OF CONTENTS

SECTION NO.	TITLE	PAGE NO.
5.6	Pressure Setting Procedures	5-110
	Main Relief	5-110
	Main Lift Down Relief	5-110
	Lower Lift Down Relief	5-110
	Telescope Relief	5-110
	Platform Level Up Relief	5-111
	Platform Level Down Relief	5-111
	Steer Relief	5-112
	Jib Lift (Up and Down) Relief	5-112
	Releveling Valve Relief	5-112
5.7	Hydraulic Schematic	5-122
SECTION 6 - JLG CONTROL SYSTEM		
6.1	JLG Control System Analyzer Kit Instructions	6-1
	Introduction	6-1
	To Connect the JLG Control System Analyzer	6-2
	Using the Analyzer	6-2
	Changing the Access Level of the Hand Held Analyzer	6-3
	Adjusting Parameters Using the Hand Held Analyzer	6-4
	Machine Setup	6-5
	Level Vehicle Description	6-5
6.2	Machine Personality Settings	6-13
6.3	Machine Orientation When performing test	6-22
	Test Notes	6-23
6.4	Function Speed	6-23
	Help Descriptions and Fault Flash Codes	6-34
	Analyzer Diagnostics Menu Structure	6-40
	System Self Test	6-46
6.5	Calibrating Steer	6-51
6.6	Calibrating Tilt Sensor	6-53
6.7	Calibrating Load Sensing	6-55
6.8	LSS System	6-58
	Diagnostic Menu	6-59
	Calibration Procedure	6-60
	Testing & Evaluation	6-65
	Troubleshooting	6-66
6.9	Resetting The MSSO System	6-67
SECTION 7 - BASIC ELECTRICAL INFORMATION & ELECTRICAL SCHEMATICS		
7.1	General	7-1
7.2	Multimeter Basics	7-1
	Grounding	7-1
	Backprobing	7-1
	Min/Max	7-1
	Polarity	7-1
	Scale	7-1
	Voltage Measurement	7-1
	Resistance Measurement	7-2
	Continuity Measurement	7-2
	Current Measurement	7-3
7.3	Checking Switches	7-3
	Basic Check	7-3
	Limit Switches	7-3
	Automatic Switches	7-4
	Switch Wiring - Low Side, High Side	7-4

SECTION NO.	TITLE	PAGE NO.
7.4	Applying Silicone Dielectric Compound to Electrical Connections.....	7-4
7.5	Dielectric Grease Application	7-5
	Installation.....	7-5
	AMP Mate-N-Lok.....	7-5
	AMP Faston.....	7-5
	AMP Micro-Fit.....	7-5
	AMP Mini Fit Jr.....	7-6
	Mini Fit Sr.....	7-6
	DIN Connectors.....	7-6
	Exceptions.....	7-6
7.6	AMP Connector	7-7
	Applying Silicone Dielectric Compound to AMP Connectors.....	7-7
	Assembly.....	7-7
	Disassembly.....	7-9
	Wedge Lock.....	7-9
	Service - Voltage Reading.....	7-9
7.7	DEUTSCH Connectors.....	7-11
	DT/DTP Series Assembly.....	7-11
	DT/DTP Series Disassembly.....	7-11
	HD30/HDP20 Series Assembly.....	7-12
	HD30/HDP20 Series Disassembly.....	7-12
7.8	Wiring Harness Connector Labels.....	7-13
	Connector Labels.....	7-13
	Component Labels.....	7-13
7.9	Electrical Schematics.....	7-71

Go to Discount-Equipment.com to order your parts

FIGURE NO.	TITLE	PAGE NO.
1-1.	Serial Number Locations	1-3
1-2.	Maintenance & Lubrication Diagram	1-4
2-1.	Engine Operating Temperature Specifications - Kubota	2-10
3-1.	Spindle Assembly	3-3
3-2.	Chassis Component Location	3-4
3-3.	Drive Components	3-5
3-4.	Cable Routing	3-6
3-5.	Relay	3-7
3-6.	System Fuses	3-8
3-7.	Ignition Relay Fuse	3-9
3-8.	Drive Fuses	3-10
3-9.	Drive Limit Switch	3-11
3-10.	Steering Installation and spindle	3-12
3-11.	Main Assembly - Sheet 1 of 2	3-14
3-12.	Main Assembly - Sheet 2 of 2	3-15
3-13.	Output Carrier	3-16
3-14.	Planet Gear	3-17
3-15.	Input Carrier	3-18
3-16.	Hub Spindle	3-19
3-17.	Cover Assembly	3-20
3-18.	Drive Hub - Sheet 1 of 2	3-24
3-19.	Drive Hub - Sheet 2 of 2	3-25
3-20.	Drive Motor	3-28
3-21.	Swing Bearing Feeler Gauge Check	3-29
3-22.	Swing Bearing Tolerance Boom Placement	3-30
3-23.	Swing Bearing Tolerance Measuring Point	3-30
3-24.	Swing Bearing Torquing Sequence	3-32
3-25.	Swing Bearing Removal	3-33
3-26.	Swing Components	3-35
3-27.	Swing Motor - Cutaway	3-36
3-28.	Swing Motor - Exploded View	3-38
3-29.	On Board Generator	3-55
3-30.	Battery Charger	3-58
3-31.	Generator	3-62
4-1.	Location of Components Platform Support	4-1
4-2.	Platform Support Torque Values	4-3
4-3.	Wear Pad Thickness	4-9
4-4.	Boom Limit Switches	4-10
4-5.	Location of Components - Articulating Jib Boom	4-11
4-6.	Rotary Actuator (Exploded View)	4-14
4-7.	Rotator- Assembly Drawing	4-15
4-8.	Rotator Counterbalance Valve	4-24
5-1.	NPTF Thread	5-3
5-2.	BSPT Thread	5-3
5-3.	JIC Thread	5-3
5-4.	SAE Thread	5-3
5-5.	ORFS Thread	5-3
5-6.	MTBL-MBTS Thread	5-3
5-7.	Bulkhead Thread	5-3
5-8.	ORB-MPP Thread	5-4
5-9.	MFF-BSPP Thread	5-4
5-10.	FL61-FL62	5-4
5-11.	Torque Wrench Angle	5-5
5-12.	Double Wrench Method	5-51
5-13.	FFWR Method	5-52
5-14.	Adjustable Stud End Assembly	5-53
5-15.	Cylinder Barrel Support	5-54

FIGURE NO.	TITLE	PAGE NO.
5-16.	Cylinder Head Removal	5-54
5-17.	Cylinder Rod Support	5-54
5-18.	Platform Level Cylinder - USA Built Machine	5-55
5-19.	Platform Level Cylinder - China Built Machine	5-56
5-20.	Composite Bearing Installation	5-58
5-21.	Rod Seal Installation	5-58
5-22.	Cylinder Head Seal Installation	5-58
5-23.	Wiper Seal Installation	5-59
5-24.	Installation of Head Seal Kit	5-59
5-25.	Piston Seal Kit Installation	5-59
5-26.	Cylinder Barrel Support	5-60
5-27.	Cylinder Head Removal	5-60
5-28.	Cylinder Rod Support	5-60
5-29.	Jib Lift Cylinder (USA Built Machine)	5-61
5-30.	Jib Lift Cylinder (China Built Machine)	5-62
5-31.	Composite Bearing Installation	5-64
5-32.	Rod Seal Installation	5-64
5-33.	Cylinder Head Seal Installation	5-64
5-34.	Wiper Seal Installation	5-65
5-35.	Installation of Head Seal Kit	5-65
5-36.	Piston Seal Kit Installation	5-65
5-37.	Cylinder Barrel Support	5-66
5-38.	Cylinder Head Removal	5-66
5-39.	Cylinder Head Removal	5-66
5-40.	Cylinder Rod Support	5-67
5-41.	Lower Lift Cylinder - USA Built Machine	5-68
5-42.	Lower Lift Cylinder - China Built Machine	5-69
5-43.	Composite Bearing Installation	5-71
5-44.	Rod Seal Installation	5-71
5-45.	Cylinder Head Seal Installation	5-71
5-46.	Wiper Seal Installation	5-72
5-47.	Installation of Head Seal Kit	5-72
5-48.	Piston Seal Kit Installation	5-72
5-49.	Cylinder Barrel Support	5-73
5-50.	Cylinder Head Removal	5-73
5-51.	Cylinder Head Removal	5-73
5-52.	Cylinder Rod Support	5-74
5-53.	Mid Lift Cylinder - USA Built Machine	5-75
5-54.	Mid Lift Cylinder - China Built Machine	5-76
5-55.	Composite Bearing Installation	5-78
5-56.	Rod Seal Installation	5-78
5-57.	Cylinder Head Seal Installation	5-78
5-58.	Wiper Seal Installation	5-79
5-59.	Installation of Head Seal Kit	5-79
5-60.	Piston Seal Kit Installation	5-79
5-61.	Cylinder Barrel Support	5-80
5-62.	Cylinder Head Removal	5-80
5-63.	Cylinder Head Removal	5-80
5-64.	Cylinder Rod Support	5-81
5-65.	Upper Lift Cylinder - USA Built Machine	5-82
5-66.	Upper Lift Cylinder - China Built Machine	5-83
5-67.	Composite Bearing Installation	5-85
5-68.	Rod Seal Installation	5-85
5-69.	Cylinder Head Seal Installation	5-85
5-70.	Wiper Seal Installation	5-86
5-71.	Installation of Head Seal Kit	5-86
5-72.	Piston Seal Kit Installation	5-86

FIGURE NO.	TITLE	PAGE NO.
5-73.	Cylinder Barrel Support	5-87
5-74.	Cylinder Head Removal	5-87
5-75.	Cylinder Rod Support	5-87
5-76.	Master Cylinder - USA Built Machine	5-88
5-77.	Master Cylinder - China Built Machine	5-89
5-78.	Composite Bearing Installation	5-91
5-79.	Rod Seal Installation	5-91
5-80.	Cylinder Head Seal Installation	5-91
5-81.	Wiper Seal Installation	5-92
5-82.	Installation of Head Seal Kit	5-92
5-83.	Piston Seal Kit Installation	5-92
5-84.	Cylinder Barrel Support	5-93
5-85.	Spanner Nut Removal	5-93
5-86.	Cylinder Rod Support	5-93
5-87.	Steer Cylinder	5-94
5-88.	Rod Seal Installation	5-96
5-89.	Cylinder Head Seal Installation	5-96
5-90.	Wiper Seal Installation	5-96
5-91.	Installation of Head Seal Kit	5-96
5-92.	Piston Seal Kit Installation	5-97
5-93.	Cylinder Barrel Support	5-98
5-94.	Cylinder Cap Removal	5-98
5-95.	Cylinder Head Removal	5-98
5-96.	Cylinder Rod Support	5-99
5-97.	Telescope Cylinder - USA Built Machine	5-100
5-98.	Telescope Cylinder - China Built Machine	5-101
5-99.	Composite Bearing Installation	5-103
5-100.	Rod Seal Installation	5-103
5-101.	Cylinder Head Seal Installation	5-103
5-102.	Wiper Seal Installation	5-104
5-103.	Installation of Head Seal Kit	5-104
5-104.	Piston Seal Kit Installation	5-104
5-105.	Components Boom	5-105
5-106.	Main Boom Lift Cylinder Removal	5-106
5-107.	Mid Boom Lift Cylinder Removal	5-107
5-108.	Lower Boom Lift Cylinder Removal	5-108
5-109.	Main Telescope Cylinder Removal	5-109
5-110.	Jib Valve Location	5-112
5-111.	Hydraulic Component Location	5-113
5-112.	Steer Valve Pressure Adjustment	5-114
5-113.	Steer Valve Component	5-115
5-114.	Steer Valve Torque Specification	5-116
5-115.	Main Valve Pressure Adjustment	5-117
5-116.	Main Valve Components	5-118
5-117.	Main Control Valve Torque Specification	5-119
5-118.	Releveling Valve Torque Specification	5-120
5-119.	Jib Valve Torque Specification	5-121
5-120.	Hydraulic Schematic - Sheet 1 of 7	5-122
5-121.	Hydraulic Schematic - Sheet 2 of 7	5-123
5-122.	Hydraulic Schematic - Sheet 3 of 7	5-124
5-123.	Hydraulic Schematic - Sheet 4 of 7	5-125
5-124.	Hydraulic Schematic - Sheet 5 of 7	5-126
5-125.	Hydraulic Schematic - Sheet 6 of 7	5-127
5-126.	Hydraulic Schematic - Sheet 7 of 7	5-128

FIGURE NO.	TITLE	PAGE NO.
6-1.	Hand Held Analyzer	6-1
6-2.	Analyzer Software P1.10 - Sheet 1 of 5	6-17
6-3.	Analyzer Software P1.10 - Sheet 2 of 5	6-18
6-4.	Analyzer Software P1.10 - Sheet 3 of 5	6-19
6-5.	Analyzer Software P1.10 - Sheet 4 of 5	6-20
6-6.	Analyzer Software P1.10 - Sheet 5 of 5	6-21
6-7.	Control Module Location - Sheet 1 of 2	6-24
6-8.	Control Module Location - Sheet 2 of 2	6-25
6-9.	Analyzer Connecting Points	6-26
6-10.	Power Module - LH.....	6-27
6-11.	Power Module - RH.....	6-28
6-12.	Ground Control Module - Sheet 1 of 3.....	6-29
6-13.	Ground Control Module - Sheet 2 of 3.....	6-30
6-14.	Ground Control Module - Sheet 3 of 3.....	6-31
6-15.	Platform Module - Sheet 1 of 2.....	6-32
6-16.	Platform Module - Sheet 2 of 2.....	6-33
7-1.	Voltage Measurement (DC).....	7-1
7-2.	Resistance Measurement.....	7-2
7-3.	Continuity Measurement.....	7-2
7-4.	Current Measurement (DC).....	7-3
7-5.	Connector Assembly Figure 1	7-7
7-6.	AMP Connector	7-7
7-7.	Connector Assembly Figure 2	7-8
7-8.	Connector Assembly Figure 3	7-8
7-9.	Connector Assembly Figure 4	7-8
7-10.	Connector Disassembly	7-9
7-11.	Connector Installation.....	7-10
7-12.	DT/DTP Contact Installation	7-11
7-13.	DT/DTP Contact Removal.....	7-11
7-14.	HD/HDP Contact Installation	7-12
7-15.	HD/HDP Locking Contacts Into Position.....	7-12
7-16.	HD/HDP Contact Removal.....	7-12
7-17.	HD/HDP Unlocking Contacts	7-12
7-18.	Platform Control Box Harness - Sheet 1 of 5	7-15
7-19.	Platform Control Box Harness - Sheet 2 of 5	7-16
7-20.	Platform Control Box Harness - Sheet 3 of 5	7-20
7-21.	Platform Control Box Harness - Sheet 4 of 5	7-22
7-22.	Platform Control Box Harness - Sheet 5 of 5	7-27
7-23.	Platform Beacon Harness.....	7-28
7-24.	Load Sensing System Harness (LSS) - Sheet 1 of 2	7-30
7-25.	Load Sensing System Harness (LSS) - Sheet 2 of 2	7-31
7-26.	Main Valve Harness - Sheet 1 of 3	7-32
7-27.	Main Valve Harness - Sheet 2 of 3	7-33
7-28.	Main Valve Harness - Sheet 3 of 3	7-34
7-29.	Turntable Harness - Sheet 1 of 4	7-35
7-30.	Turntable Harness - Sheet 2 of 4	7-36
7-31.	Turntable Harness - Sheet 3 of 4	7-40
7-32.	Turntable Harness - Sheet 4 of 4	7-43
7-33.	Ground Control Panel Harness - Sheet 1 of 3	7-44
7-34.	Ground Control Panel Harness - Sheet 2 of 3	7-45
7-35.	Ground Control Panel Harness - Sheet 3 of 3	7-46
7-36.	Chassis Traction Harness - Sheet 1 of 4.....	7-48
7-37.	Chassis Traction Harness - Sheet 2 of 4	7-49
7-38.	Chassis Traction Harness - Sheet 3 of 4	7-50
7-39.	Chassis Traction Harness - Sheet 4 of 4	7-51
7-40.	Chassis to Turntable Harness	7-52
7-41.	Chassis Steer/Brake Harness - Sheet 1 of 2.....	7-54

LIST OF FIGURES

FIGURE NO.	TITLE	PAGE NO.
7-42.	Chassis Steer/Brake Harness - Sheet 2 of 2	7-55
7-43.	Chassis Head /Tail Light Harness - Sheet 1 of 2.....	7-56
7-44.	Chassis Head /Tail Light Harness - Sheet 2 of 2.....	7-57
7-45.	Inverter IGN Harness.....	7-58
7-46.	Platform Work Light Harness.....	7-59
7-47.	Generator IGN Harness - Sheet 1 of 2	7-60
7-48.	Generator IGN Harness - Sheet 2 of 2	7-61
7-49.	SkyGuard Harness - Sheet 1 of 2.....	7-62
7-50.	SkyGuard Harness - Sheet 2 of 2.....	7-63
7-51.	Soft Touch Harness - Sheet 1 of 2.....	7-64
7-52.	Soft Touch Harness - Sheet 2 of 2.....	7-65
7-53.	Gen 2 Plat Interface Harness	7-66
7-54.	Eboom ClearSky CAN Harness.....	7-68
7-55.	Electrical Schematic - Sheet 1 of 16.....	7-72
7-56.	Electrical Schematic - Sheet 2 of 16.....	7-73
7-57.	Electrical Schematic - Sheet 3 of 16.....	7-74
7-58.	Electrical Schematic - Sheet 4 of 16.....	7-75
7-59.	Electrical Schematic - Sheet 5 of 16.....	7-76
7-60.	Electrical Schematic - Sheet 6 of 16.....	7-77
7-61.	Electrical Schematic - Sheet 7 of 16.....	7-78
7-62.	Electrical Schematic - Sheet 8 of 16.....	7-79
7-63.	Electrical Schematic - Sheet 9 of 16.....	7-80
7-64.	Electrical Schematic - Sheet 10 of 16	7-81
7-65.	Electrical Schematic - Sheet 11 of 16	7-82
7-66.	Electrical Schematic - Sheet 12 of 16	7-83
7-67.	Electrical Schematic - Sheet 13 of 16	7-84
7-68.	Electrical Schematic - Sheet 14 of 16	7-85
7-69.	Electrical Schematic - Sheet 15 of 16	7-86
7-70.	Electrical Schematic - Sheet 16 of 16	7-87

Go to Discount-Equipment.com to order your parts

TABLE NO.	TITLE	PAGE NO.
1-1	Mobil DTE 10 Excel 15 Specs.....	1-2
1-2	Mobil EAL 224H Specs.....	1-2
1-3	Lubrication Specifications.....	1-5
2-1	Inspection and Maintenance.....	2-2
2-2	Cylinder Drift.....	2-5
2-3	Inspection and Preventive Maintenance Schedule.....	2-7
3-1	Wheel Torque Chart.....	3-2
3-2	Swing Motor Troubleshooting.....	3-37
3-3	Battery Charger Fault Codes (Delta-Q).....	3-57
3-4	Battery Algorithms.....	3-60
3-5	Controller Interface Pin Assignments.....	3-66
3-6	RBS Alarms and Flash Codes.....	3-69
3-7	Troubleshooting.....	3-70
4-1	Troubleshooting.....	4-27
4-2	SkyGuard Function Table.....	4-41
5-1	NPTF Pipe Thread.....	5-6
5-2	BSPT Pipe Thread.....	5-7
5-3	37° Flare (JIC) Thread - Steel.....	5-9
5-4	37° Flare (JIC) Thread - Aluminum/Brass.....	5-10
5-5	45° Flare (SAE) - Steel.....	5-13
5-6	45° Flare (SAE) - Aluminum/Brass.....	5-13
5-7	O-ring Face Seal (ORFS) - Steel.....	5-14
5-8	O-ring Face Seal (ORFS) - Aluminum/Brass.....	5-15
5-9	DIN 24° Cone (MBTL & MBTS).....	5-17
5-10	Bulkhead Fittings (BH) - INCH.....	5-19
5-11	Bulkhead Fittings (BH) - METRIC.....	5-20
5-12	O-ring Boss (ORB) - Table 1 of 6.....	5-23
5-13	O-ring Boss (ORB) - Table 2 of 6.....	5-24
5-14	O-ring Boss (ORB) - Table 3 of 6.....	5-25
5-15	O-ring Boss (ORB) - Table 4 of 6.....	5-26
5-16	O-ring Boss (ORB) - Table 5 of 6.....	5-27
5-17	O-ring Boss (ORB) - Table 6 of 6.....	5-28
5-18	Metric Flat Face Port (MFF) - L Series - Table 1 of 3.....	5-31
5-19	Metric Flat Face Port (MFF) - L Series - Table 2 of 3.....	5-32
5-20	Metric Flat Face Port (MFF) - L Series - Table 3 of 3.....	5-33
5-21	Metric Flat Face Port (MFF) - S Series - Table 1 of 3.....	5-34
5-22	Metric Flat Face Port (MFF) - S Series - Table 2 of 3.....	5-35
5-23	Metric Flat Face Port (MFF) - S Series - Table 3 of 3.....	5-36
5-24	Metric Pipe Parallel O-Ring Boss (MPP).....	5-39
5-25	British Standard Parallel Pipe Port (BSPP) - L Series - Table 1 of 3.....	5-41
5-26	British Standard Parallel Pipe Port (BSPP) - L Series - Table 2 of 3.....	5-42
5-27	British Standard Parallel Pipe Port (BSPP) - L Series - Table 3 of 3.....	5-43
5-28	British Standard Parallel Pipe Port (BSPP) - S Series - Table 1 of 3.....	5-44
5-29	British Standard Parallel Pipe Port (BSPP) - S Series - Table 2 of 3.....	5-45
5-30	British Standard Parallel Pipe Port (BSPP) - S Series - Table 3 of 3.....	5-46
5-31	Flange Code (FL61 & FL62) -Inch Fasteners.....	5-49
5-32	Flange Code (FL61 & FL62) - Metric Fasteners.....	5-50
5-33	Cartridge Torque Values.....	5-116
5-34	Coil Torque/Resistance Values.....	5-116
5-35	Cartridge Torque Values.....	5-119
5-36	Coil Torque Values.....	5-119
5-37	Cartridge Torque Values.....	5-120
5-38	Cartridge Torque Values.....	5-121
5-39	Coil Resistance Value.....	5-121

LIST OF TABLES

TABLE NO.	TITLE	PAGE NO.
6-1	Analyzer Abbreviations	6-6
6-2	Machine Configuration Programming Information - Version P1.10	6-8
6-3	Machine Configuration Programming Settings - Version P1.10	6-12
6-4	Personality Ranges/Defaults	6-13
6-5	Machine Setup Descriptions	6-34
6-6	JLG Control System Flash Codes	6-34
6-7	Help Descriptions and Fault Flash Codes	6-35
6-8	DIAGNOSTICS - Menu Descriptions	6-40
6-9	System Test Descriptions	6-46
6-10	System Test Messages	6-47
6-11	Diagnostic Menu Descriptions	6-59
6-12	Accessory Weights	6-61
6-13	SkyGlazier Capacity Reductions	6-63
6-14	Pipe Rack Capacity Reductions	6-63
6-15	LSS Troubleshooting Chart	6-66
6-16	Diagnostic Trouble Codes	6-69
7-1	Wiring Harness Connector Labels	7-13

Go to Discount-Equipment.com to order your parts

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your information to search for manuals and parts.

* Brand:

* Model:

* Serial:

* Part Number:

SEARCH

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information:

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Part Name:

Part Description:

Part Location:

Part Condition:

Part Status:

Part Date:

Part Price:

Part Location:

Part Condition:

Part Status:

Part Date:

Part Price:

Part Location:

Part Condition:

Part Status:

Part Date:

Part Price:

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 1. SPECIFICATIONS

1.1 OPERATING SPECIFICATIONS

Maximum Work Load (Capacity) ANSI Markets Unrestricted:	500 lb (227 kg)
Maximum Work Load (Capacity) CE & Australia Markets Unrestricted:	500 lb (230 kg)
Travel Speed	3.2 mph (5.2 kph)
Maximum Travel Grade (Gradeability)	30%
Maximum Travel Grade (Side Slope)	5°
Maximum Height: (Stowed)	6 ft. 7 in. (2.0 m)
Maximum Horizontal Platform Reach	23 ft. 9 in. (7.24 m)
Turning Radius (Curb to Curb)	15 ft. 3 in. (4.65 m)
Turning Radius (Inside)	2 ft. (0.61 m)
Maximum Tire Load:	6900 lb (3,130 kg)
Ground Bearing Pressure	75 psi (5.2 kg/cm ²)
System Voltage	48 volts
Battery Life per Charge	7 hours continuous
Battery Recharge Time Charger Generator	17 hours from full discharge 6.2 hours
Gross Machine Weight (Platform Empty)	15,100 lb (6804 kg)

1.2 TIRES

Size	IN240/55-17.5	IN240/55-17.5	26x7x20
Load Range	E	E	N/A
Ply Rating	10	10	N/A
Tire Pressure	90 psi (6.2 Bar)	90 psi (6.2 Bar)	N/A
Fill Type	Foam-Filled	Foam-Filled	Solid

1.3 CAPACITIES

Generator Fuel Tank	4 Gallons (15.1 L)
Hydraulic Oil Tank	5 Gallons (19L) w/10% air space
Hydraulic System (Including Tank)	9 Gallons (34.1 L)
Torque Hub, Drive*	25.5 ounces (0.75 L)
*Torque hubs should be one half full of lubricant.	

1.4 DIMENSIONAL DATA

Machine Length (stowed)	21 ft. 2 in. (6.45 m)
Up and Over Platform Height	25 ft. 3 in. (7.7 m)
Horizontal Reach @ Maximum Up and Over	23 ft. 9 in. (7.24 m)
Machine Width	5 ft. 9 in. (1.75 m)
Wheel Base	6 ft. 7.0 in. (2.00 m)
Working Height	51 ft. 0 in. (15.54 m)
Platform Height	45 ft. 0 in. (13.72 m)
Track Width	5 ft. 0 in. (1.51 m)
Tail Swing (Any Position)	0
Ground Clearance	Drive Reduced 8 in. (0.20 m)
Occupied Floor Area	51.4 ft ² (4.7 m ²)

SECTION 1 - SPECIFICATIONS

1.5 TORQUE SPECIFICATIONS

Description	Torque Value	Interval Hours
Wheel Lugs	170 ft. lbs. (230 Nm)	150
Swing Bearing (High Strength Threadlocking Compound)	190 ft. lbs. (260 Nm)	50/600*
* Check swing bearing bolts for security after first 50 hours of operation and every 600 hours thereafter.		

1.6 LUBRICATION SPECIFICATIONS

Refer to Section 1.10, Maintenance and Lubrication, for specific lubrication procedures.

Hydraulic Oil

Hydraulic System Operating Temperature Range	S.A.E. Viscosity Grade
+0° to +180° F (-18° to +83° C)	10W
+0° to +210° F (-18° to +99° C)	10W-20, 10W30
+50° to +210° F (+10° to +99° C)	20W-20

NOTE: Hydraulic oils must have anti-wear qualities at least to API Service Classification GL-3, and sufficient chemical stability for mobile hydraulic system service.

NOTE: Aside from JLG recommendations, it is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities.

NOTE: When temperatures remain consistently below 20 degrees F. (-7 degrees C.), JLG Industries recommends the use of Premium Hydraulic Fluid.

Table 1-1. Mobil DTE 10 Excel 15 Specs

ISO Viscosity Grade	#15
Pour Point, Max	-65°F (-54°C)
Flash Point, Min.	360°F (182°C)
Viscosity	
at 40°C	15.8 cSt
at 100°C	4.07 cSt
at 100°F	15.8 cSt
at 212°F	4.07 cSt
Viscosity Index	168
Density (Kg/l) @ 15°C	0.8375
Density (lb/in ³) @ 60°F	0.0302

Table 1-2. Mobil EAL 224H Specs

Type	Synthetic Biodegradable
ISO Viscosity Grade	32/46
Specific Gravity	.922
Pour Point, Max	-25°F (-32°C)
Flash Point, Min.	428°F (220°C)
Operating Temp.	0 to 180°F (-17 to 162°C)
Weight	7.64 lb per gal. (0.9 kg per liter)
Viscosity	
at 40°C	37 cSt
at 100°C	8.4 cSt
Viscosity Index	213
NOTE: Must be stored above 32°F (14°C)	

1.7 CRITICAL STABILITY WEIGHTS

Component	LB	KG
Counterweight	3850	1746
Tire & Wheel (foam-filled)	207	94
Platform (4ft [1.2 m])	90	41
Platform (5 ft [1.5 m])	100	45
Battery (each)	120	54

⚠ WARNING

DO NOT REPLACE ITEMS CRITICAL TO STABILITY, SUCH AS BATTERIES OR TIRES, WITH ITEMS OF DIFFERENT WEIGHT OR SPECIFICATION. DO NOT MODIFY THE MEWP IN ANY WAY TO AFFECT STABILITY.

1.8 MAJOR COMPONENT WEIGHTS

Component	LB	KG
Platform and Support	215	97.5
Upper Boom Complete	450	204
Mid Boom Complete	419	190
Lower Boom Complete	419	190
Upper Lift Cylinder	97	44
Mid Lift Cylinder	60	27
Lower Lift Cylinder	130	59
Master Cylinder	405	184
Slave Cylinder	432	196
Telescope Cylinder	103	47
Upper Upright	222	101
Lower Upright	93	42
Turntable	948	430
Battery Box (incl. batteries)	600	272
Chassis (w/ foam-filled tires)	4695	2130
Counterweight	3850	1746
Machine Complete	14480	6568

1.9 SERIAL NUMBER LOCATIONS

For machine identification, a serial number plate is affixed to the left rear of frame, in front of left rear wheel. If the serial number plate is damaged or missing, the machine serial number is stamped on the top left side of the frame and the top left side of the turntable. In addition, the serial number is stamped on top of the end of the upper boom, mid boom, and lower boom at the left rear of the booms.




Figure 1-1. Serial Number Locations




Figure 1-2. Maintenance & Lubrication Diagram

1.10 MAINTENANCE AND LUBRICATION

NOTE: The following numbers correspond to those in Figure 1-2, Maintenance & Lubrication Diagram.

Table 1-3. Lubrication Specifications

KEY	SPECIFICATIONS
MPG	Multipurpose Grease having a minimum dripping point of 350 degrees F. Excellent water resistance and adhesive qualities; and being of extreme pressure type (Timken OK 40 lb minimum).
EPGL	Extreme Pressure Gear Lube (oil) meeting API Service Classification GL-5 or Mil-Spec Mil-L-2105.
HO	Hydraulic Oil. Mobil DTE-10
OG*	Open Gear Lube - Tribol Molub-Alloy 936 Open Gear Compound. (JLG Part No. 3020027)
BG*	Bearing Grease (JLG Part No. 3020029) Mobilith SHA 460.
LL	Synthetic Lithium Lubricant, Gredag 741 Grease. (JLG Part No. 3020022)
EO	Engine (crankcase) Oil. Refer to Engine Operation Manual.

*MPG may be substituted for these lubricants, if necessary, but service intervals will be reduced.

NOTICE

LUBRICATION INTERVALS ARE BASED ON MACHINE OPERATION UNDER NORMAL CONDITIONS. FOR MACHINES USED IN MULTI-SHIFT OPERATIONS AND/OR EXPOSED TO HOSTILE ENVIRONMENTS OR CONDITIONS, LUBRICATION FREQUENCIES MUST BE INCREASED ACCORDINGLY.

1. Swing Bearing

- Lube Point(s) - 2 Grease Fittings
- Capacity - A/R
- Lube - MPG
- Interval - Every 3 months or 150 hrs of operation
- Comments - Remote Access (Optional).

2. Swing Bearing/Worm Gear Teeth




- Lube Point(s) - Grease Fittings
- Capacity - Spray On
- Lube - OG or Mobiltac375NC
- Interval - A/R
- Comments - If necessary install grease fittings into worm gear housing and grease bearings.

NOTE: OG will allow better cycle times than Mobiltac375NC, however Mobiltac375NC must be used in dusty environments. If the swing function becomes noisy and/or rough lubricate the bearing teeth.


CAUTION

DO NOT OVERGREASE BEARINGS. OVERGREASING BEARINGS WILL RESULT IN BLOWING OUTER SEAL IN HOUSING.



SECTION 1 - SPECIFICATIONS

3. Hydraulic Tank



Lube Point(s) - Fill Cap



Capacity - 4 Gal. (15.1 L)

Lube - HO

Interval - Check Level daily; Change every 2 years or 1200 hours of operation.

Comments - On new machines, those recently overhauled, or after changing hydraulic oil, operate all systems a minimum of two complete cycles and recheck oil level in reservoir.

4. Hydraulic Return Filter



Interval - Change after first 50 hrs. and every 6 months or 300 hrs. thereafter.

Comments - Under certain conditions, it may be necessary to replace the hydraulic filter on a more frequent basis. A common symptom of a dirty filter is sluggishness experienced in hydraulic functions.

5. Wheel Drive Hub



Lube Point(s) - Level/Fill Plug

Capacity - 17 oz. (1/2 Full)

Lube - EPGL

Interval - Check level every 3 months or 150 hrs of operation; change every 2 years or 1200 hours of operation.

6. Wheel Bearing



Lube Point(s) - Repack
 Capacity - A/R
 Lube - MPG
 Interval - Every 2 years or 1200 hours of operation.

7. Spindles/Bushing

Capacity - A/R
 Lube - Lithium Lubricant
 Interval - Every 2 years or 1200 hours of operation
 Comments - At Spindle/Bushing Replacement; Coat I.D. of bushings prior to installing king pins.

8. Boom Pivot Pins/Bushing

Capacity - A/R
 Lube - Lithium Lubricant
 Interval - Every 2 years or 1200 hours of operation
 Comments - At boom pivot pins/bushing replacement; Coat I.D. of bushings prior to installing pivot pins.

9. Engine



Lube Point(s) - Fill Cap
 Capacity - Refer to Engine Manual
 Lube - EO
 Interval - 3 Months or 150 hours of operation
 Comments - Check level daily/Change in accordance with engine manual.

SECTION 1 - SPECIFICATIONS

1.11 THREADLOCKING COMPOUND

JLG PN	Loctite®	ND Industries	Description
0100011	242™	Vibra-TITE™ 121	Medium Strength (Blue)
1001095650	243™	Vibra-TITE™ 122	Medium Strength (Blue)
0100019	271™	Vibra-TITE™ 140	High Strength (Red)
0100071	262™	Vibra-TITE™ 131	Medium - High Strength (Red)

NOTE: Loctite® 243™ can be substituted in place of Loctite® 242™. Vibra-TITE™ 122 can be substituted in place of Vibra-TITE™ 121.

Go to Discount-Equipment.com to order your parts

1.12 TORQUE CHARTS

SAE Fastener Torque Chart

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)												
SAE GRADE 5 BOLTS & GRADE 2 NUTS												
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry)		Torque Lubricated		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140)		Torque (Loctite® 262™ or Vibra-TITE™ 111)	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
4	40	0.1120	0.00604	380	8	0.9	6	0.7				
	48	0.1120	0.00661	420	9	1.0	7	0.8				
6	32	0.1380	0.00909	580	16	1.8	12	1.4				
	40	0.1380	0.01015	610	18	2.0	13	1.5				
8	32	0.1640	0.01400	900	30	3.4	22	2.5				
	36	0.1640	0.01474	940	31	3.5	23	2.6				
10	24	0.1900	0.01750	1120	43	4.8	32	3.5				
	32	0.1900	0.02000	1285	49	5.5	36	4				
1/4	20	0.2500	0.0318	2020	96	10.8	75	9	105	12		
	28	0.2500	0.0364	2320	120	13.5	86	10	135	15		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	3340	17	23	13	18	19	26	16	22
	24	0.3125	0.0580	3700	19	26	14	19	21	29	17	23
3/8	16	0.3750	0.0775	4940	30	41	23	31	35	48	28	38
	24	0.3750	0.0878	5600	35	47	25	34	40	54	32	43
7/16	14	0.4375	0.1063	6800	50	68	35	47	55	75	45	61
	20	0.4375	0.1187	7550	55	75	40	54	60	82	50	68
1/2	13	0.5000	0.1419	9050	75	102	55	75	85	116	68	92
	20	0.5000	0.1599	10700	90	122	65	88	100	136	80	108
9/16	12	0.5625	0.1820	11600	110	149	80	108	120	163	98	133
	18	0.5625	0.2030	12950	120	163	90	122	135	184	109	148
5/8	11	0.6250	0.2260	14400	150	203	110	149	165	224	135	183
	18	0.6250	0.2560	16300	170	230	130	176	190	258	153	207
3/4	10	0.7500	0.3340	21300	260	353	200	271	285	388	240	325
	16	0.7500	0.3730	23800	300	407	220	298	330	449	268	363
7/8	9	0.8750	0.4620	29400	430	583	320	434	475	646	386	523
	14	0.8750	0.5090	32400	470	637	350	475	520	707	425	576
1	8	1.0000	0.6060	38600	640	868	480	651	675	918	579	785
	12	1.0000	0.6630	42200	700	949	530	719	735	1000	633	858
1 1/8	7	1.1250	0.7630	42300	800	1085	600	813	840	1142	714	968
	12	1.1250	0.8560	47500	880	1193	660	895	925	1258	802	1087
1 1/4	7	1.2500	0.9690	53800	1120	1518	840	1139	1175	1598	1009	1368
	12	1.2500	1.0730	59600	1240	1681	920	1247	1300	1768	1118	1516
1 3/8	6	1.3750	1.1550	64100	1460	1979	1100	1491	1525	2074	1322	1792
	12	1.3750	1.3150	73000	1680	2278	1260	1708	1750	2380	1506	2042
1 1/2	6	1.5000	1.4050	78000	1940	2630	1460	1979	2025	2754	1755	2379
	12	1.5000	1.5800	87700	2200	2983	1640	2224	2300	3128	1974	2676

NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS

5000059K

2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%

3. * ASSEMBLY USES HARDENED WASHER

SECTION 1 - SPECIFICATIONS

SAE Fastener Torque Chart (Continued)

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)										
SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS*										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry or Loctite® 263) K=0.20		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.18		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
4	40	0.1120	0.00604							
	48	0.1120	0.00661							
6	32	0.1380	0.00909							
	40	0.1380	0.01015							
8	32	0.1640	0.01400							
	36	0.1640	0.01474	1320	43	5				
10	24	0.1900	0.01750	1580	60	7				
	32	0.1900	0.02000	1800	68	8				
1/4	20	0.2500	0.0318	2860	143	16	129	15		
	28	0.2500	0.0364	3280	164	19	148	17		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	4720	25	35	20	25	20	25
	24	0.3125	0.0580	5220	25	35	25	35	20	25
3/8	16	0.3750	0.0775	7000	45	60	40	55	35	50
	24	0.3750	0.0878	7900	50	70	45	60	35	50
7/16	14	0.4375	0.1063	9550	70	95	65	90	50	70
	20	0.4375	0.1187	10700	80	110	70	95	60	80
1/2	13	0.5000	0.1419	12750	105	145	95	130	80	110
	20	0.5000	0.1599	14400	120	165	110	150	90	120
9/16	12	0.5625	0.1820	16400	155	210	140	190	115	155
	18	0.5625	0.2030	18250	170	230	155	210	130	175
5/8	11	0.6250	0.2260	20350	210	285	190	260	160	220
	18	0.6250	0.2560	23000	240	325	215	290	180	245
3/4	10	0.7500	0.3340	30100	375	510	340	460	280	380
	16	0.7500	0.3730	33600	420	570	380	515	315	430
7/8	9	0.8750	0.4620	41600	605	825	545	740	455	620
	14	0.8750	0.5090	45800	670	910	600	815	500	680
1	8	1.0000	0.6060	51500	860	1170	770	1045	645	875
	12	1.0000	0.6630	59700	995	1355	895	1215	745	1015
1 1/8	7	1.1250	0.7630	68700	1290	1755	1160	1580	965	1310
	12	1.1250	0.8560	77000	1445	1965	1300	1770	1085	1475
1 1/4	7	1.2500	0.9690	87200	1815	2470	1635	2225	1365	1855
	12	1.2500	1.0730	96600	2015	2740	1810	2460	1510	2055
1 3/8	6	1.3750	1.1550	104000	2385	3245	2145	2915	1785	2430
	12	1.3750	1.3150	118100	2705	3680	2435	3310	2030	2760
1 1/2	6	1.5000	1.4050	126500	3165	4305	2845	3870	2370	3225
	12	1.5000	1.5800	142200	3555	4835	3200	4350	2665	3625

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER

5000059K

SAE Fastener Torque Chart (Continued)

Values for Magni Coating Fasteners (Ref 4150701)										
SAE GRADE 5 BOLTS & GRADE 2 NUTS										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry) K=0.17		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.16		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
4	40	0.1120	0.00604	380	7	0.8				
	48	0.1120	0.00661	420	8	0.9				
6	32	0.1380	0.00909	580	14	1.5				
	40	0.1380	0.01015	610	14	1.6				
8	32	0.1640	0.01400	900	25	2.8				
	36	0.1640	0.01474	940	26	2.9				
10	24	0.1900	0.01750	1120	36	4.1				
	32	0.1900	0.02000	1285	42	4.7				
1/4	20	0.2500	0.0318	2020	86	9.7	80	9		
	28	0.2500	0.0364	2320	99	11.1	95	11		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	3340	15	20	14	19	15	20
	24	0.3125	0.0580	3700	15	20	15	21	15	20
3/8	16	0.3750	0.0775	4940	25	35	25	34	25	34
	24	0.3750	0.0878	5600	30	40	28	38	25	34
7/16	14	0.4375	0.1063	6800	40	55	40	54	35	48
	20	0.4375	0.1187	7550	45	60	44	60	40	54
1/2	13	0.5000	0.1419	9050	65	90	60	82	55	75
	20	0.5000	0.1599	10700	75	100	71	97	65	88
9/16	12	0.5625	0.1820	11600	90	120	87	118	80	109
	18	0.5625	0.2030	12950	105	145	97	132	90	122
5/8	11	0.6250	0.2260	14400	130	175	120	163	115	156
	18	0.6250	0.2560	16300	145	195	136	185	125	170
3/4	10	0.7500	0.3340	21300	225	305	213	290	200	272
	16	0.7500	0.3730	23800	255	345	238	324	225	306
7/8	9	0.8750	0.4620	29400	365	495	343	466	320	435
	14	0.8750	0.5090	32400	400	545	378	514	355	483
1	8	1.0000	0.6060	38600	545	740	515	700	480	653
	12	1.0000	0.6630	42200	600	815	563	765	530	721
1 1/8	7	1.1250	0.7630	42300	675	920	635	863	595	809
	12	1.1250	0.8560	47500	755	1025	713	969	670	911
1 1/4	7	1.2500	0.9690	53800	955	1300	897	1219	840	1142
	12	1.2500	1.0730	59600	1055	1435	993	1351	930	1265
1 3/8	6	1.3750	1.1550	64100	1250	1700	1175	1598	1100	1496
	12	1.3750	1.3150	73000	1420	1930	1338	1820	1255	1707
1 1/2	6	1.5000	1.4050	78000	1660	2260	1560	2122	1465	1992
	12	1.5000	1.5800	87700	1865	2535	1754	2385	1645	2237

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER

5000059K

SECTION 1 - SPECIFICATIONS

SAE Fastener Torque Chart (Continued)

Values for Magni Coating Fasteners (Ref 4150701)										
SAE GRADE 8 (HEX HD) BOLTS & GRADE 8 NUTS*										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load	Torque (Dry or Loctite® 263) K=0.17		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.16		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
4	40	0.1120	0.00604							
	48	0.1120	0.00661							
6	32	0.1380	0.00909							
	40	0.1380	0.01015							
8	32	0.1640	0.01400							
	36	0.1640	0.01474	1320	37	4				
10	24	0.1900	0.01750	1580	51	6				
	32	0.1900	0.02000	1800	58	7				
1/4	20	0.2500	0.0318	2860	122	14	114	13		
	28	0.2500	0.0364	3280	139	16	131	15		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	4720	20	25	20	25	20	25
	24	0.3125	0.0580	5220	25	35	20	25	20	25
3/8	16	0.3750	0.0775	7000	35	50	35	50	35	50
	24	0.3750	0.0878	7900	40	55	40	55	35	50
7/16	14	0.4375	0.1063	9550	60	80	55	75	50	70
	20	0.4375	0.1187	10700	65	90	60	80	60	80
1/2	13	0.5000	0.1419	12750	90	120	85	115	80	110
	20	0.5000	0.1599	14400	100	135	95	130	90	120
9/16	12	0.5625	0.1820	16400	130	175	125	170	115	155
	18	0.5625	0.2030	18250	145	195	135	185	130	175
5/8	11	0.6250	0.2260	20350	180	245	170	230	160	220
	18	0.6250	0.2560	23000	205	280	190	260	180	245
3/4	10	0.7500	0.3340	30100	320	435	300	410	280	380
	16	0.7500	0.3730	33600	355	485	335	455	315	430
7/8	9	0.8750	0.4620	41600	515	700	485	660	455	620
	14	0.8750	0.5090	45800	570	775	535	730	500	680
1	8	1.0000	0.6060	51500	730	995	685	930	645	875
	12	1.0000	0.6630	59700	845	1150	795	1080	745	1015
1 1/8	7	1.1250	0.7630	68700	1095	1490	1030	1400	965	1310
	12	1.1250	0.8560	77000	1225	1665	1155	1570	1085	1475
1 1/4	7	1.2500	0.9690	87200	1545	2100	1455	1980	1365	1855
	12	1.2500	1.0730	96600	1710	2325	1610	2190	1510	2055
1 3/8	6	1.3750	1.1550	104000	2025	2755	1905	2590	1785	2430
	12	1.3750	1.3150	118100	2300	3130	2165	2945	2030	2760
1 1/2	6	1.5000	1.4050	126500	2690	3660	2530	3440	2370	3225
	12	1.5000	1.5800	142200	3020	4105	2845	3870	2665	3625

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER

5000059K

SAE Fastener Torque Chart (Continued)

Values for Magni Coating Fasteners (Ref 4150701)										
SOCKET HEAD CAPSCREWS										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry) K=0.17		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) or Precoat® 85 K=0.16		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
4	40	0.1120	0.00604							
	48	0.1120	0.00661							
6	32	0.1380	0.00909							
	40	0.1380	0.01015							
8	32	0.1640	0.01400							
	36	0.1640	0.01474							
10	24	0.1900	0.01750							
	32	0.1900	0.02000							
1/4	20	0.2500	0.0318	2860	122	14	114	13		
	28	0.2500	0.0364	3280	139	16	131	15		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	4720	20	25	20	25	20	25
	24	0.3125	0.0580	5220	25	35	20	25	20	25
3/8	16	0.3750	0.0775	7000	35	50	35	50	35	50
	24	0.3750	0.0878	7900	40	55	40	55	35	50
7/16	14	0.4375	0.1063	9550	60	80	55	75	50	70
	20	0.4375	0.1187	10700	65	90	60	80	60	80
1/2	13	0.5000	0.1419	12750	90	120	85	115	80	110
	20	0.5000	0.1599	14400	100	135	95	130	90	120
9/16	12	0.5625	0.1820	16400	130	175	125	170	115	155
	18	0.5625	0.2030	18250	145	195	135	185	130	175
5/8	11	0.6250	0.2260	20350	180	245	170	230	160	220
	18	0.6250	0.2560	23000	205	280	190	260	180	245
3/4	10	0.7500	0.3340	30100	320	435	300	415	280	380
	16	0.7500	0.3730	33600	355	485	335	455	315	430
7/8	9	0.8750	0.4620	41600	515	700	485	660	455	620
	14	0.8750	0.5090	45800	570	775	535	730	500	680
1	8	1.0000	0.6060	51500	730	995	685	930	645	875
	12	1.0000	0.6630	59700	845	1150	795	1080	745	1015
1 1/8	7	1.1250	0.7630	68700	1095	1490	1030	1400	965	1310
	12	1.1250	0.8560	77000	1225	1665	1155	1570	1085	1475
1 1/4	7	1.2500	0.9690	87200	1545	2100	1455	1980	1365	1855
	12	1.2500	1.0730	96600	1710	2325	1610	2190	1510	2055
1 3/8	6	1.3750	1.1550	104000	2025	2755	1905	2590	1785	2430
	12	1.3750	1.3150	118100	2300	3130	2165	2945	2030	2760
1 1/2	6	1.5000	1.4050	126500	2690	3660	2530	3440	2370	3225
	12	1.5000	1.5800	142200	3020	4105	2845	3870	2665	3625

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 1 - SPECIFICATIONS

SAE Fastener Torque Chart (Continued)

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)*										
SOCKET HEAD CAPSCREWS										
Size	TPI	Bolt Dia	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry) K=0.17		Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) or Precoat® 85 K=0.16		Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15	
					IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
		In	Sq In	LB	IN-LB	[N.m]	IN-LB	[N.m]	IN-LB	[N.m]
4	40	0.1120	0.00604							
	48	0.1120	0.00661							
6	32	0.1380	0.00909							
	40	0.1380	0.01015							
8	32	0.1640	0.01400							
	36	0.1640	0.01474							
10	24	0.1900	0.01750							
	32	0.1900	0.02000							
1/4	20	0.2500	0.0318	2860	122	14	114	13		
	28	0.2500	0.0364	3280	139	16	131	15		
		In	Sq In	LB	FT-LB	[N.m]	FT-LB	[N.m]	FT-LB	[N.m]
5/16	18	0.3125	0.0524	4720	20	25	20	25	20	25
	24	0.3125	0.0580	5220	25	35	20	25	20	25
3/8	16	0.3750	0.0775	7000	35	50	35	50	35	50
	24	0.3750	0.0878	7900	40	55	40	55	35	50
7/16	14	0.4375	0.1063	9550	60	80	55	75	50	70
	20	0.4375	0.1187	10700	65	90	60	80	60	80
1/2	13	0.5000	0.1419	12750	90	120	85	115	80	110
	20	0.5000	0.1599	14400	100	135	95	130	90	120
9/16	12	0.5625	0.1820	16400	130	175	125	170	115	155
	18	0.5625	0.2030	18250	145	195	135	185	130	175
5/8	11	0.6250	0.2260	20350	180	245	170	230	160	220
	18	0.6250	0.2560	23000	205	280	190	260	180	245
3/4	10	0.7500	0.3340	30100	320	435	300	415	280	380
	16	0.7500	0.3730	33600	355	485	335	455	315	430
7/8	9	0.8750	0.4620	41600	515	700	485	660	455	620
	14	0.8750	0.5090	45800	570	775	535	730	500	680
1	8	1.0000	0.6060	51500	730	995	685	930	645	875
	12	1.0000	0.6630	59700	845	1150	795	1080	745	1015
1 1/8	7	1.1250	0.7630	68700	1095	1490	1030	1400	965	1310
	12	1.1250	0.8560	77000	1225	1665	1155	1570	1085	1475
1 1/4	7	1.2500	0.9690	87200	1545	2100	1455	1980	1365	1855
	12	1.2500	1.0730	96600	1710	2325	1610	2190	1510	2055
1 3/8	6	1.3750	1.1550	104000	2025	2755	1905	2590	1785	2430
	12	1.3750	1.3150	118100	2300	3130	2165	2945	2030	2760
1 1/2	6	1.5000	1.4050	126500	2690	3660	2530	3440	2370	3225
	12	1.5000	1.5800	142200	3020	4105	2845	3870	2665	3625

- NOTES: 1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS 5000059K
 2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
 3. * ASSEMBLY USES HARDENED WASHER
 4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

Metric Fastener Torque Chart

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)*							
CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS							
Size	Pitch	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry or Loctite® 263™)	Torque (Lube)	Torque (Loctite® 262™ or 271™ or Vibra-TITE™ 131)	Torque (Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 141)
		Sq mm	KN	[N.m]		[N.m]	[N.m]
3	0.5	5.03	2.19	1.3	1.0	1.2	1.4
3.5	0.6	6.78	2.95	2.1	1.6	1.9	2.3
4	0.7	8.78	3.82	3.1	2.3	2.8	3.4
5	0.8	14.20	6.18	6.2	4.6	5.6	6.8
6	1	20.10	8.74	11	7.9	9.4	12
7	1	28.90	12.6	18	13	16	19
8	1.25	36.60	15.9	26	19	23	28
10	1.5	58.00	25.2	50	38	45	55
12	1.75	84.30	36.7	88	66	79	97
14	2	115	50.0	140	105	126	154
16	2	157	68.3	219	164	197	241
18	2.5	192	83.5	301	226	271	331
20	2.5	245	106.5	426	320	383	469
22	2.5	303	132.0	581	436	523	639
24	3	353	153.5	737	553	663	811
27	3	459	199.5	1080	810	970	1130
30	3.5	561	244.0	1460	1100	1320	1530
33	3.5	694	302.0	1990	1490	1790	2090
36	4	817	355.5	2560	1920	2300	2690
42	4.5	1120	487.0	4090	3070	3680	4290

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 1 - SPECIFICATIONS

Metric Fastener Torque Chart (Continued)

Values for Zinc Yellow Chromate Fasteners (Ref 4150707)*						
CLASS 10.9 METRIC (HEX HEAD) BOLTS, CLASS 10 METRIC NUTS CLASS 12.9 SOCKET HEAD CAPSCREWS M3 - M5*						
Size	Pitch	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry or Loctite® 263™) K=0.20	Torque (Lube or Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.18	Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	3.13			
3.5	0.6	6.78	4.22			
4	0.7	8.78	5.47			
5	0.8	14.20	8.85			
6	1	20.10	12.5			
7	1	28.90	18.0	25	23	19
8	1.25	36.60	22.8	37	33	27
10	1.5	58.00	36.1	70	65	55
12	1.75	84.30	52.5	125	115	95
14	2	115	71.6	200	180	150
16	2	157	97.8	315	280	235
18	2.5	192	119.5	430	385	325
20	2.5	245	152.5	610	550	460
22	2.5	303	189.0	830	750	625
24	3	353	222.0	1065	960	800
27	3	459	286.0	1545	1390	1160
30	3.5	561	349.5	2095	1885	1575
33	3.5	694	432.5	2855	2570	2140
36	4	817	509.0	3665	3300	2750
42	4.5	1120	698.0	5865	5275	4395

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

Metric Fastener Torque Chart (Continued)

Values for Magni Coated Fasteners (Ref 4150701)*						
CLASS 8.8 METRIC (HEX/SOCKET HEAD) BOLTS CLASS 8 METRIC NUTS						
Size	Pitch	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry or Loctite® 263™) K=0.17	Torque (Lube or Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.16	Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	2.19	1.1	1.1	1.0
3.5	0.6	6.78	2.95	1.8	1.7	1.5
4	0.7	8.78	3.82	2.6	2.4	2.3
5	0.8	14.20	6.18	5.3	4.9	4.6
6	1	20.10	8.74	9	8.4	7.9
7	1	28.90	12.6	15	14	13
8	1.25	36.60	15.9	22	20	19
10	1.5	58.00	25.2	43	40	38
12	1.75	84.30	36.7	75	70	66
14	2	115	50.0	119	110	105
16	2	157	68.3	186	175	165
18	2.5	192	83.5	256	240	225
20	2.5	245	106.5	362	340	320
22	2.5	303	132.0	494	465	435
24	3	353	153.5	627	590	555
27	3	459	199.5	916	860	810
30	3.5	561	244.0	1245	1170	1100
33	3.5	694	302.0	1694	1595	1495
36	4	817	355.5	2176	2050	1920
42	4.5	1120	487.0	3477	3275	3070

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 1 - SPECIFICATIONS

Metric Fastener Torque Chart (Continued)

Values for Magni Coated Fasteners (Ref 4150701)*						
CLASS 10.9 METRIC (HEX HEAD) BOLTS CLASS 10 METRIC NUTS, CLASS 12.9 SOCKET HEAD CAPSCREWS M6 AND ABOVE*						
Size	Pitch	Tensile Stress Area	Clamp Load See Note 4	Torque (Dry or Loctite® 263™) K=0.17	Torque (Lube or Loctite® 242™ or 271™ or Vibra-TITE™ 111 or 140) K=0.18	Torque (Loctite® 262™ or Vibra-TITE™ 131) K=0.15
		Sq mm	KN	[N.m]	[N.m]	[N.m]
3	0.5	5.03	3.13			
3.5	0.6	6.78	4.22			
4	0.7	8.78	5.47			
5	0.8	14.20	8.85			
6	1	20.10	12.5	13	12	11
7	1	28.90	18.0	21	20	19
8	1.25	36.60	22.8	31	29	27
10	1.5	58.00	36.1	61	58	55
12	1.75	84.30	52.5	105	100	95
14	2	115	71.6	170	160	150
16	2	157	97.8	265	250	235
18	2.5	192	119.5	365	345	325
20	2.5	245	152.5	520	490	460
22	2.5	303	189.0	705	665	625
24	3	353	222.0	905	850	800
27	3	459	286.0	1315	1235	1160
30	3.5	561	349.5	1780	1680	1575
33	3.5	694	432.5	2425	2285	2140
36	4	817	509.0	3115	2930	2750
42	4.5	1120	698.0	4985	4690	4395

NOTES:

1. THESE TORQUE VALUES DO NOT APPLY TO CADMIUM PLATED FASTENERS
2. ALL TORQUE VALUES ARE STATIC TORQUE MEASURED PER STANDARD AUDIT METHODS TOLERANCE = ±10%
3. * ASSEMBLY USES HARDENED WASHER
4. CLAMP LOAD LISTED FOR SHCS IS SAME AS GRADE 8 OR CLASS 10.9 AND DOES NOT REPRESENT FULL STRENGTH CAPABILITY OF SHCS. IF HIGHER LOAD IS REQUIRED, ADDITIONAL TESTING IS REQUIRED.

5000059K

SECTION 2. GENERAL

2.1 MACHINE PREPARATION, INSPECTION, AND MAINTENANCE

General

This section provides the necessary information needed by those personnel that are responsible to place the machine in operation readiness and maintain its safe operating condition. For maximum service life and safe operation, ensure that all the necessary inspections and maintenance have been completed before placing the machine into service. With proper care, maintenance, and inspections performed per JLG's recommendations, and with any and all discrepancies corrected, this product will be fit for continued use.

Preparation, Inspection, and Maintenance

It is important to establish and conform to a comprehensive inspection and preventive maintenance program. The following table outlines the periodic machine inspections and maintenance recommended by JLG Industries, Inc. Consult your national, regional, or local regulations for further requirements for mobile elevating work platform. The frequency of inspections and maintenance must be increased as environment, severity and frequency of usage requires.

Pre-Start Inspection

It is the User's or Operator's primary responsibility to perform a Pre-Start Inspection of the machine prior to use daily or at each change of operator. Reference the Operation and Safety Manual for completion procedures for the Pre-Start Inspection. The Operation and Safety Manual must be read in its entirety and understood prior to performing the Pre-Start Inspection.

Pre-Delivery Inspection and Frequent Inspection

The Pre-Delivery Inspection and Frequent Inspection shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

The Pre-Delivery Inspection and Frequent Inspection procedures are performed in the same manner, but at different times. The Pre-Delivery Inspection shall be performed prior to each sale, lease, or rental delivery. The Frequent Inspection shall be accomplished for each machine in service for 3 months or 150 hours (whichever comes first); out of service for a period of more than 3 months; or when purchased used. The frequency of this inspection must be increased as environment, severity and frequency of usage requires.

Reference the JLG Pre-Delivery and Frequent Inspection Form and the Inspection and Preventative Maintenance Schedule for items requiring inspection during the performance of these inspections. Reference the appropriate areas of this manual for servicing and maintenance procedures.

Annual Machine Inspection

The Annual Machine Inspection must be performed by a Factory-Trained Service Technician on an annual basis, no later than thirteen (13) months from the date of the prior Annual Machine Inspection. JLG Industries, Inc. recognizes a Factory-Trained Service Technician as a person who has successfully completed the JLG Service Training School for the subject JLG product model. Reference the machine Service and Maintenance Manual and appropriate JLG inspection form for performance of this inspection.

Reference the JLG Annual Machine Inspection Form and the Inspection and Preventative Maintenance Schedule for items requiring inspection during the performance of this inspection. Reference the appropriate areas of this manual for servicing and maintenance procedures.

For the purpose of receiving safety-related bulletins, it is important that JLG Industries, Inc. has updated ownership information for each machine. When performing each Annual Machine Inspection, notify JLG Industries, Inc. of the current machine ownership.

Preventative Maintenance

In conjunction with the specified inspections, maintenance shall be performed by a qualified JLG equipment mechanic. JLG Industries, Inc. recognizes a qualified JLG equipment mechanic as a person who, by possession of a recognized degree, certificate, extensive knowledge, training, or experience, has successfully demonstrated the ability and proficiency to service, repair, and maintain the subject JLG product model.

Reference the Preventative Maintenance Schedule and the appropriate areas of this manual for servicing and maintenance procedures. The frequency of service and maintenance must be increased as environment, severity and frequency of usage requires.

Table 2-1. Inspection and Maintenance

Type	Frequency	Primary Responsibility	Service Qualification	Reference
Pre-Start Inspection	Prior to use each day; or At each Operator change.	User or Operator	User or Operator	Operation and Safety Manual
Pre-Delivery Inspection	Prior to each sale, lease, or rental delivery.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form.
Frequent Inspection	In service for 3 months or 150 hours, whichever comes first; or Out of service for a period of more than 3 months; or purchased used.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual and applicable JLG inspection form.
Annual Machine Inspection	Annually, no later than 13 months from the date of the prior inspection.	Owner, Dealer, or User	Factory-Trained Service Technician (Recommended)	Service and Maintenance Manual and applicable JLG inspection form.
Preventive Maintenance	At intervals as specified in the Service and Maintenance Manual.	Owner, Dealer, or User	Qualified JLG Mechanic	Service and Maintenance Manual

2.2 SERVICE AND GUIDELINES

General

The following information is provided to assist you in the use and application of servicing and maintenance procedures contained in this book.

Safety and Workmanship

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

Cleanliness

1. The most important single item in preserving the long service life of a machine is to keep dirt and foreign materials out of the vital components. Precautions have been taken to safeguard against this. Shields, covers, seals, and filters are provided to keep air, fuel, and oil supplies clean; however, these items must be maintained on a scheduled basis in order to function properly.

2. At any time when air, fuel, or oil lines are disconnected, clear adjacent areas as well as the openings and fittings themselves. As soon as a line or component is disconnected, cap or cover all openings to prevent entry of foreign matter.
3. Clean and inspect all parts during servicing or maintenance, and assure that all passages and openings are unobstructed. Cover all parts to keep them clean. Be sure all parts are clean before they are installed. New parts should remain in their containers until they are ready to be used.

Components Removal and Installation

1. Use adjustable lifting devices, whenever possible, if mechanical assistance is required. All slings (chains, cables, etc.) should be parallel to each other and as near perpendicular as possible to top of part being lifted.
2. Should it be necessary to remove a component on an angle, keep in mind that the capacity of an eyebolt or similar bracket lessens, as the angle between the supporting structure and the component becomes less than 90 degrees.
3. If a part resists removal, check to see whether all nuts, bolts, cables, brackets, wiring, etc., have been removed and that no adjacent parts are interfering.

Component Disassembly and Assembly

When disassembling or reassembling a component, complete the procedural steps in sequence. Do not partially disassemble or assemble one part, then start on another. Always recheck your work to assure that nothing has been overlooked. Do not make any adjustments, other than those recommended, without obtaining proper approval.

Pressure-Fit Parts

When assembling pressure-fit parts, use an anti-seize or molybdenum disulfide base compound to lubricate the mating surface.

Bearings

1. When a bearing is removed, cover it to keep out dirt and abrasives. Clean bearings in nonflammable cleaning solvent and allow to drip dry. Compressed air can be used but do not spin the bearing.
2. Discard bearings if the races and balls (or rollers) are pitted, scored, or burned.
3. If bearing is found to be serviceable, apply a light coat of oil and wrap it in clean (waxed) paper. Do not unwrap reusable or new bearings until they are ready to install.
4. Lubricate new or used serviceable bearings before installation. When pressing a bearing into a retainer or bore, apply pressure to the outer race. If the bearing is to be installed on a shaft, apply pressure to the inner race.

Gaskets

Check that holes in gaskets align with openings in the mating parts. If it becomes necessary to hand-fabricate a gasket, use gasket material or stock of equivalent material and thickness. Be sure to cut holes in the right location, as blank gaskets can cause serious system damage.

Bolt Usage And Torque Application

NOTICE

SELF LOCKING FASTENERS, SUCH AS NYLON INSERT AND THREAD DEFORMING LOCKNUTS, ARE NOT INTENDED TO BE REINSTALLED AFTER REMOVAL.

1. Use bolts of proper length. A bolt which is too long will bottom before the head is tight against its related part. If a bolt is too short, there will not be enough thread area to engage and hold the part properly. When replacing bolts, use only those having the same specifications of the original, or one which is equivalent.
2. Unless specific torque requirements are given within the text, standard torque values should be used on heat-treated bolts, studs, and steel nuts, in accordance with recommended shop practices. (See Section 1.12, Torque Charts.)

Hydraulic Lines and Electrical Wiring

Clearly mark or tag hydraulic lines and electrical wiring, as well as their receptacles, when disconnecting or removing them from the unit. This will assure that they are correctly reinstalled.

Hydraulic System

1. Keep the system clean. If evidence of metal or rubber particles are found in the hydraulic system, drain and flush the entire system.
2. Disassemble and reassemble parts on clean work surface. Clean all metal parts with non-flammable cleaning solvent. Lubricate components, as required, to aid assembly.

Lubrication

Service applicable components with the amount, type, and grade of lubricant recommended in this manual, at the specified intervals. When recommended lubricants are not available, consult your local supplier for an equivalent that meets or exceeds the specifications listed.

Battery

Clean battery, using a non-metallic brush and a solution of baking soda and water. Rinse with clean water. After cleaning, thoroughly dry battery and coat terminals with an anti corrosion compound.

Lubrication and Servicing

Components and assemblies requiring lubrication and servicing are shown in Table 1-3, Lubrication Specifications

2.3 LUBRICATION AND INFORMATION

Hydraulic System

1. The primary enemy of a hydraulic system is contamination. Contaminants enter the system by various means, e.g., using inadequate hydraulic oil, allowing moisture, grease, filings, sealing components, sand, etc., to enter when performing maintenance, or by permitting the pump to cavitate due to insufficient system warm-up or leaks in the pump supply (suction) lines.
2. The design and manufacturing tolerances of the component working parts are very close, therefore, even the smallest amount of dirt or foreign matter entering a system can cause wear or damage to the components and generally results in faulty operation. Every precaution must be taken to keep hydraulic oil clean, including reserve oil in storage. Hydraulic system filters should be checked, cleaned, and/or replaced as necessary, at the specified intervals required in the Lubrication Chart in Section 1. Always examine filters for evidence of metal particles.
3. Cloudy oils indicate a high moisture content which permits organic growth, resulting in oxidation or corrosion. If this condition occurs, the system must be drained, flushed, and refilled with clean oil.
4. It is not advisable to mix oils of different brands or types, as they may not contain the same required additives or be of comparable viscosities. Good grade mineral oils, with viscosities suited to the ambient temperatures in which the machine is operating, are recommended for use.

NOTE: Metal particles may appear in the oil or filters of new machines due to the wear-in of meshing components.

Hydraulic Oil

1. Refer to Section 1 for recommendations for viscosity ranges.
2. JLG recommends Premium Hydraulic Fluid, which has an SAE viscosity of 10W and a viscosity index of 168.

NOTE: Start-up of hydraulic system with oil temperatures below -20 degrees F (-29 degrees C) is not recommended. If it is necessary to start the system in a sub-zero environment, it will be necessary to heat the oil with a low density, 100VAC heater to a minimum temperature of -20 degrees F (-29 degrees C).

Changing Hydraulic Oil

1. Filter elements must be changed after the first 50 hours of operation and every 300 hours thereafter. If it is necessary to change the oil, use only those oils meeting or exceeding the specifications appearing in this manual. If unable to obtain the same type of oil supplied with the machine, consult local supplier for assistance in selecting the proper equivalent. Avoid mixing petroleum and synthetic base oils.
2. Use every precaution to keep the hydraulic oil clean. If the oil must be poured from the original container into another, be sure to clean all possible contaminants from the service container. Always clean the mesh element of the filter and replace the cartridge any time the system oil is changed.
3. While the unit is shut down, a good preventive maintenance measure is to make a thorough inspection of all hydraulic components, lines, fittings, etc., as well as a functional check of each system, before placing the machine back in service.

Lubrication Specifications

Specified lubricants, as recommended by the component manufacturers, are always the best choice, however, multi-purpose greases usually have the qualities which meet a variety of single purpose grease requirements. Should any question arise, regarding the use of greases in maintenance stock, consult your local supplier for evaluation. Refer to Section 1 for an explanation of the lubricant key designations appearing in the Lubrication Chart.

2.4 CYLINDER DRIFT

Theory

When a hydraulic cylinder is supporting a load, cylinder drift may occur as a result of any of the circumstances below:

- Normal leakage of load holding valves or malfunction of load holding valves. See Cylinder Leakage Test and Table 2-2, Cylinder Drift below for evaluation.
- Damaged or worn piston seal.
- Normal thermal expansion and contraction of the hydraulic oil within cylinders (See Cylinder Thermal Drift below).

The first two circumstances may result in cylinder movement due to oil leakage out of the cylinder externally or by leaking back to tank or due to oil leaking internally from one cylinder chamber to the other.

Thermal expansion or contraction of oil in hydraulic cylinders is a normal occurrence and does not result in oil leaking out of the cylinder or leaking internally from one cylinder chamber to the other. Thermal expansion or contraction is the tendency for materials to change size in response to a change in temperature.

Cylinder Leakage Test

Cylinder oil must be at stabilized ambient temperature before beginning this test.

Measure drift at cylinder rod with a calibrated dial indicator.

In an area free of obstructions, cylinder must have load applied and appropriately positioned to detect drift.

Cylinder leakage is acceptable if it passes this test.

Table 2-2. Cylinder Drift

Cylinder Bore Diameter		Max. Acceptable Drift in 10 Minutes	
inches	mm	inches	mm
3	76.2	0.026	0.66
3.5	89	0.019	0.48
4	101.6	0.015	0.38
5	127	0.009	0.22
6	152.4	0.006	0.15
7	177.8	0.005	0.13
8	203.2	0.004	0.10
9	228.6	0.003	0.08

NOTE: This information is based on 6 drops per minute cylinder leakage.

Cylinder Thermal Drift

The oil in all hydraulic cylinders will expand or contract due to thermal effects over time and may result in changes to the boom and/or platform position while the machine is stationary. These effects occur as the cylinder oil changes temperature, usually from a higher oil temperature as it cools and approaches the ambient air temperature. Results of these effects are related to several factors including cylinder length and change in temperature over the time the cylinder remains stationary.

2.5 PINS AND COMPOSITE BEARING REPAIR GUIDELINES

Filament wound bearings.

1. Pinned joints should be disassembled and inspected if the following occurs:
 - a. Excessive sloppiness in joints.
 - b. Noise originating from the joint during operation.
2. Filament wound bearings should be replaced if any of the following is observed:
 - a. Frayed or separated fibers on the liner surface.
 - b. Cracked or damaged liner backing.
 - c. Bearings that have moved or spun in their housing.
 - d. Debris embedded in liner surface.
3. Pins should be replaced if any of the following is observed (pin should be properly cleaned prior to inspection):
 - a. Detectable wear in the bearing area.
 - b. Flaking, peeling, scoring, or scratches on the pin surface.
 - c. Rusting of the pin in the bearing area.
4. Re-assembly of pinned joints using filament wound bearings.
 - a. Housing should be blown out to remove all dirt and debris. Bearings and bearing housings must be free of all contamination.
 - b. Bearing / pins should be cleaned with a solvent to remove all grease and oil. Filament wound bearing are a dry joint and should not be lubricated unless otherwise instructed (i.e. sheave pins).
 - c. Pins should be inspected to ensure it is free of burrs, nicks, and scratches which would damage the bearing during installation and operation.

2.6 WELDING ON JLG EQUIPMENT

NOTE: This instruction applies to repairs, or modifications to the machine and to welding performed from the machine on an external structure, or component,

Do the Following When Welding on JLG Equipment

- Disconnect the battery.
- Ground only to structure being welded.

Do NOT Do the Following When Welding on JLG Equipment

- Ground on frame and weld on any other area than the chassis.
- Ground on turntable and weld on any other area than the turntable.
- Ground on the platform/support and weld on any other area than the platform/support.
- Ground on a specific boom section and weld on any other area than that specific boom section.
- Allow pins, wear pads, wire ropes, bearings, gearing, seals, valves, electrical wiring, or hoses to be between the grounding position and the welded area.

NOTICE

FAILURE TO COMPLY WITH THE ABOVE REQUIREMENTS MAY RESULT IN COMPONENT DAMAGE (I.E. ELECTRONIC MODULES, SWING BEARING, COLLECTOR RING, BOOM WIRE ROPES ETC.)

Table 2-3. Inspection and Preventive Maintenance Schedule

AREA	INTERVAL	
	Pre-Delivery ¹ or Frequent ² Inspection	Annual ³ (Yearly) Inspection
Boom Assembly		
Boom Weldments	1,2,4	1,2,4
Hose/Cable Carrier Installations	1,2,9,12	1,2,9,12
Pivot Pins and Pin Retainers	1,2	1,2
Sheaves, Sheave Pins	1,2	1,2
Bearings	1,2	1,2
Wear Pads	1,2	1,2
Covers or Shields	1,2	1,2
Platform Assembly		
Platform	1,2	1,2
Railing	1	1,2
Gate	1,5	1,5
Floor	1	1,2
Rotator	5,9,15	5,9,15
Lanyard Anchorage Point	1,2,10	1,2,10
Turntable Assembly		
Swing Bearing or Worm Gear	1,2,14	1,2,3,13,14
Oil Coupling	9	9
Swing Drive System	11	11
Turntable Lock	1,2,5	1,2,5
Hood, Hood Props, Hood Latches	5	1,2,5
Chassis Assembly		
Tires	16,17,18	16,17,18
Wheel Nuts/Bolts	15	15
Wheel Bearings	1,2	1,2,14,24
Steer Components	1,2,5	1,2,5
Drive Motors	1,2,5	1,2,5
Drive Hubs	11	11

Table 2-3. Inspection and Preventive Maintenance Schedule

AREA	INTERVAL	
	Pre-Delivery ¹ or Frequent ² Inspection	Annual ³ (Yearly) Inspection
Functions/Controls		
Platform Controls Return to Neutral/Off when Released	5,6	5,6
Ground Controls Return to Neutral/Off when Released	5,6	5,6
Function Control Locks, Guards, or Detents	1,5	1,5
Footswitch (Shuts Off Function when Released)	5	5
Emergency Stop Switches (Ground & Platform) Arrest all Platform Movement	5	5
Function Limit or Cutout Switch Systems	5	5
Capacity Indicator	5	5
Drive Brakes	5	5
Swing Brakes	5	5
Boom Synchronization/Sequencing Systems	5	5
Emergency Manual Descent Control	5	5
Power System		
Batteries	1,9	1,9,19
Battery Fluid	11	11
Battery Charger	5	5
Fuel Reservoir, Cap, and Breather	1,2,5	1,2,5
Hydraulic/Electric System		
Hydraulic Pumps	1,2,9	1,2,9
Hydraulic Cylinders	1,2,7,9	1,2,7,9
Cylinder Attachment Pins and Pin Retainers	1,2,9	1,2,9
Hydraulic Hoses, Lines, and Fittings	1,2,9,12	1,2,9,12
Hydraulic Filter	1,7,9	1,7,9
Hydraulic Fluid	7,11	7,11
Electrical Connections	1,20	1,20
Instruments, Gauges, Switches, Lights, Horn	1	1,5,23
General		
Operators and Safety Manuals in Storage Box	21	21
ANSI Manual of Responsibilities and AEM Safety Manual in Storage Box (ANSI and ANSI Export Only)	21	21
Capacity Decals Installed, Secure, Legible	21	21
All Decals/Placards Installed, Secure, Legible	21	21
Annual Machine Inspection Due	21	21
No Unauthorized Modifications or Additions	21	21
All Relevant Safety Publications Incorporated	21	21

Table 2-3. Inspection and Preventive Maintenance Schedule

AREA	INTERVAL	
	Pre-Delivery ¹ or Frequent ² Inspection	Annual ³ (Yearly) Inspection
General Structural Condition and Welds	2,4	2,4
All Fasteners, Pins, Shields, and Covers	1,2	1,2
Grease and Lubricate to Specifications	22	22
Function Test of All Systems	21	21,22
Paint and Appearance	7	7
Stamp Inspection Date on Frame		22
Notify JLG of Machine Ownership		22
Footnotes:		
¹ Prior to each sale, lease, or delivery		
² In service for 3 months or 150 Hours; or Out of service for 3 months or more; or Purchased used		
³ Annually, no later than 13 months from the date of the prior inspection		
Performance Codes:		
1 - Check for proper and secure installation		
2 - Visual inspection for damage, cracks, distortion or excessive wear		
3 - Check for proper adjustment		
4 - Check for cracked or broken welds		
5 - Operates Properly		
6 - Returns to neutral or "off" position when released		
7 - Clean and free of debris		
8 - Interlocks function properly		
9 - Check for signs of leakage		
10 - Decals installed and legible		
11 - Check for proper fluid level		
12 - Check for chafing and proper routing		
13 - Check for proper tolerances		
14 - Properly lubricated		
15 - Torqued to proper specification		
16 - No gouges, excessive wear, or cords showing		
17 - Properly inflated and seated around rim		
18 - Proper and authorized components		
19 - Fully charged		
20 - No loose connections, corrosion, or abrasions		
21 - Verify		
22 - Perform		
23 - Sealed Properly		
24 - Drain, Clean, Refill		




Figure 2-1. Engine Operating Temperature Specifications - Kubota

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter your information to search for manuals and parts.

* Brand:

* Model:

* Serial:

* Part Number:

SEARCH

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information:

Manufacturer:

Model:

Description:

Quantity:

Part Number:

Part Name:

Part Description:

Part Location:

Part Condition:

Part Status:

Part Color:

Part Material:

Part Weight:

Part Dimensions:

Part Price:

Part Notes:

Submit

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 3. CHASSIS & TURNTABLE

3.1 TIRES & WHEELS

Tire Damage

For polyurethane foam filled tires, JLG Industries, Inc. recommends that when any of the following are discovered, measures must be taken to remove the JLG product from service immediately and arrangements must be made for replacement of the tire or tire assembly.

- a smooth, even cut through the cord plies which exceeds 3 inches (7.5 cm) in total length
- any tears or rips (ragged edges) in the cord plies which exceeds 1 inch (2.5 cm) in any direction
- any punctures which exceed 1 inch in diameter
- any damage to the bead area cords of the tire

If a tire is damaged but is within the above noted criteria, the tire must be inspected on a daily basis to insure the damage has not propagated beyond the allowable criteria.

Tire Replacement

JLG recommends a replacement tire be the same size, ply and brand as originally installed on the machine. Please refer to the JLG Parts Manual for the part number of the approved tires for a particular machine model. If not using a JLG approved replacement tire, we recommend that replacement tires have the following characteristics:

- Equal or greater ply/load rating and size of original
- Tire tread contact width equal or greater than original
- Wheel diameter, width, and offset dimensions equal to the original
- Approved for the application by the tire manufacturer (including inflation pressure and maximum tire load)

Unless specifically approved by JLG Industries Inc. do not replace a foam filled or ballast filled tire assembly with a pneumatic tire. Due to size variations between tire brands, both tires on the same axle should be the same.

Wheel Replacement

The rims installed on each product model have been designed for stability requirements which consist of track width, tire pressure, and load capacity. Size changes such as rim width, center piece location, larger or smaller diameter, etc., without written factory recommendations, may result in an unsafe condition regarding stability.

Wheel Installation


It is extremely important to apply and maintain proper wheel mounting torque.

WARNING

WHEEL NUTS MUST BE INSTALLED AND MAINTAINED AT THE PROPER TORQUE TO PREVENT LOOSE WHEELS, BROKEN STUDS, AND POSSIBLE DANGEROUS SEPARATION OF WHEEL FROM THE AXLE. BE SURE TO USE ONLY THE NUTS MATCHED TO THE CONE ANGLE OF THE WHEEL.

Tighten the lug nuts to the proper torque to prevent wheels from coming loose. Use a torque wrench to tighten the fasteners. If you do not have a torque wrench, tighten the fasteners with a lug wrench, then immediately have a service garage or dealer tighten the lug nuts to the proper torque. Over-tightening will result in breaking the studs or permanently deforming the mounting stud holes in the wheels. The proper procedure for attaching wheels is as follows:

1. Start all nuts by hand to prevent cross threading. DO NOT use a lubricant on threads or nuts.
2. Tighten nuts in the following sequence:



- The tightening of the nuts should be done in stages. Following the recommended sequence, tighten nuts per wheel torque chart.

Table 3-1. Wheel Torque Chart

TORQUE SEQUENCE		
1st Stage	2nd Stage	3rd Stage
40 ft. lbs. (55 Nm)	100 ft. lbs. (130 Nm)	170 ft. lbs. (255 Nm)
1st Stage	2nd Stage	3rd Stage

- Wheel nuts should be torqued after first 50 hours of operation and after each wheel removal. Check torque every 3 months or 150 hours of operation.

3.2 SPINDLE

Setting Wheel Bearing End Play

NOTICE

BE SURE NOT TO OVER-TIGHTEN THE SPINDLE NUT.

- Tighten the spindle nut to assure the bearings are properly seated.
- Loosen the spindle nut completely until the nut can be turned by hand.
- Tighten the spindle nut by hand using a socket without rotating the hub.
- If the cotter pin can be assembled with the spindle nut finger tight, insert cotter pin without backing the nut off. If the cotter pin cannot be assembled with the spindle nut hand tight, tighten the spindle nut to the nearest available slot and insert cotter pin. If more than 1/2 of the cotter pin hole in the spindle can be seen in a slot, back nut off to nearest slot and insert pin.
- Check the unit for end play by moving the hub up & down parallel along the centerline of the spindle. If you can feel excessive end play (over the 0.010" [0.25 mm] specification), recheck the nut to see what is causing the excessive end play. Keep in mind that there can be some movement and still be within the 0.010" (0.25 mm) maximum specification. If there is no way of getting the excessive end play out by using your fingers, a socket or wrench may have to be used to set the end play.
- The units should be checked visually to make sure the cotter pins are installed and that the correct components have been used. Each unit must also be checked for the proper feel to make sure there isn't excessive end play and the hubs turn freely.

- Insert the dust cap and check to make sure the cotter pin is not going to interfere. Cap must be pressed all the way down. The unit should be checked again to assure it spins freely after the dust cap is installed.

Specifications

The end play specification is 0.001"/0.010" (0.025 / 0.254 mm) for all units.

Checking

The end play is checked by clamping the spindle in a fixture or vise and moving the hub parallel to the spindle centerline without rocking the hub. If the end play is set properly the following should apply:

- Hub should rotate freely when spun by hand.
- The hub should not be noticeably loose when moved parallel with spindle centerline.

Greasing Requirements

Hub assemblies shall have grease packed in the bearings via an appropriate greasing spindle or by hand. In either method, the bearing must be greased so the grease is forced through the entire bearing cavity and through the rollers of both inner and outer bearings.

Dust or grease caps used shall have grease applied to the inside of the cap.

The bearing cavity shall be filled 50 - 80% full of grease on all applications.

Dust or grease caps shall also be filled 10-20% full of grease on all applications prior to final assembly.

Visually verify that grease has flowed all rollers of the inner and outer bearings.





Figure 3-1. Spindle Assembly



- | | | |
|-----------------------|---------------------------------|-------------------------------|
| 1. Spindle | 6. Battery | 11. Drive Module (Left/Slave) |
| 2. Steer Angle Sensor | 7. Hydraulic Tank | 12. Drive Hub |
| 3. Steer Valve | 8. Swing Bearing | 13. Drive Motor |
| 4. Motor/Pump | 9. Swing Motor | 14. Drive Brake |
| 5. Battery Charger | 10. Drive Module (Right/Master) | 15. Dual Axial Sensor |

Figure 3-2. Chassis Component Location




Figure 3-3. Drive Components

3.3 TILT MODULE

When installing a new tilt module, always ensure that it is calibrated using the JLG Control System analyzer before operating the machine. Refer to Section 6, JLG Control System Analyzer Kit Instructions. Use a standard bubble level in two different directions to ensure that the machine's frame is level prior to installing the new tilt module.

1. Place the machine on a flat, level surface. Check for level by placing a bubble level on the frame in both directions.
2. Plug in the analyzer (Analyzer - PN 1600244, Cable - PN 1600633) into port J9 on the power module or port J1 on the platform module.
3. Use the right arrow key to curse over to "ACCESSLEVEL 2". Depress Enter.

4. Use Up/Down arrow keys to enter the following password "33271". Depress Enter.
5. Use the right arrow to curse over to "LEVEL VEHICLE". Depress Enter. Depress Enter again.
6. Verify that the tilt reading is now "0.0: 0.0".

⚠ WARNING

TO ASSURE PROPER OPERATION, THE MACHINE MUST BE LEVEL WHEN INSTALLING AND CALIBRATING A NEW TILT MODULE.





Figure 3-4. Cable Routing

3.4 SPEED SENSOR



For proper drive operation, the speed sensors must be properly installed and adjusted. The sensor operates on a leading pulse to show direction. If installed wrong, the sensor will not be able to sense the proper direction.




Figure 3-5. Relay




Figure 3-6. System Fuses




Figure 3-7. Ignition Relay Fuse




Figure 3-8. Drive Fuses





Figure 3-9. Drive Limit Switch



- | | | | |
|-------------------|-----------------------|-----------------------|-------------------------|
| 1. SteerCylinder | 7. Castle Nut | 13. Hub | 18. Castle Nut |
| 2. Rod End | 8. ThrustWasher | 14. LugNut | 19. Dust Cap |
| 3. Nut | 9. Lip Seal | 15. OuterBearing Cup | 20. Cotter Pin |
| 4. Shoulder Screw | 10. Bearing Cone | 16. OuterBearing Cone | 21. Capscrew |
| 5. Steer Link | 11. Inner Bearing Cup | 17. Tanged Washer | 22. Angle Sensor Switch |
| 6. Cotter Pin | 12. Wheel Stud | | |

Figure 3-10. Steering Installation and spindle

3.5 DRIVE HUB

Roll and Leak Testing

Torque-Hub units should always be roll and leak tested before disassembly and after assembly to make sure that the unit's gears, bearings and seals are working property. The following information briefly outlines what to look for when performing these tests.

NOTE: *The brake must be released before performing the roll test. This can be accomplished by either pressure testing using the Brake Leak Test procedure below or by tightening the 12 bolts into the piston through the end plate (See Brake Disassembly Procedure).*

NOTE: *Bolts must be removed while performing brake release test.*

Roll Test

The purpose of the roll test is to determine if the unit's gears are rotating freely and properly. You should be able to rotate the gears in your unit by applying constant force to the roll checker. If you feel more drag in the gears only at certain points, then the gears are not rolling freely and should be examined for improper installation or defects. Some gear packages roll with more difficulty than others. Do not be concerned if the gears in your unit seem to roll hard as long as they roll with consistency.


Leak Test (Main Unit)

The purpose of a leak test is to make sure the unit is air tight. You can tell if your unit has a leak if the pressure gauge reading on your leak checking fitting starts to fall after the unit has been pressurized and allowed to equalize. Leaks will most likely occur at the pipe plugs, the main seal or wherever o-rings or gaskets are located. The exact location of a leak can usually be detected by brushing a soap and water solution around the main seal and where the o-rings or gaskets meet on the exterior of the unit, then checking for air bubbles. If a leak is detected in a seal, o-ring or gasket, the part must be replaced, and the unit rechecked. Leak test at 10 psi for 20 minutes.

Tightening and Torquing Bolts

If an air impact wrench is used to tighten bolts, extreme care should be taken to ensure that the bolts are not tightened beyond their specified torque.

The following steps describe how to tighten and torque bolts or socket head capscrews in a bolt circle.



1. Tighten (but do not torque) bolt "A" until snug.
2. Go to the opposite side of the bolt circle and tighten bolt "B" until equally snug.
3. Crisscross around the bolt circle and tighten remaining bolts.
4. Now use a torque wrench to apply the specified torque to bolt "A".
5. Using the same sequence, crisscross around the bolt circle and apply an equal torque to the remaining bolts.

Main Disassembly

NOTE: Refer to Figure 3-11., Main Assembly - Sheet 1 of 2 and Figure 3-12., Main Assembly - Sheet 2 of 2.

1. Perform Roll Check and Leak Check if applicable prior to disassembling the unit.
2. Drain oil from unit. Note the condition and volume of the oil.
3. Remove Coupling (7) from Spindle End first.
4. Remove Retaining Ring (6G) by prying the open end of Retaining Ring out of the groove in the Ring Gear (1F) with a screwdriver, then grasp the loose end with pliers and pull the Retaining Ring completely out of the groove.
5. Remove the Cover Subassembly (6) from the unit. The unit can be carefully pressurized with air to pop the cover out of the unit. Washer (2) may have to be removed separately because of the loose attachment.


6. Remove the First Stage Sun Gear (10) if applicable.

NOTE: On units with ratios greater than 36:1 numerically, there will not be a separate First Stage Sun Gear (10), as the gear teeth will be integral to the Input Shaft (9).

7. Remove the Input Carrier Sub-assembly (3).
8. Remove the Second Stage Sun Gear (11).
9. Remove the Input Shaft (9).


NOTE: On units with a ratio 48:1, the Sun Gear (11) and the Input Shaft (9) will need to be removed together.

10. Remove the Output Stage Carrier Sub-assembly (4).
11. Loosen and remove the three Flat Head Bolts (19) that retain the Ring Gear (1F) to the Housing (1G).
12. Lift the Ring Gear (1F) off of the Housing (1G).
13. Remove the O-Ring (18) from between the Housing (1G) and the Ring Gear (1F).



- | | |
|------------------------------|--------------------------|
| 1F. Ring Gear | 6G. Retaining Ring |
| 1G. Housing | 7. Coupling |
| 2. Washer | 10. First Stage Sun Gear |
| 3. Input Carrier Subassembly | 15. I.D. Plate |
| 6. Cover Assembly | 17. O-ring |

Figure 3-11. Main Assembly - Sheet 1 of 2



- | | |
|-------------------------------|---------------------------|
| 1F. Ring Gear | 9. Input Shaft |
| 1G. Housing | 11. Second Stage Sun Gear |
| 4. Output Carrier Subassembly | 18. O-ring |
| 5. Retaining Ring | 19. Flat Head Bolt |
| | 20. Retaining Ring |

Figure 3-12. Main Assembly - Sheet 2 of 2


Output Carrier Disassembly

NOTE: Refer to Figure 3-13., Output Carrier and Figure 3-14., Planet Gear.

1. Using a 1/8" diameter punch, drive the Roll Pin (4G) into the Planet Shaft (4E) until it bottoms against the Carrier (3A).
2. Using a soft face hammer, tap the Planet Shaft (4E) out of the Carrier (4A).
3. Using a 1/8" diameter punch, drive the Roll Pin (4G) out of the Planet Shaft (4E).


NOTE: The Roll Pins (4G) should not be reused when reassembling the unit.

4. Slide the Planet Gear Sub-assembly (4) out of the Output Carrier (4A) being careful to not drop the Needle Bearings (4C) in the process.
5. Remove 4 Thrust Washers (48), 28 Needle Rollers (4C) and the Thrust Spacer (40) from the Second Stage Planet Gear (4F).
6. Repeat Steps 1 though 5 for the remaining two Planet Gears (4F).
7. Remove the Thrust Washer (4H) from the counterbore in the Output Carrier (4A).



- | | |
|--------------------|-------------------|
| 4A. Output Carrier | 4E. Planet Shaft |
| 4B. Thrust Washer | 4F. Planet Gear |
| 4C. Needle Bearing | 4G. Roll Pin |
| 4D. Thrust Spacer | 4H. Thrust Washer |

Figure 3-13. Output Carrier



- 4B. Thrust Washer
- 4C. Needle Bearing
- 4D. Thrust Spacer
- 4F. Planet Gear

Figure 3-14. Planet Gear


Input Carrier Disassembly

NOTE: Refer to Figure 3-15., Input Carrier.

1. Using a 1/8" diameter punch, drive the Roll Pin (4G) into the Planet Shaft (3E) until it bottoms against the Carrier (3A).
2. Using a soft face hammer, tap the Planet Shaft (3E) out of the Carrier (3A).
3. Using a 1/8" diameter punch, drive the Roll Pin (4G) out of the Planet Shaft (3E).

NOTE: The Roll Pins (4G) should not be reused when reassembling the unit.

4. Slide the Planet Gear (3F) and the two Thrust Washers (3B) out of the Carrier (3A).
5. Remove the 14 needle Bearings (3C) from the bore of the Planet Gear (3F).
6. Repeat steps 1 through 5 for each of the two remaining planet gears.



- | | |
|--------------------|------------------|
| 3A. Carrier | 3E. Planet Shaft |
| 3B. Thrust Washer | 3F. Planet Gear |
| 3C. Needle Bearing | 4G. Roll Pin |


Figure 3-15. Input Carrier

Hub-spindle Disassembly

NOTE: Refer to Figure 3-16., Hub Spindle.

1. Place unit on bench with Spindle (1A) end down.
2. Remove Retaining Ring (1J) with appropriate tool.
3. Remove Spacer (1N).
4. Remove Bearing Cone (1C) from Bearing Cup (1D) in Hub (1G).
5. Lift Hub (1G) off of Spindle (1A). Remove Boot Seal (1Q) from Hub (1G) if applicable.
6. If necessary, press 9 Studs (1H) out of Hub (1G). Locate Hub (1G) on Seal (1B) end.
7. Remove Seal (1B) from Hub (1G).
8. Remove Bearing Cone (1E) from Hub (1G).
9. Using a soft steel rod, knock both Bearing Cups (1D) out of Hub (1G).

NOTE: The Seal (1B) should NOT be reused when reassembling the unit.



- | | |
|--------------------------|--------------------|
| 1A. Spindle | 1H. Stud |
| 1D. Tapered Bearing Cup | 1J. Retaining Ring |
| 1E. Tapered Bearing Cone | 1N. Spacer |
| 1G. Hub (Housing) | 1Q. Seal Boot |

Figure 3-16. Hub Spindle


Cover Disassembly

NOTE: Refer to Figure 3-17., Cover Assembly.

1. Remove O-Ring (17) from groove in Cover (6A).
2. Remove Thrust Washer (2) from Cover (6A) pockets.
3. Unscrew two Hex Head Bolts (6C) and remove Disengage Cap (6B) from Cover (6A).

4. Pull Disengage Rod (6D) out from Cover (6A).
5. Use appropriate tool to remove O-Ring (6E) from internal groove in Cover (6A).
6. Remove two O-Ring Pipe Plugs (6F) from Cover (6A).

NOTE: For reassembling unit, please refer to the exploded views in the disassembly sections.



- | | |
|-------------------|-------------------|
| 2. Thrust Spacer | 6D. Disengage Rod |
| 6A. Cover | 6E. O-ring |
| 6B. Disengage Cap | 6F. Pipe Plug |
| 6C. Bolt | 17. O-ring |

Figure 3-17. Cover Assembly

Input Carrier Assembly

NOTE: Refer to Figure 3-15., Input Carrier.

1. Apply a liberal coat of grease to the bore of one Input Planet Gear (3F).
2. Line the inside of the Planet Gear (3F) with 14 Needle Rollers (3C).

NOTE: The last roller installed must be installed end wise. That is, the end of the last roller must be placed in between the ends of the two rollers which form the space, and then slid, parallel to the other rollers, into place.

3. Set Carrier (3A) in an upright position.
4. Insert a Planet Shaft (3E) into the planet shaft hole in the end of the Carrier (3A) opposite the splined end. The end of the planet shaft that does NOT have the roll pin hole should be inserted into the carrier FIRST.
5. Place one Thrust Washer (3B) onto the end of Planet Shaft (3E). Make sure the flat faces towards the inside of the carrier and make sure the button fits in the pocket on the inside of the Carrier (3A) towards the OD.
6. Following the thrust washer, place Planet Gear (3F) with needle rollers, onto Planet Shaft (3E).
7. Following the planet gear, place one more Thrust Washer (3B) onto Planet Shaft (3E). Align the Thrust Washer (3B) in the same manner described in Step 5.
8. Now insert Planet Shaft (3E) through the opposite planet shaft hole on Carrier (3A). Use an alignment punch or similar tool to align the roll pin holes on Carrier (3A) and Planet Shaft (3E).

NOTE: Be sure not to hit the Planet Gears (3F) when driving in the Roll Pins (4G).

9. Drive Roll Pin (4G) down into the aligned roll pin holes. Pin should be flush with the flat of carrier.
10. Repeat Steps 1-9 for the installation of the two remaining Planet Gears (3F).

NOTE: Some grease may need to be applied to the Thrust Washers (3B) to hold them in place while installing the planet gears.

Output Planet Gear Assembly

NOTE: Refer to Figure 3-14., Planet Gear.

1. Apply a liberal coat of grease to the bore of one Output Planet Gear (4F).
2. Line the inside of the Planet Gear (4F) with 14 Needle Rollers (4C).

NOTE: The last roller installed must be installed end wise. That is, the end of the last roller must be placed in between the ends of the two rollers which form the space, and then slid, parallel to the other rollers, into place.

3. Place Spacer (4D) into the bore of the Output Planet (4F).
4. Repeat Step 2 to put in second roll of Needle Rollers (4C).
5. Apply grease to hold two Thrust Washers (4B) together and onto Output Planet Gear (4F) counterbore. Do the same to the other side.
6. Repeat Steps 1-5 to finish the assembly of the two remaining Output Planet Gears (4F).

Output Carrier Assembly

NOTE: Refer to Figure 3-13., Output Carrier

1. Place Thrust Washer (4H) into counterbore of Carrier (4A). BE SURE the small diameter side of Washer (4H) facing planet gear side.
2. Place Planet Gear Sub-assembly (4) into Carrier (4A). Visually align the planet gear bore with one of the planet shaft holes on the Carrier (4A).
3. Insert a Planet Shaft (4E) into the planet shaft hole described in Step 2 on Carrier (4A). The end of the planet shaft that does NOT have the roll pin hole should be inserted into the Carrier (4A) FIRST.
4. Now insert Planet Shaft (4E) through the first set of Thrust Washers (4B), Planet gear, then the second set of Thrust Washers (4B). Use an alignment punch or similar tool to align roll pin holes on Carrier (4A) and Planet Shaft (4E).

NOTE: Be sure not to hit the Planet Gears (4F) when driving in Roll Pins (4G).

5. Drive Roll Pin (4G) down into the aligned roll pin holes. Pin should be flush with OD of Carrier (4A).
6. Repeat Steps 1-5 for the installation of the two remaining Planet Gears (4F).

Hub-spindle Assembly

NOTE: Refer to Figure 3-16., Hub Spindle

NOTE: Spray a light film of oil on all component parts during assembly.

1. Place Hub (1 G) into pressing base. Press nine Studs (1H) into Hub.

NOTE: Use enough pressure to press in studs. Don't use excessively high pressure to press in studs or hub may crack.

NOTE: Spray a generous amount of oil on bearings during installation.

2. Press Bearing Cup (1D) into hub using appropriate pressing tool.
3. Turn hub over and press Bearing Cup (1D) into hub using appropriate pressing tool.
4. Place Bearing Cone (1E), into Bearing Cup (1D).
5. Grease Seal (1B) lip and press seal into Hub (1G) using appropriate tool until seal is flush with end of hub.
6. Press Seal Boot (1Q) onto Hub (1G) if required. Turn Hub (1G) over and lower onto Spindle (1A).
7. Install Bearing Cone (1C) into Bearing Cup (1D).
8. Place Bearing Spacer (1N) on top of Bearing Cone (1C).
9. Using appropriate tool, install Retaining Ring (1J) into Spindle (1A) groove. Make sure ring is completely seated in groove.

NOTE: Extra bearing pre-load caused by using tool in Step #9 must be removed. This should be done by placing a tool (NOT THE SAME TOOL USED IN STEP #9) on the end of the spindle, and then striking the tool with a piece of barstock. This should be adequate to remove any additional bearing pre-load.

Cover Assembly

NOTE: Refer to Figure 3-17., Cover Assembly.

1. Grease O-Ring (6E) and insert into internal groove in Cover (6A).
2. Assemble Disengage Cap (6B) onto Cover (6A) using two Hex Head Bolts (6C). Torque bolts to 70-80 in-lbs.
3. Insert Disengage Rod (6D) into hole in Cover (6A) until it touches the inside of the Disengage Cap (6B).

NOTE: The Disengage Rod can be inserted either end first.

4. Grease Face of Thrust Washer (2) and place in Cover (6A) making sure that tangs on washer seat into pockets in cover.
5. Install O-Ring Pipe Plugs (6F) into Cover (6A). The plugs should be hand tight according to SAE standard.

Main Assembly

NOTE: Refer to Figure 3-11., Main Assembly - Sheet 1 of 2 and Figure 3-12., Main Assembly - Sheet 2 of 2.

NOTE: All components should receive a generous amount of lubricant oil as they are being assembled.

1. Place Hub-Spindle Sub-Assembly on the bench.
2. Grease O-Ring (18) and place it into groove of Hub (1G).
3. Place Ring Gear (1F) onto Hub (1G). Align the three shipping capscrew holes on Hub (1G) and Ring Gear (1F).
4. Install three shipping Capscrews (19) into ring gear and hub. Torque them to 15-20 ft-lbs.
5. Place Output Carrier Sub-Assembly (4) into mesh with Spindle (1A) splines.
6. Place External Retaining Ring (5) over 13T spline to the retaining groove on Input Shaft (9).

NOTE: For ratio 48:1, assemble Output Sun Gear (11) over Input Shaft (9) first, then install External Retaining Ring (5).

7. Using appropriate tool to install Retaining Ring (20) into groove on Output Sun (11)
8. Place Input Shaft (9) spline end into mesh with Internal Coupling (7) splines.
9. With the modified spline end facing up, place the Output Sun Gear (11) into mesh with the output planet gears.
10. Place Input Carrier Sub-Assembly (3) onto Output Sun Gear (11) splines. Drop Input Sun (10) into mesh with planet gears for specific ratios, if required. (No timing required).
11. Grease O-Ring (17) and insert into groove in Cover Sub-Assembly (6).
12. Install Cover Sub-Assembly (6) into Ring Gear (1F) counterbore and install Retaining Ring (6G) into groove in Ring Gear (1F).
13. Attach ID Tag (15) onto unit using Drive Screws (16).
14. Check disconnect, roll and air check unit, leak check brake, and record release pressure.
15. Insert Plastic Plug (12) into place if applicable.




Figure 3-18. Drive Hub - Sheet 1 of 2

1A Spindle	1K Retaining Ring	3F Planet Gear	5 Retaining Ring	9 Input Shaft
1B Lip Seal	1L Spring	4A Output Carrier	6A Cover	10 Input Sun Gear
1C Tapered Bearing Cone	1M Thrust Washer	4B Thrust Washer	6B Disengage Cap	11 Output Sun Gear
1D Tapered Bearing Cup	1Q Seal Boot	4C Needle Bearing	6C Bolt	15 ID Plate
1E Tapered Bearing Cone	2 Thrust Spacer	4D Thrust Spacer	6D Dowel Pin	16 Drive Screw
1F Ring Gear	3A Input carrier	4E Planet Shaft	6E O-ring	17 O-ring
1G Hub (Housing)	3B Thrust Washer	4F Planet Gear	6F Pipe Plug	18 O-ring
1H Stud	3C Needle Bearing	4G Roll Pin	6G Retaining Ring	19 Bolt
1J Retaining Ring	3E Planet Shaft	4H Thrust Washer	7 Coupling	20 Retaining Ring

Figure 3-19. Drive Hub - Sheet 2 of 2

3.6 DRIVE MOTOR

Removal

1. Place machine on the firm level surface.
2. Disconnect the battery power and all electrical connections from the drive motor.

NOTE: *The drive motor weighs approximately 95 lb (43 kg).*

3. Use suitable lifting device to support the drive motor.
4. Remove four bolts attached drive motor to the frame.
5. Remove the motor from machine and place on a clean operating surface.
6. Clean the motor for dirt. Remove rust or corrosion from coupling shaft.

Disassembly

NOTE: *Refer to Figure 3-20., Drive Motor.*

1. Place the motor in a soft jawed vice, with coupling shaft from motor pointing down and the vise jaws clamping firmly to the sides of the end shield (8).

⚠ WARNING

IF THE MOTOR IS NOT FIRMLY HELD IN THE VISE, IT COULD BE DISLODGED DURING THE SERVICE PROCEDURES, CAUSING INJURY.

2. Remove the three nuts (4) and relevant washers (5) from the terminal board (3).
3. Remove the terminal board (3) from the terminal base (6).
4. Remove the screws (7). Make sure that the screws are not damage.
5. Remove four screw (35) that attach the drive brake (36) onto the drive motor. Remove the drive brake.
6. Remove the terminal base (6) from the stator (2).
7. Remove the temperature sensor (27) from the stator (2).

8. Remove the screws (22) from the retaining plate (23).
9. Remove the retaining plate (23) from the cover (21).
10. Remove the cover (21) from the shield end (18).
11. Remove the seals (20) and (19).
12. Disconnect the connector (34) from the sensor (13).
13. Remove the sensor (13) from shield end.
14. Remove four screws (26) attached to the drive end plate (8).
15. Remove end plate and shield end.
16. Remove the Shaft Seal (10). To avoid damaging the shaft during removal, install a large sheet metal screw into the chuck of a slide hammer. Drive the screw into the seal surface and use the slide hammer to pull the seal.
17. Remove Washer (12), O-ring (9) and Bearing from Stator (2).
18. Remove the retainer clips (31) and (30).
19. Remove the Bearing (24), O-ring (28) and retainer clip (25).
20. Use mallet to remove the Gear (33) and remove Gear Key (32) from the Rotor (29).
21. Remove the rotor (29) from the stator (2).
22. Remove the stator (2).
23. Keep all parts on a clean operating surface.

Inspection

Inspect the new seal, the motor housing seal bore, and the sealing area on the shaft for rust, wear, and contamination. Polish the shaft and clean the housing if necessary.

Assembly

NOTE: Refer to Figure 3-20., Drive Motor.

1. Install the rotor (29) into the stator (2).
2. Install the gear key (32) on to the rotor shaft.
3. Align the gear notch with key and install the gear (33) on to the rotor shaft.
4. Install the bearing (24), o-ring (28) and retainer clip (25).
5. Install the retainer clips (31) and (30).
6. Install washer (12), o-ring (9) and bearing into the stator (2).
7. Install the shaft seal (10).
8. Attach four bolts to secure the drive end plate with the shield end.
9. Connect the connector (34) to the sensor (13).
10. Install the sensor (13) to the shield end.
11. Install the seals (20) and (19).
12. Install the cover (21) onto the shield end (18).
13. Install the retaining plate (23) onto the cover (21).
14. Attach the bolts (22) to secure the retaining plate (23).
15. Attach the temperature sensor (27) to the stator (2).
16. Install the terminal base (6) onto the stator (2).
17. Install the screws (7).
18. Install the terminal board (3) onto the terminal base (6).
19. Attach the three nuts (4) and relevant washers (5) to the terminal board (3).
20. Install the drive brake (36) onto the drive motor.
21. Attach the screws (35) to the drive brake (36).

Installation

NOTE: The drive motor weighs approximately 95 lb (43 kg).

1. Use suitable lifting device to support the drive motor.
2. Install the drive motor to the machine.


⚠ CAUTION

INCORRECT SHAFT ALIGNMENT MAY RESULT IN DAMAGE TO DRIVE SHAFT, BEARINGS, OR SEAL WHICH CAN CAUSE EXTERNAL OIL LEAKAGE.

3. Make sure that the pump shaft is properly aligned.
4. Use the four bolts and attach the drive motor to the machine. Tighten the bolts to torque 35 ft. lbs. (48 Nm).

NOTE: Apply Medium Strength Threadlocking Compound to bolts before installation.

5. Install drive brake on to the drive motor.
6. Reconnect all electrical connections to the drive motor.
7. Start the machine and check the motor for proper functioning.



- | | | | |
|--------------------|----------------|------------------------|-------------------|
| 1. Not Included | 10. Shaft Seal | 19. Seal | 28. O-Ring |
| 2. Stator | 11. Bearing | 20. Seal | 29. Rotor |
| 3. Terminal Board | 12. Washer | 21. Cover | 30. Retainer Clip |
| 4. Nut | 13. Sensor | 22. Screw | 31. Retainer Clip |
| 5. Washer | 14. Screw | 23. Retaining Plate | 32. Key |
| 6. Terminal Base | 15. Wedge | 24. Bearing | 33. Gear |
| 7. Screw | 16. Connector | 25. Retainer Clip | 34. Connector |
| 8. Drive End Plate | 17. Male Pin | 26. Screw | 35. Screw |
| 9. O-Ring | 18. End Shield | 27. Temperature Sensor | 36. Drive Brake |

Figure 3-20. Drive Motor

3.7 SWING BEARING

Turntable Bearing Mounting Bolt Condition Check

NOTICE

THE SWING BEARING IS ONE OF THE MOST CRITICAL POINTS ON AN MOBILE ELEVATING WORK PLATFORM IT IS HERE THAT THE STRESSES OF LIFTING ARE CONCENTRATED, AT THE CENTER OF ROTATION. BECAUSE OF THIS, PROPER MAINTENANCE OF THE SWING BEARING BOLTS IS A MUST FOR SAFE OPERATION.

NOTE: This check is designed to replace the existing bearing bolt torque checks on JLG Lifts in service. This check must be performed after the first 50 hours of machine operation and every 600 hours of machine operation thereafter. If during this check any bolts are found to be missing or loose, replace missing or loose bolts with new bolts and torque to the value specified in the torque chart, after lubricating the bolt threads with High Strength Threadlocking Compound. After replacing and retorquing bolt or bolts recheck all existing bolts for looseness.

1. Check the frame to bearing. Attach bolts as follows:
 - a. Elevate the fully retracted boom to 70 degrees (full elevation).
 - b. At the positions indicated on Figure 3-22. try and insert the 0.0015" feeler gauge between the bolt head and hardened washer at the arrow indicated position.
 - c. Assure that the 0.0015" feeler gauge will not penetrate under the bolt head to the bolt shank.
 - d. Swing the turntable 90 degrees, and check some selected bolts at the new position.
 - e. Continue rotating the turntable at 90 degrees intervals until a sampling of bolts have been checked in all quadrants.

2. Check the turntable to bearing. Attach bolts as follows:
 - a. Elevate the fully retracted boom to 70 degrees (full elevation).
 - b. At the positions indicated on Figure 3-21. try and insert the 0.0015" feeler gauge between the bolt head and hardened washer at the arrow indicated position.
 - c. Lower the boom to horizontal and fully extend the boom.
 - d. At the position indicated on Figure 3-21. try and insert the 0.0015" feeler gauge between the bolt head and hardened washer at the arrow indicated position.




Figure 3-21. Swing Bearing Feeler Gauge Check

Wear Tolerance

1. With the boom positioned over the side of the machine, the Upper Boom horizontal with telescope fully

extended and Mid/Lower Boom stowed, (See Figure 3-22.), using a magnetic base dial indicator, measure and record the distance between the swing bearing and turntable. (See Figure 3-23.)




Figure 3-22. Swing Bearing Tolerance Boom Placement

2. At the same point, with the boom positioned over the side of the machine, the Upper Boom fully elevated and the Mid/Lower Boom fully elevated, (See Figure 3-22.) using a magnetic base dial indicator, measure and

record the distance between the swing bearing and turntable (See Figure 3-23.).




Figure 3-23. Swing Bearing Tolerance Measuring Point

3. If a difference greater than 0.057 in. (1.40 mm) is determined, the swing bearing should be replaced.
4. If a difference less than 0.057 in. (1.40 mm) is determined, and any of the following conditions exist, the bearing should be removed.
 - a. Metal particles in the grease.
 - b. Increased drive power.
 - c. Noise.
 - d. Rough rotation.
5. If bearing inspection shows no defects, reassemble bearing and return to service.

Replacement of Swing Bearing

1. Removal.
 - a. Attach an adequate support sling to the boom and draw all slack from sling. Prop or block the boom if feasible.
 - b. Tag and disconnect hydraulic lines running through center of turntable and frame. Use a suitable container to retain any residual hydraulic fluid. Cap lines and ports.
 - c. Attach suitable overhead lifting equipment to the base of turntable weldment.
 - d. Use a suitable tool to scribe a line on the inner race of the swing bearing and on the underside of the turntable. This will aid in aligning the bearing upon installation. Remove bolts, nuts and washers which attach the turntable to the bearing inner race. Discard nuts and bolts.
 - e. Use the lifting equipment to carefully lift the complete turntable assembly from the bearing. Ensure that no damage occurs to the turntable, bearing or frame mounted components.
 - f. Carefully place the turntable on a suitably supported trestle.
 - g. Use a suitable tool to scribe a line on the outer race of the swing bearing and the frame. This line will aid in aligning the bearing upon installation. Remove the bolts and washers which attach the outer race of the bearing to the frame. Discard the bolts. Use suitable lifting equipment to remove the bearing and rotation box assembly from the frame; move to a clean, suitably supported operating surface.
 - h. Remove the two capscrews securing the bearing to the rotation box to separate the two for inspection.

2. Installation.
 - a. Install bearing to rotation box with two capscrews, so that fill plug of bearing is as close to gear as bolt pattern will allow. Do not tighten capscrews.
 - b. Line up high spot (blue) of bearing with center tooth of worm gear. Set backlash to 0.008 - 0.010 inch (0.20 - 0.25 mm). Tighten capscrews as shown in Figure 3-24., Swing Bearing Torquing Sequence.
 - c. Apply Tribol Molub-Alloy 936 Open Gear Compound to bearing and worm gear teeth.
 - d. Grease bearing with Mobilith SHC Bearing Grease. Grease fitting is on inside wall of inner race of bearing.

NOTE: If Tribol Molub-Alloy 936 Open Gear Compound or Mobilith SHC Bearing Grease are not available, Multi-Purpose Grease (MPG) can be substituted, however the service interval will be shorter.

- e. Using suitable lifting equipment, install bearing/rotation box assembly to frame with soft spot (red) 90 degrees relative to load axis. If reusing old bearing, ensure that scribed line of outer race of the bearing aligns with the scribed mark on the frame.

CAUTION

JLG INDUSTRIES RECOMMENDS THAT ALL REMOVED GRADE 8 BEARING NUTS AND BOLTS BE DISCARDED AND REPLACED WITH NEW NUTS AND BOLTS. SINCE THE SWING BEARING IS THE ONLY STRUCTURAL LINK BETWEEN THE FRAME AND TURNTABLE, IT IS IMPERATIVE THAT SUCH REPLACEMENT HARDWARE MEETS JLG SPECIFICATIONS. USE OF GENUINE JLG HARDWARE IS HIGHLY RECOMMENDED.

- f. Apply a light coating of High Strength Threadlocking Compound to the new bearing bolts and loosely install the bolts and washers through the frame and outer race of bearing.

NOTICE

IF COMPRESSED AIR OR ELECTRICALLY OPERATED IMPACT WRENCH IS USED FOR TIGHTENING THE BEARING ATTACHMENT BOLTS, THE TORQUE SETTING ACCURACY OF THE TOOL SHOULD BE CHECKED PRIOR TO USE.

- g. Following the torque sequence diagram shown in Figure 3-24., tighten the bolts to an initial torque of 130 ft. lbs. (175 Nm). Then following the same sequence, tighten to a final torque of 190 ft. lbs. (260 Nm).
- h. Remove lifting equipment from bearing.
- i. Use suitable lifting equipment to carefully position the turntable assembly above the machine frame.
- j. Carefully lower the turntable onto the swing bearing. Ensure that the scribed line of the inner race of the bearing aligns with the scribed mark on the turntable. If a new swing bearing is used, ensure that the filler plug fitting is at 90 degrees from the fore and aft centerline of the turntable.
- k. Apply a light coating of High Strength Threadlocking Compound to the new bearing bolts and install through the turntable and inner race of bearing.
- l. Following the torque sequence shown in Figure 3-24., tighten the bolts to an initial torque of 130 ft. lbs. (175 Nm). Then following the same sequence, tighten the bolts to 190 ft. lbs (260 Nm).
- m. Remove the lifting equipment.
- n. Route hydraulic lines through center of turntable and frame and connect as tagged prior to removal.
- o. Using all applicable safety precautions, activate the hydraulic system and functionally check swing system for proper and safe operation.




Figure 3-24. Swing Bearing Torquing Sequence




Figure 3-25. Swing Bearing Removal


Swing Bearing Torque Value

Install with JLG Threadlocker - 190 ft. lbs. (260 Nm).

Checking Worm Gear End Play


NOTE: JLG Industries requires that a annual inspection be performed on the worm gear end play.

1. Using a dial indicator, measure end play of worm gear, by applying side to side movement by hand to platform.
2. If tolerance exceeds 0.010", reduce end play to less than 0.005". Refer to Adjusting End Play.



Adjusting End Play

1. Remove end plate.
2. Measure and record total thickness of existing shim pack.
3. Determine thickness of shim pack required to obtain 0.001" - 0.005" end play.
4. Adjust shim pack thickness as required to obtain proper end play. Reduce end play by removing thicker shims and replacing with thinner shims, included in kit.
5. Replace end plate and torque bolts to 90 ft. lbs. (122 Nm).
6. Recheck end play.






Figure 3-26. Swing Components

3.8 SWING MOTOR





Figure 3-27. Swing Motor - Cutaway

⚠ CAUTION

IF THE HYDRAULIC SYSTEM FLUID BECOMES OVERHEATED [IN EXCESS OF 200°F (93.3°C)], SEALS IN THE SYSTEM CAN SHRINK, HARDEN OR CRACK, THUS LOSING THEIR SEALING ABILITY.

Table 3-2. Swing Motor Troubleshooting

Trouble	Cause	Remedy
Oil Leakage	<ol style="list-style-type: none"> Hose fittings loose, worn or damaged. Oil seal rings (4) deteriorated by excess heat. Special bolt (1, 1A, 1B or 1C) loose or its sealing area deteriorated by corrosion. Internal shaft seal (16) worn or damaged. Worn coupling shaft (12) and internal seal (16). 	<p>Check & replace damaged fittings or "O" Rings. Torque to manufacturers specifications.</p> <p>Replace oil seal rings by disassembling unit.</p> <p>(a) Loosen then tighten single bolt to torque specification. (b) Replace bolt.</p> <p>Replace seal. Disassembly of motor unit necessary.</p> <p>Replace coupling shaft and seal by disassembling unit.</p>
Significant loss of speed under load	<ol style="list-style-type: none"> Lack of sufficient oil supply High internal motor leakage Severely worn or damaged internal splines. Excessive heat. 	<p>(a) Check for faulty relief valve and adjust or replace as required. (b) Check for and repair worn pump. (c) Check for and use correct oil for temperature of operation.</p> <p>Replace worn rotor set by disassembling unit.</p> <p>Replace rotor set, drive link and coupling shaft by disassembling unit.</p> <p>Locate excessive heat source (usually a restriction) in the system and correct the condition.</p>
Low mechanical efficiency or undue high pressure required to operate unit	<ol style="list-style-type: none"> Line blockage Internal interference Lack of pumping pressure Excessive binding or loading in system external to motor unit. 	<p>Locate blockage source and repair or replace.</p> <p>Disassemble unit, identify and remedy cause and repair, replacing parts as necessary.</p> <p>Check for and repair worn pump.</p> <p>Locate source and eliminate cause.</p>



- | | | | | | |
|---------------|--------------------|--------------------|--------------------|-----------------------|-------------------|
| 1. Bolt | 6. Commutator Ring | 8C. Stator Vane | 12. Coupling Shaft | 17. Backup Ring | 22. Not Used |
| 2. End Cover | 7. Manifold | 8D. Stator Half | 13. Inner Bushing | 18. Housing | 23. Not Used |
| 3. Seal Ring | 8. Rotor Set | 9. Wear Plate | 14. Thrust Washer | 19. Outer Bushing | 24. Not Used |
| 4. Seal Ring | 8A. Rotor | 10. Drive Link | 15. Thrust Bearing | 20. Dirt & Water Seal | 25. Backup Washer |
| 5. Commutator | 8B. Stator Half | 11. Thrust Bearing | 16. Seal | 21. Not Used | |

Figure 3-28. Swing Motor - Exploded View

Preparation Before Disassembly

- Before you disassemble the motor unit or any of its components read this entire section. It provides important information on parts and procedures you will need to know to service the motor.
- Thoroughly clean off all outside dirt, especially from around fittings and hose connections, before disconnecting and removing the motor. Remove rust or corrosion from coupling shaft.
- Remove coupling shaft connections and hose fittings and immediately plug port holes and fluid lines.
- Remove the motor from system, drain it of fluid and take it to a clean work surface.
- Clean and dry the motor before you start to disassemble the unit.
- As you disassemble the motor clean all parts, except seals, in clean petroleum-based solvent, and blow them dry.

⚠ WARNING

PETROLEUM-BASE SOLVENTS ARE FLAMMABLE. BE EXTREMELY CAREFUL WHEN USING ANY SOLVENT. EVEN A SMALL EXPLOSION OR FIRE COULD CAUSE INJURY OR DEATH.

⚠ WARNING

WEAR EYE PROTECTION AND BE SURE TO COMPLY WITH OSHA OR OTHER MAXIMUM AIR PRESSURE REQUIREMENTS.


⚠ CAUTION

NEVER STEAM OR HIGH PRESSURE WASH HYDRAULIC COMPONENTS. DO NOT FORCE OR ABUSE CLOSELY FITTED PARTS.

- Keep parts separate to avoid nicks and burrs.
- Discard all seals and seal rings as they are removed from the motor. Replace all seals, seal rings and any damaged or worn parts with OEM approved service parts.

Disassembly and Inspection


1. Place the motor in a soft jawed vice, with coupling shaft (12) pointed down and the vise jaws clamping firmly on the sides of the housing (18) mounting flange or port bosses. Remove manifold port O-Rings if applicable.




⚠ WARNING


IF THE MOTOR IS NOT FIRMLY HELD IN THE VISE, IT COULD BE DISLODGED DURING THE SERVICE PROCEDURES, CAUSING INJURY.

2. Scribe an alignment mark down and across the motor components from end cover (2) to housing (18) to facilitate reassembly orientation where required.





3. Remove the special ring head bolts (1) using an appropriate 1/2 or 9/16 inch size socket. Inspect bolts for damaged threads, or sealing rings, under the bolt head. Replace damaged bolts.



4. Remove end cover assembly (2) and seal ring (4). Discard seal ring.



5. Thoroughly wash end cover (2) in proper solvent and blow dry. Be sure the end cover valve apertures are free of contamination. Inspect end cover for cracks and the bolt head recesses for good bolt head sealing surfaces. Replace end cover as necessary.



NOTE: A polished pattern (not scratches) on the cover from rotation of the commutator (5) is normal. Discoloration would indicate excess fluid temperature, thermal shock, or excess speed and require system investigation for cause and close inspection of end cover, commutator, manifold, and rotor set.

6. Remove commutator ring (6). Inspect commutator ring for cracks, or burrs.



7. Remove commutator (5) and seal ring (3) Remove seal ring from commutator, using an air hose to blow air into ring groove until seal ring is lifted out and discard seal ring. Inspect commutator for cracks or burrs, wear, scoring, spalling or brinelling. If any of these conditions exist, replace commutator and commutator ring as a matched set.




8. Remove manifold (7) and inspect for cracks surface scoring, brinelling or spalling. Replace manifold if any of these conditions exist. A polished pattern on the ground surface from commutator or rotor rotation is normal. Remove and discard the seal rings (4) that are on both sides of the manifold.



NOTE: The manifold is constructed of plates bonded together to form an integral component not subject to further disassembly for service. Compare configuration of both sides of the manifold to ensure that same surface is reassembled against the rotor set.

SECTION 3 - CHASSIS & TURNTABLE


9. Remove rotor set (8) and wearplate (9), together to retain the rotor set in its assembled form, maintaining the same rotor vane to stator contact surfaces. The drive link (10) may come away from the coupling shaft (12) with the rotor set, and wearplate. You may have to shift the rotor set on the wearplate to work the drive link out of the rotor and wearplate. Inspect the rotor set in its assembled form for nicks, scoring, or spalling on any surface and for broken or worn splines. If the rotor set component requires replacement, the complete rotor set must be replaced as it is a matched set. Inspect the wearplate for cracks, brinelling, or scoring. Discard seal ring (4) that is between the rotor set and wearplate.



NOTE: The rotor set (8) components may become disassembled during service procedures. Marking the surface of the rotor and stator that is facing UP, with etching ink or grease pencil before removal will ensure correct reassembly of rotor into stator and rotor set into motor. Marking all rotor components and mating spline components for exact repositioning at assembly will ensure maximum wear life and performance of rotor set and motor.

NOTE: A polished pattern on the wear plate from rotor rotation is normal.

10. Place rotor set (8) and wear plate (9) on a flat surface and center rotor in stator such that two rotor lobes (180 degrees apart) and a roller vane centerline are on the same stator centerline. Check the rotor lobe to roller vane clearance with a feeler gage at this common centerline. If there is more than 0.005 inches (0.13 mm) of clearance, replace rotor set.




NOTE: If rotor set (8) has two stator halves and two sets of seven vanes as shown, check the rotor lobe to roller vane clearance at both ends of rotor.

11. Remove drive link (10) from coupling shaft (12) if it was not removed with rotor set and wear plate. Inspect drive link for cracks and worn or damaged splines. No perceptible lash (play) should be noted between mating spline parts. Remove and discard seal ring (4) from housing (18).



12. Check exposed portion of coupling shaft (12) to be sure you have removed all signs of rust and corrosion which might prevent its withdrawal through the seal and bearing. Crocus cloth or fine emery paper may be used.



13. Remove coupling shaft (12), by pushing on the output end of shaft. Inspect coupling shaft bearing and seal surfaces for spalling, nicks, grooves, severe wear or corrosion and discoloration. Inspect for damaged or worn internal and external splines or keyway. Replace coupling shaft if any of these conditions exist.



NOTE: Minor shaft wear in seal area is permissible. If wear exceeds 0.020 inches (0.51 mm) diametrically, replace coupling shaft.

NOTE: A slight "polish" is permissible in the shaft bearing areas. Anything more would require coupling shaft replacement.

14. Remove and discard seal ring (4) from housing (18).

SECTION 3 - CHASSIS & TURNTABLE

15. Remove thrust bearing (15) and thrust washer (14). Inspect for wear, brinelling, corrosion and a full complement of retained rollers.




16. Remove seal (16) and backup ring (17) from housing (18) and backup washer (25). Discard both.



17. Remove housing (18) from vise, invert it and remove and discard seal (20). A blind hole bearing or seal puller is required.




18. Inspect housing (18) assembly for cracks, the machined surfaces for nicks, burrs, brinelling or corrosion. Remove burrs that can be removed without changing dimensional characteristics. Inspect tapped holes for thread damage. If the housing is defective in these areas, discard the housing assembly.



19. If the housing (18) assembly has passed inspection to this point, inspect the housing bearings/bushings (19) and (13) and if they are captured in the housing cavity the two thrust washers (14) and thrust bearing (15). The bearing rollers must be firmly retained in the bearing cages, but must rotate and orbit freely. All rollers and thrust washers must be free of brinelling and corrosion. The bushing (19) or (13) to coupling shaft diameter clearance must not exceed 0.010 inch (0.025 mm). A bearing, bushing, or thrust washer that does not pass inspection must be replaced. If the housing has passed

this inspection the disassembly of the motor is completed.



NOTE: The depth or location of bearing/bushing (13) in relation to the housing wear plate surface and the depth or location of bearing/bushing (19) in relation to the beginning of bearing/bushing counterbore should be measured and noted before removing the bearings/bushings. This will facilitate the correct reassembly of new bearings/bushings.



20. If the bearings, bushing or thrust washers must be replaced use a suitable size bearing puller to remove bearing/bushings (19) and (13) from housing (18) without damaging the housing. Remove thrust washers (14) and thrust bearing (15) if they were previously retained in the housing by bearing (13).



Assembly

Replace all seals and seal rings with new ones each time you reassemble the motor unit. Lubricate all seals and seal rings with Dual fuel 10W40 engine fluid or clean grease before assembly.

NOTE: Unless otherwise indicated, do not oil or grease parts before assembly.

Wash all parts in clean petroleum-based solvents before assembly. Blow them dry with compressed air. Remove any paint chips from mating surfaces of the end cover, commutator set, manifold rotor set, wear plate and housing and from port and sealing areas.

⚠ WARNING

SINCE THEY ARE FLAMMABLE, BE EXTREMELY CAREFUL WHEN USING ANY SOLVENT. EVEN A SMALL EXPLOSION OR FIRE COULD CAUSE INJURY OR DEATH.

⚠ WARNING

WEAR EYE PROTECTION AND BE SURE TO COMPLY WITH OSHA OR OTHER MAXIMUM AIR PRESSURE REQUIREMENTS.

1. If the housing (18) bearing components were removed for replacement, thoroughly coat and pack a new outer bearing/bushing (19) with clean corrosion resistant grease recommended in the material section. Press the new bearing/bushing into the counterbore at the mounting flange end of the housing, using the appropriate sized bearing mandrel as described which will control the bearing/ bushing depth.


The housing requires the use of bearing mandrel to press bearing/ bushing (19) into the housing to a required depth of 0.151/0.161 inches (3.84/4.09 mm) from the end of the bearing counterbore.



NOTE: Bearing mandrel must be pressed against the lettered end of bearing shell. Take care that the housing bore is square with the press base and the bearing/ bushing is not cocked when pressing a bearing/bushing into the housing.

⚠ CAUTION

IF A BEARING MANDREL IS NOT AVAILABLE AND ALTERNATE METHODS ARE USED TO PRESS IN BEARING/BUSHING (13) AND (19) THE BEARING/BUSHING DEPTHS SPECIFIED MUST BE ACHIEVED TO INSURE ADEQUATE BEARING SUPPORT AND CORRECT RELATIONSHIP TO ADJACENT COMPONENTS WHEN ASSEMBLED.




⚠ CAUTION

BECAUSE THE BEARING/BUSHINGS (13) AND (19) HAVE A PRESS FIT INTO THE HOUSING THEY MUST BE DISCARDED WHEN REMOVED. THEY MUST NOT BE REUSED.


2. The inner housing bearing/bushing (13) can now be pressed into its counterbore in housing (18) flush to 0.03 inch (0.76 mm) below the housing wear plate contact face. Use the opposite end of the bearing mandrel that was used to press in the outer bearing/bushing (19).




3. Press a new dirt and water seal (20) into the housing (18) outer bearing counterbore. The dirt and water seal (20) must be pressed in until its' flange is flush against the housing.



4. Place housing (18) assembly into a soft jawed vise with the coupling shaft bore down, clamping against the mounting flange.



5. Assemble a new backup ring (17), new backup washer (25) and new seal (16) with the seal lip facing toward the inside of the motor, into their respective counterbores in housing (18).




6. Assemble thrust washer (14) then thrust bearing (15) that was removed from the motor.




NOTE: The motor requires one thrust washer (14) with thrust bearing (15). The coupling shaft will be seated directly against the thrust bearing.

7. Apply masking tape around splines or keyway on shaft (12) to prevent damage to seal.



SECTION 3 - CHASSIS & TURNTABLE

8. Be sure that a generous amount of clean corrosion resistant grease has been applied to the lower (outer) housing bearing/bushing (19). Install the coupling shaft (12) into housing (18), seating it against the thrust bearing (15).



⚠ CAUTION

THE OUTER BEARING (19) IS NOT LUBRICATED BY THE SYSTEM'S HYDRAULIC FLUID. BE SURE IT IS THOROUGHLY PACKED WITH THE RECOMMENDED GREASE.

NOTE: The coupling shaft (12) will be flush or just below the housing wear surface when properly seated while the coupling shaft (12). The coupling shaft must rotate smoothly on the thrust bearing package.



9. Apply a small amount of clean grease to a new seal ring (4) and insert it into the housing (18) seal ring groove.



NOTE: One or two alignment studs screwed finger tight into housing (18) bolt holes, approximately 180 degrees apart, will facilitate the assembly and alignment of components as required in the following procedures. The studs can be made by cutting off the heads of either 3/8-24 UNF 2A or 5/16-24 UNF 2A bolts as required that are over 0.5 inch (12.7 mm) longer than the bolts (1) used in the motor.

10. Install drive link (10) the long splined end down into the coupling shaft (12) and engage the drive link splines into mesh with the coupling shaft splines.




NOTE: Use any alignment marks put on the coupling shaft and drive link before disassembly to assemble the drive link splines in their original position in the mating coupling shaft splines.

11. Assemble wear plate (9) over the drive link (10) and alignment studs onto the housing (18).



12. Apply a small amount of clean grease to a new seal ring (4) and assemble it into the seal ring groove on the wear plate side of the rotor set stator.



13. Install the assembled rotor set (8) onto wear plate (9) with rotor counterbore and seal ring side down and the splines into mesh with the drive link splines.



NOTE: It may be necessary to turn one alignment stud out of the housing (18) temporarily to assemble rotor set (8) or manifold (7) over the drive link.

NOTE: If necessary, go to the appropriate, "Rotor Set Component Assembly Procedure."

NOTE: The rotor set rotor counterbore side must be down against wear plate for drive link clearance and to maintain the original rotor-drive link spline contact. A rotor set without a counterbore and that was not etched before disassembly can be reinstalled using the drive link spline pattern on the rotor splines if apparent, to determine which side was down. The rotor set seal ring groove faces toward the wear plate (9).

14. Apply clean grease to a new seal ring (4) and assemble it in the seal ring groove in the rotor set contact side of manifold (7).



NOTE: The manifold (7) is made up of several plates bonded together permanently to form an integral component. The manifold surface that must contact the rotor set has it's series of irregular shaped cavities on the largest circumference or circle around the inside diameter. The polished impression left on the manifold by the rotor set is another indication of which surface must contact the rotor set.

SECTION 3 - CHASSIS & TURNTABLE

15. Assemble the manifold (7) over the alignment studs and drive link (10) and onto the rotor set. Be sure the correct manifold surface is against the rotor set.



16. Apply grease to a new seal ring (4) and insert it in the seal ring groove exposed on the manifold.




17. Assemble the commutator ring (6) over alignment studs onto the manifold.




18. Assemble a new seal ring (3) flat side up, into commutator (5) and assemble commutator over the end of drive link (10) onto manifold (7) with seal ring side up.




19. Assemble a new seal ring (4) into end cover (2) and assemble end cover over the alignment studs and onto the commutator set. If the end cover has only 5 bolt holes be sure the cover holes are aligned with the 5 threaded holes in housing (18). The correct 5 bolt end cover bolt hole relationship to housing port bosses is shown below.






20. Assemble the bolts (1) and screw in finger tight. Remove and replace the two alignment studs with bolts after the other bolts are in place. Alternately and progressively tighten the bolts to pull the end cover and other components into place with a final torque of 25-30 ft. lbs. (34-41 Nm).



NOTE: If the end cover has a valve (24) or has five bolt holes, use the line you previously scribed on the cover to radially align the end cover into its original position.



One Piece Stator Construction

A disassembled rotor stator and vanes that cannot be readily assembled by hand can be assembled by the following procedures.

1. Place stator onto wear plate (9) with seal ring (4) side down, after following assembly procedures 1 through 13. Be sure the seal ring is in place.



2. If assembly alignment studs are not being utilized, align stator bolt holes with wear plate and housing bolt holes and turn two bolts (1) finger tight into bolt holes approximately 180 degrees apart to retain stator and wear plate stationary.
3. Assemble the rotor, counterbore down if applicable, into stator, and onto wear plate (9) with rotor splines into mesh with drive link (10) splines.



4. Assemble six vanes, or as many vanes that will readily assemble into the stator vane pockets.



CAUTION

EXCESSIVE FORCE USED TO PUSH THE ROTOR VANES INTO PLACE COULD SHEAR OFF THE COATING APPLIED TO THE STATOR VANE POCKETS.

5. Grasp the output end of coupling shaft (12) with locking pliers or other appropriate turning device and rotate coupling shaft, drive link and rotor to seat the rotor and the assembled vanes into stator, creating the necessary clearance to assemble the seventh or full complement of seven vanes. Assemble the seven vanes using minimum force.



6. Remove the two assembled bolts (1) if used to retain stator and wear plate.

Go to assembly procedure #15, to continue assembly.

Two Piece Stator Construction

A disassembled rotor set (8) that cannot be readily assembled by hand and has a two piece stator can be assembled by the following procedures.

1. Place stator half onto wear plate (9) with seal ring (4) side down, after following motor assembly procedures 1 through 13. Be sure the seal ring is in place.
2. Align stator bolt holes with wear plate and housing bolts and turn two alignment studs finger tight into bolt holes approximately 180 degrees apart to retain stator half and wear plate stationary.
3. Assemble rotor, counterbore down if applicable, into stator half, and onto wear plate (9) with rotor splines into mesh with drive link (10) splines.

NOTE: Use any marking you applied to rotor set components to reassemble the components in their original relationship to ensure ultimate wear life and performance.

4. Assemble six vanes, or as many vanes that will readily assemble into the stator vane pockets.

⚠ CAUTION

EXCESSIVE FORCE USED TO PUSH THE ROTOR VANES INTO PLACE COULD SHEAR OFF THE COATING APPLIED TO THE STATOR VANE POCKETS.

5. Grasp the output end of coupling shaft (12) with locking pliers or other appropriate turning device and rotate coupling shaft, drive link and rotor to seat the rotor and the assembled vanes (8C) into stator half, creating the necessary clearance to assemble the seventh or full complement of seven vanes. Assemble the seven vanes using minimum force.
6. Place second stator half on a flat surface with seal ring groove up. Apply a small amount of grease to a new seal ring (4) and assemble it into stator half ring groove.
7. Assemble the second stator half over the two alignment studs and rotor with seal ring side down onto the first stator half aligning any timing marks applied for this purpose.

⚠ CAUTION

IF THE STATOR HALF (8B) IS A DIFFERENT HEIGHT (THICKNESS) THAN STATOR HALF (8D) THE STATOR VANES (8C) OR (8E) OF THE SAME LENGTH (HEIGHT) AS THE STATOR HALF MUST BE REASSEMBLED IN THEIR RESPECTIVE STATOR HALF FOR THE ROTOR SET TO FUNCTION PROPERLY.

8. Assemble six vanes, or as many vanes that will readily assemble into the stator vane pockets.
9. Grasp the output end of coupling shaft (12) with locking pliers or other appropriate turning device and rotate coupling shaft, drive link and rotor to seat the rotor and the assembled vanes into stator, creating the necessary clearance to assemble the seventh or full complement of seven vanes. Assemble the seven vanes using minimum force.

Go to assembly procedure #15, to continue assembly.

Final Checks

1. Pressurize the motor with 100 p.s.i. dry air or nitrogen and submerge in solvent to check for external leaks.
2. Check motor for rotation. Torque required to rotate coupling shaft should not be more than 50 ft. lbs. (68 N m)
3. Pressure port with "A" cast under it on housing (18) is for clockwise coupling shaft rotation as viewed from the output end of coupling shaft. Pressure port with "B" cast under it is for counterclockwise coupling shaft rotation.
4. Use test stand if available, to check operation of the motor.

3.9 BATTERY MAINTENANCE AND CHARGING

Battery Maintenance, Quarterly

1. Open battery compartment cover to allow access to battery terminals and vent caps.

NOTICE

WHEN ADDING WATER TO BATTERIES, ADD WATER UNTIL ELECTROLYTE COVERS PLATES. DO NOT CHARGE BATTERIES UNLESS ELECTROLYTE COVERS THE PLATES.

NOTE: When adding distilled water to batteries, non-metallic containers and/or funnels must be used.

To avoid electrolyte overflow, add distilled water to batteries after charging.

When adding water to the battery, fill only to level indicated or 3/8" above separators.

2. Remove all vent caps and inspect electrolyte level of each cell. Electrolyte level should be to the ring approximately one inch from top of battery. Fill batteries with distilled water only. Replace and secure all vent caps.
3. Remove battery cables from each battery post one at a time, negative first. Clean cables with acid neutralizing solution (e.g. baking soda and water or ammonia) and wire brush. Replace cables and/or cable clamp bolts as required.
4. Clean battery post with wire brush then re-connect cable to post. Coat non-contact surfaces with mineral grease or petroleum jelly.
5. When all cables and terminal posts have been cleaned, ensure all cables are properly positioned and do not get pinched. Close battery compartment cover.
6. Start hydraulic system and ensure that it functions properly.

Optional On Board Generator

⚠ WARNING

EXHAUST GAS HAZARD. RUN THE GENERATOR IN A WELL VENTILATED AREA ONLY.

NOTICE

WHEN THE GENERATOR ENABLE CONTROL LOCATED IN THE PLATFORM CONTROL BOX IS IN THE ON POSITION AND THE GROUND EMERGENCY STOP SWITCH IS ON (PULLED OUT), THE GENERATOR WILL START AUTOMATICALLY WHEN THE BATTERIES REACH A LOW-CHARGE STATE, AUTOMATICALLY CHARGING THE BATTERIES. THE GENERATOR WILL ALSO AUTOMATICALLY START IF THE GENERATOR START BATTERY IS LOW.

NOTE: The engine will automatically shut down under the following conditions:

- High Engine Oil Temperature
- Low Engine Oil Pressure
- Engine Overspeed
- Generator Overvoltage
- Batteries fully charged

⚠ WARNING

TO AVOID INJURY FROM AN EXPLOSION, DO NOT SMOKE OR ALLOW SPARKS OR A FLAME NEAR BATTERY DURING SERVICING. ALWAYS WEAR EYE AND HAND PROTECTION WHEN SERVICING BATTERIES.

Battery Charging (On Board Charger)

1. For maximum battery life:
 - a. Avoid completely discharging the batteries.
 - b. Fully charge the batteries each day the machine is used.
 - c. Charge the batteries at available times between charging.
 - d. Be sure the battery fluid covers the battery plates before charging, but to avoid overflow, do not top off the fluid level until charging.
2. To charge the batteries, connect the charger to a 115 volt source with a 15 amp minimum capacity.
3. The Charger will shut off automatically when the batteries are fully charged.
4. The charge cycle is complete when the ammeter reads 0 amps. Any reading indicates the charge cycle is not complete.
5. Depleted batteries will take approximately 17 hours to charge.




Figure 3-29. On Board Generator

3.10 BATTERY CHARGER

NOTICE

JLG MACHINES EQUIPPED WITH DELTA Q BATTERY CHARGERS ARE DESIGNED FOR THE BEST PERFORMANCE WITH OEM FACTORY APPROVED BATTERIES.

APPROVED JLG REPLACEMENT BATTERIES ARE AVAILABLE THROUGH JLG'S AFTERMARKET PARTS DISTRIBUTION CENTERS OR JLG'S AFTERMARKET PROGRAMS. FOR ASSISTANCE WITH PROPER BATTERY REPLACEMENT, PLEASE CONTACT YOUR LOCAL JLG SUPPORT OFFICE.

BATTERIES APPROVED BY JLG HAVE BEEN TESTED FOR COMPATIBILITY WITH THE ALGORITHM PROGRAMMING OF THE DELTA Q BATTERY CHARGER TO OPTIMIZE BATTERY LIFE AND MACHINE CYCLE TIMES. THE USE OF NON APPROVED BATTERIES IN YOUR JLG EQUIPMENT MAY RESULT IN PERFORMANCE ISSUES OR BATTERY CHARGER FAULT CODES. JLG ASSUMES NO RESPONSIBILITY FOR SERVICE OR PERFORMANCE ISSUES ARISING FROM THE USE OF NON APPROVED BATTERIES.

⚠ WARNING

LEAD ACID BATTERIES MAY GENERATE EXPLOSIVE HYDROGEN GAS DURING NORMAL OPERATION. KEEP SPARKS, FLAMES, AND SMOKING MATERIALS AWAY FROM BATTERIES. PROVIDE ADEQUATE VENTILATION DURING CHARGING. NEVER CHARGE A FROZEN BATTERY. STUDY ALL BATTERY MANUFACTURERS' SPECIFIC PRECAUTIONS SUCH AS RECOMMENDED RATES OF CHARGE AND REMOVING OR NOT REMOVING CELL CAPS WHILE CHARGING.

⚠ WARNING

RISK OF ELECTRIC SHOCK. CONNECT CHARGER POWER CORD TO AN OUTLET THAT HAS BEEN PROPERLY INSTALLED AND GROUNDED IN ACCORDANCE WITH ALL LOCAL CODES AND ORDINANCES. A GROUNDED OUTLET IS REQUIRED TO REDUCE RISK OF ELECTRIC SHOCK - DO NOT USE GROUND ADAPTERS OR MODIFY PLUG. DO NOT TOUCH UNINSULATED PORTION OF OUTPUT CONNECTOR OR UNINSULATED BATTERY TERMINAL. DISCONNECT THE AC SUPPLY BEFORE MAKING OR BREAKING THE CONNECTIONS TO THE BATTERY WHILE CHARGING. DO NOT OPEN OR DISASSEMBLE CHARGER. DO NOT OPERATE CHARGER IF THE AC SUPPLY CORD IS DAMAGED OR IF THE CHARGER HAS RECEIVED A SHARP BLOW, BEEN DROPPED, OR OTHERWISE DAMAGED IN ANY WAY - REFER ALL REPAIR WORK TO QUALIFIED PERSONNEL. NOT FOR USE BY CHILDREN.

Operating Instructions

NOTICE

ALWAYS USE A GROUNDED OUTLET. WHEN USING AN EXTENSION CORD, AVOID EXCESSIVE VOLTAGE DROPS BY USING A GROUNDED 3-WIRE 12 AWG CORD.

1. The charger will automatically turn on and go through a short self-test. All LED's will flash in an up-down sequence for two seconds. The yellow "Charging" LED will turn on and a trickle current will be applied until a minimum voltage is reached.
2. Once a minimum battery voltage of 2 volts per cell is detected, the charger will enter the constant-current charging stage and the yellow LED will remain on. The length of charge time will vary by input voltage and ambient temperature.
3. When the green "Charged" LED turns on, the batteries are completely charged. The charger may now be unplugged from AC power. If left plugged in, the charger will automatically restart a complete charge cycle if battery voltage drops below a minimum voltage or 30 days have elapsed.
4. If a fault occurred during charging, the red "Fault" LED will flash with a code corresponding to the error.

Maintenance Instructions


1. For flooded lead-acid batteries, regularly check water levels of each battery cell after charging and add distilled water as required to level specified by battery manufacturer. Follow the safety instructions recommended by the battery manufacturer.
2. Make sure charger connections to battery terminals are tight and clean.
3. Do not expose charger to oil or to direct heavy water spraying when cleaning vehicle.

Battery Charger Fault Codes

If a fault occurred during charging, the red "Fault" LED will flash with a code corresponding to the error. Refer to the table following for the flash codes and their removal.

Table 3-3. Battery Charger Fault Codes (Delta-Q)

Flash(s)	Fault	Fault Removal
1	Battery voltage high	Auto-recover - Indicates a high battery pack voltage
2	Battery voltage low	Auto-recover - Indicates either a battery pack failure, battery pack not connected to charger or battery volts per cell is less than 0.5VDC. Check the battery pack and connections
3	Charge time-out	Indicates the batteries did not charge in the allowed time. This could occur if the batteries are a larger capacity than the algorithm is intended for or if the batteries are damaged old or in poor condition.
4	Check battery	Indicates the batteries could not be trickle charged up to the minimum voltage per cell level required for the charge to be started.
5	Over-temperature	Auto-recover - Indicates charger has shut down due to high internal temperature
6	QuiQ fault	Indicates that the battery will not accept charge current, or an internal fault has been detected in the charger. This fault will nearly always be set within the first 30 seconds of operation. Once it has been determined that the batteries and connections are not faulty and fault 6 is again displayed after interrupting AC power for at least 10 seconds, the charger must be brought to a qualified service depot.



- 1. AC Voltage - Input Cable
- 2. Battery Charge Signal Cable
- 3. DC Power Cable to Batteries

Figure 3-30. Battery Charger

NO LIGHTS AT ALL

No Lights at all indicate that AC power to the charger is not connected or that the AC voltage is too low. It could also indicate an internal failure in the charger.

1. Check the connections to AC power. Check for AC voltage between 90 and 260 VAC at the charger.
2. If the AC voltage is verified to be correct at the connection to the charger, and the charger still displays no lights at all, return the charger for service.

FAULT LED FLASHING

The Fault LED flashes to indicate the microcontroller inside the battery charger has detected a fault. The fault detected is indicated by the number of flashes. Count the number of flashes to determine the fault.

With any battery system, the most common problem will be a faulty battery connection. Because of the high likelihood of a battery connection problem, it is always worthwhile to confirm that all connections are good before checking for any other problems.

[1 Flash] - High Battery Voltage

1. Indicates a high battery voltage. Check that the battery charger voltage is consistent with the battery pack voltage. The first two digits of the four digit model name indicate the battery voltage the charger supports.
2. Check for wiring errors.
3. This fault will automatically clear and the charger will restart charging when this problem is removed.
4. High battery voltage could also occur if there is another source charging the battery. Disconnect any other sources during charging.
5. If this problem does not clear after the battery voltage is confirmed to be less than 2.5V per cell, return the charger for service.

[2 Flashes] - Low Battery Voltage

1. Indicates either a battery failure, no battery connected, or a lower than expected battery voltage. Check the battery and battery connections.
2. Check the nominal battery voltage. The first two digits of the four digit model name indicate the battery voltage the charger supports. Confirm that a nominal battery voltage is the same as the charger voltage.
3. This fault will clear automatically when the low battery voltage problem is rectified.
4. If this problem does not clear after the battery voltage is confirmed to be higher than 1.0V per cell and all connections are good, return the charger for service.

[3 Flashes] - Charge Timeout

Indicates the battery failed to charge within the allowed time. This could occur if the battery is of larger capacity than the algorithm is intended for. In unusual cases it could mean charger output is reduced due to high ambient temperature. It can also occur if the battery is damaged, old, or in poor condition.

1. Check the battery for damage such as shorted cells and insufficient water. Try the charger on a good battery.
2. If the same fault occurs on a good battery, check the connections on the battery and connection to AC, and the AC voltage itself.
3. Confirm that the nominal battery pack voltage is the same as the battery charger voltage.
4. This fault must be cleared manually by unplugging the AC, waiting 30 seconds and reconnecting the AC power.
5. If a charger displays this fault on a battery pack, and the pack is of questionable status, reset the charger by disconnecting AC for 30 seconds, and then reconnect the AC to start a new charge cycle. After a few charge cycles, this problem could stop occurring as the pack "recovers."

[4 Flashes] - Check Battery

This fault indicates the battery pack could not be trickle charged up to the minimum level required for the normal charge cycle to be started.

1. Check that none of the battery pack connections between modules are reversed or incorrectly connected.
2. Check that one or more cells in the battery are not shorted.
3. Confirm that the nominal battery pack voltage is the same as the battery charger voltage.
4. Try the charger on a good battery.
5. If this fault occurs, the battery is likely in poor condition. Try to recover the pack with a charger that can charge the individual cells - such as an automotive charger. Be sure to set this charger to the appropriate voltage - 6V per 6V battery, 12V per 12V string/battery.

[5 Flashes] - Over Temperature

This fault indicates the charger has become too hot during operation. Though not damaging to the charger, charge time will be extended significantly.

1. This fault indication will not clear automatically, but the charger will restart charging automatically when the temperature drops. The fault indication must be cleared manually by unplugging the AC, waiting 30 seconds and reconnecting the AC power.
2. If possible, move the machine to a cooler location.

3. Confirm that dirt or mud is not blocking the cooling fins of the charger. Clean the charger. Rinse the charger with a low pressure hose if required. Do not use high pressure. Do not use a pressure washer.

[6 Flashes] - Over Load/Over Temperature

This fault indicates that the batteries will not accept charge current, or an internal fault has been detected in the charger. This fault will nearly always be set within the first 30 seconds of operation. If it occurs after the charger has started charging normally, be sure to make a note of it.

1. Remove excessive AC loads from inverter if installed.
2. Try to clear the fault by unplugging the AC, waiting 30 seconds and reconnecting the ac power.
3. Check all battery connections. Look for a high resistance connection. The most likely reason for this fault is a fault in the battery such as a bad battery connection, an open cell, or insufficient water.
4. This fault will occur if an internal fuse inside the charger blows. If the green wire is shorted to ground even momentarily, this fuse will blow. To check the fuse, measure with an ohmmeter between the green and red wires with the AC disconnected. If a short circuit is not measured, the fuse has blown. Return unit to a service depot to have this fuse replaced.
5. If this fault occurs after battery charging has started, confirm that AC power was not interrupted and that all battery connections are good.
6. If all battery connections are good, an internal fault has been detected and the charger must be brought to a qualified service depot.

4. If the output voltage of the charger seems excessive, return the charger for service. Contact JLG to get the expected battery voltage settings for the charger in question. Be sure to have the charger's serial number and charge algorithm setting available when calling.

Checking/Changing the Battery Charger Algorithm

The charger is pre-loaded with programming algorithms for the specific batteries detailed in Table 3-4, Battery Algorithms.

NOTE: Contact JLG if your specific battery model is not listed.

Each time AC power is applied with the battery pack not connected, the charger enters an algorithm select/display mode for approximately 11 seconds. During this time, the current Algorithm # is indicated on the Yellow Charging LED. A single digit Algorithm # is indicated by the number of blinks separated by a pause. A two digit Algorithm # is indicated by the number of blinks for the first digit followed by a short pause, then the number of blinks for the second digit followed by a longer pause.

To check / change the charging algorithm:

1. Disconnect the charger positive connector from the battery pack. Apply AC power and after the LED test, the Algorithm # will display for 11 seconds.
2. To change the algorithm, touch the connector to the battery's positive terminal for 3 seconds during the 11 second display period and then remove. The Algorithm # will advance after 3 seconds. Repeat this procedure until the desired Algorithm # is displayed. A 30 second timeout is extended for every increment. Incrementing beyond the last Algorithm will recycle back to the first Algorithm. When the desired Algorithm is displayed, touch the charger connector to the battery positive terminal until the output relay makes a clicking noise (approx. 10 seconds). The algorithm is now in the permanent memory.
3. Remove the AC power from the charger and reconnect the charger's positive connector to the battery. It is recommended to check a newly changed algorithm by repeating the above steps 1 and 3.

Table 3-4. Battery Algorithms

Algorithm #	JLG PN	Battery Type	Proper Algorithm Setting
173	1001114782	DISCOVER EV 305A-A	43
173	0400055	USBATTERY L16	173

Excessive Battery Watering Requirements or Strong Sulphur (Rotten Egg) Smell

These symptoms indicate over-charging or high battery temperature. These symptoms are unlikely to be caused by too high a charge current since the maximum charge current of the charger will be small compared to even a moderately sized battery pack. The most likely cause for this problem is incorrect charge algorithm setting and/or high ambient temperatures.

1. Confirm that the battery pack is not too small - usually > 50Ah.
2. Confirm that the nominal battery voltage matches the charger output voltage.
3. Confirm the correct battery charge algorithm. If the battery pack is new, the algorithm will need to be changed if the pack is not the same as the old one. For instructions on how to determine and change the battery charge algorithm see the following sub-section.

3.11 GENERATOR

NOTE: Throughout the Generator section, the abbreviation RBS is used. RBS stands for Rotary Battery System, which is the generator system.

The engine-driven generator is designed to produce a DC output directly without the need of a separate rectifier. Included in the RBS unit is the engine, generator, engine/generator controller, harness and related components.


Engine

Peak rating: 6.2 HP

Continuous rating: 5.6 HP at 3600 RPM

Refer to the Engine Manual for a complete description of the engine.

Alternator



The RBS is equipped with a brushless DC output alternator.


The 3-phase AC output of the alternator is full wave rectified and presented to the output terminals.

Output rating: 58.0V at 45A

Voltage regulation and current limiting is provided by the RBS Engine/Generator Controller.

The rectifier diodes and output current sensor are located in the alternator endbell.

Dynamo and Dynamo Voltage Regulator




The engine is equipped with a dynamo and dynamo voltage regulator.

Dynamo output: 12V
7ADC

Refer to the Engine Manual for a complete description of the dynamo and dynamo voltage regulator.

Dynamo Output Fuse



This fuse protects the dynamo output; it is located on the left side of the engine.

Rating: 20ADC

Control Fuse

The control fuse provides power to the engine/generator controller and the relays for start control, fuel control and glow plug.

Rating: 15ADC

This fuse is located on the right side of the engine.




Figure 3-31. Generator


Start Battery



The RBS requires a 12V lead-acid start battery (not supplied with the system), which provides starting power and power for the RBS controls.

This battery is charged by the engine dynamo and dynamo regulator when the engine is running.



Engine Starter



The engine is equipped with a 12VDC starter, which provides the mechanical power to crank the engine. Electrical power for the starter is provided by the start battery.

The starter is energized by the start control relay.

Start Control Relay




The start control relay energizes the solenoid of the engine starter and the pull coil of the engine fuel solenoid.

The start control relay is energized by the engine/generator controller from pin J2-4.

The start control relay is located on the fuel solenoid bracket on the right side of the engine.

Fuel Control Relay




The fuel control relay energizes the hold coil of the fuel solenoid.

The fuel control relay is energized by the engine/generator controller from pin J2-3.

The fuel control relay is located on the fuel solenoid bracket on the right side of the engine.

Glow Plug Control Relay



The glow plug control relay energizes the glow plug. It is energized by the engine/generator controller, pin J2-27.


The glow plug control relay is located on the fuel solenoid bracket on the right side of the engine.

Glow Plug

The glow plug is a resistive heating element located in the combustion chamber. It is used during starting at temperatures below 32°F (0°C).

The heater is energized by the glow plug control relay.

Fuel Pump




The fuel pump runs in parallel with the fuel solenoid hold coil which is run by the fuel control relay.

The pump runs whenever the engine runs, and keeps the fuel filter filled. Excess fuel flows through the return line back to the fuel tank.



The fuel pump is located on the right side of the engine.

Engine Low Oil Pressure Switch



The engine is equipped with a low oil pressure switch. This switch is closed when the oil pressure is below 7psi. It is mounted on the side cover.



Fuel Solenoid



The fuel solenoid actuates the run/stop lever of the engine. This solenoid has a pull coil energized by the start control relay and a hold coil energized by the fuel control relay.

The fuel solenoid is located on the right side of the engine.

Engine Oil Temperature Sensor



The engine oil temperature sensor is used to sense the temperature of the oil in the sump of the engine.

This sensor provides an analog signal to the engine/generator controller. The primary use of this signal is for high

engine temperature shutdown 248°F (120°C) for the engine. The signal is also used in determining if the air glow plug should be energized.

The engine oil temperature sensor is connected to the engine/generator controller at pins J2-8 and J2-19.

The engine oil temperature sensor is located on the left side of the engine.


Alternator Output Current Sensor

The alternator output current sensor provides a signal proportional to the output current of the alternator to the engine/generator controller. The output current is regulated at 45ADC.

The alternator output current sensor is connected to the engine/generator controller at pins J2-21, J2-31 and J2-32.

The alternator output current sensor is located inside the rear cover of the alternator.

Engine Speed Sensor



The engine speed sensor provides a signal proportional to the rotational speed of the engine to the engine/generator controller. This signal is used by the engine/generator controller to determine starter cut-out, overspeed fault and underspeed fault. If the signal is not present at the engine/generator controller, the unit will fault with a loss of speed signal indication.

The engine speed sensor is connected to the engine/generator controller at pins J2-9, J2-15 and J2-20.

The engine speed sensor is located inside the recoil starter cover at the front of the engine.

RBS Engine/Generator Controller

The control system enclosure houses the RBS engine/generator controller, which performs all control tasks associated with the RBS.

The engine/generator controller interface is via a J2 35-pin connector.




Table 3-5. Controller Interface Pin Assignments

PIN	FUNCTION
1	System 48VDC
2	System 0VDC
3	Fuelsolenoid
4	Starter Solenoid
5	Manual call to start
6	Low oil pressure
7	Not used
8	Engine oil temperature
9	Speedsensing input
10	RS-232 +12V
11	RXD
12	TXD
13	LED Driver GND
14	LED Driver +48V
15	Speed sensor GND
16	Not used
17	Not used
18	- Output voltage
19	Engine oil temperature/ambient temp. + 8V
20	Speed Sensing + 8V
21	Output current sensor (GND)
22	Not used
23	RS-232 GND
24	- Field drive
25	+ Start battery
26	- Start battery
27	Pre-heat
28	Inhibit run
29	Engine temp. switch

Table 3-5. Controller Interface Pin Assignments

PIN	FUNCTION
30	+ Output voltage
31	Speed sensing + 5V
32	Output current sense
33	Not used
34	Not used
35	Field Drive

Warnings and Safety Precautions

⚠ WARNING

THE RBS MAY START WITHOUT WARNING.

⚠ WARNING

MORE THAN ONE LIVE CIRCUIT IS USED INSIDE THE RBS CONTROL PANEL. EXERCISE CAUTION WHEN THE CONTROL PANEL IS OPEN, EVEN WHEN THE RBS IS NOT RUNNING.

System Controls

INHIBIT RUN INPUT

The inhibit run input prevents the RBS from starting, clears any existing calls to start and stops the engine immediately. To return to normal operating mode, the inhibit run input must be removed.

MANUAL CALL TO START

The manual call to start input initiates an automatic run of the RBS unit.

RS232 PORT

The RS232 allows the RBS to be monitored and controlled using an analyzer.

System Status and Performance Monitoring

System status and performance can be monitored by the analyzer.

System Settings

CALL TO START SETTINGS

Low battery voltage call to start level	48.0VDC
Low battery voltage remove call to start level	54.0VDC
Low temperature call to start level	5°C
Low temperature remove call to start level	8°C
Low start battery voltage call to start level	12.2V
Low start battery voltage remove call to start level	12.9V

CURRENT AND VOLTAGE SETTINGS

Normal output voltage level	58.0VDC
Extend output voltage level	58.0VDC
Current limit level	45 ADC
High voltage shutdown level	63 ADC
Finish charging current level	30 ADC

TIME DELAY SETTINGS

TD engine start	30s
TD purge	0s
TD bypass	10s
TD engine run	1800s
TD cool-down	30s
TD high volts	2s

CRANK SETTINGS

Crank time	15s
Reset time	15s
Crank cycles	3

SPEED TIME AND GLOW PLUG SETTINGS

TD no speed signal	5s
TD DC sensing fault	10s
Starter disconnect	1000Hz
Overspeed shutdown	3800rpm
Underspeed shutdown	2000rpm
Glow plug on temperature	5°C
Glow plug on time	15s

RBS Start

Call to start	Manual	48VDC applied to the input
	Automatic	1 Low battery voltage (below 48VDC)
		2 Low engine temperature (below 5°C)
		3 Low start battery voltage (below 12.2V)
Engine start time delay		RBS waits to verify that call to start is valid (not a transient condition).
Preheat delay		- if engine temperature is below 32°F (0°C)
Crank time (Rest time)		RBS will crank and rest until engine starts, or Overcrank fault is indicated after 3 failed crank cycles.
Time delay bypass		RBS waits until normal engine operating conditions are reached before Low oil pressure and Underspeed faults are monitored.

RBS shutdown

Call to start removed	Manually	Inhibit run input applied
	Automatically:	1 Battery voltage above 54VDC and finish charging current below 30ADC
		2 Engine temperature above 8°C
		3 Start battery voltage above 12.9V and finish charging current below 30ADC
Engine run time delay		This period ensures that no further call to start conditions occur prior to cool-down period.
Cool-down period		Alternator output is reduced to a minimal level to allow the engine to cool down.

Go to Discount-Equipment.com to order your parts

RBS Alarms and Flash Codes

In the event of an RBS alarm, a flash code will be issued and an alarm indicated on the analyzer.

Table 3-6. RBS Alarms and Flash Codes

Flash Code	Problem		RBS Condition
1-1	Low Oil Pressure ¹	Below 7psi	Shutdown
1-2	High Engine Temp.	Over 248°F (120°C)	Shutdown
1-3	Overspeed	Over 3800 rpm	Shutdown
1-4	Underspeed 1	Below 2000 rpm	Shutdown
	Overcrank	3 failed crank cycles Call to start removed	Call to start removed
1-5	No Speed Signal ²		Shutdown
2-1	Overvoltage ³	Over 63VDC	Shutdown
2-2	Engine Starting System fault ⁴		Alarm
2-4	Loss Of Voltage Sense	Alternator output less than 1/2 of the system nominal voltage (58VDC)	Shutdown
steady	Unit Enabled, no faults		Unit can respond to any call to start
-	Unit Off / Disabled		Unit will not respond to any call to start
Notes:			
1 Enabled once time delay bypass period has elapsed after engine startup.			
2 Delayed to ensure the fault was not momentary.			
3 Measured at the alternator output, shutdown is delayed by a factory set period to ensure the fault was not caused by a transient condition.			
4 Indicates a problem with the engine start battery, engine magneto or magneto-voltage regulator.			

Alarms must be reset once the fault has been corrected (see below).

Resetting the RBS Controller

The RBS can be reset using the analyzer or by disabling and re-enabling the RBS controller. This will clear any current fault condition with the controller.

Maintenance Schedule

Check oil level every 24 hours

Change engine oil and filter every 150 hours

Troubleshooting

Table 3-7. Troubleshooting

Flash Code	Problem	Solution
-	Unit Off/ Disabled (engine will not crank)	<p>Check position of selector switch.</p> <p>Verify that the inhibit run is released.</p> <p>Check the warning LED. Remedy fault if present and restart the RBS.</p> <p>Check the start battery voltage.</p> <p>Check control fuse.</p> <p>Check for loose wiring or connection.</p>
1-1	Low Oil Pressure	<p>Check oil level.</p> <p>Check oil supply lines.</p> <p>Refer to Kubota Workshop manual WSM OC60/80/95.</p> <p>Verify correct operation of oil pressure switch with a test gauge.</p>
1-2	High Engine Temp.	<p>Check for obstructions in the cooling airflow to the engine.</p> <p>Check that the ambient temperature is within the design limits of the engine.</p> <p>Verify correct operation of engine temperature sensor.</p>
1-3	Overspeed	<p>Verify setting of governor lever. Readjust, if required.</p> <p>Refer to Kubota Workshop manual WSM OC60/80/95.</p>
1-4	Underspeed	<p>Ensure there is an adequate supply of fuel to the engine.</p> <p>Ensure there is an adequate supply of combustion air to the engine. Check air cleaner.</p> <p>Verify setting of governor lever. Readjust if required.</p> <p>Refer to Kubota OC60 Engine Manual.</p>
	Overcrank	<p>Check fuel level.</p> <p>Check fuel connections.</p> <p>Verify operation of fuel solenoid and fuel pump.</p> <p>Check the start battery voltage.</p> <p>If the engine exhaust contains white smoke then fuel is entering the engine but the engine is not firing. Refer to the Kubota OC60 Engine Manual for further checks.</p> <p>If the ambient temperature is low, verify that the heater and/or glow plug are operating.</p>
1-5	No Speed Signal	Check wiring connections.
2-1	Overvoltage	Check alternator output voltage.
2-2	Engine Starting System fault	Check engine start battery charging system for current output.
		Check for failed engine start battery.
2-4	Loss Of Voltage Sense	

APU Engine Start Battery Boosting

Always connect the POSITIVE (+) of the booster battery to the POSITIVE (+) of the APU start battery, and the NEGATIVE (-) of the booster battery to the ground of the engine block.

WARNINGS:

⚠ WARNING

ALWAYS SHIELD YOUR EYES AND AVOID LEANING OVER THE BATTERY WHENEVER POSSIBLE.

⚠ WARNING

DO NOT ALLOW BATTERY ACID TO CONTACT EYES OR SKIN. FLUSH ANY CONTACTED AREA WITH WATER IMMEDIATELY. SEEK MEDICAL ATTENTION IF IRRITATION PERSISTS.

⚠ WARNING

STARTING BATTERIES GENERATE EXPLOSIVE GASES. KEEP SPARKS, FLAME AND LIGHTED CIGARETTES AWAY FROM BATTERIES.

⚠ WARNING

IMPROPER USE OF A BOOSTER BATTERY TO START AN APU MAY CAUSE AN EXPLOSION.

⚠ WARNING

DO NOT ATTEMPT TO JUMP START AN APU WITH A LOW ACID LEVEL IN THE BATTERY.

⚠ WARNING

THE VOLTAGE OF THE BOOSTER BATTERY MUST BE RATED AT 12V. THE AMP-HOUR CAPACITY OF THE BOOSTER BATTERY MUST NOT BE LOWER OR SUBSTANTIALLY HIGHER THAN THAT OF THE DISCHARGED BATTERY. USE OF BATTERIES OF DIFFERENT VOLTAGE OR SUBSTANTIALLY DIFFERENT AMP-HOUR RATING MAY CAUSE AN EXPLOSION OR PERSONAL INJURY. APPLYING A HIGHER VOLTAGE WHILE BOOSTING WILL ALSO CAUSE DAMAGE TO SENSITIVE ELECTRONIC COMPONENTS.

⚠ WARNING

A CHARGING SYSTEM (BATTERY CHARGER OR BATTERY CHARGING ALTERNATOR) MUST NEVER BE ENERGIZED WHILE BOOSTING. DAMAGE TO SENSITIVE ELECTRONIC COMPONENTS WILL RESULT.

NOTICE

THE MAIN BATTERY OF THE LIFT MUST NEVER BE USED TO BOOST THE APU. DAMAGE TO SENSITIVE ELECTRONIC COMPONENTS WILL RESULT.

3.12 SUPPLEMENTARY FUSE FOR APU

The purpose of this section is to describe the procedure to add a supplementary fuse for the Engine Generator Controller for the APU.

Tools And Material

- - Weather proof fuse holder - JLG PN 2400081
- - AGC1, 1 Amp fuse - JLG PN 2400080
- - 45 cm of #16 AWG wire - JLG PN 4920019
- - 2 X insulated butt splice connectors - JLG PN 4460035
- - 6 X medium length wire ties - JLG PN 4240033
- - Wire/Side cutters
- - 5/32" Allen Key
- - Crimping tool

Procedure

⚠ WARNING

BEFORE BEGINNING THIS PROCEDURE, ENSURE THAT ALL SOURCES OF POWER ARE DISCONNECTED FROM THE APU!

This procedure is common for all applications of the APU. The photos contained in this document illustrate the modification performed to an APU supplied in a JLG lift.

1. Locate the harness at the rear of the APU.



2. Where the harness attaches to the rear cover of the generator and the connection point for the new inline fuse.



3. Remove the socket head drive screw with a 5/32" Allen key. Next remove the cable clamp from the harness.



4. Cut and remove the Wire Ties holding the Harness label to the harness. Next, remove the Wire Ties so that the cable sleeve can be moved, exposing the conductors of the harness.



5. Cut wire 106 going to the Engine/Generator Controller after the existing connection point and install the conductors that lead to the new inline fuse holder. Use insulated butt splice connectors for these conductors.



6. Re-install the harness with the new fuse in place.



7. Reconnect the lift and APU start battery. The APU is now ready for use.

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

A screenshot of the "Search Manuals" form. It includes a title "Search Manuals" and a subtitle "Please provide information to help us locate the manual and/or parts you need." The form has several input fields: "Brand" (a dropdown menu), "Serial Number" (a text field), "Model" (a text field), "Part Number" (a text field), "Part Name" (a text field), and "Quantity" (a text field). There is a "Search" button at the bottom.

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

A screenshot of the "Parts Order Form". It has a title "Parts Order Form" and a subtitle "Please fill in as much information as possible." The form includes a "Manufacturer" dropdown menu, a "Model" text field, a "Description" text field, and a "Quantity" text field. There are also checkboxes for "Urgent" and "Request Quote". A "Submit" button is at the bottom.

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, , Stow, Wacker, Sakai, Mi-T- M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Barreto, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, ,AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

SECTION 4. BOOM & PLATFORM

4.1 PLATFORM

Support Removal





Figure 4-1. Location of Components Platform Support


1. Disconnect electrical cables from control console.
2. Remove the bolts securing the platform to the platform support, then remove the platform.



3. Using a suitable lifting device, support the platform support.


NOTE: The platform support weighs approximately 77 lb (35 kg).

4. Remove the bolts and washer securing the platform support cover to the platform support. Remove platform support cover.



MAF17790


5. Remove the bolts and locknuts securing the support to the rotator.



MAF17730


SECTION 4 - BOOM & PLATFORM

- Using a suitable brass drift and hammer, remove the rotator shaft, then remove the support from the rotator.



MAF17740

- Apply Medium Strength Threadlocking Compound to the bolts and locknuts securing the support to the rotator and install the bolts and locknuts.




MAF17730

Support Installation

- Using a suitable lifting device, support the platform support and position it on the rotator.


NOTE: The platform support weighs approximately 77 lb (35 kg).

- Install the rotator shaft.




MAF17740

- Torque the nut on the rotator center bolt to 250-270 ft. lbs. (339-366 Nm). Torque the retaining bolts to 40 ft. lbs. (55 Nm).
- Apply Medium Strength Threadlocking Compound to the bolts and washers securing platform support cover to the platform support.




MAF17790

- Position the platform on the platform support and install the bolts securing the platform to the platform support.



- Connect the electrical cables to the platform control console.




- A Torque to 40 ft. lbs. (55 Nm)
- B Medium Strength Threadlocking Compound
- C Torque to 250-270 ft. lbs. (339-366 Nm)
- D Check torque every 150 hours of operation

Figure 4-2. Platform Support Torque Values

4.2 ROTATOR AND PLATFORM LEVEL CYLINDER REMOVAL


Removal

1. Using a suitable lifting equipment, adequately support main boom weight along entire length.
2. Tag and disconnect hydraulic lines to the rotator. Use a suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
3. Supporting the rotator, remove hardware from pin. Using a suitable brass drift and hammer remove pin from the rotator.
4. Remove the hardware from pin. Using a suitable brass drift and hammer, remove from the fly boom and remove the rotator.
5. Supporting the slave cylinder, remove the hardware from pin. Using a suitable brass drift and hammer, remove pin from the fly boom.
6. Tag and disconnect hydraulic lines to the slave leveling cylinder. Use a suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports. Remove the slave cylinder.



Installation

1. Using a suitable lifting equipment, adequately support main boom weight along entire length.
2. Supporting the slave cylinder, Using a suitable brass drift and hammer, Install pin to the fly boom.
3. Using a suitable brass drift and hammer, Install pin to the fly boom and Install the rotator.
4. Using a suitable brass drift and hammer, Install pin to the rotator.
5. Remove tag and reconnect the hydraulic lines to the rotator and the slave cylinder.



4.3 MAIN BOOM POWERTRACK

Removal

1. Disconnect wiring harness connectors located in main upright.


NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID ENTRY OF CONTAMINANTS INTO SYSTEM.

2. Tag and disconnect hydraulic lines to the connectors at boom assembly. Use a suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
3. Remove hydraulic lines and electrical cables from Powertrack.

NOTE: The Main Boom weighs approximately 590 lb (268kg).


4. Using suitable lifting equipment, adequately support Powertrack weight along entire length.
5. Remove bolts #1 securing the push tube on the fly boom section.
6. Remove bolts #2 that attaches rail to the push tube on the main boom section.
7. With powertrack supported and using all applicable safety precautions, remove bolts #3 securing rail to the base boom. Remove powertrack from the boom section.



Installation

NOTE: The Main Boom weighs approximately 590 lb (268kg).

1. Using suitable lifting equipment, adequately support Powertrack weight along entire length.
2. With powertrack supported and using all applicable safety precautions, install bolts #3 securing rail to the base boom.
3. Install bolts #2 that attaches rail to the push tube on the main boom section.
4. Install bolts #1 securing the push tube on the fly boom section.
5. Remove tag and reconnect all hydraulic lines.
6. Reconnect all electrical harness.



4.4 BOOM MAINTENANCE

Removal

- a. Remove hardware securing the cover plate on the side of the base boom section and remove hose clamps. Disconnect wiring harness from ground control harness connector.


NOTICE

HYDRAULIC LINES AND PORTS SHOULD BE CAPPED IMMEDIATELY AFTER DISCONNECTING LINES TO AVOID ENTRY OF CONTAMINANTS INTO SYSTEM.


- b. Tag and disconnect hydraulic lines from boom to control valve. Use a suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.

NOTE: The Main Boom weighs approximately 450 lb (204kg).


- c. Using a suitable lifting equipment, adequately support boom weight along entire length.
- d. Remove hardware securing the lift cylinder pin. Using a suitable brass drift and hammer, remove pin from the base boom.



- e. Remove hardware securing the master cylinder pin. Using a suitable brass drift and hammer, remove pin from the base boom.



- f. Remove hardware securing the base boom pin. Using a suitable brass drift and hammer, remove pin from the upright.



- g. Using all applicable safety precautions, carefully lift boom assembly clear of upright and lower to ground or suitable supported work surface.

Disassembly

1. Loosen jam nuts on aft end of fly boom wear pad adjustment and loosen adjustments.
2. Using a portable power source, attach hose to telescope cylinder port block. Using all applicable safety precautions, activate hydraulic system and extend cylinder to gain access to cylinder rod pin #1. Shut down hydraulic system.
3. Carefully disconnect hydraulic hose from retract port of cylinder. There will be initial weeping of hydraulic fluid which can be caught in a suitable container. After initial discharge, there should be no further leakage from the retract port.
4. Remove hardware securing telescope cylinder #1 to the fly boom section, then remove pin from fly.
5. Remove hardware securing telescope cylinder to the base boom section.

NOTICE

WHEN REMOVING TELESCOPE CYLINDER FROM BOOM SECTIONS. CARE SHOULD BE TAKEN NOT TO LET CYLINDER REST ON POWERTRACK WHICH COULD CAUSE DAMAGE TO POWERTRACK.

6. Using a suitable lifting device, remove telescope cylinder from boom sections.
7. Using a piece of tape, mark the length of hoses and wires from front of fly boom and bottom of base boom for reassembly.
8. Remove hardware securing the front cover on base boom section.
9. Loosen jam nuts on front wear pad adjustments and loosen adjustments.
10. Remove hardware securing the front wear pads on base boom section, remove wear pads.
11. Remove wire clamp on the inside of the fly nose.
12. Manually push the fly boom section into base boom section to gain access to the powertrack attachment bolts on the right side of the base boom section.
13. Remove hardware securing the powertrack to the aft end of the fly boom section.
14. Using a suitable lifting device, remove fly boom from boom section.
15. Remove hydraulic lines and electrical cables from powertrack.
16. Remove hardware securing powertrack to the base boom section. Remove powertrack.

Inspection

1. Inspect boom pivot pin for wear, scoring or other damage, and for tapering or ovality. Replace pin as necessary.
2. Inspect lift and master cylinder pins for wear, scoring or other damage, and for tapering or ovality. Ensure pin surfaces are protected prior to installation. Replace pins as necessary.
3. Inspect telescope cylinder rod attach pin for wear, scoring or other damage. Replace pin as necessary.
4. Inspect inner diameter of boom pivot bushings for scoring, distortion, wear or other damage. Replace bushings as necessary.
5. Inspect wear pads for wear as shown in Section 4.5, Wear Pads.
6. Inspect all threaded components for damage such as stretching, thread deformation, or twisting. Replace as necessary.
7. Inspect structural units of boom assembly for bending, cracking, separation of welds, or other damage. Replace boom sections as necessary.

Assembly


1. Install power track to the attach point on the inside of the base boom section. Secure power track with hardware.
2. Install hydraulic lines and electrical cables into the power track.
3. Install wear pads to the aft end of the fly section.
4. Using suitable lifting equipment, slide fly section into the base section until power track attach point aligns with holes in side of base section.
5. Attach the power track to the aft end of fly boom section. Secure power track with hardware.
6. Using suitable lifting equipment, slide fly boom section out to gain access to telescope cylinder attach pin hole.
7. Measure the distance between the telescope cylinder port block attach point on base boom section and the attach point on fly boom section.
8. Connect a suitable auxiliary hydraulic power source to the telescope cylinder port block.
9. Extend the telescope cylinder the distance of the two attach points.
10. Secure the sling and lifting device at the telescope cylinder's approximate center of gravity, and lift the cylinder to the aft end of the boom assembly.

NOTICE


WHEN INSERTING THE TELESCOPE CYLINDER INTO THE BOOM, CARE MUST BE TAKEN NOT TO DAMAGE THE POWER TRACK ASSEMBLY.

SECTION 4 - BOOM & PLATFORM

11. Slowly slide the telescope cylinder into boom assembly, align rod end with attach point in fly section. Insert pin and secure with retaining ring.
12. Align bolt holes at aft end of base boom section with telescope cylinder port block. Secure telescope cylinder with hardware.
13. Install wear pads at end of base boom section. Adjust the adjustable wear pads to zero clearance. Adjust pads alternately side to side, so that fly boom section is centered in base boom section.
14. Retract boom section fully. Adjust wear pads at aft end of boom section to zero clearance. Adjust pads alternately side to side, so that fly boom section is centered in base boom section.
15. Disconnect auxiliary power source from telescope cylinder.



4. If necessary, gently tap pins into position with a soft headed mallet, ensuring that attach holes in pins are aligned with attach holes in boom structure. Secure with hardware.




5. Connect all hosing and wiring.
6. Install the slave leveling cylinder to the boom assembly.
7. Install the platform to the boom assembly.
8. Connect all hosing and wiring at platform control station.
9. Using all safety precautions, operate machine systems and extend and retract boom for four or five cycles.
10. Shut down machine systems and check for leakage.

Installation

NOTE: The Main Boom weighs approximately 450 lb (204 kg).

1. Using suitable lifting equipment, position boom assembly on upright so that boom pivot holes in both boom and upright are aligned.
2. Install boom pivot pin, ensuring that location of the hole in pivot pin aligns with attach point on upright.



3. Using all applicable safety precautions, operate lifting equipment in order to position boom lift and master cylinders so that holes in cylinder rod ends and boom structure are aligned. Insert cylinder pins.

4.5 WEAR PADS

1. Shim up wear pads until snug to adjacent surface.
2. Replace wear pads when worn to thickness shown below.




Figure 4-3. Wear Pad Thickness

3. Adjust wear pads as follows:
 - a. Loosen jam nut on adjustment bolt, turn bolt CW until wear pad is snug to adjacent surface.
 - b. After adjustments have been made, tighten the jam nuts on wear pad bolts.

4.6 BOOM LIMIT SWITCHES

Refer to Figure 4-4., Boom Limit Switches for adjustments to be made to the two Boom Limit Switches which bolt in place on the upright.

4.7 BOOM CLEANLINESS GUIDELINES

The following are guidelines for internal boom cleanliness for machines that are used in excessively dirty environments.

1. JLG recommends the use of the JLG Hostile Environment Package if available to keep the internal portions of a boom cleaner and to help prevent dirt and debris from entering the boom. This package reduces the amount of contamination which can enter the boom but does not eliminate the need for more frequent inspections and maintenance when used in these types of environments.
2. JLG recommends that you follow all guidelines for servicing your equipment in accordance with the instructions outlined in the JLG Service & Maintenance Manual for your machine. Periodic maintenance and inspection is vital to the proper operation of the machine. The frequency of service and maintenance must be increased as environment, severity and frequency of usage requires.
3. Debris and foreign matter inside of the boom can cause premature failure of components and should be removed. Methods to remove debris should always be done using all applicable safety precautions outlined in the JLG Service & Maintenance Manuals.
4. The first attempt to remove debris from inside the boom must be to utilize pressurized air to blow the debris toward the nearest exiting point from the boom. Make sure that all debris is removed before operating the machine.
5. If pressurized air cannot dislodge the debris, then water with mild solvents applied via a pressure washer can be used. Again the method is to wash the debris toward the nearest exiting point from the boom. Make sure that all debris is removed, that no "puddling" of water has occurred, and that the boom internal components are dry prior to operating the machine. Make sure you comply with all federal and local laws for disposing of the wash water and debris.
6. If neither pressurized air nor washing of the boom dislodges and removes the debris, then disassemble the boom in accordance to the instructions outlined in the JLG Service & Maintenance Manual to remove the debris.

SECTION 4 - BOOM & PLATFORM




Figure 4-4. Boom Limit Switches

4.8 ARTICULATING JIB BOOM

Removal

1. For platform/support removal see platform/support removal diagram. See Section 4.1, Platform.
2. Position the articulating jib boom level with ground.
3. Remove mounting hardware from slave leveling cylinder pin #1. Using a suitable brass drift and hammer, remove the cylinder pin from articulating jib boom.




Figure 4-5. Location of Components - Articulating Jib Boom

4. Remove mounting hardware from articulating jib boom pivot pin #2. Using a suitable brass drift and hammer, remove the pivot pin from boom assembly.

Disassembly

1. Remove mounting hardware from articulating jib boom pivot pins #3 and #4. Using a suitable brass drift and hammer, remove the pins from articulating jib boom pivot weldment.
2. Remove mounting hardware from rotator support pins #5 and #6. Using a suitable brass drift and hammer, remove the pins from rotator support.
3. Remove mounting hardware from lift cylinder pin #7. Using a suitable brass drift and hammer, remove the cylinder pin from articulating jib boom.

Inspection

NOTE: When inspecting pins and bearings refer to "Pins and Composite Bearing Repair Guidelines" on page 6.

1. Inspect articulating fly boom pivot pin for wear, scoring, tapering and ovality, or other damage. Replace pins as necessary.
2. Inspect articulating fly boom pivot attach points for scoring, tapering and ovality, or other damage. Replace pins as necessary.
3. Inspect inner diameter of articulating fly boom pivot bearings for scoring, distortion, wear, or other damage. Replace bearings as necessary.
4. Inspect lift cylinder attach pin for wear, scoring, tapering and ovality, or other damage. Ensure pin surfaces are protected prior to installation. Replace pins as necessary.
5. Inspect inner diameter of rotator attach point bearings for scoring, distortion, wear, or other damage. Replace bearing as necessary.
6. Inspect all threaded components for damage such as stretching, thread deformation, or twisting. Replace as necessary.
7. Inspect structural units of articulating jib boom assembly for bending, cracking, separation of welds, or other damage. Replace boom sections as necessary.

Assembly

NOTE: For location of components See Figure 4-5., Location of Components - Articulating Jib Boom.

1. Align lift cylinder with attach holes in articulating jib boom. Using a soft head mallet, install cylinder pin #7 into articulating jib boom and secure with mounting hardware.
2. Align rotator support with attach hole in articulating jib boom. Using a soft head mallet, install rotator support pin #6 into articulating jib boom and secure with mounting hardware.

3. Align bottom tubes with attach holes in rotator support. Using a soft head mallet, install rotator support pin #5 into articulating jib boom and secure with mounting hardware.
4. Align articulating jib boom with attach hole in articulating jib boom pivot weldment. Using a soft head mallet, install rotator support pin #4 into articulating jib boom and secure with mounting hardware.
5. Align bottom tubes with attach holes in articulating jib boom pivot weldment. Using a soft head mallet, install rotator support pin #3 into articulating jib boom pivot weldment and secure with mounting hardware.
6. Align articulating jib boom pivot weldment with attach holes in fly boom assembly. Using a soft head mallet, install pivot pin #2 into fly boom assembly and secure with mounting hardware.
7. Align the slave leveling cylinder with attach holes in articulating jib boom pivot weldment. Using a soft head mallet, install slave leveling cylinder pin #1 into articulating jib boom pivot weldment and secure with mounting hardware.

4.9 BOOM SYNCHRONIZING PROCEDURE

NOTE: *If the Lower Boom assembly does not fully lower:*

1. Remove all personnel from the platform.
2. Pull the red knob located under the main control valve.
3. From Ground Control, activate the lift control switch, raise Lower Boom 6 ft. (1.8m).
4. After raising Lower Boom, release the red knob.
5. Activate Lower Boom Down, fully lower boom.
6. Repeat step 1 through 5 if necessary.

4.10 FOOT SWITCH ADJUSTMENT


Adjust switch so that functions will operate when pedal is at center of travel. If switch operates within last 1/4 inch (6.35 mm) of travel, top or bottom, it should be adjusted.

4.11 ROTARY ACTUATOR

Theory Of Operation

The rotary actuator is a simple mechanism that uses the sliding spline operating concept to convert linear piston motion into powerful shaft rotation. Each actuator is composed of a housing with integrated gear teeth (01) and only two moving parts: the central shaft with integrated bearing tube and mounting flange (02), and the annular piston sleeve (03). Helical spline teeth machined on the shaft engage matching splines on the in-side diameter of the piston. The outside diameter of the piston carries a second set of splines, of opposite hand, which engage with matching splines in the housing. As hydraulic pressure is applied, the piston is displaced axially within the housing - similar to the operation of a hydraulic cylinder while the splines cause the shaft to rotate. When the control valve is closed, oil is trapped inside the actuator, preventing piston movement and locking the shaft in position.

The shaft is supported radially by the large upper radial bearing and the lower radial bearing. Axially, the shaft is separated from the housing by the upper and lower thrust washers. The end cap is adjusted for axial clearance and locked in position by setscrews or pins.



NOTE: Bars indicate starting positions of piston and shaft. Arrows indicate direction they will rotate. The housing with integral ring gear remains stationary.


As fluid pressure is applied, the piston is displaced axially while the helical gearing causes the piston and shaft to rotate simultaneously. The double helix design compounds rotation: shaft rotation is about twice that of the piston.

Tools Required for Assembly/Disassembly

Upon assembly and disassembly of the actuator there are basic tools required. The tools and their intended functions are as follows:

1. Flashlight- helps examine timing marks, component failure and overall condition.
2. Felt Marker- match mark the timing marks and outline troubled areas.
3. Allen wrench- removal of port plugs and setscrews.
4. Box knife- removal of seals.
5. Seal tool- assembly and disassembly of seals and wear guides.
6. Pry bar- removal of end cap and manual rotation of shaft.
7. Rubber mallet- removal and installation of shaft and piston sleeve assembly.
8. Nylon drift- installation of piston sleeve.
9. End cap dowel pins- removal and installation of end cap (sold with Helac seal kit).






- 1. Housing
- 2. Shaft
- 3. Piston Sleeve
- 4. End Cap
- 109. Lock Pin
- 113. Capscrew

- 200. T-Seal
- 202. T-Seal
- 204. O-Ring
- 205. Cup Seal
- 207. Backup Ring
- 302. Wear Guide

- 304. Thrust Washer
- 304.1. Wiper Seal
- 400. Stop Tube (Optional)
- 401. Counterbalance Valve

Figure 4-6. Rotary Actuator (Exploded View)



PARTS	HARDWARE	SEALS	BEARINGS	ACCESSORIES
1. Housing	103.1. Screw	200. T-Seal	302. Wear Guide	400. Stop Tube
2. Shaft	103.2. Washer	202. T-Seal	304. Thrust Washer	420.1 Bushing
3. Piston Sleeve	106.1. Port Plug	204. O-ring		420.2 Bushing
4. End Cap	106.2. Port Plug	205. Cup Seal		421.1 Bushing
	109. Lock Pin	207. Backup Ring		
	113. Capscrew	304.1. Wiper Seal		

Figure 4-7. Rotator- Assembly Drawing

Disassembly

1. Remove the capscrews (113) over end cap lock pins (109).



2. Using a 1/8" (3.18mm) drill bit, drill a hole in the center of each lock pin to a depth of approximately 3/16" (4.76mm).



3. Remove the lock pins using an "Easy Out" (a size #2 is shown). If the pin will not come out with the "Easy Out", use 5/16" drill bit to a depth of 1/2" (12.7mm) to drill out the entire pin.



4. Install the end cap (4) removal tools provided with the Helac seal kit.



5. Using a metal bar, or something similar, un-screw the end cap (4) by turning it counter clock-wise.





6. Remove the end cap (4) and set aside for later inspection.



7. Remove the stop tube if included. The stop tube is an available option to limit the rotation of the actuator.




8. Every actuator has timing marks for proper engagement.



9. Prior to removing the shaft (2), use a felt marker to clearly indicate the timing marks between shaft and piston. This will greatly simplify timing during assembly.



10. Remove the shaft (2). It may be necessary to strike the threaded end of the shaft with a rubber mallet.



11. Before removing the piston (3), mark the housing (1) ring gear in relation to the piston O.D. gear. There should now be timing marks on the housing (1) ring gear, the piston (3) and the shaft (2).



SECTION 4 - BOOM & PLATFORM

12. To remove the piston (3) use a rubber mallet and a plastic mandrel so the piston is not damaged.



13. At the point when the piston gear teeth come out of engagement with the housing gear teeth, mark the piston and housing with a marker as shown.



14. Remove the o-ring (204) and backup ring (207) from end cap (4) and set aside for inspection.



15. Remove the wear guides (302) from the end cap (4) and shaft (2).



16. To remove the main pressure seals (205), it is easiest to cut them using a sharp razor blade being careful not to damage the seal groove.



17. Remove the thrust washers (304), from the end cap (4) and shaft (2).



18. Remove the wiper seal (304.1) from its groove in the end cap (4) and shaft (2).



19. Remove the piston O.D. seal (202).



20. Remove the piston I.D. seal (200). You may now proceed to the inspection process.




Inspection

1. Clean all parts in a solvent tank and dry with compressed air prior to inspecting. Carefully inspect all critical areas for any surface finish abnormalities: Seal grooves, bearing grooves, thrust surfaces, rod surface, housing bore and gear teeth.



2. Inspect the thrust washers (304) for rough or worn edges and surfaces. Measure it's thickness to make sure it is within specifications (Not less than 0.092" or 2.34 mm).



3. Inspect the wear guide condition and measure thickness (not less than 0.123" or 3.12 mm).



Assembly

1. Gather all the components and tools into one location prior to re-assembly. Use the cut away drawing to reference the seal orientations.



2. Install the thrust washer (304) onto shaft (2) and end cap (4).



3. Install the wiper seal (304.1/green O-ring) into its groove on the shaft (2) and end cap (4) around the outside edge of the thrust washer (304).



4. Using a seal tool install the main pressure seal (205) onto shaft (2) and end cap (4). Use the seal tool in a circular motion.



5. Install the wear guide (302) on the end cap (4) and shaft (2).



6. Install the inner T-seal (200) into the piston (3) using a circular motion. Install the outer T-seal (202) by stretching it around the groove in a circular motion. Each T-seal has 2 backup rings (see drawing for orientation).



7. Beginning with the inner seal (200) insert one end of b/u ring in the lower groove and feed the rest in using a circular motion. Make sure the wedged ends overlap correctly. Repeat this step for the outer seal (202).



8. Insert the piston (3) into the housing (1) as shown, until the outer piston seal (202) is touching inside the housing bore.



9. Looking from the angle shown, rotate the piston (3) until the marks you put on the piston and the housing (1) during disassembly line up as shown. Using a rubber mallet, tap the piston into the housing up to the point where the gear teeth meet.



Go to Discount-Equipment.com to buy your parts

SECTION 4 - BOOM & PLATFORM

10. Looking from the opposite end of the housing (1) you can see if your timing marks are lining up. When they do, tap the piston (3) in until the gear teeth mesh together. Tap the piston into the housing the rest of the way until it bottoms out.




11. Install the shaft (2) into the piston (3). Be careful not to damage the seals. Do not engage the piston gear teeth yet.



12. Looking from the view shown, use the existing timing marks to line up the gear teeth on the shaft (2) with the gear teeth on the inside of the piston (3). Now tap the flange end of the shaft with a rubber mallet until the gear teeth engage.



13. Install 2 bolts in the threaded holes in the flange. Using a bar, rotate the shaft in a clockwise direction until the wear guides are seated inside the housing bore.



14. Install the stop tube onto the shaft end. Stop tube is an available option to limit the rotation of an actuator.



15. Coat the threads on the end of the shaft with anti-seize grease to prevent galling.



- 16.** Install the O-ring (204) and backup ring (207) into the inner seal groove on the end cap (4).



- 17.** Thread the end cap (4) onto the shaft (2) end. Make sure the wear guide stays in place on the end cap as it is threaded into the housing (1).



- 18.** Tighten the end cap (4). In most cases the original holes for the lock pins will line up.



- 19.** Place the lock pins (109) provided in the Helac seal kit in the holes with the dimple side up. Then, using a punch, tap the lock pins to the bottom of the hole.



- 20.** Insert the setscrews (113) over the lock pins. Tighten them to 25 in. lbs. (2.825 Nm).



Installing Counterbalance Valve

Refer to Figure 4-8., Rotator Counterbalance Valve.

1. Make sure the surface of the actuator is clean, free of any contamination and foreign debris including old threadlocking compound.
2. Make sure the new valve has the O-rings in the counterbores of the valve to seal it to the actuator housing.
3. The bolts that come with the valve are grade 8 bolts. New bolts should be installed with a new valve. Medium Strength Threadlocking Compound should be applied to the shank of the three bolts at the time of installation.
4. Torque the 1/4-inch bolts 110 to 120 in. lbs. (12.4 to 13.5 Nm). Do not torque over 125 in. lbs. (14.1 Nm). Torque the 5/16-inch bolts 140 in. lbs. (15.8 Nm). Do not torque over 145 in. lbs. (16.3 Nm).
5. Make sure the valve is seated against the housing valve flat. If it is raised up on any side or corner, remove the valve to determine what the obstruction is. If possible test this using hydraulic hand pump or electric test.




Figure 4-8. Rotator Counterbalance Valve

Greasing Thrust Washers

6. After the actuator is assembled but before it is put into service, the thrust washer area must be packed with Lithium grease.
7. There are two grease ports located on both the shaft flange and the end cap. They are plugged with capscrews (113) or setscrews. Remove the grease port screws from the shaft flange and end cap. (See exploded view)



NOTICE

IF A HYDRAULIC TEST BENCH IS NOT AVAILABLE, THE ACTUATOR CAN BE ROTATED BY HAND, OPEN THE PRESSURE PORTS AND USE A PRY BAR WITH CAPSCREWS INSERTED INTO THE SHAFT FLANGE TO TURN THE SHAFT IN THE DESIRED DIRECTION.

8. Insert the tip of a grease gun into one port and apply grease to the shaft flange. Continue applying until grease flows from the opposite port. Cycle the actuator five times and apply grease again. Repeat this process on the end cap. Insert the capscrews into the grease ports and tighten to 25 in-lbs. (2.8 Nm).



Testing the Actuator

If the equipment is available, the actuator should be tested on a hydraulic test bench. The breakaway pressure — the pressure at which the shaft begins to rotate — should be approximately 400 psi (28 bar). Cycle the actuator at least 25 times at 3000 psi (210 bar) pressure. After the 25 rotations, increase the pressure to 4500 psi (315 bar) to check for leaks and cracks. Perform the test again at the end of the rotation in the opposite direction.

TESTING THE ACTUATOR FOR INTERNAL LEAKAGE

If the actuator is equipped with a counterbalance valve, plug the valve ports. Connect the hydraulic lines to the housing ports. Bleed all air from the actuator (see Installation and Bleeding) Rotate the shaft to the end of rotation at 3000 psi (210 bar) and maintain pressure. Remove the hydraulic line from the non-pressurized side.

Continuous oil flow from the open housing port indicates internal leakage across the piston. Replace the line and rotate the shaft to the end of rotation in the opposite direction. Repeat the test procedure outlined above for the other port. If there is an internal leak, disassemble, inspect and repair.

Installation and Bleeding


After installation of the actuator on the equipment, it is important that all safety devices such as tie rods or safety cables are properly reattached.

To purge air from the hydraulic lines, connect them together to create a closed loop and pump hydraulic fluid through them. Review the hydraulic schematic to determine which hydraulic lines to connect. The linear feet and inside diameter of the hydraulic supply lines together with pump capacity will determine the amount of pumping time required to fully purge the hydraulic system.

Bleeding may be necessary if excessive backlash is exhibited after the actuator is connected to the hydraulic system. The following steps are recommended when a minimum of two gallons (8 liters) is purged.

1. Connect a 3/16" inside diameter x 5/16" outside diameter x 5 foot clear, vinyl drain tube to each of the two bleed nipples. Secure them with hose clamps. Place the vinyl tubes in a clean 5-gallon container to collect the purged oil. The oil can be returned to the reservoir after this procedure is completed.

2. With an operator in the platform, open both bleed nipples 1/4 turn. Hydraulically rotate the platform to the end of rotation (either clockwise or counterclockwise), and maintain hydraulic pressure. Oil with small air bubbles will be seen flowing through the tubes. Allow a 1/2 gallon of fluid to be purged from the actuator.
3. Keep the fittings open and rotate the platform in the opposite direction to the end position. Maintain hydraulic pressure until an additional 1/4 gallon of fluid is pumped into the container.
4. Repeat steps 2 & 3. After the last 1/2 gallon is purged, close both bleed nipples before rotating away from the end position.



Troubleshooting

Table 4-1. Troubleshooting

Problem	Cause	Solution
1. Shaft rotates slowly or not at all	<p>a. Insufficient torque output</p> <p>b. Low rate of fluid flow</p> <p>c. Control or counterbalance valve has internal leak</p> <p>d. Piston and/or shaft seal leak</p> <p>e. Corrosion build-up on the thrust surfaces</p> <p>f. Swollen seals and composite bearings caused by incompatible hydraulic fluid</p>	<p>a. Verify correct operating pressure. Do not exceed OEM's pressure specifications. Load may be above maximum capacity of the actuator.</p> <p>b. Inspect ports for obstructions and hydraulic lines for restrictions and leaks.</p> <p>c. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports.</p> <p>d. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test as described in the Testing section on page 24 of this manual.</p> <p>e. Re-build the actuator. Remove all rust then polish. Replacement parts may be needed.</p> <p>f. Re-build the actuator. Use fluid that is compatible with seals and bearings.</p>
2. Operation is erratic or not responsive	a. Air in actuator	a. Purge air from actuator. See bleeding procedures.
3. Shaft will not fully rotate	<p>a. Twisted or chipped gear teeth</p> <p>b. Port fittings are obstructing the piston</p>	<p>a. Check for gear binding. Actuator may not be able to be rebuilt and may need to be replaced. Damage could be a result of overload or shock.</p> <p>b. Check thread length of port fittings. Fittings should during stroke not reach inside the housing bore.</p>
4. Selected position cannot be maintained	<p>a. Control or counterbalance valve has internal leak</p> <p>b. Piston and/or shaft seal leak</p> <p>c. Air in actuator</p>	<p>a. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports.</p> <p>b. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test as described in the Testing section on page 24 of this manual.</p> <p>c. Purge air from actuator. See bleeding procedures</p>


4.12 POWERTRACK MAINTENANCE

Removing a Link


NOTE: Hoses shown in the powertrack are for example only. Actual hose and cable arrangements will be different.





1. Clamp the bar and poly roller tightly so they do not spin when removing the screw. With a small $\frac{1}{4}$ " ratchet and a t-20 torx bit, remove the 8-32 x 0.500 screw from one side.





2. Repeat step 1 and remove the screw from the other side of track. Remove the bar/poly roller from the powertrack.



3. To remove a link, the rivets holding the links together must be removed. Use a right-angle pneumatic die grinder with a ¼" ball double cut bur attachment.



4. Insert the tool into the rolled over end of the rivet as shown. Grind out the middle of the rivet until the rolled over part of the rivet falls off. Repeat this step for all the rivets that must be removed.





NOTICE


MOVE THE CABLES/HOSES OUT OF THE WAY DURING THE GRINDING PROCESS TO PROTECT THEM. KEEP THE HOSES AND CABLES COVERED TO PREVENT ANY DEBRIS FROM GETTING ON THEM.

SECTION 4 - BOOM & PLATFORM

5. After grinding it may be necessary to help the rivet out by using a center punch with a hammer.



6. Using a flat head screwdriver between the links, twist the screwdriver and pull the links apart.



NOTE: It may be necessary to loosen the fixed end brackets from the machine in order to twist and pull the track section enough to disconnect the links.

7. Remove the link from the other section of the powertrack using a screwdriver.



Installing a New Link

1. Squeeze the peanut cut out end of the new link into the half-shear (female) end of the track section.

