

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524067	2	absolute difference of sensed temperature of supply module heater temperature and ambient temperature UPmpT_tDiffP-mpHtrAmb_mp > threshold	absolute difference of sensed temperature of supply module heater temperature and ambient temperature UPmpT_tDiffP-mpHtrAmb_mp > threshold	Compare SCR_tSMT with SCR_tSMHtrT, EnvT_t and CEngTds_t and SCR_tAdapUTnkT => All identical? If not: Has the machine been brought from cold environment into a warm one or vice versa without engine running, e.g. at workshop? Environment temperature sensor defect Coolant temperature sensor defect Supply module temperature sensor defect Problem at Supply module unit (broken?) => exchange supply module
524067	2	absolute difference of sensed temperature of supply module temperature and ambient temperature > threshold	absolute difference of sensed temperature of supply module temperature and ambient temperature UPmpT_tDiffPmpAmb_mp > threshold	Compare SCR_tSMT with SCR_tSMHtrT, EnvT_t and CEngTds_t and SCR_tAdapUTnkT => All identical? If not: Has the machine been brought from cold environment into a warm one or vice versa without engine running, e.g. at workshop? Environment temperature sensor defect Coolant temperature sensor defect Supply module temperature sensor defect Problem at Supply module unit (broken?) => exchange supply module
524074	9	Open load sensor internally at NOx-sensor downstream SCR	Open load sensor internally at NOx-sensor downstream SCR	Threshold for error detection is an internal ECU threshold. Check NOx-Sensor downstream SCR catalyst: water inside? Shake out sensor after dismounting. => If water inside, replace sensor. Check mounting position of sensor and judge it regarding condense water formation / agglomeration. Check wiring harness Exchange sensor
524075	11	Short circuit sensor internally at NOx-sensor downstream SCR	Short circuit sensor internally at NOx-sensor downstream SCR	Threshold for error detection is an internal ECU threshold. Check NOx-Sensor downstream SCR catalyst: water inside? Shake out sensor after dismounting. => If water inside, replace sensor. Check mounting position of sensor and judge it regarding condense water formation / agglomeration? Rearrange if critical and possible Check wiring harness Exchange sensor

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524076	9	Open line sensor internally at NOx-sensor downstream SCR NOx Sensors are CAN Sensors --> no HW Pin on the ECU	Open line sensor internally at NOx-sensor downstream SCR	Threshold for error detection is an internal ECU threshold. Check NOx-Sensor upstream SCR catalyst: water inside? Shake out sensor after dismounting. => If water inside, replace sensor. Check mounting position of sensor and judge it regarding condense water formation / agglomeration. Check wiring harness Exchange sensor
524077	11	Short circuit sensor internally at NOx-sensor downstream SCR NOx Sensors are CAN Sensors --> no HW Pin on the ECU	Short circuit sensor internally at NOx-sensor downstream SCR	Threshold for error detection is an internal ECU threshold. Check NOx-Sensor upstream SCR catalyst: water inside? Shake out sensor after dismounting. => If water inside, replace sensor. Check mounting position of sensor and judge it regarding condense water formation / agglomeration. Check wiring harness Exchange sensor
524078	9	Lambda value of NOx-Sensor downstream SCR is out of range. When the filtered Lambda concentration value at the sensor (ComRxSCR_rFltLamDs_mp) is greater than the physical range check max. lambda threshold	sensed lambda value of Nox-sensor downstream SCR catalyst is > physical high limit ComRxSCR_rCanLamDs_mp > threshold	Check whether NOx-sensor downstream SCR catalyst is physically mounted within the exhaust line Check Lambda values of NOx-sensor downstream SCR catalyst at idle conditions, ComRxSCR_rCanLamDs_mp > threshold? Compare to ComRxSCR_rCanLamUs_mp. Values must be almost identical Check CANBus of NOx-sensor downstream SCR catalyst Check NOx-sensor downstream SCR catalyst wiring Check NOx-sensor downstream SCR catalyst itself Replace NOx-sensor downstream SCR catalyst

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524079	9	sensed lambda value of NOx-sensor downstream SCR catalyst is < physical low limit ComRxSCR_rCanLamDs_mp < threshold	sensed lambda value of NOx-sensor downstream SCR catalyst is < physical low limit ComRxSCR_rCanLamDs_mp < threshold	Compare to ComRxSCR_rCanLamUs_mp. ComRxSCR_rCanLamDs_mp must be almost identical! If almost identical, Check air path of engine: EGR-Valve, Intake-Throttle, Turbocharger and Piping each for leakage and correct function Check injection system of engine. Injector stuck? if sensed lambda upstream SCR higher (ComRxSCR_rCanLamUs_mp): Diesel in Urea-tank? Check CANBus of NOx-sensor downstream SCR catalyst Check NOx-sensor downstream SCR catalyst wiring Check NOx-sensor downstream SCR catalyst itself Replace NOx-sensor downstream SCR catalyst
524080	9	sensed lambda value of Nox-sensor upstream SCR catalyst is > physical high limit ComRxSCR_rCanLamUs_mp > Threshold	sensed lambda value of Nox-sensor upstream SCR catalyst is > physical high limit ComRxSCR_rCanLamUs_mp > Threshold	Check whether NOx-sensor upstream SCR catalyst is physically mounted within the exhaust line Check Lambda values of NOx-sensor upstream SCR catalyst at idle conditions, ComRxSCR_rCanLamUs_mp < Threshold? Compare to ComRxSCR_rCanLamDs_mp. Must be almost identical Check CANBus of NOx-sensor upstream SCR catalyst Check NOx-sensor upstream SCR catalyst wiring Check NOx-sensor upstream SCR catalyst itself Replace NOx-sensor upstream SCR catalyst
524081	9	sensed lambda value of Nox-sensor upstream SCR catalyst is < physical low limit ComRxSCR_rCanLamUs_mp < Threshold	sensed lambda value of Nox-sensor upstream SCR catalyst is < physical low limit ComRxSCR_rCanLamUs_mp < Threshold	Check air path of engine: EGR-Valve, Intake-Throttle, Turbocharger and Piping each for leakage and correct function Check injection system of engine. Injector stuck? Check CANBus of NOx-sensor upstream SCR catalyst Check NOx-sensor upstream SCR catalyst wiring Check NOx-sensor upstream SCR catalyst itself Replace NOx-sensor upstream SCR catalyst
524083	9	sensed NOx-value of NOx-sensor downstream SCR catalyst < Threshold	sensed Nox-value of Nox-sensor downstream SCR catalyst < physical low limit	Check CANBus of NOx-sensor downstream SCR catalyst Check NOx-sensor downstream SCR catalyst wiring Check NOx-sensor downstream SCR catalyst itself Replace NOx-sensor downstream SCR catalyst

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524085	9	sensed Nox-value of Nox-sensor upstream SCR catalyst < Threshold	sensed Nox-value of Nox-sensor upstream SCR catalyst < physical low limit	Check CANBus of NOx-sensor upstream SCR catalyst Check NOx-sensor upstream SCR catalyst wiring Check NOx-sensor upstream SCR catalyst itself Replace NOx-sensor upstream SCR catalyst
524100	9	Timeout error of CAN-Transmit-Frame Com-DPFHisDat.	Open load on CANBUS wiring.	Check wiring, component.
524104	9	Timeout error of CAN-Receive-Frame Com-RxDPFctl. CM1 Module Customer Recieve Message.	Time out of Check CANBUS EAT Control Receive Message, PGN65348. The message is not received.	Threshold for error detection is an internal ECU threshold. Check CANBUS EAT Control Receive Message, PGN65348. CM1 Module Customer Recieve Message.
524118	9	Timeout error of CAN-Receive-Frame Com-RxCM1	If the frame CM1 message is not transmitted successfully	Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range.
524121	9	Timeout error of CAN-Receive-Frame Com-RxTrbChActr	Timeout Error (Missing CAN Bus message)	Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range.
524125	9	Timeout error of CAN-Receive-Frame ComTxTrbChActr	Timeout Error (Missing CAN Bus message)	Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range.
524141	7	DEF dosing valve is blocked with crystalized urea or other deposits.	While SCR system is starting up and fter urea pressure reaches 10000 hPa, the DEF dosing module is tested. Expectation is that urea pressure drops below 1500 hPa if injector works properly. The test is repeated up to 3 times before an error is set. SCRsysPresMon_stPresDropDet_mp=0 while SCRCo_stStatus_mp=16. Suspected component: wiring harness DEF dosing valve The error is stored into the EEPROM of the ECU and status at ECU shut down is regained at ignition on.	Check electrical connection of urea injector: - wiring harness - connector Conduct SERDIA use-case "injection test". If it is faulty: - remove urea injector from exhaust line: - check for crystallisation direct on injector nozzle / plate - rinse it thoroughly in water - remount urea injector and conduct SERDIA use-case "injection test" If the error is still active, then exchange urea injector.
524141	7	DEF dosing valve is blocked with crystalized urea or other deposits.	While SCR system is starting up and fter urea pressure reaches 10000 hPa, the DEF dosing module is tested. Expectation is that urea pressure drops below 1500 hPa if injector works properly. The test is repeated up to 3 times before an error is set. SCRsysPresMon_stPresDropDet_mp=0 while SCRCo_stStatus_mp=16. Suspected component: wiring harness DEF dosing valve The error is stored into the EEPROM of the ECU and status at ECU shut down is regained at ignition on.	Check electrical connection of urea injector: - wiring harness - connector Conduct SERDIA use-case "injection test". If it is faulty: - remove urea injector from exhaust line: - check for crystallisation direct on injector nozzle / plate - rinse it thoroughly in water - remount urea injector and conduct SERDIA use-case "injection test" If the error is still active, then exchange urea injector.

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524147	13	No proper urea pressure level could be build up within the SCR system state "Fill Lines" => SCRCO_stStatus_mp = 1 within some minutes	This error shows up, if no proper urea pressure level could be build up within the SCR system state "Fill Lines" => SCRCO_stStatus_mp = 1 within some minutes Once the urea pump pressure has exceeded the threshold the error is declared as okay. Suspected components: Suction line blocked PWM Powerstage has a defect and a default value which leads not to a rising pressure Pump Pressure sensor defect pump filter contains dirty parts reverting valve continuously open	Make sure that frozen lines, pump or tank can be excluded! Check whether there is urea in the urea tank Check urea lines: All lines connected? The right lines connected to the correct places? Suction line blocked? No leakage? Not also urea to the outside but also air into the lines, especially in the suction line! Perform service routine "pressure test": Does the urea pump work? => check wiring harness & PWM signal for pump Does the urea pressure rise? DFC already healed? If all unsuccessful so far: Check urea pressure sensor: At ignition on and SCR system state = 0 ("Init check"), SCR_pAbsAdapUPmpP shall be identical to EnvP_p. Fulfilled: Sensor okay! Check reverting valve => see DFC_SCRCoRev-VlvBlk Check pump filter: dirt inside? Suspected components: Urea pump broken Reverting valve continuously open Urea suction line, backflow line broken or connection swapped PWM Powerstage has a defect Pump Pressure sensor broken
524152	2	CAN message is not received for a definite time => error is set. As soon as the message is received the error heals.	CAN message is not received for a definite time => error is set. As soon as the message is received the error heals.	Check electrical connection of urea quality sensor Check engine CAN bus Check urea quality sensor itself Exchange urea quality sensor
524153	2	CAN message is not received for a definite time => error is set. As soon as the message is received the error heals.	CAN message is not received for a definite time => error is set. As soon as the message is received the error heals.	Check electrical connection of suction unit sensor (combined sensor with tank level and tank temperature) Check engine CAN bus Check level sensor itself Exchange suction unit
524156	9	Timeout error of CAN-Receive-Frame Com-RxEBC2 from wheel speed sensor.	Timeout Error (Missing CAN Bus message) Defect on wheel speed sensor.	Check CAN Bus cabling (Bus shedding, polarity, short circuit, power interrupt), test protocol of receiver, check CAN functional range. Replace the wheel speed sensor.

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524177	7	The error shows up, if no proper urea pressure could be build up within the SCR system state "Fill Lines" => SCRCo_stStatus_mp = 1.	This error shows up, if no proper urea pressure could be build up within the SCR system state "Fill Lines" => SCRCo_stStatus_mp = 1. 3 cases can lead to the error: Case A: increasing pressure is detected within 15s the check has passed => no error Case B: The pressure threshold was not reached within the 60s but case A was not positiv. Case C: The minimum pressure of 3000 hPa was not reached within the 60s.	Make sure that DEF lines, pump and tank are not frozen. Check for DEF level in the tank. Check DEF lines: Are all DEF lines connected? Is the suction line blocked? Is there any leakage? Not only urea to the outside but also air into the lines, especially in the suction line! Perform SERDIA usecase "pressure test": Does the DEF pump work? => check wiring harness & PWM signal for pump. Does the urea pressure increase? All errors are already healed? If still unsuccessful so far: Check urea pressure sensor: At ignition on and SCR system state = 0 ("Init check"), SCR_pAbsAdapUPmpP shall be identical to EnvP_p. Fulfilled: Sensor okay! Check DEF pump filter: Is any dirt inside? Suspected components: Suction line PWM Powerstage has a defect and a default value which leads not to a rising pressure DEF pump pressure sensor defect DEF pump filter contains dirty parts

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524178	7	The urea pump is not able to control the urea pressure between 9bar and 11 bar.	The urea pump controller is not able to control the urea pressure between 9bar and 11 bar due to malfunction in the SCR system. Suspected components: - DEF pump broken - Reverting valve continuously open - Urea suction line, backflow line broken or connection swapped - PWM Powerstage has a defect - Pump Pressure sensor broken	Make sure that DEF lines, pump and tank are not frozen. Check for DEF level in the tank Check DEF lines: All lines connected? The right lines connected to the correct places? Suction line blocked? Is there any leakage? Not also urea to the outside but also air into the lines, especially in the suction line! Perform SERDIA usecase "pressure test": Does the DEF pump work properly? => check wiring harness & PWM signal for pump Does the DEF pressure rise? Is the error healed? If still unsuccessful so far: - Check DEF pressure sensor: At ignition on and SCR system state = 0 ("Init check"), SCR_pAbsAdapUPmpP shall be identical to EnvP_p. Fulfilled: Sensor okay! - Check reverting valve - Check DEF pump filter: dirt inside? Suspected components: DEF pump broken Reverting valve continuously open DEF suction line, backflow line broken or connection swapped PWM Powerstage has a defect DEF pump pressure sensor broken
524190	14	Not enough urea in tank or low urea quality or hardware tampering failure is detected or hardware failure is detected	Low DEF tank level Low DEF quality Hardware Tampering is active Hardware Failure is active	Check DEF level in tank. If there is no DEF, refill up to volume above the warning threshold. Check the DEF quality in the tank. If wrong fluid is filled, refill with proper DEF. Check other errors based on hardware malfunctions.
524191	14	A low DEF tank level or a low DEF quality is detected or hardware tampering (system components are pinched off) or hardware failures as shortcut to battery, shortcut to ground etc. are detected.	Low DEF tank level Low DEF quality Hardware Tampering is active Hardware Failure is active	Threshold for error detection is an internal ECU threshold. Check the DEF level in tank. If there is no DEF, refill up above the warning level. Check DEF quality filled in the tank. Check other errors based on hardware tampering or failure.

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524193	8	The total time in standstill-regeneration mode exceeds the long-limit threshold within last 500h total engine run time. The error is activated if the engine runs to many times in Standstill regeneration.	Stand-still mode is very often aborted by the operator. Stand-still mode does not reach required temperature level and regeneration level is therefore reached after a short time again	Read out stand-still statistics => see service manual: Stand-still operation finished or often interrupted by driver / engine shut-off? => Run stand-still and instruct operator Stand-still operation required often by soot load => Check dp DPF pressure sensor Stand-still mode does not reach required temperature level: Check engine air path: Intake Trottle, EGR-Valve and turbocharger okay? Any leakage in engine air intake sytem or exhaust gas system? Check temperature sensors within exhaust system: upstream DOC, downstream DOC If soot load level of DPf allow it: Perform Stand-still and check reached temperature level upstream and downstream DOC: T upstream DOC in the range of 480-550°C? Downstream DOC after 25 min stand-still main phase 590°C are reached? Temperature traces are steady and even? Temperature downstream DOC higher than upstream DOC but difference does not exceed 100 K? Very small difference (< 10 K after 25 min stand-still main phase, 590 °C downstream DOC are not reached) => exchange DOC Very big difference (> 100 K after 25 min stand-still main phase, 590 °C downstream DOC exceeded) => check injection system of engine & engine air path

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524194	8	<p>The total time in standstill-regeneration mode exceeds the long-limit threshold: 2,5h stand-still operation within 50h total motor run time.</p> <p>The error is activated if the engine runs to much time in short Standstill regeneration.</p>	<p>Stand-still mode is aborted / interrupted too often by the operator</p> <p>Stand-still is required too often due to miscalculation in the soot model</p> <p>Stand-still mode does not reach temperature level and regeneration level is therefore reached after a short time again.</p>	<p>Read out stand-still statistics => see service manual:</p> <p>Stand-still operation finished or often interrupted by driver / engine shut-off? => Run stand-still and instruct operator</p> <p>Stand-still operation required often by soot load => Check dp DPF pressure sensor</p> <p>Stand-still mode does not reach required temperature level:</p> <p>Check engine air path: Intake Trottle, EGR-Valve and turbocharger okay?</p> <p>Any leakage in engine air intake system or exhaust gas system?</p> <p>Check temperature sensors within exhaust system: upstream DOC, downstream DOC</p> <p>If soot load level of DPF allows it:</p> <p>Perform Stand-still and check reached temperature level upstream and downstream DOC: T upstream DOC in the range of 480-550 °C? Downstream DOC after 25 min stand-still main phase 590 °C are reached? Temperature traces are steady and even? Temperature downstream DOC higher than upstream DOC but difference does not exceed 100 K?</p> <p>Very small difference (< 10 K after 25 min stand-still main phase, 590 °C downstream DOC are not reached) => exchange DOC</p> <p>Very big difference (> 100 K after 25 min stand-still main phase, 590 °C downstream DOC exceeded) => check injection system of engine & engine air path</p>

Table 3-10. Engine Fault Codes

SPN	FMI	Description	Possible Cause	Action
524195	14	<p>The standstill request of detected crystallization is ignored for more than 5h(>300min)</p> <p>This will be activated if there is a standstill request activated by Crystallisation Monitoring.</p>	<p>Back pressure upstream SCR catalyst has reached a level which indicates crystallisation inside of exhaust line.</p> <p>The error detection depends on the sensed pressure upstream of the SCR catalyst and the calculated exhaust volume flow through the mixer pipe.</p> <p>In case of error is set, but no crystallisation can be found in the mixing pipe, a possible reason can be the defect sensors:</p> <ul style="list-style-type: none"> - exhaust pressure & temperature upstream of the SCR catalyst, - the ambient pressure - the exhaust mass flow => Check air path system at the engine. 	<p>Dismount urea injector from exhaust line and inspect visually the injector and the exhaust line for urea crystallisation upstream of SCR catalyst:</p> <p>If crystallisation can be clearly seen, then standstill must be processed.</p> <p>Has the engine been operated in low load for longer time? If yes, then it could be the reason for crystallisation.</p> <p>Does the NOx-Sensors work properly? Compare ComRxSCR_rNOxUs to ComRxSCR_rNOxDs, when ComRxSCR_stNOxRdyUs = 1 & ComRxSCR_stNOxRdyDs = 1 (Warm engine and EAT-system, SCRT_tCatAverExhGs_mp > 250°C, SCR_stStatus = "Dosing" = 8): sensed NOx upstream of SCR catalyst must be higher than downstream of SCR catalyst.</p> <p>Go to idle and wait until SCR system enters status "stand-by" (no dosing), SCRT_tCatAverExhGs_mp < 225°C: ComRxSCR_rNOxUs = ComRxSCR_rNOxDs</p> <p>Clean urea injector: rinse it thoroughly under water</p> <p>Check EGR-Path: difference pressure sensor at venturi tube, EGR cooler, EGR-Valve, Reed-Valve, Intake throttle regarding function and leakage. Does the EGR-cooler leak water in the exhaust?</p> <p>Check air path for leakage</p> <p>Check turbocharger</p> <p>No crystallisation can be seen in the mixing pipe:</p> <p>Check exhaust pressure sensor upstream of SCR catalyst (SCR_pSensUCatUsP): tube, water in sensor?</p> <p>Check environmental pressure sensor (EnvP_p): plausible?</p> <p>Check exhaust temperature sensor upstream of SCR-catalyst (SCR_tSensUCatUsT): plausible compared to Exh_tOxiCatUs & Exh_tOxiCatDs e.g. when engine has idled for 20 minutes?</p> <p>=> Run stand-still to remove crystallisation and to reset the DFC</p>
5232719	3	<p>Urea supply module heater: the current drain measured by ECU is above the target range</p>	<p>Short circuit to battery</p> <p>If this error detected during the heating phase it is a result error:KWP 1089</p> <p>Broken wiring</p> <p>Heating element in supply module defect</p>	<p>Threshold for error detection is an internal ECU threshold</p> <p>Check wiring</p> <p>Check cabling, if necessary replace supply module</p>

SECTION 4. BOOM & PLATFORM

4.1 BOOM SYSTEMS

Wire Rope Service Indicator

The main boom is a 3 section proportionally driven telescopic boom. The mid boom section (Section #2) is driven directly by the telescope cylinder. The fly boom section (Section #3) is driven by a wire rope system.

The system contains a redundant rope that is capable of allowing the operator to unknowingly continue use of the machine with a single rope failure.

The Broken Cable Indicator System shows the operator one of the ropes has failed or needs adjustment. This system uses two proximity sensors (One for extend ropes and one for retract ropes) to detect excessive movement of the sensed rope as would be expected with a rope failure.

A broken rope detection results in illuminating the Cable Break indicator on the platform control panel.

Platform Control Enable System

The platform controls make use of a time dependent enable circuit to limit the time availability of "live" or enabled controls. To operate any directional function, the footswitch must be depressed before activation of the function. When the footswitch is depressed, the controls are enabled and the operator has 7 seconds to operate any function.

The controls will remain enabled as long as the operator continues to use any function and will remain enabled 7 seconds after the last function has been used. While the controls are "live", the enabled light will be illuminated in the platform display panel.

When the time limit has been reached, the enabled light will turn off and the controls will be "dead" or disabled. To continue use of the machine the controls must be re-enabled to start the timer system over again.

This is done by releasing all functions, then releasing and re-depressing the footswitch.

Platform Load Sensing System

The Platform Load Sensing System consists of a single load cell mounted within the platform support. This system compares the capacity mode (600 lb (270 kg) or 1000 lb (454 kg)) recognized by the dual capacity system (item 27) to the measured weight in the platform.

When the platform capacity is exceeded, or when there is a fault in the system, the platform overload indicator will flash, the platform alarm will sound at the rate of 5 sec on / 2 sec off and all platform function controls (except auxiliary power) will be disabled.

The ground controls are unaffected unless configured otherwise in the machine setup selection.

Jib Lift End Of Stroke Dampening

The jib lift cylinder is made in a way that causes the jib lift cylinder oil flow to be restricted while raising the jib within 5 degrees of maximum elevation. This restriction slows the jib lift speed while raising the jib. The oil flow is not restricted while lowering the jib and therefore the speed is not altered.

Transport Position Sensing System

The Transport Position Sensing System uses the following sensors to sense when the boom is in the position associated with high speed travel.

- Main boom angle sensors; The main boom angle limit switch will be used in the event of a main boom angle sensor fault
- Main boom length sensors; The main boom length switch will be used in the event of a main boom length sensor fault.
- Tower lift cylinder angle sensor; The tower angle sensors in conjunction with the chassis tilt sensor will be used in the event of a tower lift cylinder angle sensor fault
- Tower boom length sensors; The tower length switch will be used in the event of a tower length sensor fault.
- The position of the articulated jib is not considered

With healthy sensors, in transport, is defined as:

- Tower boom angle $\leq 8^\circ$ with respect to gravity
- Tower boom extended $\leq 4"$ (100mm)
- Main boom angle (With tower in transport position) 3°
- Main boom extended $\leq 4"$ (100mm)

This system is used in the control of the following systems:

- Beyond Transport - Drive Speed Cutback System
- Drive/Steer - Boom Function Interlock System - CE Only
- Jib Stow System
- Electrical Retrieval System
- Swing Speed Proportioning System
- Axle Extension System

Beyond Transport - Drive Speed Cutback System

When boom is positioned beyond the transport position as described above, the drive motors are automatically restricted to their maximum displacement position (slow speed). See the Tilt Indicator System in Section 3 for interaction with the tilt sensor.

Jib Stow System

This machine has a full function side swing rotator that is mechanically limited to 55 degree rotation to the left and electrically limited to 70 degrees to the right through the use of a limit switch mounted on the rotator assembly. The machine's stowed length can be reduced to help transport on trailers by swinging the jib further to the right using the hydraulic power of the side swing rotator. The control system will prevent swinging the jib past the 70 degree position unless the axles are retracted, the boom is in the transport position (see Transport Position Sensing System), and the jib stow override button on the platform control panel is held in combination with the jib swing function switch. When the jib is stowed, automatic platform leveling is disabled, the boom is restricted to the transport position, and axle extension is disabled. This system is functional only in the 600 lb (270 kg) mode of the Dual Capacity System.

Envelope Control System

The Envelope Control System is the primary means of controlling the working positions of the tower and main boom within the stability and structural specifications of the machine. The main boom must be controlled to avoid entering a position that could compromise stability and also avoid main boom to tower boom interference. The main boom envelope does not change based on tower boom angle. The tower boom must be controlled by permitting specific combinations of tower length and tower angle to avoid entering a position that could compromise stability (see Tower Path Control System).

SENSOR UTILIZATION AND SENSOR FAULT RESPONSE

This system uses two gravitationally based angle sensors and two length sensors to measure the position of the tower boom. The system also uses two rotary angle sensors and two length sensors to measure the position of the main boom. Each pair of sensors are monitored for agreement, response to command, and for correlation to a main boom angle proximity switch, a main boom length proximity switch, a tower boom length proximity switch, and a tower lift cylinder angle sensor. Recognized faults within this system will result in control by the Electrical Retrieval System, reduced function speeds, and BCS warning light illumination. After retrieval the boom will be restricted from leaving the transport position until the fault is resolved.

MAIN BOOM VIOLATIONS AND MACHINE RESPONSE

Boom position violations outside of the allowable envelope will result in reduced function speeds, BCS warning light illumination, and restriction of functions. The platform alarm will sound and the BCS light will flash with attempts to operate restricted functions.

The restricted functions due to main boom envelope violations related to forward reach are disallowing the following;

- Main lift down
- Main telescope out
- Swing
- Drive
- Steer.

The restricted functions due to main boom envelope violations related to backward reach are disallowing the following;

- Main lift up
- Main telescope in
- Swing
- Drive
- Steer.

TOWER BOOM VIOLATIONS AND MACHINE RESPONSE

Normally, the tower lift function switch on the ground and platform control panels automatically activates both tower lift and tower telescope as described in the tower path control system. Violations of the tower envelope will result in the suspension of this feature. If the control system is operating properly, violations of the tower envelope can be corrected by actuating either of the tower lift up or tower lift down directions of the tower lift switch regardless of the direction of the violation. The control system will telescope or lift the tower in a singular manner to correct the tower position.

The restricted functions due to forward tower envelope violations are disallowing the following;

- Automatic tower lift up with tower lift up commands
- Automatic tower telescope in with tower lift down commands
- Main lift up and down
- Main telescope out
- Jib
- Swing
- Drive
- Steer

The restricted functions due to backward tower envelope violations are disallowing the following;

- Automatic tower lift down with tower lift down commands
- Automatic tower telescope out with tower lift up commands
- Main lift up and down
- Main telescope in
- Jib
- Swing
- Drive
- Steer

In the event that the Tower Boom is not able to keep on its tower path and becomes encroached, the system will put the machine into Electrical Retrieval in order to safely retrieve both booms back into their stowed positions.

Tower Path Control System

The Tower Path Control System uses the envelope control sensors to enhance the control of the tower boom for increased user efficiency and is used as an integral part of the envelope control system. Both the ground and platform control panels use one function switch to control the tower. Operator commands for tower lift up or tower lift down cause the control system to automatically introduce the correct combination of tower telescope and tower lift for the tower boom to follow a pre-described path of the tower nose.

The tower path is a fixed relationship of tower length and tower angle (relative to gravity) and is constant regardless of main boom angle and is not affected by the main boom control select position.

Automatic Main Boom Control System

The Automatic Main Boom Control System uses the envelope control sensors to enhance the control of the main boom during tower lift functions. Due to the mechanical joining of the main and tower booms, changes in tower boom angle would normally have an opposite effect on the main boom angle. To take care of this, when the tower is raised the control system automatically functions main lift up. In the same manner, when the tower is lowered the control system automatically functions main lift down. This is done to keep the platform moving in the same direction as the user command and to increase user efficiency during tower lift functions.

During tower lift up or tower lift down movements, the control system will maintain the angle of the main boom (relative to gravity) read at the start of the tower lift command or as read at the conclusion of main lift during combined tower and main lift commands.

Main Boom Controlled Arc System

The Controlled Arc System uses the envelope control sensors to enhance the control of the main boom within the working envelope. The purpose of the controlled arc system is to minimize the interaction of lift functions with envelope edges and to increase operator efficiency. Because the boom is permitted to extend to longer lengths at high angles than at it is low angles, lift commands normally cause the boom to violate the permitted envelope while lifting down or require the operator to frequently command telescope out while lifting to high heights. The controlled arc system enhances the envelope shape by introducing telescope in or out during "lift only" commands. Telescope flow is regulated during lift commands to maintain a constant percentage of available boom length (0% is always fully retracted, 100% is variable as the permitted length changes when the boom is raised). The target percentage will be maintained throughout the lift command whether it is maintaining 0%, 100%, or any percentage in between. The target percentage is established at the start of lift command or end of manual telescope commands when using multiple functions with lift. The telescope command can be used independently or in combination with other functions. Manual introduction of telescope will override the controlled arc system and result in conventional control. Controlled arc will be disabled with any sensor failure, any envelope violation, or with auxiliary power functions. The controlled arc functionality can be turned off using the manual position of the boom control select switch on the platform console. When selected, this system is active at all main boom angles and lengths above 8° with respect to gravity. At main boom angles below 8° with respect to gravity, the main boom will stay at a constant length. In operating from ground control the Main Boom Controlled Arc System is always active.




Figure 4-1. Main Boom Controlled Arc Movement

Controlled Boom Angle System

The Controlled Boom Angle System uses the envelope control sensors to enhance the control of the boom by minimizing the interaction of swing and drive functions with the envelope edges. This interaction is due to two factors. First, the envelope is controlled relative to gravity regardless of ground slope and second, the turntable/boom mounting is effected by swing and drive functions when the ground slope varies. This can cause the boom position to vary within the envelope or even violate the envelope edges when swinging or driving without intentionally moving the boom. The controlled boom angle system minimizes this effect by automatically introducing either the tower or main boom lift up or down during swing and drive commands to maintain a constant boom angle relative to gravity.

When the tower is below the tower transport angle and the main boom is greater than 8° with respect to gravity, the angle of the main boom is controlled. When the tower is above the tower transport angle, the angle of the tower is controlled regardless of main boom control select switch selection. When both the tower boom and the main boom are in the transport position, no controlled boom angle occurs.

To compensate for any potential thermal drifting of the tower lift or tower tele cylinder while the machine is in a stationary position, when main boom up or down is activated, a potentially small tower lift compensation is made in the direction of travel to get the tower back to its normal tower path. This compensation is only done if the tower boom is not in transport position.

Controlled boom angle is disabled with any envelope violation or fault and can be turned off with the manual position of the boom control select switch.

Main Boom Control Select

The main boom control select switch is mounted on the platform control panel and allows the operator the ability to select between two different modes of main boom control functionality: automatic and manual. While in either mode, the Envelope Control System remains active.

When the main boom control is selected to the automatic boom control position, main lift and telescope movements are coordinated by the control system as described in the Main Boom Controlled Arc and Controlled Boom Angle sub-sections. These systems will remain active to automatically assist the operator in keeping the boom within the envelope boundaries. When operating in the automatic mode, the following functionality characteristics should be noted:

- While operating main boom lift up, the boom may also telescope out (controlled arc)
- While operating main boom lift down, the boom may also telescope in (controlled arc)
- While operating Swing or Drive, the main boom may lift up or lift down (controlled boom angle)

Also, when the main boom control is in the automatic position, the automatic platform leveling feature is active during main boom lift, telescope, swing, and drive movements as described in the Electronic Platform Leveling System sub-section.

When the main boom control is selected to the manual position, main boom lift and telescope movements are controlled separately by the operator effectively turning off the controlled arc and controlled main boom angle systems. Without these systems being active, the control system will stop the movements of the boom when the envelope boundaries are reached and the functions that could violate the envelope will be restricted. The platform alarm will sound and the BCS light will flash with attempts to operate a restricted function. Also, when the boom control is selected to the manual position, the automatic platform leveling feature is active only during main boom lift and tower boom lift movements.

Slow Down System

To reduce the machine dynamics and improve operator control, the control system uses the envelope control sensors to automatically slow down the tower lift up and tower lift down at the top of the tower path and to automatically slow down main lift up and main lift down function speeds as the minimum and maximum angles of the working envelope are approached, and main boom telescope out as the edge of the envelope is approached. The control system indicates to the operator this automatic introduction of slow down by illuminating the creep light on the platform display panel. This system applies to both platform and ground controls, however, no indication is made on the ground control panel.

Dual Capacity System

The Dual Capacity System is a multiple envelope control system. The control system changes the allowable working envelope to match the capacity select mode to either the 600 lb (272 kg) mode or the 1000 lb (454 kg) mode. It then displays the capacity mode on the platform and ground display panel and controls the positions of the main boom within the allowable envelope for that mode. The mode is selectable by the operator using the dual capacity select switch on the platform control panel.

The 600 lb (272 kg) mode has the largest envelope and allows the use of the side swing jib. The 1000 lb (454 kg) mode has a smaller envelope and requires the jib to be fixed in the centered position.

To select the 1000 lb (454 kg) mode the boom must already be in the smaller 600 lb (272 kg) envelope and the jib must be centered (± 10 degrees) verified to the control system by the jib centered limit switch mounted on the side swing rotator.

When the operator selects the 1000 lb (454 kg) mode and these conditions are met, the capacity light changes from 600 lb (272 kg) to 1000 lb (454 kg), jib swing is disallowed, and the envelope is changed accordingly.

When the operator selects the 1000 lb (454 kg) mode and these conditions are not met, both capacity lights will flash, the platform alarm will sound, and all functions except jib swing will be disabled until the capacity select switch is put back into the 600 lb (272 kg) position. Operation of jib swing in this condition can be used to find the center position of the jib as the jib swing function will stop when the center position is reached.

When in the 1000 lb (454 kg) mode, attempts to telescope, lift or lower the main boom into the restricted area will cause that function to be prevented and the BCS light will flash.




Figure 4-2. Boom and Cylinders Installation - Sheet 1 of 4




Figure 4-3. Boom and Cylinders Installation - Sheet 2 of 4




Figure 4-4. Boom and Cylinders Installation - Sheet 3 of 4




Figure 4-5. Boom and Cylinders Installation - Sheet 4 of 4





Figure 4-6. Jib and Rotator Hydraulic System


4.2 PLATFORM

Platform Valve Removal

1. Tag and disconnect the hydraulic lines from the platform control valve. Use suitable container to retain any residual hydraulic fluid. Cap hydraulic lines and ports.
2. Remove hardware securing cover from the platform support. Remove cover.




3. Remove hardware securing the mounting bracket to the platform support. Remove the mounting bracket along with platform control valve.
4. Remove hardware securing the platform control valve to the mounting bracket. Remove platform control valve.




Platform Valve Installation

1. Install platform control valve onto the mounting bracket and secure using hardware.
2. Install the mounting bracket onto the platform support and secure using hardware.



3. Install cover onto the platform support securing the hardware.



4. Remove tag and reconnect the hydraulic lines to the platform control valve.

Support Removal





Figure 4-7. Location of Components Platform Support


1. Disconnect electrical cables from control console.
2. Remove the bolts securing the platform to the platform support, then remove the platform.

NOTE: The platform support weighs approximately 124 lb (56 kg).




3. Using a suitable device, support the platform support.

4. Remove the bolts securing the support to the rotator.



5. Using a suitable brass drift and hammer, remove the rotator center bolt, then remove the support from the rotator.




Support Installation


1. Using a suitable device, support the platform support and position it on the rotator.

NOTE: The platform support weighs approximately 124 lb (56 kg).

2. Install the rotator center bolt.




3. Apply Medium Strength Threadlocking Compound to the eight bolts securing the support to the rotator and install the bolts.




4. Torque the nut on the rotator center bolt to 565 ft. lbs. (766 Nm). Torque the retaining bolts to 43 ft. lbs. (58 Nm).

5. Position the platform on the platform support and install the bolts securing the platform to the platform support.



6. Connect the electrical cables to the platform control console.



- A Torque to 43 ft. lbs. (58 Nm)
- B Medium Strength Threadlocking Compound
- C Torque to 565 ft. lbs. (766 Nm)
- D Check torque every 150 hours of operation

Figure 4-8. Platform Support Torque Values

4.3 ROTATOR

Removal

1. Remove the Platform and Platform Support. Refer to Section 4.2, Platform.
2. Tag and disconnect hydraulic lines to rotator. Use suitable container to retain any residual hydraulic fluid. Cap or plug all openings of hydraulic lines and ports.

NOTE: The rotator approximately weighs 60 lb (27 kg).

NOTE: The jib lift cylinder approximately weighs 82 lb (37 kg).

3. Supporting the rotator and jib lift cylinder, remove hardware from pin #1. Using a suitable brass drift and hammer remove pin #1.
4. Remove the hardware from pin #2. Using a suitable brass drift and hammer, remove pin #2 and remove the rotator.

Installation

NOTE: The rotator approximately weighs 60 lb (27 kg).

NOTE: The jib lift cylinder approximately weighs 82 lb (37 kg).

1. Supporting the rotator and jib lift cylinder, align rotator with jib lift cylinder and jib. Using a soft head mallet, install pin #1 to the jib assembly. Install hardware securing pin #1.
2. Using a soft head mallet install pin #2 to jib assembly and install the rotator. Install hardware securing pin #2.
3. Install the platform and platform support. Refer Section 4.2, Platform.
4. Remove cap or plugs from openings of hydraulic lines and ports and connect hydraulic lines to the rotator as tagged during removal.





Figure 4-9. Rotator Removal/Installation


4.4 BOOM MAINTENANCE

Tower and Main Boom Removal

1. Tag and disconnect the electrical wires and cables from the platform and pull them back through the jib.



2. Remove the hose clamps at the top and bottom of the jib. Tag and disconnect the hoses going to the platform valve and pull them back through the jib. Disconnect the cannon plug from under the console and pull it through the jib.



3. Disconnect the level sensor on the rotator and the level sensor on the fly section.
4. Disconnect the jib level sensor.

5. Attach a lifting device to support the front of the jib/platform assembly.



6. Remove the pivot pin bolt and remove the jib level cylinder pivot pin.







Figure 4-10. Main Boom Assembly - Sheet 1 of 7



* Medium Strength Threadlocking Compound
 ** High Strength Threadlocking Compound

- | | | | | |
|------------------------|--------------------------|--------------------------|-----------------------|-------------------------|
| 1. Main Extend Rope | 5. Prox Switch Mount | 9. Sheave Plate | 13. Cable Mount Block | 17. Sheave Spacer |
| 2. Main Extend Rope | 6. Trunnion Keeper Block | 10. Retract Sheave | 14. Main Retract Rope | 18. Sheave |
| 3. Rope Retainer Mount | 7. Trunnion Block Shim | 11. Sheave Bushing | 15. Main Retract Rope | 19. Wear Pad |
| 4. Prox Switch Spring | 8. Rope Retainer Block | 12. Sensor Spacer Sleeve | 16. Sheave Pin | 20. Rope Retainer Block |

Figure 4-11. Main Boom Assembly - Sheet 2 of 7




Figure 4-12. Main Boom Assembly - Sheet 3 of 7

SECTION 4 - BOOM & PLATFORM




Figure 4-13. Main Boom Assembly - Sheet 4 of 7




Figure 4-14. Main Boom Assembly - Sheet 5 of 7




Figure 4-15. Main Boom Assembly - Sheet 6 of 7





Figure 4-16. Main Boom Assembly - Sheet 7 of 7

SECTION 4 - BOOM & PLATFORM

7. Remove the bolt securing the keeper pin and remove the keeper pin and pivot pin securing the jib rotator support to the boom fly section.
8. Using an adequate lifting device, remove the jib and platform assembly from the machine and lay it on blocking.



⚠ WARNING

USE THE SERVICE MODE WITH EXTREME CAUTION AS IT OVERRIDES THE BOOM ENVELOPE CONTROL SYSTEM. IMPROPER USE CAN RESULT IN DAMAGE OR MACHINE INSTABILITY.

9. Use service mode code 68862 to extend the main boom using the main telescope switch on the ground control panel. Extend the boom (nearly full extension) until the pin securing the length sensor is visible in the cutout on


the base boom. Disconnect the cable and unbolt and remove the sensor.



10. Remove the side and upper wear pads from the boom base section.



11. Remove the wire rope sensor block and spring from the rear of the telescope cylinder.



12. Tag and disconnect the hoses from the rear of the telescope cylinder.
13. Remove the length sensor and mounting bracket.



14. Remove the bolts securing the trunnion blocks and remove the trunnion blocks securing the telescope cylinder rod to the boom base section.

15. Attach a source of hydraulic power to the telescope cylinder. Extend the cylinder and twist the end of the cylinder to allow it to pass through the boom base section.



16. Remove the component that secures the wire ropes.



SECTION 4 - BOOM & PLATFORM

17. Remove the bolts securing the push tube at the front of the fly section and mid sections. Strap the push tubes together.



18. Attach a lifting strap to the boom mid and fly assemblies. Lift the mid and fly assemblies up and remove the lower wear pads.




19. Pull the mid/fly boom assembly out of the boom base section, repositioning the lifting device as needed. Pull the wire ropes out from the cutout at the front of the base boom to ensure they don't get tangled or damaged. When pulling the wire ropes out through the front of the boom section, reinstall the lower wear pads to

protect the wire ropes. Remove the fly/mid boom assembly completely from the boom base section.




NOTE: The boom base section can remain on the machine for main boom maintenance.

20. Remove the plastic cover from the rear of the tower boom.



- 21. Tag and disconnect the wiring from the tower telescope cylinder port block.
- 22. Tag and disconnect the hoses on the tower telescope cylinder port block. Cap or plug all openings.




- 23. Tag and disconnect the wiring from the tower boom gravity sensors.



- 24. Tag and disconnect the wiring harnesses on the left side of the turntable beside the fuel tank that run to the tower boom.



- 25. Tag and disconnect the hoses running from the tower boom to the return manifold (T3 and T4). Cap or plug all openings.





SECTION 4 - BOOM & PLATFORM

26. Tag and disconnect the wiring from the tower boom that runs to the generator.



27. Tag and disconnect the hydraulic lines running from the tower boom to the main hydraulic control valve (Ports ML, TT, and P6). Cap or plug all openings.





⚠ WARNING

THE SERVICE MODE SHOULD BE USED WITH EXTREME CAUTION AS IT OVERRIDES THE BOOM ENVELOPE CONTROL SYSTEM. IMPROPER USE CAN RESULT IN COMPONENT INTERFERENCE/DAMAGE OR MACHINE INSTABILITY.

28. Use service code 12593 to raise the tower boom to horizontal using the tower lift switch on the ground control panel. Do not exceed a maximum tower boom angle of 65° relative to gravity.

NOTE: The tower boom weighs approximately 13,000 lb

29. Attach an adequate lifting device to the tower boom.






Figure 4-17. Tower Boom Assembly - Sheet 1 of 6




Figure 4-18. Tower Boom Assembly - Sheet 2 of 6




Figure 4-20. Tower Boom Assembly - Sheet 4 of 6






Figure 4-21. Tower Boom Assembly - Sheet 5 of 6



* Medium Strength Threadlocking Compound
** TORQUE TO 74 FT.LBS. (100 Nm)

Figure 4-22. Tower Boom Assembly - Sheet 6 of 6

- 30.** Tag and disconnect the hoses running through the push tubes to gain better access to the tower boom pivot pin. Cap or plug all openings and pull the hoses through the push tube.




- 31.** Remove the tower pivot pin bolt and keeper pin. Remove the pivot pin.



- 32.** Lift the boom up to expose the lift cylinder pivot pin.



- 33.** Place blocking underneath the lift cylinder.



- 34.** Remove the bolt and keeper pin from the lift cylinder pivot pin and remove the pivot pin.

- 35.** Lift the tower boom assembly from the machine.




Main Boom Disassembly

1. Remove the bolts securing the trunnion blocks securing the telescope cylinder barrel from the mid section. Remove the bolts from the cable blocks on the boom fly section..



2. Remove the telescope cylinder, with cables, from the boom mid section.



3. Unbolt the sheave guides at the rear of the mid section and remove the guides and sheave wheels.



4. Remove the wear pads from the front of the mid boom section.



5. Pull the fly section from the mid section. Ensure the cables do not get tangled in the mid section as the fly section is being removed.



6. Remove the wire ropes from the boom fly section.




7. Support the weight of the boom base section.




SECTION 4 - BOOM & PLATFORM


8. Tag and disconnect the hoses from the main boom valve. Cap or plug all openings.



9. Remove the keeper pin from the boom pivot pin. Remove the keeper bolt from the lift cylinder link pivot pin.



10. Remove the boom pivot pin.



11. Place a block under the lift cylinder link pivot.



12. Remove the link pivot pin. Remove the boom base section from the machine.

Main Boom Assembly

1. Apply Medium Strength Threadlocking Compound to the bolts and install the side, top, and bottom wear pads on the rear of the fly section. Torque the bolts to 43 ft. lbs. (58 Nm).



2. Lube the inside of the boom mid section. Refer to Break-In Lubrication in this Section.

3. Place the retract cable into the boom fly section, coiled to aid in assembly.



4. Install the swaged end of the wire ropes into the slots on the side of the boom section. Place tape over the slot to keep the ropes from jumping out during assembly.



5. Insert the boom fly section into the mid section.



SECTION 4 - BOOM & PLATFORM


6. Lift up the fly nose. Apply Medium Strength Threadlocking Compound to the bolts and install the front lower wear pads. Torque the bolts to 43 ft. lbs. (58 Nm).




7. Apply Medium Strength Threadlocking Compound to the bolts and install the top and side wear pads onto the boom fly section. Torque the bolts to 43 ft. lbs. (58 Nm).




8. Route the wire ropes from the boom fly section through the cutouts in the rear of the boom mid section.



9. Coat the sheave bushings with moly paste and install the wire rope sheaves, sheave plates, and retainer blocks using the attaching hardware at the rear of the mid boom section. Coat the larger bolts with High Strength Threadlocking Compound and torque to 178 ft. lbs. (241 Nm). Coat the smaller bolts with Medium Strength Threadlocking Compound and torque to 41 ft. lbs. (55 Nm).



10. Apply Medium Strength Threadlocking Compound to the bolts and install the wear pads on the rear of the boom mid section. Torque the bolts to 43 ft. lbs. (58 Nm).




SECTION 4 - BOOM & PLATFORM

11. Install the telescope cylinder, including wire ropes, part way into the fly/mid section assembly.



12. Install the cable guide to the fly section.




13. Continue inserting the telescope cylinder assembly into the fly/mid assembly until the trunnions are in place.



NOTE: Ensure the telescope cylinder is extended several feet to aid in assembly.

14. Install the trunnion blocks. Apply Medium Strength Threadlocking Compound to the keeper bolts and torque to 41 ft. lbs. (55 Nm).




- 15.** Insert the fly/mid boom assembly part way into the boom base section.



- 16.** Apply Medium Strength Threadlocking Compound to the bolts and install the front lower wear pads into the boom base section. Torque the bolts to 43 ft. lbs. (58 Nm).



- 17.** Using a portable source of hydraulic power, retract the telescope cylinder until the trunnions in the rod are in place in the boom base section.



- 18.** Install the trunnion blocks. Apply Medium Strength Threadlocking Compound to the keeper bolts and torque to 41 ft. lbs. (55 Nm).



- 19.** Install the length sensor.




SECTION 4 - BOOM & PLATFORM

20. Apply Medium Strength Threadlocking Compound to the bolts and install the remaining wear pads at the front of the boom base section. Torque the bolts to 43 ft. lbs. (58 Nm).



21. Bolt the push tube to the fly nose and the push tube support to the mid section.



22. Install the half sheaves at the front of the boom base section.



23. Install the adjustment nuts on the wire ropes at the front of the boom base.
24. Tighten the wire rope adjustment nuts at the rear of the boom. Refer to Section 4.9, Wire Rope for final adjustment procedures.



Tower Boom and Main Boom Installation

1. Install the push tube onto the tower boom.





2. Using an adequate lifting device, position the boom link to the mounting fixture on the tower boom.



3. Install the pivot pin. Install the keeper pin and apply High Strength Threadlocking Compound to the retaining bolt. Torque to 409 ft. lbs. (555 Nm).



4. Lower the boom link down onto blocking.



5. Install the main lift cylinder onto the tower boom. Use an adequate lifting device to position the lift cylinder to the attachment fitting on the tower link.




6. Install the pivot pin into the cylinder and tower link.



SECTION 4 - BOOM & PLATFORM

7. Install the keeper pin. Apply High Strength Threadlocking Compound to the retaining bolt and torque to 236 ft. lbs. (320 Nm).



8. Lower the cylinder onto blocking.



9. Apply moly paste to all the pivot pin holes, then attach lifting straps to the tower boom.



10. Lift the tower boom assembly into place above the machine.



11. Align the mounting fixture on the bottom of the tower boom assembly with the rod end of the tower lift cylinder. If necessary, use the service mode to extend the tower lift cylinder to aid in alignment.





- 12.** Install the boom pivot pin and the keeper. Coat the retaining bolt with High Strength Threadlocking Compound and torque to 409 ft. lbs. (555 Nm).



- 13.** If not already performed, use the service mode to extend the tower lift cylinder enough to remove the lift cylinder prop and remove the prop.

- 14.** Lower the tower enough to align the rear pivot fixture and tower boom. Install the thrust bushings, pivot pin, and keeper. Coat the retaining bolt with High Strength Threadlocking Compound and torque to 409 ft. lbs. (555 Nm).



- 15.** Route the hydraulic hoses through the push tube and connect them as tagged during removal.



SECTION 4 - BOOM & PLATFORM

16. Lift up the boom pivot link and place blocking under the link to aid in alignment when the main boom is set in place.




17. Lift the main boom into position above the tower boom and align the mounting fixtures.



18. Install the pivot pin for the link. Coat the bolt with High Strength Threadlocking Compound and secure the pin in place with the bolt and washer. Torque to 236 ft. lbs. (320 Nm).




19. Line up the boom pivot attachment fitting and install the boom pivot pin and keeper pin. Coat the retaining bolt with High Strength Threadlocking Compound and torque to 409 ft. lbs. (555 Nm).



- 20.** Lift the main lift cylinder to align the attachment fitting on the main boom with the cylinder rod.



- 22.** Connect the hydraulic lines to the lift cylinder as tagged during removal.



- 21.** Line up the lift cylinder attachment fitting and install the pivot pin and keeper pin. Coat the retaining bolt with High Strength Threadlocking Compound and torque to 250 ft. lbs. (339 Nm).

- 23.** Connect the hydraulic lines to the main boom valve as tagged during removal.



SECTION 4 - BOOM & PLATFORM

24. Install the boom length sensor. Connect the wiring to the sensor as tagged during removal.



⚠ WARNING

USE THE SERVICE MODE WITH EXTREME CAUTION AS IT OVERRIDES THE BOOM ENVELOPE CONTROL SYSTEM. IMPROPER USE CAN RESULT IN DAMAGE OR MACHINE INSTABILITY.

25. Use service mode code 68862 to extend the main boom using the main telescope switch on the ground control panel. Extend the boom (nearly full extension) until the attachment fitting for the pin to secure the length sensor cable is visible in the cutout on the base boom.



26. Install the pin and secure the end of the boom sensor cable.



4.5 LIFT CYLINDER

Removal

1. Fasten the tower mid boom section to the tower base boom section.



2. Use service mode code 49880 to extend the tower telescope just enough to access the lift cylinder pin.



3. Attach an adequate lifting strap to the cylinder.



4. Place blocking under the front of the boom.



5. Remove the bolt securing the keeper pin and remove the keeper pin securing the front of the cylinder to the main boom. Remove the pivot pin.



SECTION 4 - BOOM & PLATFORM

6. Place blocking under the cylinder and lower the cylinder onto the blocking.



7. Disconnect the wiring from the valve on the cylinder. Remove the sensor cover. Tag and disconnect the sensor wires. Tag and disconnect the hydraulic hoses from the cylinder. Cap or plug all openings.

8. Support the weight of the cylinder with the lifting strap. Remove the bolt securing the keeper pin and remove the keeper pin and rear pivot pin.



9. Place blocking under the rear of the cylinder to make it level with the blocking in the front.



10. Use an adequate lifting device to remove the cylinder from the machine.

4.6 BREAK-IN LUBRICATION

Main Boom

1. Use Super Lube® (JLG PN 3020042), moderately applied to all four inner surfaces of both ends of each boom section to a minimum depth of 3-4 feet (900-1200 mm). For the fly boom section, only apply to the end to be inserted into the mid boom section.
2. Also apply Super Lube® to all outer surface of interior wear pads after they are installed on the insertion end of the boom sections.

NOTICE

AVOID APPLICATION OF SUPER LUBE® ON EXPOSED, PAINTED SURFACES OF THE FULLY EXTENDED BOOM.

Tower Boom

1. Use Super Lube® (JLG PN 3020042), moderately applied to all four inner surfaces of both ends of boom sections #1 and #2 to a minimum depth of 3-4 feet (900-1200 mm).
2. Apply Super Lube® to the wear pads on the telescope cylinder support frame.
3. Also apply Super Lube® to all outer surface of interior wear pads after they are installed on the insertion end of boom sections #1 and #2.

NOTICE

AVOID APPLICATION OF SUPER LUBE® ON EXPOSED, PAINTED SURFACES OF THE FULLY EXTENDED BOOM.

4.7 BOOM CLEANLINESS GUIDELINES

The following are guidelines for internal boom cleanliness for machines that are used in excessively dirty environments.

1. JLG recommends the use of the JLG Hostile Environment Package if available to keep the internal portions of a boom cleaner and to help prevent dirt and debris from entering the boom. This package reduces the amount of contamination which can enter the boom but does not eliminate the need for more frequent inspections and maintenance when used in these types of environments.
2. JLG recommends that you follow all guidelines for servicing your equipment in accordance with the instructions outlined in the JLG Service & Maintenance Manual for your machine. Periodic maintenance and inspection is vital to the proper operation of the machine. The frequency of service and maintenance must be increased as environment, severity and frequency of usage requires.
3. Debris and foreign matter inside of the boom can cause premature failure of components and should be removed. Methods to remove debris should always be done using all applicable safety precautions outlined in the JLG Service & Maintenance Manuals.
4. The first attempt to remove debris from inside the boom must be to utilize pressurized air to blow the debris toward the nearest exiting point from the boom. Make sure that all debris is removed before operating the machine.
5. If pressurized air cannot dislodge the debris, then water with mild solvents applied via a pressure washer can be used. Again the method is to wash the debris toward the nearest exiting point from the boom. Make sure that all debris is removed, that no "puddling" of water has occurred, and that the boom internal components are dry prior to operating the machine. Make sure you comply with all federal and local laws for disposing of the wash water and debris.
6. If neither pressurized air nor washing of the boom dislodges and removes the debris, then disassemble the boom in accordance to the instructions outlined in the JLG Service & Maintenance Manual to remove the debris.

4.8 SHIMMING PROCEDURE FOR THE MAIN BOOM

NOTE: Throughout this procedure, boom sections are identified numerically, 1-3. Boom Section 1 is the base, Boom Section 3 is the fly. Boom wear pads are typically accompanied by corresponding shims in two thicknesses.

1. Measure and record any sweep dimension and direction of Boom Section 3. Measure and record the inside width and inside height of the Boom Section 2 opening.
2. Install the Internal Side wear pads on the Section 3 sides and shim as required to match the corresponding dimension recorded in step 1 within plus or minus 0.8mm (1/32"). Shims should be divided as evenly as possible between the side pads unless corrections are needed to compensate for any sweep recorded in step 1. If the sweep is to the left, the internal side pads on the right should have more shims than the left side pads and vice-versa.

NOTE: When installing wear pads, the wear pad bolt lengths may need to be adjusted as shim thicknesses are adjusted. Bolt lengths should fall flush to one thread below the surface of the insert. Bolt length can be tailored by substitution with like hardware of same grade and finish, one length increment longer or shorter than specified or by addition of a second washer under bolt head.




Figure 4-23. Boom Shimming

3. Install the internal bottom wear pad(s) and shims on Section 3 boom as specified on the boom assembly drawing including shims and/or spacer plates as indicated.

NOTE: There may be no shims on bottom pads.

4. Install the internal top wear pad(s) on Section 3 boom and shim as required to obtain the total dimension 0 to 1.6mm (1/16") under the corresponding dimension in step 1. Shims may be added or removed from the bottom pad position to achieve the desired gap if provided in the assembly.
5. Slide Section 3 into Section 2, leaving 2 to 6 feet exposed.
6. Install the external bottom wear pad(s) onto the end of Section 2 as specified on the boom assembly drawing including shims and/or spacer plates as indicated.

NOTE: There may be no shims on bottom pads.

7. Temporarily attach the External Side pads on one side of Section 2 and slide Section 3 boom to that side. Insert the other external side pads using shims. Measure how many will be required to fill the remaining space. Once this is established, install the total amount of shims as evenly as possible between the two sides unless corrections are needed to compensate for out of square booms or for additional corrections for any sweep recorded in step 1. Care should be taken to keep the bottom pads evenly loaded while shimming the side pads. If the sweep is to the left, the external side pads on the left should have more shims than the right side pads and vice-versa.

NOTE: Do not use a wedge to install more shims than will fit with the use of a pry bar. This may result in a boom being shimmed too tight. The use of pry bars should only be used to finish installing a shim that can be installed by hand more than 1/2 of its' length.

8. Install the external top wear pads and shims into the end of Section 2 leaving a gap of 0 to 1.6mm (1/16") between the top of the Section 3 and the pad inside Section 2. Shims may be added or removed from the bottom pad position to achieve the desired gap if provided in the assembly.
9. Repeat steps 1-8 above to assemble the Section 3/2 assembly into Section 1.
10. Complete the boom and machine assembly. The boom should be functionally tested and evaluated for boom sweep. If necessary, the boom may be re-shimmed by moving shims from one side to the other to further correct any remaining boom sweep. There may be some instances where no shims are used under a given side pad to pass the criteria for boom sweep at final inspection of machine.

4.9 WIRE ROPE


⚠ WARNING

IF DELAYED MOVEMENT IS DETECTED IN WIRE ROPE OPERATION, LOWER PLATFORM TO STOWED POSITION, SHUT DOWN MACHINE, AND HAVE WIRE ROPES INSPECTED/SERVICED BY A QUALIFIED JLG MECHANIC. LOOSE OR MIS-ADJUSTED WIRE ROPES COULD RESULT IN SERIOUS INJURY OR DEATH.

Inspection


NOTE: The pictures in this paragraph are just samples to show the replacement criteria of the rope.

1. Inspect ropes for broken wires, particularly valley wire breaks and breaks at end terminations.



Flexing a wire rope can often expose broken wires hidden in valleys between strands.


2. Inspect ropes for corrosion.
3. Inspect ropes for kinks or abuse.



A kink is caused by pulling down a loop in a slack line during improper handling, installation, or operation.

4. Inspect sheaves for condition of bearings/pins. (See Dimension Of Sheaves for proper dimension.)
5. Inspect sheaves for condition of flanges. (See Dimension Of Sheaves for proper dimension.)

6. Inspect sheaves with a groove wearout gauge for excessive wear.



Observe the groove so that it may be clearly seen whether the contour of the gauge matches the contour of the bottom of the groove.

7. Ropes passing inspection should be lubricated with wire rope lubricant before reassembly.

Three Month Inspection

1. Remove boom covers and visually (with flashlight) inspect the ropes for rust, broken wires, frays, abuse, or any signs of abnormalities.
2. Check rope tension by deflecting the ropes by hand. Properly tensioned ropes should have little or no movement.

NOTE: Delayed movement of the fly boom indicates loose wire ropes.

Additional Inspection Required If:

1. Machine is exposed to hostile environment or conditions.
2. Erratic boom operation or unusual noise exists.
3. Machine is idle for an extended period.
4. Boom is overloaded or sustained a shock load.
5. Boom exposed to electrical arc. Wires may be fused internally.

12 Year or 7000 Hour Replacement

1. Mandatory wire rope and sheave replacement.

Additional Replacement Criteria

NOTE: Sheaves and wire rope must be replaced as sets.

1. Rusted or corroded wire ropes.
2. Kinked, "bird caged", or crushed ropes.
3. Ropes at end of adjustment range.
4. Sheaves failing wearout gage inspection.
5. Ropes with 6 total broken wires in one rope lay, 3 in one strand in one rope lay, 1 valley break, or 1 break at any end termination.

4.10 WIRE ROPE TENSIONING/ADJUSTMENT PROCEDURE

The proper position of the boom sections (reference Figure A) must be achieved prior to tensioning, with wire rope equalized on both sides of sheaves and ropes properly seated in their grooves to allow proper tensioning of the wire ropes.

NOTE: Throughout this procedure, boom sections are identified numerically, 1-3. For example, Boom Section 1 is at the base, Boom Section 3 is the fly.




Figure 4-24. Figure A-Fully Retracted Boom Section Position Dimensions

Boom Preparation for Section Repositioning

NOTE: Use the Boom Telescope function to position the boom sections. Attempting to use rope adjustment nuts to position the boom sections will result in damage to the ropes and adjusters.

1. Confirm the boom assembly is in the fully retracted position.
2. Take preliminary measurements of the position of each boom section in the fully retracted position and compare to the dimensions shown in Figure A.

3. If the measurements do not fall within the tolerances in Figure A, adjust the position using the re-position procedures in Section 3 of this document.
4. If the measurements do fall within the tolerance in Figure A, proceed to Section 4 to apply proper tension to the ropes.

Boom Section #2 Repositioning:

NOTE: Boom Section #2 is positioned by the telescope cylinder. No adjustments to this section are necessary. The wire ropes within this assembly only control the movement of Boom Section #3. If Section #2 is out of tolerance, confirm boom is fully retracted and inspect telescope cylinder and boom tube weldment.

Boom Section #3 Repositioning

1. If Boom Section #3 does not fall within the dimension and tolerance shown in Figure A with the boom fully retracted, perform the following procedures.
2. If the Section needs to be RETRACTED (measured dimension greater than dimension shown in Figure A):
 - a. Remove any covers necessary to access the wire rope adjustment nuts. See Figure B.
 - b. Remove lock plates from wire rope adjustment studs.
 - c. Loosen the Section #3 Extend Adjustment Nuts shown in Figure C, moving them a distance equal to twice what the section needs to move to be within tolerance. (E.g. If the section must move $\frac{1}{2}$ " to fall within the dimension shown, loosen the nut such that it moves 1" closer to the exposed end of the adjustment stud.)
 - d. Extend the boom assembly such that the platform moves 4 to 5 feet (1.2m-1.5m) from the fully retracted position.




Figure 4-25. Figure B-Rope Adjuster Covers

- e. Tighten the Section #3 Retract Adjustment Nuts shown in Figure D, moving them a distance equal to what the section needs to move to be within tolerance. (E.g. If the section must move $\frac{1}{2}$ " to fall within the dimension shown, tighten the nut such that it moves $\frac{1}{2}$ " farther from the exposed end of the adjustment stud.)

- f. Fully retract the boom.
- g. To remove slack resulting from the adjustment in step C, tighten the Section #3 Extend Adjustment Nuts shown in Figure C until they contact the rope mount plate.
- h. Extend the boom assembly such that the platform moves 4 to 5 feet, then fully retract.
- i. Repeat step h three times to equalize rope position.
- j. Go to step 4.

3. If the Section needs to be EXTENDED (measured dimension less than dimension shown in Figure A):
 - a. Remove any covers necessary to access the wire rope adjustment nuts. See Figure B.
 - b. Remove lock plates from wire rope adjustment studs.
 - c. Extend the boom assembly such that the platform moves 4 to 5 feet (1.2m-1.5m) from the fully retracted position.
 - d. Loosen the Section #3 Retract Adjustment Nuts shown in Figure D, moving them a distance equal to twice what the section needs to move to be within tolerance. (E.g. If the section must move $\frac{1}{2}$ " to fall within the dimension shown, loosen the nut such that it moves 1" closer to the exposed end of the adjustment stud.)




Figure 4-26. Figure C-Section #3 Extend Rope Adjusters




Figure 4-27. Figure D-Section #3 Retract Rope Adjust-

- e. Retract the boom assembly such that the platform moves 2 to 3 feet (0.6m-0.9m) from the previous extended position in step 3C.
 - f. Tighten the Section #3 Extend Adjustment Nuts shown in Figure C, moving them a distance equal to what the section needs to move to be within tolerance. (E.g. If the section must move $\frac{1}{2}$ " to fall within the dimension shown, tighten the nut such that it moves $\frac{1}{2}$ " farther from the exposed end of the adjustment stud.)
 - g. To remove slack resulting from the adjustment in step 3D, tighten the Section #3 Retract Adjustment Nuts shown in Figure D until they contact the rope mount plate.
 - h. Extend the boom assembly such that the platform moves 4 to 5 feet, then fully retract.
 - i. Repeat 3H three times to equalize rope position.
 - j. Proceed to Step 4
4. Fully retract the boom sections.
 5. Verify that the exposed boom section dimensions meet the dimension and tolerance of Figure A.
 - a. If Section #3 still does not fall within the dimension and tolerance of Figure A, repeat the steps outlined in 3. Boom Section #3 Repositioning.
 - b. If Section #3 does fall within the dimension and tolerance of Figure A, proceed to 4. Wire Rope Tensioning Procedure.

Wire Rope Tensioning Procedure

NOTE: Repeat Wire Rope Tensioning Procedure only as necessary to achieve proper tension.

Verification of the rope tension should be determined by proper deployment function of the boom assembly and by the dimensions and tolerances shown in Figure A.

If the boom sections have been properly positioned but there is not enough adjustment travel remaining on a wire rope to achieve proper torque, the service life of the rope has been consumed. Do not continue with the remainder of this procedure. Replace all wire ropes and sheaves.

1. Remove any covers necessary to access the wire rope adjustment nuts. See Figure B.
2. Remove lock plates from wire rope adjustment studs.
3. Position the boom so that it is horizontal within $\pm 5^\circ$, and not supported by the boom rest.
 4. Extend the boom assembly such that the platform moves 4 to 5 feet (1.2m-1.5m) from the fully retracted position. The purpose of this step is to position the boom sections such that the ropes to be tensioned are not under load. If the extending boom reaches end of stroke and then automatically retracts a small amount, the ropes may still be under load. In such case, the following additional steps are necessary:
 - a. Note where the boom reached end of stroke.
 - b. Retract 3 to 4 feet (1m-1.3m).
 - c. Extend the boom, stopping just before end of stroke is reached.
 5. Using tool, JLG PN 1001203463, torque Section #3 Retract Adjustment Nuts shown in Figure D to 25 ft-lb (34 Newton meters), alternating between the two ropes until both maintain the required torque.
 6. Retract the boom 2-3 feet (.6m-1.0m) Do NOT fully retract the boom or bottom out any section.
 7. Using tool, JLG PN 1001203463, torque Section #3 Extend Adjustment Nuts shown in Figure C to 25 ft-lb (34 Newton meters), alternating between the two ropes until both maintain the required torque.

8. Equalize the rope tension across the sheaves by exercising the boom telescope position:
 - a. Fully retract the boom
 - b. Extend the boom 4 to 5 feet (1.2m-1.5m) from the fully retracted position or to the stroke limit identified in Step 4.
 - c. Repeat step A and step B for a minimum of three cycles, stopping with the boom extended 4 to 5 feet (1.2m-1.5m) from the fully retracted position or to the stroke limit identified in Step 4.
9. Verify wire rope torque values for retract ropes.
10. If the torque values are NOT correct, repeat Wire Rope Tensioning Procedure.
11. If the torque values are correct, proceed to Confirm Proper Boom Deployment Function.

Confirm Proper Boom Deployment Function

Exercise the boom telescope function. When wire ropes are properly torqued, all traveling sections will move simultaneously when extending and retracting.

Re-Assembly

1. Reinstall all lock plates to adjuster nuts.
2. Reinstall all covers.



4.11 HOSE ROUTING

For proper hose routing, refer to Figure 4-28. thru Figure 4-31. It is important to periodically inspect hoses, wraps and clamps for proper slack adjustments and clamping integrity (pull check). Any changes as a result of inspection should be verified by performing full strokes of boom functions especially lift, telescope, jib, and platform rotate.

Hose and Cables Adjustment Procedure


NOTE: The following procedure should be followed after the first 150 hours or 3 months (whichever comes first) of operation of a new machine or whenever hydraulic hoses or cables are replaced.

1. Fully secure all hydraulic hoses and cables in a clamp at Location A while maintaining 4.5" (114 mm) hose and cable loop as shown below.




SECTION 4 - BOOM & PLATFORM

2. While hydraulic hoses are under maximum circuit pressure, ensure all hoses and cables are resting against the flat bars on the outside radius of the powertrack curl (Location C as shown below).



3. While hydraulic hoses continue to be pressurized, tighten the clamp at Location B.



Go to Discount-Equipment.com to order your parts




Figure 4-28. Boom Hosing - Sheet 1 of 4

SECTION 4 - BOOM & PLATFORM




Figure 4-29. Boom Hosing - Sheet 2 of 4




Figure 4-30. Boom Hosing - Sheet 3 of 4




Figure 4-31. Boom Hosing - Sheet 4 of 4

4.12 ELECTRONIC PLATFORM LEVELING

The Electronic Platform Leveling System uses one gravity based tilt sensor (mounted on the side of the pivot weldment), a rotary sensor mounted between the main boom section #3 and jib pivot weldment), a control valve (mounted to the platform support), a level cylinder, and the platform control module (mounted in the platform control box) to measure and control the incline of the platform. This system is active while operating drive, telescope, lift, turntable swing and jib swing. It is not active while operating any other function (e.g. rotate, jib lift, or steer).

The system controls the platform angle relative to gravity only while activating tower lift, drive, main boom telescope, turntable swing, and jib swing. The system controls the platform angle relative to gravity using a new set point established during each machine enable or when switching from protractor leveling to gravity leveling or after a platform level override.

The system controls the platform angle by way of closed loop velocity control for platform level relative to main boom angle while activating main boom lift. The system controls the platform angle relative to main boom angle using a new protractor leveling set point taken after each machine enable or when switching from gravity level to protractor leveling or after a platform level override.

The operator can chose a platform incline other than level with gravity and the system will maintain that incline automatically.

If a fault occurs in the platform leveling system the following will occur:


- Automatic platform leveling will stop (except when there is a fault in only one sensor)
- The platform level fault indicator will flash
- The platform alarm will sound
- All functions will default to creep speed if in platform mode and the boom is out of the transport position

To reset a platform leveling fault, the emergency stop switch should be recycled.

4.13 POWERTRACK MAINTENANCE

One Piece Bracket Maintenance

1. Place the powertrack on a workbench.



2. Remove the screws from the bars on one side of the powertrack on the first link.




3. Remove the screws from the flat bar on the other side of the powertrack.




4. Pull up on the loose side of the round bar to allow the poly roller to slide off.





- 5.** Slide the poly roller off of the round bar.




- 6.** Hold the round bar to remove the other screw.



- 7.** Slide the flat bar out.




- 8.** Remove the snap ring from one side of the bracket.



- 9.** Remove the snap ring from the other side of the bracket.



10. Push down with slight pressure on the link and slide the bracket side up and over the extrusion on the link.



11. Repeat the previous step on the other side.




12. Slide the bracket off of the powertrack.



Two Piece Bracket Maintenance


1. Loosen the screw.




2. Slide the roller off the bar.




3. Hold the bar tightly and remove the other screw.



4. Hold the flat bar and remove the screws.



7. Slide the link out.



5. Remove the snap rings and pins.




Snap Rings and Screws

NOTICE

WHEN PERFORMING MAINTENANCE ON THE POWERTRACK, MAKE SURE TO DISCARD AND REPLACE ALL OLD SCREWS.


Make sure screws are tight and installed properly.

6. Remove the screws from the bar. Remove the snap ring and pin.



SECTION 4 - BOOM & PLATFORM


Make sure that all snap rings are closed and seated.



An open snap ring is shown below.



A snap ring that is not seated is shown below.



A seated and closed snap ring is shown below.



10-24 x 0.812 button torx socket head with blue locking patch:

- Tighten to 45-50 in.lbs. (5-5.6 Nm).
- Use T-25 torx bit.
- Do not reuse this screw. After removing replace with a new one.

4.14 ROTARY ACTUATOR

Each actuator is individually serial numbered. The serial number is a five or six digit number and must be provided before parts and/ or service issues can be addressed.

The serial number can be found on the Identification (ID) Tag that is affixed to all actuators. The tag is a thin, silver colored, plastic material with a self-adhesive backing. Information is imprinted in black. The tag is located either on the side plate or on the housing tube of the actuator.

Additionally, the serial number of the actuator is stamped onto the side plate or the housing tube. It may be necessary to remove paint to expose the serial number.

Theory of Operation

The rotary actuator is a simple mechanism that uses Helac's sliding spline technology which converts axial piston motion into powerful shaft rotation. As seen in the illustration below left, each actuator is composed of a housing with an integral ring gear (1) and only two moving parts: the central shaft (2), and the annular piston sleeve (3). Note the actuator shaft features an integral mounting flange and bearing which are not shown in the illustration.

Helical spline teeth machined on the shaft engage matching splines on the inside diameter of the piston. The outside diameter of the piston carries a second set of splines, of opposite hand, which engage the matching splines of the housing's ring gear.

As hydraulic pressure is applied, the piston is displaced axially within the housing - similar to the operation of a hydraulic cylinder - while, simultaneously, the splines cause the shaft to rotate. When the control valve is closed, oil is trapped inside the housing, preventing piston movement and locking the shaft firmly in position.

The shaft is supported radially by the large upper radial bearing and the lower radial bearing (see drawings on pages 8 and 9). Axially, the shaft is separated from the housing by the upper and lower thrust washers. The end cap is adjusted for axial clearance and locked in position by set screws or pins. Configurations of parts may be slightly different depending on model.

Many actuators are equipped with counterbalance valves, which performs four major functions.

- Protects the actuator in the event of overload
- Enables the actuator to hold position without drifting when external loads are applied
- Reduces hydraulic backlash by pressuring the hydraulic fluid
- Provides a constant controlled rate of rotation in over-center load conditions

Applying fluid pressure will displace the piston axially while the helical gearing causes the piston and shaft to rotate simultaneously. The double helix design compounds rotation: shaft rotation is about twice that of the piston. Applying pressure to the opposite port will return the piston and shaft to their original starting positions.




Figure 4-32. Actuator Theory of Operation

Tools Required



Several basic tools are required for the disassembly and reassembly of the actuator. The tools and their intended functions are outlined below:

1. PIPE VISE
2. HEXWRENCH
Removal and replacement of port plugs and set screws.
3. ASSORTED SCREWS
4. SAFETY GLASSES
5. END CAP REMOVAL TOOLS
(provided with seal kit)
6. DRILL
7. FLASHLIGHT
Helps in locating and examining timing marks, component failure and overall condition.
8. RUBBER MALLETT
Removal and installation of shaft and piston sleeve assembly.
9. PLASTIC MANDREL
10. PRY BAR
Removal of end cap and manual rotation of shaft.
11. FELT MARKER
Highlights timing marks and outlines troubled areas. Permanent ink is recommended.
12. T-HANDLE SCREW EXTRACTOR
13. HEX WRENCH SET
Removal and replacement of port plugs and set screws (106,110).
14. SEAL TOOLS
Removal and installation of seals and wear guides.
15. PUNCH
16. DOWEL PINS
Removal and installation of end cap.


CAUTION

TO AVOID INJURY BE CAREFUL WHEN HANDLING THE SCREWDRIVER WHEN HOT.

Disassembly

Inspect the actuator for corrosion prior to disassembly. Severe corrosion can make it difficult to remove the lock pins (109) and unthread the end cap (04). If corrosion is evident, soak the lock pins and end cap with penetrating oil for several hours before disassembling.

Disassembly is easier if the actuator is firmly secured to a work bench. A pipe vise or mounting fixture works well for this purpose.




1. Remove port plugs (106.1) (106.2) and drain oil. Inspect oil for signs of contamination, i.e. water, metal shavings.



2. Remove the capscrews (113) that cover the end cap lock pins (109).
3. Using a 1/8" (3 mm) drill bit, drill a hole in the center of each lock pin to a depth of approximately 3/16" (5 mm).

4. Remove the lock pins using a screw extracting tool such as an "Easy Out" (a size #2 is shown).

If the pin cannot be removed with the screw extractor, use a 5/16" bit to drill out the entire pin. Do not drill deeper than 1/2" (12.7 mm).




5. Install the end cap removal tools provided with the seal kit. (1/4-20)




6. Using a metal bar or similar tool, unthread the end cap (4) by turning it counterclockwise.





PARTS	HARDWARE	SEALS	BEARINGS	ACCESSORIES
1. Housing	103.1. Screw	200. T-Seal	302. Wear Guide	400. Stop Tube
2. Shaft	103.2. Washer	202. T-Seal	304. Thrust Washer	420.1 Bushing
3. Piston Sleeve	106.1. Port Plug	204. O-ring		420.2 Bushing
4. End Cap	106.2. Port Plug	205. Cup Seal		421.1 Bushing
	109. Lock Pin	207. Backup Ring		
	113. Capscrew	304.1. Wiper Seal		

Figure 4-33. Rotary Actuator - Assembly Drawing



PARTS

- 1. Housing
- 2. Shaft
- 3. Piston Sleeve
- 4. End Cap

HARDWARE

- 103.1. Screw
- 103.2. Washer
- 106.1. Port Plug
- 106.2. Port Plug
- 109. Lock Pin
- 113. Capscrew

SEALS

- 200. T-Seal
- 202. T-Seal
- 204. O-ring
- 205. Cup Seal
- 207. Backup Ring
- 304.1. Exclusion Seal

BEARINGS

- 302. Wear Guide
- 304. Thrust Washer

ACCESSORIES

- 400. Stop Tube
- 401. Counterbalance Valve

Figure 4-34. Rotary Actuator - Exploded View

SECTION 4 - BOOM & PLATFORM

7. Remove the end cap (4) and carefully set aside for later inspection.





8. Remove the stop tube (400) if the actuator is equipped with one. The stop tube is an available option that limits the rotation of the actuator.



9. Every actuator has two sets of small punched timing marks that indicate timing between the gear sets. The location and appearance of the marks can vary slightly between models. One set indicates the timing between the piston sleeve (3) and the housing (1) (upper photo), the second set between the piston and the shaft (lower photo). To ensure correct rotation and accurate end positions, it is essential that the actuator be correctly timed when it is reassembled. The punched timing marks can be used, but it is easier to highlight punched


marks with a marker before disassembly as outlined in the steps below.



10. Prior to removing the shaft (2), use a felt marker to clearly indicate the timing between shaft and piston sleeve (3). This will greatly simplify timing when the actuator is reassembled.




11. Remove the shaft (2) by rotating counterclockwise. As the shaft is rotated, it will disengage from the piston sleeve (3) and can be removed. It may be necessary to strike the threaded end of the shaft with a rubber mallet.



12. As in step 9, before removing the piston (3), mark the housing (1) ring gear in relation to the piston outside diameter gear. There should now be timing marks on the housing (1) ring gear, the piston (3) and the shaft (2).



13. To remove the piston (3) use a rubber mallet and a plastic mandrel so the piston and housing bore are not damaged.



14. At the point when the piston gear teeth come out of engagement with the housing gear teeth, mark the piston and housing with a marker as shown.



15. Remove the O-ring (204) and backup ring (207) from end cap (4).



NOTICE

TO AVOID DAMAGE TO MACHINED PARTS CAREFULLY REMOVE SEALS USING REMOVAL TOOLS WITH ROUNDED EDGES.

16. Remove the wear guide (302) from the end cap (4) and shaft (2).



17. Remove the main pressure seal (205).



18. Remove the thrust washer (304) from the end cap (4) and shaft (2).



19. Remove the O-ring (304.1) from its groove in the end cap (4) and shaft (2).



20. Remove the outside diameter piston seal (202) from the piston.



21. Remove the inside diameter piston seal (200).



Inspection

NOTICE

PRIOR TO ASSEMBLY OF ACTUATOR, THESE STEPS MUST BE CLOSELY FOLLOWED TO ENSURE PROPER OPERATION OF THE ACTUATOR.

1. Clean all parts in a solvent tank and dry with compressed air prior to inspecting.
2. Carefully inspect all critical areas for any surface finish abnormalities: Seal grooves, bearing grooves, thrust surfaces, shaft surface, housing bore and gear teeth.

NOTICE

SMALL OR MINOR SURFACE SCRATCHES CAN BE CAREFULLY POLISHED.

Assembly

1. Gather all the components and tools into one location prior to re-assembly. Use the cut away drawing to reference the seal orientations.



2. Coat the thrust washers (304) with a generous amount of Lithium grease. Install the thrust washer (304) onto shaft (2) and end cap (4).



3. Install the exclusion seal (304.1) into the appropriate grooves on the shaft (2) and end cap (4) around the outside edge of the thrust washer (304).



4. Using a seal tool install the main pressure seal (205) onto shaft (2) and end cap (4). Use the seal tool in a circular motion.



5. Install the wear guide (302) on the end cap (4) and shaft (2).



6. Install the O-ring (204) and backup ring (207) into the inner seal groove on the end cap (4).



SECTION 4 - BOOM & PLATFORM

7. Install the inner T-seal (200) into the appropriate groove in the piston (3). Use a circular motion to ensure the seal is correctly seated in the groove.

Install the outer T-seal (202) by stretching it around the groove in a circular motion.




Each T-seal has 2 backup rings (see Assembly Drawing for orientation). Beginning with the inner seal (200) insert one end of backup ring in the lower groove and feed the rest in using a circular motion. Make sure the wedged ends overlap correctly.

Insert the other backup ring in upper groove.

Repeat both of these steps for the outer seal (202).




8. Insert the piston (3) into the housing (1) as shown, until the outer piston seal (202) contacts the inside housing bore.



9. Looking into the housing bore from the shaft flange end, rotate the piston (3) until the marks you put on the piston and the housing (1) during disassembly align as shown. Using a rubber mallet, tap the piston into the housing until the gear teeth contact.




- 10.** Looking into the bore from the opposite end of the housing (1) be sure the timing marks align correctly. Rotate the piston as necessary until aligned, then gently tap the piston (3) into the housing until the gear teeth mesh together. Tap the piston into the housing until it completely bottoms out against the ring gear.



- 12.** Looking at the actuator from the end opposite the shaft flange, use the existing timing marks to align the gear teeth on the shaft (2) with the gear teeth on the inside of the piston (3). When the marks align, gently tap the flange end of the shaft with a rubber mallet until the gear teeth engage.




- 11.** Insert the shaft (2) into the piston (3). Be careful not to damage the piston seals. Do not engage the piston gear teeth yet.



- 13.** Install two bolts in the threaded holes in the flange. Using a metal bar, rotate the shaft in a clockwise direction until the wear guides are seated inside the housing bore.

NOTICE

AS THE SHAFT IS ROTATED, BE CAREFUL NOT TO DISENGAGE THE PISTON AND HOUSING GEARING.



SECTION 4 - BOOM & PLATFORM

14. Install the stop tube (400) onto the shaft end if necessary. Stop tubes are an available option to limit the rotation of an actuator.




15. Coat the threads on the end of the shaft with anti-seize grease to prevent galling.



16. Thread the end cap (4) onto the shaft (2). Make sure the wear guide remains in place on the end cap as it is threaded into the housing (1).




17. Tighten the end cap (4) using a metal bar. In most cases the original holes for the lock pins will align.



18. Insert the lock pins (109) provided with the Helac seal kit into the holes with the dimple side up. Then, using a punch, tap the lock pins to the bottom of the hole.




19. Insert the set screws (113) over the lock pins. Tighten to 25 in-lbs. (2.8 Nm).



Greasing Thrust Washers

1. After the actuator is assembled but before it is put into service, the thrust washer area must be packed with Lithium grease.


There are two grease ports located on both the shaft flange and the end cap. They are plugged with capscrews (113) or set screws. Remove the grease port screws from the shaft flange and end cap. (See exploded view)



NOTICE

IF A HYDRAULIC TEST BENCH IS NOT AVAILABLE, THE ACTUATOR CAN BE ROTATED BY HAND, OPEN THE PRESSURE PORTS AND USE A PRY BAR WITH CAPSCREWS INSERTED INTO THE SHAFT FLANGE TO TURN THE SHAFT IN THE DESIRED DIRECTION.

Insert the tip of a grease gun into one port and apply grease to the shaft flange. Continue applying until grease flows from the opposite port. Cycle the actuator five times and apply grease again. Repeat this process on the end cap. Insert the capscrews into the grease ports and tighten to 25 in-lbs. (2.8 Nm).



Installing Counterbalance Valve

Refer to Figure 4-35., Rotator Counterbalance Valve.

1. Make sure the surface of the actuator is clean, free of any contamination and foreign debris including old Threadlocking compound.
2. Make sure the new valve has the O-rings in the counterbores of the valve to seal it to the actuator housing.
3. The bolts that come with the valve are grade 8 bolts. New bolts should be installed with a new valve. Medium strength Threadlocking Compound should be applied to the shank of the three bolts at the time of installation.
4. Torque the 1/4-inch bolts 110 to 120 inch pounds (12.4 to 13.5 Nm). Do not torque over 125 inch pounds (14.1 Nm). Torque the 5/16-inch bolts 140 inch pounds (15.8 Nm). Do not torque over 145 inch pounds (16.3 Nm).

Testing the Actuator

If the equipment is available, the actuator should be tested on a hydraulic test bench. The breakaway pressure — the pressure at which the shaft begins to rotate — should be approximately 400 psi (28 bar). Cycle the actuator at least 25 times at 3000 psi (210 bar) pressure. After the 25 rotations, increase the pressure to 4500 psi (315 bar) to check for leaks and cracks. Perform the test again at the end of the rotation in the opposite direction.

TESTING THE ACTUATOR FOR INTERNAL LEAKAGE

If the actuator is equipped with a counterbalance valve, plug the valve ports. Connect the hydraulic lines to the housing ports. Bleed all air from the actuator (see Installation and Bleeding) Rotate the shaft to the end of rotation at 3000 psi (210 bar) and maintain pressure. Remove the hydraulic line from the non-pressurized side.

Continuous oil flow from the open housing port indicates internal leakage across the piston. Replace the line and rotate the shaft to the end of rotation in the opposite direction. Repeat the test procedure outlined above for the other port. If there is an internal leak, disassemble, inspect and repair.




Figure 4-35. Rotator Counterbalance Valve


Installation and Bleeding

After installation of the actuator on the equipment, it is important that all safety devices such as tie rods or safety cables are properly re-attached.

To purge air from the hydraulic lines, connect them together to create a closed loop and pump hydraulic fluid through them. Review the hydraulic schematic to determine which hydraulic lines to connect. The linear feet and inside diameter of the hydraulic supply lines together with pump capacity will determine the amount of pumping time required to fully purge the hydraulic system.

Bleeding may be necessary if excessive backlash is exhibited after the actuator is connected to the hydraulic system. The following steps are recommended when a minimum of two gallons (8 liters) is purged.

1. Connect a 3/16" inside diameter x 5/16" outside diameter x 5 foot clear, vinyl drain tube to each of the two bleed nipples. Secure them with hose clamps. Place the vinyl tubes in a clean 5-gallon container to collect the purged oil. The oil can be returned to the reservoir after this procedure is completed.



2. With an operator in the platform, open both bleed nipples 1/4 turn. Hydraulically rotate the platform to the end of rotation (either clockwise or counterclockwise), and maintain hydraulic pressure. Oil with small air bubbles will be seen flowing through the tubes. Allow a 1/2 gallon of fluid to be purged from the actuator.
3. Keep the fittings open and rotate the platform in the opposite direction to the end position. Maintain hydraulic pressure until an additional 1/4 gallon of fluid is pumped into the container.
4. Repeat steps 2 & 3. After the last 1/2 gallon is purged, close both bleed nipples before rotating away from the end position.

Troubleshooting

Table 4-1. Rotator Troubleshooting

Problem	Cause	Solution
1. Shaft rotates slowly or not at all	<p>a. Insufficient torque output</p> <p>b. Low rate of fluid flow</p> <p>c. Control or counterbalance valve has internal leak</p> <p>d. Piston and/or shaft seal leak</p> <p>e. Corrosion build-up on the thrust surfaces</p> <p>f. Swollen seals and composite bearings caused by incompatible hydraulic fluid</p>	<p>a. Verify correct operating pressure. Do not exceed OEM's pressure specifications. Load may be above maximum capacity of the actuator.</p> <p>b. Inspect ports for obstructions and hydraulic lines for restrictions and leaks.</p> <p>c. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports.</p> <p>d. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test as described in the Testing section on page 24 of this manual.</p> <p>e. Re-build the actuator. Remove all rust then polish. Replacement parts may be needed.</p> <p>f. Re-build the actuator. Use fluid that is compatible with seals and bearings.</p>
2. Operation is erratic or not responsive	a. Air in actuator	a. Purge air from actuator. See bleeding procedures.
3. Shaft will not fully rotate	<p>a. Twisted or chipped gear teeth</p> <p>b. Port fittings are obstructing the piston</p>	<p>a. Check for gear binding. Actuator may not be able to be re-built and may need to be replaced. Damage could be a result of overload or shock.</p> <p>b. Check thread length of port fittings. Fittings should during stroke not reach inside the housing bore.</p>
4. Selected position cannot be maintained	<p>a. Control or counterbalance valve has internal leak</p> <p>b. Piston and/or shaft seal leak</p> <p>c. Air in actuator</p>	<p>a. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports.</p> <p>b. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test as described in the Testing section on page 24 of this manual.</p> <p>c. Purge air from actuator. See bleeding procedures</p>

4.15 SKYWELDER

NOTE: Must be equipped with SkyPower™ unless otherwise approved.

NOTICE

INSTALLING OR REMOVING APPROVED ACCESSORIES OR CHANGING PLATFORM SIZE REQUIRES RECALIBRATION OF THE BOOM CONTROL SYSTEM AND THE LSS SYSTEM (IF EQUIPPED).




Figure 4-36. SkyWelder

Description

The welder is capable of TIG and Stick welding and is capable at producing 200 Amps at 100% duty cycle or 250 Amps at 50% duty cycle.

Generator Output

ANSI Specs: 240V; 60Hz; 3-Phase; 7.5kW and 240V/120V; 60Hz; Single Phase; 6kW.

CE Specs: 400V; 50Hz; 3-Phase; 7.5kW and 220V; 50Hz; Single Phase; 6kW.

Engine Speed of 1800 rpm +/- 10%.

Welding Accessories

The platform provides provisions for storing 12 ft. welding leads consisting of a clamp and a stinger. A fire extinguisher is also provided.

Welding Characteristics

Table 4-2. Welding Characteristics

Welding Mode	Input Power	Rated Output	Welding Amperage Range	Maximum Open Circuit Voltage	Amps Input At Rated Load Output. 50/60 Hz				
					230 V	460 V	575 V	KVA	KW
Stick (SMAW)	3-Phase	5-250 Amp at 30V. 50% Duty Cycle	5-250Amp	80VDC	30.5	14.7	11.6	11.7	8.6
		200 Amp at 28V. 100% Duty Cycle			21.7	11.4	9.2	9.1	6.4
TIG (GTAW)	1-Phase	200 Amp at 28V. 50% Duty Cycle	5-200Amp	65VDC	42.6	-----	-----	9.8	6.5
		150 Amp at 28V. 100% Duty Cycle			30.4	-----	-----	6.9	4.4

Safety Precautions

GENERAL



WARNING

DO NOT OVER LOAD PLATFORM.



WARNING

DE-RATE THE PLATFORM BY 70LB (32KG) WHEN WELDER IS INSTALLED IN THE PLATFORM.

1. Check for cracked welds and damage to welder supports.
2. Check for proper and secure installation of welder and bracket.
3. Be certain no personnel are beneath platform.
4. Do not exit platform over rails or stand on rails.
5. Only use this option on models specified.
6. Keep lanyard attached at all times.
7. Ensure correct polarity of leads.
8. Use proper welding apparel.
9. Use correct rod size and current settings.
10. Do not use electrical cords without ground.
11. Do not use electrical tools in water.
12. Do not weld to platform.
13. Do not ground through the platform.
14. Do not use a high frequency arc starter with TIG welder

Preparation and Inspection

Connect ground clamp to metal being welded, make sure there is a good ground connection and observe proper polarity, begin welding.

Operation

Start engine turn on generator then turn on welder.

Wear proper welding apparel. Set welder to proper amperage and voltage settings for thickness and type of metal being welded. Begin welding.

Refer to Miller Welder Operators Manual.

NOTE: Generator will not start under an electrical load.

Service and Maintenance

Refer to Miller Welder Service and Maintenance Manual.

Installation and Removal

REMOVAL

1. Unplug SkyWelder™ at twistlock plug.
2. Unbolt SkyWelder™ from bracket.
3. Remove for storage.

INSTALLATION

1. Place SkyWelder™ in weldment support.
2. Bolt top plate weldment support.
3. Connect twistlock plug.

4.16 SKYGLAZIER¹

NOTICE

INSTALLING OR REMOVING APPROVED ACCESSORIES OR CHANGING PLATFORM SIZE REQUIRES RECALIBRATION OF THE BOOM CONTROL SYSTEM.




Figure 4-37. SkyGlazier™

Description

This accessory is designed to allow the glaziers to efficiently position panels. The glazier package will consist of a tray which extends from the bottom of the platform. The panel will rest on the tray and against top-rail of the platform, which is padded to prevent damage to the panel. The accessory includes a strap to secure the panel to the platform rail. The SkyGlazier™ can only be utilized with a side entry platform.

Specifications

Table 4-3. Specifications with SkyGlazier™ Installed

Total Platform Capacity* - 272kg/600lbs capacity zone w/tray installed (ANSI Specs) - 270kg/600lbs capacity zone w/tray installed (CE Spec)	181kg/ 400lb
Total Platform Capacity* - 454kg/1000lbs capacity zone w/tray installed (ANSI Spec) - 450kg/1000lbs capacity zone w/tray installed (CE Spec)	340kg/ 750lb
Platform Size	0.914m x2.43m/ 36in. x96in.
Required Platform Type	Side Entry
Max. Tray Capacity in 270 kg / 600lbs capacity zone (ANSI Spec) - 230kg / 500lbs capacity zone (CE Spec)	68kg/ 150lb
Max. Tray Capacity in 454kg / 1000lbs capacity zone (ANSI Spec) - 450kg / 1000lbs capacity zone (CE Spec)	113kg/ 250lb
Max. Dimensions of panel	3 m ² / 32 sq ft
* Total Platform Capacity is defined as platform capacity + tray capacity.	
⚠ WARNING	
**INSTALLING OR REMOVING APPROVED ACCESSORIES OR CHANGING PLATFORM SIZE REQUIRES RECALIBRATION OF THE BOOM CONTROL SYSTEM.	

Safety Precautions

GENERAL

NOTE: Read and understand the Operation Manual. Ensure load is secured with load strap.

⚠ WARNING

DO NOT OVERLOAD TRAY OR PLATFORM. TOTAL MACHINE CAPACITY IS REDUCED WHEN TRAY IS INSTALLED.

⚠ WARNING

WITH THE SKYGLAZIER INSTALLED, THE ORIGINAL PLATFORM CAPACITY RATINGS ARE REDUCED AS SPECIFIED IN TABLE 4-3, SPECIFICATIONS WITH SKY-GLAZIER™ INSTALLED. DO NOT EXCEED THE NEW PLATFORM CAPACITY RATING. REFER TO CAPACITY DECAL LOCATED ON TRAY.

⚠ DANGER

AN INCREASE OF THE AREA EXPOSED TO THE WIND WILL DECREASE STABILITY. LIMIT PANEL AREA TO 32 SQ.FT. (3 SQ.M)

1. Make sure no personnel are beneath platform.
2. Do not exit platform over rails or stand on rails.
3. Only use this option as specified.

4. Remove tray when not in use.

Preparation and Inspection

1. Check for cracked welds and damage to tray. Make sure tray is properly secured to platform.
2. Check to ensure strap is not torn or frayed.

Operation

Load SkyGlazier™ with panel and secure with strap. Position panel to its desired location.

Service and Maintenance

Replace torn or frayed straps, bent or crushed tray, missing or illegible decals.

Check for loose nuts and bolts and Torque loose nuts and bolts to JLG Torque Chart specifications.

NOTE: The machine must be recalibrated. Refer to Section 6 for calibration procedure.


1. Install platform support onto rotator.
2. Insert the bolts with Medium strength Threadlocking Compound and torque to 50-55 lbs-ft.
3. Insert the bolt through the center and torque nut to 480 lbs-ft.
4. Install Glazier base (left & right) and platform onto the platform support.
5. Align base hole pattern with the hole pattern in the platform support.
6. Place platform onto the base and align similarly.
7. Secure with bolts, washers, and nuts with Medium strength Threadlocking Compound. Torque to 85 lbs-ft.
8. Install the control box and foot switch with existing hardware.
9. Mount Glazier tray onto Glazier base.
10. Secure tray with bolts, nuts, and washers. Torque to 260 lbs-ft.
11. Install bumper and strap kit as shown in Figure 4-37., SkyGlazier™.
12. To remove reverse instructions.

4.17 SKYGUARD


Operation

SkyGuard provides enhanced control panel protection. When the SkyGuard sensor is activated, functions in use at the time of actuation will reverse or cutout. The SkyGuard Function Table provides more details on these functions.


Consult the following illustrations to determine which type of SkyGuard the machine is equipped with. Regardless of the type, SkyGuard function according to the SkyGuard Function Table does not change.



SkyGuard



SkyGuard SkyLine™



SkyGuard SkyEye™

⚠ WARNING

THE MACHINE OPERATOR IS REQUIRED TO PERFORM A DAILY FUNCTION TEST TO ENSURE PROPER OPERATION OF THE SKYGUARD SYSTEM.

Function Test

SKYGUARD ONLY

Perform this function test if **SkyGuard only** is selected in machine setup (refer to Table 6-2).

From the Platform Control Console in an area free from obstructions:

1. Operate the telescope out function, then activate SkyGuard sensor.
2. Once sensor has been activated, ensure telescope out function stops then telescope in function operates for a short duration. Additionally, verify Soft Touch/SkyGuard indicator light flashes and horn sounds. If machine is equipped with SkyGuard beacon, ensure it flashes when sensor activates.
3. With SkyGuard sensor still engaged, press and hold yellow Soft Touch/SkyGuard override button. Operate a function to verify operation can be resumed.
4. Disengage SkyGuard sensor, release controls, and recycle footswitch. Ensure normal operation available.

In Ground Mode:

Operation is allowed regardless of SkyGuard activation.

SOFT TOUCH ONLY

If **Soft Touch only** is selected in machine setup (refer to Table 6-2), machine will treat the Soft Touch/SkyGuard override switch as if it is a Soft Touch switch.

SKYGUARD NOT SELECTED IN MACHINE SETUP

If the SkyGuard system is installed on the machine, but no option is selected in the machine setup (refer to Table 6-2), SkyGuard sensor status will be ignored. No function cutout or reversal will be implemented.

Diagnostics & Troubleshooting

If SkyGuard does not function when the sensor is engaged, first verify the configuration under the MACHINE SETUP: SKYGUARD OPTION menu using the handheld Analyzer. Ensure the selected configuration matches the actual system installed on the machine. If not, select the correct configuration, then verify operation.

Additionally, use the handheld analyzer to navigate to the DIAGNOSTICS: FEATURES → SKYGUARD INPUTS menu to determine additional SkyGuard fault information.

Engage the SkyGuard sensor and observe the Analyzer to determine if the switch/relay closes.

If the status of the switch/relay remains OPEN while the SkyGuard sensor is actively engaged, it is possible the sensor has failed and should be replaced immediately.

If the status of the switch/relay remains CLOSED while the SkyGuard sensor is actively engaged, a power or ground wire may not be making good contact or may be loose or broken. Additionally, there is a low probability that both relays may have failed.

If the switch/relay status is in disagreement, then one may have failed or is not installed correctly. In this case, the machine will be inoperable.

FAULT CODES

Refer to Table 6-15 for more fault code information

- **0039** - SkyGuard switch activation fault
- **2563** - switch disagreement fault

Table 4-4. SkyGuard Function Table

Drive Forward	Drive Reverse	Steer	Swing	Tower Lift Up	Tower Tele Out	Tower Lift Down	Tower Tele In	Boom Lift Up	Boom Lift Down	Boom Tele Out	Boom Tele In	Jib Lift	Jib Swing	Basket Level	Basket Rotate
R*/C**	R	C	R	C	C	C	C	R***/C****	R***/C****	R	C	C	C	C	C
R = Indicates Reversal is Activated															
C = Indicates Cutout is Activated															
*DOS (Drive Orientation System) Enabled															
**DOS Not Enabled, machine is driving straight without steering, and any other hydraulic function is active															
*** Operator is initiating command															
**** Control system is initiating command															

4.16 BOLT-ON EXTERNAL FALL ARREST

The bolt-on external fall arrest system is designed to provide a lanyard attach point while allowing the operator to access areas outside the platform. Exit/Enter the platform through the gate area only. The system is designed for use by one person.

Personnel must use fall protection at all times. A full body harness is required with lanyard not to exceed 6 ft. (1.8 M) in length, that limits the maximum arrest force to 900 lb (408 kg).

Bolt-On External Fall Arrest System capacity is 310 lb (140 kg) - one (1) person maximum.

Do not move the platform during use of the bolt-on external fall arrest system.

⚠ WARNING

DO NOT OPERATE ANY MACHINE FUNCTIONS WHILE OUTSIDE OF PLATFORM. BE CAREFUL WHEN ENTERING/EXITING THE PLATFORM AT ELEVATION.

⚠ WARNING

IF THE BOLT-ON EXTERNAL FALL ARREST SYSTEM IS USED TO ARREST A FALL OR IS OTHERWISE DAMAGED, THE ENTIRE SYSTEM MUST BE REPLACED AND THE PLATFORM FULLY INSPECTED BEFORE RETURNING TO SERVICE. REFER TO THE SERVICE MANUAL FOR REMOVAL AND INSTALLATION PROCEDURES.

THE BOLT-ON EXTERNAL FALL ARREST SYSTEM REQUIRES AN ANNUAL INSPECTION AND CERTIFICATION. THE ANNUAL INSPECTION AND CERTIFICATION MUST BE PERFORMED BY A QUALIFIED PERSON OTHER THAN THE USER.

Inspection Before Use

The bolt-on external fall arrest system must be inspected before each use of the mobile elevating work platform. Replace components if there are any signs of wear or damage.

Before each use, perform a visual inspection of the following components:

- Cable: Inspect cable for proper tension, broken strands, kinks, or any signs of corrosion.





Figure 4-38. Bolt-On External Fall Arrest Cable Tension


- Fittings & Brackets: Ensure all fittings are tight and there are no signs of fractures. Inspect brackets for any damage.
- Attachment Ring: No cracks or signs of wear are acceptable. Any signs of corrosion requires replacement.
- Attaching Hardware: Inspect all attaching hardware to ensure there are no missing components and hardware is properly tightened.
- Platform Rails: No visible damage is acceptable.

Installation

1. Install the retaining hardware (bolts, nuts, and washers) and secure the brackets to the platform rail. Tighten the nuts but do not torque them yet.




2. Attach the fall arrest cable to the right hand bracket Using the attaching bolt and nut. Orient the bolt as shown below. Do not tighten the nut so cable can still rotate.




3. Install the Attachment Ring onto the cable.
4. Without twisting the fall arrest cable, pull it thru the left hand bracket and mark the top of the swaged cable end. Install the fall arrest cable through the left hand bracket and secure it using the belleville washers, washer, retaining nut, and jam nuts. Orient the hardware as shown below and with the belleville washers so the gap is present at the outside diameter of the washers. install the

nuts onto the cable finger tight so the mark on the cable does not move.



5. Use the two jam nuts to prevent the cable from rotating while the nut is tightened. Tighten the nut until the belleville washers are fully compressed and no gap is present at the outside diameter of the washers. Ensure the cable has not rotated during tightening.



6. Tighten the first jam nut against the retaining nut to keep the nut from loosening. Tighten the remaining jam nut against the first jam nut.
7. Torque the nuts and bolts securing the brackets to 15 ft.lbs. (20 Nm)..




Figure 4-39. Bolt-On External Fall Arrest System

SECTION 5. BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

5.1 LUBRICATING O-RINGS IN THE HYDRAULIC SYSTEM


When assembling connectors in the hydraulic that use o-ring fittings, it is necessary to lubricate all fittings with hydraulic oil prior to assembly. To lubricate the fittings, use one of the following procedures.

NOTE: All O-ring fittings must be pre-lubricated with hydraulic oil prior to assembly.

Cup and Brush

The following is needed to correctly oil the o-ring in this manner:

- A small container for hydraulic oil
- Small paint brush



1. Hold the fitting in one hand while using the brush with the other hand to dip into the container. Remove excess hydraulic oil from the brush so an even film of oil is applied on the o-ring.



2. Holding the fitting over the hydraulic oil container, brush an even film of oil around the entire o-ring in the fitting, making sure the entire o-ring is completely saturated.



3. Turn the o-ring on the other side of the fitting and repeat the previous step, ensuring the entire o-ring is coated with hydraulic oil.



Dip Method

NOTE: This method works best with Face Seal o-rings, but will work for all o-ring fitting types.

The following is needed to correctly oil the o-ring in this manner:

- A small leak proof container
 - Sponge cut to fit inside the container
 - A small amount of hydraulic oil to saturate the sponge.
1. Place the sponge inside the container and add hydraulic oil to the sponge until it is fully saturated.
 2. Dip the fitting into the sponge using firm pressure. Upon lifting the fitting, a small droplet will form and drip from the bottom of the fitting. This should signify an even coating of oil on the fitting.



3. O-ring Boss type fittings will require more pressure in able to immerse more of the fitting into the saturated sponge. This will also cause more oil to be dispersed from the sponge.



Spray Method

This method requires a pump or trigger spray bottle.

1. Fill the spray bottle with hydraulic oil.
2. Hold the fitting over a suitable catch can.
3. Spray the entire o-ring surface with a medium coat of oil.



Brush-on Method

This method requires a sealed bottle brush.

1. Fill the bottle with hydraulic oil.
2. Using slight pressure to the body of the spray bottle, invert the bottle so the brush end is in the downward position.
3. Brush hydraulic oil on the entire o-ring, applying an even coat of oil.



5.2 HYDRAULIC CONNECTION ASSEMBLY AND TORQUE SPECIFICATION

Tapered Thread Types

NPTF = national tapered fuel (Dry Seal) per SAE J476/J512




Figure 5-1. NPTF Thread

BSPT = British standard pipe tapered per ISO7-1




Figure 5-2. BSPT Thread

Straight Thread Types, Tube and Hose Connections

JIC = 37° flare per SAE J514




Figure 5-3. JIC Thread

SAE = 45° flare per SAE J512




Figure 5-4. SAE Thread

ORFS = o-ring face seal per SAE J1453




Figure 5-5. ORFS Thread

MBTL = metric flareless bite type fitting, pressure rating L (medium) per ISO 8434, DIN 2353

MBTS = metric flareless bite type fitting, pressure rating S (high) per ISO 8434, DIN 2353




Figure 5-6. MTBL-MBTS Thread

BH = bulkhead connection – JIC, ORFS, MBTL, or MBTS types




Figure 5-7. Bulkhead Thread

Straight Thread Types, Port Connections

ORB = o-ring boss per SAE J1926, ISO 11926

MPP = metric pipe parallel o-ring boss per SAE J2244, ISO 6149, DIN 3852




Figure 5-8. ORB-MPP Thread

MFF = metric flat face port per ISO 9974-1

BSPP = British standard parallel pipe per ISO 1179-1, DIN 3852-2




Figure 5-9. MFF-BSPP Thread

Flange Connection Types

FL61 = code 61 flange per SAE J518, ISO 6162

FL62 = code 62 flange per SAE J518, ISO 6162




Figure 5-10. ORB-MPP Thread

Tightening Methods

Torque = Application of a twisting force to the applicable connection by use of a precise measurement instrument (i.e. torque wrench).

Finger Tight = The point where the connector will no longer thread onto the mating part when tightened by hand or fingers. Finger Tight is relative to user strength and will have some variance. The average torque applied by this method is 3 ft-lbs [4 N-m] Also referred to as 'Hand Tight.'

TFFT = Turns From Finger Tight; Application of a preload to a connection by first tightening the connection by hand (fingers) and applying an additional rotation counted by a defined number of turns by use of a tool.

FFWR = Flats from Wrench Resistance; Application of a preload to a connection by tightening to the point of initial wrench resistance and turning the nut a described number of 'flats'. A 'flat' is one side of the hexagonal tube nut and equates to 1/6 of a turn. Also referred to as the 'Flats Method.'

Assembly And Torque Specifications

Prior to selecting the appropriate torque from the tables within this section, it is necessary to properly identify the connector being installed. Refer to the Figures and Tables in this section.

GENERAL TUBE TYPE FITTING ASSEMBLY INSTRUCTIONS

1. Take precautions to ensure that fittings and mating components are not damaged during storage, handling or assembly. Nicks and scratches in sealing surfaces can create a path for leaks which could lead to component contamination and/or failure.
2. When making a connection to tubing, compression or flare, inspect the tube in the area of the fitting attachment to ensure that the tube has not been damaged.
3. The assembly process is one of the leading causes for contamination in air and hydraulic systems. Contamination can prevent proper tightening of fittings and adapters from occurring.
 - a. Avoid using dirty or oily rags when handling fittings.
 - b. If fittings are disassembled, they should be cleaned and inspected for damage. Replace fittings as necessary before re-installing.
 - c. Sealing compounds should be applied where specified; however, care should be taken not to introduce sealant into the system.
 - d. Avoid applying sealant to the area of the threads where the sealant will be forced into the system. This is generally the first two threads of a fitting.
 - e. Sealant should only be applied to the male threads.
 - f. Straight thread fittings do not require sealants. O-rings or washers are provided for sealing.
 - g. When replacing or installing an O-ring, care is to be taken while transferring the O-ring over the threads as it may become nicked or torn. When replacing an O-ring on a fitting, the use of a thread protector is recommended.
 - h. When installing fittings with O-rings, lubrication shall be used to prevent scuffing or tearing of the O-ring. See O-ring Installation (Replacement) in this section.
4. Take care to identify the material of parts to apply the correct torque values.
 - a. Verify the material designation in the table headings.
 - b. If specifications are given only for steel fittings and components, the values for alternate materials shall be as follows: Aluminum and Brass- reduce steel values by 35%; Stainless Steel- Use the upper limit for steel.
5. To achieve the specified torque, the torque wrench is to be held perpendicular to the axis of rotation.
6. Refer to the appropriate section in this manual for more specific instructions and procedures for each type of fitting connection

Assembly Instructions for American Standard Pipe Thread Tapered (NPTF) Connections.

1. Inspect components to ensure male and female port threads are free of rust, splits, dirt, foreign matter, or burrs.
2. Apply a suitable thread sealant, such as High Strength Threadlocking Compound, to the male pipe threads if not already applied. Ensure the first 1 to 2 threads are uncovered to prevent system contamination.
3. Assemble connection hand tight.
4. Mark fittings, male and female.

CAUTION

OVER TIGHTENING MAY CAUSE DEFORMATION OF THE PIPE FITTING AND DAMAGE TO THE JOINING FITTING, FLANGE OR COMPONENT MAY OCCUR.


NEVER BACK OFF (LOOSEN) PIPE THREADED CONNECTORS TO ACHIEVE ALIGNMENT. MEET THE MINIMUM REQUIRED TURNS AND USE THE LAST TURN FOR ALIGNMENT.

5. Rotate male fitting the number of turns per Table 5-1, NPTF Pipe Thread. See FFWR and TFFT Methods for TFFT procedure requirements.

NOTE: TFFT values provided in Table 5-1, NPTF Pipe Thread are applicable for the following material configurations:

- STEEL fittings with STEEL mating components
- STEEL fittings with ALUMINUM or BRASS mating components
- ALUMINUM or BRASS fittings with STEEL mating components
- ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

Table 5-1. NPTF Pipe Thread



TYPE/FITTING IDENTIFICATION					
Material	Dash Size	Thread Size (UNF)	ØA*		Turns From Finger Tight (TFFT)**
			(in)	(mm)	
STEEL, ALUMINUM, OR BRASS FITTINGS WITH STEEL, ALUMINUM, OR BRASS MATING COMPONENTS	2	1/8-27	0.40	10.24	2 to 3
	4	1/4-18	0.54	13.61	2 to 3
	6	3/8-18	0.67	17.05	2 to 3
	8	1/2-14	0.84	21.22	2 to 3
	12	3/4-14	1.05	26.56	2 to 3
	16	1-11 1/2	1.31	33.22	1.5 to 2.5
	20	1 1/4-11 1/2	1.65	41.98	1.5 to 2.5
	24	1 1/2-11 1/2	1.89	48.05	1.5 to 2.5
	32	2-11 1/2	2.37	60.09	1.5 to 2.5

* ØA thread dimension for reference only.

** See FFWR and TFFT Methods subsection for TFFT procedure requirements.

Assembly Instructions for British Standard Pipe Thread Tapered (BSPT) Connections

1. Inspect components to ensure male and female port threads are free of rust, splits, dirt, foreign matter, or burrs.
2. Apply a suitable thread sealant, such as High Strength Threadlocking Compound, to the male pipe threads if not already applied. Ensure the first 1 to 2 threads are uncovered to prevent system contamination.
3. Assemble connection hand tight.
4. Mark fittings, male and female.

5. Rotate male fitting the number of turns per Table 5-2, BSPT Pipe Thread. See FFWR and TFFT Methods for TFFT procedure requirements.

NOTE: TFFT values provided in Table 5-2, BSPT Pipe Thread are applicable for the following material configurations:


- STEEL fittings with STEEL mating components
- STEEL fittings with ALUMINUM or BRASS mating components
- ALUMINUM or BRASS fittings with STEEL mating components
- ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

⚠ CAUTION

OVER TIGHTENING MAY CAUSE DEFORMATION OF THE PIPE FITTING AND DAMAGE TO THE JOINING FITTING, FLANGE OR COMPONENT MAY OCCUR.

NEVER BACK OFF (LOOSEN) PIPE THREADED CONNECTORS TO ACHIEVE ALIGNMENT. MEET THE MINIMUM REQUIRED TURNS AND USE THE LAST TURN FOR ALIGNMENT.

Table 5-2. BSPT Pipe Thread



TYPE/FITTING IDENTIFICATION					Turns From Finger Tight (TFFT)**
MATERIAL	Dash Size	Thread Size	ØA*		
		(BSPT)	(in)	(mm)	
STEEL, ALUMINUM, OR BRASS FITTINGS WITH STEEL, ALUMINUM, OR BRASS MATING COMPONENTS	2	1/8-28	0.38	9.73	2 to 3
	4	1/4-19	0.52	13.16	2 to 3
	6	3/8-19	0.66	16.66	2 to 3
	8	1/2-14	0.83	20.96	2 to 3
	12	3/4-14	1.04	26.44	2 to 3
	16	1-11	1.31	33.25	1.5 to 2.5
	20	1 1/4-11	1.65	41.91	1.5 to 2.5
	24	1 1/2-11	1.88	47.80	1.5 to 2.5
	32	2-11	2.35	59.61	1.5 to 2.5

*ØA thread dimension for reference only.

** See Appendix B for TFFT procedure requirements.

Assembly Instructions for 37°(JIC) Flare Fittings

1. Inspect the flare for obvious visual squareness and concentricity issues with the tube OD. Ensure surface is smooth, free of rust, weld and brazing splatter, splits, dirt, foreign matter, or burrs. If necessary replace fitting or adapter.

⚠ CAUTION

DO NOT FORCE A MISALIGNED OR SHORT HOSE/TUBE INTO ALIGNMENT. IT PUTS UNDESIRABLE STRAIN ONTO THE JOINT EVENTUALLY LEADING TO LEAKAGE.

2. Align tube to fitting and start threads by hand.

⚠ CAUTION

THE TORQUE METHOD SHOULD NOT BE USED ON LUBRICATED OR OILY FITTINGS. NO LUBRICATION OR SEALANT IS REQUIRED. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Torque assembly to value listed in Table Table 5-3, 37° Flare (JIC)Thread - Steel or Table 5-4, 37° Flare (JIC)Thread - Aluminum/Brass while using the Double Wrench Method per Double Wrench Method. Refer to FFWR and TFFT Methods for procedure requirements if using the FFWR method.


NOTE: *Torque values provided in Table Table 5-3, 37° Flare (JIC)Thread - Steel and Table 5-4, 37° Flare (JIC)Thread - Aluminum/Brass are segregated based on the material configuration of the connection.*

ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- STEEL fittings with ALUMINUM or BRASS mating components
- ALUMINUM or BRASS fittings with STEEL mating components
- ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-3. 37° Flare (JIC) Thread - Steel




Type/Fitting Identification							Torque						Flats from Wrench Resistance (F.F.W.R)**
MATERIAL	Dash Size	Thread Size	ØA*		ØB*		[Ft-Lb]			[N-m]			
		(UNF)	(in)	(mm)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max	
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.28	7.00	0.31	7.75	6	7	7	8	9	10	--
	3	3/8-24	0.34	8.60	0.37	9.50	8	9	10	11	12	14	--
	4	7/16-20	0.39	10.00	0.44	11.10	13	14	14	18	19	19	1-1/2 to 1-3/4
	5	1/2-20	0.46	11.60	0.50	12.70	14	15	15	19	20	21	1 to 1-1/2
	6	9/16-18	0.51	13.00	0.56	14.30	22	23	24	30	31	33	1 to 1-1/2
	8	3/4-16	0.69	17.60	0.75	19.10	42	44	46	57	60	63	1-1/2 to 1-3/4
	10	7/8-14	0.81	20.50	0.87	22.20	60	63	66	81	85	89	1 to 1-1/2
	12	1 1/16-12	0.97	24.60	1.06	27.00	84	88	92	114	120	125	1 to 1-1/2
	14	1 3/16-12	1.11	28.30	1.19	30.10	100	105	110	136	142	149	1 to 1-1/2
	16	1 5/16-12	1.23	31.30	1.31	33.30	118	124	130	160	168	176	3/4 to 1
	20	1 5/8-12	1.54	39.20	1.63	41.30	168	176	185	228	239	251	3/4 to 1
	24	1 7/8-12	1.80	45.60	1.87	47.60	195	205	215	264	278	291	3/4 to 1
32	2 1/2-12	2.42	61.50	2.50	63.50	265	278	292	359	377	395	3/4 to 1	

* ØA and ØB thread dimensions for reference only.

** See Appendix B for FFWR procedure requirements.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-4. 37° Flare (JIC)Thread - Aluminum/Brass



TYPE/FITTING IDENTIFICATION							Torque						Flats from Wrench Resistance (F.F.W.R)**
MATERIAL	Dash Size	Thread Size	ØA*		ØB*		[Ft-Lb]			[N-m]			
		(UNF)	(in)	(mm)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max	
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.28	7.00	0.31	7.75	4	4	5	5	6	7	--
	3	3/8-24	0.34	8.60	0.37	9.50	5	6	7	7	8	9	--
	4	7/16-20	0.39	10.00	0.44	11.10	8	9	9	11	12	13	1-1/2 to 1-3/4
	5	1/2-20	0.46	11.60	0.50	12.70	9	10	10	12	13	14	1 to 1-1/2
	6	9/16-18	0.51	13.00	0.56	14.30	14	15	16	19	20	21	1 to 1-1/2
	8	3/4-16	0.69	17.60	0.75	19.10	27	29	30	37	39	41	1-1/2 to 1-3/4
	10	7/8-14	0.81	20.50	0.87	22.20	39	41	43	53	56	58	1 to 1-1/2
	12	11/16-12	0.97	24.60	1.06	27.00	55	57	60	74	78	81	1 to 1-1/2
	14	13/16-12	1.11	28.30	1.19	30.10	65	68	72	88	93	97	1 to 1-1/2
	16	15/16-12	1.23	31.30	1.31	33.30	77	81	84	104	109	114	3/4 to 1
	20	15/8-12	1.54	39.20	1.63	41.30	109	115	120	148	155	163	3/4 to 1
	24	17/8-12	1.80	45.60	1.87	47.60	127	133	139	172	180	189	3/4 to 1
32	2 1/2-12	2.42	61.50	2.50	63.50	172	181	189	234	245	257	3/4 to 1	

*ØA and ØB thread dimensions for reference only.

** See FFWR and TFFT Methods for FFWR procedure requirements.

Assembly Instructions for 45° SAE Flare Fittings

1. Inspect the flare for obvious visual squareness and concentricity issues with the tube OD. Ensure surface is smooth, free of rust, weld and brazing splatter, splits, dirt, foreign matter, or burrs. If necessary replace fitting or adapter.

⚠ CAUTION

DO NOT FORCE A MISALIGNED OR SHORT HOSE/TUBE INTO ALIGNMENT. IT PUTS UNDESIRABLE STRAIN ONTO THE JOINT EVENTUALLY LEADING TO LEAKAGE.

2. Align tube to fitting.
3. Tighten fitting by hand until hand tight.

⚠ CAUTION

THE TORQUE METHOD SHOULD NOT BE USED ON LUBRICATED OR OILY FITTINGS. NO LUBRICATION OR SEALANT IS REQUIRED. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

Torque fitting to value listed in Table 5-5, 45° Flare (SAE) - Steel and Table 5-6, 45° Flare (SAE) - Aluminum/Brass while using the Double Wrench Method outlined in this section. Refer to FFWR and TFFT Methods for procedure requirements if using the TFFT method.


NOTE: *Torque values provided in Table 5-5, 45° Flare (SAE) - Steel and Table 5-6, 45° Flare (SAE) - Aluminum/Brass are segregated based on the material configuration of the connection.*

ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- STEEL fittings with ALUMINUM or BRASS mating components
- ALUMINUM or BRASS fittings with STEEL mating components
- ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-5. 45° Flare (SAE) - Steel




TYPE/FITTING IDENTIFICATION							Torque					
MATERIAL	Dash Size	Thread Size	ØA*		ØB*		[Ft-Lb]			[N-m]		
			(UNF)	(in)	(mm)	(in)	(mm)	Min	Nom	Max	Min	Nom
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	4	7/16-20	0.39	9.90	0.44	11.10	13	14	14	18	19	19
	6	5/8-18	0.56	14.30	0.63	15.90	22	23	24	30	31	33
	8	3/4-16	0.69	17.50	0.75	19.10	42	44	46	57	60	62
	10	7/8-14	0.81	20.60	0.87	22.20	60	63	66	81	85	89
	12	1 1/16-14	0.98	25.00	1.06	27.00	84	88	92	114	119	125

* ØA and ØB thread dimensions for reference only.

** See FFWR and TFFT Methods for FFWR procedure requirements.

Table 5-6. 45° Flare (SAE) - Aluminum/Brass



TYPE/FITTING IDENTIFICATION							Torque					
MATERIAL	Dash Size	Thread Size	ØA*		ØB*		[Ft-Lb]			[N-m]		
			(UNF)	(in)	(mm)	(in)	(mm)	Min	Nom	Max	Min	Nom
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	4	7/16-20	0.39	9.90	0.44	11.10	8	9	9	11	12	12
	6	5/8-18	0.56	14.30	0.63	15.90	14	15	15	19	20	20
	8	3/4-16	0.69	17.50	0.75	19.10	27	29	30	37	39	41
	10	7/8-14	0.81	20.60	0.87	22.20	39	41	43	53	56	58
	12	1 1/16-14	0.98	25.00	1.06	27.00	55	58	61	75	79	83

* ØA and ØB thread dimensions for reference only.

** See FFWR and TFFT Methods for TFFT procedure requirements.

Assembly Instructions for O-Ring Face Seal (ORFS) Fittings

1. Ensure proper O-ring is installed. If O-ring is missing install per O-ring Installation (Replacement).
2. Ensure surface is smooth, free of rust, weld and brazing splatter, splits, dirt, foreign matter, or burrs. If necessary replace fitting or adapter.

CAUTION

CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. Place the tube assembly against the fitting body so that the flat face comes in contact with the O-ring. Hand thread the nut onto the fitting body.


5. Torque nut to value listed in Table 5-7, O-ring Face Seal (ORFS) - Steel or Table 5-8, O-ring Face Seal (ORFS) - Aluminum/Brass while using the Double Wrench Method. Refer to FFWR and TFFT Methods for procedure requirements if using the FFWR method.

NOTE: Torque values provided in Table 5-7, O-ring Face Seal (ORFS) - Steel and Table 5-8, O-ring Face Seal (ORFS) - Aluminum/Brass are segregated based on the material configuration of the connection.

ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:

- STEEL fittings with ALUMINUM or BRASS mating components
- ALUMINUM or BRASS fittings with STEEL mating components
- ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components

Table 5-7. O-ring Face Seal (ORFS) - Steel




TYPE/FITTING IDENTIFICATION						Torque						Flats from Wrench Resistance (F.F.W.R)**		
MATERIAL	Dash Size	Thread Size	ØA*		ØB*		[Ft-Lb]			[N-m]			Tube Nuts	Swivel & Hose Ends
		(UNF)	(in)	(mm)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max		
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	4	9/16-18	0.51	13.00	0.56	14.20	18	19	20	25	26	27	1/4 to 1/2	1/2 to 3/4
	6	11/16-16	0.63	15.90	0.69	17.50	30	32	33	40	43	45	1/4 to 1/2	1/2 to 3/4
	8	13/16-16	0.75	19.10	0.81	20.60	40	42	44	55	57	60	1/4 to 1/2	1/2 to 3/4
	10	1-14	0.94	23.80	1.00	25.40	60	63	66	81	85	89	1/4 to 1/2	1/2 to 3/4
	12	13/16-12	1.11	28.20	1.19	30.10	85	90	94	115	122	127	1/4 to 1/2	1/2 to 3/4
	16	17/16-12	1.34	34.15	1.44	36.50	110	116	121	149	157	164	1/4 to 1/2	1/2 to 3/4
	20	1 1/16-12	1.59	40.50	1.69	42.90	150	158	165	203	214	224	1/4 to 1/2	1/2 to 3/4
	24	2-12	1.92	48.80	2.00	50.80	230	242	253	312	328	343	1/4 to 1/2	1/2 to 3/4
	32	2 1/2-12	2.43	61.67	2.50	63.50	375	394	413	508	534	560	1/4 to 1/2	1/2 to 3/4

* ØA and ØB thread dimensions for reference only.

** See FFWR and TFFT Methods for FFWR procedure requirements.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-8. O-ring Face Seal (ORFS) - Aluminum/Brass



TYPE/FITTING IDENTIFICATION							Torque						Flats from Wrench Resistance (F.F.W.R)**	
MATERIAL	Dash Size	Thread Size (UNF)	ØA*		ØB*		[Ft-Lb]			[N-m]			Tube Nuts	Swivel & Hose Ends
			(in)	(mm)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max		
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	4	9/16-18	0.51	13.00	0.56	14.20	12	13	13	16	18	18	1/4 to 1/2	1/2 to 3/4
	6	11/16-16	0.63	15.90	0.69	17.50	20	21	22	27	28	30	1/4 to 1/2	1/2 to 3/4
	8	13/16-16	0.75	19.10	0.81	20.60	26	28	29	35	38	39	1/4 to 1/2	1/2 to 3/4
	10	1-14	0.94	23.80	1.00	25.40	39	41	43	53	56	58	1/4 to 1/2	1/2 to 3/4
	12	13/16-12	1.11	28.20	1.19	30.10	55	58	61	75	79	83	1/4 to 1/2	1/2 to 3/4
	16	17/16-12	1.34	34.15	1.44	36.50	72	76	79	98	103	107	1/4 to 1/2	1/2 to 3/4
	20	1 1/16-12	1.59	40.50	1.69	42.90	98	103	108	133	140	146	1/4 to 1/2	1/2 to 3/4
	24	2-12	1.92	48.80	2.00	50.80	12	13	13	16	18	18	1/4 to 1/2	1/2 to 3/4
	32	2 1/2-12	2.43	61.67	2.50	63.50	20	21	22	27	28	30	1/4 to 1/2	1/2 to 3/4

* ØA and ØB thread dimensions for reference only.

** See FFWR and TFFT Methods for FFWR procedure requirements.

Assembly Instructions for DIN 24¹/₄ Flare Bite Type Fittings (MBTL and MBTS)

⚠ CAUTION

A NON-SQUARE TUBE END CAN CAUSE IMPROPERLY SEATED FITTINGS AND LEAKAGE.

1. Inspect the components to ensure free of contamination, external damage, rust, splits, dirt, foreign matter, or burrs. Ensure tube end is visibly square. If necessary replace fitting or tube.
2. Lubricate thread and cone of fitting body or hardened pre-assembly tool, as well as the progressive ring and nut threads.
3. Slip nut and progressive ring over tube, assuring that they are in the proper orientation.
4. Push the tube end into the coupling body.
5. Slide collet into position and tighten until finger tight. Mark nut and tube in the finger-tight position. Tighten nut to the number of flats listed in Table Table 5-9, DIN 24° Cone (MBTL & MBTS) while using the Double Wrench Method. The tube must not turn with the nut.

Go to Discount-Equipment.com to order your parts

Table 5-9. DIN 24° Cone (MBTL & MBTS)

TYPE/FITTING IDENTIFICATION								DIN 24° CONE FLARELESS BITE FITTING (With or Without O-Ring)									
MATERIAL	TYPE	Tube O.D.	Thread M Size	ØA*	ØB*	C*	ØD*	Torque						Flats from Wrench Resistance (F.F.W.R)**			
		(mm)	(Metric)	(mm)	(mm)	(mm)	(mm)	[Ft-Lb]			[N-m]						
								Min	Nom	Max	Min	Nom	Max				
STEEL FITTINGS WITH STEEL MATING COMPONENTS	DIN 24° CONE FLARELESS BITE (MBTL) FITTING	6	M12x1.5	10.50	12.00	7.00	6.20	FFWR is the recommended method of fitting assembly. Torque values are application specific due to variability in the fitting supplier, coating, lubrication, and other physical characteristics of the connection. Refer to the specific procedure in this Service Manual.						1.5 to 1.75			
		8	M14x1.5	12.50	14.00	7.00	8.20							1.5 to 1.75			
		10	M16x1.5	14.50	16.00	7.00	10.20							1.5 to 1.75			
		12	M18x1.5	16.50	18.00	7.00	12.20							1.5 to 1.75			
		15	M22x1.5	20.50	22.00	7.00	15.20							1.5 to 1.75			
		18	M26x1.5	24.50	26.00	7.50	18.20							1.5 to 1.75			
		22	M30x2	27.90	30.00	7.50	22.20							1.5 to 1.75			
		28	M36x2	33.90	36.00	7.50	28.20							1.5 to 1.75			
		35	M45x2	42.90	45.00	10.50	35.30							1.5 to 1.75			
	42	M52x2	49.90	52.00	11.00	42.30	1.5 to 1.75										
	DIN 24° CONE FLARELESS BITE (MBTS) FITTING	TYPE	Tube O.D.	Thread M Size	ØA*	ØB*	C*	ØD*	Torque						Flats from Wrench Resistance (F.F.W.R)**		
			(mm)	(Metric)	(mm)	(mm)	(mm)	(mm)	[Ft-Lb]			[N-m]					
									Min	Nom	Max	Min	Nom	Max			
					6	M14x1.5	12.50	14.00	7.00	6.20	FFWR is the recommended method of fitting assembly. Torque values are application specific due to variability in the fitting supplier, coating, lubrication, and other physical characteristics of the connection. Refer to the specific procedure in this Service Manual.						1.5 to 1.75
					8	M16x1.5	14.50	16.00	7.00	8.20							1.5 to 1.75
					10	M18x1.5	16.50	18.00	7.50	10.20							1.5 to 1.75
					12	M20x1.5	18.50	20.00	7.50	12.20							1.5 to 1.75
					14	M22x1.5	20.50	22.00	8.00	14.20							1.5 to 1.75
16					M24x1.5	22.50	24.00	8.50	16.20	1.5 to 1.75							
20	M30x2	27.90			30.00	10.50	20.20	1.5 to 1.75									
25	M36x2	33.90			36.00	12.00	25.20	1.5 to 1.75									
30	M42x2	39.90			42.00	13.50	30.20	1.5 to 1.75									
38	M52x2	49.90	52.00	16.00	38.30	1.5 to 1.75											

* ØA, ØB, C, & ØD thread dimensions for reference only.

** See Appendix B for FFWR procedure requirements.


Assembly Instructions for Bulkhead (BH) Fittings

1. Ensure threads and surface are free of rust, weld and brazing splatter, splits, burrs or other foreign material. If necessary replace fitting or adapter.
2. Remove the locknut from the bulkhead assembly.
3. Insert the bulkhead side of the fitting into the panel or bulkhead bracket opening.
4. Hand thread the locknut onto the bulkhead end of the fitting body.
5. Torque nut onto fitting per Table 5-10 and Table 5-11 while using the Double Wrench Method.

Go to Discount-Equipment.com to order your parts


SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-10. Bulkhead Fittings (BH) - INCH



TYPE/FITTING IDENTIFICATION				FASTENING JAM NUT for Bulkhead Connectors						
MATERIAL	TYPE	Dash Size	Thread Size	Torque						
				[Ft-Lb]			[N-m]			
			(UNF)	Min	Nom	Max	Min	Nom	Max	
STEEL FITTINGS	O-RING FACE SEAL (ORFS) BULKHEAD FITTING	4	9/16-18	15	16	17	20	22	23	
		6	11/16-16	25	27	28	34	37	38	
		8	13/16-16	55	58	61	75	79	83	
		10	1-14	85	90	94	115	122	127	
		12	13/16-12	135	142	149	183	193	202	
		14	15/16-12	170	179	187	230	243	254	
		16	17/16-12	200	210	220	271	285	298	
		20	1 1/16-12	245	258	270	332	350	366	
		24	2-12	270	284	297	366	385	403	
	37° FLARE (JIC) BULKHEAD FITTING	TYPE	Dash Size	Thread Size	Torque					
					[Ft-Lb]			[N-m]		
		(UNF)	Min	Nom	Max	Min	Nom	Max		
		3	3/8-24	8	9	9	11	12	12	
		4	7/16-20	13	14	14	18	19	19	
		5	1/2-20	20	21	22	27	28	30	
		6	9/16-18	25	27	28	34	37	38	
		8	3/4-16	50	53	55	68	72	75	
		10	7/8-14	85	90	94	115	122	127	
		12	1 1/16-12	135	142	149	183	193	202	
		14	13/16-12	170	179	187	230	243	254	
		16	15/16-12	200	210	220	271	285	298	
		20	15/8-12	245	258	270	332	350	366	
24	17/8-12	270	284	297	366	385	403			
32	2 1/2-12	310	326	341	420	442	462			

Table 5-11. Bulkhead Fittings (BH) - METRIC



TYPE/FITTING IDENTIFICATION				FASTENING JAM NUT for Bulkhead Connectors					
MATERIAL	TYPE	Connecting Tube O.D.	Thread M Size	Torque					
				[Ft-Lb]			[N-m]		
		(mm)	(metric)	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS	DIN 24° CONE FLARELESS BITE (MBTL) BULKHEAD FITTING	6	M12x1.5	14	15	16	19	20	22
		8	M14x1.5	17	18	19	23	24	26
		10	M16x1.5	22	23	24	30	31	33
		12	M18x1.5	35	37	39	47	50	53
		15	M22x1.5	44	47	50	60	64	68
		18	M26x1.5	70	75	80	95	102	108
		22	M30x2	115	120	125	156	163	169
		28	M36x2	150	157	164	203	213	222
		35	M45x2	155	162	169	210	220	229
		42	M52x2	220	230	240	298	312	325
	DIN 24° CONE FLARELESS BITE (MBTS) BULKHEAD FITTING	Connecting Tube O.D.	Thread M Size	Torque					
				[Ft-Lb]			[N-m]		
		(mm)	(metric)	Min	Nom	Max	Min	Nom	Max
		6	M14x1.5	17	15	16	23	20	22
		8	M16x1.5	22	18	19	30	24	26
		10	M18x1.5	35	23	24	47	31	33
		12	M20x1.5	40	35	37	54	47	50
		14	M22x1.5	44	47	50	60	64	68
		16	M24x1.5	70	75	80	95	102	108
		20	M30x2	115	120	125	156	163	169
25	M36x2	150	157	164	203	213	222		
30	M42x2	155	162	169	210	220	229		
38	M52x2	220	230	240	298	312	325		

Assembly Instructions for O-Ring Boss (ORB)

Fittings

1. Inspect components to ensure that male and female port threads are free of rust, splits, dirt, foreign matter, or burrs.
2. Ensure proper O-ring is installed. If O-ring is missing install per O-ring Installation (Replacement).

⚠ CAUTION


CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. For Non-Adjustable and Plugs, thread the fitting by hand until contact.
5. For Adjustable fittings, refer to Adjustable Stud End Assembly for proper assembly.

6. Torque the fitting or nut to value listed in Table 5-12 thru Table 5-17 while using the Double Wrench Method.
 - a. The table headings identify the straight thread O-ring port and the type on the other side of the fitting. The torque will be applied to the straight thread O-ring port.
 - b. Torque values provided in Table 5-12 thru Table 5-17 are segregated based on the material configuration of the connection. 'ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:
 - STEEL fittings with ALUMINUM or BRASS mating components
 - ALUMINUM or BRASS fittings with STEEL mating components
 - ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.
7. Inspect to ensure the O-ring is not pinched and the washer is seated flat on the counterbore of the port.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-12. O-ring Boss (ORB) - Table 1 of 6




TYPE/FITTING IDENTIFICATION					HEX TYPE PLUGS & STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	(85)	(90)	(94)	10	10	11
	3	3/8-24	0.37	9.52	(155)	(163)	(171)	18	18	19
	4	7/16-20	0.44	11.11	22	23	24	29	31	33
	5	1/2-20	0.50	12.70	23	25	26	32	34	35
	6	9/16-18	0.56	14.28	29	31	32	40	42	43
	8	3/4-16	0.75	19.10	52	55	57	70	75	77
	10	7/8-14	0.87	22.22	85	90	94	115	122	127
	12	1 1/16-12	1.06	27.00	135	142	149	185	193	202
	14	1 3/16-12	1.19	30.10	175	184	193	235	249	262
	16	1 5/16-12	1.31	33.30	200	210	220	270	285	298
	20	1 5/8-12	1.63	41.30	250	263	275	340	357	373
	24	1 7/8-12	1.87	47.60	305	321	336	415	435	456
32	2 1/2-12	2.50	63.50	375	394	413	510	534	560	
TYPE/FITTING IDENTIFICATION					HEX TYPE PLUGS & STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	(55)	(58)	(61)	6	7	7
	3	3/8-24	0.37	9.52	(101)	(106)	(111)	11	12	13
	4	7/16-20	0.44	11.11	14	15	16	19	20	22
	5	1/2-20	0.50	12.70	15	16	17	20	22	23
	6	9/16-18	0.56	14.28	19	20	21	26	27	28
	8	3/4-16	0.75	19.10	34	36	37	46	49	50
	10	7/8-14	0.87	22.22	55	58	61	75	79	83
	12	1 1/16-12	1.06	27.00	88	93	97	119	126	132
	14	1 3/16-12	1.19	30.10	114	120	126	155	163	171
	16	1 5/16-12	1.31	33.30	130	137	143	176	186	194
	20	1 5/8-12	1.63	41.30	163	171	179	221	232	243
	24	1 7/8-12	1.87	47.60	198	208	218	268	282	296
32	2 1/2-12	2.50	63.50	244	256	268	331	347	363	

*ØA Thread OD dimension for reference only.

**Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-13. O-ring Boss (ORB) - Table 2 of 6




TYPE/FITTING IDENTIFICATION					STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	--	--	--	--	--	--
	3	3/8-24	0.37	9.52	--	--	--	--	--	--
	4	7/16-20	0.44	11.11	26	27	28	35	37	38
	5	1/2-20	0.50	12.70	30	32	33	40	43	45
	6	9/16-18	0.56	14.28	35	37	39	46	50	53
	8	3/4-16	0.75	19.10	60	63	66	80	85	89
	10	7/8-14	0.87	22.22	100	105	110	135	142	149
	12	1 1/16-12	1.06	27.00	135	142	149	185	193	202
	14	1 3/16-12	1.19	30.10	175	184	193	235	249	262
	16	1 5/16-12	1.31	33.30	200	210	220	270	285	298
	20	1 5/8-12	1.63	41.30	250	263	275	340	357	373
	24	1 7/8-12	1.87	47.60	305	321	336	415	435	456
32	2 1/2-12	2.50	63.50	375	394	413	510	534	560	
TYPE/FITTING IDENTIFICATION					STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	--	--	--	--	--	--
	3	3/8-24	0.37	9.52	--	--	--	--	--	--
	4	7/16-20	0.44	11.11	17	18	18	23	24	24
	5	1/2-20	0.50	12.70	20	21	21	27	28	28
	6	9/16-18	0.56	14.28	23	24	24	31	33	33
	8	3/4-16	0.75	19.10	39	41	43	53	56	58
	10	7/8-14	0.87	22.22	65	69	72	88	94	98
	12	1 1/16-12	1.06	27.00	88	93	97	119	126	132
	14	1 3/16-12	1.19	30.10	114	120	126	155	163	171
	16	1 5/16-12	1.31	33.30	130	137	143	176	186	194
	20	1 5/8-12	1.63	41.30	163	171	179	221	232	243
	24	1 7/8-12	1.87	47.60	198	208	218	268	282	296
32	2 1/2-12	2.50	63.50	244	256	268	331	347	363	

*ØA Thread OD dimension for reference only.

**Removal Torque for Zero Leak Gold® Hollow HexPlugs is significantly higher than install torque, typically 1.5-3.5X install torque.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-14. O-ring Boss (ORB) - Table 3 of 6




TYPE/FITTING IDENTIFICATION					ADJUSTABLE STUD END with 37° (JIC) or L series DIN (MBTL) opposite end					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	(60)	(63)	(66)	7	7	7
	3	3/8-24	0.37	9.52	(100)	(105)	(110)	11	12	12
	4	7/16-20	0.44	11.11	15	16	17	20	22	23
	5	1/2-20	0.50	12.70	21	22	23	28	30	31
	6	9/16-18	0.56	14.28	29	31	32	40	42	43
	8	3/4-16	0.75	19.10	52	55	57	70	75	77
	10	7/8-14	0.87	22.22	85	90	94	115	122	127
	12	1 1/16-12	1.06	27.00	135	142	149	185	193	202
	14	1 3/16-12	1.19	30.10	175	184	193	235	249	262
	16	1 5/16-12	1.31	33.30	200	210	220	270	285	298
	20	1 5/8-12	1.63	41.30	250	263	275	340	357	373
	24	1 7/8-12	1.87	47.60	305	321	336	415	435	456
32	2 1/2-12	2.50	63.50	375	394	413	510	534	560	
TYPE/FITTING IDENTIFICATION					ADJUSTABLE STUD END with 37° (JIC) or L series DIN (MBTL) opposite end					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	(39)	(41)	(43)	4	5	5
	3	3/8-24	0.37	9.52	(65)	(69)	(72)	7	8	8
	4	7/16-20	0.44	11.11	10	11	11	14	15	15
	5	1/2-20	0.50	12.70	14	15	15	19	20	20
	6	9/16-18	0.56	14.28	19	20	21	26	27	28
	8	3/4-16	0.75	19.10	34	36	37	46	49	50
	10	7/8-14	0.87	22.22	55	58	61	75	79	83
	12	1 1/16-12	1.06	27.00	88	93	97	119	126	132
	14	1 3/16-12	1.19	30.10	114	120	126	155	163	171
	16	1 5/16-12	1.31	33.30	130	137	143	176	186	194
	20	1 5/8-12	1.63	41.30	163	171	179	221	232	243
	24	1 7/8-12	1.87	47.60	198	208	218	268	282	296
32	2 1/2-12	2.50	63.50	244	256	268	331	347	363	

*ØA Thread OD dimension for reference only.

**Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-15. O-ring Boss (ORB) - Table 4 of 6



TYPE/FITTING IDENTIFICATION					ADJUSTABLE STUD END with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	--	--	--	--	--	--
	3	3/8-24	0.37	9.52	--	--	--	--	--	--
	4	7/16-20	0.44	11.11	15	16	17	20	22	23
	5	1/2-20	0.50	12.70	30	32	33	40	43	45
	6	9/16-18	0.56	14.28	35	37	39	46	50	53
	8	3/4-16	0.75	19.10	60	63	66	80	85	89
	10	7/8-14	0.87	22.22	100	105	110	135	142	149
	12	1 1/16-12	1.06	27.00	135	142	149	185	193	202
	14	1 3/16-12	1.19	30.10	175	184	193	235	249	262
	16	1 5/16-12	1.31	33.30	200	210	220	270	285	298
	20	1 5/8-12	1.63	41.30	250	263	275	340	357	373
	24	1 7/8-12	1.87	47.60	305	321	336	415	435	456
32	2 1/2-12	2.50	63.50	375	394	413	510	534	560	
TYPE/FITTING IDENTIFICATION					ADJUSTABLE STUD END with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	--	--	--	--	--	--
	3	3/8-24	0.37	9.52	--	--	--	--	--	--
	4	7/16-20	0.44	11.11	10	11	11	14	15	15
	5	1/2-20	0.50	12.70	20	21	21	27	28	28
	6	9/16-18	0.56	14.28	23	24	24	31	33	33
	8	3/4-16	0.75	19.10	39	41	43	53	56	58
	10	7/8-14	0.87	22.22	65	69	72	88	94	98
	12	1 1/16-12	1.06	27.00	88	93	97	119	126	132
	14	1 3/16-12	1.19	30.10	114	120	126	155	163	171
	16	1 5/16-12	1.31	33.30	130	137	143	176	186	194
	20	1 5/8-12	1.63	41.30	163	171	179	221	232	243
	24	1 7/8-12	1.87	47.60	198	208	218	268	282	296
32	2 1/2-12	2.50	63.50	244	256	268	331	347	363	
*ØA Thread OD dimension for reference only.										
**Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.										

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS


Table 5-16. O-ring Boss (ORB) - Table 5 of 6



TYPE/FITTING IDENTIFICATION					HOLLOW HEX PLUGS					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	(30)	(32)	(33)	3	4	4
	3	3/8-24	0.37	9.52	(55)	(58)	(61)	6	7	7
	4	7/16-20	0.44	11.11	10	11	11	14	15	15
	5	1/2-20	0.50	12.70	14	15	16	19	20	22
	6	9/16-18	0.56	14.28	34	36	38	46	49	52
	8	3/4-16	0.75	19.10	60	63	66	80	85	89
	10	7/8-14	0.87	22.22	100	105	110	135	142	149
	12	1 1/16-12	1.06	27.00	135	142	149	185	193	202
	14	1 3/16-12	1.19	30.10	175	184	193	235	249	262
	16	1 5/16-12	1.31	33.30	200	210	220	270	285	298
	20	1 5/8-12	1.63	41.30	250	263	275	340	357	373
	24	1 7/8-12	1.87	47.60	305	321	336	415	435	456
32	2 1/2-12	2.50	63.50	375	394	413	510	534	560	
TYPE/FITTING IDENTIFICATION					HOLLOW HEX PLUGS					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	(20)	(21)	(21)	2	2	2
	3	3/8-24	0.37	9.52	(36)	(38)	(40)	4	4	5
	4	7/16-20	0.44	11.11	6	7	7	8	9	9
	5	1/2-20	0.50	12.70	9	10	10	12	14	14
	6	9/16-18	0.56	14.28	22	24	25	30	33	34
	8	3/4-16	0.75	19.10	39	41	43	53	56	58
	10	7/8-14	0.87	22.22	65	69	72	88	94	98
	12	1 1/16-12	1.06	27.00	88	93	97	119	126	132
	14	1 3/16-12	1.19	30.10	114	120	126	155	163	171
	16	1 5/16-12	1.31	33.30	130	137	143	176	186	194
	20	1 5/8-12	1.63	41.30	163	171	179	221	232	243
	24	1 7/8-12	1.87	47.60	198	208	218	268	282	296
32	2 1/2-12	2.50	63.50	244	256	268	331	347	363	
* ØA Thread OD dimension for reference only.										
** Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.										

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-17. O-ring Boss (ORB) - Table 6 of 6



TYPE/FITTING IDENTIFICATION					ZERO LEAK GOLD® HOLLOW HEX PLUGS					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	2	3	4	3	4	5
	3	3/8-24	0.37	9.52	3	4	5	4	5	7
	4	7/16-20	0.44	11.11	7	8	9	9	11	12
	5	1/2-20	0.50	12.70	9	10	11	12	14	15
	6	9/16-18	0.56	14.28	11	12	13	15	16	18
	8	3/4-16	0.75	19.10	28	30	32	38	41	43
	10	7/8-14	0.87	22.22	46	48	50	62	65	68
	12	11/16-12	1.06	27.00	51	54	57	69	73	77
	14	13/16-12	1.19	30.10	Fitting size greater than -12 not typically specified on JLG applications. Consult specific service procedure if encountered.					
	16	15/16-12	1.31	33.30						
	20	15/8-12	1.63	41.30						
	24	17/8-12	1.87	47.60						
32	21/2-12	2.50	63.50							
TYPE/FITTING IDENTIFICATION					ZERO LEAK GOLD® HOLLOW HEX PLUGS					
MATERIAL	Dash Size	Thread Size	ØA*		Torque					
		(UNF)	(in)	(mm)	Min	Nom	Max	Min	Nom	Max
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	2	5/16-24	0.31	7.93	2	3	4	3	4	5
	3	3/8-24	0.37	9.52	3	4	5	4	5	7
	4	7/16-20	0.44	11.11	7	8	9	9	11	12
	5	1/2-20	0.50	12.70	9	10	11	12	14	15
	6	9/16-18	0.56	14.28	11	12	13	15	16	18
	8	3/4-16	0.75	19.10	28	30	32	38	41	43
	10	7/8-14	0.87	22.22	46	48	50	62	65	68
	12	11/16-12	1.06	27.00	51	54	57	69	73	77
	14	13/16-12	1.19	30.10	Fitting size greater than -12 not typically specified on JLG applications. Consult specific service procedure if encountered.					
	16	15/16-12	1.31	33.30						
	20	15/8-12	1.63	41.30						
	24	17/8-12	1.87	47.60						
32	21/2-12	2.50	63.50							

*ØA Thread OD dimension for reference only.

**Removal Torque for Zero Leak Gold® Hollow Hex Plugs is significantly higher than install torque, typically 1.5-3.5X install torque.

Assembly Instructions for Adjustable Port End Metric (MFF) Fittings

1. Inspect components to ensure that male and female threads and surfaces are free of rust, splits, dirt, foreign matter, or burrs.
2. If O-ring is not pre-installed, install proper size, taking care not to damage it. See O-ring Installation (Replacement) for instructions.

⚠ CAUTION

CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. For Non-Adjustable Fittings and Plugs, thread the fitting by hand until contact.
5. For Adjustable fittings, refer to Adjustable Stud End Assembly for proper assembly.

6. Torque the fitting or nut to value listed in Table 5-18, Table 5-19, Table 5-20, Table 5-21, Table 5-22, or Table 5-23 while using the Double Wrench Method.
 - a. The table headings identify the Metric port and the type on the other side of the fitting. The torque will be applied to the Metric port.
 - b. Torque values provided in Table 5-18, Table 5-19, Table 5-20, Table 5-21, Table 5-22, and Table 5-23 are segregated based on the material configuration of the connection. 'ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:
 - STEEL fittings with ALUMINUM or BRASS mating components
 - ALUMINUM or BRASS fittings with STEEL mating components
 - ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.
7. Inspect to ensure the O-ring is not pinched and the washer is seated flat on the counterbore of the port.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-18. Metric Flat Face Port (MFF) - L Series - Table 1 of 3

TYPE/FITTING IDENTIFICATION			FORM A (SEALING WASHER) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end						FORM B (CUTTING FACE) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end					
MATERIAL	Thread M Size	Connecting Tube O.D.	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
	(metric)	(mm)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	7	8	8	9	11	11	13	14	14	18	19	19
	M12x1.5	8	15	16	17	20	22	23	22	23	24	30	31	33
	M14x1.5	10	26	28	29	35	38	39	33	35	36	45	47	49
	M16x1.5	12	33	35	36	45	47	49	48	51	53	65	69	72
	M18x1.5	15	41	43	45	55	58	61	59	62	65	80	84	88
	M22x1.5	18	48	51	53	65	69	72	103	108	113	140	146	153
	M27x2	22	66	70	73	90	95	99	140	147	154	190	199	209
	M33x2	28	111	117	122	150	159	165	251	264	276	340	358	374
	M42x2	35	177	186	195	240	252	264	369	388	406	500	526	550
	M48x2	42	214	225	235	290	305	319	465	489	512	630	663	694
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	4	5	5	5	7	7	8	9	9	11	12	12
	M12x1.5	8	10	11	11	14	15	15	14	15	16	19	20	22
	M14x1.5	10	17	18	19	23	24	26	21	22	23	28	30	31
	M16x1.5	12	21	22	23	28	30	31	31	33	34	42	45	46
	M18x1.5	15	27	28	29	37	38	39	38	40	42	52	54	57
	M22x1.5	18	31	33	34	42	45	46	67	70	73	91	95	99
	M27x2	22	43	45	47	58	61	64	91	96	100	123	130	136
	M33x2	28	72	76	79	98	103	107	163	171	179	221	232	243
	M42x2	35	115	121	127	156	164	172	240	252	264	325	342	358
	M48x2	42	139	146	153	188	198	207	302	318	332	409	431	450




SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-19. Metric Flat Face Port (MFF) - L Series - Table 2 of 3

TYPE/FITTING IDENTIFICATION			FORM A (SEALING WASHER) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end						FORM B (CUTTING FACE) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end					
MATERIAL	Thread M Size (metric)	Connecting Tube O.D. (mm)	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
			Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	13	14	14	18	19	19	13	14	15	18	19	20
	M12x1.5	8	18	19	20	25	26	27	18	19	20	25	26	28
	M14x1.5	10	33	35	36	45	47	49	30	31	32	40	42	44
	M16x1.5	12	41	43	45	55	58	61	41	43	45	55	58	61
	M18x1.5	15	52	55	57	70	75	77	52	54	57	70	74	77
	M22x1.5	18	92	97	101	125	132	137	66	70	73	90	95	99
	M27x2	22	133	140	146	180	190	198	133	139	146	180	189	198
	M33x2	28	229	241	252	310	327	342	229	240	252	310	326	341
	M42x2	35	332	349	365	450	473	495	332	348	365	450	473	495
	M48x2	42	398	418	438	540	567	594	398	418	438	540	567	594
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	8	9	9	11	12	12	8	9	9	11	12	12
	M12x1.5	8	12	13	13	16	18	18	12	13	13	16	18	18
	M14x1.5	10	21	22	23	28	30	31	19	20	21	26	27	29
	M16x1.5	12	27	28	29	37	38	39	26	28	29	36	38	39
	M18x1.5	15	34	36	37	46	49	50	34	35	37	46	48	50
	M22x1.5	18	60	63	66	81	85	89	43	45	47	59	61	64
	M27x2	22	86	91	95	117	123	129	86	91	95	117	123	129
	M33x2	28	149	157	164	202	213	222	149	157	164	202	213	222
	M42x2	35	216	227	237	293	308	321	216	227	237	293	308	321
	M48x2	42	259	272	285	351	369	386	259	272	285	351	369	386

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-20. Metric Flat Face Port (MFF) - L Series - Table 3 of 3

																						
TYPE/FITTING IDENTIFICATION		BANJO FITTINGS with L series DIN (MBTL) opposite end							HIGH PRESSURE BANJO FITTINGS with L series DIN (MBTL) opposite end							FORM E (EOLASTIC SEALING RING) HOLLOW HEX PLUGS						
MATERIAL	Thread M Size (metric)	Connecting Tube O.D. (mm)	Torque						Torque						Torque							
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]				
			Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max		
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	13	14	14	18	19	19	13	14	14	18	19	19	9	10	10	12	14	14		
	M12x1.5	8	26	28	29	35	38	39	33	35	36	45	47	49	18	19	20	25	26	27		
	M14x1.5	10	37	39	41	50	53	56	41	43	45	55	58	61	26	28	29	35	38	39		
	M16x1.5	12	44	46	48	60	62	65	59	62	65	80	84	88	41	43	45	55	58	61		
	M18x1.5	15	59	62	65	80	84	88	74	78	81	100	106	110	48	51	53	65	69	72		
	M22x1.5	18	89	94	98	120	127	133	103	108	113	140	146	153	66	70	73	90	95	99		
	M27x2	22	96	101	106	130	137	144	236	248	260	320	336	353	100	105	110	135	142	149		
	M33x2	28	--	--	--	--	--	--	266	280	293	360	380	397	166	175	183	225	237	248		
	M42x2	35	--	--	--	--	--	--	398	418	438	540	567	594	266	280	293	360	380	397		
	M48x2	42	--	--	--	--	--	--	516	542	568	700	735	770	266	280	293	360	380	397		
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	8	9	9	11	12	12	8	9	9	11	12	12	6	7	7	8	9	9		
	M12x1.5	8	17	18	19	23	24	26	21	22	23	28	30	31	12	13	13	16	18	18		
	M14x1.5	10	24	26	27	33	35	37	27	28	29	37	38	39	17	18	19	23	24	26		
	M16x1.5	12	29	30	31	39	41	42	38	40	42	52	54	57	27	28	29	37	38	39		
	M18x1.5	15	38	40	42	52	54	57	48	51	53	65	69	72	31	33	34	42	45	46		
	M22x1.5	18	58	61	64	79	83	87	67	70	73	91	95	99	43	45	47	58	61	64		
	M27x2	22	62	66	69	84	89	94	153	161	169	207	218	229	65	69	72	88	94	98		
	M33x2	28	--	--	--	--	--	--	173	182	190	235	247	258	108	114	119	146	155	161		
	M42x2	35	--	--	--	--	--	--	259	272	285	351	369	386	173	182	190	235	247	258		
	M48x2	42	--	--	--	--	--	--	335	352	369	454	477	500	173	182	190	235	247	258		

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-21. Metric Flat Face Port (MFF) - S Series - Table 1 of 3

TYPE/FITTING IDENTIFICATION			FORM A (SEALING WASHER) STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end						FORM B (CUTTING FACE) STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	Thread M Size (metric)	Connecting Tube O.D. (mm)	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
			Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	M12x1.5	6	15	16	17	20	22	23	26	28	29	35	38	39
	M14x1.5	8	26	28	29	35	38	39	41	43	45	55	58	61
	M16x1.5	10	33	35	36	45	47	49	52	55	57	70	75	77
	M18x1.5	12	41	43	45	55	58	61	81	85	89	110	115	121
	M20x1.5	14	41	43	45	55	58	61	111	117	122	150	159	165
	M22x1.5	16	48	51	53	65	69	72	125	132	138	170	179	187
	M27x2	20	66	70	73	89	95	99	199	209	219	270	283	297
	M33x2	25	111	117	122	150	159	165	302	317	332	410	430	450
	M42x2	30	177	186	195	240	252	264	398	418	438	540	567	594
	M48x2	38	214	225	235	290	305	319	516	542	568	700	735	770
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	M12x1.5	6	10	11	11	14	15	15	17	18	19	23	24	26
	M14x1.5	8	17	18	19	23	24	26	27	28	29	37	38	39
	M16x1.5	10	21	22	23	28	30	31	34	36	37	46	49	50
	M18x1.5	12	27	28	29	37	38	39	53	56	58	72	76	79
	M20x1.5	14	27	28	29	37	38	39	72	76	79	98	103	107
	M22x1.5	16	31	33	34	42	45	46	81	86	90	110	117	122
	M27x2	20	43	45	47	58	61	64	129	136	142	175	184	193
	M33x2	25	72	76	79	98	103	107	196	206	216	266	279	293
	M42x2	30	115	121	127	156	164	172	259	272	285	351	369	386
	M48x2	38	139	146	153	188	198	207	335	352	369	454	477	500




SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-22. Metric Flat Face Port (MFF) - S Series - Table 2 of 3

TYPE/FITTING IDENTIFICATION			FORM E (EOLASTIC SEALING RING) STUD ENDS AND HEX TYPE PLUGS with (ORFS) or S series DIN (MBTS) opposite end						FORM G/H (O-RING W/ RETAINING RING) STUD ENDS & ADJUSTABLE STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	Thread M Size (metric)	Connecting Tube O.D. (mm)	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
			Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	26	28	29	35	38	39	26	28	29	35	38	39
	M12x1.5	8	33	35	36	45	47	49	41	43	45	55	58	61
	M14x1.5	10	52	55	57	70	75	77	52	55	57	70	75	77
	M16x1.5	12	66	70	73	90	95	99	66	70	73	90	95	99
	M18x1.5	15	92	97	101	125	132	137	92	97	101	125	132	137
	M22x1.5	18	100	105	110	135	142	149	100	105	110	135	142	149
	M27x2	22	133	140	146	180	190	198	133	140	146	180	190	198
	M33x2	28	229	241	252	310	327	342	229	241	252	310	327	342
	M42x2	35	332	349	365	450	473	495	332	349	365	450	473	495
	M48x2	42	398	418	438	540	567	594	398	418	438	540	567	594
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	17	18	19	23	24	26	17	18	19	23	24	26
	M12x1.5	8	21	23	23	29	31	32	27	28	29	37	38	39
	M14x1.5	10	34	36	37	46	49	50	34	36	37	46	49	50
	M16x1.5	12	43	45	47	58	61	64	43	45	47	58	61	64
	M18x1.5	15	60	63	66	81	85	89	60	63	66	81	85	89
	M22x1.5	18	65	69	72	88	94	98	65	69	72	88	94	98
	M27x2	22	86	91	95	117	123	129	86	91	95	117	123	129
	M33x2	28	149	157	164	202	213	222	149	157	164	202	213	222
	M42x2	35	216	227	237	293	308	321	216	227	237	293	308	321
	M48x2	42	259	272	285	351	369	386	259	272	285	351	369	386

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-23. Metric Flat Face Port (MFF) - S Series - Table 3 of 3

																						
TYPE/FITTING IDENTIFICATION		BANJO FITTINGS with S series DIN (MBTS) opposite end									HIGH PRESSURE BANJO FITTINGS with S series DIN (MBTS) opposite end						FORM E (EOLASTIC SEALING RING) HOLLOW HEX PLUGS					
MATERIAL	Thread M Size	Connecting Tube O.D.	Torque						Torque						Torque							
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]				
	(metric)	(mm)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max		
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	26	28	29	35	38	39	33	35	36	45	47	49	--	--	--	--	--	--		
	M12x1.5	8	37	39	41	50	53	56	41	43	45	55	58	61	--	--	--	--	--	--		
	M14x1.5	10	44	46	48	60	62	65	59	62	65	80	84	88	--	--	--	--	--	--		
	M16x1.5	12	59	62	65	80	84	88	74	78	81	100	106	110	--	--	--	--	--	--		
	M18x1.5	15	81	85	89	110	115	121	92	97	101	125	132	137	59	62	65	80	84	88		
	M22x1.5	18	89	94	98	120	127	133	100	105	110	135	142	149	--	--	--	--	--	--		
	M27x2	22	100	105	110	135	142	149	236	248	260	320	336	353	--	--	--	--	--	--		
	M33x2	28	--	--	--	--	--	--	266	280	293	360	380	397	--	--	--	--	--	--		
	M42x2	35	--	--	--	--	--	--	398	418	438	540	567	594	--	--	--	--	--	--		
	M48x2	42	--	--	--	--	--	--	516	542	568	700	735	770	--	--	--	--	--	--		
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	M10x1	6	17	18	19	23	24	26	21	22	23	28	30	31	--	--	--	--	--	--		
	M12x1.5	8	24	26	27	33	35	37	27	28	29	37	38	39	--	--	--	--	--	--		
	M14x1.5	10	29	30	31	39	41	42	38	40	42	52	54	57	--	--	--	--	--	--		
	M16x1.5	12	38	40	42	52	54	57	48	51	53	65	69	72	--	--	--	--	--	--		
	M18x1.5	15	53	56	58	72	76	79	60	63	66	81	85	89	38	40	42	52	54	57		
	M22x1.5	18	58	61	64	79	83	87	65	69	72	88	94	98	--	--	--	--	--	--		
	M27x2	22	65	69	72	88	94	98	153	161	169	207	218	229	--	--	--	--	--	--		
	M33x2	28	--	--	--	--	--	--	173	182	190	235	247	258	--	--	--	--	--	--		
	M42x2	35	--	--	--	--	--	--	259	272	285	351	369	386	--	--	--	--	--	--		
	M48x2	42	--	--	--	--	--	--	335	352	369	454	477	500	--	--	--	--	--	--		

Assembly Instructions for Metric ISO 6149 (MPP) Port Assembly Stud Ends

1. Inspect components to ensure that male and female threads and surfaces are free of rust, splits, dirt, foreign matter, or burrs.
2. If O-ring is not preinstalled, install proper size, taking care not to damage it. See O-ring Installation (Replacement) for instructions.

⚠ CAUTION




CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. For Non-Adjustable Fittings and Plugs, thread the fitting by hand until contact.
5. For Adjustable fittings, refer to Adjustable Stud End Assembly for proper assembly.

6. Torque the fitting or nut to value listed in Table 5-24 while using the Double Wrench Method.
 - a. The table headings identify the Metric port and the type on the other side of the fitting. The torque will be applied to the Metric port.
 - b. Torque values provided in Table 5-24 are segregated based on the material configuration of the connection. 'ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:
 - STEEL fittings with ALUMINUM or BRASS mating components
 - ALUMINUM or BRASS fittings with STEEL mating components
 - ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.
7. Inspect to ensure the O-ring is not pinched and the washer is seated flat on the counterbore of the port.




Go to Discount-Equipment.com to order your parts

Table 5-24. Metric Pipe Parallel O-Ring Boss (MPP)

														
TYPE/FITTING IDENTIFICATION			STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end						STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	Thread M Size	Connecting Tube O.D.	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
	(metric)	(mm)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	M8x1	4	6	7	7	8	9	9	8	9	9	10	12	12
	M10x1	6	11	12	12	15	16	16	15	16	17	20	22	23
	M12x1.5	8	18	19	20	25	26	27	26	28	29	35	38	39
	M14x1.5	10	26	28	29	35	38	39	33	35	36	45	47	49
	M16x1.5	12	30	32	33	40	43	45	41	43	45	55	58	61
	M18x1.5	15	33	35	36	45	47	49	52	55	57	70	75	77
	M20x1.5	--	--	--	--	--	--	--	59	62	65	80	84	88
	M22x1.5	18	44	46	48	60	62	65	74	78	81	100	106	110
	M27x2	22	74	78	81	100	106	110	125	132	138	170	179	187
	M30x2	--	95	100	105	130	136	142	175	184	193	237	249	262
	M33x2	25	120	126	132	160	171	179	230	242	253	310	328	343
	M38x2	--	135	142	149	183	193	202	235	247	259	319	335	351
	M42x2	30	155	163	171	210	221	232	245	258	270	330	350	366
	M48x2	38	190	200	209	260	271	283	310	326	341	420	442	462
M60x2	50	230	242	253	315	328	343	370	389	407	500	527	552	

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-24. Metric Pipe Parallel O-Ring Boss (MPP)

 <p>Note: Metric O-ring only style (ISO 6149) requires o-ring chamfer in the port, similar to ISO 11926 (SAE ORB), but is not interchangeable.</p>														
TYPE/FITTING IDENTIFICATION			STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end						STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	Thread M Size	Connecting Tube O.D.	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
	(metric)	(mm)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	M8x1	4	4	5	5	5	7	7	5	6	6	7	8	8
	M10x1	6	7	8	8	9	11	11	10	11	11	14	15	15
	M12x1.5	8	12	13	13	16	18	18	17	18	19	23	24	26
	M14x1.5	10	17	18	19	23	24	26	21	22	23	28	30	31
	M16x1.5	12	20	21	21	27	28	28	27	28	29	37	38	39
	M18x1.5	15	21	22	23	28	30	31	34	36	37	46	49	50
	M20x1.5	--	--	--	--	--	--	--	30	40	42	41	54	57
	M22x1.5	18	29	30	31	39	41	42	48	51	53	65	69	72
	M27x2	22	48	51	53	65	69	72	81	86	90	110	117	122
	M30x2	--	62	65	68	84	88	92	114	120	125	155	163	169
	M33x2	25	78	82	86	106	111	117	150	157	164	203	213	222
	M38x2	--	88	93	97	119	126	132	153	161	168	207	218	228
	M42x2	30	101	106	111	137	144	150	159	168	176	216	228	239
	M48x2	38	124	130	136	168	176	184	202	212	222	274	287	301
M60x2	50	150	157	164	203	213	222	241	253	265	327	343	359	

Assembly instructions for Adjustable Port End (BSPP) Fittings

1. Inspect components to ensure that male and female threads and surfaces are free of rust, splits, dirt, foreign matter, or burrs.
2. If O-ring is not preinstalled, install proper size, taking care not to damage it. See O-ring Installation (Replacement) for instructions.

⚠ CAUTION

CARE TO BE TAKEN WHEN LUBRICATING O-RING. AVOID ADDING OIL TO THE THREADED CONNECTION OF THE FITTING. THE LUBRICATION WOULD CAUSE INCREASED CLAMPING FORCE AND CAUSE FITTING DAMAGE.

3. Pre-lubricate the O-ring with Hydraulic Oil.
4. For Non-Adjustable Fittings and Plugs, thread the fitting by hand until contact.
5. For Adjustable fittings, refer to Adjustable Stud End Assembly for proper assembly.

6. Torque the fitting or nut to value listed in Table 5-25, Table 5-26, Table 5-27, Table 5-28, Table 5-29, or Table 5-30 while using the Double Wrench Method.
 - a. The table headings identify the BSPP port and the type on the other side of the fitting. The torque will be applied to the BSPP port.
 - b. Torque values provided in Table 5-25, Table 5-26, Table 5-27, Table 5-28, Table 5-29, and Table 5-30 are segregated based on the material configuration of the connection. 'ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS' indicate either the following material configurations:
 - STEEL fittings with ALUMINUM or BRASS mating components
 - ALUMINUM or BRASS fittings with STEEL mating components
 - ALUMINUM or BRASS fittings with ALUMINUM or BRASS mating components.
7. Inspect to ensure the O-ring is not pinched and the washer is seated flat on the counterbore of the port.

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-25. British Standard Parallel Pipe Port (BSPP) - L Series - Table 1 of 3

TYPE/FITTING IDENTIFICATION			FORM A** (SEALING WASHER) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end						FORM B** (CUTTING FACE) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end					
MATERIAL	BSPP Thread G Size	Connecting Tube O.D.	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
	(metric)	(mm)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	G1/8A	6	7	8	8	9	11	11	13	14	14	18	19	19
	G1/4A	8	26	28	29	35	38	39	26	28	29	35	38	39
	G1/4A	10	26	28	29	35	38	39	26	28	29	35	38	39
	G3/8A	12	33	35	36	45	47	49	52	55	57	70	75	77
	G1/2A	15	48	51	53	65	69	72	103	108	113	140	146	153
	G1/2A	18	48	51	53	65	69	72	74	78	81	100	106	110
	G3/4A	22	66	70	73	90	95	99	133	140	146	180	190	198
	G1A	28	111	117	122	150	159	165	243	255	267	330	346	362
	G1-1/4A	35	177	186	195	240	252	264	398	418	438	540	567	594
G1-1/2A	42	214	225	235	290	305	319	465	489	512	630	663	694	
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	G1/8A	6	4	5	5	5	7	7	8	9	9	11	12	12
	G1/4A	8	17	18	19	23	24	26	17	18	19	23	24	26
	G1/4A	10	17	18	19	23	24	26	17	18	19	23	24	26
	G3/8A	12	21	22	23	28	30	31	34	36	37	46	49	50
	G1/2A	15	31	33	34	42	45	46	67	70	73	91	95	99
	G1/2A	18	31	33	34	42	45	46	48	51	53	65	69	72
	G3/4A	22	42	45	47	57	61	64	86	91	95	117	123	129
	G1A	28	72	76	79	98	103	107	158	166	174	214	225	236
	G1-1/4A	35	115	121	127	156	164	172	259	272	285	351	369	386
	G1-1/2A	42	139	146	153	188	198	207	302	318	333	409	431	451

* Typical for JLG Straight Male Stud Fittings

** Non typical for JLG Straight Male Stud Fittings, reference only.

*** Typical for JLG Adjustable Fittings

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-26. British Standard Parallel Pipe Port (BSPP) - L Series - Table 2 of 3

TYPE/FITTING IDENTIFICATION			FORM E* (EOLASTIC SEALING RING) STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end						FORM G/H*** (O-RING W/ RETAINING RING) STUD ENDS & ADJUSTABLE STUD ENDS with 37° (JIC) or L series DIN (MBTL) opposite end					
MATERIAL	BSPP Thread G Size	Connecting Tube O.D.	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
	(metric)	(mm)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	G1/8A	6	13	14	14	18	19	19	13	14	14	18	19	19
	G1/4A	8	26	28	29	35	38	39	26	28	29	35	38	39
	G1/4A	10	26	28	29	35	38	39	26	28	29	35	38	39
	G3/8A	12	52	55	57	70	75	77	52	55	57	70	75	77
	G1/2A	15	66	70	73	90	95	99	66	70	73	90	95	99
	G1/2A	18	66	70	73	90	95	99	66	70	73	90	95	99
	G3/4A	22	133	140	146	180	190	198	133	140	146	180	190	198
	G1A	28	229	241	252	310	327	342	229	241	252	310	327	342
	G1-1/4A	35	332	349	365	450	473	495	332	349	365	450	473	495
G1-1/2A	42	398	418	438	540	567	594	398	418	438	540	567	594	
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	G1/8A	6	8	9	9	11	12	12	8	9	9	11	12	12
	G1/4A	8	17	18	19	23	24	26	17	18	19	23	24	26
	G1/4A	10	17	18	19	23	24	26	17	18	19	23	24	26
	G3/8A	12	34	36	37	46	49	50	34	36	37	46	49	50
	G1/2A	15	43	45	47	58	61	64	43	45	47	58	61	64
	G1/2A	18	43	45	47	58	61	64	43	45	47	58	61	64
	G3/4A	22	86	91	95	117	123	129	86	91	95	117	123	129
	G1A	28	149	157	164	202	213	222	149	157	164	202	213	222
	G1-1/4A	35	216	227	237	293	308	321	216	227	237	293	308	321
G1-1/2A	42	259	272	285	351	369	386	259	272	285	351	369	386	




Elastomeric Seal Ring Seal Type "E"
Special Elastomeric Seal Ring Seal Type "E"

O-Ring with Retaining Ring Types "G" & "H"
O-Ring Rigid Seal Type "G"
O-Ring Adjustable Seal Type "H"

* Typical for JLG Straight Male Stud Fittings
 ** Non typical for JLG Straight Male Stud Fittings, reference only.
 *** Typical for JLG Adjustable Fittings

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-27. British Standard Parallel Pipe Port (BSPP) - L Series - Table 3 of 3

																													
TYPE/FITTING IDENTIFICATION			BANJO FITTINGS with L series DIN (MBTL) opposite end									HIGH PRESSURE BANJO FITTINGS with L series DIN (MBTL) opposite end									FORM E (EOLASTIC SEALING RING) HOLLOW HEX PLUGS								
MATERIAL	BSPP Thread G Size	Connecting Tube O.D.	Torque									Torque									Torque								
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]											
	(metric)	(mm)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max									
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	G1/8A	6	13	14	14	18	19	19	13	14	14	18	19	19	10	11	11	13	15	15									
	G1/4A	8	30	32	33	40	43	45	33	35	36	45	47	49	22	23	24	30	31	33									
	G1/4A	10	30	32	33	40	43	45	33	35	36	45	47	49	22	23	24	30	31	33									
	G3/8A	12	48	51	53	65	69	72	52	55	57	70	75	77	44	46	48	60	62	65									
	G1/2A	15	66	70	73	90	95	99	89	94	98	120	127	133	59	62	65	80	84	88									
	G1/2A	18	66	70	73	90	95	99	89	94	98	120	127	133	59	62	65	80	84	88									
	G3/4A	22	92	97	101	125	132	137	170	179	187	230	243	254	103	108	113	140	146	153									
	G1A	28	--	--	--	--	--	--	236	248	260	320	336	353	148	156	163	200	212	221									
	G1-1/4A	35	--	--	--	--	--	--	398	418	438	540	567	594	295	313.5	332	400	425	450									
	G1-1/2A	42	--	--	--	--	--	--	516	542	568	700	735	770	332	349	365	450	473	495									
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	G1/8A	6	8	9	9	11	12	12	8	9	9	11	12	12	6	7	7	8	9	9									
	G1/4A	8	20	21	21	27	28	28	21	22	23	28	30	31	14	15	16	19	20	22									
	G1/4A	10	20	21	21	27	28	28	21	22	23	28	30	31	14	15	16	19	20	22									
	G3/8A	12	31	33	34	42	45	46	34	36	37	46	49	50	29	30	31	39	41	42									
	G1/2A	15	43	45	47	58	61	64	58	61	64	79	83	87	38	40	42	52	54	57									
	G1/2A	18	43	45	47	58	61	64	58	61	64	79	83	87	38	40	42	52	54	57									
	G3/4A	22	60	63	66	81	85	89	111	117	122	150	159	165	67	70	73	91	95	99									
	G1A	28	--	--	--	--	--	--	153	161	169	207	218	229	96	101	106	130	137	144									
	G1-1/4A	35	--	--	--	--	--	--	259	272	285	351	369	386	216	227	237	293	308	321									
	G1-1/2A	42	--	--	--	--	--	--	335	352	369	454	477	500	216	227	237	293	308	321									

*Typical for JLG Straight Male Stud Fittings

** Non typical for JLG Straight Male Stud Fittings, reference only.

***Typical for JLG Adjustable Fittings

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-28. British Standard Parallel Pipe Port (BSPP) - S Series - Table 1 of 3

TYPE/FITTING IDENTIFICATION			FORM A** (SEALING WASHER) STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end						FORM B** (CUTTING FACE) STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	BSPP Thread G Size (metric)	Connecting Tube O.D. (mm)	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
			Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	G1/4A	6	26	28	29	35	38	39	41	43	45	55	58	61
	G1/4A	8	26	28	29	35	38	39	41	43	45	55	58	61
	G3/8A	10	33	35	36	45	47	49	66	70	73	90	95	99
	G3/8A	12	33	35	36	45	47	49	66	70	73	90	95	99
	G1/2A	14	48	51	53	65	69	72	111	117	122	150	159	165
	G1/2A	16	48	51	53	65	69	72	96	101	106	130	137	144
	G3/4A	20	66	70	73	90	95	99	199	209	219	270	283	297
	G1A	25	111	117	122	150	159	165	251	264	276	340	358	374
	G1-1/4A	30	177	186	195	240	252	264	398	418	438	540	567	594
G1-1/2A	38	214	225	235	290	305	319	516	542	568	700	735	770	
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	G1/4A	6	17	18	19	23	24	26	27	28	29	37	38	39
	G1/4A	8	17	18	19	23	24	26	27	28	29	37	38	39
	G3/8A	10	21	22	23	28	30	31	43	45	47	58	61	64
	G3/8A	12	21	22	23	28	30	31	43	45	47	58	61	64
	G1/2A	14	31	33	34	42	45	46	72	76	79	98	103	107
	G1/2A	16	31	33	34	42	45	46	62	66	69	84	89	94
	G3/4A	20	43	45	47	58	61	64	129	136	142	175	184	193
	G1A	25	72	76	79	98	103	107	163	171	179	221	232	243
	G1-1/4A	30	115	121	127	156	164	172	259	272	285	351	369	386
	G1-1/2A	38	139	146	153	188	198	207	335	352	369	454	477	500

* Typical for JLG Straight Male Stud Fittings

** Non typical for JLG Straight Male Stud Fittings, reference only.

*** Typical for JLG Adjustable Fittings

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-29. British Standard Parallel Pipe Port (BSPP) - S Series - Table 2 of 3

TYPE/FITTING IDENTIFICATION			FORM E* (EOLASTIC SEALING RING) STUD ENDS AND HEX TYPE PLUGS with (ORFS) or S series DIN (MBTS) opposite end						FORM G/H*** (O-RING W/ RETAINING RING) STUD ENDS & ADJUSTABLE STUD ENDS with (ORFS) or S series DIN (MBTS) opposite end					
MATERIAL	BSPP Thread G Size	Connecting Tube O.D.	Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
	(metric)	(mm)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	G1/4A	6	41	43	45	55	58	61	26	28	29	35	38	39
	G1/4A	8	41	43	45	55	58	61	26	28	29	35	38	39
	G3/8A	10	59	62	65	80	84	88	52	55	57	70	75	77
	G3/8A	12	59	62	65	80	84	88	52	55	57	70	75	77
	G1/2A	14	85	90	94	115	122	127	66	70	73	90	95	99
	G1/2A	16	85	90	94	115	122	127	66	70	73	90	95	99
	G3/4A	20	133	140	146	180	190	198	133	140	146	180	190	198
	G1A	25	229	241	252	310	327	342	229	241	252	310	327	342
	G1-1/4A	30	332	349	365	450	473	495	332	349	365	450	473	495
G1-1/2A	38	398	418	438	540	567	594	398	418	438	540	567	594	
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	G1/4A	6	27	28	29	37	38	39	17	18	19	23	24	26
	G1/4A	8	27	28	29	37	38	39	17	18	19	23	24	26
	G3/8A	10	38	40	42	52	54	57	34	36	37	46	49	50
	G3/8A	12	38	40	42	52	54	57	34	36	37	46	49	50
	G1/2A	14	55	58	61	75	79	83	43	45	47	58	61	64
	G1/2A	16	55	58	61	75	79	83	43	45	47	58	61	64
	G3/4A	20	86	91	95	117	123	129	86	91	95	117	123	129
	G1A	25	149	157	164	202	213	222	149	157	164	202	213	222
	G1-1/4A	30	216	227	237	293	308	321	216	227	237	293	308	321
G1-1/2A	38	259	272	285	351	369	386	259	272	285	351	369	386	

Diagram of Form E fitting showing Cutting Face Seal Type 'B' and Metal-to-Metal Seal.

Diagram of Form G/H fitting showing O-Ring with Retaining Ring Types 'G' & 'H', Retaining Ring, Locknut, Back-Up Washer, O-Ring Rigid Seal Type 'G', and O-Ring Adjustable Seal Type 'H'.

* Typical for JLG Straight Male Stud Fittings
 ** Non typical for JLG Straight Male Stud Fittings, reference only.
 *** Typical for JLG Adjustable Fittings

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-30. British Standard Parallel Pipe Port (BSPP) - S Series - Table 3 of 3

TYPE/FITTING IDENTIFICATION			BANJO FITTINGS with S series DIN (MBTS) opposite end						HIGH PRESSURE BANJO FITTINGS with S series DIN (MBTS) opposite end						JIS/BSPP O-RING ONLY					
MATERIAL	BSPP Thread G Size	Connecting Tube O.D.	Torque						Torque						Torque					
			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
	(metric)	(mm)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS WITH STEEL MATING COMPONENTS; UN-LUBRICATED THREADS	G1/4A	6	30	32	33	40	43	45	33	35	36	45	47	49	Fitting type not typically specified on JLG applications. Refer to the specific procedure in this Service Manual.					
	G1/4A	8	30	32	33	40	43	45	33	35	36	45	47	49						
	G3/8A	10	48	51	53	65	69	72	52	55	57	70	75	77						
	G3/8A	12	48	51	53	65	69	72	52	55	57	70	75	77						
	G1/2A	14	66	70	73	90	95	99	89	94	98	120	127	133						
	G1/2A	16	66	70	73	90	95	99	89	94	98	120	127	133						
	G3/4A	20	92	97	101	125	132	137	170	179	187	230	243	254						
	G1A	25	--	--	--	--	--	--	236	248	260	320	336	353						
	G1-1/4A	30	--	--	--	--	--	--	398	418	438	540	567	594						
G1-1/2A	38	--	--	--	--	--	--	516	542	568	700	735	770							
ALUMINUM/BRASS FITTINGS OR ALUMINUM/BRASS MATING COMPONENTS; UN-LUBRICATED THREADS	G1/4A	6	20	21	21	27	28	28	22	22	23	30	30	31	Fitting type not typically specified on JLG applications. Refer to the specific procedure in this Service Manual.					
	G1/4A	8	20	21	21	27	28	28	22	22	23	30	30	31						
	G3/8A	10	31	33	34	42	45	46	34	36	37	46	49	50						
	G3/8A	12	31	33	34	42	45	46	34	36	37	46	49	50						
	G1/2A	14	43	45	47	58	61	64	58	61	64	79	83	87						
	G1/2A	16	43	45	47	58	61	64	58	61	64	79	83	87						
	G3/4A	20	60	63	66	81	85	89	111	117	122	150	159	165						
	G1A	25	--	--	--	--	--	--	153	161	169	207	218	229						
	G1-1/4A	30	--	--	--	--	--	--	259	272	285	351	369	386						
	G1-1/2A	38	--	--	--	--	--	--	335	352	368	454	477	499						

O-Ring
Metal Seal Ring

O-Ring
Metal Seal Ring

Note: BSPP O-ring only style (ISO 228-1) requires o-ring chamfer in the port, similar to ISO 11926 (SAE ORB), but is not interchangeable. Not typically used on JLG machines.

*Typical for JLG Straight Male Stud Fittings

** Non typical for JLG Straight Male Stud Fittings, reference only.

***Typical for JLG Adjustable Fittings

**Assembly Instructions for Flange Connections:
(FL61 and FL62)**

1. Make sure sealing surfaces are free of rust, splits, scratches, dirt, foreign matter, or burrs.
2. See Figure for O-ring installation instructions.
3. Pre-lubricate the O-ring with Hydraulic Oil.
4. Position flange and clamp halves.
5. Place lock washers on bolt and bolt through clamp halves.
6. Tighten all bolts by hand.
7. Torque bolts in diagonal sequence in two or more increments to the torque listed on Table Table 5-31 and Table 5-32.



Go to Discount-Equipment.com to order your parts

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-31. Flange Code (FL61 & FL62) -Inch Fasteners

TYPE/FITTING IDENTIFICATION		STEEL 4-BOLT FLANGE SAE J518 (INCH FASTENERS)																
TYPE	Inch Flange SAE Dash Size	Flange Size		A*		Bolt Thread Size	Fastener Torque for Flanges Equipped with GRADE 5 Screws						Fastener Torque for Flanges Equipped with GRADE 8 Screws					
		(in)	(mm)	(in)	(mm)		[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
							Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
CODE 61 SPLIT FLANGE (FL61)	8	0.50	13	1.50	38.10	5/16-18	18	19	19	24	25	26	24	25	26	32	34	35
	12	0.75	19	1.88	47.75	3/8-16	32	33	35	43	45	47	44	46	49	60	63	66
	16	1.00	25	2.06	52.32	3/8-16	32	33	35	43	45	47	44	46	49	60	63	66
	20	1.25	32	2.31	58.67	7/16-14	52	54	57	70	74	77	68	71	75	92	97	101
	24	1.50	38	2.75	69.85	1/2-13	77	81	85	105	110	116	111	116	122	150	158	165
	32	2.00	51	3.06	77.72	1/2-13	77	81	85	105	110	116	111	116	122	150	158	165
	40	2.50	64	3.50	88.90	1/2-13	77	81	85	105	110	116	111	116	122	150	158	165
	48	3.00	76	4.19	106.43	5/8-11	155	163	170	210	221	231	218	228	239	295	310	325
	56	3.50	89	4.75	120.65	5/8-11	155	163	170	210	221	231	218	228	239	295	310	325
	64	4.00	102	5.13	130.30	5/8-11	155	163	170	210	221	231	218	228	239	295	310	325
	80	5.00	127	6.00	152.40	5/8-11	155	163	170	210	221	231	218	228	239	295	310	325
CODE 62 SPLIT FLANGE (FL62)	8	0.50	13	1.59	40.39	5/16-18	--	--	--	--	--	--	24	25	26	32	34	35
	12	0.75	19	2.00	50.80	3/8-16	--	--	--	--	--	--	44	46	49	60	63	66
	16	1.00	25	2.25	57.15	7/16-14	--	--	--	--	--	--	68	71	75	92	97	101
	20	1.25	32	2.62	66.55	1/2-13	--	--	--	--	--	--	111	116	122	150	158	165
	20	1.25	32	2.62	66.55	--	--	--	--	--	--	--	--	--	--	--	--	--
	24	1.50	38	3.12	79.25	5/8-11	--	--	--	--	--	--	218	228	239	295	310	325
	32	2.00	51	3.81	96.77	3/4-10	--	--	--	--	--	--	332	348	365	450	473	495

* A dimension for reference only.



M19300

SECTION 5 - BASIC HYDRAULIC INFORMATION & HYDRAULIC SCHEMATICS

Table 5-32. Flange Code (FL61 & FL62) - Metric Fasteners

TYPE/FITTING IDENTIFICATION						STEEL 4-BOLT FLANGE SAE J518 (INCH FASTENERS)												
TYPE	Inch Flange SAE Dash Size	Flange Size		A*		Bolt Thread Size (Metric)	Fastener Torque for Flanges Equipped with CLASS 8.8 Screws						Fastener Torque for Flanges Equipped with CLASS 10.9 Screws					
		(in)	(mm)	(in)	(mm)		[Ft-Lb]			[N-m]			[Ft-Lb]			[N-m]		
							Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
CODE 61 SPLIT FLANGE (FL61)	8	0.50	13	1.50	38.10	(Metric)	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max	Min	Nom	Max
	12	0.75	19	1.88	47.75	M8x1.25	18	19	19	24	25	26	18	19	19	24	25	26
	16	1.00	25	2.06	52.32	M10x1.5	37	39	41	50	53	55	37	39	41	50	53	55
	20	1.25	32	2.31	58.67	M10x1.5	37	39	41	50	53	55	37	39	41	50	53	55
	24	1.50	38	2.75	69.85	M10x1.5	37	39	41	50	53	55	37	39	41	50	53	55
	32	2.00	51	3.06	77.72	M12x1.75	68	71	75	92	97	101	68	71	75	92	97	101
	40	2.50	64	3.50	88.90	M12x1.75	68	71	75	92	97	101	68	71	75	92	97	101
	48	3.00	76	4.19	106.43	M12x1.75	68	71	75	92	97	101	68	71	75	92	97	101
	56	3.50	89	4.75	120.65	M16x2	155	163	170	210	221	231	155	163	170	210	221	231
	64	4.00	102	5.13	130.30	M16x2	155	163	170	210	221	231	155	163	170	210	221	231
80	5.00	127	6.00	152.40	M16x2	155	163	170	210	221	231	155	163	170	210	221	231	
CODE 62 SPLIT FLANGE (FL62)	8	0.50	13	1.59	40.39	M8x1.25	--	--	--	--	--	--	24	25	26	32	34	35
	12	0.75	19	2.00	50.80	M10x1.5	--	--	--	--	--	--	52	54	57	70	74	77
	16	1.00	25	2.25	57.15	M12x1.75	--	--	--	--	--	--	96	101	105	130	137	143
	20	1.25	32	2.62	66.55	M12x1.75	--	--	--	--	--	--	96	101	105	130	137	143
	20	1.25	32	2.62	66.55	M14x2	--	--	--	--	--	--	133	139	146	180	189	198
	24	1.50	38	3.12	79.25	M16x2	--	--	--	--	--	--	218	228	239	295	310	325
	32	2.00	51	3.81	96.77	M20x2.5	--	--	--	--	--	--	406	426	446	550	578	605

* A dimension for reference only.

Double Wrench Method

To prevent undesired hose or connector rotation, two wrenches must be used; one torque wrench and one backup wrench. If two wrenches are not used, inadvertent component rotation may occur which absorbs torque and causes improper joint load and leads to leaks. For hose connections,

the 'layline' printed on the hose is a good indicator of proper hose installation. A twisted lay-line usually indicates the hose is twisted. See Figure 5-12. for double wrench method requirements.




Figure 5-12. Double Wrench Method

FFWR and TFFT Methods

FFWR (FLATS FROM WRENCH RESISTANCE METHOD)

1. Tighten the swivel nut to the mating fitting until no lateral movement of the swivel nut can be detected; finger tight condition.
2. Mark a dot on one of the swivel hex nut flats and another dot in line on the connecting tube adapter. See Figure B.1.
3. Use the double wrench method per Appendix A, turn the swivel nut to tighten as shown in Figure B.1. The nut is to be rotated clockwise the number of hex flats as defined by the applicable Table in Section 5.0.
4. After the connection has been properly tightened, mark a straight line across the connecting parts, not covering the dots, to indicate the connection has been properly tightened. See Figure 5-13.




Figure 5-13. FFWR Method

TFFT (TURNS FROM FINGER TIGHT METHOD)

1. Tighten the swivel nut to the mating fitting until no lateral movement of the swivel nut can be detected; finger tight condition.
2. Mark a dot on one of the swivel hex nut flats and another dot in line on the connecting tube adapter.
3. Use the double wrench method per Appendix A, turn the swivel nut to tighten. The nut is to be rotated clockwise the number of turns as defined by the applicable Table in Section 5.0.
4. After the connection has been properly tightened, mark a straight line across the connecting parts, not covering the dots, to indicate the connection has been properly tightened.

Adjustable Stud End Assembly

For Adjustable Stud End Connections; the following assembly steps are to be performed:

1. Lubricate the o-ring with a light coat of hydraulic oil.
2. Position #1 – The o-ring should be located in the groove adjacent to the face of the backup washer. The washer and o-ring should be positioned at the extreme top end of the groove as shown.
3. Position #2 – Position the locknut to just touch the backup washer as shown. The locknut in this position will eliminate potential backup washer damage during the next step.
4. Position #3 – Install the connector into the straight thread box port until the metal backup washer contacts the face of the port as shown.
5. Position #4 – Adjust the connector to the proper position by turning out (counterclockwise) up to a maximum of one turn as shown to provide proper alignment with the mating connector, tube assembly, or hose assembly.
6. Position #5 – Using two wrenches, use the backup wrench to hold the connector in the desired position and then use the torque wrench to tighten the locknut to the appropriate torque.
7. Visually inspect, where possible, the joint to ensure the o-ring is not pinched or bulging out from under the washer and that the backup washer is properly seated flat against the face of the port.




Figure 5-14. Adjustable Stud End Assembly

O-ring Installation (Replacement)

Care must be taken when installing O-rings over threads during replacement or installation. O-rings could become nicked or torn. A damaged O-ring could lead to leakage problems.

1. Inspect O-ring for tears or nicks. If any are found replace O-ring.
2. Ensure proper O-ring to be installed. Many O-rings look the same but are of different material, different hardness, or are slightly different diameters or widths.
3. Use a thread protector when replacing O-rings on fittings.
4. In ORB; ensure O-ring is properly seated in groove. On straight threads, ensure O-ring is seated all the way past the threads prior to installation.
5. Inspect O-ring for any visible nicks or tears. Replace if found.

5.3 HYDRAULIC CYLINDERS

Axle Extend Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

NOTICE

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Remove the counterbalance valves and plugs from the cylinder port block. Discard o-rings.
4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-15. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-16. Capscrews Removal

6. Attach a suitable pulling device to the cylinder rod end.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully remove the complete rod assembly from the cylinder barrel.





Figure 5-17. Cylinder Rod Support



- | | | | |
|---------------|--------------------|---------------------|--------------------------|
| 1. Barrel | 7. O-ring | 13. Backup Ring | 19. Bushing |
| 2. Rod | 8. Backup Ring | 14. Tapered Bushing | 20. Counterbalance Valve |
| 3. Head | 9. Piston | 15. Capscrew | 21. Plug |
| 4. Wiper Seal | 10. Hydrolock Seal | 16. Capscrew | 22. Plug |
| 5. Rod Seal | 11. Guidelock Seal | 17. Spacer | 23. Plug |
| 6. Wear Ring | 12. O-ring | 18. Bushing | 24. Plug |

Figure 5-18. Axle Extend Cylinder

8. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
9. Loosen and remove the capscrews from drilled holes.




Figure 5-19. Tapered Bushing Removal

10. Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen from the piston.
11. Remove the tapered bushing from the piston.
12. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
13. Remove and discard the piston o-ring, backup ring, hydrolock seals, and guidelock rings.
14. Remove piston spacer from the rod.
15. Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup rings, rod seals, wear rings, and wiper seals.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect threaded portion of barrel for damage. Dress threads as necessary.
6. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
7. Inspect threaded portion of piston for damage. Dress threads as necessary.
8. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
9. Inspect cylinder head inside diameter for scoring, tapering, ovality or other damage. Replace as necessary.
10. Inspect threaded portion of head for damage. Dress threads as necessary.
11. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
12. Inspect cylinder head outside diameter for scoring, tapering, ovality or other damage. Replace as necessary.
13. Inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt, etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inner side of the steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-20. Composite Bearing Installation

14. Inspect travel limiting collar or spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
15. If applicable, inspect port block fittings and holding valve. Replace as necessary.
16. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
17. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-21. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-22. Cylinder Head Seal Installation

2. Use a soft mallet to tap a new wiper seal into the cylinder head gland groove. Install a new wear rings into the cylinder head gland groove.




Figure 5-23. Wiper Seal Installation

3. Place a new o-ring and backup ring in the outside diameter groove of the cylinder head.




Figure 5-24. Installation of Head Seal Kit

4. Install washer ring onto rod if applicable, carefully install the head gland on the rod, ensuring the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end.
5. Carefully slide the piston spacer on the rod.
6. Place a new o-rings and backup rings in the inner piston diameter groove.
7. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
8. Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-rings and backup rings are not damaged or dislodged.

9. Thread piston onto rod end and install the tapered bushing.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

10. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-25. Tapered Bushing Installation

11. Tighten the capscrews evenly and progressively in rotation refer Figure 5-18.
12. After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows;
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - b. Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-26. Seating the Tapered Bearing

13. Re-torque the capscrews evenly and progressively in rotation Figure 5-18.
14. Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-27. Hydrolock Piston Seal Installation

15. Place a new hydrolock seals and guidelock rings in the outer piston diameter grooves. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the seal).




Figure 5-28. Piston Seal Kit Installation

16. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

17. With barrel clamped securely, and adequately supporting the rod, insert the piston end into the barrel cylinder. ensuring that the piston loading hydrolock seals and guidelock rings are not damaged or dislodged.
18. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.
19. Apply JLG Threadlocker PN 0100011 to the socket head capscrews. Secure the cylinder head gland using the washer ring and capscrews. Torque capscrews to 85 ft. lbs. (115.3 Nm).




Figure 5-29. Rod Assembly Installation

20. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any valves.
21. Install the counterbalance valves and fittings in the rod port block, using new o-rings as applicable. Torque valves to 30-35 ft. lbs. (41-47 Nm).

Platform Level Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

NOTICE

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Remove the counterbalance valves, orifice valve and fittings from the cylinder port block. Discard o-rings.
4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-30. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-31. Capscrews Removal

6. Attach a suitable pulling device to the cylinder rod end.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully remove the complete rod assembly from the cylinder barrel.





Figure 5-32. Cylinder Rod Support



- | | | | |
|---------------|--------------------|--------------------------|--------------|
| 1. Barrel | 8. Backup Ring | 15. Capscrew | 22. Bushing |
| 2. Rod | 9. Piston | 16. Capscrew | 23. Plug |
| 3. Head | 10. Hydrolock Seal | 17. Washer Ring | 24. Plug |
| 4. Wiper Seal | 11. Guidelock Ring | 18. Counterbalance Valve | 25. Link Rod |
| 5. Rod Seal | 12. O-ring | 19. Counterbalance Valve | 26. Rollpin |
| 6. Wear Ring | 13. Backup Ring | 20. Orifice Valve | |
| 7. O-ring | 14. Tapered Ring | 21. Bushing | |

Figure 5-33. Platform Level Cylinder

8. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
9. Loosen and remove the capscrews from drilled holes.




Figure 5-34. Tapered Bushing Removal

10. Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen from the piston.
11. Remove the tapered bushing from the piston.
12. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
13. Remove and discard the piston o-rings, backup rings, hydrolock seals and guidelock rings.
14. Remove rollpin from cylinder rod.
15. Screw the link rod counterclockwise and remove from cylinder rod.
16. Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-ring, backup ring, rod seal, wear rings and wiper seal.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect threaded portion of barrel for damage. Dress threads as necessary.
6. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
7. Inspect threaded portion of piston for damage. Dress threads as necessary.
8. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
9. Inspect cylinder head inside diameter for scoring, tapering, ovality or other damage. Replace as necessary.
10. Inspect threaded portion of head for damage. Dress threads as necessary.
11. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
12. Inspect cylinder head outside diameter for scoring, tapering, ovality or other damage. Replace as necessary.
13. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inner side of the steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-35. Composite Bearing Installation

14. Inspect link rod outside diameter for scoring, tapering, ovality or other damage. Replace as necessary.
15. If applicable, inspect port block fittings and holding valve. Replace as necessary.
16. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
17. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-36. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-37. Cylinder Head Seal Installation

- Use a soft mallet to tap a new wiper seal into the cylinder head gland groove. Install a new wear rings into the cylinder head gland groove.




Figure 5-38. Wiper Seal Installation

- Place a new o-ring and backup ring in the outside diameter groove of the cylinder head.




Figure 5-39. Installation of Head Seal Kit

- Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end.
- Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston threads as possible.

NOTE: Apply High strength Threadlocking Compound and primer to internal thread for rod and external thread of link rod prior to installation.

- Carefully thread the link rod into cylinder rod and hand tight, ensuring that the holes of link rod and cylinder rod are aligned properly.
- Using suitable tool and support, insert rollpin into the hole to lock link rod with cylinder rod.
- Place a new o-ring and backup rings in the inner piston diameter groove.

- Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

- Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-40. Tapered Bushing Installation

- Tighten the capscrews evenly and progressively in rotation refer Figure 5-34. and Figure 5-33.
- After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows;
 - Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-41. Seating the Tapered Bearing

13. Re-torque the capscrews evenly and progressively in rotation refer Figure 5-33.
14. Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-42. Hydrolock Piston Seal Installation

15. Place new hydrolock seals and guidelock rings in the outer piston diameter grooves. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the seal).




Figure 5-43. Piston Seal Installation

16. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

17. With barrel clamped secured and adequately support to the cylinder rod, insert the piston end into the barrel cylinder. ensuring that the piston loading guidelock rings and hydrolock seals are not damaged or dislodged.
18. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.
19. Apply Medium strength Threadlocking Compound to the socket head capscrew and secure the cylinder head gland using the washer ring and capscrews. Torque cap-screws to 85 ft. lbs. (115.3 Nm).




Figure 5-44. Rod Assembly Installation

20. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any valves.
21. Install the counterbalance valves in the rod port block. Torque 30-35 ft. lbs. (41-47 Nm).
22. Install the counterbalance valves and orifice valve in the rod port block. Torque 20-25 ft. lbs. (27-34 Nm).

Jib Lift Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

NOTICE

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Remove the counterbalance valves and plug fittings from the cylinder port block or cylinder barrel end, as applicable. Discard o-rings.
4. Place the cylinder barrel into a suitable holding fixture.




Figure 5-45. Cylinder Barrel Support

5. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-46. Capscrews Removal

6. Attach a suitable pulling device to the cylinder rod end.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

7. With the barrel clamped securely, apply pressure to the rod pulling device and carefully remove the complete rod assembly from the cylinder barrel.





Figure 5-47. Cylinder Rod Support



- | | | | |
|---------------|-------------------|--------------------------|-----------------|
| 1. Barrel | 8. Backup Ring | 15. Spacer | 22. Check Valve |
| 2. Rod | 9. Piston | 16. Tapered Bushing | 23. Bushing |
| 3. Head | 10. Seal | 17. Capscrew | 24. Plug |
| 4. Wiper Seal | 11. Wear Ring | 18. Capscrew | 25. Plug |
| 5. Rod Seal | 12. O-ring | 19. Washer Ring | |
| 6. Wear Ring | 13. Backup Ring | 20. Counterbalance Valve | |
| 7. O-ring | 14. Metallic Seal | 21. Counterbalance Valve | |

Figure 5-48. Jib Lift Cylinder

8. Using suitable protection, clamp the cylinder rod in a vise or holding fixture as close to the piston as possible.
9. Loosen and remove the capscrews from drilled holes.




Figure 5-49. Tapered Bushing Removal

10. Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen from the piston.
11. Remove the tapered bushing from the piston.
12. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
13. Remove and discard the piston o-rings, seal, wear rings and backup rings.
14. Remove the piston spacer from the rod. Discard the o-ring.
15. Remove the rod from the holding fixture. Remove the cylinder head gland. Discard the o-rings, backup rings, rod seal, wear ring and wiper seal.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect threaded portion of barrel for damage. Dress threads as necessary.
6. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
7. Inspect threaded portion of piston for damage. Dress threads as necessary.
8. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
9. Inspect cylinder head inside diameter for scoring, tapering, ovality or other damage. Replace as necessary.
10. Inspect threaded portion of head for damage. Dress threads as necessary.
11. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
12. Inspect cylinder head outside diameter for scoring, tapering, ovality or other damage. Replace as necessary.
13. If applicable, inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inner side of the steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-50. Composite Bearing Installation

14. Inspect travel limiting collar or spacer for burrs and sharp edges. If necessary, dress inside diameter surface with Scotch Brite or equivalent.
15. If applicable, inspect port block fittings and holding valve. Replace as necessary.
16. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
17. If applicable, inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-51. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-52. Cylinder Head Seal Installation

2. Use a soft mallet to tap a new wiper seal into the cylinder head gland groove. Install a new wear ring into the cylinder head gland groove.




Figure 5-53. Wiper Seal Installation

3. Place a new o-ring and backup ring in the outside diameter groove of the cylinder head.




Figure 5-54. Installation of Head Seal Kit

4. Install washer ring onto rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end.
5. Place the new o-ring in the inner diameter groove of spacer.
6. Carefully slide the spacer onto the rod, ensuring that the o-ring are not damage or dislodged.
7. Place a new o-ring and backup rings in the inner piston diameter groove.
8. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston threads as possible.
9. Carefully thread the piston on the cylinder rod and hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

10. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-55. Tapered Bushing Installation

11. Tighten the capscrews evenly and progressively in rotation to 5 ft. lbs. (7 Nm).
12. After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz) and brass shaft (approximately 3/4" in diameter) as follows;
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - b. Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-56. Seating the Tapered Bearing

13. Re-torque the capscrews evenly and progressively in rotation to 5 ft. lbs. (7 Nm).

14. Remove the cylinder rod from the holding fixture.
15. Place new seal, wear rings, and metallic seal in the outer piston diameter grooves. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the seal).




Figure 5-57. Piston Seal Installation

16. Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

17. With barrel clamped securely, and adequately supporting the rod, insert the piston end into the barrel cylinder, ensuring that piston loading seal, wear rings and metallic seal ring are not damage or dislodged.
18. Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.

19. Apply Medium Strength Threadlocking Compound to the socket head capscrews and secure the cylinder head gland using the capscrews. Torque capscrews to 20 ft. lbs. (27 Nm).




Figure 5-58. Rod Assembly Installation

20. After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any valves.
21. Install the counterbalance valves and fittings in the rod port block or barrel end, using new o-rings as applicable. Torque valves to 30-35 ft. lbs. (41-47.5 Nm).
22. Install the check valve in the barrel end, using new o-rings as applicable. Torque valves to 18-20 ft. lbs. (24-27 Nm).

Main Boom Lift Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

NOTICE

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Remove the check valve, counterbalance valve, shuttle valve, custom cartridge valve from and fittings from valve assembly. Discard o-rings.
4. Remove capscrews and remove the valve assembly from barrel.
5. Place the cylinder barrel into a suitable holding fixture.




Figure 5-59. Cylinder Barrel Support

6. Loosen and remove the plug from cylinder barrel end.

7. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-60. Capscrews Removal

8. Attach a suitable pulling device to the cylinder rod end.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

9. With the barrel clamped securely, apply pressure to the rod pulling device and carefully remove the complete one rod assembly from the cylinder barrel.





Figure 5-61. Cylinder Rod Support



- | | | | |
|----------------|---------------------|--------------------|--------------------------|
| 1. Barrel | 9. Piston | 17. Plug | 25. Counterbalance Valve |
| 2. Rod | 10. Hydrolock Seal | 18. Valve Assembly | 26. Shuttle Valve |
| 3. Head | 11. Guidelock Ring | 19. Capscrew | 27. Check Valve |
| 4. Wiper Seal | 12. Wear Ring | 20. Plug | 28. O-ring |
| 5. Rod Seal | 13. O-ring | 21. Plug | 29. Counterbalance Valve |
| 6. Wear Ring | 14. Backup Ring | 22. Capscrew | 30. Plug |
| 7. O-ring | 15. Tapered Bushing | 23. Washer Ring | |
| 8. Backup Ring | 16. Capscrew | 24. Bushing | |

Figure 5-62. Main Boom Lift Cylinder

10. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston as possible.
11. Screw the plug counterclockwise and remove cap end from cylinder rod.
12. Loosen and remove the capscrews from drilled holes.




Figure 5-63. Tapered Bushing Removal

13. Insert the capscrews in the threaded holes in the outer piece of the tapered bushing. Progressively tighten the capscrews until the bushing is loosen from the piston.
14. Remove the tapered bushing from the piston.
15. Screw the piston counterclockwise by hand and remove the piston from cylinder rod.
16. Remove and discard the piston o-rings, backup rings, wear ring, hydrolock seals, and guidelock rings.
17. Remove the rod from the holding fixture. Remove the cylinder head gland and washer ring. Discard the o-rings, backup rings, rod seal, wear rings and wiper seal.
18. Similarly, do the disassembly for another cylinder rod.

CLEANING AND INSPECTION

1. Clean all parts thoroughly in an approved cleaning solvent.
2. Inspect the cylinder rod for scoring, tapering, ovality, or other damage. If necessary, dress rod with Scotch Brite or equivalent. Replace rod if necessary.
3. Inspect threaded portion of rod for excessive damage. Dress threads as necessary.
4. Inspect inner surface of cylinder barrel tube for scoring or other damage. Check inside diameter for tapering or ovality. Replace if necessary.
5. Inspect threaded portion of barrel for damage. Dress threads as necessary.
6. Inspect piston surface for damage and scoring and for distortion. Dress piston surface or replace piston as necessary.
7. Inspect threaded portion of piston for damage. Dress threads as necessary.
8. Inspect seal and o-ring grooves in piston for burrs and sharp edges. Dress applicable surfaces as necessary.
9. Inspect cylinder head inside diameter for scoring, tapering, ovality or other damage. Replace as necessary.
10. Inspect threaded portion of head for damage. Dress threads as necessary.
11. Inspect seal and o-ring grooves in head for burrs and sharp edges. Dress applicable surfaces as necessary.
12. Inspect cylinder head outside diameter for scoring, tapering, ovality or other damage. Replace as necessary.
13. Inspect rod and barrel bearings for signs of correct excessive wear or damage. Replace as necessary.
 - a. Thoroughly clean hole, (steel bushing) of burrs, dirt etc. to facilitate bearing installation.
 - b. Inspect steel bushing for wear or other damage. If steel bushing is worn or damaged, rod/barrel must be replaced.
 - c. Lubricate inner side of the steel bushing prior to bearing installation.
 - d. Using an arbor of the correct size, carefully press the bearing into steel bushing.

NOTE: Install pin into the composite bearing dry. Lubrication is not required with nickel plated pins and bearings.




Figure 5-64. Composite Bearing Installation

14. Inspect port block fittings and holding valve. Replace as necessary.
15. Inspect the oil ports for blockage or the presence of dirt or other foreign material. Repair as necessary.
16. Inspect piston rings for cracks or other damage. Replace as necessary.

ASSEMBLY

NOTE: Prior to cylinder assembly, ensure that the proper cylinder seal kit is used. See your JLG Parts Manual.

NOTE: Apply a light film of hydraulic oil to all components prior to assembly.

1. A special tool is used to install a new rod seal into the applicable cylinder head gland groove.




Figure 5-65. Rod Seal Installation

NOTICE

WHEN INSTALLING NEW SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-66. Cylinder Head Seal Installation

2. Use a soft mallet to tap a new wiper seal into the cylinder head gland groove. Install a new wear rings into the cylinder head gland groove.




Figure 5-67. Wiper Seal Installation

3. Place a new o-ring and backup ring in the outside diameter groove of the cylinder head.




Figure 5-68. Installation of Head Seal Kit

4. Install washer ring onto cylinder rod, carefully install the head gland on the rod, ensuring that the wiper and rod seals are not damaged or dislodged. Push the head along the rod to the rod end.
5. Place a new o-ring and backup rings in the inner piston diameter groove.
6. Using suitable protection, clamp the cylinder rod in a vise or similar holding fixture as close to the piston threads as possible.
7. Carefully thread the piston on the cylinder rod hand tight, ensuring that the o-ring and backup rings are not damaged or dislodged.

NOTE: When installing the tapered bushing, piston and mating end of rod must be free of oil.

8. Assemble the tapered bushing loosely into the piston and insert capscrews through the drilled holes in the bushing and into the tapped holes in the piston.




Figure 5-69. Tapered Bushing Installation

9. Tighten the capscrews evenly and progressively in rotation refer Figure 5-66. and Figure 5-62. for torque values.
10. After the screws have been torqued, tap the tapered bushing with a hammer (16 to 24 oz.) and brass shaft (approximately 3/4" in diameter) as follows;
 - a. Place the shaft against the cylinder rod and in contact with the bushing in the spaces between the capscrews.
 - b. Tap each space once; this means the tapered bushing is tapped 3 times as there are 3 spaces between the capscrews.




Figure 5-70. Seating the Tapered Bearing

11. Re-torque the capscrews evenly and progressively in rotation refer Figure 5-66. and Figure 5-62. for torque values.

- Remove the cylinder rod from the holding fixture.

NOTICE

WHEN INSTALLING HYDROLOCK PISTON SEALS, ENSURE SEALS ARE INSTALLED PROPERLY. REFER TO HYDROLOCK PISTON SEAL INSTALLATION FOR CORRECT SEAL ORIENTATION. IMPROPER SEAL INSTALLATION COULD RESULT IN CYLINDER LEAKAGE AND IMPROPER CYLINDER OPERATION.




Figure 5-71. Hydrolock Piston Seal Installation

- Place new hydrolock seals, guidelock rings and wear ring in the outer piston diameter grooves. (A tube, with I.D. slightly larger than the O.D. of the piston is recommended to install the seal).




Figure 5-72. Piston Seal Installation

- Place end cap onto cylinder rod and tighten with plug. refer Figure 5-66. and Figure 5-62. for torque values.
- Similarly, do the assembly for another cylinder rod.
- Position the cylinder barrel in a suitable holding fixture.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN INSTALLING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

- With barrel clamped securely, and adequately supporting the rod, insert the piston end into the barrel cylinder. ensuring that the piston loading hydrolock seals, guidelock rings and wear ring are not damaged or dislodged.
- Continue pushing the rod into the barrel until the cylinder head gland can be inserted into the barrel cylinder.

- Apply Medium strength Threadlocking Compound to the socket head bolts and secure the cylinder head gland using the washer ring and capscrews. Torque cap-screws refer Figure 5-66. and Figure 5-62. as per the torque sequence shown in Figure 5-73..




Figure 5-73. Capscrews Torque Sequence




Figure 5-74. Rod Assembly Installation

- After the cylinder has been reassembled, the rod should be pushed all the way in (fully retracted) prior to the reinstallation of any valves.
- Insert and tighten the plug to cylinder barrel end. Torque refer Figure 5-66. and Figure 5-62. for torque values.
- Tighten the capscrews and install valve assembly to barrel. Refer Figure 5-66. and Figure 5-62. for torque values.
- Install the check valve in the valve assembly. Refer Figure 5-62. for torque values.
- Install the counterbalance valve and custom cartridge valve in the valve assembly. Refer Figure 5-66. and Figure 5-62. for torque values.
- Install the shuttle valve in the valve assembly. Refer Figure 5-62. and Figure 5-62. for torque values.
- Install plug fitting to barrel. Torque to fitting as shown in Figure 5-62., Main Boom Lift Cylinder.

Tower Boom Lift Cylinder

DISASSEMBLY

NOTICE

DISASSEMBLY OF THE CYLINDER SHOULD BE PERFORMED ON A CLEAN WORK SURFACE IN A DIRT FREE WORK AREA.

1. Connect a suitable auxiliary hydraulic power source to the cylinder port block fitting.

NOTICE

DO NOT FULLY EXTEND CYLINDER TO THE END OF STROKE. RETRACT CYLINDER SLIGHTLY TO AVOID TRAPPING PRESSURE.

2. Operate the hydraulic power source and extend the cylinder. Shut down and disconnect the power source. Adequately support the cylinder rod, if applicable.
3. Remove the counterbalance valve, shuttle valve and plug fittings from the valve assembly. Discard o-rings.
4. Loosen and remove the capscrew and remove the valve assembly from barrel.
5. Place the cylinder barrel into a suitable holding fixture.




Figure 5-75. Cylinder Barrel Support

6. Mark cylinder head and barrel with a center punch for easy realignment. Using an allen wrench, loosen the cylinder head retainer capscrews, and remove capscrews from cylinder barrel.




Figure 5-76. Capscrew Removal

7. Attach a suitable pulling device to the cylinder rod end.

NOTICE

EXTREME CARE SHOULD BE TAKEN WHEN REMOVING THE CYLINDER ROD, HEAD, AND PISTON. AVOID PULLING THE ROD OFF-CENTER, WHICH COULD CAUSE DAMAGE TO THE PISTON AND CYLINDER BARREL SURFACES.

8. With the barrel clamped securely, apply pressure to the rod pulling device and carefully remove the complete rod assembly from the cylinder barrel.





Figure 5-77. Cylinder Rod Support



- | | | | | |
|---------------|--------------------|--------------------|--------------------------|-------------------|
| 1. Barrel | 8. Backup Ring | 15. Tapered Ring | 22. Bushing | 29. Shuttle Valve |
| 2. Rod | 9. Piston | 16. Bolt | 23. Plug | 30. O-ring |
| 3. Head | 10. Hydrolock Seal | 17. Capscrew | 24. Plug | 31. O-ring |
| 4. Wiper Seal | 11. Guidelock Ring | 18. Washer Ring | 25. Plug | 32. Orifice |
| 5. Rod Seal | 12. Wear Ring | 19. Valve Assembly | 26. Plug | 33. Plug |
| 6. Wear Ring | 13. O-ring | 20. Capscrew | 27. Counterbalance Valve | |
| 7. O-ring | 14. Backup Ring | 21. Bearing | 28. Counterbalance Valve | |

Figure 5-78. Tower Boom Lift Cylinder