OPERATION MANUAL



MODEL QP2H CENTRIFUGAL PUMP (HONDA GX120UT2PX2 GASOLINE ENGINE)

Revision #3 (05/28/20)



www.discount-equipment.com

THIS MANUAL MUST ACCOMPANY THE EQUIPMENT AT ALL TIMES.

PARTS FINDER Search Website Search Website Search Website Search Website







Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: http://www.discount-equipment.com/category/5443-parts/ and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep,Small Line, Wanco, Yanmar



QP2H Centrifugal Pump

QPZH Centrifugai Pump	
Proposition 65 Warning2	
Safety Information4-8	
Specifications (Pump)9	25
Specifications (Engine)10	
General Information11	
Pump Components12	
Basic Engine13	
Inspection (Engine)14	
Setup 15	
Operation16-17	
Maintenance (Pump) 18-19	
Maintenance (Engine)20-22	
Storage	
Troubleshooting (Engine)24	
Troubleshooting (Engine/Pump)25	×O
NOTICE	
NOTICE	
Specifications and part numbers are subject to change without notice.	
a e	

NOTICE

Do not operate or service the equipment before reading the entire manual. Safety precautions should be followed at all times when operating this equipment. Failure to read and understand the safety messages and operating instructions could result in injury to yourself and others.

SAFETY MESSAGES

The four safety messages shown below will inform you about potential hazards that could injure you or others. The safety messages specifically address the level of exposure to the operator and are preceded by one of four words: DANGER, WARNING, CAUTION or NOTICE.

SAFETY SYMBOLS



DANGER

Indicates a hazardous situation which, if not avoided, WILL result in **DEATH** or **SERIOUS INJURY**.



WARNING

Indicates a hazardous situation which, if not avoided, **COULD** result in **DEATH** or **SERIOUS INJURY**.



CAUTION

Indicates a hazardous situation which, if not avoided, **COULD** result in **MINOR** or **MODERATE INJURY**.

NOTICE

Addresses practices not related to personal injury.

Potential hazards associated with the operation of this equipment will be referenced with hazard symbols which may appear throughout this manual in conjunction with safety messages.

Symbol	Safety Hazard
	Lethal exhaust gas hazards
ANY.	Explosion hazards
allh Allka	Burn hazards
	Pressurized fluid hazards
	Battery acid hazards
	Eye safety hazards

GENERAL SAFETY

CAUTION

■ **NEVER** operate this equipment without proper protective clothing, shatterproof glasses, respiratory protection, hearing protection, steel-toed boots and other protective devices required by the job or city and state regulations.











■ **NEVER** operate this equipment when not feeling well due to fatigue, illness or when under medication.



■ **NEVER** operate this equipment under the influence of drugs or alcohol.







NOTICE

- This equipment should only be operated by trained and qualified personnel 18 years of age and older.
- Whenever necessary, replace nameplate, operation and safety decals when they become difficult read.
- Manufacturer does not assume responsibility for any accident due to equipment modifications. Unauthorized equipment modification will void all warranties.
- NEVER use accessories or attachments that are not recommended by Multiquip for this equipment. Damage to the equipment and/or injury to user may result.
- ALWAYS know the location of the nearest fire extinguisher.



■ ALWAYS know the location of the nearest first aid kit.



ALWAYS know the location of the nearest phone or keep a phone on the job site. Also, know the phone numbers of the nearest ambulance, doctor and fire department. This information will be invaluable in the case of an emergency.









PUMP SAFETY

DANGER

- **NEVER** pump volatile, explosive, flammable or low flash point fluids. These fluids could ignite or explode.
- The engine fuel exhaust gases contain poisonous carbon monoxide. This gas is colorless and odorless, and can cause death if inhaled.
- The engine of this equipment requires an adequate free flow of cooling air. **NEVER** operate this equipment in any

enclosed or narrow area where free flow of the air is restricted. If the air flow is restricted it will cause injury to people and property and serious damage to the equipment or engine.



NEVER operate the equipment in an explosive atmosphere or near combustible materials. An explosion or fire could result causing severe bodily harm or even death.



WARNING

- **NEVER** pump corrosive chemicals or water containing toxic substances. These fluids could create serious health and environmental hazards. Contact local authorities for assistance.
- **NEVER** open the priming plug when pump is hot. Hot water inside could be pressurized much like the radiator of an automobile. Allow pump to cool to the touch before loosening plug. The possibility exists of scalding, resulting in severe bodily harm.



■ NEVER disconnect any emergency or safety devices.

These devices are intended for operator safety.

Disconnection of these devices can cause severe injury, bodily harm or even death. Disconnection of any of these devices will void all warranties.

A CAUTION

- **NEVER** lubricate components or attempt service on a running machine.
- NEVER block or restrict flow from discharge hose. Remove kinks from discharge line before starting pump. Operation with a blocked discharge line can cause water inside pump to overheat.

NOTICE

- ALWAYS fill the pump casing with water before starting the engine. Failure to maintain water inside the pump housing will cause severe damage to the pump and mechanical seal.
- In winter drain water from pump housing to prevent freezing.
- **NEVER** start the pump with the clean-out cover removed. The rotating impeller inside the pump can cut or sever objects caught in it. Before starting the pump, check that the clean-out cover is securely fastened.
- ALWAYS keep the machine in proper running condition.
- ALWAYS ensure pump is on level ground before use.
- Fix damage to machine and replace any broken parts immediately.
- ALWAYS store equipment properly when it is not being used. Equipment should be stored in a clean, dry location out of the reach of children and unauthorized personnel.

ENGINE SAFETY

WARNING

- NEVER operate the engine with heat shields or guards removed.
- DO NOT remove the engine oil drain plug while the engine is hot. Hot oil will gush out of the oil tank and severely scald any persons in the general area of the pump.



CAUTION

■ **NEVER** touch the hot exhaust manifold, muffler or cylinder. Allow these parts to cool before servicing equipment.



NOTICE


- **NEVER** run engine without an air filter or with a dirty air filter. Severe engine damage may occur. Service air filter frequently to prevent engine malfunction.
- NEVER tamper with the factory settings of the engine or engine governor. Damage to the engine or equipment can result if operating in speed ranges above the maximum allowable.



FUEL SAFETY

DANGER

DO NOT add fuel to equipment if it is placed inside truck bed with plastic liner. Possibility exists of explosion or fire due to static electricity.



- **DO NOT** start the engine near spilled fuel or combustible fluids. Fuel is extremely flammable and its vapors can cause an explosion if ignited.
- ALWAYS refuel in a well-ventilated area, away from sparks and open flames.
- ALWAYS use extreme caution when working with flammable liquids.
- DO NOT fill the fuel tank while the engine is running or hot.
- **DO NOT** overfill tank, since spilled fuel could ignite if it comes into contact with hot engine parts or sparks from the ignition system.

- Store fuel in appropriate containers, in well-ventilated areas and away from sparks and flames.
- **NEVER** use fuel as a cleaning agent.
- **DO NOT** smoke around or near the equipment. Fire or explosion could result from fuel vapors or if fuel is spilled on a hot engine.



BATTERY SAFETY (ELECTRIC START ONLY)

DANGER

- **DO NOT** drop the battery. There is a possibility that the battery will explode.
- DO NOT expose the battery to open flames, sparks, cigarettes, etc. The battery contains combustible gases and liquids. If these gases and liquids come into contact with a flame or spark, an explosion could occur.



WARNING

■ ALWAYS wear safety glasses when handling the battery to avoid eye irritation. The battery contains acids that can cause injury to the eyes and skin.



- Use well-insulated gloves when picking up the battery.
- ALWAYS keep the battery charged. If the battery is not charged, combustible gas will build up.
- DO NOT charge battery if frozen. Battery can explode. When frozen, warm the battery to at least 61°F (16°C).
- ALWAYS recharge the battery in a well-ventilated environment to avoid the risk of a dangerous concentration of combustible gases.
- If the battery liquid (dilute sulfuric acid) comes into contact with **clothing or skin**, rinse skin or clothing immediately with plenty of water.



If the battery liquid (dilute sulfuric acid) comes into contact with eyes, rinse eyes immediately with plenty of water and contact the nearest doctor or hospital to seek medical attention.

CAUTION

- ALWAYS disconnect the NEGATIVE battery terminal before performing service on the equipment.
- ALWAYS keep battery cables in good working condition. Repair or replace all worn cables.

TRANSPORTING SAFETY

CAUTION

■ **NEVER** allow any person or animal to stand underneath the equipment while lifting.

NOTICE

- Before lifting, make sure that the equipment parts (hook and vibration insulator) are not damaged and screws are not loose or missing.
- Always make sure crane or lifting device has been properly secured to the lifting bail (hook) of the equipment.
- **ALWAYS** shutdown engine before transporting.
- **NEVER** lift the equipment while the engine is running.
- Tighten fuel tank cap securely and close fuel cock to prevent fuel from spilling.
- Use adequate lifting cable (wire or rope) of sufficient strength.
- Use one point suspension hook and lift straight upwards.



- DO NOT lift machine to unnecessary heights.
- ALWAYS tie down equipment during transport by securing the equipment with rope.

ENVIRONMENTAL SAFETY/DECOMMISSIONING

NOTICE

Decommissioning is a controlled process used to safely retire a piece of equipment that is no longer serviceable. If the equipment poses an unacceptable and unrepairable safety risk due to wear or damage or is no longer cost effective to maintain (beyond life-cycle reliability) and is to be decommissioned (demolition and dismantlement), be sure to follow rules below.

- **DO NOT** pour waste or oil directly onto the ground, down a drain or into any water source.
- Contact your country's Department of Public Works or recycling agency in your area and arrange for proper disposal of any electrical components, waste or oil associated with this equipment.



- When the life cycle of this equipment is over, remove battery and bring to appropriate facility for lead reclamation. Use safety precautions when handling batteries that contain sulfuric acid.
- When the life cycle of this equipment is over, it is recommended that the trowel frame and all other metal parts be sent to a recycling center.

Metal recycling involves the collection of metal from discarded products and its transformation into raw materials to use in manufacturing a new product.

Recyclers and manufacturers alike promote the process of recycling metal. Using a metal recycling center promotes energy cost savings.

EMISSIONS INFORMATION

NOTICE

The gasoline engine used in this equipment has been designed to reduce harmful levels of carbon monoxide (CO), hydrocarbons (HC) and nitrogen oxides (NOx) contained in gasoline exhaust emissions.

This engine has been certified to meet US EPA Evaporative emissions requirements in the installed configuration.

Attempting to modify or make adjustments to the engine emmission system by unauthorized personnel without proper training could damage the equipment or create an unsafe condition.

Additionally, modifying the fuel system may adversely affect evaporative emissions, resulting in fines or other penalties.

Emission Control Label

The emission control label is an integral part of the emission system and is strictly controlled by regulation(s).

The label must remain with the engine for its entire life.

If a replacement emission label is needed, please contact your authorized engine distributor.

Table 1. Specifications (Pump)			
	Model	QP2H	
	Туре	Centrifugal Pump	
	Suction and Discharge Size	2.00 in. (51 mm.)	
Pump	Maximum Pumping Capacity	158 gallons/minute (600 liters/minute)	
	Max. Lift	25 ft. (7.62 m)	
	Max. Head	115 ft. (35 m)	
	Max. Pressure	50 psi (345 kPa)	
Dry Net Weight		53 lb. (24 Kg.)	




Figure 1. QP2H Dimensions

SPECIFICATIONS (ENGINE)

Table 2. Specifications (Engines)				
	Model	HONDA GX120UT2PX2		
	Туре	Air-cooled 4 stroke, Single Cylinder, OHV, Horizontal Shaft Gasoline Engine		
	Bore x Stroke	2.40 in. x 1.60 in. (60 mm x 42 mm)		
Engine	Displacement	118 cc (7.3 cu-in)		
	Max Output	4.0 H.P./3,600 R.P.M.		
	Fuel Tank Capacity	Approx. 0.53 U.S. Gallons (2.0 Liters)		
	Fuel	Unleaded Automobile Gasoline		
	Lube Oil Capacity	0.59 quarts (0.56 liters)		
	Speed Control Method	Centrifugal Fly-weight Type		
Starting Method		Recoil Start		
Dimension (L x W x H)		11.7 x 13.4 x 12.5 in. (297 x 341 x 318 mm)		
Dry Net Weight	, U	28.7 lbs (13 Kg.)		




Figure 2. QP2H Performance Curve

GENERAL INFORMATION

APPLICATION

The QP2H Centrifugal Pump is designed to handle all types of clear water applications. It is ideal for residential use such as dewatering basements and swimming pools.

Both the suction and discharge ports on the QP2H pump use a 2-inch diameter opening, which allows the pump to pump at a rate of approximately 158 gallons/minute (gpm) or 600 liters/minute (lpm).

Centrifugal or self priming pumps are designed to purge air from the suction line and create a partial vacuum in the pump body. The reduced atmospheric pressure inside the pump allows water to flow through the suction line and into the pump body. The centrifugal force created by the rotating impeller pressurizes the water and expels it from the pump.

POWER PLANT

This centrifugal pump is powered by a 4.0 horsepower air cooled 4-stroke, single cylinder HONDA GX120 gasoline engine that incorporates a low "Oil Alert Feature."

OIL ALERT FEATURE

In the event of low oil or no oil, the HONDA GX120 engine has a built-in oil alarm engine shut-down feature. In the event the oil level is low the engine will automatically shutdown.

STANDARD CENTRIFUGAL PUMP

Standard centrifugal pumps provide an economical choice for general purpose dewatering. These types of pumps should only be used in clear water applications (agricultural, industrial, residential) as they have a limited solid handling capability of only 10% by volume.

SUCTION LIFT

This pump is intended to be used for de-watering applications and is capable of suction lifts up to 25 feet at sea level. For optimal suction lift performance keep the suction hose or line as short as possible. In general always place the pump as close to the water as possible.

PUMP SUPPORT

The pump should always be placed on solid stationary ground in a level position.

NEVER place the pump on **soft soil.** The suction hose or pipe connection should always be checked for tightness and leaks. A small suction leak in the hose or fittings could prevent the pump from priming.

Elevation

Higher elevations will effect the performance of the pump. Due to less atmospheric pressure at higher altitudes, pumps **DO NOT** have the priming ability that they have at sea level. This is due to the "thinner air" or lack of oxygen at higher altitudes.

A general rule of thumb is that for every 1,000 feet of elevation above sea level a pump will lose one foot of priming ability.

For example, in Flagstaff, Arizona where the elevation is approximately 7,000 feet, the pump would have a suction lift of only 18 feet rather than the 25 feet at sea level. Table 3 shows suction lift at various elevations.

Table 3. Suction Lift at Various Elevations				
Altitude Feet (Meters)	Suction Lift in Feet (Meters)			
Sea Level	10.0 (3.048)	15.0 (4.572)	20.0 (6.096)	25.0 (7.620)
2,000 (610)	8.80 (2.680)	13.2 (4.023)	17.6 (5.364)	22.0 (6.705)
4,000 (1,219)	7.80 (2.377)	11.7 (3.566)	15.6 (4.754)	19.5 (5.943)
6,000 (1,829)	6.90 (2.103)	10.4 (3.169)	13.8 (4.206)	17.3 (5.273)
8,000 (2,438)	6.20 (1.889)	9.30 (2.834)	12.4 (3.779)	15.5 (4.724)
10,000 (3,048)	5.70 (1.737)	8.60 (2.621)	11.4 (3.474)	14.3 (4.358)

Table 4 shows percentage drops in performance as elevation increases.

Table 4. Performance Loss at Various Elevations			
Altitude Feet (Meters)	Discharge Flow	Discharge Head	
Sea Level	100%	100%	
2,000 (610)	97%	95%	
4,000 (1,219)	95%	91%	
6,000 (1,829)	93%	87%	
8,000 (2,438)	91%	83%	
10,000 (3,048)	88%	78%	

Figure 3 shows a typical application using the QP2H centrifugal pump. Please note that this pump is intended for the removal of clean water.




Figure 3. QP2H Pump Application

- Pump The QP2H is 2-inch centrifugal pump used in general de-watering applications. Typical dewatering applications consist of dewatering basements and swimming pools.
- Fill Cap Prior to operation, the pump casing should be filled with water. Remove this cap to add water to the pump. After the initial prime, a sufficient amount of water will be retained in the casing so that the operator will not need to re-prime later.
 - If the casing is dry or has insufficient water, the pump will have difficulty in priming which could lead to premature mechanical seal wear thus causing damage to the pump.
- 3. **Discharge Port** Connect a 2-inch discharge hose to this port.
- 4. **Worm Clamp** Used to secure the hose to the inlet and outlet ports on the pump. Use two clamps to secure the hose on the inlet side of the pump.
- Discharge Hose Connect this flexible rubber hose to the discharge port on the pump. Make sure that the hose lays flat and is not kinked. Use only recommended type discharge hose. Contact Multiquip parts department for ordering information.

- 6. **Suction Port** Connect a 2-inch inlet hose to this port. Use two worm clamps to secure the hose.
- Suction Hose Connect this flexible rubber hose to the suction port on the pump. Make sure that the hose lays flat and is not kinked. Use only recommended type suction hose. Contact Multiquip parts department for ordering information.
- 8. **Drain Plug** Remove this plug to drain water from the pump.
- Strainer Always attach a strainer to bottom side of the suction hose to prevent large objects and debris from entering the pump. Strainer should be positioned so that it will remain completely under water. Running the pump with the strainer above water for long periods can damage pump.

er your part




Figure 4. Engine Controls and Components

INITIAL SERVICING

The engine (See Figure 4) must be checked for proper lubrication and filled with fuel prior to operation. Refer to the manufacturers engine manual for instructions and details of operation and servicing. The engine shown above is a HONDA engine, operation for other types of engines may vary somewhat.

 Fuel Filler Cap — Remove this cap to add unleaded gasoline to the fuel tank. Make sure cap is tightened securely. DO NOT over fill.

A

DANGER



Adding fuel to the tank should be done only when the engine is stopped and has had an opportunity to cool down. In the event of a fuel spill, **DO NOT** attempt to start the engine until the fuel residue has been completely wiped up, and the area surrounding the engine is dry.

- Throttle Lever Used to adjust engine RPM speed (lever advanced forward SLOW, lever back toward operator FAST).
- 3. **Engine ON/OFF Switch** ON position permits engine starting, OFF position stops engine operations.
- Recoil Starter (pull rope) Manual-starting method.
 Pull the starter grip until resistance is felt, then pull briskly and smoothly.
- 5. **Fuel Valve Lever OPEN** to let fuel flow, **CLOSE** to stop the flow of fuel.

- Choke Lever Used in the starting of a cold engine, or in cold weather conditions. The choke enriches the fuel mixture.
- 7. **Air Cleaner** Prevents dirt and other debris from entering the fuel system. Remove wing-nut on top of air filter cannister to gain access to filter element.

NOTICE

Operating the engine without an air filter, with a damaged air filter, or a filter in need of replacement will allow dirt to enter the engine, causing rapid engine wear.

A

WARNING



Engine components can generate extreme heat. To prevent burns, **DO NOT** touch these areas while the engine is running or immediately after operating. **NEVER** operate the engine with the muffler removed.

- 8. **Spark Plug** Provides spark to the ignition system. Set spark plug gap to 0.6 0.7 mm (0.028 0.031 inch). Clean spark plug once a week.
- 9. **Muffler** Used to reduce noise and emissions.
- 10. **Fuel Tank** Holds unleaded gasoline. For additional information refer to engine owner's manual.

INSPECTION (ENGINE)

A

CAUTION



DO NOT attempt to operate the pump untilthe Safety Information, General Information and Inspection sections of this manual have been read and thoroughly understood.

BEFORE STARTING

- 1. Read safety instructions at the beginning of manual.
- Clean the pump, removing dirt and dust, particularly the engine cooling air inlet, carburetor and air cleaner.
- 3. Check the air filter for dirt and dust. If air filter is dirty, replace air filter with a new one as required.
- 4. Check carburetor for external dirt and dust. Clean with dry compressed air.
- 5. Check fastening nuts and bolts for tightness.

Engine Oil Check

- 1. To check the engine oil level, place the pump on secure level ground with the engine stopped.
- 2. Remove the filler dipstick from the engine oil filler hole (See Figure 5) and wipe clean.




Figure 5. Engine Oil Dipstick (Removal)

- Insert and remove the dipstick without screwing it into the filler neck. Check the oil level shown on the dipstick.
- If the oil level is low (See Figure 6), fill to the edge of the oil filler hole with the recommended oil type (Table 5). Maximum oil capacity is 0.59 quarts (0.56 liters).




Figure 6. Engine Oil DipStick (Oil Level

	Table 5. Oil Type		
Season	Temperature	Oil Type	
Summer	25°C or Higher	SAE 10W-30	
Spring/Fall	25°C~10°C	SAE 10W-30/20	
Winter	0°C or Lower	SAE 10W-10	



DANGER



Motor fuels are highly flammable and can be dangerous if mishandled. **DO NOT** smoke while refueling. **DO NOT** attempt to refuel the pump if the engine is *hot!* or running.

Fuel Check

- 1. Remove the gasoline cap located on top of fuel tank.
- 2. Visually inspect to see if the fuel level is low. If fuel is low, replenish with unleaded fuel.
- When refueling, be sure to use a strainer for filtration.
 DO NOT top-off fuel. Wipe up any spilled fuel immediately!

- 1. Place pump as near to water as possible, on a firm flat, level surface.
- To prime pump, remove fill cap (See Figure 3) and fill pump casing with water. If the pump casing is not filled with water before starting, it will not begin pumping.
- Attach suction and discharge hoses to the pump. Check that all hoses are **securely** attached to the pump. Make certain suction hose (See Figure 3) does not have any air leakage. Tighten hose clamps and couplings as required.
- 4. It is recommended that 2 clamps be used when securing the suction hose to the inlet side (suction) of the pump.
- 5. Remember suction hoses must be *rigid* enough not to collapse when the pump is in operation.
- 6. Check that the *discharge* hose (See Figure 3) is not restricted. Place hose so that it lays as straight as it is possible on the ground. Remove any twists or sharp bends from hose which may block the flow of water.

o to Discount. Eduiphnei

NOTICE

Suction and discharge hoses are available from Multiquip. Contact your nearest dealer for more information.

- 7. The discharge hose is usually a *collapsible* (thin-walled) hose, however if a thin-walled discharge hose is not available, a rigid suction hose can be substituted in its place.
- 8. Make sure the **suction strainer** (See Figure 3) is clean and securely attached to the water end of the suction hose. The strainer is designed to protect the pump by preventing large objects from being pulled in to the pump.

A

CAUTION

The strainer should be positioned so it will remain completely *under water*. Running the pump with the strainer above water for long periods can damage the pump.

CAUTION

DO NOT attempt to start the engine unless the pump has previously been primed with water. Severe pump damage will occur if pump has not been primed.

STARTING THE ENGINE

1. Place the engine fuel valve lever (See Figure 7) to the **ON** position.



Figure 7. Engine Fuel Valve Lever (ON Position)

Move the throttle lever (See Figure 8) away from the slow position, about 1/3 of the way toward the fast position.




Figure 8. Throttle Lever (1/3 Start Position

3. Place the choke lever (See Figure 9) in the **CLOSED** position if starting a cold engine.




Figure 9. Engine Choke Lever (Closed)

4. Place the choke lever (See Figure 10) in the **OPEN** position if starting a warm engine or the temperature is warm.




Figure 10. Engine Choke Lever (Open)

5. Place the engine **ON/OFF** switch (See Figure 11) in the ON position.




Figure 11. Engine ON/OFF Switch (ON Position)

6. Grasp the starter grip (See Figure 12) and slowly pull it out. The resistance becomes the hardest at a certain position, corresponding to the compression point. Pull the starter grip briskly and smoothly for starting.




Figure 12. Starter Grip

7. If the engine has started and the choke lever was moved to the **CLOSED** position to start the engine, gradually move the choke lever to the **OPEN** position (Figure 13) as the engine warms up. If the engine has not started repeat steps 1 through 6.




Figure 13. Choke Lever (Open)

- 8. Before the pump is placed in to operation, run the engine for several minutes. Check for fuel leaks, and noises that would associate with a lose component.
- 9. To begin pumping, place the throttle lever (See Figure 13) in the **RUN** position. If water is not flowing out of the discharge port, turn off the engine and check for and clear any obstructions within the suction hose.




Figure 14. Throttle Lever (Run)

WARNING

Water must always be flowing through the pump casing while the engine is running. Loss of flow may be the result of a loss of prime, restricted water flow or a deadhead situation. Please note that in such a condition, water in the pump can reach temperatures of 150-200°F in 15 to 20 minutes. This can cause serious burns if this hot water comes into contact with unprotected skin.

Before touching or opening the fill plug or drain plug, first turn off the engine and allow the pump casing to cool to the touch, and then open the pump carefully. Be cautious of any built up water pressure.



CAUTION

ALWAYS run engine at *full speed* while pumping.

STOPPING THE ENGINE

Normal Shutdown

 Move the throttle lever to the IDLE position (See Figure 14) and run the engine for three minutes at low speed.




Figure 15. Throttle Lever (Idle)

2. After the engine cools, turn the engine **ON/OFF** switch to the **OFF** position (See Figure 15).




Figure 16. Engine ON/OFF Switch (OFF)

3. Place the fuel shut-off lever (See Figure 16) in the **OFF** position



Figure 17. Fuel Valve Lever (OFF)

Emergency Shutdown

 Move the throttle lever quickly to the IDLE position, and place the engine ON/OFF switch in the OFF position. it.comito order your parte

PUMP VACUUM TEST

CAUTION

DO NOT attempt to start the engine unless the pump has previously been *primed* with water. Severe pump damage will occur if pump has not been primed.

To perform the pump vacuum test do the following:

- 1. Remove the pump fill cap (See Figure 3), and fill the pump with water.
- 2. Start the engine as outlined in the initial start-up section, and wait for the pump to begin pumping.
- 3. As shown in Figure 18, place a water hose inside the discharge opening of the pump, and turn on the water. This flow of water into the discharge opening will *prevent* the pump from running dry.
- 4. Place the Pump Vacuum Tester (P/N 7000030) over the pump suction (inlet) opening (See Figure 18) with the vacuum gauge facing upwards. It may be necessary to apply a small amount of water around the rubber seal of the vacuum tester to make a good suction fit.
- 5. Check and make sure that there are no air leaks between the vacuum tester and the inlet port on the pump. If air leaks are present reseat vacuum tester.
- 6. Run the pump for a few minutes while monitoring the vacuum gauge. If the gauge indicates a reading between -25 and -20 in. Hg. (inches of mercury) then it can be assumed that the pump is working correctly.

NOTICE

25 in. Hg (inches of mercury) translates into 25 feet of lift at sea level.

- 7. If the vacuum tester gauge indicates a reading below -20 in. Hg, it can then be assumed that the pump is not functioning correctly, and corrective action needs to be taken.
- 8. To test the flapper valve, shutdown the engine. The vacuum tester should remain attached to the pump suction inlet port by vacuum. This indicates the pump's flapper valve is seating properly to hold water in the suction hose when the engine is stopped. This prevents backflow and allows for faster priming when the engine is restarted.




Figure 18. Pump Vacuum Tester

ENGINE MAINTENANCE

Perform engine maintenance procedures as referenced by Table 6 below:

Table 6. Engine Maintenance Schedule							
Description (3)	Operation	Before	First Month or 10 hrs	Every 3 Months or 25 hrs	Every 6 Months or 50 hrs	Every Year or 100 hrs	Every 2 Years or 200 hrs
Engine Oil	CHECK	Χ					
Engine Oil	CHANGE		Χ			4	
Air Cleaner	CHECK	Χ					
All Cleaner	CHANGE			X (1)			
All Nuts and Bolts	Re-tighten If Necessary	X			0		
Spark Plug	CHECK-CLEAN			•	X		
Spark Flug	REPLACE			4			Χ
Cooling Fins	CHECK				Χ		
Spark Arrester	CLEAN					Χ	
Fuel Tank	CLEAN		X	•		Χ	
Fuel Filter	CHECK					Χ	
Idle Speed	CHECK-ADJUST		70.			X (2)	
Valve Clearance	CHECK-ADJUST			Х		Х	X (2)
Fuel lines	CHECK Every 2 years (replace if necessary) (2)						

- 1. Service more frequently when used in **DUSTY** areas.
- 2. These items should be serviced by your service dealer, unless you have the proper tools and are mechanically proficient. Refer to the HONDA shop Manual for service procedures.
- 3. For commercial use, log hours of operation to determine proper maintenance intervals.

NOTICE

Reference manufacturer engine manual for specific servicing instructions.

DAILY

 Thoroughly remove dirt and oil from the engine and control area. Clean or replace the air cleaner elements as necessary. Check and retighten all fasteners as necessary. Check the spring box and bellows for oil leaks. Repair or replace as needed.

WEEKLY

- 1. Remove the fuel filter cap and clean the inside of the fuel tank.
- 2. Remove or clean the filter at the bottom of the tank.
- 3. Remove and clean the spark plug (See Figure 19), then adjust the spark gap to 0.028~0.031 inch (0.6~0.7 mm). This unit has electronic ignition, which requires no adjustments.




Figure 19. Spark Plug Gap

ENGINE OIL

- 1. Drain the engine oil when the oil is **warm** as shown in Figure 20.
- 2. Remove the oil drain bolt and sealing washer and allow the oil to drain into a suitable container.
- Replace engine oil with recommended type oil as listed in Table 5. Engine oil capacity is 0.59 quarts (0.56 liters). DO NOT over fill.
- 4. Install drain bolt with sealing washer and tighten securely.




Figure 20. Engine Oil (Draining)

A DANGER



DO NOT use gasoline as a cleaning solvent, because that would create a risk of fire or explosion.

ENGINE AIR CLEANER

- 1. Remove the air cleaner cover and foam filter element as shown in Figure 21.
- 2. Tap the paper filter element (See Figure 21) several times on a hard surface to remove dirt, or blow compressed air [not exceeding 30 psi (207 kPa, 2.1 kgf/cm²)] through the filter element from the air cleaner case side. *NEVER* brush off dirt. Brushing will force dirt into the fibers. Replace the paper filter element if it is excessively dirty.
- Clean foam element in warm, soapy water or non-flammable solvent. Rinse and dry thoroughly. Dip the element in clean engine oil and completely squeeze out the excess oil from the element before installing.




Figure 21. Engine Air Cleaner

MAINTENANCE (ENGINE)

SPARK ARRESTER CLEANING

Clean the spark arrester every 6 months or 100 hours.

- 1. Remove the 4 mm screw (3) from the exhaust deflector, then remove the deflector. See Figure 22.
- 2. Remove the 5 mm screw (4) from the muffler protector, then remove the muffler protector.
- 3. Remove the 4 mm screw from the spark arrester, then remove the spark arrester




Figure 22. Spark Arrester Removal

30 to Discount

4. Carefully remove carbon deposits from the spark arrester screen (Figure 23) with a wire brush.




Figure 23. Cleaning The Spark Arrester

- 5. If the spark arrester is damaged and has breaks or holes, replace with a new one.
- 6. Reinstall the spark arrester and muffler protector in reverse order of disassembly.

com to order your parts

PUMP STORAGE

For storage of the pump for over 30 days, the following is required:

- Drain the fuel tank completely.
- Run the engine until the fuel is completely consumed.
- Completely drain used oil from the engine crankcase and fill with fresh clean oil, then follow the procedures described in the engine manual for engine storage.
- Remove the drain plug from the pump and drain out any water from left in the housing.
- Remove the pump cover and clean inside of pump housing. Coat inside of pump housing with a light film of oil to reduce corrosion. A spray can of oil works well for this application.
- Cover suction and discharge ports with duct tape to prevent any foreign matter from falling into pump.
- Cover pump and engine with plastic covering or equivalent and store in a clean, dry place.
- To protect the water cooled-seals, place one-half pint of lubricating oil (new or used) through the discharge opening on the pump and crank the engine several times. This will prevent excessive corrosion and also keep the mechanical seal lubricated.

TROUBLESHOOTING (ENGINE)

	Table 7. Engine Troubleshooting	
Symptom	Possible Problem	Solution
Difficult to start		
	Ignition plug being bridge?	Check ignition system.
Fuel is available but spark plug will not	Carbon deposit at ignition?	Clean or replace ignition.
ignite. (Power available at high tension	Short circuit due to defective insulators?	Replace insulators.
cable).	Improper spark gap?	Set spark plug gap to the correct gap.
Fuel is available but spark plug will not ignite. (Power NOT available at high	Short circuit at stop switch?	Check stop switch circuit. Replace stop switch if defective.
tension cable).	Ignition coil defective?	Replace ignition coil.
	Muffler clogged with carbon deposits?	Clean or replace muffler.
Fuel is evailable and enerty plug ignites	Mixed fuel quality is inadequate?	Check fuel to oil mixture.
Fuel is available and spark plug ignites (compression normal).	Fuel in use inadequate (water, dust)?	Flush fuel system and replace with fresh fuel.
	Air Cleaner clogged?	Clean or replace air cleaner.
Fuel is available and spark plug ignites	Defective cylinder head gasket?	Tighten cylinder head bolts or replace head gasket.
(compression low).	Cylinder worn?	Replace cylinder.
	Spark plug loose?	Tighten spark plug.
Operation not satisfactory		
	Air cleaner clogged?	Clean or replace air cleaner.
Not enough power available	Air in fuel line?	Bleed (remove air) from fuel line.
(compression normal, no miss-firing).	Fuel level in carburetor float chamber improper?	Adjust carburetor float.
X/V	Carbon deposits in cylinder?	Clean or replace cylinder.
	Ignition coil defective?	Flush fuel system and replace with fresh fuel.
Not enough power available (compression normal, miss-firing).	Ignition plug often shorts?	Replace ignition wires, clean ignition.
	Fuel in use inadequate (water, dust)?	Flush fuel system and replace with fresh fuel.
×O,	Excessive carbon deposition in combustion chamber?	Clean or replace crankcase.
Engine overheats.	Exhaust or muffler clogged with carbon.	Clean or replace muffler.
	Spark plug heat value incorrect?	Replace spark plug with correct type spark plug.

TROUBLESHOOTING (ENGINE/PUMP)

Table 7. Engine Troubleshooting				
Symptom	Possible Problem Solution			
Operation not satisfactory				
Rotational speed fluctuates.	Governor adjustment improper?	Adjust governor to correct lever.		
	Governor spring defective?	Clean or replace ignition.		
	Fuel flow erratic?	Check fuel line.		
	Air taken in through suction line?	Check suction line.		
Recoil starter not working properly.	Dust in rotating part?	Clean recoil starter assembly.		
	Spring failure?	Replace spiral spring.		

Table 8. Pump Troubleshooting				
Symptom	Possible Problem	Solution		
	Not enough priming water in the housing?	Add water.		
	Engine speed too low?	Increase throttle.		
	Strainer plugged?	Clean strainer.		
	Suction hose damaged?	Replace or repair hose, and clamps.		
Pump does not take	Air leak at suction port?	Check that fittings are tight and properly sealed.		
on water.	Pump is located too high above water line?	Move pump closer to water.		
	Debris collecting in pump housing?	Clean pump housing.		
	Too much distance between impeller and volute.	Adjust clearance by adding shims or replace impeller. Min006" - Max020".		
	Water leaking out weep hole between pump and engine?	Check condition of mechanical seal and gaskets, between pump end and engine housing.		
	Engine speed too low?	Increase throttle speed.		
Pump takes in water, little or	Suction strainer partially plugged?	Clean strainer.		
no discharge.	Impeller/Volute worn?	Adjust clearance by adding shims or replace impeller/volute.		
Suction hose leaks at inlet.	Fittings/clamps are not sealed properly?	Tighten, replace or add clamp. (Keep extra seals on pump).		
Suction nose leaks at met.	Hose diameter is too large?	Use smaller diameter hose or replace hose.		
Discharge does not stay on	Pressure too high?	Check pressure, add additional clamp.		
coupling.	Hose kinked or end blocked?	Check hose.		
langellen de ee zakkinge	Impeller jammed or blocked?	Open pump cover and clean dirt and debris from inside housing.		
Impeller does not turn: pump is hard to start.	Impeller and volute binding?	Adjust clearance by removing shim from behind impeller.		
	Defective engine?	See Engine Owner's Manual.		

OPERATION MANUAL

HERE'S HOW TO GET HELP

PLEASE HAVE THE MODEL AND SERIAL NUMBER ON-HAND



www.discount-equipment.com

© COPYRIGHT 2020, MULTIQUIP INC.

Multiquip Inc, the MQ logo are registered trademarks of Multiquip Inc. and may not be used, reproduced, or altered without written permission. All other trademarks are the property of their respective owners and used with permission.

This manual MUST accompany the equipment at all times. This manual is considered a permanent part of the equipment and should remain with the unit if resold.

The information and specifications included in this publication were in effect at the time of approval for printing. Illustrations, descriptions, references and technical data contained in this manual are for guidance only and may not be considered as binding. Multiquip Inc. reserves the right to discontinue or change specifications, design or the information published in this publication at any time without notice and without incurring any obligations.



PARTS FINDER Search Website Search Website Search Website Search Website







Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: http://www.discount-equipment.com/category/5443-parts/ and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep,Small Line, Wanco, Yanmar