




[www.Discount-Equipment.com](http://www.Discount-Equipment.com)

**SKYJACK**

# SERVICE MANUAL

**SJ82 T, SJ86 T**

TELESCOPIC BOOMS



**229040ABA**

August 2020

ANSI/CSA, CE, AS

**TO PURCHASE THIS PRODUCT PLEASE CONTACT US**



**Equipment Financing and  
Extended Warranties Available**



**Discount-Equipment.com is your online resource for  
commercial and industrial quality parts and equipment sales.**

**561-964-4949**

**visit us on line @ [www.discount-equipment.com](http://www.discount-equipment.com)**

Select an option below to find your Equipment

**Search by Manufacturer**

**Search by Product Type**

**Request a Quote**

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar



**This manual is for MEWPs with serial numbers:**

**SJ82 T:** A402 000 001 - A402 999 999

**SJ86 T:** A402 000 001 - A402 999 999

To order go to [Discount-Equipment.com](http://Discount-Equipment.com)

---

**THIS SAFETY ALERT SYMBOL MEANS ATTENTION!**



**BECOME ALERT! YOUR SAFETY IS INVOLVED.**

The Safety Alert Symbol identifies important safety messages on MEWPs, safety signs in manuals or elsewhere. When you see this symbol, be alert to the possibility of personal injury or death. Follow the instructions in the safety message.

** DANGER**

**DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

** WARNING**

**WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

** CAUTION**

**CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

**IMPORTANT**

**IMPORTANT** indicates a procedure essential for safe operation and which, if not followed, may result in a malfunction or damage to the MEWP.

# Table of Contents

|  |           |
|--|-----------|
| <b>Section 1 – Scheduled Maintenance</b> .....                                   | <b>11</b> |
| <b>1.1 Read and Heed</b> .....   | <b>11</b> |
| 1.1-1 <i>Aerial Platform and Mobile Elevating Work Platform Definition</i> ..... | 11        |
| 1.1-2 <i>Purpose of Equipment</i> .....  | 11        |
| 1.1-3 <i>Use of Equipment</i> .....  | 11        |
| 1.1-4 <i>Manual</i> .....  | 11        |
| 1.1-5 <i>Service Policy and Warranty</i> .....                                   | 11        |
| 1.1-6 <i>Operator Safety Reminders, Warnings and Precautions</i> .....           | 11        |
| <b>1.2 Maintenance and Service</b> .....   | <b>12</b> |
| 1.2-1 <i>Maintenance and Inspection Schedule</i> .....                           | 12        |
| 1.2-2 <i>Owner's Annual Inspection Record</i> .....                              | 12        |
| 1.2-3 <i>Replacement Parts</i> .....   | 12        |
| 1.2-4 <i>Maintenance and Service Safety Tips</i> .....                           | 12        |
| 1.2-5 <i>Hydraulic System &amp; Component Maintenance and Repair</i> .....       | 13        |
| 1.2-6 <i>Hydraulic Maintenance Hints</i> .....                                   | 13        |
| 1.2-7 <i>Railing Maintenance and Repair</i> .....                                | 14        |
| <b>1.3 Scheduled Maintenance</b> .....   | <b>15</b> |
| 1.3-1 <i>Service Bulletins</i> .....   | 15        |
| 1.3-2 <i>Maintenance and Inspection</i> .....                                    | 15        |
| 1.3-3 <i>Maintenance Instructions</i> .....                                      | 15        |
| <b>1.4 Owner's Annual Inspection Record</b> .....                                | <b>16</b> |
| <b>1.5 Pre-Delivery/Maintenance Inspection Checklist</b> .....                   | <b>17</b> |
| <b>1.6 Scheduled Maintenance Inspections</b> .....                               | <b>18</b> |
| 1.6-1 <i>Electrical</i> .....  | 18        |
| 1.6-2 <i>Hydraulic</i> .....   | 18        |
| 1.6-3 <i>Labels</i> .....  | 18        |
| 1.6-4 <i>Limit switches</i> .....  | 18        |
| 1.6-5 <i>Engine Compartment</i> .....  | 19        |
| 1.6-6 <i>Control Compartment</i> .....   | 22        |
| 1.6-7 <i>Base</i> .....  | 24        |
| 1.6-8 <i>Platform Assembly</i> .....   | 26        |
| 1.6-9 <i>Boom Assembly</i> .....   | 27        |
| 1.6-10 <i>Optional equipment</i> .....   | 29        |
| <b>1.7 Function Tests</b> .....  | <b>30</b> |
| <b>Section 2 – Maintenance Tables and Diagrams</b> .....                         | <b>31</b> |
| <b>2.1 Standard Hose Numbering System</b> .....                                  | <b>31</b> |
| <b>2.2 MEWP Torque Specifications</b> .....                                      | <b>33</b> |

|   |   |           |
|---|---|-----------|
| 2.3   | Axle Torque Specifications                            | 34        |
| 2.4   | Torque Specifications for Fasteners (US)              | 35        |
| 2.5   | Torque Specifications for Fasteners (Metric)          | 36        |
| 2.6   | Torque Specifications for Hydraulic Couplings & Hoses | 37        |
| 2.7   | Axles Maintenance Intervals                           | 38        |
| 2.8   | Tire Specifications                                   | 39        |
| 2.9   | Floor Loading Pressure                                | 40        |
| 2.10  | Hydraulic Specifications & Gear Oil                   | 41        |
| 2.11  | Specifications & Features - Dimensional Data          | 42        |
| 2.12  | Specifications & Features - Performance and Speeds    | 43        |
| 2.13  | Engine Specifications                                 | 44        |
| 2.14  | Axle Oscillation Diagrams                             | 45        |
| 2.15  | Dimension and Reach Diagram - SJ82 T                  | 46        |
| 2.16  | Dimension and Reach Diagram - SJ86 T                  | 47        |
| <b>Section 3 – System Component Identification and Schematics</b> |   | <b>49</b> |
| 3.1   | Electrical Symbol Chart                               | 50        |
| 3.2   | Hydraulic Symbol Chart                                | 51        |
| 3.3   | Wire Number and Color Code                            | 52        |
| 3.4   | Wire Numbers and Color Codes - Additional             | 53        |
| 3.5   | Hydraulic Parts List                                  | 54        |
| 3.6   | Electrical Parts List                                 | 57        |
| 3.7   | Hourmeter/Counter Harness - CE                        | 62        |
| 3.8   | Rotary Manifold Port Identification                   | 63        |
| 3.9   | System and Drive Pump Port Identification             | 65        |
| 3.10  | Drive Motors Port Identification                      | 66        |
| 3.11  | Jib Valve Port Identification                         | 67        |
| 3.12  | No Jib Valve Port Identification                      | 68        |
| 3.13  | Brake Manifold Port Identification                    | 69        |
| 3.14  | Main Manifold Port Identification                     | 71        |
| 3.15  | Main Manifold Electrical Component Identification     | 72        |
| 3.16  | Main Manifold Hydraulic Component Identification      | 73        |
| 3.17  | Main Harness Wiring Diagram                           | 74        |
| 3.18  | Boom Lift Valve Harness                               | 75        |
| 3.19  | Differential Lock Harness                             | 76        |
| 3.20  | Platform Rotate & Jib Harnesses                       | 77        |
| 3.21  | Platform to Base Control Cable Harnesses              | 78        |
| 3.22  | Limit Switch Connections                              | 79        |
| 3.23  | Load Sensing Cable Connection - CE & AS               | 80        |
| 3.24  | ECU Engine Wiring Diagram - Deutz Diesel Engine       | 81        |
| 3.25  | Glow Plug and EGR Harnesses - Deutz Diesel Engine     | 82        |
| 3.26  | Generator and Oil Cooler Harness Connections          | 83        |
| 3.27  | Generator Wiring                                      | 84        |
| 3.28  | Platform Work Light                                   | 85        |

|  |  |            |
|--|--|------------|
| 3.29   | Positive Air Shut-Off Option Harness   | 86         |
| 3.30   | Dual Capacity Sensing Module   | 87         |
| 3.31   | Load Circuit - ANSI/CSA with Deutz TD2.9L and Arctic Package                     | 88         |
| 3.32   | Hydraulic Schematic  | 89         |
| 3.33   | Platform Controls Wiring - SJ82 T  | 90         |
| 3.34   | Platform Controls Wiring - SJ86 T with Deutz TD2.9L or D2011 Engines             | 91         |
| 3.35   | Platform Controls Wiring - SJ86 T with Deutz TCD2.2 Engine                       | 92         |
| 3.36   | Base Controls Wiring - SJ82 T ANSI/CSA - Deutz TD2.9L                            | 93         |
| 3.37   | Base Controls Wiring - SJ82 T ANSI/CSA - Deutz TD2.9L with Positive Air Shut-Off | 94         |
| 3.38   | Base Controls Wiring - SJ82 T ANSI/CSA - Deutz D2011                             | 95         |
| 3.39   | Base Controls Wiring - SJ86 T ANSI/CSA - Deutz TD2.9L                            | 96         |
| 3.40   | Base Controls Wiring - SJ86 T ANSI/CSA - Deutz TD2.9L with Positive Air Shut-Off | 97         |
| 3.41   | Base Controls Wiring - SJ86 T ANSI/CSA & AS - Deutz D2011                        | 98         |
| 3.42   | Base Controls Wiring - SJ86 T CE - Deutz TCD2.2                                  | 99         |
| 3.43   | Base Controls Wiring - SJ86 T CE - Deutz D2011                                   | 100        |
| 3.44   | Base Controls Wiring - SJ86 T CE - Deutz TD2.9L                                  | 101        |
| 3.45   | Electrical Schematic - ANSI/CSA Deutz TD2.9L                                     | 102        |
| 3.46   | Electrical Schematic - ANSI/CSA & AS Deutz D2011                                 | 103        |
| 3.47   | Electrical Schematic - CE Deutz TCD2.2   | 104        |
| 3.48   | Electrical Schematic - CE Deutz D2011  | 105        |
| 3.49   | Engine Electrical Schematic - Deutz TD2.9L                                       | 106        |
| 3.50   | Engine Interface Harness Schematic - Deutz TD2.9L                                | 107        |
| 3.51   | Engine Electrical Schematic - Deutz TCD2.2                                       | 108        |
| 3.52   | Engine Interface Harness Schematic - Deutz TCD2.2                                | 109        |
| <b>Section 4 – Troubleshooting Information</b> |  | <b>111</b> |
| 4.1  | Introduction   | 111        |
| 4.2  | Electrical System  | 112        |
| 4.2-1  | All Controls Inoperative   | 112        |
| 4.2-2  | No Power   | 113        |
| 4.2-3  | Engine Will Not Crank  | 114        |
| 4.2-4  | Engine Cranks but Will Not Start   | 117        |
| 4.2-5  | Glow Plug Circuit Inoperative - Deutz D2011 diesel engine                        | 118        |
| 4.2-6  | Glow Plug Circuit Inoperative - Deutz D2.9 diesel engine                         | 118        |
| 4.2-7  | All Base Control Console Inoperative   | 119        |
| 4.2-8  | No Movement from Base Control Console  | 120        |
| 4.2-9  | All Controls Inoperative From Platform Control Console                           | 127        |
| 4.2-10   | Throttle Inoperative, Mid and High - Deutz D2.9L                                 | 136        |
| 4.2-11   | Mid Throttle Inoperative   | 137        |
| 4.2-12   | High Throttle Inoperative  | 138        |
| 4.2-13   | Brake will not Release   | 139        |
| 4.2-14   | No Drive and Steer   | 139        |
| 4.2-15   | No High Speed Drive  | 142        |
| 4.2-16   | No Elevated Drive  | 143        |



|            |  |            |
|------------|--|------------|
| 4.2-17     | <i>Direction Sensing Inoperative</i> . . . . .   | 144        |
| 4.2-18     | <i>Steer Direction Sensing Inoperative</i> . . . . .   | 144        |
| 4.2-19     | <i>No boom down or extend Functions from Base or Platform Consoles (ANSI)</i> . . . . .                | 145        |
| 4.2-20     | <i>No boom down Function from Base or Platform Consoles (ANSI)</i> . . . . .                           | 145        |
| 4.2-21     | <i>No boom extend Function from Base or Platform Consoles (ANSI)</i> . . . . .                         | 146        |
| 4.2-22     | <i>No boom down Function from Base or Platform Consoles (CE, AS)</i> . . . . .                         | 146        |
| 4.2-23     | <i>No boom extend Function from Base or Platform Consoles (CE, AS)</i> . . . . .                       | 147        |
| <b>4.3</b> | <b>Hydraulic System</b> . . . . .  | <b>148</b> |
| 4.3-1      | <i>All Controls Inoperative</i> . . . . .  | 148        |
| 4.3-2      | <i>All Boom Functions Inoperative</i> . . . . .  | 148        |
| 4.3-3      | <i>No Main Boom Up</i> . . . . .   | 148        |
| 4.3-4      | <i>No Main Boom Down</i> . . . . .   | 148        |
| 4.3-5      | <i>No Turret Rotate</i> . . . . .  | 149        |
| 4.3-6      | <i>No Boom Extend</i> . . . . .  | 150        |
| 4.3-7      | <i>No Boom Retract</i> . . . . .   | 150        |
| 4.3-8      | <i>No Jib Up</i> . . . . .   | 151        |
| 4.3-9      | <i>No Jib Down</i> . . . . .   | 152        |
| 4.3-10     | <i>No Platform Rotation</i> . . . . .  | 152        |
| 4.3-11     | <i>Platform will not Level</i> . . . . .   | 153        |
| 4.3-12     | <i>Brake will not Release</i> . . . . .  | 154        |
| 4.3-13     | <i>Brake will not Engage</i> . . . . .   | 154        |
| 4.3-14     | <i>No Drive</i> . . . . .  | 155        |
| 4.3-15     | <i>Differential Lock will not Engage</i> . . . . .   | 155        |
| 4.3-16     | <i>No High Speed Drive</i> . . . . .   | 155        |
| 4.3-17     | <i>No Steer</i> . . . . .  | 156        |
| <b>4.4</b> | <b>Load Sensing System - CE</b> . . . . .  | <b>158</b> |
| 4.4-1      | <i>Green LED on Load Sense/Dual Load Zone Module is not on</i> . . . . .                               | 158        |
| 4.4-2      | <i>Load Sense indicates overload or overload warning with platform empty or below weight</i> . . . . . | 158        |
| 4.4-3      | <i>Load Sense/Dual Load Zone Module Error</i> . . . . .  | 159        |
| 4.4-4      | <i>No Light/Alarm when Platform is Overloaded</i> . . . . .  | 160        |
|            | <b>Section 5 – Procedures</b> . . . . .  | <b>161</b> |
| <b>5.1</b> | <b>General</b> . . . . .   | <b>161</b> |
| 5.1-1      | <i>Safety and Workmanship</i> . . . . .  | 161        |
| 5.1-2      | <i>How to Install the Boom Maintenance Support</i> . . . . .   | 162        |
| <b>5.2</b> | <b>Platform</b> . . . . .  | <b>166</b> |
| 5.2-1      | <i>Human Machine Interface (HMI)</i> . . . . .   | 166        |
| 5.2-2      | <i>User Interface Keys</i> . . . . .   | 166        |
| 5.2-3      | <i>SCM Character Functions Charts</i> . . . . .  | 167        |
| 5.2-4      | <i>SCM Operating Values Chart</i> . . . . .  | 168        |
| 5.2-5      | <i>How to Select SCM Functionality</i> . . . . .   | 169        |
| 5.2-6      | <i>How to View SCM Operation</i> . . . . .   | 170        |
| 5.2-7      | <i>How to Unlock and Modify SCM Settings</i> . . . . .   | 171        |

|            |  |            |
|------------|--|------------|
| 5.2-8      | SCM Pin Voltage Reference . . . . .                              | 172        |
| 5.2-9      | Fly Boom Switch Voltage References . . . . .                     | 175        |
| 5.2-10     | Platform Controller Voltage References . . . . .                 | 176        |
| <b>5.3</b> | <b>Load Sensing System . . . . .</b>                             | <b>177</b> |
| 5.3-1      | Load Sensing System Overload Status . . . . .                    | 177        |
| 5.3-2      | Dual Capacity Overload Module Function Table . . . . .           | 178        |
| 5.3-3      | Calibration of Load Sensing System . . . . .                     | 179        |
| <b>5.4</b> | <b>Boom . . . . .</b>  | <b>181</b> |
| 5.4-1      | Check Wear Pads . . . . .  | 181        |
| 5.4-2      | Shim Wear Pads . . . . .   | 181        |
| 5.4-3      | Cable Carrier Repair . . . . .                                   | 181        |
| 5.4-4      | Rotary Actuator Bolt Torque Procedure . . . . .                  | 181        |
| 5.4-5      | Boom Section Wear Pad Replacement . . . . .                      | 182        |
| 5.4-6      | Platform and Jib Boom Removal . . . . .                          | 183        |
| 5.4-7      | Platform Removal (no Jib Boom) . . . . .                         | 185        |
| 5.4-8      | Operating Machine Functions from Base Controls . . . . .         | 187        |
| 5.4-9      | Fly Boom Section Removal . . . . .                               | 188        |
| 5.4-10     | Mid Boom Section Removal . . . . .                               | 189        |
| 5.4-11     | Mid Boom Section Installation . . . . .                          | 190        |
| 5.4-12     | Fly Boom Section Installation . . . . .                          | 191        |
| 5.4-13     | Platform and Jib Boom Installation . . . . .                     | 191        |
| 5.4-14     | Platform Installation (no Jib Boom) . . . . .                    | 192        |
| 5.4-15     | Platform Control Console Connection . . . . .                    | 193        |
| 5.4-16     | Extension Cylinder and Wire Rope Replacement . . . . .           | 194        |
| 5.4-17     | Extension Cylinder and Cable Assembly Removal . . . . .          | 194        |
| 5.4-18     | Extension Cylinder and Wire Rope Assembly Installation . . . . . | 197        |
| 5.4-19     | Proper Wire Rope Tension . . . . .                               | 199        |
| 5.4-20     | Wire Rope Inspection . . . . .                                   | 200        |
| 5.4-21     | Limit Switch Checking and Adjusting . . . . .                    | 201        |
| 5.4-22     | Directional Sensing Limit Switch (LS1) . . . . .                 | 202        |
| 5.4-23     | High Speed Drive / Tilt Override Limit Switch (LS2) . . . . .    | 203        |
| 5.4-24     | Fly-in Limit Switch (LS3) . . . . .                              | 205        |
| 5.4-25     | Boom Angle (Dual Load) Limit Switch (LS4) . . . . .              | 206        |
| 5.4-26     | Boom Extension (Dual Load) Limit Switch (LS5) . . . . .          | 208        |
| 5.4-27     | Lift Cushion Limit Switch (LS6) . . . . .                        | 210        |
| <b>5.5</b> | <b>Turret . . . . .</b>  | <b>212</b> |
| 5.5-1      | Check and Replace the High Pressure Filter . . . . .             | 212        |
| 5.5-2      | Adjust the Turret Rotation Gear Backlash . . . . .               | 212        |
| 5.5-3      | Check the Swing Drive Oil . . . . .                              | 213        |
| 5.5-4      | Change the Swing Drive Oil . . . . .                             | 213        |
| 5.5-5      | Battery Replacement . . . . .                                    | 214        |
| 5.5-6      | Turret Rotation Gear Bolt Torque Sequence . . . . .              | 214        |
| 5.5-7      | Electronic Tilt Switch Setup Procedure . . . . .                 | 215        |

|             |  |            |
|-------------|--|------------|
| 5.5-8       | <i>Check Rotation Bearing for Axial Wear</i> . . . . .   | 217        |
| 5.5-9       | <i>Resetting the Emergency Lowering Counter (CE only)</i> . . . . .                                | 218        |
| <b>5.6</b>  | <b>Deutz Diesel Engines</b> . . . . .  | <b>219</b> |
| 5.6-1       | <i>Replace Engine Oil and Filter</i> . . . . .   | 219        |
| 5.6-2       | <i>Replace the Fuel Filter</i> . . . . .   | 220        |
| 5.6-3       | <i>Replace the Air Filter</i> . . . . .  | 220        |
| 5.6-4       | <i>Check the Engine Belt</i> . . . . .   | 220        |
| 5.6-5       | <i>Check the Oil Cooler (Deutz D2011 only)</i> . . . . .   | 220        |
| 5.6-6       | <i>Deutz TD2.9L Fault Codes</i> . . . . .  | 221        |
| 5.6-7       | <i>Diesel Particulate Filter (DPF) and Standstill Regeneration - Deutz TCD2.2 Engine</i> . . . . . | 241        |
| <b>5.7</b>  | <b>Hydraulic Tank</b> . . . . .  | <b>243</b> |
| 5.7-1       | <i>Change the Hydraulic Tank Filter</i> . . . . .  | 243        |
| 5.7-2       | <i>Change the Hydraulic Oil</i> . . . . .  | 243        |
| <b>5.8</b>  | <b>Manifolds and Hydraulic Pumps</b> . . . . .   | <b>244</b> |
| 5.8-1       | <i>Hydraulic Brake Pressure Adjustment</i> . . . . .   | 244        |
| 5.8-2       | <i>Hydraulic Standby Pressure Adjustment</i> . . . . .   | 245        |
| 5.8-3       | <i>Hydraulic High Pressure Adjustment</i> . . . . .  | 246        |
| 5.8-4       | <i>Hydraulic System Relief Valve Adjustment</i> . . . . .  | 247        |
| 5.8-5       | <i>Turret Rotate Relief Valve Adjustment</i> . . . . .   | 248        |
| 5.8-6       | <i>Platform Level Relief Valve Adjustment</i> . . . . .  | 248        |
| 5.8-7       | <i>Fly Boom Relief Valve Adjustment</i> . . . . .  | 249        |
| 5.8-8       | <i>Test Charge Pump Pressure on Drive Pump</i> . . . . .   | 249        |
| 5.8-9       | <i>Test Forward Drive Pressure on Drive Pump</i> . . . . .   | 250        |
| 5.8-10      | <i>Test Reverse Drive Pressure on Drive Pump</i> . . . . .   | 250        |
| <b>5.9</b>  | <b>Axles</b> . . . . .   | <b>251</b> |
| 5.9-1       | <i>Change the Oil in the Axles</i> . . . . .   | 251        |
| 5.9-2       | <i>Check the Oil Level in the Torque Hubs</i> . . . . .  | 251        |
| 5.9-3       | <i>Change the Oil in the Torque Hubs</i> . . . . .   | 251        |
| 5.9-4       | <i>Check the Oil Level in the Axle Gearbox</i> . . . . .   | 252        |
| 5.9-5       | <i>Change the Oil in the Axle Gearbox</i> . . . . .  | 252        |
| 5.9-6       | <i>Brake Inspection</i> . . . . .  | 253        |
| 5.9-7       | <i>Oscillating Cylinder Bolt Replacement</i> . . . . .   | 253        |
| 5.9-8       | <i>Oscillating Cylinder Replacement</i> . . . . .  | 254        |
| 5.9-9       | <i>Bleed the Oscillating Axle Cylinders</i> . . . . .  | 255        |
| 5.9-10      | <i>Test the Oscillating Axle Cylinders</i> . . . . .   | 256        |
| <b>5.10</b> | <b>Grease Points</b> . . . . .   | <b>257</b> |
| 5.10-1      | <i>Grease the Turret Ring Gear</i> . . . . .   | 257        |
| 5.10-2      | <i>Grease the Turret Swing Drive</i> . . . . .   | 257        |
| 5.10-3      | <i>Grease the Axles</i> . . . . .  | 258        |
| 5.10-4      | <i>Grease the Drive Shaft</i> . . . . .  | 258        |

---

# Section 1 – Scheduled Maintenance

## 1.1 Read and Heed

SKYJACK is continuously improving and expanding product features on its equipment, therefore, specifications and dimensions are subject to change without notice.

### 1.1-1 Aerial Platform and Mobile Elevating Work Platform Definition

A mobile device that has a positionable platform supported from ground level by a structure.

### 1.1-2 Purpose of Equipment

The SKYJACK Telescopic Boom Series MEWPS are designed to transport and raise personnel, tools and materials to overhead work areas.

### 1.1-3 Use of Equipment

The MEWP is a highly maneuverable, mobile work station. Work platform elevation and elevated driving must only be done on a firm, level surface.

### 1.1-4 Manual

**Operating Manual:** The operating manual is considered a fundamental part of the aerial platform. It is a very important way to communicate necessary safety information to users and operators. A complete and legible copy of this manual must be kept in the provided weather-resistant storage compartment on the aerial platform at all times.

**Service & Maintenance:** The purpose of this is to provide the customer with the servicing and maintenance procedures essential for the promotion of proper machine operation for its intended purpose.

All information in this manual should be read and understood before any attempt is made to service the machine. The updated copy of the manuals are found on the company's website: [www.skyjack.com](http://www.skyjack.com).

### 1.1-5 Service Policy and Warranty

SKYJACK warrants each new product to be free of defective parts and workmanship for the first 2 years or 3000 hours, whichever occurs first. Any defective part will be replaced or repaired by your local SKYJACK dealer at no charge for parts or labor. In addition, all products have a 5 year structural warranty. Contact the SKYJACK Service Department for warranty statement extensions or exclusions.

### 1.1-6 Operator Safety Reminders, Warnings and Precautions

Operator safety is SKYJACK's priority. The operator should comply with all applicable safety-related reminders, warnings and precautions found in the Operating Manual. They should be read and understood completely before operating the aerial platform.

## 1.2 Maintenance and Service

### 1.2-1 Maintenance and Inspection Schedule

The actual operating environment of the work platform governs the use of the maintenance schedule. The inspection points covered in [1.5 Pre-Delivery/Maintenance Inspection Checklist](#) indicates the areas of the MEWP to be maintained or inspected and at what intervals the maintenance and inspections are to be performed.

### 1.2-2 Owner's Annual Inspection Record

It is the responsibility of the owner to arrange quarterly and annual inspections of the MEWP. [1.4 Owner's Annual Inspection Record](#) Owner's Annual Inspection Record is to be used for recording the date of the inspection, owner's name, and the person responsible for the inspection of the work platform.

### 1.2-3 Replacement Parts

Use only original replacement parts. Parts such as batteries, wheels, railings, etc. with weight and dimensions different from original parts will affect stability of the MEWP and must not be used without manufacturer's consent.

All replacement tires must be of the same size and load rating as originally supplied tires; to maintain safety and stability of MEWP.

Consult SKYJACK's Service Department for optional tires specifications and installation.

#### **WARNING**

**Any unit that is damaged or not operating properly must be immediately tagged and removed from service until proper repairs are completed.**

### 1.2-4 Maintenance and Service Safety Tips

Maintenance and repair should only be performed by personnel who are trained and qualified to service this MEWP.

All maintenance and service procedures should be performed in a well lighted and well ventilated area.

Anyone operating or servicing this MEWP must read and completely understand all operating instructions and safety hazards in this manual and operating manual.

All tools, supports and lifting equipment to be used must be of proper rated load and in good working order before any service work begins. Work area should be kept clean and free of debris to avoid contaminating components while servicing.

Ensure personnel are clear from under unsupported components/systems that are at risk of movement during maintenance.

All service personnel must be familiar with employer and governmental regulations that apply to servicing this type of equipment.

Keep sparks and flames away from all flammable or combustible materials.

Properly dispose of all waste material such as lubricants, rags, and old parts according to the relative law provisions obtaining in the country.

Before attempting any repair work, disconnect the main power connectors.

Keep personnel clear of components, systems or unsupported loads that may move unexpectedly during maintenance procedures.

Preventive maintenance is the easiest and least expensive type of maintenance.



### 1.2-5 Hydraulic System & Component Maintenance and Repair

The following points should be kept in mind when working on the hydraulic system or any component:

#### **WARNING**

**Escaping fluid from a hydraulic pressure leak can damage your eyes, penetrate the skin and cause serious injury. Use proper personal protection at all times.**

1. Any structure has limits of strength and durability. To prevent failure of structural parts of hydraulic components, relief valves which limit pressure to safe operating values are included in the hydraulic circuits.
2. Tolerance of working parts in the hydraulic system is very close. Even small amounts of dirt or foreign materials in the system can cause wear or damage to components, as well as general faulty operation of the hydraulic system. Every precaution must be taken to assure absolute cleanliness of the hydraulic oil.
3. Whenever there is a hydraulic system failure which gives reason to believe that there are metal particles or foreign materials in the system, drain and flush the entire system and replace the filter cartridges. A complete change of oil must be performed under these circumstances.
4. Whenever the hydraulic system is drained, check the magnets in the hydraulic reservoir for metal particles. If metal particles are present, flush the entire system and add a new change of oil. The presence of metal particles also may indicate the possibility of imminent component failure. A very small amount of fine particles is normal.
5. All containers and funnels used in handling hydraulic oil must be absolutely clean. Use a funnel when necessary for filling the hydraulic oil reservoir, and fill the reservoir only through the filter opening. The use of cloth to strain the oil should be avoided to prevent lint from getting into the system.
6. When removing any hydraulic component, be sure to cap and tag all hydraulic lines involved. Also, plug the ports of the removed components.

7. All hydraulic components must be disassembled in spotlessly clean surroundings. During disassembly, pay particular attention to the identification of parts to assure proper reassembly. Clean all metal parts in a clean mineral oil solvent. Be sure to thoroughly clean all internal passages. After the parts have been dried thoroughly, lay them on a clean, lint-free surface for inspection.
8. Replace all O-rings and seals when overhauling any component. Lubricate all parts with clean hydraulic oil before reassembly. Use small amounts of petroleum jelly to hold O-rings in place during assembly.
9. Be sure to replace any lost hydraulic oil when completing the installation of the repaired component, and bleed any air from the system when required.
10. All hydraulic connections must be kept tight. A loose connection in a pressure line will permit the oil to leak out or air to be drawn into the system. Air in the system can cause damage to the components and noisy or erratic system operation.

### 1.2-6 Hydraulic Maintenance Hints

Three simple maintenance procedures have the greatest effect on the hydraulic system performance, efficiency and life. Yet, the very simplicity of them may be the reason they are so often overlooked. They are simply these:

1. Change filters annually. The filters will need to be changed more often depending on the operating conditions. Dirty, dusty, high moisture environments may cause the hydraulic system to be contaminated more quickly.
2. Maintain a sufficient quantity of clean hydraulic oil of the proper type and viscosity in the hydraulic reservoir.
3. Keep all connections tight.

### 1.2-7 Railing Maintenance and Repair

Skyjack MEWPs have been designed to ensure compliance with the relevant design standards applicable for that particular unit at the time of manufacture. As such, any repairs made to the guardrail or basket structure need to ensure this compliance is not compromised and must return the structure to its original condition.

Any damage must be repaired by returning the railing assembly to its undamaged state. Damage includes, but is not limited to, the items listed below:

- bent/deformed guardrail sections
- cracks or broken welds in railing sections
- damaged pin connections
- missing pins or broken pin lanyards
- missing railing hardware
- loose or missing parts
- additional holes in guardrail sections other than those approved by Skyjack

Additionally, the guardrails must be properly positioned and secured, and the entry gate must be in good working order.

The strength of the guardrail system, and therefore its ability to provide fall protection for platform occupants, depends upon the design being secure and undamaged.

Skyjack railings are designed for modular replacement, and Skyjack recommends replacement of any damaged railing section. Skyjack-approved replacement parts will meet this requirement.

### 1.3 Scheduled Maintenance

This section contains the maintenance and inspection schedule that is to be performed.

References are made to the procedures in Section 5 that outline detailed step-by-step instructions for checks and replacements.

#### 1.3-1 Service Bulletins

Before performing any scheduled maintenance inspection procedure, refer to service bulletins found in our web site: *www.skyjackinc.com* for updates related to service and maintenance of this MEWP.

#### 1.3-2 Maintenance and Inspection

Death or injury can result if the MEWP is not kept in good working order. Inspection and maintenance should be performed by competent personnel who are trained and qualified on maintenance of this MEWP.

#### WARNING

**Failure to perform each procedure as presented and scheduled may cause death, serious injury or substantial damage.**

#### NOTE

*Preventive maintenance is the easiest and least expensive type of maintenance.*

- Unless otherwise specified, perform each maintenance procedure with the MEWP in the following configuration:
  - MEWP parked on a flat and level surface
  - Disconnect the batteries by disconnecting the main power connectors.
- Repair any damaged or malfunction components before operating MEWP.
- Keep records on all inspections.

### 1.3-3 Maintenance Instructions

This manual consists of four schedules to be done for maintaining on an MEWP. Inspection schedule frequency is shown below:
















| Issue or Symptom |              |   |
|------------------|--------------|---|
| PDI/Frequent     | <b>B</b>     | Perform PDI prior to each delivery, or Frequent Inspection every 200 days or 200 hours. |
| Annual           | <b>B + C</b> | Perform Scheduled Maintenance Inspections every year.                                   |
| Additional       | <b>*</b>     | Perform at time sensitive maintenance intervals.  |

- Make copies of the maintenance and inspection checklist to be used for each inspection.
- Check the schedule on the checklist for the type of inspection to be performed.
- Place a check in the appropriate box after each inspection procedure is completed.
- Use the maintenance and inspection checklist and step-by-step procedures in Section 1 to perform these inspections.
- If any inspection receives a fail, tag and remove the MEWP from service.
- If any MEWP component(s) has been repaired, an inspection must be performed again before removing the tag. Place a check in the repair column.

#### Legend

|                |            |
|----------------|------------|
| Pass           | <b>P</b>   |
| Fail           | <b>F</b>   |
| Repaired       | <b>R</b>   |
| Not applicable | <b>N/A</b> |

**Table 1.4 Owner's Annual Inspection Record**

|  Model _____ SN _____   |   |   |   |   |   |   |   |   |   |   |   |
|--|---|---|---|---|---|---|---|---|---|---|---|
| <br>Inspection Date     |   |   |   |   |   |   |   |   |   |   |   |
| <br>Inspector Signature |  | 20  | 20  | 20  | 20  | 20  | 20  | 20  | 20  | 20  | 20  |
|  |  |  |  |  |  |  |  |  |  |  |  |

**⚠ WARNING**

Do not use the MEWP if there is no inspection recorded in the last 13 months. If you do not obey, there is a risk of death or serious injury.

**IMPORTANT**

The Owner's annual inspection record is located on the scissor assembly. It must be filled out after an annual inspection has been completed. Do not use the MEWP if an inspection has not been recorded in the last 13 months.

To order go to Discount-Equipment.com

# 1.5 Pre-Delivery/Maintenance Inspection Checklist



## Frequent/Periodic/Annual/PDI Checklist Articulating Booms and Telescopic Booms

Serial Number: Starting with serial number A000 000 000 or B000 000 000 and above

Product Owner: \_\_\_\_\_

Model: \_\_\_\_\_

Product User: \_\_\_\_\_

Hourmeter Reading: \_\_\_\_\_

Date/Time: \_\_\_\_\_

Inspection Type (Choose one):  Pre-delivery  Frequent  Periodic  Annual

Use this table for pre-delivery inspections (PDI) before each rental, lease or sale and as an instruction for all frequent inspections and annual inspections. Refer to the operation and service manuals for inspection instructions (for example, visual inspection and function tests, torque specs, engine oil, chain inspection intervals, and more).

| Inspection Type Schedule |     |
|--------------------------|-----|
| PDI/Frequent/Periodic    | B   |
| Annual                   | B+C |

**B** - Do the pre-delivery inspection before the machine is sent out or during the frequent inspections at 200 days or 200 hour intervals. For more instructions, refer to the operation and service manuals. **P** - Pass **N/A** - Not Applicable

**C** - Do the scheduled maintenance inspections each year. For more instructions, refer to the service manual.

Put a check mark in the "Pass" column as you meet the requirements of the inspection for each item. Add a comment if the item does not pass inspection.

| Items for Inspection  | P | N/A |
|---|---|-----|
| <b>Service Bulletins.</b> Make sure there are no open service bulletins.  | B |     |
| <b>Annual Inspection.</b> Make sure you complete it within 13 months.   | B |     |
| <b>Labels.</b> In place, correctly attached and you can read them.  | B |     |
| <b>Limit Switches.</b> Correctly installed and no obstructions or damage.   | B |     |
| <b>ENGINE COMPARTMENT</b>   |   |     |
| <b>Main Power Disconnect Switch.</b> Cables and switch tight and in working order.  | B |     |
| <b>Battery.</b> No damage, tight connections and sufficient fluid levels. Clean terminals and cable ends.   | B |     |
| <b>Swing Drive.</b> Tight fittings, hoses and bolts. No damage, missing components or leaks.  | B |     |
| <b>Hydraulic Pump and Motor.</b> Tight fittings, hoses and bolts. No damage, missing components or leaks.   | B |     |
| <b>Engine and Components.</b> Do a check of the engine and components for any loose, missing, damaged, or failed items. Do a check of the oil and coolant levels. Make sure you do not exceed the recommended oil and coolant change intervals. | B |     |
| <b>Air Filter.</b> Do a check of the filter. Replace the air filter if necessary.   | C |     |
| <b>Fuel Filter.</b> Do a check of the filter. Replace the fuel filter if necessary.   | C |     |
| <b>Radiator.</b> Do a check of the coolant condition and replace if necessary.  | C |     |
| <b>CONTROL COMPARTMENT</b>  |   |     |
| <b>Turret Transportation Lock.</b> Unlocked and no damage or missing components.  | B |     |
| <b>Base Control Console.</b> Operate the switches and make sure they all operate correctly. No damage or missing components.  | B |     |
| <b>Hydraulic Tank.</b> Filler cap closed tightly and no damage or leaks.  | B |     |
| <b>Hydraulic Oil.</b> Level between min. and max. marks.  | B |     |
| <b>Hydraulic Oil.</b> Do a check and replace oil and filters if necessary.  | C |     |
| <b>Hydraulic Return Filter.</b> Correctly attached and no damage, missing components or leaks.  | B |     |
| <b>Hydraulic Return Filter.</b> Do a check of the filter. Replace the filter if necessary.  | C |     |
| <b>Manifolds.</b> Tight fittings and hoses and no damage or leaks. Tight wire connections, no missing components and correctly working valves.  | B |     |
| <b>High-pressure Filter.</b> Do a check of the filter. Replace the filter if necessary.   |   |     |
| <b>Emergency Power Unit.</b> Tight fittings and hoses. No leaks. Tight wire connections and no damage or missing components.  | B |     |
| <b>Fuel Tank and Lines.</b> Filler cap, tank, fittings and hoses are closed tightly and no damage or leaks.   | B |     |
| <b>BASE</b>   |   |     |
| <b>Base Weldment.</b> No deformation or cracks.   | B |     |
| <b>Rotary Manifold.</b> Tight fittings and hoses, and no leaks.   | B |     |
| <b>Turret Rotation Motor/Gear.</b> Tight fittings, hoses and bolts. No damage, missing components or leaks. Make sure the gears are lubricated.   | B |     |
| <b>Turret Rotation Motor/Gear.</b> Lubricate the gears.   | C |     |

| Items for Inspection   | P | N/A                        |
|--|---|----------------------------|
| <b>Axles.</b> Correctly attached and no missing components. Tight fittings and hoses and no leaks.   | B |                            |
| <b>Axles.</b> Do a check of the brakes.  | C |                            |
| <b>Oscillating Cylinders.</b> Correctly attached and no missing components. Tight fittings and hoses and no leaks.   | B |                            |
| <b>Oscillating Cylinders.</b> Correctly attached and no missing components. Tight fittings and hoses and no leaks. Do a check of the mounting bolts torque seal. | C |                            |
| <b>Steer Cylinder.</b> Correctly attached and no missing components. Tight fittings and hoses and no leaks.  | B |                            |
| <b>Steer Linkage.</b> No damage/wear or missing components.  | B |                            |
| <b>Wheel/Tire Assembly.</b> Do a check of all tires for damage, wear and correctly aligned.  | B |                            |
| <b>Wheel/Tire Assembly.</b> No loose bolts. Wheel nuts torqued as recommended.   | C |                            |
| <b>PLATFORM</b>  |   |                            |
| <b>Railings and Gates.</b> Correctly attached and no damage or missing components.   | B |                            |
| <b>Platform Floor.</b> Correctly attached and no damage or missing components.   | B |                            |
| <b>Footswitch.</b> Correctly attached. Operates correctly with no modifications.   | B |                            |
| <b>Fall-Protection Anchorage.</b> Anchorages are correctly attached and no damage.   | B |                            |
| <b>AC Power Socket.</b> No obstructions, dirt, or damage.  | B |                            |
| <b>Platform Control Console.</b> Operate the switches and make sure they all operate correctly. No damage or missing components.                                 | B |                            |
| <b>Manual Storage Box.</b> Manuals and documents are in the storage the box, in good condition, and you can read them.   | B |                            |
| <b>BOOM</b>  |   |                            |
| <b>Rotary Actuator.</b> No damage or missing components. Tight fittings, hoses and bolts and no leaks.   | B |                            |
| <b>Jib.</b> No damage or missing components. Tight hoses and bolts and no leaks.   | B |                            |
| <b>Boom.</b> No damage or missing components. No deformation or cracks in welds. Tight fittings, hoses, bolts, and pins. No leaks.                               | B |                            |
| <b>Cable Track.</b> No damage or missing components.   | B |                            |
| <b>Wear Pads.</b> No damage, wear or missing components. Fasteners tight.  | B |                            |
| <b>Riser.</b> No damage or missing components. No deformation or cracks in welds. Tight fittings, hoses, bolts, and pins. No leaks.                              | B |                            |
| <b>Cylinders.</b> No damage or missing components. Tight fittings and hoses and no leaks. Pins and bushing are tight and correctly installed.                    | B |                            |
| <b>Control Cables and Hoses.</b> No damage or missing components. No leaks.  | B |                            |
| <b>Wire Ropes.</b> No damage or missing components. Tight jam nuts. No spring gaps. Do not exceed the inspection interval.                                       | B |                            |
| <b>OPTIONAL EQUIPMENT</b>  |   |                            |
| <b>Special Options and Approved Attachments.</b> Correctly attached and no damage or missing components.   | B |                            |
| <b>Function Tests.</b> Refer to the operating manual for your serial number for information on how to run these tests.   |   | <b>PASS</b><br><b>FAIL</b> |

199342AA


Comments: \_\_\_\_\_

The undersigned has made sure that all areas in the list have received an inspection.  
The undersigned has told the machine owner of all inconsistencies in the inspection and corrected them before machine operation.

Owner: \_\_\_\_\_ Print Name \_\_\_\_\_ Signature \_\_\_\_\_ Date (DD/MM/YY) \_\_\_\_\_

User: \_\_\_\_\_ Print Name \_\_\_\_\_ Signature \_\_\_\_\_ Date (DD/MM/YY) \_\_\_\_\_





## 1.6 Scheduled Maintenance Inspections

Do an inspection of the MEWP in this sequence.

### **⚠ WARNING**

**Do not operate a MEWP until all malfunctions have been corrected. If you do not obey, there is a risk of death or serious injury.**

### **⚠ WARNING**

**Turn the main power disconnect switch to the off position before you do the visual and daily maintenance inspections. If you do not obey, there is a risk of death or serious injury.**

### 1.6-1 Electrical

Do a check on these areas for chafed, corroded, and loose wires:

- Boom to platform cable harness
- Engine compartment electrical panel
- Engine wiring harness
- Rotary manifold wiring

### 1.6-2 Hydraulic

Do a check on these areas and make sure there are no signs of leakage:

- Hydraulic tank filter, fittings, hoses, emergency-power unit, turret and base surfaces
- Engine compartment fittings, hoses, primary pump, filter, turret and base surface
- All hydraulic cylinders
- All hydraulic manifolds
- The ground area below the MEWP.


### 1.6-3 Labels (B)

Refer to the labels section in the Operating Manual. Make sure all the labels are in the correct location, are in good condition, and you can read them.

### 1.6-4 Limit switches (B)

Do an inspection of all limit switches **1** located inside the turret and on the boom. Inspect for the following:

- Broken or missing actuator arms
- Missing fasteners
- Loose wiring.



### 1.6-5 Engine Compartment

Do the inspection that follows:

Make sure all compartment latches are latched tightly and in good condition.

#### 1 Main power disconnect switch (B)

- Turn the **main power disconnect** switch to the off position.
- Make sure the switch rotates and stays in the on and off position.
- Make sure the cables are not loose.

#### 2 Batteries (B)

#### **⚠ WARNING**

Explosion hazard. Keep flames and sparks away. Do not smoke near the batteries. If you do not obey, there is a risk of death or serious injury.

#### **⚠ WARNING**

Corrosion hazard. Do not touch battery acid. Wear the correct PPE. If the battery acid touches you, immediately flush the area with cold water and get medical aid.

#### B - Frequent Inspection

1. Do an inspection of the battery case for damage.
  - Clean the battery terminals and cable ends thoroughly with a terminal cleaning tool or wire brush.
2. Make sure all the battery connections are tight.
3. If applicable, check the battery fluid level.
  - If the plates do not have a minimum 13 mm (1/2 inch) of solution above them, add distilled or demineralized water.
  - Replace the battery if it is damaged or cannot hold a lasting charge.

#### **⚠ WARNING**


Only use original or manufacturer-approved parts and components for the MEWP. If you do not obey, there is a risk of death, serious injury, or machine damage.

#### 3 Swing drive motor (B,C)

- Make sure there are no loose or missing parts.
- Make sure there is no visible damage.
- Make sure all bolts are correctly tightened.
- Make sure all fittings and hoses are correctly tightened and there are no hydraulic leaks.

#### C - Annual Inspection

- For the brake/motor oil replacement procedure, refer to [5.5-3 Check the Swing Drive Oil](#).



#### 4 Hydraulic pump and motor (B)

- Make sure there are no loose or missing parts.
- Make sure there is no visible damage.
- Make sure all bolts are correctly tightened.
- Make sure all fittings and hoses are correctly tightened and there are no hydraulic leaks.

### Engine and Components

#### 5 Engine pivot tray (B)

- Make sure there are no loose or missing parts.
- Make sure there is no visible damage.
- Make sure that the engine is correctly attached to the pivot tray.
- Make sure the tray-securing bolt is in place.

#### 6 Muffler and exhaust (B)

- Make sure that the muffler and exhaust systems are correctly attached with no visible damage.

#### Engine fuel leaks (B,C)

- Make sure that there no fuel leaks at the engine.
- Make sure there is no visible damage.

### **▲ WARNING**

**Explosion or fire hazard. Do not smoke near the fuel system. If you do not obey, there is a risk of death or serious injury.**

#### Engine fuel filter (B,C)

- Make sure there are no loose or missing parts.
- Make sure there is no visible damage.

#### C - Annual Inspection


- For the engine fuel filter replacement procedure, refer to the engine manual.

#### 7 Radiator (B, C)

- Make sure there are no loose or missing parts.
- Make sure there is no visible damage.
- Make sure that the radiator is correctly attached to the engine tray.
- Check the coolant level and add more if necessary.

#### C - Annual Inspection

- Check the coolant strength. For recommended coolant change intervals, refer to the engine manual.



### 8 Engine oil level (B)

#### **⚠ WARNING**

**Burn hazard. Do not touch hot engine components without the correct PPE. Let the engine cool before you do an inspection or servicing. If you do not obey, there is a risk of death or serious injury.**

- Use the dipstick to check the oil level.
- The oil level must be between the marks L (low) and H (high). Add oil if it is necessary. Refer to [2.13 Engine Specifications](#) for recommended oil types.

#### **B - Frequent Inspection**

- For recommended oil change, refer to engine manual

#### **B - Frequent Inspection**

- For the recommended oil change interval and procedure, refer to the engine manual.

### 9 Air filter (B,C)

- Make sure there are no loose or missing parts.
- Make sure there is no visible damage.
- Squeeze the lips of the vacuator valve to remove the dirt and dust.
- Do an inspection of the service indicator on the air cleaner. Replace the filter element if necessary.


#### **B - Frequent Inspection**

- For the engine air filter maintenance procedure, refer to the engine manual.

#### **C - Annual Inspection**

- For the engine air filter replacement procedure, refer to the engine manual.





### 1.6-6 Control Compartment

Do the inspection that follows:

Make sure all compartment latches are latched tightly and in good condition.

#### 1 Turret transportation lock (B)

- Make sure the turret transportation lock is unlocked.
- Make sure there are no loose or missing parts.
- Make sure there is no visible damage

#### 2 Base Control Console (B)

- Make sure there are no loose or missing parts.
- Make sure there is no visible damage, and all the switches are in their off/neutral positions.

#### 3 Hydraulic Tank (B)

- Make sure the hydraulic filler cap closes tightly.
- Make sure there is no visible damage or hydraulic leaks.

#### Hydraulic Oil (B, C)

- Make sure the boom is in the stowed position.
- Do a check on the **gauge** on the side of the hydraulic oil tank. The hydraulic oil level must be at or a small distance above the top mark of the gauge. Add oil if it is necessary. Refer to [2.10 Hydraulic Specifications & Gear Oil](#).

#### C - Annual Inspection

- For hydraulic oil replacement procedure, refer to [5.7-2 Change the Hydraulic Oil](#).

#### 4 Hydraulic Return Filter (B,C)

- Make sure the filter element is attached and tight.
- Make sure there is no visible damage or hydraulic leaks.

#### C - Annual Inspection

- For the hydraulic tank filter replacement procedure, refer to [5.7-1 Change the Hydraulic Tank Filter](#).


#### 5 High-pressure filter (B,C)

- Make sure the housing is attached and tight.
- Make sure there is no visible damage or hydraulic leaks.

#### C - Annual Inspection

- For the filter element replacement procedure, refer to [5.5-1 Check and Replace the High Pressure Filter](#).





### 6 Manifolds (B)

- Make sure all fittings and hoses are correctly tightened.
- Make sure there is no indication of hydraulic leakage.
- Make sure there are no loose wires or missing fasteners.

### 7 Emergency Power Unit (B)

- Make sure there are no loose or missing parts.
- Make sure there are no loose wires or missing fasteners.
- Make sure there is no visible damage.
- Make sure all the fittings and hoses are correctly tightened and there are no hydraulic leaks.

### 8 Fuel Tank and Lines (B)

## IMPORTANT

Before you use the MEWP, make sure there is sufficient fuel for the estimated task.


## **⚠ DANGER**

**Explosion or fire hazard. Do not smoke near the fuel system. If you do not obey, there is a risk of death or serious injury.**

- Make sure that the fuel filler cap closes tightly.
- Make sure there is no visible damage to the tank, gauge, hoses, or fittings.
- Make sure there is no indication of fuel leakage from the tank, gauge, hoses, fittings, pump, and filter.

## **⚠ WARNING**

**Environmental hazard. Immediately remove gasoline, diesel fuel, engine oil, and hydraulic fluid spills and leaks with rags. Discard these rags in accordance with national, state/provincial/territorial, and local regulations. Spilled fluids can damage the environment. When spilled fluids go into the water (for example, a sewage system, streams, rivers, or other surface water), they can kill aquatic life.**



### 1.6-7 Base

#### 1 Base weldment (B)

- Make sure there are no visible cracks in welds or structure and there are no signs of deformation.

#### 3 Rotary manifold (B)

- Make sure all hoses are correctly tightened and there is no sign of hydraulic leakage.

#### 3 Turret rotation gear (B,C)

- Make sure there are no loose or missing parts.
- Make sure there is no visible damage.

#### C - Annual Inspection

- For the lube procedure, refer to [5.10 Grease Points](#).

#### 4 Axles (B,C)

- Make sure the front and rear axles are correctly attached.
- Make sure there are no loose or missing parts.
- Make sure all the fittings and hose connections are tight.
- Make sure there is no sign of hydraulic leakage.

#### C - Annual Inspection

- Check the brakes annually. Refer to the procedure [5.9-6 Brake Inspection](#).

#### 5 Brakes (B)


- Make sure there are no loose or missing parts.
- Make sure all the fittings and hoses are correctly tightened and there are no hydraulic leaks.

#### 6 Steer cylinder (B)

- Make sure there are no loose or missing parts.
- Make sure all the fittings and hoses are correctly tightened and there are no hydraulic leaks.

#### 7 Steer linkage (B)

- Make sure there are no loose or missing parts.
- Make sure the tie rod end studs are locked and there is no visible damage.



### 8 Oscillating cylinders (B,C)

- Make sure the oscillating cylinders are correctly attached, and there are no visible spaces.
- Make sure there are no loose or missing parts.
- Make sure all the fittings and hose connections are tight.
- Make sure there is no sign of hydraulic leakage.
- Do a check of the heads of the oscillating cylinder mounting bolts to make sure the torque seal is visible and undamaged. If the torque seal is damaged or is missing, remove and replace the affected bolts. Refer to [5.9-7 Oscillating Cylinder Bolt Replacement](#).

### NOTE

The oscillating axle is locked when the MEWP is in the elevated travel position or at the elevated travel speed. Refer to [2.14 Axle Oscillation Diagrams](#).

### 9 Wheel/tires (B,C)

- Do a check on all tire treads and sidewalls for cuts, cracks, holes, and unusual wear.
- Do a check on each wheel for damage, and cracked welds.
- Do a check on each lug nut for the correct torque to make sure they are not loose.
- Make sure the wheels are correctly aligned vertically and horizontally.
- Make sure there are no loose or missing parts.
- Make sure there is no visible damage.


### B - Frequent Inspection

- For proper torque information, refer to [2.2 MEWP Torque Specifications](#).

### WARNING

Do not use tires other than the tires that Skyjack specifies for this MEWP. Do not mix different types of tires or use tires that are not in good condition. Only replace the tires with the same types that are approved by Skyjack. The use of other tires can make the MEWP less stable. If you do not obey, there is a risk of death or serious injury.

Refer to [2.8 Tire Specifications](#).



### 1.6-8 Platform Assembly

#### 1 2 Railings and gates

- Make sure there are no loose or missing parts, and there is no visible damage.
- Make sure the fasteners are correctly installed.
- Make sure the platform railings 1 are in the correct position.
- Make sure the gates or drop bars 2 are in good condition and operate correctly.

#### 3 MEWP floor

- Make sure the MEWP floor is solid and there is no visible damage.

#### 4 Footswitch

- Make sure the footswitch is in good working order and has not been tampered with, disabled or blocked.

#### 5 Fall-protection anchorages

- Make sure that the fall-protection anchorages are correctly installed.
- Make sure there is no visible damage.

#### 6 AC power socket

- Make sure that the socket is free of dirt or blockages.

#### 7 Platform control console (B)

- Make sure all switches and controllers are in the neutral position.
- Make sure there are no loose or missing parts, and there is no visible damage.


#### 8 Manual storage box (B)

- Make sure that the operation manual and other important documents are in the manual storage box.
- Make sure that the documents are in good condition, and you can read them.
- Always put the manuals and other documents back in the storage box after use.

#### 9 Load Cell - CE & AS (B)

- Make sure there are no loose or missing parts, and there is no visible damage.
- Make sure the fasteners are correctly installed.
- Make sure the cables are in good condition.
- Make sure the cable connections are tight.
- Make sure there is no debris lodged between the platform and the boom adaptor.





### 1.6-9 Boom Assembly

#### 1 Rotary actuator

- There are no loose or missing parts, and there is no visible damage.
- All fasteners are correctly tightened.
- All hoses are correctly tightened and there is no sign of hydraulic leakage.

#### 2 Jib (if equipped) (B)

- There are no loose or missing parts, and there is no visible damage.
- All fasteners are correctly tightened.
- All hoses are correctly tightened and there is no sign of hydraulic leakage.

#### 3 Boom (B)

- There are no loose or missing parts, and there is no visible damage.
- All fasteners are correctly tightened.
- All hoses are correctly tightened and there is no sign of hydraulic leakage.
- Make sure there are no visible cracks in welds or structure and there are no signs of deformation.

#### 4 Cable Track (B)

- There are no loose or missing parts, and there is no visible damage.

#### 5 Wear Pads (B)


- All fasteners are correctly tightened.
- There are no loose or missing parts, and there is no visible damage to the wear pads.

#### 6 Cylinders (B)

- Make sure the cylinders are correctly installed.
- Make sure there is no indication of leaks or damage.
- Make sure all pins and bushings are secure and properly tightened.


#### 7 Control Cables and Hoses (B)

- There are no loose or missing parts, and there is no visible damage.
- All hoses are correctly tightened and there is no sign of hydraulic leakage.




**8 Wire ropes (B)**

- There are no loose or missing parts, and there is no visible damage.
- All fasteners are correctly tightened.
- Make sure that the nuts are correctly tightened and are locked together.
- Make sure that there are no gaps between the springs. For the wire rope tension procedure, refer to [5.4-19 Proper Wire Rope Tension](#).



**Cable Disc Springs**



**1.6-10 Optional equipment (B)**

Do the inspection that follows, and make sure:

**1 Generator**

- There are no loose or missing parts, and there is no visible damage.
- All hoses are correctly tightened and there is no sign of hydraulic leakage.

**2 Flashing amber light**

- The lamp is correctly attached, and there is no visible damage.

**3 Welder**

- The welder and the welder tray are correctly attached.
- There are no loose or missing parts, and there is no visible damage.
- There are no loose wires or missing fasteners.

**4 Cold or arctic weather package**

- The heater plugs are correctly attached with no visible damage.
- There is no sign of engine oil leakage.

**5 Tool tray**

- The tray is correctly attached with lock-pins, and there is no visible damage.

**6 Glazier**

- There are no loose or missing parts, and there is no visible damage.

**7 Pipe rack**

- There are no loose or missing parts, and there is no visible damage.

## 1.7 Function Tests

Function tests are designed to discover any malfunctions before an aerial platform is put into service. The operator must understand and follow step-by-step instructions to test all aerial platform functions.

### IMPORTANT

Never use a malfunctioning aerial platform. If malfunctions are discovered, aerial platform must be tagged and placed out of service. Repairs to aerial platform may only be made by a qualified service technician.

- After repairs are completed, the operator must perform a pre-operation inspection and a series of function tests again before putting aerial platform into service.
- Prior to performing function tests, be sure to read and understand the “Start Operation” section of the operating manual.
- For function tests that are to be performed, please refer to the operating manual that corresponds to the correct serial number. Found there will be detailed instructions for which tests to perform, as well as how to properly and successfully perform them.




### NOTE

The all-function motion alarm should sound while operating any boom and drive function.



# Section 2 – Maintenance Tables and Diagrams

**Table 2.1 Standard Hose Numbering System**



Using the number above as an example, H1104 0081 2, this hose requires a 37° JIC female swivel fitting on one end, and a medium length 90° JIC female swivel fitting for the other end. The hose must meet or exceed the S.A.E. 100R13 hose specification, and be a total of 81-1/2" long.



**NOTE**

Hose ends and hose must be from same manufacturer per S.A.E. J1273 Nov. '91, Sections 3.10 and 4.2. Hose ends and hose must be of the same size i.e. #4 size fittings must be used with #4 size hose.

| Hose Size Chart |       |      |      |      |      |      |    |        |        |    |        |    |        |    |
|-----------------|-------|------|------|------|------|------|----|--------|--------|----|--------|----|--------|----|
| Size            | 03    | 04   | 06   | 08   | 10   | 12   | 16 | 20     | 24     | 32 | 40     | 48 | 56     | 64 |
| ID              | 3/16" | 1/4" | 3/8" | 1/2" | 5/8" | 3/4" | 1" | 1-1/4" | 1-1/2" | 2" | 2-1/2" | 3" | 3-1/2" | 4" |

| Fitting Arrangement Schedule |                                    |                                     |                           |
|------------------------------|------------------------------------|-------------------------------------|---------------------------|
| Hose Prefix                  | Hose End Fitting                   | Hose End Fitting                    | S.A.E. Hose Specification |
| H01                          | FEMALE, 37° JIC, SWIVEL            | FEMALE, 37° JIC, SWIVEL             | 100R17                    |
| H02                          | FEMALE, 37° JIC, SWIVEL            | FEMALE, 37° JIC, SWIVEL             | 100R13                    |
| H03                          | FEMALE, 37° JIC, SWIVEL            | 45°, FEMALE, 37° JIC, SWIVEL        | 100R17                    |
| H04                          | FEMALE, 37° JIC, SWIVEL            | 45°, FEMALE, 37° JIC, SWIVEL        | 100R13                    |
| H05                          | FEMALE, 37° JIC, SWIVEL            | LONG 90°, FEMALE, 37° JIC, SWIVEL   | 100R17                    |
| H06                          | FEMALE, 37° JIC, SWIVEL            | SHORT 90°, FEMALE, 37° JIC, SWIVEL  | 100R17                    |
| H07                          | LONG 90°, FEMALE, 37° JIC, SWIVEL  | LONG 90°, FEMALE, 37° JIC, SWIVEL   | 100R17                    |
| H08                          | FEMALE, 37° JIC, SWIVEL            | FEMALE, 37° JIC, SWIVEL             | 100R4                     |
| H09                          | FEMALE, 37° JIC, SWIVEL            | 45°, FEMALE, 37° JIC, SWIVEL        | 100R4                     |
| H10                          | FEMALE, 37° JIC, SWIVEL            | MALE PIPE THREAD FITTING            | 100R17                    |
| H11                          | FEMALE, 37° JIC, SWIVEL            | MEDIUM 90°, FEMALE, 37° JIC, SWIVEL | 100R13                    |
| H12                          | SHORT 90°, FEMALE, 37° JIC, SWIVEL | SHORT 90°, FEMALE, 37° JIC, SWIVEL  | 100R17                    |
| H13                          | FEMALE, 37° JIC, SWIVEL            | REUSABLE MALE PIPE THREAD FITTING   | 300 PSI                   |
| H14                          | REUSABLE MALE PIPE THREAD FITTING  | NO FITTING                          | 300 PSI                   |

| Hose Prefix | Hose End Fitting                     | Hose End Fitting                   | S.A.E. Hose Specification |
|-------------|--------------------------------------|------------------------------------|---------------------------|
| H15         | REUSABLE FEMALE, 37° JIC, SWIVEL     | REUSABLE FEMALE, 37° JIC, SWIVEL   | 300 PSI                   |
| H16         | NO FITTING                           | NO FITTING                         | 100R4                     |
| H17         | NO FITTING                           | NO FITTING                         | 300 PSI                   |
| H18         | REUSABLE, FEMALE, 37° JIC, SWIVEL    | NO FITTING                         | 300 PSI                   |
| H19         | LONG 90°, FEMALE, 37° JIC, SWIVEL    | FEMALE, 37° JIC, SWIVEL            | 100R13                    |
| H20         | FEMALE, SHORT 37° JIC, SWIVEL        | SHORT 90°, FEMALE, 37° JIC, SWIVEL | 100R4                     |
| H21         | FEMALE, SHORT 37° JIC, SWIVEL        | SHORT 90°, FEMALE, 37° JIC, SWIVEL | 100R2AT                   |
| H22         | FEMALE, 37° JIC, SWIVEL              | FEMALE, 37° JIC, SWIVEL            | 100R2AT                   |
| H23         | FEMALE, LONG 37° JIC, SWIVEL         | LONG 90°, FEMALE, 37° JIC, SWIVEL  | 100R2AT                   |
| H24         | FEMALE, SHORT 37° JIC, SWIVEL        | SHORT 90°, FEMALE, 37° JIC, SWIVEL | 100R13                    |
| H25         | FEMALE, 37° JIC, SWIVEL              | FEMALE, 37° JIC, SWIVEL            | 100R4                     |
| H30         | MEDIUM 90°, FEMALE, 37° JIC, SWIVEL  | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H31         | FEMALE, 37° JIC, SWIVEL              | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H32         | SHORT 45°, FEMALE, 37° JIC, SWIVEL   | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H33         | MEDIUM 45°, FEMALE, 37° JIC, SWIVEL  | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H34         | SHORT 90°, FEMALE, 37° JIC, SWIVEL   | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H35         | MEDIUM 90°, FEMALE, 37° JIC, SWIVEL  | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H36         | LONG 90°, FEMALE, 37° JIC, SWIVEL    | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H37         | SHORT 45°, FEMALE, 37° JIC, SWIVEL   | FEMALE, 37° JIC, SWIVEL            | 100R4                     |
| H38         | SHORT 90°, FEMALE, 37° JIC, SWIVEL   | FEMALE, 37° JIC, SWIVEL            | 100R4                     |
| H39         | LONG 90°, FEMALE, 37° JIC, SWIVEL    | FEMALE, 37° JIC, SWIVEL            | 100R4                     |
| H40         | SHORT 90°, FEMALE, 37° JIC, SWIVEL   | FEMALE, 37° JIC, SWIVEL            | 100R16                    |
| H43         | FEMALE, 37° JIC, SWIVEL              | FEMALE, 37° JIC, SWIVEL            | 100R16                    |
| H51         | FEMALE, 37° JIC, SWIVEL              | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H52         | SHORT 45°, FEMALE, 37° JIC, SWIVEL   | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H53         | MEDIUM 45°, FEMALE, 37° JIC, SWIVEL  | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H54         | SHORT 90°, FEMALE, 37° JIC, SWIVEL   | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H55         | MEDIUM 90°, FEMALE, 37° JIC, SWIVEL  | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H56         | LONG 90°, FEMALE, 37° JIC, SWIVEL    | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H57         | SHORT 45°, FEMALE, SAE ORFS, SWIVEL  | FEMALE, SAE ORFS, SWIVEL           | 100R13                    |
| H58         | FEMALE, SAE ORFS, SWIVEL             | FEMALE, SAE ORFS, SWIVEL           | 100R13                    |
| H59         | MEDIUM 90°, FEMALE, SAE ORFS, SWIVEL | FEMALE, SAE ORFS, SWIVEL           | 100R13                    |
| H60         | FEMALE, 37° JIC, SWIVEL              | FEMALE, 37° JIC, SWIVEL            | 100R17                    |
| H61         | FEMALE, 37° JIC, SWIVEL              | FEMALE, 37° JIC, SWIVEL            | 100R16                    |
| H62         | SHORT 90°, FEMALE, 37° JIC, SWIVEL   | FEMALE, 37° JIC, SWIVEL            | 100R16                    |
| H63         | MEDIUM 90°, FEMALE, 37° JIC, SWIVEL  | FEMALE, 37° JIC, SWIVEL            | 100R16                    |
| H64         | LONG 90°, FEMALE, 37° JIC, SWIVEL    | FEMALE, 37° JIC, SWIVEL            | 100R16                    |
| H65         | MEDIUM 67°, FEMALE, 37° JIC, SWIVEL  | FEMALE, 37° JIC, SWIVEL            | 100R12                    |
| H66         | FEMALE, 37° JIC, SWIVEL              | NO FITTING                         | 100R4                     |
| H67         | FEMALE, 37° JIC, SWIVEL              | FEMALE, 37° JIC, SWIVEL            | 100R19                    |
| H68         | SHORT 45°, FEMALE, 37° JIC, SWIVEL   | FEMALE, 37° JIC, SWIVEL            | 100R19                    |
| H69         | MEDIUM 90°, FEMALE, 37° JIC, SWIVEL  | FEMALE, 37° JIC, SWIVEL            | 100R19                    |
| H70         | LONG 90°, FEMALE, 37° JIC, SWIVEL    | FEMALE, 37° JIC, SWIVEL            | 100R19                    |
| H71         | LONG 90°, FEMALE, SAE ORFS, SWIVEL   | FEMALE, SAE ORFS, SWIVEL           | 100R15                    |

**Table 2.2 MEWP Torque Specifications**

| Location               | Description  | Torque (ft-lb) | Torque (Nm) |
|------------------------|--|----------------|-------------|
| <b>Base</b>            |  |                |             |
| Trunnion Mount         | BOLT, Hex head (3.4"-10 x 4.5", Grade 8)               | 210            | 285         |
| Rear Axle Mount        | BOLT, Hex head (M20 x 2.5 120mm, Grade 10.9)           | 210            | 285         |
| Oscillating Axle Mount | BOLT, Hex head (M20 x 2.5 120mm, Grade 10.9)           | 280            | 380         |
| Lockout Cylinder Pin   | BOLT, Hex head (3/8"-16 x 1", Grade 5)                 | 23             | 31          |
| Swing Drive Motor      | BOLT, Hex head (3/4"-10 x 2", Grade 8)                 | 280            | 380         |
| Rotation Gear          | BOLT, Hex head (3/4"-10 x 5", zinc, Grade 8)           | 280            | 380         |
| Hydraulic Drive Motor  | BOLT, Hex head (M14 x 2 x 30mm, ZP, Grade 8.8)         | 80             | 108         |
| Wheel Nut              | NUT, Wheel   | 247-302        | 335-410     |
| <b>Turret</b>          |  |                |             |
| Rotation Gear          | BOLT, Hex head (3/4"-10 x 4", zinc, Grade 8)           | 280            | 380         |
| <b>Engine</b>          |  |                |             |
| Deutz Engine Mount     | BOLT, Hex head (1/2"-13 x 3.75", Grade 5)              | 55             | 75          |
| Coupling Assembly      | BOLT (M10)   | 40             | 55          |
| Muffler                | NUT  | 40             | 55          |
| <b>Engine</b>          |  |                |             |
| Deutz Engine Mount     | BOLT, Hex head (1/2"-13 x 3.75", Grade 5)              | 55             | 75          |
| Coupling Assembly      | BOLT (M10)   | 40             | 55          |
| Muffler                | NUT  | 40             | 55          |
| <b>Cylinders</b>       |  |                |             |
| Jib                    | ROD NUT  | 347            | 470         |
| <b>Platform</b>        |  |                |             |
| Rotary Mount           | BOLT, Hex head, patch (3/8"-16 x 7/8", zinc, Grade 8)  | 35             | 48          |
|                        | BOLT, Hex head (1"-8 x 10.5", zinc, Grade 8)           | 480            | 569         |
| Rotary Manifold        | BOLT, Hex head (1/2"-13 x 2", Grade 8)                 | 80             | 108         |
| Rotary Actuator        | BOLT, Hex head (3/4"-10 x 3", Grade 8)                 | 210            | 285         |
| Load Cell Mounting     | BOLT, Hex head patch (ZP, M16 x 1.5 x 4.5", Grade 8.8) | 130            | 177         |
|                        | BOLT, Hex head (1/2"-13 x 2.25", Grade 8)              | 80             | 108         |
| <b>Special Options</b> |  |                |             |
| Generator Support      | BOLT, Hex head (1/2"-13 x 2", Grade 8)                 | 55             | 75          |
| Oil Cooler Support     | BOLT, Hex head (1/2"-13 x 2", Grade 8)                 | 55             | 75          |

1394AA

**Table 2.3 Axle Torque Specifications**

| Size of Bolt |            | Type of Bolt                   |                     |                                |                     |                                |                     |
|--------------|------------|--------------------------------|---------------------|--------------------------------|---------------------|--------------------------------|---------------------|
|              |            | 8.8                            |                     | 10.9                           |                     | 12.9                           |                     |
|              |            | Normali<br>Loctite 242<br>(Nm) | Loctite 270<br>(Nm) | Normali<br>Loctite 242<br>(Nm) | Loctite 270<br>(Nm) | Normali<br>Loctite 242<br>(Nm) | Loctite 270<br>(Nm) |
| Coarse Pitch | M6 x 1     | 9.5-10.5                       | 10.5-11.5           | 14.3-15.7                      | 15.2-16.8           | 16.2-17.8                      | 18.1-20.0           |
|              | M8 x 1.25  | 23.8-26.2                      | 25.6-28.4           | 34.2-37.8                      | 36.7-40.5           | 39.0-43.0                      | 43.7-48.3           |
|              | M10 x 1.5  | 48-53                          | 52-58               | 68-75                          | 73-81               | 80-88                          | 88-97               |
|              | M12 x 1.75 | 82-91                          | 90-100              | 116-128                        | 126-139             | 139-153                        | 152-168             |
|              | M14 x 2    | 129-143                        | 143-158             | 182-202                        | 200-221             | 221-244                        | 238-263             |
|              | M16 x 2    | 200-221                        | 219-242             | 283-312                        | 309-341             | 337-373                        | 371-410             |
|              | M18 x 2.5  | 276-305                        | 299-331             | 390-431                        | 428-473             | 466-515                        | 509-562             |
|              | M20 x 2.5  | 390-431                        | 428-473             | 553-611                        | 603-667             | 660-730                        | 722-798             |
|              | M22 x 2.5  | 523-578                        | 575-635             | 746-824                        | 817-903             | 893-987                        | 974-1076            |
|              | M24 x 3    | 675-746                        | 732-809             | 950-1050                       | 1040-1150           | 1140-1260                      | 1240-1370           |
|              | M27 x 3    | 998-1103                       | 1088-1202           | 1411-1559                      | 1539-1701           | 1710-1890                      | 1838-2032           |
| M30 x 3.5    | 1378-1523  | 1473-1628                      | 1914-2115           | 2085-2305                      | 2280-2520           | 2494-2757                      |                     |
| Fine Pitch   | M8 x 1     | 25.7-28.3                      | 27.5-30.5           | 36.2-39.8                      | 40.0-44.0           | 42.8-47.2                      | 47.5-52.5           |
|              | M10 x 1.25 | 49.4-54.6                      | 55.2-61.0           | 71.5-78.5                      | 78.0-86.0           | 86.0-94.0                      | 93.0-103.0          |
|              | M12 x 1.25 | 90-100                         | 98-109              | 128-142                        | 139-154             | 152-168                        | 166-184             |
|              | M12 x 1.5  | 86-95                          | 94-104              | 120-132                        | 133-147             | 143-158                        | 159-175             |
|              | M14 x 1.5  | 143-158                        | 157-173             | 200-222                        | 219-242             | 238-263                        | 261-289             |
|              | M16 x 1.5  | 214-236                        | 233-257             | 302-334                        | 333-368             | 361-399                        | 394-436             |
|              | M18 x 1.5  | 312-345                        | 342-378             | 442-489                        | 485-536             | 527-583                        | 580-641             |
|              | M20 x 1.5  | 437-483                        | 475-525             | 613-677                        | 674-745             | 736-814                        | 808-893             |
|              | M22 x 1.5  | 581-642                        | 637-704             | 822-908                        | 903-998             | 998-1103                       | 1078-1191           |
|              | M24 x 2    | 741-819                        | 808-893             | 1045-1155                      | 1140-1260           | 1235-1365                      | 1363-1507           |
|              | M27 x 2    | 1083-1197                      | 1178-1302           | 1520-1680                      | 1672-1848           | 1834-2027                      | 2000-2210           |
| M30 x 2      | 1511-1670  | 1648-1822                      | 2138-2363           | 2332-2577                      | 2565-2835           | 2788-3082                      |                     |

1373AA

Note: 1 Nm = 0.7376 ft-lb

Screw-locking, Sealing and Lubricating Materials

**Loctite 242**

- Anaerobic product apt to prevent the loosening of screws, nuts and plugs. Used for medium-strength locking. Before using it, completely remove any lubricant by using the specific activator.

**Loctite 270**

- Anaerobic product apt to prevent the loosening of screws, nuts and plugs. Used for medium-strength locking. Before using it, completely remove any lubricant by using the specific activator. To remove parts, it may be necessary to heat them at 80°C approx.

**Table 2.4 Torque Specifications for Fasteners (US)**

| Size    | Torque Type   | SAE2 |       | SAE 5 |       | SAE 8 |       |
|---------|---------------|------|-------|-------|-------|-------|-------|
|         |               | Dry  | Lubed | Dry   | Lubed | Dry   | Lubed |
| 4-40    | (in-lb)       | (5)  | (4)   | (8)   | (6)   | (12)  | (9)   |
|         | Nm            | 0.6  | 0.5   | 0.9   | 0.7   | 1.4   | 1.0   |
| 4-48    | (in-lb)       | (6)  | (5)   | (9)   | (7)   | (13)  | (10)  |
|         | Nm            | 0.7  | 0.6   | 1.0   | 0.8   | 1.5   | 1.1   |
| 6-32    | (in-lb)       | (10) | (8)   | (16)  | (12)  | (23)  | (17)  |
|         | Nm            | 1.1  | 0.9   | 1.8   | 1.4   | 2.6   | 1.9   |
| 6-40    | (in-lb)       | (12) | (9)   | (18)  | (13)  | (25)  | (19)  |
|         | Nm            | 1.4  | 1.0   | 2.0   | 1.5   | 2.8   | 2.1   |
| 8-32    | (in-lb)       | (19) | (14)  | (30)  | (22)  | (41)  | (31)  |
|         | Nm            | 2.1  | 1.6   | 3.4   | 2.5   | 4.6   | 3.5   |
| 8-36    | (in-lb)       | (20) | (15)  | (31)  | (23)  | (43)  | (32)  |
|         | Nm            | 2.3  | 1.7   | 3.5   | 2.6   | 4.9   | 3.6   |
| 10-24   | (in-lb)       | (27) | (21)  | (43)  | (32)  | (60)  | (45)  |
|         | Nm            | 3.1  | 2.4   | 4.9   | 3.6   | 6.8   | 5.1   |
| 10-32   | (in-lb)       | (31) | (23)  | (49)  | (36)  | (68)  | (51)  |
|         | Nm            | 3.5  | 2.6   | 5.5   | 4.1   | 7.7   | 5.8   |
| 1/4-20  | (in-lb) ft-lb | (66) | (50)  | 8     | (75)  | 12    | 9     |
|         | Nm            | 7.5  | 5.6   | 11    | 8.5   | 16    | 12    |
| 1/4-28  | (in-lb) ft-lb | (76) | (56)  | 10    | (86)  | 14    | 10    |
|         | Nm            | 8.6  | 6.3   | 14    | 9.7   | 19    | 14    |
| 5/16-18 | ft-lb         | 11   | 8     | 17    | 13    | 25    | 18    |
|         | Nm            | 15   | 11    | 23    | 18    | 34    | 24    |
| 5/16-24 | ft-lb         | 12   | 9     | 19    | 14    | 25    | 20    |
|         | Nm            | 16   | 12    | 26    | 19    | 34    | 27    |
| 3/8-16  | ft-lb         | 20   | 15    | 30    | 23    | 45    | 35    |
|         | Nm            | 27   | 20    | 41    | 31    | 61    | 47    |
| 3/8-24  | ft-lb         | 23   | 17    | 35    | 25    | 50    | 35    |
|         | Nm            | 31   | 23    | 47    | 34    | 68    | 47    |
| 7/16-14 | ft-lb         | 32   | 24    | 50    | 35    | 70    | 55    |
|         | Nm            | 43   | 33    | 68    | 47    | 95    | 75    |
| 7/16-20 | ft-lb         | 36   | 27    | 55    | 40    | 80    | 60    |
|         | Nm            | 49   | 37    | 75    | 54    | 108   | 81    |
| 1/2-13  | ft-lb         | 50   | 35    | 75    | 55    | 110   | 80    |
|         | Nm            | 68   | 47    | 102   | 75    | 149   | 108   |
| 1/2-20  | ft-lb         | 55   | 40    | 90    | 65    | 120   | 90    |
|         | Nm            | 75   | 54    | 122   | 88    | 163   | 122   |

| Size     | Torque Type | SAE2 |       | SAE 5 |       | SAE 8 |       |
|----------|-------------|------|-------|-------|-------|-------|-------|
|          |             | Dry  | Lubed | Dry   | Lubed | Dry   | Lubed |
| 9/16-12  | ft-lb       | 70   | 55    | 110   | 80    | 150   | 110   |
|          | Nm          | 95   | 75    | 149   | 108   | 203   | 149   |
| 9/16-18  | ft-lb       | 80   | 60    | 120   | 90    | 170   | 130   |
|          | Nm          | 108  | 81    | 163   | 122   | 230   | 176   |
| 5/8-11   | ft-lb       | 100  | 75    | 150   | 110   | 220   | 170   |
|          | Nm          | 136  | 102   | 203   | 149   | 298   | 230   |
| 5/8-18   | ft-lb       | 110  | 85    | 180   | 130   | 240   | 180   |
|          | Nm          | 149  | 115   | 244   | 176   | 325   | 244   |
| 3/4-10   | ft-lb       | 175  | 130   | 260   | 200   | 380   | 280   |
|          | Nm          | 237  | 176   | 353   | 271   | 515   | 380   |
| 3/4-16   | ft-lb       | 200  | 150   | 300   | 220   | 420   | 320   |
|          | Nm          | 271  | 203   | 407   | 298   | 569   | 434   |
| 7/8-9    | ft-lb       | 170  | 125   | 430   | 320   | 600   | 460   |
|          | Nm          | 230  | 169   | 583   | 434   | 813   | 624   |
| 7/8-14   | ft-lb       | 180  | 140   | 470   | 360   | 660   | 500   |
|          | Nm          | 244  | 190   | 637   | 488   | 895   | 678   |
| 1-8      | ft-lb       | 250  | 190   | 640   | 480   | 900   | 680   |
|          | Nm          | 339  | 258   | 868   | 651   | 1220  | 922   |
| 1-12     | ft-lb       | 270  | 210   | 710   | 530   | 1000  | 740   |
|          | Nm          | 366  | 285   | 963   | 719   | 1356  | 1003  |
| 1-14     | ft-lb       | 280  | 210   | 730   | 540   | 1020  | 760   |
|          | Nm          | 380  | 285   | 990   | 732   | 1383  | 1030  |
| 1 1/8-7  | ft-lb       | 350  | 270   | 800   | 600   | 1280  | 960   |
|          | Nm          | 475  | 366   | 1085  | 813   | 1735  | 1302  |
| 1 1/8-12 | ft-lb       | 400  | 300   | 880   | 660   | 1440  | 1080  |
|          | Nm          | 542  | 407   | 1193  | 895   | 1952  | 1464  |
| 1 1/4-7  | ft-lb       | 500  | 380   | 1120  | 840   | 1820  | 1360  |
|          | Nm          | 678  | 515   | 1519  | 1139  | 2468  | 1844  |
| 1 1/4-12 | ft-lb       | 550  | 420   | 1240  | 920   | 2000  | 1500  |
|          | Nm          | 746  | 569   | 1681  | 1247  | 2712  | 2034  |
| 1 3/8-6  | ft-lb       | 670  | 490   | 1460  | 1100  | 2380  | 1780  |
|          | Nm          | 908  | 664   | 1979  | 1491  | 3227  | 2413  |
| 1 3/8-12 | ft-lb       | 750  | 560   | 1680  | 1260  | 2720  | 2040  |
|          | Nm          | 1017 | 759   | 2278  | 1708  | 3688  | 2766  |
| 1 1/2-6  | ft-lb       | 870  | 650   | 1940  | 1460  | 3160  | 2360  |
|          | Nm          | 1180 | 881   | 2630  | 1979  | 4284  | 3200  |
| 1 1/2-12 | ft-lb       | 980  | 730   | 2200  | 1640  | 3560  | 2660  |
|          | Nm          | 1329 | 990   | 2983  | 2224  | 4827  | 3606  |

**NOTE:** Lubed includes lubricants such as lubrizing, oil, grease, or uncured Loctite.

1374AA

**Table 2.5 Torque Specifications for Fasteners (Metric)**

| Size       | Torque Type | SAE 2 |       | SAE 5 |       | SAE 8 |       |
|------------|-------------|-------|-------|-------|-------|-------|-------|
|            |             | Dry   | Lubed | Dry   | Lubed | Dry   | Lubed |
| M5 x 0.80  | (in-lb)     | (54)  | (41)  | (78)  | (59)  | (12)  | (9)   |
|            | Nm          | 6.1   | 4.6   | 8.8   | 6.7   | 1.4   | 1.0   |
| M6 x 1.00  | (in-lb)     | (92)  | (69)  | (133) | (99)  | (13)  | (10)  |
|            | Nm          | 10.4  | 7.8   | 15    | 11.2  | 1.5   | 1.1   |
| M7 x 1.00  | (in-lb)     | (156) | (116) | (222) | (167) | (23)  | (17)  |
|            | Nm          | 17.6  | 13.1  | 25.1  | 18.9  | 2.6   | 1.9   |
| M8 x 1.25  | (in-lb)     | (225) | (169) | (333) | (242) | (25)  | (19)  |
|            | Nm          | 25.4  | 19.1  | 37.6  | 27.3  | 2.8   | 2.1   |
| M10 x 1.50 | ft-lb       | 37    | 28    | 53    | 40    | (41)  | (31)  |
|            | Nm          | 50    | 38    | 72    | 54    | 4.6   | 3.5   |
| M12 x 1.75 | ft-lb       | 65    | 49    | 93    | 69    | (43)  | (32)  |
|            | Nm          | 88    | 66    | 126   | 94    | 4.9   | 3.6   |
| M14 x 2.00 | ft-lb       | 104   | 78    | 148   | 111   | (60)  | (45)  |
|            | Nm          | 141   | 106   | 201   | 150   | 6.8   | 5.1   |
| M16 x 2.00 | ft-lb       | 161   | 121   | 230   | 172   | (68)  | (51)  |
|            | Nm          | 218   | 164   | 312   | 233   | 7.7   | 5.8   |
| M18 x 2.50 | ft-lb       | 222   | 167   | 318   | 238   | 12    | 9     |
|            | Nm          | 301   | 226   | 431   | 323   | 16    | 12    |
| M20 x 2.50 | ft-lb       | 314   | 235   | 449   | 337   | 14    | 10    |
|            | Nm          | 426   | 319   | 609   | 457   | 19    | 14    |
| M22 x 2.50 | ft-lb       | 428   | 321   | 613   | 460   | 25    | 18    |
|            | Nm          | 580   | 435   | 831   | 624   | 34    | 24    |
| M24 x 3.00 | ft-lb       | 543   | 407   | 776   | 582   | 25    | 20    |
|            | Nm          | 736   | 552   | 1052  | 789   | 34    | 27    |
| M27 x 3.00 | ft-lb       | 796   | 597   | 1139  | 854   | 45    | 35    |
|            | Nm          | 1079  | 809   | 1544  | 1158  | 61    | 47    |
| M30 x 3.50 | ft-lb       | 1079  | 809   | 1543  | 1158  | 50    | 35    |
|            | Nm          | 1463  | 1097  | 2092  | 1570  | 68    | 47    |
| M33 x 3.50 | ft-lb       | 1468  | 1101  | 2101  | 1576  | 70    | 55    |
|            | Nm          | 1990  | 1493  | 2849  | 2137  | 95    | 75    |
| M36 x 4.00 | ft-lb       | 1886  | 1415  | 2699  | 2024  | 80    | 60    |
|            | Nm          | 2557  | 1918  | 3659  | 2744  | 108   | 81    |

**NOTE:** Lubed includes lubricants such as lubricizing, oil, grease, or uncured Loctite.

1375AA

**Table 2.6 Torque Specifications for Hydraulic Couplings & Hoses**

| <b>Hydraulic Coupling Torque Chart<br/>O-Ring Port Connectors</b> |                    |           |                          |           |
|---|--------------------|-----------|--------------------------|-----------|
| <b>SAE Size</b>   | <b>Steel Ports</b> |           | <b>Non-ferrous Ports</b> |           |
|   | <b>ft-lb</b>       | <b>Nm</b> | <b>ft-lb</b>             | <b>Nm</b> |
| 4   | 14-16              | 20-22     | 9-10                     | 12-13     |
| 6   | 24-26              | 33-35     | 15-16                    | 20-21     |
| 8   | 50-60              | 68-78     | 30-36                    | 41-47     |
| 10  | 72-80              | 98-110    | 43-48                    | 60-66     |
| 12  | 125-135            | 170-183   | 75-81                    | 102-110   |
| 16  | 200-220            | 270-300   | 120-132                  | 162-180   |
| 20  | 210-280            | 285-380   | 126-168                  | 171-228   |
| 24  | 270-360            | 370-490   | 162-216                  | 222-294   |
| 32  | -                  | -         | -                        | -         |

| <b>Hose End Torque Chart<br/>for JIC</b> |              |              |             |             |             |              |             |             |             |
|--|--------------|--------------|-------------|-------------|-------------|--------------|-------------|-------------|-------------|
| <b>Size</b>                              |              | <b>Steel</b> |             |             |             | <b>Brass</b> |             |             |             |
| <b>Dash</b>                              | <b>Frac.</b> | <b>ft-lb</b> |             | <b>Nm</b>   |             | <b>ft-lb</b> |             | <b>Nm</b>   |             |
|  |              | <b>Min.</b>  | <b>Max.</b> | <b>Min.</b> | <b>Max.</b> | <b>Min.</b>  | <b>Max.</b> | <b>Min.</b> | <b>Max.</b> |
| -4                                       | 1/4"         | 10           | 11          | 13          | 15          | 5            | 6           | 6.75        | 9           |
| -6                                       | 3/8"         | 17           | 19          | 23          | 26          | 12           | 15          | 17          | 20          |
| -8                                       | 1/2"         | 34           | 38          | 47          | 52          | 20           | 24          | 27.66       | 33          |
| -10                                      | 5/8"         | 50           | 56          | 69          | 76          | 34           | 40          | 46.33       | 55          |
| -12                                      | 3/4"         | 70           | 78          | 96          | 106         | 53           | 60          | 72.33       | 82          |
| -16                                      | 1"           | 94           | 104         | 127         | 141         | 74           | 82          | 100.5       | 111         |
| -20                                      | 1 1/4"       | 124          | 138         | 169         | 188         | 75           | 83          | 101.5       | 113         |
| -24                                      | 1 1/2"       | 156          | 173         | 212         | 235         | 79           | 87          | 107         | 118         |
| -32                                      | 2"           | 219          | 243         | 296         | 329         | 158          | 175         | 214         | 237         |

| <b>Hose End Torque Chart<br/>for Flat-Face O-Ring Seal (Steel)</b> |              |                             |             |             |             |
|--|--------------|-----------------------------|-------------|-------------|-------------|
| <b>Size</b>  |              | <b>Torque Specification</b> |             |             |             |
| <b>Dash</b>  | <b>Frac.</b> | <b>ft-lb</b>                |             | <b>Nm</b>   |             |
|  |              | <b>Min.</b>                 | <b>Max.</b> | <b>Min.</b> | <b>Max.</b> |
| -4   | 1/4"         | 10                          | 12          | 14          | 16          |
| -6   | 3/8"         | 18                          | 20          | 24          | 27          |
| -8   | 1/2"         | 32                          | 40          | 43          | 54          |
| -10  | 5/8"         | 46                          | 56          | 60          | 75          |
| -12  | 3/4"         | 65                          | 80          | 90          | 110         |
| -14  | 1"           | 65                          | 80          | 90          | 110         |
| -16  | 1 1/4"       | 92                          | 105         | 125         | 240         |
| -20  | 1 1/2"       | 125                         | 140         | 170         | 190         |
| -24  | 2"           | 150                         | 180         | 200         | 245         |

1276AA

**Table 2.7 Axles Maintenance Intervals**

| Operation    | Component                      | Frequency                               | Lubricants          |
|--------------|--------------------------------|---|---------------------|
| Check Levels | Differential                   | monthly                                 | SAE 80W-90 API GL-5 |
|              | Planetary reduction            | every 200 hours                         |                     |
|              | Gear box                       | monthly                                 |                     |
| Oil Change   | Differential                   | every 800 hours *                       | SAE 80W-90 API GL-5 |
|              | Planetary reduction            | every 1000 hours *                      |                     |
|              | Self-locking differential gear | every 700 hours * &                     |                     |
|              | Gear box                       | once at 50 hours after every 1000 hours |                     |
| Tighten      | Gear box screws/bolts          | every 200 hours                         | N/A                 |
|              | Wheel Nuts                     | every 200 hours                         |                     |

| Operation | Member        | Conditions   | Frequency | Lubricants |
|-----------|---------------|--------------|-----------|------------|
| Grease    | Articulations | Normal work  | monthly   | MOLIKOTE   |
|           |               | Awkward work | weekly    |            |

| Torque Wrench Settings (Nm) |        |          |          |
|-----------------------------|--------|----------|----------|
| Size of Screw               | 8G/8.8 | 10K/10.9 | 12K/12.9 |
| M4                          | 2.9    | 4.1      | -        |
| M6                          | 10     | 14       | -        |
| M8                          | 25     | 35       | -        |
| M12                         | 49     | 69       | -        |
| M10 X 1.25                  | -      | 73       | -        |
| M12                         | 86     | 120      | -        |
| M14                         | 135    | 190      | -        |
| M14 X 1.5                   | -      | -        | 250      |
| M16                         | 210    | 295      | -        |
| A18                         | 325    | -        | -        |

\*Initially after 100 working hours  
& when it starts sounding noisy

1376AB



**NOTE**

1 Nm = 0.7376 ft-lb



**Table 2.8 Tire Specifications**

|                          | <b>SJ82T/86T</b>                       |
|--------------------------|--|
| <b>Tire Size</b>         | Outrigger R4 18-625                    |
|                          | 18.71" x 41.16" (47.52 cm x 104.55 cm) |
| <b>Pressure</b>          | Foam-filled                            |
| <b>Tire Ply Rating</b>   | 16                                     |
| <b>Wheel Nuts Torque</b> | 275 ft-lb (373 Nm)                     |

1395AA

**⚠ WARNING**

Do not use tires other than those specified for this machine. Do not mix different types of tires. Tires other than those specified can adversely affect stability. Failure to operate with matched, approved tires in good condition can result in death or serious injury. Replace tires with the exact, Skyjack-approved types only.

**⚠ IMPORTANT**

For proper function of each axle differential, all four wheels must have same tire size installed at all times. Failure to comply with this requirement will reduce the life of the differentials and reduce overall mobility of aerial platform. Sample warning text.

**Table 2.9 Floor Loading Pressure**

| Model          | Weight |        | Total Aerial Platform Load |      |     |      |     |      |
|----------------|--------|--------|----------------------------|------|-----|------|-----|------|
|                |        |        | Wheel                      |      | LCP |      | OUP |      |
|                | lb     | kg     | lb                         | kg   | psi | kPa  | psf | kPa  |
| SJ82T ANSI/CSA | 37,600 | 17 055 | 17,850                     | 8097 | 175 | 1207 | 325 | 15.6 |
| SJ86T ANSI/CSA | 37,800 | 17 145 | 17,850                     | 8097 | 175 | 1207 | 330 | 15.8 |
| SJ86T CE & AS  | 38,691 | 17 550 | 17,857                     | 8100 | 175 | 1210 | 334 | 16   |

2054AA

- Gross Aerial Platform Weight = Weight + platform capacity
- LCP – Locally Concentrated Pressure – is a measure of how hard the aerial platform tire tread presses on the area in direct contact with the floor. The floor covering (tile, carpet, etc.) must be able to withstand more than the indicated values above.
- OUP – Overall Uniform Pressure – is a measure of the average load the aerial platform imparts on the whole surface projected directly underneath it. The structure of the operating surface (beams, etc.) must be able to withstand more than the indicated values above.
- The welder option will add approximately 350 lb (158.8 kg) to total aerial platform weight and 175 lb (79.4 kg) to max. wheel load.


**NOTE:**

The LCP or OUP that an individual surface can withstand varies from structure to structure and is generally determined by the engineer or architect for that particular structure.


**Locally Concentrated Pressure (LCP)**

Foot Print Area identified by test

$$LCP = \frac{\text{Wheel Load}}{\text{Foot Print Area}}$$





Foot Print Area



**Overall Uniform Pressure (OUP)**

Base Area = Length x Width

$$OUP = \frac{\text{Weight of MEWP} + \text{Capacity}}{\text{Base Area}}$$



**Table 2.10 Hydraulic Specifications & Gear Oil**

| Description                      |                                | US  | Metric                  |
|----------------------------------|--------------------------------|---|-------------------------|
| <b>Pumps</b>                     |                                |   |                         |
| Drive Pump                       | Displacement                   | 2.48 in <sup>3</sup> /r<br>37 gpm @ 3600 rpm          | 40.6 cm <sup>3</sup> /r |
|                                  | Drive Pump Pressure            | 3000 psi  | 207 bar                 |
|                                  | Charge Pump Displacement       | 0.84 in <sup>3</sup> /r                               | 13.8 cm <sup>3</sup> /r |
|                                  | Charge Pump Pressure           | 300 - 320 psi   | 20.68 - 22.41 bar       |
| System Pump                      | Displacement - Static          | 3.00 in <sup>3</sup> /r                               | 49.2 cm <sup>3</sup> /r |
|                                  | System Pump Pressure           | 3050 psi  | 210 bar                 |
| <b>Filters</b>                   |                                |   |                         |
| High Pressure Filter             | Max. Operating Pressure        | 4000 psi  | 276 bar                 |
| Return Filter                    | Max. Operating Pressure        | 120 psi   | 8 bar                   |
| <b>Motors</b>                    |                                |   |                         |
| Drive Motor                      | Displacement - Low             | 0.90 in <sup>3</sup> /r                               | 14.7 cm <sup>3</sup> /r |
|                                  | Displacement - High            | 2.48 in <sup>3</sup> /r                               | 40.6 cm <sup>3</sup> /r |
| Swing Motor                      | Motor Displacement             | 6.1 in <sup>3</sup> /r                                | 100 cm <sup>3</sup> /r  |
|                                  | Maximum Operating Pressure     | 3000 psi  | 206.8 bar               |
| <b>Cylinders</b>                 |                                |   |                         |
| Extension Cylinder               | Bore                           | 3.93 in   | 9.98 cm                 |
|                                  | Rod Diameter                   | 2.95 in   | 7.493 cm                |
|                                  | Stroke                         | 255 in  | 64.77 m                 |
|                                  | Maximum Boom Pressure          | 3000 psi  | 207 bar                 |
| Lift Cylinder                    | Bore                           | 7.48 in   | 19 cm                   |
|                                  | Rod Diameter                   | 3.93 in   | 9.98 in                 |
|                                  | Stroke                         | 84.06 in  | 2.13 m                  |
|                                  | Maximum Lift Pressure          | 3000 psi  | 207 bar                 |
| Steering Cylinder                | Bore                           | 3.06 in   | 7.77 cm                 |
|                                  | Stroke                         | 4.31 in   | 10.94 cm                |
| <b>Hydraulic &amp; Gear Oils</b> |                                |   |                         |
| Hydraulic Oil Cooler Option      | 100°F to 115°F (38°C to 45°C)  | Oil cooler option recommended                         |                         |
| Standard Hydraulic Oil           | -15°F to 100°F (-26°C to 38°C) | Shell Tellus T46, Petro-Canada Hydrex MV46            |                         |
| Arctic Hydraulic Oil             | -40°F to 100°F (-40°C to 38°C) | Esso/Mobil UNIVIS HVI 26, Petro-Canada Hydrex Extreme |                         |
| Biodegradable Hydraulic Oil      | -20°F to 90°F (-29°C to 32°C)  | Shell Naturelle HF-E 46                               |                         |
| Hydraulic Tank Capacity          |                                | 59 gal (223.3 L)                                      |                         |
| Standard Gear Oil                | -20°F to 115°F (-29°C to 45°C) | SAE 80W-90 API GL5                                    |                         |
| Arctic Gear Oil                  | -40°F to 115°F (-40°C to 45°C) | Durafran XL Synthetic Oil                             |                         |
| Gear Oil Capacity                |                                | 10 gal (38 L)   |                         |

\*For other component specifications, refer to the hydraulic schematic.

1397AB

**Table 2.11 Specifications & Features - Dimensional Data**

|                                    | <b>SJ82 T ANSI/CSA</b> | <b>SJ86 T ANSI/CSA</b> | <b>SJ86 T CE</b> | <b>SJ86 T AS</b> |               |               |
|------------------------------------|------------------------|------------------------|------------------|------------------|---------------|---------------|
| <b>Height &amp; Reach</b>          |                        |                        |                  |                  |               |               |
| Working Height - Maximum           | 26.82 m                | 88'                    | 28.04 m          | 92'              | 28.04 m       | 28.04 m       |
| Platform Height - Maximum          | 24.99 m                | 82'                    | 26.21 m          | 86'              | 26.21 m       | 26.21 m       |
| Horizontal Reach - Maximum         | 22.1 m                 | 72' 6"                 | 23.41 m          | 76' 10"          | 23.41 m       | 23.41 m       |
| Horizontal Reach at Maximum Height | 8.15 m                 | 26' 8"                 | 8.61 m           | 28' 3"           | 8.61 m        | 8.61 m        |
| Tailswing                          | 1.52 m                 | 60"                    | 1.52 m           | 60"              | 1.52 m        | 1.52 m        |
| <b>Platform</b>                    |                        |                        |                  |                  |               |               |
| Platform Size                      | 0.9 x 2.4 m            | 36" x 96"              | 0.9 x 2.4 m      | 36" x 96"        | 0.91 x 2.44 m | 0.91 x 2.44 m |
|                                    | 0.9 x 1.8 m            | 36" x 72"              | 0.9 x 1.8 m      | 36" x 72"        | 0.91 x 1.83 m | 0.91 x 1.83 m |
| Platform Rotation                  | 170°                   | 170°                   | 170°             | 170°             | 170°          | 170°          |
| Platform Rotation Radius           | 1.61 m                 | 63-3/4"                | 1.62 m           | 64"              | 1.62 m        | 1.62 m        |
| Platform Height - Stowed           | 0.48 m                 | 19"                    | 0.48 m           | 19"              | 0.28 m        | 0.28 m        |
| Overall Railing Height             | 1.34 m                 | 52-3/4"                | 1.34 m           | 52-3/4"          | 1.35 m        | 1.35 m        |
| Platform Railing Height            | 1.09 m                 | 43"                    | 1.09 m           | 43"              | 1.12 m        | 1.12 m        |
| <b>Dimensional Data</b>            |                        |                        |                  |                  |               |               |
| Height Stowed                      | 2.59 m                 | 8'-6"                  | 2.59 m           | 8'-6"            | 3 m           | 3 m           |
| Length Stowed                      | 11.52 m                | 37' 10"                | 12.34 m          | 40' 6"           | 12.95 m       | 12.95 m       |
| Width                              | 2.44 m                 | 8'                     | 2.44 m           | 8'               | 2.49 m        | 2.49 m        |
| Wheelbase                          | 3.35 m                 | 11'                    | 3.35 m           | 11'              | 3.35 m        | 3.35 m        |
| Ground Clearance - Chassis         | 0.41 m                 | 16"                    | 0.43 m           | 17"              | 0.4 m         | 0.4 m         |
| Ground Clearance - Front Axle      | 0.34 m                 | 13-1/4"                | 0.36 m           | 14-1/4"          | 0.34 m        | 0.34 m        |
| Axle Oscillation                   | 0.04 m                 | 1-3/4"                 | 0.04 m           | 1-3/4"           | 1-3/4"        | 1-3/4"        |
| Inside Turning Radius              | 6.10 m                 | 19' 11"                | 6.20 m           | 20' 5"           | 6.20 m        | 6.20 m        |
| Outside Turning Radius             | 7.18 m                 | 23' 7"                 | 7.20 m           | 23' 7"           | 7.20 m        | 7.20 m        |
| Turret Rotation                    | 360°                   | 360°                   | 360°             | 360°             | 360°          | 360°          |
| <b>Weight</b>                      |                        |                        |                  |                  |               |               |
| Weight                             | 17 055 kg              | 37,600 lb              | 17 145 kg        | 37,800 lb        | 17 550 kg     | 17 550 kg     |

2040AA

**Table 2.12 Specifications & Features - Performance and Speeds**

|                                    | SJ82 T ANSI/CSA |              | SJ86 T ANSI/CSA, CE, AS |              |
|------------------------------------|-----------------|--------------|-------------------------|--------------|
| <b>Performance &amp; Speeds</b>    |                 |              |                         |              |
| Gradeability - Maximum             | 45%             |              | 45%                     |              |
| Drive Speed - Stowed/Low Torque    | 4.8 km/h        | 3.0 mph      | 4.8 km/h                | 3.0 mph      |
| Drive Speed - Stowed/High Torque   | 1.9 km/h        | 1.2 mph      | 1.9 km/h                | 1.2 mph      |
| Drive Speed - Elevated/Low Torque  | 0.8 km/h        | 0.5 mph      | 0.8 km/h                | 0.5 mph      |
| Drive Speed - Elevated/High Torque | 0.8 km/h        | 0.5 mph      | 0.8 km/h                | 0.5 mph      |
| Turret Rotation Time - Stowed      | 95-130 seconds  |              | 95-130 seconds          |              |
| Turret Rotation Time - Extended    | 190-220 seconds |              | 190-220 seconds         |              |
| Platform Rotation Time             | 10-20 seconds   |              | 10-20 seconds           |              |
| Boom Up Time                       | 90-100 seconds  |              | 90-100 seconds          |              |
| Boom Down Time                     | 90-100 seconds  |              | 90-100 seconds          |              |
| Boom Extend Time                   | 60-70 seconds   |              | 60-70 seconds           |              |
| Boom Retract Time                  | 60-70 seconds   |              | 60-70 seconds           |              |
| Jib Up Time                        | N/A             |              | 18-28 seconds           |              |
| Jib Down Time                      | N/A             |              | 10-16 seconds           |              |
| Steer Left Time                    | 5-8 seconds     |              | 5-8 seconds             |              |
| Steer Right Time                   | 5-8 seconds     |              | 5-8 seconds             |              |
| <b>Lift Capacity</b>               |                 |              |                         |              |
| Lift Capacity                      | 227 / 340 kg    | 500 / 750 lb | 227 / 340 kg            | 500 / 750 lb |
| Maximum Number of Persons          | 2 / 3           |              | 2 / 3                   |              |
| <b>Electrical</b>                  |                 |              |                         |              |
| System Voltage                     | 12 V DC         |              | 12 V DC                 |              |
| Battery Type                       | Lead/Acid       |              | Lead/Acid               |              |

2040AA-1

**Table 2.13 Engine Specifications**


|                        |                                      | <b>SJ82T/SJ86T</b>             |                                  |
|------------------------|--------------------------------------|--------------------------------|----------------------------------|
| <b>Deutz TD2.9L</b>    | RPM Settings                         | 900 Low / 1600 / 2600 High     |                                  |
|                        | Horsepower @ 2600 rpm (intermittent) | 55.4 kW / 75 hp                |                                  |
|                        | Fuel Type                            | Diesel                         |                                  |
|                        | Fuel Tank Capacity                   | 45 gal (170.3 L)               |                                  |
|                        | Standard Oil Factory Fill            | 0°F to 115°F (-18°C to 45°C)   | SAE 15W-40 API CF/CG/CH-6        |
|                        | Cold Lube Oil Option                 | -20°F to 90°F (-29°C to 32°C)  | SAE 5W-30 API CF/CG/CH-6         |
|                        | Arctic Lube Oil Option               | -40°F to 115°F (-40°C to 45°C) | SAE 0W-40 API CF/CG/CH-6         |
|                        | Standard & Arctic Coolant            | -40°F to 115°F (-40°C to 45°C) | Delo 50/50 Extended Life Coolant |
|                        | Coolant Capacity                     | 3.0 gal (11.4 L)               |                                  |
|                        | Lube Oil Sump Capacity               | 2.64 gal (10.0 L)              |                                  |
| <b>Deutz TCD2.2</b>    | RPM Settings                         | 1200 Low / 1600 / 2600 High    |                                  |
|                        | Horsepower @ 2600 rpm (intermittent) | 55.4 kW / 75 hp                |                                  |
|                        | Fuel Type                            | Diesel                         |                                  |
|                        | Fuel Tank Capacity                   | 45 gal (170.3 L)               |                                  |
|                        | Standard Oil Factory Fill            | 0°F to 115°F (-18°C to 45°C)   | SAE 15W-40 API CF/CG/CH-6        |
|                        | Standard Coolant                     | -40°F to 115°F (-40°C to 45°C) | Delo 50/50 Extended Life Coolant |
|                        | Coolant Capacity                     | 3.0 gal (11.4 L)               |                                  |
|                        | Lube Oil Sump Capacity               | 2.11 gal (8.0 L)               |                                  |
| <b>Deutz D2011L04i</b> | RPM Settings                         | 1600 Low / 2100 / 2675 High    |                                  |
|                        | Horsepower @ 2600 rpm (intermittent) | 48 kW / 65 hp                  |                                  |
|                        | Fuel Type                            | Diesel                         |                                  |
|                        | Fuel Tank Capacity                   | 45 gal (170.3 L)               |                                  |
|                        | Standard Oil Factory Fill            | 0°F to 115°F (-18°C to 45°C)   | SAE 15W-40 API CF/CG/CH-6        |
|                        | Cold Lube Oil Option                 | -20°F to 90°F (-29°C to 32°C)  | SAE 5W-30 API CF/CG/CH-6         |
|                        | Arctic Lube Oil Option               | -40°F to 115°F (-40°C to 45°C) | SAE 0W-40 API CF/CG/CH-6         |
|                        | Lube Oil Sump Capacity               | 2.64 gal (10.0 L)              |                                  |

1399AB-1

### Table 2.14 Axle Oscillation Diagrams


**⚠ WARNING**

Do not raise the platform in work mode if it is not on a firm level surface.



- Axle oscillation free (travel mode) - drive speed 3.0 mph (4.8 km/h) max
- ▨ Axle oscillation locked (work mode) - drive speed 0.5 mph (0.8 km/h) max

**Axle Oscillation - SJ82 T**




- Axle oscillation free (travel mode) - drive speed 3.0 mph (4.8 km/h) max
- ▨ Axle oscillation locked (work mode) - drive speed 0.5 mph (0.8 km/h) max

**Axle Oscillation - SJ86 T**




# Diagram 2.15 Dimension and Reach Diagram - SJ82 T

Feet (meters)



# Diagram 2.16 Dimension and Reach Diagram - SJ86 T









































---










































## Section 3 – System Component Identification and Schematics

To order go to [Discount-Equipment.com](http://Discount-Equipment.com)

**Table 3.1 Electrical Symbol Chart**

|   |   |  |  |
|---|---|--|--|
|  CIRCUIITS CROSSING<br>NO CONNECTION |  HOURMETER                               |  KEY SWITCH                             |  LIMIT SWITCH                       |
|  CIRCUIITS<br>CONNECTED              |  LIGHT                                   |  FOOT SWITCH                            |  CAM OPERATED<br>LIMIT SWITCH       |
|  BATTERY                             |  HYDRAULIC<br>VALVE COIL                 |  TOGGLE SWITCH                          |  LIMIT SWITCH<br>N.O.               |
|  GROUND                              |  PROPORTIONAL<br>HYDRAULIC<br>VALVE COIL |  ANGLE<br>TRANSDUCER<br>& TILT SWITCH   |  LIMIT SWITCH<br>N.O HELD<br>CLOSED |
|  FUSE                                |  ELECTRIC<br>MOTOR                       |  TEMPERATURE<br>SWITCH                  |  LIMIT SWITCH<br>N.C.               |
|  CIRCUIT<br>BREAKER                |  HORN                                  |  SINGLE POLE<br>SINGLE THROW<br>RELAY |  LIMIT SWITCH<br>N.C HELD OPEN    |
|  VOLT METER                        |  PUSH BUTTON                           |  SINGLE POLE<br>DOUBLE THROW<br>RELAY |  BEEPER                           |
|  CAPACITOR                         |  ROTARY SWITCH                         |  DOUBLE POLE<br>DOUBLE THROW<br>RELAY |  DIODE                            |
|  POTENTIOMETER                     |  EMERGENCY<br>STOP BUTTON              |  DOUBLE POLE<br>SINGLE THROW<br>RELAY |  |
|  RESISTOR                          |  RHEOSTAT                              |  TRIPLE POLE<br>DOUBLE THROW<br>RELAY |  |
|   |   |  |  |

**Table 3.2 Hydraulic Symbol Chart**

|   |  |   |   |
|---|--|---|---|
|  LINE CROSSING                           |  FIXED DISPLACEMENT PUMP    |  SHUTTLE VALVE                                       |  THREE POSITION FOUR WAY CLOSED CENTER OPEN PORT |
|  LINE JOINED                             |  VARIABLE DISPLACEMENT PUMP |  PRESSURE SWITCH                                     |  CUSHION CYLINDER                                |
|  MAIN LINES Solid                        |  HAND PUMP                  |  MOTION CONTROL VALVE                                |  DOUBLE ACTING CYLINDER                          |
|  PILOT LINES Dashed                      |  OIL COOLER                 |  FLOW DIVIDER COMBINER                               |  DOUBLE ACTING DOUBLE RODDED CYLINDER            |
|  HYDRAULIC TANK                          |  VELOCITY FUSE              |  COUNTER BALANCE VALVE                               |  BRAKE CYLINDER                                  |
|  HYDRAULIC FILTER WITH BYPASS          |  RELIEF VALVE             |  VALVE COIL  |  SPRING APPLIED HYDRAULIC RELEASED BRAKE       |
|  ELECTRIC MOTOR                        |  PRESSURE REDUCING VALVE  |  TWO POSITION TWO WAY NORMALLY OPEN VALVE          |  ROTARY ACTUATOR                               |
|  ENGINE                                |  PRESSURE TRANSDUCER      |  TWO POSITION TWO WAY NORMALLY CLOSED VALVE        |  SERVO   |
|  BI DIRECTIONAL HYDRAULIC MOTOR        |  FIXED ORIFICE            |  TWO POSITION THREE WAY VALVE                      |   |
|  VARIABLE DISPLACEMENT HYDRAULIC MOTOR |  ADJUSTABLE FLOW CONTROL  |  TWO POSITION THREE WAY VALVE                      |   |
|  SERIES PARALLEL HYDRAULIC MOTOR       |  CHECK VALVE              |  THREE POSITION FOUR WAY CLOSED CENTER CLOSED PORT |   |

### 3.3 Wire Number and Color Code

| WIRE NO. | WIRE COLOR  | WIRE NO. | WIRE COLOR  | WIRE NO. | WIRE COLOR | WIRE NO. | WIRE COLOR  | WIRE NO. | WIRE COLOR |
|----------|-------------|----------|-------------|----------|------------|----------|-------------|----------|------------|
| 00       | WHT         | 20       | ORG/BLU     | 44       | YEL/WHT    | 67       | ORG/BRN     | 92       | GRN SHLD   |
| 000      | WHT         | 21       | WHT/RED     | 45       | YEL/ORG    | 68       | GREY        | 93       | BLK SHLD   |
| B1       | BLU/PINK    | 23       | BLK/WHT     | 46       | RED/BLK    | 69       | WHT/GRN     | 95       | YEL/GREY   |
| 01       | PUR/BLK     | 24       | BLU/BLK     | 47       | PUR/ORG    | 70       | ORG/PINK    | 96       | WHT/GREY   |
| 02       | WHT         | 25       | BRN/BLK     | 48       | YEL/GREY   | 71       | RED/ORG     | 97       | ORG/GREY   |
| 03       | GRN/PUR     | 26       | BLU/YEL     | 49       | GRN/RED    | 72       | RED/BRN     | 98       | RED SHLD   |
| 04       | RED/YEL     | 27       | RED/BLK/WHT | 50       | BRN        | 73       | RED/PINK    | 98A      | BLK SHLD   |
| 05       | PUR         | 28       | GRN         | 51       | BLK/GRN    | 74       | GRN/GREY    | 99       | BLK/GREY   |
| 06       |             | 29       | GREY/ORG    | 52       | GRN/BLU    | 75       | GREY/PUR    | 103      | BLK/PUR    |
| 07       | RED         | 30       | RED/GRN     | 53       | BRN/RED    | 76       | BRN/BLU     | 104      | GRN/ORG    |
| 08       | PUR/WHT     | 31       | RED/WHT     | 54       | PUR/RED    | 77       | BRN/GREY    | 105      | GRN/BRN    |
| 09       | YEL         | 32       | GRN/BLK     | 55       | YEL/PUR    | 78       | RED/BLU     | 106      | GRN/PINK   |
| 10       | BLU/WHT     | 33       | GRN/WHT     | 56       | YEL/BLK    | 79       | BRN/PUR     | 107      | BLK/BLU    |
| 11       | WHT/ORG     | 34       | ORG/BLK     | 57       | BRN/GRN    | 80       | GREY/WHT    | 108      | YEL/BRN    |
| 12       | RED/YEL/BLK | 35       | ORG/WHT     | 58       | WHT/PUR    | 81       | GREY/BLK    | 109      | GRN/YEL    |
| 13       | ORG         | 36       | RED/PUR     | 59       | YEL/BLU    | 82       | BRN/WHT     | 110A     | BLU        |
| 14       | BLK         | 37       | WHT/RED/BLK | 60       | WHT/BLU    | 83       | BLU/GREY    | 110B     | BRN        |
| 15       | BLU         | 38       | ORG/RED     | 61       | GREY/BRN   | 84       | WHT/BLK/PUR | 111      | GREY/GRN   |
| 16       | WHT/BLK     | 39       | BLK/RED     | 62       | GREY/RED   | 85       | GREY/BLU    | 112      | BLU/ORG    |
| 17       | BLU/GRN     | 40       | BLU/RED     | 63       | GREY/YEL   | 86/87    | PUR/BLU     | 113      | BLU/BRN    |
| 18       | GRN/BLU     | 41       | BLU/PUR     | 64       | WHT/BRN    | 88       | BLK/ORG     | 114      | YEL/RED    |
| 19       | ORG/GRN     | 42       | PINK        | 65       | YEL/PINK   | 90       | RED/GREY    | 115      | WHT/PUR    |
| 22       | PUR/GRN     | 43       | WHT/YEL     | 66       | ORG/YEL    | 91       | RED SHLD    | 118      | PUR/PINK   |

This table is to be used as a wire number/color reference for all electrical drawings and schematics. All wire numbers will retain their original color coding, for example if wire 7 is red, wire 7A, 7B, and 7C will also be red.



### 3.4 Wire Numbers and Color Codes - Additional

| AC Cord Color Code<br>(Battery Charger & Platform Power Outlet) |            |                        |
|---|------------|------------------------|
| Standard Definition   | NEC Colors | IEC Colors             |
| Protective Ground/Protective Earth                              | Green      | Green/Yellow           |
| Neutral   | White      | Blue                   |
| Line, Single Phase  | Black      | Black or Brown or Grey |

Note: Standard colors referenced from IEC 60445:2010, Annex A: Table 1.

1789AA

| Load Cell Color Code |            |          |            |          |            |          |            |
|----------------------|------------|----------|------------|----------|------------|----------|------------|
| Wire No.             | Wire Color | Wire No. | Wire Color | Wire No. | Wire Color | Wire No. | Wire Color |
| 02                   | Brown      | 60       | Yellow     | 161      | White      | unused   | Beige      |
| 02                   | Blue       | 60       | Red        | 162      | Green      | unused   | Purple     |
|                      |            |          |            |          |            | unused   | Black      |

1790AA

To order go to Discount-Equipment.com


### 3.5 Hydraulic Parts List

| Index No. | Skyjack Part No. | Description                                    |
|-----------|------------------|--|
| 2H-19     | 171435           | VALVE, Control - lift cushion flow             |
| 2H-21A    | 159805           | VALVE, Control - pressure dump                 |
| 2H-42     | 168755           | VALVE, Control - flow enable                   |
| 2H-85     | 168056           | VALVE, Control - flow enable, 12 kW generator  |
| 2H-85     | 168056           | VALVE, Control - flow enable, 3.5 kW generator |
| 3H-26     | 159827           | VALVE, Control - brake release                 |
| 3H-45     | 159827           | VALVE, Control - 2-Speed                       |
| 3H-65     | 159827           | VALVE, Control - axle lock out                 |
| 3H-V1     | N/A              | VALVE, Control - pressure compensator          |
| 3H-V2     | N/A              | VALVE, Control - load sense compensator        |
| 4H-13     | 168756           | VALVE, Control - boom up                       |
| 4H-14     | 168756           | VALVE, Control - boom down                     |
| 4H-15     | N/A              | VALVE, Control - drive pump control reverse    |
| 4H-16     | N/A              | VALVE, Control - drive pump control forward    |
| 4H-34     | 166036           | VALVE, Control - jib down                      |
| 4H-35     | 166036           | VALVE, Control - jib up                        |
| 4H-36     | 168757           | VALVE, Control - platform rotate left          |
| 4H-37     | 168757           | VALVE, Control - platform rotate right         |
| 4H-38     | 168758           | VALVE, Control - boom retract                  |
| 4H-39     | 168756           | VALVE, Control - boom extend                   |
| 4H-40     | 159803           | VALVE, Control - platform level down           |
| 4H-41     | 159803           | VALVE, Control - platform level up             |
| 5H-23A    | 159807           | VALVE, Control - steer right                   |
| 5H-24A    | 159807           | VALVE, Control - steer left                    |
| 5H-32     | 159806           | VALVE, Control - swing right                   |
| 5H-33     | 159806           | VALVE, Control - swing left                    |
| C1        | 165079           | CYLINDER, Boom lift                            |
| C2        | 165080           | CYLINDER, Boom extend                          |
| C3        | 165081           | CYLINDER, Master                               |
| C4        | 165082           | CYLINDER, Slave                                |
| C5        | 165083           | CYLINDER, Jib                                  |
| C6        | 212871           | CYLINDER, Axle lock                            |
| C7        | 1212871          | CYLINDER, Axle lock                            |
| C8        | 170903           | CYLINDER, Steer                                |
| C9        | N/A              | CYLINDER, Brake - front                        |
| C10       | N/A              | CYLINDER, Brake - rear                         |
| CB1       | 171421           | VALVE, Counterbalance - swing drive            |
| CB2       | 171421           | VALVE, Counterbalance - swing drive            |
| CB3       | 159841           | VALVE, Counterbalance - boom lift              |
| CB4       | 165486           | VALVE, Counterbalance - boom extend            |
| CB5       | 165486           | VALVE, Counterbalance - boom extend            |
| CB6       | 159841           | VALVE, Counterbalance - platform level         |
| CB7       | 159841           | VALVE, Counterbalance - platform level         |
| CB8       | 159841           | VALVE, Counterbalance - jib                    |
| CB9       | 159841           | VALVE, Counterbalance - jib                    |
| CB10      | 141399           | VALVE, Counterbalance - platform rotate        |

| Index No. | Skyjack Part No. | Description                                |
|-----------|------------------|--|
| CB11      | 141399           | VALVE, Counterbalance - platform rotate    |
| CB12      | 212872           | VALVE, Counterbalance - axle lock          |
| CB13      | 212872           | VALVE, Counterbalance - axle lock          |
| CB14      | 171388           | VALVE, Counterbalance - lift cylinder      |
| CV1       | 171389           | VALVE, Check - main inlet                  |
| CV2       | 171410           | VALVE, Check - auxiliary pump              |
| CV3       | 171411           | VALVE, Check - steer load sense            |
| CV4       | 159815           | VALVE, Check - main LS                     |
| CV5       | 159815           | VALVE, Check - main LS                     |
| CV6       | 171412           | VALVE, Check - swing drive load sense      |
| CV7       | 171412           | VALVE, Check - main boom load sense        |
| CV8       | 171412           | VALVE, Check - extension load sense        |
| CV9       | 159815           | VALVE, Check - main LS                     |
| CV10      | 159815           | VALVE, Check - main LS                     |
| CV11      | 171411           | VALVE, Check - level override load sense   |
| CV12      | 141712           | VALVE, Check - pilot pressure              |
| CV13      | 171413           | VALVE, Check - brake manifold              |
| CV14      | N/A              | VALVE, Check - EPU                         |
| CV16      | N/A              | VALVE, Check - 3.5 kW generator            |
| CV17      | 159814           | VALVE, Check - 12 kW generator manifold LS |
| CV18      | 171410           | VALVE, Check - 12 kW generator manifold    |
| CV19      | N/A              | VALVE, Check - 12 kW generator             |
| CV20      | 159814           | VALVE, Check - 3.5 kW generator LS         |
| DSV1      | 166062           | COMPENSATOR, Swing                         |
| DSV2      | 171417           | COMPENSATOR, Boom lift                     |
| DSV3      | 171417           | COMPENSATOR, Boom extend                   |
| EPU       | 168672           | PUMP, Emergency                            |
| F1        | 161932           | FILTER, High pressure                      |
| F2        | 161933           | FILTER, Return                             |
| FR1       | 166058           | FLOW REGULATOR, Pressure-compensated       |
| M1        | 171944           | MOTOR, Drive - axle                        |
| M2        | 170930           | MOTOR, Swing                               |
| M3        | 171419           | MOTOR, Generator - 3.5 kW                  |
| M4        | 171438           | MOTOR, Generator - 12 kW                   |
| MB1       | 165487           | MANIFOLD, Main                             |
| MB2       | 216511           | MANIFOLD, Brake                            |
| MB3       | 168661           | MANIFOLD, Jib                              |
| MB4       | 163541           | MANIFOLD, No jib                           |
| MB5       | 168618           | MANIFOLD, 3.5 kW generator                 |
| MB6       | 171437           | MANIFOLD, 12 kW generator                  |
| OC1       | 160800           | COOLER, Oil                                |
| OR1       | 171414           | ORIFICE, 0.090" - main manifold            |
| OR2       | 171415           | ORIFICE, 0.055" - main manifold            |
| OR3       | 171416           | ORIFICE, 0.020" - main manifold            |
| OR4       | 171416           | ORIFICE, 0.020" - main manifold            |
| OR5       | 171416           | ORIFICE, 0.020" - main manifold            |
| OR6       | 171416           | ORIFICE, 0.020" - main manifold            |

| Index No. | Skyjack Part No. | Description                                 |
|-----------|------------------|---|
| OR8       | 171422           | ORIFICE, 0.035" - main manifold             |
| OR9       | 171420           | ORIFICE, 0.073" - bleed off                 |
| OR10      | 171450           | VALVE, Flow regulator - 3.5 kW generator    |
| OR11      | 171450           | VALVE, Flow regulator - 12 kW generator     |
| P1        | 169006           | PUMP, Hydrostatic                           |
| P1A       | 154119           | PUMP, Charge                                |
| P2        | 165101           | PUMP, System                                |
| PR1       | 216235           | VALVE, Pressure reducing                    |
| QD1       | 122420           | QUICK DISCONNECT                            |
| RA1       | 144710           | ACTUATOR, Rotary - platform - <b>SJ86 T</b> |
| RA2       | 167073           | ACTUATOR, Rotary - turret                   |
| RA3       | 165466           | ACTUATOR, Rotary - platform - <b>SJ82 T</b> |
| RV1       | 168759           | VALVE, Relief - main manifold               |
| RV2       | 171385           | VALVE, Relief - swing drive                 |
| RV3       | 166047           | VALVE, Relief - platform level              |
| RV4       | 171386           | VALVE, Relief - boom extend                 |
| RV5       | N/A              | VALVE, Relief - brake manifold              |
| RV6       | N/A              | VALVE, Relief - drive                       |
| RV7       | N/A              | VALVE, Relief - drive                       |
| RV8       | N/A              | VALVE, Relief - charge                      |
| SV1       | 141414           | VALVE, Shuttle - brake manifold             |
| SV2       | 166054           | VALVE, Shuttle - brake manifold             |
| SV3       | 159803           | VALVE, Shuttle - main manifold              |
| SV4       | N/A              | VALVE, Shuttle - swing drive brake          |
| V1        | 141436           | VALVE, Control - brake release override     |
| V2        | 166053           | VALVE, Control - loop flush                 |
| V3        | 159831           | VALVE, Control - brake hand pump            |
| V4        | 171387           | VALVE, Control - pilot operated             |
| V5        | 171387           | VALVE, Control - pilot operated             |
| V6        | 221775           | VALVE, Control - pilot operated             |
| V7        | 221776           | VALVE, Control - pilot operated             |
| V8        | 166053           | VALVE, Control - loop flush                 |

### 3.6 Electrical Parts List



| Index No. | Skyjack Part No. | Description  |
|-----------|------------------|--|
| 01ACR     | 127131           | RELAY, 12 Volt 40 Amp (E-pump)                         |
| 01CR      | 127131           | RELAY, 12 Volt 40 Amp (E-pump)                         |
| 07CR      | 127131           | RELAY, 12 Volt 40 Amp (E-pump enable)                  |
| 08CR      | 127131           | RELAY, 12 Volt 40 Amp (Engine start interlock)         |
| 08CR1     | 127131           | RELAY, 12 Volt 40 Amp (Dump valve interlock)           |
| 09CR      | 127131           | RELAY, 12 Volt 40 Amp (ECU power or Telematics)        |
| 11CR      | 127131           | RELAY, 12 Volt 40 Amp (Cold start)                     |
| 17ACR1    | 127131           | RELAY, 12 Volt 40 Amp (Steer reverse)                  |
| 17ACR2    | 127131           | RELAY, 12 Volt 40 Amp (Steer reverse)                  |
| 19CR      | 127131           | RELAY, 12 Volt 40 Amp (Boom down throttle)             |
| 21CR      | 127131           | RELAY, 12 Volt 40 Amp (Dump valve)                     |
| 27CR      | 127131           | RELAY, 12 Volt 40 Amp (Tilt alarm)                     |
| 45CR1     | 127131           | RELAY, 12 Volt 40 Amp (Torque mode)                    |
| 45CR2     | 127131           | RELAY, 12 Volt 40 Amp (Torque mode)                    |
| 49CR      | 127131           | RELAY, 12 Volt 40 Amp (Horn)                           |
| 54ACR     | 127131           | RELAY, 12 Volt 40 Amp (Cold start)                     |
| 56ACR     | 127131           | RELAY, 12 Volt 40 Amp (Fuel pump)                      |
| 57ACR     | 127131           | RELAY, 12 Volt 40 Amp (Anti-restart)                   |
| 57ACR1    | 127131           | RELAY, 12 Volt 40 Amp (Generator interlock)            |
| 60CR      | 127131           | RELAY, 12 Volt 40 Amp (Main power enable)              |
| 76ACR     | 127131           | RELAY, 12 Volt 40 Amp (MIL light)                      |
| 77CR      | 127131           | RELAY, 12 Volt 40 Amp (E-pump enable)                  |
| 77CR1     | 127131           | RELAY, 12 Volt 40 Amp (Hourmeter/counter)              |
| 78CR      | 127131           | RELAY, 12 Volt 40 Amp (High idle)                      |
| 79CR      | 127131           | RELAY, 12 Volt 40 Amp (Low idle)                       |
| 82CR      | 127131           | RELAY, 12 Volt 40 Amp (Overload light)                 |
| 86CR      | 127131           | RELAY, 12 Volt 40 Amp (Oil cooler)                     |
| 120CR     | 127131           | RELAY, 12 Volt 40 Amp (Low capacity enable) - ANSI/CSA |
| 120CR     | 127131           | RELAY, 12 Volt 40 Amp (High capacity light) - CE & AS  |

| Index No. | Skyjack Part No. | Description   |
|-----------|------------------|---|
| 121CR     | 127131           | RELAY, 12 Volt 40 Amp (Boom down enable) - <b>ANSI/CSA</b>                    |
| 121CR2    | 127131           | RELAY, 12 Volt 40 Amp (Telescope out enable) - <b>ANSI/CSA</b>                |
| 121CR3    | 127131           | RELAY, 12 Volt 40 Amp (High capacity light) - <b>ANSI/CSA</b>                 |
| 121CR4    | 127131           | RELAY, 12 Volt 40 Amp (High capacity light) - <b>ANSI/CSA</b>                 |
| 123CR     | 127131           | RELAY, 12 Volt 40 Amp (Load capacity enable) - <b>ANSI/CSA</b>                |
| 123CR     | 127131           | RELAY, 12 Volt 40 Amp (Load sense fault - boom down) - <b>CE &amp; AS</b>     |
| 123CR1    | 127131           | RELAY, 12 Volt 40 Amp (Load sense fault - telescope out) - <b>CE &amp; AS</b> |
| 162BCR    | 127131           | RELAY, 12 Volt 40 Amp (Overload counter)                                      |
| 165CR     | 127131           | RELAY, 12 Volt 40 Amp (Diff lock)   |
| 2H-19     | 159839           | COIL, 12 Volt (Lift cushion valve)  |
| 2H-21A    | 159821           | COIL, 12 Volt (Dump valve)  |
| 2H-42     | 159819           | COIL, 12 Volt (Flow enable valve)   |
| 2H-85     | 168056           | COIL, 12 Volt (Optional 3.5 kW generator valve)                               |
| 3H-26     | 159827           | COIL, 12 Volt (Brake valve)   |
| 3H-45A    | 159827           | COIL, 12 Volt (2 speed valve)   |
| 3H-65     | 159827           | COIL, 12 Volt (Axle lockout valve)  |
| 3H-165    | 159827           | COIL, 12 Volt (Differential lock valve)                                       |
| 3H-V1     | N/A              | COIL, 12 Volt (Pressure compensator)  |
| 3H-V2     | N/A              | COIL, 12 Volt (Load sense compensator)  |
| 4H-13     | 159820           | COIL, 12 Volt (Boom down valve)   |
| 4H-14     | 159820           | COIL, 12 Volt (Boom up valve)   |
| 4H-15     | N/A              | COIL, 12 Volt (Reverse drive valve)   |
| 4H-16     | N/A              | COIL, 12 Volt (Forward drive valve)   |
| 4H-34     | 159821           | COIL, 12 Volt (Jib down valve) - <b>SJ86 T</b>                                |
| 4H-35     | 159821           | COIL, 12 Volt (Jib up valve) - <b>SJ86 T</b>                                  |
| 4H-36     | 159819           | COIL, 12 Volt (Platform left rotate valve)                                    |
| 4H-37     | 159819           | COIL, 12 Volt (Platform right rotate valve)                                   |
| 4H-38     | 159820           | COIL, 12 Volt (Boom in valve)   |
| 4H-39     | 159820           | COIL, 12 Volt (Boom out valve)  |
| 4H-40     | 159821           | COIL, 12 Volt (Platform level down valve)                                     |
| 4H-41     | 159821           | COIL, 12 Volt (Platform level up valve)                                       |
| 5H-23A    | 159821           | COIL, 12 Volt (Steer right valve)   |
| 5H-24A    | 159821           | COIL, 12 Volt (Steer left valve)  |
| 5H-32     | 159820           | COIL, 12 Volt (Turret rotate left valve)                                      |
| 5H-33     | 159820           | COIL, 12 Volt (Turret rotate right valve)                                     |
| A1        | 138224           | JOYSTICK (Drive/steer)  |
| A2        | 138225           | JOYSTICK (Boom/turret)  |
| A3        | 138226           | CONTROLLER, Speed control selector  |
| AT1       | 166163           | SWITCH, Tilt (analog 28°)   |
| B1        | 103295           | BATTERY, 12V (Wet)  |
| B2        | 103295           | BATTERY, 12V (Wet)  |
| BP1       | 103057           | BEEPER, 4-28 VDC Slow pulsing (Platform control console)                      |
| BP2       | 103056           | BEEPER, 7.5-16 VDC (Base control console) - <b>ANSI/CSA</b>                   |
| BP3       | 144387           | ALARM, Overload - <b>CE &amp; AS</b>  |
| CB1       | 117325           | CIRCUIT BREAKER (15 Amp)  |
| CB2       | 117325           | CIRCUIT BREAKER (15 Amp)  |
| CB3       | 117325           | CIRCUIT BREAKER (15 Amp)  |

| Index No. | Skyjack Part No. | Description   |
|-----------|------------------|---|
| CB4       | 117326           | CIRCUIT BREAKER (20 Amp)                                    |
| CB5       | 141631           | CIRCUIT BREAKER (50 Amp)                                    |
| CB6       | 141630           | CIRCUIT BREAKER (15 Amp)                                    |
| DXX       | 102921           | DIODE   |
| FU1       | 138848           | FUSE, 50 Amp  |
| FS1       | 138230           | SWITCH, Low fuel  |
| H1        | 146652           | HORN, 12 Volt   |
| LB1       | 169001           | LIGHT, Work (optional)                                      |
| LB2       | 169001           | LIGHT, Work (optional)                                      |
| LB3       | 144078           | LIGHT, Flashing (optional)                                  |
| LS1       | 111356           | LIMIT SWITCH, Direction sensing                             |
| LS2       | 165090           | LIMIT SWITCH, Boom Angle - Creep                            |
| LS3       | 165429           | LIMIT SWITCH, Boom Extend/Retract - Creep                   |
| LS4       | 168762           | LIMIT SWITCH, Boom Angle - Dual Load                        |
| LS5       | 165428           | LIMIT SWITCH, Boom Extend/Retract - Dual Load               |
| M1        | 170713           | PUMP, Emergency   |
| PL1       | 147229           | LED BLOCK, Red (12 volts) (Base control console)            |
| PL2       | 138229           | MODULE, Upper indicating                                    |
| PL3       | 170502           | LIGHT, Amber (Engine failure) (Base control console)        |
| PL4       | 170502           | LIGHT, Amber (Low fuel) (Base control console)              |
| PL5       | 164832           | LIGHT, Red (Oil pressure) (Base control console)            |
| PL6       | 171501           | LIGHT, Green (Glow plug) (Base control console)             |
| PL7       | 164832           | LIGHT, Red (Engine temperature) (Base control console)      |
| PL8       | 170502           | LIGHT, Amber (Water in fuel) (Base control console)         |
| PL9       | 147229           | LED BLOCK, Red (12 volts) (Platform control console)        |
| PL10      | 170501           | LIGHT, Green (Low capacity) (Platform control console)      |
| PL11      | 170501           | LIGHT, Green (High capacity) (Platform control console)     |
| PL12      | 170501           | LIGHT, Green (Low capacity) (Base control console)          |
| PL13      | 170501           | LIGHT, Green (High capacity) (Base control console)         |
| PL14      | 170502           | LIGHT, Amber (Load zone border) (Base control console)      |
| PL15      | 171502           | LIGHT, Amber (Load zone border) (Platform control console)  |
| PL16      | 171502           | LIGHT, Amber (Differential lock) (Platform control console) |
| R1        | 144714           | RESISTOR, 7 ohm 25 W  |
| R2        | 168783           | RESISTOR, 4 ohm 25 W - <b>Deutz D2011</b>                   |
|           | 144523           | RESISTOR, 7 ohm 25 W - <b>ANSI/CSA Deutz TD2.9L</b>         |
|           | 144714           | RESISTOR, 6 ohm 25 W - <b>CE Deutz TD2.9L</b>               |
| R3        | 144523           | RESISTOR, 7 ohm 25 W - <b>Deutz D2011</b>                   |
|           | 163021           | RESISTOR, 120 ohm 1/2 W - <b>Deutz TD2.9L</b>               |
| R4        | 172005           | RESISTOR, 3 ohm 25 W - <b>ANSI/CSA Deutz D2011</b>          |
|           | 139088           | RESISTOR, 6 ohm 25 W - <b>CE &amp; AS D2011</b>             |
|           | 164855           | RESISTOR, 1.0k ohm 1/2 W - <b>Deutz TD2.9L</b>              |
| R5        | 143952           | RESISTOR, 51 ohm 2 W - <b>Deutz D2011</b>                   |
|           | 164856           | RESISTOR, 3.3k ohm 1/22 W - <b>Deutz TD2.9L</b>             |
| R6        | 172005           | RESISTOR, 3 ohm 25 W - <b>ANSI/CSA Deutz D2011</b>          |
|           | 168783           | RESISTOR, 4 ohm 25 W - <b>CE &amp; AS Deutz D2011</b>       |
|           | 164857           | RESISTOR, 3.9k ohm 1/2 W - <b>Deutz TD2.9L</b>              |
| R7        | 151643           | RESISTOR, 250 ohm 1 W                                       |




| Index No. | Skyjack Part No. | Description   |
|-----------|------------------|---|
| R8        | 151643           | RESISTOR, 250 ohm 1 W   |
| R9        | 151643           | RESISTOR, 250 ohm 1 W   |
| R10       | 151643           | RESISTOR, 250 ohm 1 W   |
| R11       | 151643           | RESISTOR, 250 ohm 1 W   |
| R12       | 171987           | RESISTOR, 1 ohm 1/4 W - <b>Deutz D2011</b>                                    |
|           | 168783           | RESISTOR, 4 ohm 25 W - <b>Deutz TD2.9L</b>                                    |
| R13       | 139088           | RESISTOR, 6 ohm 25 W - <b>ANSI/CSA Deutz TD2.9L &amp; D2011</b>               |
|           | 171987           | RESISTOR, 1 ohm 1/4 W - <b>CE &amp; AS Deutz D2011</b>                        |
| R14       | 172005           | RESISTOR, 3 ohm 25 W - <b>Deutz D2011 &amp; ANSI/CSA Deutz TD2.9L</b>         |
|           | 168783           | RESISTOR, 4 ohm 25 W - <b>CE Deutz TD2.9L</b>                                 |
| R15       | 144714           | RESISTOR, 11 ohm 25 W - <b>ANS/CSA</b>  |
|           | 171988           | RESISTOR, 2 ohm 25 W - <b>CE &amp; AS Deutz D2011</b>                         |
|           | 139088           | RESISTOR, 6 ohm 25 W - <b>CE Deutz TD2.9L</b>                                 |
| R16       | 171988           | RESISTOR, 2 ohm 25 W - <b>ANSI/CSA Deutz D2011 &amp; CE TD2.9L</b>            |
|           | 172005           | RESISTOR, 1 ohm 1/4 W - <b>ANSI/CSA Deutz TD2.9L</b>                          |
| R17       | 138783           | RESISTOR, 4 ohm 25 W - <b>ANSI/CSA Deutz TD2.9L</b>                           |
|           | 171987           | RESISTOR, 1 ohm 1/4 W - <b>CE Deutz TD2.9L</b>                                |
| R18       | 171988           | RESISTOR, 1 ohm 25 W - <b>ANSI/CSA Deutz TD2.9L</b>                           |
|           | 171987           | RESISTOR, 1 ohm 1/4 W - <b>CE Deutz TD2.9L</b>                                |
| S1        | 119725           | SWITCH, Main power disconnect   |
| S2        | 138277           | KEYSWITCH, Base/Off/Platform (Base control console) - <b>ANSI/CSA&amp;AS</b>  |
|           | 144366           | KEYSWITCH, Base/Off/Platform (Base control console) - <b>CE</b>               |
| S3        | 147053           | N.C. CONTACT, Emergency stop (Base control console)                           |
| S4        | 147053           | N.C. CONTACT, Emergency stop (Platform control console)                       |
| S5        | 138278           | SWITCH, Ignition/emergency pump toggle (Base control console)                 |
| S6        | 138278           | SWITCH, Ignition/emergency toggle (Platform control console)                  |
| S8        | 102853           | SWITCH, Diagnose toggle (Base control console)                                |
| S9        | 124446           | SWITCH, Ignition (Platform control console)                                   |
| S10       | 115747           | SWITCH, Throttle toggle (Platform control console)                            |
| S11       | 154127           | FOOTSWITCH  |
| S12       | 138278           | SWITCH, Boom up/down toggle (Base control console)                            |
| S13       | 102853           | SWITCH, Turret rotate toggle (Base control console)                           |
| S14       | 102853           | SWITCH, Telescope in/out toggle (Base control console)                        |
| S15       | 102853           | SWITCH, Platform leveling toggle (Base control console)                       |
| S16       | 102853           | SWITCH, Platform rotate toggle (Base control console)                         |
| S17       | 102853           | SWITCH, Jib up/down toggle (Base control console) (SJ86 T)                    |
| S18       | 102853           | SWITCH, Telescope in/out toggle (Platform control console)                    |
| S19       | 102853           | SWITCH, Platform leveling toggle (Platform control console) - <b>ANSI/CSA</b> |
| S20       | 102853           | SWITCH, Platform rotate toggle (Platform control console)                     |
| S21       | 102853           | SWITCH, Jib up/down toggle (Platform control console) - <b>SJ86 T</b>         |
| S22       | 144266           | SWITCH, Electrical generator (Platform control console)                       |
| S23       | 147054           | SWITCH, Horn (Platform control console)                                       |
| S24       | 168678           | SWITCH, Load zone toggle (Platform control console)                           |
| S25       | 148988           | SWITCH, Load zone select (Base control console)                               |
| S28       | 148988           | SWITCH, Differential lock (Platform control console)                          |
| S48       | 115574           | SWITCH, Drive torque toggle (Platform control console)                        |
| TT1       | 103336           | HOUR METER - <b>ANSI/CSA</b>  |


| Index No. | Skyjack Part No. | Description                             |
|-----------|------------------|---|
| X22       | 170787           | HOUR METER - <b>CE &amp; AS</b>         |
| X23       | 138576           | PORT, Diagnose - <b>Deutz engine</b>    |
|           | 138574           | CONNECTOR, Engine - <b>Deutz engine</b> |

To order go to [Discount-Equipment.com](http://Discount-Equipment.com)


### 3.7 Hourmeter/Counter Harness - CE



**SECTION A-A  
SCALE 2:1**




**SECTION B-B**



| DESCRIPTION   | IDENTIFICATION | COLOUR | CAVITY ID. |
|---------------|----------------|--------|------------|
| +12 VDC       | +              | PURPLE | 1          |
| HOURMETER     | H-1            | RED    | 2          |
| COUTNER       | C-1            | BLUE   | 3          |
| HOUR RESET    | RH-1           | GREEN  | 4          |
| COUNTER RESET | RC-1           | WHITE  | 5          |
| GROUND        | -              | WHITE  | 6          |


### 3.8 Rotary Manifold Port Identification




M167068AH-1

SJ82 T, SJ86 T


### 3.8 Rotary Manifold Port Identification



### 3.9 System and Drive Pump Port Identification




### 3.10 Drive Motors Port Identification







### 3.11 Jib Valve Port Identification




### 3.12 No Jib Valve Port Identification



### 3.13 Brake Manifold Port Identification




### 3.14 Main Manifold Port Identification



M165487AG-PI




### 3.15 Main Manifold Electrical Component Identification




M165487AH-EC

### 3.16 Main Manifold Hydraulic Component Identification



M165487AH-HC


### 3.17 Main Harness Wiring Diagram



M165094AD-1




### 3.18 Boom Lift Valve Harness




M168763AA

### 3.19 Differential Lock Harness



M167195AB


### 3.20 Platform Rotate & Jib Harnesses



M168644AB\_M167740AB\_M168650AA




### 3.21 Platform to Base Control Cable Harnesses




M165497AD\_M165499AD

### 3.22 Limit Switch Connections




M63752AA

### 3.23 Load Sensing Cable Connection - CE & AS



M168774AB


### 3.24 ECU Engine Wiring Diagram - Deutz Diesel Engine



M138708AA




### 3.25 Glow Plug and EGR Harnesses - Deutz Diesel Engine




M138849AB

### 3.26 Generator and Oil Cooler Harness Connections




M171443AA\_1

### 3.27 Generator Wiring




M169566AC\_M166385AA

### 3.28 Platform Work Light




M168636AB

### 3.29 Positive Air Shut-Off Option Harness



M171529AA-2


### 3.30 Dual Capacity Sensing Module



M167280AE




### 3.31 Load Circuit - ANSI/CSA with Deutz TD2.9L and Arctic Package



M194713AB



3.32 Hydraulic Schematic




M167056AA

3.32 Hydraulic Schematic



3.33 Platform Controls Wiring - SJ82 T




M218444D

3.33 Platform Controls Wiring - SJ82 T



3.34 Platform Controls Wiring - SJ86 T with Deutz TD2.9L or D2011 Engines




M231432AB

3.34 Platform Controls Wiring - SJ86 T with Deutz TD2.9L or D2011 Engines



3.35 Platform Controls Wiring - SJ86 T with Deutz TCD2.2 Engine




M224643AD

3.35 Platform Controls Wiring - SJ86 T with Deutz TCD2.2 Engine



3.36 Base Controls Wiring - SJ82 T ANSI/CSA - Deutz TD2.9L




**DETAIL A**  
RESISTOR & DIODE PLACEMENT

M2184404C




3.37 Base Controls Wiring - SJ82 T ANSI/CSA - Deutz TD2.9L with Positive Air Shut-Off



M231371AB






M231383AB





3.39 Base Controls Wiring - SJ86 T ANSI/CSA - Deutz TD2.9L



**DETAIL A**  
RESISTOR  
& DIODE  
PLACEMENT



3.40 Base Controls Wiring - SJ86 T ANSI/CSA - Deutz TD2.9L with Positive Air Shut-Off





DETAIL A  
RESISTOR  
& DIODE  
PLACEMENT








3.42 Base Controls Wiring - SJ86 T CE - Deutz TCD2.2




DETAIL A  
RESISTOR & DIODE PLACEMENT



DETAIL C  
CONNECTOR FEMALE  
PIN1-05 PURPLE  
PIN2-050 YELLOW  
PIN3-018 PURPLE/BLACK  
PIN4-110  
PIN5-08F YELLOW  
PIN6-02 WHITE



3.43 Base Controls Wiring - SJ86 T CE - Deutz D2011




**DETAIL C**

CONNECTOR(FEMALE)


- PIN1 - 05 PURPLE
- PIN2 - 77 BROWN
- PIN3 - 01B PURPLE/BLACK
- PIN4 - n/a
- PIN5 - 09F YELLOW
- PIN6 - 02 WHITE

AT1 SENSOR CONNECTION  
 PIN 1 - 09 YELLOW  
 PIN 2 - 28 GREEN  
 PIN 3 - 02 WHITE  
 PIN 4 - 128 BLACK/YELLOW




LOAD SENSE CONNECTOR J3-BLACK

- PIN 8 - 161 PINK/WHITE
- PIN 7 - 162 PINK/PURPLE
- PIN 6 - 121 GRAY/RED
- PIN 5 - 122 GRAY/YELLOW
- PIN 4 - 120 GRAY/BROWN
- PIN 3 - 82 BROWN/WHITE
- PIN 2 - 119 PURPLE/YELLOW
- PIN 1 - 123 WHITE/BROWN



LOAD SENSE CONNECTOR J4-WHITE

- PIN 8 - 09 YELLOW
- PIN 7 - 13 ORANGE
- PIN 6 - 39 BLACK/RED
- PIN 5 - 13A ORANGE
- PIN 4 - 09 YELLOW
- PIN 3 - 39A BLACK/RED
- PIN 2 - 162B PINK/PURPLE
- PIN 1 - 02 WHITE




CONNECTOR J3

- SOCKET 1 - 77
- SOCKET 2 - KEY
- SOCKET 3 - B+
- SOCKET 4 - 00
- SOCKET 5 - PLUG
- SOCKET 6 - PLUG
- SOCKET 7 - CAN/H
- SOCKET 8 - CAN/L
- SOCKET 9 - 57D
- SOCKET 10 - PLUG
- SOCKET 11 - 20
- SOCKET 12 - 26D



3.44 Base Controls Wiring - SJ86 T CE - Deutz TD2.9L



M231430AA


3.44 Base Controls Wiring - SJ86 T CE - Deutz TD2.9L







3.46 Electrical Schematic - ANSI/CSA & AS Deutz D2011




M218473AA

3.46 Electrical Schematic - ANSI/CSA & AS Deutz D2011

SEE OPTION  
NOTE A: AMPRS REMOVED WITH SGE OPTION  
NOTE B: 1-AMPRS REMOVED WITH SGE OPTION  
NOTE C: AMPRS REMOVED WITH TRACK UNIT OPTION




3.47 Electrical Schematic - CE Deutz TCD2.2




NOTE A: SGE IS STANDARD FOR CE  
 NOTE B: JIMPR8 REMOVED WITH TRACK UNIT OPTION  
 NOTE C: JIMPR8 REMOVED WITH TRACK UNIT OPTION  
 NOTE D: S31A IS NO. S31B IS NC CONTACTS  
 NOTE E: STATIONARY MODE CAN ONLY BE ACCESSED IN BASE MODE





SEE OPTION  
NOTE: JAPRS REMOVED WITH SEE OPTION  
NOTE B: JAPRS REMOVED WITH SEE OPTION  
NOTE C: JAPRS REMOVED WITH TRACK UNIT OPTION


3.49 Engine Electrical Schematic - Deutz TD2.9L



M218476AA-2



3.50 Engine Interface Harness Schematic - Deutz TD2.9L




M195628AA

3.50 Engine Interface Harness Schematic - Deutz TD2.9L




3.51 Engine Electrical Schematic - Deutz TCD2.2



M224629AD-2

3.51 Engine Electrical Schematic - Deutz TCD2.2

3.52 Engine Interface Harness Schematic - Deutz TCD2.2



M224638AD-1

3.52 Engine Interface Harness Schematic - Deutz TCD2.2

---

# Section 4 – Troubleshooting Information

## 4.1 Introduction

The following pages contain a table of Troubleshooting for locating and correcting most service trouble which can develop. Careful and accurate analysis of the systems listed in the table of Troubleshooting will localize the trouble more quickly than any other method. This manual cannot cover all possible troubles and deficiencies that may occur. If a specific trouble is not listed, isolate the major component in which the trouble occurs, isolate whether the problem is electrical or hydraulic, and then isolate and correct the specific problem.

The content of this section is separated into “probable cause” and “remedy”. See the example below for clarification.

---

1. Probable cause

**Remedy**

To order go to Discount-Equipment.com

**NOTE**

All tests should be performed with boom over non-steering axle.

## 4.2 Electrical System

### 4.2-1 All Controls Inoperative

|  |   |
|--|---|
| 1. Battery disconnected or discharged.   | <b>Connect battery or recharge.</b>                                     |
| 2. Loose or broken B+ cable from battery to battery disconnect switch S1.              | <b>Check continuity. Replace if defective.</b>                          |
| 3. Open or defective battery disconnect switch S1.                                     | <b>Close switch. Replace if defective.</b>                              |
| 4. Loose or broken wire #03 from battery disconnect switch S1 to circuit breaker CB1.  | <b>Check continuity. Replace if defective.</b>                          |
| 5. Circuit breaker CB1 tripped or defective.   | <b>Reset breaker, check for defective wiring. Replace if defective.</b> |
| 6. Loose or broken wire #05 from circuit breaker CB1 to base emergency stop switch S3. | <b>Check continuity. Replace if defective.</b>                          |
| 7. Open or defective base emergency stop switch S3.                                    | <b>Close switch. Replace if defective.</b>                              |
| 8. Loose or broken wire #07 from base emergency stop switch S3 to base key S2.         | <b>Check continuity. Replace if defective.</b>                          |
| 9. Open or defective key select switch S2.   | <b>Close switch. Replace if defective.</b>                              |
| 10. Loose or broken wire #60 from base terminal block to relay 60CR.                   | <b>Check continuity. Replace if defective.</b>                          |
| 11. Loose or broken wire #07 from base emergency stop switch S3 to relay 60CR.         | <b>Check continuity. Replace if defective.</b>                          |
| 12. Loose or broken wire #02 from relay 60CR to base terminal block.                   | <b>Check continuity. Replace if defective.</b>                          |
| 13. Defective relay 60CR.  | <b>Check relay. Replace if defective.</b>                               |
| 14. Loose or broken wire #9 from relay 60CR to base terminal block.                    | <b>Check continuity. Replace if defective.</b>                          |
| 15. Loose or broken wire #02 from base terminal block to circuit breaker CB2.          | <b>Check continuity. Replace if defective.</b>                          |
| 16. Circuit breaker CB2 tripped or defective.  | <b>Reset breaker, check for defective wiring. Replace if defective.</b> |
| 17. Loose or broken wire #00 from circuit breaker CB2 to battery negative.             | <b>Check continuity. Replace if defective.</b>                          |

## 4.2-2 No Power

### To Platform

|   |  |
|---|--|
| 1. Open or defective key select switch S2.  | <b>Close switch. Replace if defective.</b>     |
| 2. Loose or broken wire #07A from key select switch S2 to to platform emergency stop switch S4. | <b>Check continuity. Replace if defective.</b> |
| 3. Open or defective platform emergency stop switch S4.   | <b>Check switch. Replace if defective.</b>     |
| 4. Loose or broken wire #04B from platform emergency stop switch S4 to Ignition switch S9.      | <b>Check continuity. Replace if defective.</b> |

### To Base

|   |   |
|---|---|
| 1. Open or defective base key switch S2.  | <b>Select base position on key switch. Check continuity through base key switch. Replace if defective.</b>                                      |
| 2. Loose or broken wire #12 from base key switch S2 to Ignition/E-pump switch S5.                           | <b>Check continuity. Replace if defective</b>   |
| 3. Loose or broken wire #12 from base key switch S2 to base connector plug A pins #2 & 3.                   | <b>Check continuity. Replace if defective</b>   |
| 4. Loose or broken wires #12 in boom cable A or its connectors.   | <b>Check for continuity between pins on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 5. Loose or broken wire #12 from plug A pin #2 & 3 to emergency stop switch S4 in platform control console. | <b>Check continuity. Replace if defective</b>   |
| 6. Open or defective emergency stop switch S4.  | <b>Check switch is in on position. Check continuity through switch. Replace if defective.</b>   |
| 7. Loose or broken wire #10 from base terminal block to Ignition/E-pump (enable) switch S5.                 | <b>Check continuity. Replace if defective</b>   |
| 8. Open or defective Ignition/E-pump (enable) switch S5.  | <b>Check switch. Replace if defective</b>   |

### 4.2-3 Engine Will Not Crank

#### From Base

- |  |   |
|--|---|
| 1. Loose or broken wire #57A from base start switch S5 to relay 57ACR (Deutz D2011 and GM 3.0L engines). | Check continuity. Replace if defective.   |
| 2. Defective base start switch S5.   | Check start switch. Replace if defective. |

#### From Platform



#### NOTE

Engine will not crank from platform with footswitch depressed.

- |   |   |
|---|---|
| 1. Loose or broken wire #4 from emergency stop switch S4 to start switch S6.  | Check continuity. Replace if defective.   |
| 2. Defective start switch S6.   | Check continuity through contacts of relay. Replace if defective.   |
| 3. Loose or broken wire #57 from start switch S6 to relay 08CR.   | Check continuity. Replace if defective.   |
| 4. Defective relay 08CR.  | Check continuity through contacts of relay. Replace if defective.   |
| 5. Loose or broken wire #57A from relay 08CR to plug B pin #14.   | Check continuity. Replace if defective.   |
| 6. Loose or broken wire #57A in boom cable B or its connectors.   | Check for continuity between pin #14 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective. |
| 7. Loose or broken wire #57A from plug B pin #14 to relay 57ACR in base control console (Deutz D2011, GM 3.0L) or to base start switch S5 (Deutz TD2.9L). | Check continuity. Replace if defective.   |

#### From Platform or Base

#### With the following conditions:

- Deutz Diesel D2.9L

- |  |   |
|--|---|
| 1. Loose or broken wire #57A from base start switch S5 to 12 pin connector (J1) pin 8.         | Check continuity. Replace if defective.                         |
| 2. Loose or broken wire #57A from 12 pin connector (P1) pin 8 to 94 pin ECU connector, pin 35. | Check continuity. Replace if defective.                         |
| 3. Loose or broken B+ wire from battery B+ to ECU fuse connector P6 pin A.                     | Check continuity. Replace if defective.                         |
| 4. ECU 30A fuse open or defective.   | Check for defective wiring. Replace if defective. Replace fuse. |



- |  |  |
|--|--|
| 5. Loose or broken wire #K01 from ECU fuse connector P6 pin B to 94 pin ECU connector 3 places pins 1, 3, and 5. | <b>Check continuity. Replace if defective.</b> |
| 6. Loose or broken ground wire #00 from battery B- to 94 pin ECU connector 3 places pins 2, 4, and 6.            | <b>Check continuity. Replace if defective.</b> |

**NOTE**

*For other engine related problems, consult engine manufacturer's manual.*

**With the following conditions:**

- Deutz Diesel D2011

- |   |   |
|---|---|
| 1. Loose or broken wire #57A at relay 57ACR (2 places).                                       | <b>Check for connections at relay. Check for voltage on relay (2 places).</b>                       |
| 2. Loose or broken wire #57A from relay 57ACR to relay 57BCR.                                 | <b>Check continuity. Replace if defective.</b>  |
| 3. Loose or broken wire #00A from X23 engine connector pin #11 to relay 57ACR.                | <b>Check continuity. Replace if defective.</b>  |
| 4. Loose or broken wire #00A from X23 engine connector pin #11 to engine oil pressure switch. | <b>Check continuity. Replace if defective.</b>  |
| 5. Defective relay 57ACR.   | <b>Check relay. Replace if defective.</b>   |
| 6. Loose or broken wire #09 from base terminal block to relay 09CR.                           | <b>Check continuity. Replace if defective.</b>  |
| 7. Loose or broken wire #03A from circuit breaker CB3 to relay 09CR.                          | <b>Check continuity. Replace if defective.</b>  |
| 8. Tripped or defective circuit breaker CB3.  | <b>Reset circuit breaker. Check continuity through circuit breaker. Replace if defective.</b>       |
| 9. Loose or broken wire #3 from circuit breaker CB3 to turret harness plug pin #2.            | <b>Check continuity. Replace if defective.</b>  |
| 10. Loose or broken wire #02 from relay 09CR to base terminal block.                          | <b>Check continuity. Replace if defective.</b>  |
| 11. Defective relay 09CR.   | <b>Check relay. Replace if defective.</b>   |
| 12. Loose or broken wire #54A from relay 09CR to base terminal block.                         | <b>Check continuity. Replace if defective.</b>  |
| 13. Loose or broken wire #54A from base terminal block to relay 57BCR1.                       | <b>Check continuity. Replace if defective.</b>  |
| 14. Defective contacts in relay 57BCR1.   | <b>Check continuity between wires #54A and #57C when cranking. If no continuity, replace relay.</b> |
| 15. Loose or broken wire #57C from relay 57BCR1 to X23 engine connector pin #4.               | <b>Check continuity. Replace if defective.</b>  |

|  |   |
|--|---|
| 16. Loose or broken wire #57C from X23 engine plug to start solenoid 57CCR.              | <b>Check continuity. Replace if defective.</b>    |
| 17. Loose or broken starter cable #03 from disconnect switch S1 to start solenoid 57CCR. | <b>Check continuity. Replace if defective.</b>    |
| 18. Defective start solenoid 57CCR.  | <b>Check solenoid. Replace if defective.</b>      |
| 19. Defective starter motor.   | <b>Check starter motor. Replace if defective.</b> |

**With the following conditions:**

- Equipped with Elevate/Trackunit Telematics Ready

**NOTE**

*If the unit is equipped with an Access keypad, a passcode is required from the machine owner.*

|   |  |
|---|--|
| 1. Loose or broken B+ wire from battery + to telematics pin 3.  | <b>Check continuity. Replace if defective.</b>                             |
| 2. Loose or broken B- wire 00 from battery - to telematics pin 4.   | <b>Check continuity. Replace if defective.</b>                             |
| 3. Loose or broken wire 07 from S3 base Emergency stop switch to 57DCR pin 86.                                  | <b>Check continuity. Replace if defective.</b>                             |
| 4. Loose or broken wire 57A from S5 ignition switch to 57DCR pin 30.  | <b>Check continuity. Replace if defective.</b>                             |
| 5. If telematics device is not installed: loose, broken or missing Jumper JMPR1 from 57DCR pin 85 to ground 00. | <b>Check continuity. Replace if defective or missing.</b>                  |
| 6. Loose or broken wire 57D from telematics pin 9 to 57DCR pin 85.  | <b>Check continuity. Replace if defective.</b>                             |
| 7. Missing output from telematics pin 9.  | <b>Check for ground on pin 9. If no ground, contact the machine owner.</b> |
| 8. Defective relay 57DCR.   | <b>Check relay. Replace if defective.</b>                                  |
| 9. Loose or broken wire 57B from 57DCR pin 87 to engine starter contactor coil.                                 | <b>Check continuity. Replace if defective.</b>                             |
| 10. Defective telematics module.  | <b>Check telematics assembly; repair or replace as required.</b>           |

## 4.2-4 Engine Cranks but Will Not Start

### Deutz Diesel D2.9L

|  |  |
|--|--|
| 1. Loose or broken wire #54 from 94 pin ECU connector, pin90 to 12 pin connector (P2), pin 9.  | <b>Check continuity. Replace if defective.</b>                           |
| 2. Loose or broken wire #54 from 12 pin connector (J2) pin 9 to relay 56ACR.                   | <b>Check continuity. Replace if defective.</b>                           |
| 3. Loose or broken wire #03 to circuit breaker CB3.  | <b>Check continuity. Replace if defective.</b>                           |
| 4. Circuit breaker CB3 tripped or defective.   | <b>Reset breaker, check for defective wiring. Replace if defective</b>   |
| 5. Loose or broken wire #56 from CB3 to relay 56ACR.   | <b>Check continuity. Replace if defective.</b>                           |
| 6. Loose or broken wire #56A from relay 56ACR to 12 pin connector (J1) pin 4.                  | <b>Check continuity. Replace if defective.</b>                           |
| 7. Loose or broken wire #56A from 12 pin connector (P1) pin 4 to 94 pin ECU connector, pin 26. | <b>Check continuity. Replace if defective.</b>                           |
| 8. Loose or broken wire #56B from relay 56ACR to 12 pin connector (J1) pin 3.                  | <b>Check continuity. Replace if defective.</b>                           |
| 9. Defective relay 56ACR.  | <b>Check continuity through contacts of relay. Replace if defective.</b> |
| 10. Loose or broken wire #56B from 12 pin connector (P1) pin 3 to fuel pump.                   | <b>Check continuity. Replace if defective.</b>                           |
| 11. Loose or broken ground wire #00 from fuel pump to battery B-.                              | <b>Check continuity. Replace if defective.</b>                           |
| 12. Engine pre-heat circuit inoperative.   | <b>Refer to Engine manufacturer's manual to diagnose.</b>                |



### NOTE

*For other engine related problems, consult engine manufacturer's manual.*

### Deutz Diesel D2011

|  |  |
|--|--|
| 1. Loose or broken wire #57B from relay 57ACR to relay 57BCR (2 places). | <b>57BCR maintains power for start circuit before engine starts and after oil pressure switch opens to relay 57BCR1. Check wire #57B for continuity. Replace if defective.</b> |
| 2. Loose or broken wire #57A from relay 57ACR to relay 57BCR.            | <b>Check continuity. Replace if defective.</b>   |
| 3. Loose or broken wire #02 from base terminal block to relay 57BCR.     | <b>Check continuity. Replace if defective.</b>   |

|  |   |
|--|---|
| 4. Defective relay 57BCR.                          | Check relay. Replace if defective.                                    |
| 5. Glow plug circuit not operating.                | See “Glow Plug Circuit Inoperative” in this section.                  |
| 6. No fuel in fuel tank or fuel line obstructions. | Check fuel level and flow through lines. Fill or repair if necessary. |

**NOTE**

For other engine related problems, consult engine manufacturer's manual.

#### 4.2-5 Glow Plug Circuit Inoperative - Deutz D2011 diesel engine

|   |   |
|---|---|
| 1. Defective glow plug fuse FU1 50 amp.                                   | Check fuse. Replace if defective.       |
| 2. Loose or broken wire #03 from start solenoid 57CCR to fuse holder FU1. | Check continuity. Replace if defective. |
| 3. Loose or broken wire #11A from fuse holder FU1 to relay 54ACR.         | Check continuity. Replace if defective. |
| 4. Loose or broken wire #11B from relay 54ACR to glow plugs.              | Check continuity. Replace if defective. |
| 5. Loose or broken wire #54A from base terminal strip to relay 54ACR.     | Check continuity. Replace if defective. |
| 6. Loose or broken wire #11 from base terminal block to relay 54ACR.      | Check continuity. Replace if defective. |
| 7. Defective relay 54ACR.   | Check relay. Replace if defective.      |
| 8. Defective glow plugs.  | Check glow plugs. Replace if defective. |

**NOTE**

For other glow plug related problems, consult engine manufacturer's manual.

#### 4.2-6 Glow Plug Circuit Inoperative - Deutz D2.9 diesel engine

|   |   |
|---|---|
| 1. Defective glow plug fuse FU2 100 amp.                            | Check fuse. Replace if defective.       |
| 2. Loose or broken wire #03 from start solenoid to fuse holder FU1. | Check continuity. Replace if defective. |
| 3. Loose or broken wire #11B from fuse holder FU1 to relay 11CR.    | Check continuity. Replace if defective. |
| 4. Loose or broken wire #11C from relay 11CR to glow plugs.         | Check continuity. Replace if defective. |

|  |  |
|--|--|
| 5. Loose or broken wire #11 from 60 pin ECU connector D2.1 pin 35 to relay 11CR.   | <b>Check continuity. Replace if defective.</b> |
| 6. Loose or broken wire #11A from 60 pin ECU connector D2.1 pin 45 to relay 54ACR. | <b>Check continuity. Replace if defective.</b> |
| 7. Defective relay 11CR.   | <b>Check relay. Replace if defective.</b>      |
| 8. Defective glow plugs.   | <b>Check glow plugs. Replace if defective.</b> |

**NOTE**

*For other glow plug related problems, consult engine manufacturer's manual.*

#### 4.2-7 All Base Control Console Inoperative

|   |  |
|---|--|
| 1. Loose or broken wire #10 from base emergency stop switch S3 to ignition/ pump switch S5. | <b>Check continuity. Replace if defective.</b>                               |
| 2. Defective ignition/ pump switch S5.  | <b>Check continuity through switch when activated. Replace if defective.</b> |
| 3. Loose or broken wire #10A from ignition/ pump switch S5 to basket rotation switch S16.   | <b>Check continuity. Replace if defective.</b>                               |
| 4. Loose or broken wire #10A from basket rotation switch S16 to level switch S15.           | <b>Check continuity. Replace if defective.</b>                               |
| 5. Loose or broken wire #10A from level switch S15 to jib switch S17.                       | <b>Check continuity. Replace if defective.</b>                               |
| 6. Loose or broken wire #10A from jib switch S17 to telescope switch S14.                   | <b>Check continuity. Replace if defective.</b>                               |
| 7. Loose or broken wire #10A from telescope switch S14 to boom switch S12.                  | <b>Check continuity. Replace if defective.</b>                               |
| 8. Loose or broken wire #10A from boom switch S12 to base terminal block.                   | <b>Check continuity. Replace if defective.</b>                               |
| 9. Loose or broken wire #10A from base terminal block to diode D10A.                        | <b>Check continuity. Replace if defective.</b>                               |
| 10. Open or defective diode D10A.   | <b>Check diode. Replace if defective.</b>                                    |
| 11. Loose or broken wire #20 from diode D10A to base terminal block.                        | <b>Check continuity. Replace if defective.</b>                               |
| 12. Missing or broken jumper JMPR3 on base terminal block between wires #20 and #21.        | <b>Check for jumper. Replace if missing or broken.</b>                       |

**NOTE**

*Jumper is removed if equipped with generator option.*

|   |   |
|---|---|
| 13. Loose or broken wire #21 from base terminal block to relay 21CR.                | Check continuity. Replace if defective.                             |
| 14. Loose or broken wire #02 from base terminal block to relay 21CR.                | Check continuity. Replace if defective.                             |
| 15. Loose or broken wire #09 from base terminal block to relay 21CR.                | Check continuity. Replace if defective.                             |
| 16. Defective relay 21CR.   | Check relay. Replace if defective.                                  |
| 17. Loose or broken wire #21A from relay 21CR to turret harness plug pin #5.        | Check continuity. Replace if defective.                             |
| 18. Loose or broken wire #21A from turret harness plug pin #5 to dump valve 2H-21A. | Check continuity. Replace if defective.                             |
| 19. Loose or broken wire #02 from dump valve 2H-21A to turret harness plug.         | Check continuity. Replace if defective.                             |
| 20. Defective dump valve coil 2H-21A.   | Check continuity and resistance through coil. Replace if defective. |

#### 4.2-8 No Movement from Base Control Console

##### No Boom Up

|   |   |
|---|---|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to boom switch S12.      | Check continuity. Replace if defective.   |
| 2. Defective boom switch S12.   | Check continuity through switch while activating up function between wires #10A and #14. Replace switch if no continuity. |
| 3. Loose or broken wire #14 from boom switch S12 to resistor R17.                   | Check continuity. Replace if defective.   |
| 4. Defective resistor R17.  | Check continuity. Replace if defective.   |
| 5. Loose or broken wire #14 from resistor R17 to base terminal block.               | Check continuity. Replace if defective.   |
| 6. Loose or broken wire #14 from base terminal block to turret harness plug pin #4. | Check continuity. Replace if defective.   |
| 7. Loose or broken wire #14 from turret harness plug pin #4 to boom up valve 4H-14. | Check continuity. Replace if defective.   |
| 8. Loose or broken wire #02 from turret harness plug to boom up valve 4H-14.        | Check continuity. Replace if defective.   |
| 9. Defective boom up coil 4H-14.  | Check continuity and resistance through coil. Replace if defective.   |



**No Boom Down****NOTE**

*Boom Down may be disabled by the dual load zone system and/or overload system if equipped. Please first ensure the boom is fully retracted and there are no faults in the overload system.*

- |  |   |
|--|---|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to boom switch S12. | <b>Check continuity. Replace if defective.</b>  |
| 2. Defective boom switch S12.  | <b>Check continuity through switch while activating down function between wires #10B and #13. If no continuity found, replace switch.</b> |
| 3. Loose or broken wire #13 from boom down switch S12 to base terminal block.  | <b>Check continuity. Replace if defective. Follow steps on No Boom Down Function from Base or Platform Consoles.</b>                      |

**No Turret Rotate Left**

- |   |  |
|---|--|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to resistor R2.                      | <b>Check continuity. Replace if defective.</b>   |
| 2. Open resistor R2.  | <b>Check resistor for 7 ohms. If no resistance found, replace resistor.</b>  |
| 3. Loose or broken wire #10B from resistor R1 to turret rotate switch S13.                      | <b>Check continuity. Replace if defective.</b>   |
| 4. Defective turret rotate switch S13.  | <b>Check continuity through switch while activating rotate left function between wires #10B and #32. If no continuity found, replace switch.</b> |
| 5. Loose or broken wire #32 from turret rotate switch S13 to base terminal block.               | <b>Check continuity. Replace if defective.</b>   |
| 6. Loose or broken wire #32 from base terminal block to turret harness plug pin #10.            | <b>Check continuity. Replace if defective.</b>   |
| 7. Loose or broken wire #32 from turret harness plug pin #10 to turret rotate left valve 4H-32. | <b>Check continuity. Replace if defective.</b>   |
| 8. Loose or broken wire #02 from turret harness plug to turret rotate left valve 4H-32.         | <b>Check continuity. Replace if defective.</b>   |
| 9. Defective turret rotate left valve coil 4H-32.   | <b>Check continuity and resistance through coil. Replace if defective.</b>   |

**No Turret Rotate Right**

|   |  |
|---|--|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to resistor R2.                      | <b>Check continuity. Replace if defective.</b>   |
| 2. Open resistor R2.  | <b>Check resistor for 7 ohms. If no resistance found, replace resistor.</b>  |
| 3. Loose or broken wire #10B from resistor R1 to turret rotate switch S13.                      | <b>Check continuity. Replace if defective.</b>   |
| 4. Defective turret rotate switch S13.  | <b>Check continuity through switch while activating rotate left function between wires #10B and #33. If no continuity found, replace switch.</b> |
| 5. Loose or broken wire #33 from turret rotate switch S13 to base terminal block.               | <b>Check continuity. Replace if defective.</b>   |
| 6. Loose or broken wire #33 from base terminal block to turret harness plug pin #11.            | <b>Check continuity. Replace if defective.</b>   |
| 7. Loose or broken wire #33 from turret harness plug pin #10 to turret rotate left valve 4H-33. | <b>Check continuity. Replace if defective.</b>   |
| 8. Loose or broken wire #02 from turret harness plug to turret rotate left valve 4H-33.         | <b>Check continuity. Replace if defective.</b>   |
| 9. Defective turret rotate left valve coil 4H-33.   | <b>Check continuity and resistance through coil. Replace if defective.</b>   |

**No Telescope Retract From Base Control Console**

|  |  |
|--|--|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to telescope switch S14.            | <b>Check continuity. Replace if defective.</b>   |
| 2. Defective telescope switch S14.   | <b>Check continuity through switch while activating retract function between wires #10A and #38. If no continuity found, replace switch.</b> |
| 3. Loose or broken wire #38 from telescope switch S14 to base terminal block.                  | <b>Check continuity. Replace if defective.</b>   |
| 4. Loose or broken wire #38 from base terminal block to turret harness plug pin #12.           | <b>Check continuity. Replace if defective.</b>   |
| 5. Loose or broken wire #38 from turret harness plug pin #12 to telescope retract valve 3H-38. | <b>Check continuity. Replace if defective.</b>   |
| 6. Loose or broken wire #02 from turret harness plug to telescope retract valve 3H-38.         | <b>Check continuity. Replace if defective.</b>   |
| 7. Defective telescope retract valve coil 3H-38.   | <b>Check continuity and resistance through coil. Replace if defective.</b>   |

**No Telescope Extend****NOTE**

*Boom Down may be disabled by the dual load zone system and/or overload system if equipped. Please first ensure the boom is fully retracted and there are no faults in the overload system.*

|  |   |
|--|---|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to telescope switch S14.  | <b>Check continuity. Replace if defective.</b>  |
| 2. Defective telescope switch S14.   | <b>Check continuity through switch while activating extend function between wires #10A and #39. If no continuity found, replace switch.</b> |
| 3. Loose or broken wire #39 from telescope switch S14 to base terminal block.        | <b>Check continuity. Replace if defective.</b>  |
| 4. Loose or broken wire #39 from base terminal block to turret harness plug pin #13. | <b>Check continuity. Replace if defective.</b><br><b>Follow steps on No Boom Telescope Extend Function from Base or Platform Consoles.</b>  |

**No Platform Rotate Left**

|   |   |
|---|---|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to platform rotate switch S16.     | <b>Check continuity. Replace if defective.</b>  |
| 2. Defective platform rotate switch S16.  | <b>Check continuity through switch while activating rotate left function between wires #10A and #36. If no continuity found, replace switch.</b>    |
| 3. Open or defective diode D36-1.   | <b>Check diode. Replace if defective.</b>   |
| 4. Loose or broken wire #37A from diode D36-1 to resistor R1.                                 | <b>Check continuity. Replace if defective.</b>  |
| 5. Loose or broken wire #36 from platform rotate switch S16 to base connector plug A pin #18. | <b>Check continuity. Replace if defective.</b>  |
| 6. Loose or broken wire #36 in boom cable A or its connectors.                                | <b>Check for continuity between pins #18 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 7. Loose or broken wire #36 plug A pin #18 to platform terminal block.                        | <b>Check continuity. Replace if defective.</b>  |
| 8. Loose or broken wire #36 from platform terminal block to platform rotate left valve 4H-36. | <b>Check continuity. Replace if defective.</b>  |
| 9. Loose or broken wire #02 from platform terminal block to platform rotate left valve 4H-36. | <b>Check continuity. Replace if defective.</b>  |
| 10. Defective platform rotate left valve coil 4H-36.  | <b>Check continuity and resistance through coil. Replace if defective.</b>  |



**No Platform Rotate Right**

|  |   |
|--|---|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to platform rotate switch S16.      | <b>Check continuity. Replace if defective.</b>  |
| 2. Defective platform rotate switch S16.   | <b>Check continuity through switch while activating rotate right function between wires #10A and #37. If no continuity found, replace switch.</b>   |
| 3. Open or defective diode D37-1.  | <b>Check diode. Replace if defective.</b>   |
| 4. Loose or broken wire #37A from diode D37-1 to resistor R1.                                  | <b>Check continuity. Replace if defective.</b>  |
| 5. Loose or broken wire #37 from platform rotate switch S16 to base connector plug A pin #19.  | <b>Check continuity. Replace if defective.</b>  |
| 6. Loose or broken wire #37 in boom cable A or its connectors.                                 | <b>Check for continuity between pins #19 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 7. Loose or broken wire #37 plug A pin #19 to platform terminal block.                         | <b>Check continuity. Replace if defective.</b>  |
| 8. Loose or broken wire #37 from platform terminal block to platform rotate right valve 4H-37. | <b>Check continuity. Replace if defective.</b>  |
| 9. Loose or broken wire #02 from platform terminal block to platform rotate right valve 4H-37. | <b>Check continuity. Replace if defective.</b>  |
| 10. Defective platform rotate right valve coil 4H-37.  | <b>Check continuity and resistance through coil. Replace if defective.</b>  |

**No Platform Rotate Left or Right**

|  |   |
|--|---|
| 1. Open resistor R1 (ANSI)/ R2 (CE, AS).   | <b>Check resistor for 10 ohms (45T) or 13 ohms (40T). If no resistance found, replace resistor.</b> |
| 2. Loose or broken wire #35A from resistor R2 to base key switch S2. (ANSI)  | <b>Check continuity. Replace if defective</b>   |
| 3. Open or defective base key switch S2.   | <b>Select base control on switch. Check continuity through switch. Replace if defective.</b>        |
| 4. Loose or broken wire #42 from base key switch S2 (ANSI) or resistor R2 (CE, AS) to turret harness plug pin #16. | <b>Check continuity. Replace if defective</b>   |
| 5. Loose or broken wire #42 from turret harness plug pin #16 to proportional flow enable valve 2H-42.              | <b>Check continuity. Replace if defective</b>   |
| 6. Loose or broken wire #02 from turret harness plug to proportional flow enable valve 2H-42.                      | <b>Check continuity. Replace if defective</b>   |
| 7. Defective proportional flow enable valve coil 2H-42.  | <b>Check continuity and resistance through coil. Replace if defective.</b>                          |

**No Jib Up**

|  |   |
|--|---|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to jib switch S17.        | <b>Check continuity. Replace if defective</b>   |
| 2. Defective jib up switch S17.  | <b>Check continuity through switch while activating jib up function between wires #10A and #35. If no continuity found, replace switch.</b>         |
| 3. Open or defective diode D35-1.  | <b>Check diode. Replace if defective.</b>   |
| 4. Loose or broken wire #35A from diode D35-1 to resistor R2.                        | <b>Check continuity. Replace if defective.</b>  |
| 5. Loose or broken wire #35 from jib up switch S17 to base connector plug A pin #17. | <b>Check continuity. Replace if defective</b>   |
| 6. Loose or broken wire #35 in boom cable A or its connectors.                       | <b>Check for continuity between pins #17 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 7. Loose or broken wire #35 from plug A pin #17 to platform terminal block.          | <b>Check continuity. Replace if defective</b>   |
| 8. Loose or broken wire #35 from platform terminal block to jib up valve 4H-35.      | <b>Check continuity. Replace if defective</b>   |
| 9. Loose or broken wire #02 from platform terminal block to jib up valve 4H-35.      | <b>Check continuity. Replace if defective</b>   |
| 10. Defective jib up valve coil 4H-35.   | <b>Check continuity and resistance through coil. Replace if defective.</b>  |

**No Jib Down**

|  |   |
|--|---|
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to jib switch S17.          | <b>Check continuity. Replace if defective</b>   |
| 2. Defective jib down switch S17.  | <b>Check continuity through switch while activating jib down function between wires #10A and #34. If no continuity found, replace switch.</b>       |
| 3. Open or defective diode D34-1.  | <b>Check diode. Replace if defective.</b>   |
| 4. Loose or broken wire #35A from diode D34-1 to resistor R2.                          | <b>Check continuity. Replace if defective</b>   |
| 5. Loose or broken wire #34 from jib down switch S17 to base connector plug A pin #16. | <b>Check continuity. Replace if defective</b>   |
| 6. Loose or broken wire #34 in boom cable A or its connectors.                         | <b>Check for continuity between pins #16 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 7. Loose or broken wire #34 from plug A pin #16 to platform terminal block.            | <b>Check continuity. Replace if defective</b>   |
| 8. Loose or broken wire #34 from platform terminal block to jib down valve 4H-34.      | <b>Check continuity. Replace if defective</b>   |

|   |   |
|---|---|
| 9. Loose or broken wire #02 from platform terminal block to jib down valve 4H-34.                     | <b>Check continuity. Replace if defective</b>   |
| 10. Defective jib down valve coil 4H-34.  | <b>Check continuity and resistance through coil. Replace if defective.</b>  |
| <b>No Jib Up Or Down</b>  |   |
| 1. Loose or broken wire #35A from resistor R2 to base key switch S2.                                  | <b>Check continuity. Replace if defective</b>   |
| 2. Open or defective base key switch S2.  | <b>Select base control console on switch. Check continuity through switch. Replace if defective.</b>  |
| 3. Loose or broken wire #42 from base key switch S2 to turret harness plug pin #16.                   | <b>Check continuity. Replace if defective</b>   |
| 4. Loose or broken wire #42 from turret harness plug pin #16 to proportional flow enable valve 2H-42. | <b>Check continuity. Replace if defective</b>   |
| 5. Loose or broken wire #02 from turret harness plug to proportional flow enable valve 2H-42.         | <b>Check continuity. Replace if defective</b>   |
| 6. Defective proportional flow enable valve coil 2H-42.   | <b>Check continuity and resistance through coil. Replace if defective.</b>  |
| <b>No Manual Platform Level Up</b>  |   |
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to platform level switch S15.              | <b>Check continuity. Replace if defective</b>   |
| 2. Defective platform level switch S15.   | <b>Check continuity through switch while activating level up function between wires #10A and #41. If no continuity found replace switch.</b>        |
| 3. Loose or broken wire #41 from platform level switch S15 to base terminal block.                    | <b>Check continuity. Replace if defective</b>   |
| 4. Loose or broken wire #41 from base terminal block to turret harness pin plug pin#15.               | <b>Check continuity. Replace if defective</b>   |
| 5. Loose or broken wire #41 from turret harness pin plug pin#15 platform level up valve 4H-41.        | <b>Check continuity. Replace if defective</b>   |
| 6. Loose or broken wire #02 from turret harness pin plug platform level up valve 4H-41.               | <b>Check continuity. Replace if defective</b>   |
| 7. Defective platform level up valve coil 4H-41.  | <b>Check continuity and resistance through coil. Replace if defective.</b>  |
| 8. Loose or broken wire #41 from base terminal block to base connector plug B pin #11.                | <b>Check continuity. Replace if defective</b>   |
| 9. Loose or broken wire #41 in boom cable B or its connectors.  | <b>Check for continuity between pins #11 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |



|   |  |
|---|--|
| 10. Loose or broken wire #41 from plug B pin #11 to platform terminal block.                      | Check continuity. Replace if defective   |
| 11. Open diode D41 located in platform terminal block.  | Check diode. Replace if defective.   |
| <b>No Manual Platform Level Down</b>  |  |
| 1. Loose or broken wire #10A from ignition/ pump switch S5 to platform level switch S15.          | Check continuity. Replace if defective   |
| 2. Defective platform level switch S15.   | Check continuity through switch while activating level down function between wires #10A and #40. If no continuity found replace switch.      |
| 3. Loose or broken wire #40 from platform level switch S15 to base terminal block.                | Check continuity. Replace if defective   |
| 4. Loose or broken wire #40 from base terminal block to turret harness pin plug pin #14.          | Check continuity. Replace if defective   |
| 5. Loose or broken wire #40 from turret harness pin plug pin #14 platform level down valve 4H-40. | Check continuity. Replace if defective   |
| 6. Loose or broken wire #02 from turret harness pin plug platform level down valve 4H-40.         | Check continuity. Replace if defective   |
| 7. Defective platform level down valve coil 4H-40.  | Check continuity and resistance through coil. Replace if defective.  |
| 8. Loose or broken wire #40 from base terminal block to base connector plug B pin #10.            | Check continuity. Replace if defective   |
| 9. Loose or broken wire #40 in boom cable B or its connectors.                                    | Check for continuity between pins #10 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective. |
| 10. Loose or broken wire #40 from plug B pin #10 to platform terminal block.                      | Check continuity. Replace if defective   |
| 11. Open diode D40 located in platform terminal block.  | Check diode. Replace if defective.   |

#### 4.2-9 All Controls Inoperative From Platform Control Console

|   |   |
|---|---|
| 1. Open or defective emergency stop switch S4.  | Pull emergency switch out. Check continuity through switch. Replace if defective. |
| 2. Loose or broken wire #4B from emergency stop switch S4 to platform terminal block. | Check continuity. Replace if defective.   |
| 3. Loose or broken jumper wire #4B on emergency stop switch S4.                       | Check continuity. Replace if defective.   |

|  |   |
|--|---|
| 4. Loose or broken pin jumper between #04 and #04A on platform terminal block (without generator option only). | <b>Check continuity. Replace if defective.</b>  |
| 5. Loose or broken wire #04 from platform terminal block to generator switch S22 (generator option only).      | <b>Check continuity. Replace if defective.</b>  |
| 6. Generator switch S22 in generator mode or is open or defective (generator option only).                     | <b>Select OFF mode on generator switch. Check continuity through switch from #04 to #04A. Replace if defective</b>                              |
| 7. Loose or broken wire #04A from generator switch S22 to platform terminal block (generator option only).     | <b>Check continuity. Replace if defective.</b>  |
| 8. Loose or broken wire #04A from platform terminal block to footswitch S11.                                   | <b>Check continuity. Replace if defective.</b>  |
| 9. Open or defective footswitch S11.   | <b>Check continuity through switch while activating footswitch function between wires #04A and #08A. If no continuity found replace switch.</b> |
| 10. Loose or broken wire #08A from footswitch S11 to valve driver pin #16.                                     | <b>Check continuity. Replace if defective.</b>  |
| 11. Loose or broken wire #04 from platform terminal block to valve driver pin #1, 2 & 13.                      | <b>Check continuity. Replace if defective.</b>  |
| 12. Loose or broken wire #02 from platform terminal block to valve driver pin #26.                             | <b>Check continuity. Replace if defective.</b>  |
| 13. No output on pin #6 of the valve driver to wire #08.   | <b>Check pin #6 for 12 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.</b>                  |
| 14. Loose or broken wire #08 from valve driver pin #6 to relay 08CR1.  | <b>Check continuity. Replace if defective.</b>  |
| 15. Loose or broken wire #02 from platform terminal block to relay 08CR1.                                      | <b>Check continuity. Replace if defective.</b>  |
| 16. Loose or broken wire #20D from platform terminal block to relay 08CR1.                                     | <b>Check continuity. Replace if defective.</b>  |
| 17. Loose or broken wire #20 from 08CR1 relay to plug A pin #8 in platform control console.                    | <b>Check continuity. Replace if defective.</b>  |
| 18. Defective relay 08CR1.   | <b>Check relay. Replace if defective.</b>   |

**No Manual Platform Level Up****NOTE**

*This function times out after 15 seconds when operating this function only*

- |  |   |
|--|---|
| 1. Loose or broken wire #08 from platform terminal block (ANSI) or wire 26A from OCM pin 19 (CE, AS) to platform level switch S19. | <b>Check continuity. Replace if defective.</b>  |
| 2. Defective platform level switch S19.  | <b>Check continuity through switch while activating level up function between wires #08 and #41. If no continuity found replace switch.</b> |
| 3. Loose or broken wire #41 from platform level switch S19 to platform terminal block.   | <b>Check continuity. Replace if defective.</b>  |
| 4. Open diode D41 located in platform terminal block.  | <b>Check diode. Replace if defective.</b>   |

**No Manual Platform Level Down****NOTE**

*This function times out after 15 seconds when operating this function only*

- |  |   |
|--|---|
| 1. Loose or broken wire #08 from platform terminal block to platform level switch S19. | <b>Check continuity. Replace if defective.</b>  |
| 2. Defective platform level switch S19.  | <b>Check continuity through switch while activating level up function between wires #08 and #40. If no continuity found replace switch.</b> |
| 3. Loose or broken wire #40 from platform level switch S19 to platform terminal block. | <b>Check continuity. Replace if defective.</b>  |
| 4. Open diode D40 located in platform terminal block.                                  | <b>Check diode. Replace if defective.</b>   |

**No Boom Up From Platform Control Console**

- |   |  |
|---|--|
| 1. Loose or broken wire #04 from platform terminal block to joystick controller A1. | <b>Check continuity. Replace if defective.</b>   |
| 2. Loose or broken wire #02 from platform terminal block to joystick controller A1. | <b>Check continuity. Replace if defective.</b>   |
| 3. No output on y-axis of joystick controller A1.                                   | <b>Refer to joystick test procedure in section 5.</b>  |
| 4. Loose or broken wire “Y” from joystick controller A1 to valve driver pin #29.    | <b>Check continuity. Replace if defective.</b>   |
| 5. No output on pin #5 of the valve driver to wire #20B.                            | <b>Check pin #5 for 12 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.</b> |



|   |   |
|---|---|
| 6. No output on pin #22 of the valve driver to wire #14.  | Check pin #22 for minimum 3.5 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.           |
| 7. Loose or broken wire #14 from valve driver pin #22 to plug A pin #7 in platform control console. | Check continuity. Replace if defective.   |
| 8. Loose or broken wire #14 in boom cable A or its connectors.                                      | Check for continuity between pins #7 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective. |
| 9. Loose or broken wire #14 from base connector plug A pin #7 to base terminal block.               | Check continuity. Replace if defective.   |
| 10. Loose or broken wire #14 from base terminal block to turret harness plug pin #4.                | Check continuity. Replace if defective.   |
| 11. Loose or broken wire #14 from turret harness plug pin #4 to boom up valve 4H-14.                | Check continuity. Replace if defective.   |
| 12. Loose or broken wire #02 from turret harness plug to boom up valve 4H-14.                       | Check continuity. Replace if defective.   |
| 13. Defective boom up valve coil 4H-14.   | Check continuity and resistance through coil. Replace if defective.   |

**No Boom Down****NOTE**

*Boom Down may be disabled by the dual load zone system and/or overload system if equipped. Please first ensure the boom is fully retracted and there are no faults in the overload system.*

|  |   |
|--|---|
| 1. Loose or broken wire #04 from platform terminal block to joystick controller A1.                | Check continuity. Replace if defective.   |
| 2. Loose or broken wire #02 from platform terminal block to joystick controller A1.                | Check continuity. Replace if defective.   |
| 3. No output on y-axis of joystick controller A1.  | Refer to joystick test procedure in section 5.  |
| 4. Loose or broken wire "Y" from joystick controller A1 to valve driver pin #29.                   | Check continuity. Replace if defective.   |
| 5. No output on pin #5 of the valve driver to wire #20B.   | Check pin #5 for 12 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.                     |
| 6. No output on pin #8 of the valve driver to wire #13.  | Check pin #8 for minimum 3.5 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.            |
| 7. Loose or broken wire #13 from valve driver pin #8 to plug A pin #6 in platform control console. | Check continuity. Replace if defective.   |
| 8. Loose or broken wire #13 in boom cable A or its connectors.                                     | Check for continuity between pins #6 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective. |

- |   |   |
|---|---|
| 9. Loose or broken wire #13 from base connector plug A pin #6 to base terminal block. | <b>Check continuity. Replace if defective.</b>  |
| 10. Loose or broken wire #13 from base terminal block to turret harness plug pin #3.  | <b>Check continuity. Replace if defective.<br/>Go to No Boom Lower Function from Base or Platform Control Consoles.</b> |

**No Turret Left**

- |  |   |
|--|---|
| 1. Loose or broken wire #04 from platform terminal block to joystick controller A1.                  | <b>Check continuity. Replace if defective.</b>  |
| 2. Loose or broken wire #02 from platform terminal block to joystick controller A1.                  | <b>Check continuity. Replace if defective.</b>  |
| 3. No output on x-axis of joystick controller A1.  | <b>Refer to joystick test procedure in section 5.</b>   |
| 4. Loose or broken wire "X" from joystick controller A1 to valve driver pin #28.                     | <b>Check continuity. Replace if defective.</b>  |
| 5. No output on pin #5 of the valve driver to wire #20B.   | <b>Check pin #5 for 12 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.</b>                      |
| 6. No output on pin #20 of the valve driver to wire #32.   | <b>Check pin #20 for minimum 3.5 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.</b>            |
| 7. Loose or broken wire #32 from valve driver pin #20 to plug A pin #14 in platform control console. | <b>Check continuity. Replace if defective.</b>  |
| 8. Loose or broken wire #32 in boom cable A or its connectors.                                       | <b>Check for continuity between pins #14 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 9. Loose or broken wire #32 from base connector plug A pin #14 to base terminal block.               | <b>Check continuity. Replace if defective.</b>  |
| 10. Loose or broken wire #32 from base terminal block to turret harness plug pin #10.                | <b>Check continuity. Replace if defective.</b>  |
| 11. Loose or broken wire #32 from turret harness plug pin #10 to turret left valve 4H-32.            | <b>Check continuity. Replace if defective.</b>  |
| 12. Loose or broken wire #02 from turret harness plug to turret left valve 4H-32.                    | <b>Check continuity. Replace if defective.</b>  |
| 13. Defective turret left valve coil 4H-32.  | <b>Check continuity and resistance through coil. Replace if defective.</b>  |

**No Turret Right**

- |   |  |
|---|--|
| 1. Loose or broken wire #04 from platform terminal block to joystick controller A1. | <b>Check continuity. Replace if defective.</b> |
| 2. Loose or broken wire #02 from platform terminal block to joystick controller A1. | <b>Check continuity. Replace if defective.</b> |

|  |  |
|--|--|
| 3. No output on x-axis of joystick controller A1.  | Refer to joystick test procedure in section 5.   |
| 4. Loose or broken wire "X" from joystick controller A1 to valve driver pin #28.                     | Check continuity. Replace if defective.  |
| 5. No output on pin #5 of the valve driver to wire #20B.   | Check pin #5 for 12 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.  |
| 6. No output on pin #35 of the valve driver to wire #33.   | Check pin #10 for minimum 3.5 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.  |
| 7. Loose or broken wire #33 from valve driver pin #35 to plug A pin #15 in platform control console. | Check continuity. Replace if defective.  |
| 8. Loose or broken wire #33 in boom cable A or its connectors.                                       | Check for continuity between pins #15 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.                             |
| 9. Loose or broken wire #33 from base connector plug A pin #15 to base terminal block.               | Check continuity. Replace if defective.  |
| 10. Loose or broken wire #33 from base terminal block to turret harness plug pin #11.                | Check continuity. Replace if defective.  |
| 11. Loose or broken wire #33 from turret harness plug pin #11 to turret right valve 4H-33.           | Check continuity. Replace if defective.  |
| 12. Loose or broken wire #02 from turret harness plug to turret right valve 4H-33.                   | Check continuity. Replace if defective.  |
| 13. Defective turret right valve coil 4H-33.   | Check continuity and resistance through coil. Replace if defective.  |
| <b>No Telescope In</b>   |  |
| 1. Loose or broken purple wire from speed controller to resistor R9 in platform control console.     | Check continuity. Replace if defective.  |
| 2. Open or defective resistor R9.  | Check resistor. Replace if defective.  |
| 3. Loose or broken wire #38B from resistor R9 to telescope switch S18.                               | Check continuity. Replace if defective.  |
| 4. Defective telescope switch S18.   | Check continuity through switch while activating the function between wires #38B and #38A.   |
| 5. Loose or broken wire #38A from telescope switch S18 to valve driver pin #32.                      | Check continuity. Replace if defective.  |
| 6. Voltage out of range at valve driver pin #32.   | Check voltage while operating telescope in. Voltage should be between 4.75 and 5.25 volts. Refer to telescope voltage reference table in section 5 if out of this range. |



|  |   |
|--|---|
| 7. No output on pin #5 of the valve driver to wire #20B.   | Check pin #5 for 12 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.                     |
| 8. No output on pin #9 of the valve driver to wire #38.  | Check pin #9 for minimum 3.5 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.            |
| 9. Loose or broken wire #38 from valve driver pin #9 to plug B pin #8 in platform control console. | Check continuity. Replace if defective.   |
| 10. Loose or broken wire #38 in boom cable B or its connectors.                                    | Check for continuity between pins #8 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective. |
| 11. Loose or broken wire #38 from base connector plug B pin #8 to base terminal block.             | Check continuity. Replace if defective.   |
| 12. Loose or broken wire #38 from base terminal block to turret harness plug pin #12.              | Check continuity. Replace if defective.   |
| 13. Loose or broken wire #38 from turret harness plug pin #12 to telescope in valve 3H-38.         | Check continuity. Replace if defective.   |
| 14. Loose or broken wire #02 from turret harness plug to telescope in valve 3H-38.                 | Check continuity. Replace if defective.   |
| 15. Defective telescope in valve coil 3H-38.   | Check continuity and resistance through coil. Replace if defective.   |

### No Telescope Out



#### NOTE

Telescope extend function may be disabled by the dual load zone system and/or overload system if equipped. Please first ensure the boom is fully retracted and there are no faults in the overload system.

|  |   |
|--|---|
| 1. Loose or broken purple wire from speed controller to resistor R9 in platform control console. | Check continuity. Replace if defective.   |
| 2. Open or defective resistor R9.  | Check resistor. Replace if defective.   |
| 3. Loose or broken wire #38B from resistor R9 to telescope switch S18.                           | Check continuity. Replace if defective.   |
| 4. Open or defective resistor R10.   | Check resistor. Replace if defective.   |
| 5. Defective telescope switch S18.   | Check continuity through switch while activating the function between wires #38C and #38A.  |
| 6. Loose or broken wire #38A from telescope switch S18 to valve driver pin #32.                  | Check continuity. Replace if defective.   |
| 7. Voltage out of range at valve driver pin #32.   | Check voltage while operating telescope out. Voltage should be between 2.25 and 2.75 volts. Refer to telescope voltage reference table in section 5 if out of this range. |

|   |  |
|---|--|
| 8. No output on pin #5 of the valve driver to wire #20B.  | Check pin #5 for 12 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.                      |
| 9. No output on pin #12 of the valve driver to wire #39.  | Check pin #12 for minimum 3.5 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.            |
| 10. Loose or broken wire #39 from valve driver pin #12 to plug B pin #9 in platform control console.  | Check continuity. Replace if defective.  |
| 11. Loose or broken wire #39 in boom cable B or its connectors.                                       | Check for continuity between pins #9 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective.  |
| 12. Loose or broken wire #39 from base connector plug B pin #9 to base terminal block.                | Check continuity. Replace if defective.  |
| <b>No Platform Rotate or Jib Function</b>   |  |
| 1. Loose or broken wire #08 from platform terminal block to rotate switch S20 and jib switch S21.     | Check continuity. Replace if defective.  |
| 2. No output on pin #21 of the valve driver to wire #42.  | Check pin #20 for minimum 3.5 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.            |
| 3. Loose or broken wire #42 from valve driver pin #21 to plug B pin #24 in platform control console.  | Check continuity. Replace if defective.  |
| 4. Loose or broken wire #42 in boom cable B or its connectors.  | Check for continuity between pins #24 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective. |
| 5. Loose or broken wire #42 from base connector plug B pin #24 to base key switch S2.                 | Check continuity. Replace if defective.  |
| 6. Loose or broken wire #42 from base key switch S2 to turret harness plug pin #16.                   | Check continuity. Replace if defective.  |
| 7. Loose or broken wire #42 from turret harness plug pin #16 to proportional flow enable valve 2H-42. | Check continuity. Replace if defective.  |
| 8. Loose or broken wire #02 from turret harness plug to proportional flow enable valve 2H-42.         | Check continuity. Replace if defective.  |
| 9. Defective proportional flow enable valve 2H-42.  | Check continuity and resistance through coil. Replace if defective.  |
| <b>No Platform Rotate Left</b>  |  |
| 1. Defective platform rotate switch S20.  | Check continuity through switch while activating rotate left function between wires #08 and #36.   |
| 2. Loose or broken wire #36 from platform rotate switch S20 to platform terminal block.               | Check continuity. Replace if defective.  |

|  |  |
|--|--|
| 3. Loose or broken jumper wire #36 on platform terminal block.                               | <b>Check continuity. Replace if defective.</b>   |
| 4. Open or defective diode D36 in platform terminal block.                                   | <b>Check diode. Replace if defective.</b>  |
| 5. Loose or broken wire #36A from platform terminal block to valve driver pin #17.           | <b>Check continuity. Replace if defective.</b>   |
| 6. Loose or broken wire #36 or #02 from platform terminal block to rotate left valve 4H-36.  | <b>Check continuity. Replace if defective.</b>   |
| 7. Defective rotate left valve coil 4H-36.   | <b>Check continuity and resistance through coil. Replace if defective.</b>                               |
| <b>No Platform Rotate Right</b>  |  |
| 1. Defective platform rotate switch S20.   | <b>Check continuity through switch while activating rotate right function between wires #08 and #37.</b> |
| 2. Loose or broken wire #37 from platform rotate switch S20 to platform terminal block.      | <b>Check continuity. Replace if defective.</b>   |
| 3. Loose or broken jumper wire #37 on platform terminal block.                               | <b>Check continuity. Replace if defective.</b>   |
| 4. Open or defective diode D37 in platform terminal block.                                   | <b>Check diode. Replace if defective.</b>  |
| 5. Loose or broken wire #36A from platform terminal block to valve driver pin #17.           | <b>Check continuity. Replace if defective.</b>   |
| 6. Loose or broken wire #37 or #02 from platform terminal block to rotate right valve 4H-37. | <b>Check continuity. Replace if defective.</b>   |
| 7. Defective rotate right Valve coil 4H-37.  | <b>Check continuity and resistance through coil. Replace if defective.</b>                               |
| <b>No Jib Up</b>   |  |
| 1. Defective jib switch S21.   | <b>Check continuity through switch while activating jib up function between wires #08 and #35.</b>       |
| 2. Loose or broken wire #35 from jib switch S21 to platform terminal block.                  | <b>Check continuity. Replace if defective.</b>   |
| 3. Loose or broken jumper wire #35 on platform terminal block.                               | <b>Check continuity. Replace if defective.</b>   |
| 4. Open or defective diode D35 in platform terminal block.                                   | <b>Check diode. Replace if defective.</b>  |
| 5. Loose or broken wire #34A from platform terminal block to valve driver pin #33.           | <b>Check continuity. Replace if defective.</b>   |
| 6. Loose or broken wire #35 or #02 from platform terminal block to jib up valve 4H-35.       | <b>Check continuity. Replace if defective.</b>   |
| 7. Defective jib up valve coil 4H-35.  | <b>Check continuity and resistance through coil. Replace if defective.</b>                               |

**No Jib Down**

|  |  |
|--|--|
| 1. Defective jib switch S21.   |  |
| 2. Loose or broken wire #34 from jib switch S21 to platform terminal block.              | <b>Check continuity. Replace if defective.</b>                             |
| 3. Loose or broken jumper wire #34 on platform terminal block.                           | <b>Check continuity. Replace if defective.</b>                             |
| 4. Open or defective diode D34 in platform terminal block.                               | <b>Check diode. Replace if defective.</b>                                  |
| 5. Loose or broken wire #34A from platform terminal block to valve driver pin #33.       | <b>Check continuity. Replace if defective.</b>                             |
| 6. Loose or broken wire #34 or #02 from platform terminal block to jib down valve 4H-34. | <b>Check continuity. Replace if defective.</b>                             |
| 7. Defective jib down valve coil 4H-34.  | <b>Check continuity and resistance through coil. Replace if defective.</b> |

**4.2-10 Throttle Inoperative, Mid and High - Deutz D2.9L**

|  |   |
|--|---|
| 1. Loose or broken wire #90 from base terminal block to connector J2 pin #5.       | <b>Check continuity. Replace if defective.</b>  |
| 2. Loose or broken wire #90 from connector P2 pin #5 94 pin ECU connector pin 80.  | <b>Check continuity. Replace if defective.</b>  |
| 3. Loose or broken wire #99 from base terminal block to connector J2 pin 4         | <b>Check continuity. Replace if defective.</b>  |
| 4. Loose or broken wire #99 from connector P2 pin 4 to 94 pin ECU connector pin 74 | <b>Check continuity. Replace if defective.</b>  |
| 5. Resistor R4 open or poor connection at base terminal block.                     | <b>Measure resistance (1K<math>\Omega</math>) between 99 and 99A. Check connections. Replace if defective.</b>    |
| 6. Resistor R5 open or poor connection at base terminal block.                     | <b>Measure resistance (3.3K<math>\Omega</math>) between 99A and 99B. Check connections. Replace if defective.</b> |
| 7. Resistor R6 open or poor connection at base terminal block.                     | <b>Measure resistance (3.9K<math>\Omega</math>) between 99B and 90. Check connections. Replace if defective.</b>  |



### 4.2-11 Mid Throttle Inoperative

|   |   |
|---|---|
| 1. Loose or broken wire #08 from platform terminal block to throttle switch S10.                    | <b>Check continuity. Replace if defective.</b>  |
| 2. Open or defective diode D08. (Generator option only)   | <b>Check diode. Replace if defective.</b>   |
| 3. Defective throttle switch S10.   | <b>Check continuity through switch while activating mid throttle function between wires #08 and #79. If no continuity found replace switch.</b>     |
| 4. Loose or broken wire #79 from throttle switch S10 to plug B pin #20 in platform control console. | <b>Check continuity. Replace if defective.</b>  |
| 5. Loose or broken wire #79 in Cable B or its connectors.   | <b>Check for continuity between pins #20 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| <b>With the following conditions:</b>   |   |
| ▪ Deutz D2.9L Diesel  |   |
| 6. Loose or broken wire #79 from base plug B pin #20 to relay 79CR.                                 | <b>Check continuity. Replace if defective.</b>  |
| 7. Loose or broken wire #02 from base terminal block to relay 79CR.                                 | <b>Check continuity. Replace if defective.</b>  |
| 8. Loose or broken wire #90 from relay 79CR to base terminal block.                                 | <b>Check continuity. Replace if defective.</b>  |
| 9. Loose or broken wire #99B from relay 79CR to base terminal block.                                | <b>Check continuity. Replace if defective.</b>  |
| 10. Defective relay 79CR.   | <b>Check relay. Replace if defective.</b>   |
| <b>With the following conditions:</b>   |   |
| ▪ Deutz D2011 Diesel  |   |
| 11. Loose or broken wire #79 from base plug B pin #20 to relay 79CR.                                | <b>Check continuity. Replace if defective.</b>  |
| 12. Loose or broken wire #02 from base terminal block to relay 79CR.                                | <b>Check continuity. Replace if defective.</b>  |
| 13. Loose or broken wire #99 from relay 79CR to ECU connector pin #18.                              | <b>Check continuity. Replace if defective.</b>  |
| 14. Loose or broken wire #103 from relay 79CR to base terminal block.                               | <b>Check continuity. Replace if defective.</b>  |
| 15. Loose or broken wire #103 from base terminal block to ECU connector pin #17.                    | <b>Check continuity. Replace if defective.</b>  |
| 16. Defective relay 79CR.   | <b>Check relay. Replace if defective.</b>   |

## 4.2-12 High Throttle Inoperative

|   |   |
|---|---|
| 1. Loose or broken wire #08 from platform terminal block to throttle switch S10.                    | <b>Check continuity. Replace if defective.</b>  |
| 2. Defective throttle switch S10.   | <b>Check continuity through switch while activating high throttle function between wires #08 and #78. If no continuity found replace switch.</b>    |
| 3. Loose or broken wire #78 from throttle switch S10 to plug B pin #19 in platform control console. | <b>Check continuity. Replace if defective.</b>  |
| 4. Loose or broken wire #78 in Cable B or its connectors.   | <b>Check for continuity between pins #19 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| <b>With the following conditions:</b>   |   |
| <ul style="list-style-type: none"> <li>▪ Deutz D2.9L Diesel</li> </ul>                              |   |
| 5. Loose or broken wire #78 from base plug B pin #19 to relay 78CR.                                 | <b>Check continuity. Replace if defective.</b>  |
| 6. Loose or broken wire #02 from base terminal block to relay 78CR.                                 | <b>Check continuity. Replace if defective.</b>  |
| 7. Loose or broken wire #90 from relay 78CR to base terminal block.                                 | <b>Check continuity. Replace if defective.</b>  |
| 8. Loose or broken wire #99A from relay 78CR to base terminal block.                                | <b>Check continuity. Replace if defective.</b>  |
| 9. Defective relay 78CR.  | <b>Check relay. Replace if defective.</b>   |
| <b>With the following conditions:</b>   |   |
| <ul style="list-style-type: none"> <li>▪ Deutz D2011 Diesel</li> </ul>                              |   |
| 10. Loose or broken wire #78 from base plug B pin #17 to relay 78CR.                                | <b>Check continuity. Replace if defective.</b>  |
| 11. Loose or broken wire #02 from base terminal block to relay 78CR.                                | <b>Check continuity. Replace if defective.</b>  |
| 12. Loose or broken wire #90 from relay 78CR to ECU connector pin #21.                              | <b>Check continuity. Replace if defective.</b>  |
| 13. Loose or broken wire #103 from relay 78CR to base terminal block.                               | <b>Check continuity. Replace if defective.</b>  |
| 14. Loose or broken wire #103 from base terminal block to ECU connector pin #17.                    | <b>Check continuity. Replace if defective.</b>  |
| 15. Defective relay 78CR.   | <b>Check relay. Replace if defective.</b>   |

### 4.2-13 Brake will not Release

|   |   |
|---|---|
| 1. No output on pin #10 from valve driver to wire #26 when operating a drive function.              | <b>Check pin #10 for 12 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.</b>                     |
| 2. Loose or broken wire #26 from valve drive pin #10 to plug A pin #11 in platform control console. | <b>Check continuity. Replace if defective.</b>  |
| 3. Loose or broken wire #26 in Cable A or its connectors.   | <b>Check for continuity between pins #11 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 4. Loose or broken wire #26 from base plug A pin #11 to turret harness plug pin #8.                 | <b>Check continuity. Replace if defective.</b>  |
| 5. Loose or broken wire #26 or #02 from turret harness plug to brake valve 3H-26.                   | <b>Check continuity. Replace if defective.</b>  |
| 6. Defective brake valve coil 3H-26.  | <b>Check continuity and resistance through coil. Replace if defective.</b>  |

### 4.2-14 No Drive and Steer



#### NOTE

*Aerial platform will not drive or steer if it is tilted and off limit switches.*

|   |  |
|---|--|
| 1. Loose or broken wire #4 from platform terminal block to drive joystick A2 in platform control console. | <b>Check continuity. Replace if defective.</b>         |
| 2. Loose or broken wire #02 from platform terminal block to drive joystick A2.                            | <b>Check continuity. Replace if defective.</b>         |
| 3. Defective drive joystick A2.   | <b>See drive joystick test procedure in section 5.</b> |

#### No Forward Drive

|   |  |
|---|--|
| 1. No output on "D" when forward is selected on drive joystick A2.                                  | <b>See drive joystick test procedure in section 5.</b>   |
| 2. Loose or broken wire "D-signal" from drive joystick A2 to valve driver pin #27.                  | <b>Check continuity. Replace if defective.</b>   |
| 3. No output from valve driver pin #34 to wire #16.   | <b>Check pin #34 for minimum 2 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.</b> |
| 4. Loose or broken wire #16 from valve driver pin #34 to plug B pin #5 in platform control console. | <b>Check continuity. Replace if defective.</b>   |

|   |   |
|---|---|
| 5. Loose or broken wire #5 in cable B or its connectors.                                  | Check for continuity between pins #5 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective. |
| 6. Loose or broken wire #16 from base plug B pin #5 to turret harness plug pin #21.       | Check continuity. Replace if defective.   |
| 7. Loose or broken wire #16 or #02 from turret harness plug to forward drive valve 3H-16. | Check continuity. Replace if defective.   |
| 8. Defective forward drive valve coil 3H-16.  | Check continuity and resistance through coil. Replace if defective.   |

**No Reverse Drive**

|   |   |
|---|---|
| 1. No output on "D" when forward is selected on drive joystick A2.                                  | See drive joystick test procedure in section 5.   |
| 2. Loose or broken wire "D-signal" from drive joystick A2 to valve driver pin #27.                  | Check continuity. Replace if defective.   |
| 3. No output from valve driver pin #23 to wire #15.   | Check pin #23 for minimum 2 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.             |
| 4. Loose or broken wire #15 from valve driver pin #23 to plug B pin #4 in platform control console. | Check continuity. Replace if defective.   |
| 5. Loose or broken wire #15 in cable B or its connectors.   | Check for continuity between pins #4 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective. |
| 6. Loose or broken wire #15 from base plug B pin #4 to turret harness plug pin #20.                 | Check continuity. Replace if defective.   |
| 7. Loose or broken wire #15 or #02 from turret harness plug to reverse drive valve 3H-15.           | Check continuity. Replace if defective.   |
| 8. Defective reverse drive valve coil 3H-15.  | Check continuity and resistance through coil. Replace if defective.   |

**No Left Steer****NOTE**

*This function times out after 15 seconds when operating this function only.*

|  |   |
|--|---|
| 1. Loose or broken wire #24 from drive joystick A2 to platform terminal block. | Check continuity. Replace if defective. |
| 2. Open or defective diode D24 in platform terminal block.                     | Check diode. Replace if defective.      |
| 3. Loose or broken wire #24 from platform terminal block to relay 17ACR1.      | Check continuity. Replace if defective. |
| 4. Defective N/C contacts in relay 17ACR1.                                     | Check relay. Replace if defective.      |



|   |   |
|---|---|
| 5. Loose or broken wire #24A from relay 17ACR1 to plug A pin #10 in platform control console. | <b>Check continuity. Replace if defective.</b>  |
| 6. Loose or broken wire #24A in boom cable A or its connectors.                               | <b>Check for continuity between pins #10 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 7. Loose or broken wire #24A from base plug A pin #10 in base terminal block.                 | <b>Check continuity. Replace if defective.</b>  |
| 8. Loose or broken wire #24A from base terminal block to turret harness plug pin #7.          | <b>Check continuity. Replace if defective.</b>  |
| 9. Loose or broken wire #24A or #02 from turret harness plug to left steer valve 4H-24A.      | <b>Check continuity. Replace if defective.</b>  |
| 10. Defective left steer valve coil 4H-24A.   | <b>Check continuity and resistance through coil. Replace if defective.</b>  |

### No Right Steer



#### NOTE

*This function times out after 15 seconds when operating this function only.*

|  |  |
|--|--|
| 1. Loose or broken wire #23 from drive joystick A2 to platform terminal block.               | <b>Check continuity. Replace if defective.</b>   |
| 2. Open or defective diode D23 in platform terminal block.                                   | <b>Check diode. Replace if defective.</b>  |
| 3. Loose or broken wire #23 from platform terminal block to relay 17ACR2.                    | <b>Check continuity. Replace if defective.</b>   |
| 4. Defective N/C contacts in relay 17ACR2.   | <b>Check relay. Replace if defective.</b>  |
| 5. Loose or broken wire #23A from relay 17ACR2 to plug A pin #9 in platform control console. | <b>Check continuity. Replace if defective.</b>   |
| 6. Loose or broken wire #23A in boom cable A or its connectors.                              | <b>Check for continuity between pins #9 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 7. Loose or broken wire #23A from base plug A pin #9 to base terminal block.                 | <b>Check continuity. Replace if defective.</b>   |
| 8. Loose or broken wire #23A from base terminal block to turret harness plug pin #6.         | <b>Check continuity. Replace if defective.</b>   |
| 9. Loose or broken wire #23A or #02 from turret harness plug to right steer valve 4H-23A.    | <b>Check continuity. Replace if defective.</b>   |
| 10. Defective left steer valve coil 4H-23A.  | <b>Check continuity and resistance through coil. Replace if defective.</b>   |

## 4.2-15 No High Speed Drive



### NOTE

*Aerial platform must be level and boom must be below 15 degrees and fully retracted for high speed drive.*

|   |   |
|---|---|
| 1. Loose or broken wire #09 from base terminal block to limit switch LS2.                               | <b>Check continuity. Replace if defective.</b>  |
| 2. Open or defective limit switch LS2.  | <b>Ensure boom is below 15 degrees. Adjust switch if required. Check continuity through switch. Replace if required.</b>                            |
| 3. Loose or broken wire #29 from limit switch LS2 to base terminal block.                               | <b>Check continuity. Replace if defective.</b>  |
| 4. Loose or broken wire #29 from base terminal block to limit switch LS3.                               | <b>Check continuity. Replace if defective.</b>  |
| 5. Open or defective limit switch LS3.  | <b>Ensure boom is fully retracted. Adjust switch if required. Check continuity through switch. Replace if defective.</b>                            |
| 6. Loose or broken wire #59 from limit switch LS3 to base terminal block.                               | <b>Check continuity. Replace if defective.</b>  |
| 7. Loose or broken wire #59 from base terminal block to plug B pin #15.                                 | <b>Check continuity. Replace if defective.</b>  |
| 8. Loose or broken wire #59 in boom cable B or its connectors.  | <b>Check for continuity between pins #15 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 9. Loose or broken wire #59 from plug B pin #15 in platform control console to platform terminal block. | <b>Check continuity. Replace if defective.</b>  |
| 10. Loose or broken wire #59 from platform terminal block to valve driver pin #31.                      | <b>Check continuity. Replace if defective.</b>  |
| 11. Defective valve driver channel input for high drive enable.   | <b>See section 5 for OCM pin voltage reference.</b>   |
| 12. Loose or broken wire #59 from platform terminal block to torque switch S48.                         | <b>Check continuity. Replace if defective.</b>  |
| 13. Open or defective torque switch S48.  | <b>Check continuity through switch while activating low torque function between wires #59 and #45. If no continuity found replace switch.</b>       |
| 14. Loose or broken wire #45 from torque switch S48 to plug A pin #20 in platform control console.      | <b>Check continuity. Replace if defective.</b>  |
| 15. Loose or broken wire #45 in cable A or its connectors.  | <b>Check for continuity between pins #20 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |

|  |   |
|--|---|
| 16. Loose or broken wire #45 from base plug A pin #20 to relay 45CR1.                  | Check continuity. Replace if defective.                             |
| 17. Loose or broken wire #02 from base terminal block to relay 45CR1.                  | Check continuity. Replace if defective.                             |
| 18. Loose or broken wire #09 from base terminal block to relay 45CR1.                  | Check continuity. Replace if defective.                             |
| 19. Defective relay 45CR1.   | Check relay. Replace if defective.                                  |
| 20. Loose or broken wire #45A from base terminal block to turret harness plug pin #17. | Check continuity. Replace if defective.                             |
| 21. Loose or broken wire #45A or #02 from turret harness plug to 2 speed valve 3H-45A. | Check continuity. Replace if defective.                             |
| 22. Defective 2 speed valve 3H-45A.  | Check continuity and resistance through coil. Replace if defective. |

#### 4.2-16 No Elevated Drive



#### NOTE

*Aerial platform must be level to drive elevated.*

|   |   |
|---|---|
| 1. Loose or broken wire #09 or #02 from base terminal block to angle transducer/ tilt switch AT1. | Check continuity. Replace if defective.   |
| 2. Misadjusted, no output or defective angle transducer/ tilt switch AT1.                         | Adjust angle transducer/ tilt switch if required. Check for 12 volts on wire #28. If no voltage present with angle transducer/ tilt switch adjusted it is defective, replace angle transducer/ tilt switch. |
| 3. Loose or broken wire #28 from level sensor TS1 to plug B pin #7.                               | Check continuity. Replace if defective.   |
| 4. Loose or broken wire #28 in cable B or its connectors.   | Check for continuity between pins #7 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective.   |
| 5. Loose or broken wire #28 from plug B pin #7 to platform terminal block.                        | Check continuity. Replace if defective.   |
| 6. Loose or broken wire #28 from platform terminal block to valve driver pin #18.                 | Check continuity. Replace if defective.   |

### 4.2-17 Direction Sensing Inoperative

|  |  |
|--|--|
| 1. Loose or broken wire #09 from base terminal block to limit switch LS1.                                | <b>Check continuity. Replace if defective.</b>   |
| 2. Open or defective limit switch LS1.   | <b>Adjust limit switch if required. Check continuity through switch. Replace if defective.</b>   |
| 3. Loose or broken wire #17 from limit switch LS1 to base terminal block.                                | <b>Check continuity. Replace if defective.</b>   |
| 4. Loose or broken wire #17 from base terminal block to base plug B pin #6.                              | <b>Check continuity. Replace if defective.</b>   |
| 5. Loose or broken wire #17 in boom cable B or its connectors.   | <b>Check for continuity between pins #6 on cable B. Check for loose or corroded connections on cable connectors. Replace if wire is defective.</b> |
| 6. Loose or broken wire #17 from base plug B pin #6 to valve driver pin #15 in platform control console. | <b>Check continuity. Replace if defective.</b>   |
| 7. Defective valve driver channel input for direction sense enable.                                      | <b>See section 5 for OCM pin voltage reference.</b>  |

### 4.2-18 Steer Direction Sensing Inoperative

|   |  |
|---|--|
| 1. No output on valve driver pin #4 to wire #17A.                                     | <b>Check pin #4 for 12 volts. If no voltage present with foot on footswitch check section 5 for OCM pin voltage reference.</b> |
| 2. Loose or broken wire #17A from valve driver pin #4 to relays 17ACR1 and 17ACR2.    | <b>Check continuity. Replace if defective.</b>   |
| 3. Loose or broken wire #02 from platform terminal block to relays 17ACR1 and 17ACR2. | <b>Check continuity. Replace if defective.</b>   |
| 4. Defective relays 17ACR1 and 17ACR2.  | <b>Check relay. Replace if defective.</b>  |



#### **NOTE**

*If only one relay is bad and one is OK, you will have steer in one direction only.*



#### 4.2-19 No boom down or extend Functions from Base or Platform Consoles (ANSI)

|  |  |
|--|--|
| 1. Defective diode D09-1 in base control console.  | <b>Check diode. Replace if defective.</b>  |
| 2. Loose or broken wire #9B from base terminal block to LS4 (boom angle) and/or LS5 (boom extension) dual load zone limit switches.  | <b>Check continuity. Replace if defective.</b>   |
| 3. Open or defective limit switch LS4. Switch is NCHO (normally open held open). Closed above 57°                                    | <b>Adjust limit switch if required. Check continuity through switch. Replace if defective.</b> |
| 4. Open or defective limit switch LS5. Switch is NC (normally closed). Open beyond   | <b>Adjust limit switch if required. Check continuity through switch. Replace if defective.</b> |
| 5. Loose or broken wire #121 from LS4 (boom angle) and/or LS5 (boom extension) dual load zone limit switches to base terminal block. | <b>Check continuity. Replace if defective.</b>   |
| 6. Loose or broken wire #121 from base terminal block to boom down and boom extend cut out relays CR121 and 121CR2.                  | <b>Check continuity. Replace if defective.</b>   |

#### 4.2-20 No boom down Function from Base or Platform Consoles (ANSI)

|   |  |
|---|--|
| 1. Loose or broken wire #13 from base terminal block to 121CR pin 30.           | <b>Check continuity. Replace if defective.</b>                             |
| 2. Loose or broken wire #02 from 121CR relay pin 86 to ground.                  | <b>Check continuity. Replace if defective.</b>                             |
| 3. Defective relay 121CR.   | <b>Check relay. Replace if defective</b>                                   |
| 4. Loose or broke wire #13A from 121CR relay to harness plug pin #3.            | <b>Check continuity. Replace if defective.</b>                             |
| 5. Loose or broke wire #13A from harness plug pin #3 to boom down valve 4H-13A. | <b>Check continuity. Replace if defective.</b>                             |
| 6. Loose or broken wire #02 from turret harness plug to boom down valve 4H-13A. | <b>Check continuity. Replace if defective.</b>                             |
| 7. Defective boom down coil 4H-13A.   | <b>Check continuity and resistance through coil. Replace if defective.</b> |

#### 4.2-21 No boom extend Function from Base or Platform Consoles (ANSI)

|  |   |
|--|---|
| 1. Loose or broken wire #39 from base terminal block to 121CR2 pin 30.             | Check continuity. Replace if defective.                             |
| 2. Loose or broken wire #02 from 121CR2 relay pin 86 to ground.                    | Check continuity. Replace if defective.                             |
| 3. Defective relay 121CR2.   | Check relay. Replace if defective                                   |
| 4. Loose or broke wire #39A from 121CR2 relay to harness plug pin #13.             | Check continuity. Replace if defective.                             |
| 5. Loose or broke wire #39A from harness plug pin #13 to boom extend valve 4H-39A. | Check continuity. Replace if defective.                             |
| 6. Loose or broken wire #02 from turret harness plug to boom extend valve 4H-39A.  | Check continuity. Replace if defective.                             |
| 7. Defective boom extend coil 4H-39A.  | Check continuity and resistance through coil. Replace if defective. |

#### 4.2-22 No boom down Function from Base or Platform Consoles (CE, AS)

|  |   |
|--|---|
| 1. Loose or broken wire #13 from base terminal block to load sense/dual load zone module white connector J4 pin 7. | Check continuity. Replace if defective.   |
| 2. No output on load sense/dual load zone module white connector J4 pin 5 to wirer 13A.                            | Check pin #5 for 12 volts. If no voltage present when operating down function check section 5 for module information. |
| 3. Loose or broke wire #13A from load sense/dual load zone module white connector J4 pin 5 to harness plug pin #3. | Check continuity. Replace if defective.   |
| 4. Loose or broke wire #13A from harness plug pin #3 to boom down valve 4H-13A.                                    | Check continuity. Replace if defective.   |
| 5. Loose or broken wire #02 from turret harness plug to boom down valve 4H-13A.                                    | Check continuity. Replace if defective.   |
| 6. Defective boom down coil 4H-13A.  | Check continuity and resistance through coil. Replace if defective.   |

#### 4.2-23 No boom extend Function from Base or Platform Consoles (CE, AS)

- |  |  |
|--|--|
| 1. Loose or broken wire #39 from base terminal block to load sense/dual load zone module white connector J4 pin 6. | <b>Check continuity. Replace if defective.</b>   |
| 2. No output on load sense/dual load zone module white connector J4 pin 3 to wirer 39A.                            | <b>Check pin #5 for 12 volts. If no voltage present when operating down function check section 5 for module information.</b> |
| 3. Loose or broke wire #13A from load sense/dual load zone module white connector J4 pin 5 to harness plug pin #3. | <b>Check continuity. Replace if defective.</b>   |
| 4. Loose or broke wire #13A from harness plug pin #3 to boom down valve 4H-13A.                                    | <b>Check continuity. Replace if defective.</b>   |
| 5. Loose or broken wire #02 from turret harness plug to boom down valve 4H-13A.                                    | <b>Check continuity. Replace if defective.</b>   |
| 6. Defective boom down coil 4H-13A.  | <b>Check continuity and resistance through coil. Replace if defective.</b>   |

To order go to Discount-Equipment.com

## 4.3 Hydraulic System

### 4.3-1 All Controls Inoperative

- |  |   |
|--|---|
| 1. Broken or defective drive pump shaft or coupling. | <b>Check pump shaft and coupling. Replace if defective.</b> |
| 2. Hydraulic oil level low.                          | <b>Check oil level. Fill to proper level.</b>               |

### 4.3-2 All Boom Functions Inoperative

- |  |  |
|--|--|
| 1. Open or defective dump/ enable valve 2H-21A.      | <b>Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required.</b> |
| 2. Stuck or defective relief valve RV1.              | <b>Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required.</b>    |
| 3. System pump P2 out of adjustment or is defective. | <b>Refer to section 5 for pump set up procedure. Replace if defective.</b>                                 |
| 4. Defective load sense adjusting valve 3H-V2.       | <b>Check valve. Replace if defective.</b>  |
| 5. Defective pressure compensator valve 3H-V1.       | <b>Check valve. Replace if defective.</b>  |
| 6. Plugged or defective high pressure filter F1.     | <b>Check filter. Replace if plugged or defective.</b>  |

### 4.3-3 No Main Boom Up

- |  |  |
|--|--|
| 1. Stuck or defective differential sensing valve DSV2. | <b>Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required.</b> |
| 2. Stuck or defective lift up valve 4H-14.             | <b>Clean valve. Check operation of valve. Repair or replace valve as required.</b>                         |
| 3. Stuck or defective shuttle valve SV2.               | <b>Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required.</b> |
| 4. Stuck or defective check valve CV5.                 | <b>Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required.</b> |
| 5. Stuck or defective counterbalance valve CB3.        | <b>Clean valve. Check O-rings on valve. Repair or replace valve as required.</b>                           |
| 6. Defective lift cylinder C1.                         | <b>Check seals on cylinder. Replace as necessary. Replace cylinder if defective.</b>                       |

### 4.3-4 No Main Boom Down



|  |   |
|--|---|
| 1. Stuck or defective differential sensing valve DSV2. | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Stuck or defective lift up valve 4H-13.             | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 3. Stuck or defective shuttle valve SV2.               | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 4. Stuck or defective check valve CV5.                 | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 5. Stuck or defective counterbalance valve CB3.        | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 6. Defective lift cylinder C1.                         | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

### 4.3-5 No Turret Rotate

#### Left Rotate

|  |   |
|--|---|
| 1. Stuck or defective differential sensing valve DSV1. | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Stuck or defective rotate left valve 4H-32.         | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 3. Stuck or defective shuttle valve SV1.               | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 4. Stuck or defective check valve CV4.                 | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 5. Stuck or defective relief valve RV2.                | Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required.    |
| 6. Stuck or defective shuttle valve SV7.               | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 7. Stuck or defective counterbalance valve CB2.        | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 8. Turret rotate brake BR1 not releasing.              | Inspect brake for worn seals or broken components. Repair and replace as necessary.                 |
| 9. Worn or defective swing drive motor M2.             | Check motor. Repair or replace if defective.  |

#### Right Rotate

|  |   |
|--|---|
| 1. Stuck or defective differential sensing valve DSV1. | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Stuck or defective rotate left valve 4H-33.         | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 3. Stuck or defective shuttle valve SV1.               | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |

|   |   |
|---|---|
| 4. Stuck or defective check valve CV4.          | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 5. Stuck or defective relief valve RV2.         | Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required.    |
| 6. Stuck or defective shuttle valve SV7.        | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 7. Stuck or defective counterbalance valve CB1. | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 8. Turret rotate brake BR1 not releasing.       | Inspect brake for worn seals or broken components. Repair and replace as necessary.                 |
| 9. Worn or defective swing drive motor M2.      | Check motor. Repair or replace if defective.  |

#### 4.3-6 No Boom Extend

|  |   |
|--|---|
| 1. Stuck or defective differential sensing valve DSV3.           | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Stuck or defective boom extend valve 3H-39.                   | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 3. Stuck or defective check valve CV11.                          | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 4. Stuck or defective check valve CV6.                           | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 5. Stuck or defective relief valve RV4.                          | Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required.    |
| 6. Return valve V5 stuck in the open position.                   | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 7. Stuck or defective counterbalance valve CB4.                  | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 8. Return valve V4 stuck in the closed position or is defective. | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 9. Defective extension cylinder C2.                              | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

#### 4.3-7 No Boom Retract

|  |   |
|--|---|
| 1. Stuck or defective differential sensing valve DSV3.           | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Stuck or defective boom extend valve 3H-38.                   | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 3. Stuck or defective check valve CV10.                          | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 4. Stuck or defective check valve CV6.                           | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 5. Stuck or defective relief valve RV4.                          | Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required.    |
| 6. Return valve V4 stuck in the open position.                   | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 7. Stuck or defective counterbalance valve CB5.                  | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 8. Return valve V5 stuck in the closed position or is defective. | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 9. Defective extension cylinder C2.                              | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

#### 4.3-8 No Jib Up

|   |   |
|---|---|
| 1. Stuck or defective proportional flow enable valve 2H-42. | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Stuck or defective check valve CV9.                      | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 3. Stuck or defective jib up valve 4H-35.                   | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 4. Stuck or defective counterbalance valve CB9.             | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 5. Defective jib cylinder C5.                               | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

### 4.3-9 No Jib Down

|   |   |
|---|---|
| 1. Stuck or defective proportional flow enable valve 2H-42. | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Stuck or defective check valve CV9.                      | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 3. Stuck or defective jib up valve 4H-34.                   | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 4. Stuck or defective counterbalance valve CB8.             | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 5. Defective jib cylinder C5.                               | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

### 4.3-10 No Platform Rotation

#### Right Rotation

|   |   |
|---|---|
| 1. Stuck or defective proportional flow enable valve 2H-42. | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Stuck or defective check valve CV9.                      | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 3. Stuck or defective jib up valve 4H-37.                   | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 4. Stuck or defective counterbalance valve CB11.            | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 5. Defective rotary actuator RA1.                           | Check actuator. Repair or replace as necessary.   |

#### Left Rotation

|   |   |
|---|---|
| 1. Stuck or defective proportional flow enable valve 2H-42. | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Stuck or defective check valve CV9.                      | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |



|  |   |
|--|---|
| 3. Stuck or defective jib up valve 4H-36.        | Clean valve. Check operation of valve. Repair or replace valve as required. |
| 4. Stuck or defective counterbalance valve CB10. | Clean valve. Check O-rings on valve. Repair or replace valve as required.   |
| 5. Defective rotary actuator RA1.                | Check actuator. Repair or replace as necessary.                             |

### 4.3-11 Platform will not Level

#### Level Down

|   |   |
|---|---|
| 1. Stuck or defective platform level down valve 4H-40.  | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 2. Stuck or defective dual check valve DCV2.            | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 3. Stuck or defective check valve CV8.                  | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 4. Stuck or defective shuttle valve SV3.                | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 5. Stuck or defective relief valve RV3.                 | Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required.    |
| 6. Stuck or defective counterbalance valve CB6.         | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 7. Plugged orifice OR2.                                 | Check orifice. Clean if plugged or replace if defective.  |
| 8. Defective leveling cylinder C3 or slave cylinder C4. | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

#### Level Up

|   |   |
|---|---|
| 1. Stuck or defective platform level down valve 4H-41.  | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 2. Stuck or defective dual check valve DCV2.            | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 3. Stuck or defective check valve CV7.                  | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 4. Stuck or defective shuttle valve SV3.                | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 5. Stuck or defective relief valve RV3.                 | Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required.    |
| 6. Stuck or defective counterbalance valve CB7.         | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 7. Plugged orifice OR2.                                 | Check orifice. Clean if plugged or replace if defective.  |
| 8. Defective leveling cylinder C3 or slave cylinder C4. | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

#### 4.3-12 Brake will not Release

|  |   |
|--|---|
| 1. Stuck or defective shuttle valve SV5.                 | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Defective or misadjusted pressure reducing valve PR1. | Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required.    |
| 3. Stuck or defective brake valve 3H-26.                 | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 4. Stuck or defective shuttle valve SV6.                 | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 5. Defective or misadjusted relief valve RV5.            | Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required.    |
| 6. Stuck or defective brake release override valve V1.   | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 7. Bypassing or defective brake hand pump V3.            | Clean valve. Check O-rings on valve. Repair or replace valve as required.                           |
| 8. Bypassing or defective brake cylinder BR1.            | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

#### 4.3-13 Brake will not Engage

|   |   |
|---|---|
| 1. Brake return spring or defective cylinder.   | Check cylinder. Repair or replace as necessary. |
| 2. Brake valve 3H-26 stuck in shifted position. | Check valve. Replace if defective.              |
| 3. Brake in axle out of adjustment.             | See section 5 for brake adjustment procedure.   |

### 4.3-14 No Drive

#### **Forward or Reverse**

|   |  |
|---|--|
| 1. Brake not releasing.                                   | See “brake will not release” in this section.  |
| 2. Defective or misadjusted charge pump relief valve RV8. | Set valve to specifications. Check O-rings and clean valve. Repair or replace valve as required. |
| 3. Worn charge pump P1A.                                  | Check pump. Replace if defective.  |
| 4. Defective pump displacement control 4H-15 and 4H-16.   | Check control. Replace if defective.   |
| 5. Open bypass valve V6.                                  | Close bypass valve.  |
| 6. Worn or defective drive pump P1.                       | Check pump. Replace if defective.  |
| 7. Worn or defective drive motor M1.                      | Check motor. Replace if defective.   |

#### **Forward Drive**

|   |   |
|---|---|
| 1. Defective pump displacement control 4H-16.       | Check control. Replace if defective.            |
| 2. Defective or misadjusted drive relief valve RV6. | See section 5 for drive pump set up procedures. |

#### **Reverse Drive**

|   |   |
|---|---|
| 1. Defective pump displacement control 4H-15.       | Check control. Replace if defective.            |
| 2. Defective or misadjusted drive relief valve RV7. | See section 5 for drive pump set up procedures. |

### 4.3-15 Differential Lock will not Engage

|   |   |
|---|---|
| 1. Stuck or defective differential lock valve 3H-165.     | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Bypassing or defective differential lock cylinder C10. | Check seals on cylinder. Replace as necessary. Replace cylinder if defective                        |

### 4.3-16 No High Speed Drive

|   |   |
|---|---|
| 1. Stuck or defective 2 speed valve 3H-45.  | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 2. Defective shift spool in drive motor M1. | Check motor. Repair or replace if necessary.  |

### 4.3-17 No Steer

#### Steer Right

|   |   |
|---|---|
| 1. Stuck or defective right steer valve 4H-23A.       | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 2. Stuck or defective dual check valve DCV2.          | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 3. Stuck or defective check valve CV2.                | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 4. Plugged orifice OR1.                               | Check orifice. Clean if plugged or replace if defective.  |
| 5. Defective steer cylinder C8 for 4WD or C9 for 2WD. | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

#### Steer Left

|   |   |
|---|---|
| 1. Stuck or defective right steer valve 4H-24A.       | Clean valve. Check operation of valve. Repair or replace valve as required.                         |
| 2. Stuck or defective dual check valve DCV2.          | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 3. Stuck or defective check valve CV3.                | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
| 4. Plugged orifice OR1.                               | Check orifice. Clean if plugged or replace if defective.  |
| 5. Defective steer cylinder C8 for 4WD or C9 for 2WD. | Check seals on cylinder. Replace as necessary. Replace cylinder if defective.                       |

#### Axle Will Not Oscillate



#### NOTE

*Axle will only oscillate when boom is fully retracted and is no greater than 15 degrees above horizontal.*

|  |   |
|--|---|
| 1. Stuck or defective axle lockout valve 3H-65.                                      | Clean valve. Replace if defective.  |
| 2. One or more counterbalance valves (CB12 or CB13) failed to shift or is defective. | Clean valve. Check O-rings on valve. Repair or replace valve as required. |

#### Axle Will Not Lock



#### NOTE

*Axle is in constant float if boom is fully retracted and is below 15 degrees of elevation.*

|   |   |
|---|---|
| 1. Axle lockout valve 3H-65 is stuck in shifted position or is defective. | Clean valve. Check O-rings on valve. Check operation of valve. Repair or replace valve as required. |
|---|---|



- 
- |   |  |
|---|--|
| 2. Bypassing or defective axle cylinders C6 and C7.                         | <b>Check seals on cylinder. Replace as necessary. Replace cylinder if defective.</b> |
| 3. Counterbalance valves (CB12 or CB13) out of adjustment or are defective. | <b>Clean valve. Check O-rings on valve. Repair or replace valve as required.</b>     |
- 

To order go to [Discount-Equipment.com](http://Discount-Equipment.com)

## 4.4 Load Sensing System - CE

### 4.4-1 Green LED on Load Sense/Dual Load Zone Module is not on

1. Loose or broken wires #9 and #02 at base terminal block to load sense/dual load zone module white connector J4 pins #8 and #1

Check for connections. Check for voltage (12V).

### 4.4-2 Load Sense indicates overload or overload warning with platform empty or below weight


1. Load cell has lost its calibration.

Refer to calibration procedure for recalibration of load cell.

2. Load cell circuit not operating.

Check Voltage across 1Ω (ohm) resistors 161 and 162 in base control console.

Put volt meter across the two 161 blocks to measure voltage across the 1 ohm resistor.  
 Empty platform = 8.7 - 9.2 mV (0.0087 V - 0.0092 V)  
 500 lbs (227 kg) = 15.9 - 16.4 mV (0.0159 V - 0.0164 V)  
 748 lbs (339 kg) = 19.6 - 20.1 mV (0.0196 V - 0.0201 V)



Voltage across 162 resistor should match voltage across 161.

### 4.4-3 Load Sense/Dual Load Zone Module Error

**When a fault is detected, the module outputs will have limited operation depending on the fault type:**

**For ANY and all faults:**

- Load zone border light is turned on
- Low capacity lamp and high capacity lamp will flash alternately
- Overload lamp will flash
- The Red diagnostic LED on The module will be illuminated (no flashing)

**If a short circuit is detected on wire 120, 82, or 119:**

- The output that is shorted will be disabled (open, high Z to ground)
- 120 shorted: high capacity light on solid, border light on solid, overload light flashes
- 82 shorted: capacity lights flash alternately, border light on solid, overload light off
- 119 shorted: capacity lights flash alternately, border light off, overload light flashes

**If a short circuit is detected on any safety contact (wire 162B, 13A, or 39A):**

- All safety contacts will be disabled (opened)
- Stowed Position: all functions are available
- Off limits (boom extended and/or boom above 10°): No functions and overload alarm pulses with overload light.

**If the measured load falls below the tare (no load/empty platform) calibration point by 2.0mA, for 1.5 seconds:**

- 13A is disabled (open) – Down Function is disabled. Will self-clear when the measured load returns to normal.
- Module Amber and Green diagnostic LEDs flash together

**If a discrepancy is detected between the load cell analog inputs (delta > 2mA for 2.0 seconds):**

- Wire 162B, 13A, and 39A are disabled (opened) - - Stowed Position: all functions are available: lower and retract functions may not be operable. Off limits: (boom extended and/or boom above 10°): No functions and overload alarm pulses with overload light.
- Module Amber and Green diagnostic LEDs on the module flash alternately

**To reset the module hold the actuator button down for 5 seconds, or shut the MEWP platform power off using the ignition switch or e-stop..**

#### 4.4-4 No Light/Alarm when Platform is Overloaded

##### **Overload Indicator Light does not Turn On when Platform is Overloaded:**

|  |   |
|--|---|
| 1. Defective lamp  | Check lamp. Replace if defective  |
| 2. Load cell circuit not operating.  | Check Voltage across 1Ω (ohm) resistors 161 and 162 in base control console. See Fig. 1 above   |
| 3. Load sense/dual load zone module out of calibration.                          | Calibrate module. Refer to section 5 of this manual for procedure.  |
| 4. No output from module.  | Check Voltage at black connector J3 pin #3 for 12V when platform is loaded with 110% of rated capacity. (Boom fully retracted and 12" (30cm) off the ground.) |
| 5. Loose or broken wire #82 from the base terminal strip to connector A pin #13. | Check continuity. Replace if defective.   |
| 6. Loose or broken wire #82 in boom cable A or its connectors.                   | Check for continuity between pins #13 on cable A. Check for loose or corroded connections on cable connectors. Replace if wire is defective.                  |
| 7. Loose or broken wire #13 plug A pin #13 to 82CR pin 85.                       | Check continuity. Replace if defective.   |
| 8. Defective relay 82CR.   | Check relay. Replace if defective.  |
| 9. Load cell circuit not operating.  | Check for connections with wire #02A at pilot light strip and relay 82CR, and wire #82 at platform terminal block and relay 82CR.                             |

##### **Audible Alarm does not Turn ON when Platform is Overloaded:**

|   |   |
|---|---|
| 1. Defective alarm BP3.   | Check alarm. Replace if defective.      |
| 2. Loose or broken wire #13 plug A pin #13 to 162ACR1 pin 30.         | Check continuity. Replace if defective. |
| 3. Loose or broken wire #118 from relay 162ACR1 to alarm BP3          | Check continuity. Replace if defective. |
| 4. Loose or broken wire #2 from alarm BP3 to platform terminal block. | Check continuity. Replace if defective. |
| 5. Defective relay 162ACR1.   | Check relay. Replace if defective.      |



# Section 5 – Procedures

## 5.1 General

The following information is provided to assist you in the use and application of servicing and maintenance procedures contained in this chapter.

### NOTE

The illustrations shown in this manual are for instructional purposes only. The models and components shown may appear somewhat different from those on your actual MEWP.



### 5.1-1 Safety and Workmanship

Your safety, and that of others, is the first consideration when engaging in the maintenance of equipment. Always be conscious of weight. Never attempt to move heavy parts without the aid of a mechanical device. Do not allow heavy objects to rest in an unstable position. When raising a portion of the equipment, ensure that adequate support is provided.

Before performing routine maintenance underneath the boom, support it using a maintenance support or equivalent supporting device. Refer to Figure 01 and 5.1-2 How to Install the Boom Maintenance Support. Contact Skyjack Parts to order a maintenance support.

### WARNING

**Remove all material and personnel from the platform while using the maintenance support(s).**

1. Park the MEWP on a firm, level surface.
2. Retract and lower the boom and platform until the MEWP is in the stowed position.
3. Turn the engine off.
4. Pull out the emergency stop buttons  on the base controls and on the platform controls.
5. Turn the battery disconnect switch to the off position .

After completing any procedure which involves modifying, adjusting, or replacing any hydraulic or electrical components, perform all of the function tests given in your unit's Operating Manual.

### WARNING

**Make sure you maintain three points of contact when mounting and dismounting the platform.**

### WARNING

**Do not operate any platform controls without the proper fall protection secured to the designated location in the platform. Failure to do so could result in death or serious injury!**

### WARNING

**Make sure there are no people or obstructions in the test area, and there is sufficient space for the boom and drive functions required for the given procedures.**




Figure 01 Support location


## 5.1-2 How to Install the Boom Maintenance Support

The boom maintenance support, or an equivalent supporting device in the same location capable of supporting a minimum of 106 757 N (24,000 lbf), must be used whenever work is done underneath the boom. Refer to 5.1-1 Safety and Workmanship.


### IMPORTANT

Due to the weight of the maintenance support and the size of the MEWP, it is recommended that you have a second person assist with this procedure.



1. Raise the boom to an angle of 40°.




2. Open the engine side cowling. Remove and set aside the fixed cowling from the engine side of the boom. There are six sets of hardware to remove - one outside the cowling and five inside the cowling.




3. Check that the bottom of the main lift cylinder is clear of the maintenance support notch in the turret wall. If it is not, raise the boom higher.



4. Make sure the lock-pin is out of the support.
5. Lift the boss end of the maintenance support bar over the notch in the turret wall. Then angle it downward a little and slide it under the main lift cylinder.




- Continue to slide the support bar in. Set the boss end in the notch in the opposite turret wall. Note: The boss must be on the inside of the turret.




### IMPORTANT

Do not lower the main lift cylinder onto the maintenance support bar. The bottom of the cylinder should stop just above the support.



- Push the lock-pin through the hole in the maintenance support. Make sure the detent ball comes all the way out the other side.



## 5.2 Platform


### 5.2-1 Human Machine Interface (HMI)

Maintaining proper calibration is essential for good performance of the aerial platform.

To access the SCM console, open the platform control cover.

The SCM has an integrated multi segment, two line display with membrane keys that allow it to be used as the main interface to system controls and adjustments. The Human Machine Interface (referred to as the HMI) will serve as your window into the application software to allow the operator to monitor/adjust the following information:

- Active Function Being Used
- Part Number and Serial Number
- Restore the Factory Default Settings
- Output Calibrations (Tresh, Max, Ramp.etc)
- I-O Status
- CANBus Status



### 5.2-2 User Interface Keys

|     |  |  |
|-----|--|--|
| 1.0 |  | 1.0-1 <MENU> enters a new menu screen and/or<br>1.0-2 <SELECT> select the flashing item.   |
| 1.1 |  | 1.1-1 <MINUS> decreases an adjustable parameter such as ramp time.<br>1.1-2 <DOWN> selects the previous item in the current menu's list. |
| 1.2 |  | 1.2-1 <PLUS> increases an adjustable parameter.<br>1.2-2 <UP> selects the next item in the current menu's list.                          |
| 1.3 |  | 1.3-1 <SAVE> saves the new data to EEPROM (permanent memory storage).  |
| 1.4 |  | Simultaneously pressing <UP> and <DOWN> resets the HMI to menu screen 0.   |



### 5.2-3 SCM Character Functions Charts

| SCM Keypad  |            |
|-------------|------------|
| Keys        | Short Form |
| Menu/Select | (M/S)      |
| ▼/-         | (-)        |
| ▲/+         | (+)        |
| Save/Exit   | (S/E)      |

| Function Attribute |                |
|--------------------|----------------|
| THRESH             | Threshold      |
| RAMPDN             | Ramp Down      |
| RAMPUP             | Ramp Up        |
| LOWRNG             | Low Range      |
| MAXOUT             | Maximum Output |

1345AA

| SCM Function (Channel) Names |                         |
|------------------------------|-------------------------|
| DRIVE REV Fn01A              | Drive Reverse           |
| DRIVE FWD Fn01B              | Drive Forward           |
| ROTATE L Fn02A               | Turret Rotate Left      |
| ROTATE R Fn02B               | Turret Rotate Right     |
| BOOM DOWN Fn03A              | Main Boom Down          |
| BOOM UP Fn03B                | Main Boom Up            |
| FLY IN Fn04A                 | Boom Telescope Retract  |
| FLY OUT Fn04B                | Boom Telescope Extend   |
| PROP FLOW Fn05A              | Jib and Platform Rotate |
| PROP FLOW Fn05B              | Unused Channel          |
| LR REV Fn06A                 | Virtual Channel         |
| LR FEW Fn06B                 | Virtual Channel         |


1369AA

### 5.2-4 SCM Operating Values Chart

| Input  | Expected Value       | Description                             |
|--------|----------------------|---|
| AI 1   | 0.5V to 8.5V         | Drive Joystick                          |
| AI 2   | 0.5V to 8.5V         | Turret Rotation Joystick                |
| AI 3   | 0.5V to 8.5V         | Boom Elevation Joystick                 |
| AI 4   | 0.5V to 7.5V         | Flow Enable Rotary Potentiometer        |
| DI 1   | 0 or 1               | Direction Reverse Limit Switch          |
| DI 2   | 0 or 1               | Footswitch Actuated                     |
| DI 3   | 0 or 1               | Telescope Out Toggle Switch             |
| DI 4   | 0 or 1               | Telescope In Toggle Switch              |
| DI 5   | 0 or 1               | Jib Toggle Enabled                      |
| DI 6   | 0 or 1               | Platform Rotation Toggle Enabled        |
| DI 11  | 0 or 1               | High Speed Drive Enable Limit Switch    |
| Output | Adjustable Parameter | Description                             |
| PWM 1  | 25 to 75%            | Drive Reverse                           |
| PWM 2  | 25 to 75%            | Drive Forward                           |
| PWM 3  | 21 to 35%            | Turret Rotate Left                      |
| PWM 4  | 21 to 35%            | Turret Rotate Right                     |
| PWM 5  | 21 to 35%            | Main Boom Down                          |
| PWM 6  | 38 to 47%            | Main Boom Up                            |
| PWM 7  | 0 to 100%            | Jib and Platform Rotate                 |
| PWM 11 | 40 to 48%            | Boom Telescope Retract                  |
| PWM 12 | 45 to 70%            | Boom Telescope Extend                   |
| Output | Expected Value       | Description                             |
| DOUT 1 | 0 or 1               | Steering Reverse Relay                  |
| DOUT 2 | 0 or 1               | Load Sense Valve Enable                 |
| DOUT 3 | 0 or 1               | Footswitch Actuated Indicator           |
| DOUT 4 | 0 or 1               | Holding Brake OFF (energize to release) |
| DOUT 5 | 0 or 1               | Manual Platform Level Enable            |

1371AA

### 5.2-5 How to Select SCM Functionality




**STD** Machines for the North American market (ANSI/CSA models)  
**LTD** Machines for the European market (CE models)

Recycle power to the OCM with E-Stop to re-enable password protection.  
 If the OCM is inactive for more than 5 minutes, password must be re-entered.

### 5.2-6 How to View SCM Operation


As a joystick or toggle switch is being activated, the OCM screen will display the active function and % output. Also, the following procedure will allow monitoring of all input and output channels:



See 5.2-4 SCM Operating Values Chart for operating values for the previous observations.




5.2-7 How to Unlock and Modify SCM Settings



Recycle power to the SCM with the E-Stop to re-enable password protection.  
 If the SCM is inactive for more than 5 minutes, password must be re-entered.

## 5.2-8 SCM Pin Voltage Reference



All voltages given are with SCM controller at maximum % adjustable settings.  
 All voltages should be tested with key on, engine off and foot switch depressed.  
 All tests should be performed with platform over drive axle, boom fully stowed and on flat level surface.

- Pin 1 - 12 volt input from wire 4.  
 Test between pin 1 and 02 wire.
- Pin 2 - 12 volt input from wire 4.  
 Test between pin 2 and 02 wire.
- Pin 3 - 8 volt output (purple wire) to boom speed controller.  
 7.5 volts= speed control in circuit. Test between pin 3 and 02 wire.
- Pin 4 - Turret position. 12 volt output on wire 17A to relays 17ACR1 and 17ACR2 for directional sensing.  
 0 volts= Platform over drive axle.  
 12 volts= Platform over steer axle. Test between pin 4 and 02 wire.
- Pin 5 - 12 volt output on wire 20B to load sense dump valve when any function selected.  
 Test between pin 5 and 02 wire while selecting a function.
- Pin 6 - 12 volt output on wire 08 to boom control switches.  
 Test between pin 6 and 02 wire.
- Pin 7 - 12 volt output on wire 65 to axle lock valve 3H-65 to float axle. 0 volts when above limit switches.  
 Test between pin 7 and 02 wire.
- Pin 8 - Boom down selected. Proportional output on wire 13 to boom down valve 4H-13.  
 0 volts to 4.85 volts depending on position of joystick. Threshold= 1.5 volts. Test between pin 8 and 02 wire while operating boom down.
- Pin 9 - Telescope in selected. Proportional output on wire 38 to telescope in valve 3H-38.  
 0 volts to 4.65 volts depending on boom speed control potentiometer.  
 Threshold= .95 volts.  
 Test between pin 9 and 02 wire while operating telescope in.



- Pin 10 - 12 volt output on wire 26 to brake valve 3H-26 to release brakes.  
Test between pin 10 and 02 wire.
- Pin 11- 12 volt output on wire 27 to tilt alarm relay 27CR.  
Test between pin 11 and 02 wire.
- Pin 12 - Telescope out selected. Proportional output on wire 39 to telescope out valve 3H-39.  
0 volts to 6.8 volts depending on boom speed control potentiometer position. Threshold= .95 volts.  
Test between pin 12 and 02 wire while operating telescope out.
- Pin 13 - 12 volt input from wire 4.  
Test between pin 13 and 02 wire.
- Pin 14 - Variable input from wire 128A.  
1 volt to 5 volts depending on angle of machine.  
1 volt = Level.  
Test between pin 14 and 02 wire.
- Pin 15 - Turret position. 12 volt input from wire 17 (limit switch LS1).  
0 volts= Platform over drive axle.  
12 volts= Platform over steer axle.  
Test between 15 and 02 wire.
- Pin 16 - Foot switch activated. 12 volt input from wire 08A.  
Test between pin 16 and 02 wire.
- Pin 17 - Platform rotate selected. 12 volt input from wire 36A.  
Test between pin 17 and 02 wire.
- Pin 18 - 12 volt input from angle sensor on wire 28. 12V= <5 degrees.  
Test between pin 18 and 02 wire.
- Pin 19 - Diff. lock enable toggle switch (ANSI/CSA & CE) / Platform level toggle switch (CE only).  
Driving = 0 volts  
Not driving = 12 to 13.5 volts
- Pin 20 - Turret rotate left selected. Proportional output on wire 32 to turret rotate left valve 4H-32.  
0 volts to 5 volts depending on position of joystick. Threshold= .5 volts. Test between pin 20 and 02 wire while operating turret rotate left.
- Pin 21 - Platform rotate or jib function selected. Proportional output on wire 42 to proportional flow enable valve 2H-42.  
0 volts to 3.85 volts while operating platform rotate depending on boom speed control potentiometer position. Threshold= 2.3 volts.  
0 volts to 9 volts while operating jib function depending on boom speed control potentiometer position.  
Threshold= 2.3 volts.  
Test between pin 21 and 02 wire.
- Pin 22 - Boom up selected. Proportional output on wire 14 to boom up valve 4H-14.  
0 volts to 6.3 volts depending on joystick position. Threshold= 1.5 volts. Test between pin 22 and 02 wire while operating boom up.

- Pin 23 - Reverse drive selected. Proportional output on wire 15 to reverse drive valve 3H-15.  
0 volts to 7.5 volts depending on joystick position. Threshold= 1.5 volts. Test between pin 23 and 02 wire while operating reverse drive.
- Pin 24 - Battery negative. Wire 02.
- Pin 25 - Battery negative. Wire 02.
- Pin 26 - Battery negative. Wire 02.
- Pin 27 - Accelerator input. Wire D from drive joystick controller.  
Neutral position= 4.2 volts to 4.8 volts. Forward function= 4.9 volts to 8.5 volts. Reverse function= 4.1 volts to .5 volts. Test between pin 27 and 02 wire.
- Pin 28 - Turret rotate input. Wire X from boom joystick controller.  
Neutral position= 4.2 volts to 4.8 volts. Rotate right function= 4.9 volts to 8.5 volts. Rotate left function= 4.1 volts to .5 volts. Test between pin 28 and 02 wire.
- Pin 29 - Boom elevation input. Wire Y from boom joystick controller.  
Neutral position= 4.2 volts to 4.8 volts. Boom up function= 4.9 volts to 8.5 volts. Boom down function= 4.1 volts to .5 volts. Test between pin 29 and 02 wire.
- Pin 30 - Accelerator input. Signal wire (green wire) from boom speed controller.  
Proportional voltage. .5 volts= slow speed up to 7.5 volts= fast speed.  
Test between pin 30 and 02 wire while operating telescope in/out, jib up/down or basket rotate.
- Pin 31 - 12 volt input from wire 59. From LS2 boom elevation limit switch and LS3 telescope limit switch.  
12 volts= full speed. 0 volts= creep speed (one or more limit switches open). Test between pin 31 and 02 wire.
- Pin 32 - Telescope selected. Input from wire 38A.  
Neutral position= 3.58 volts.  
Telescope in function= 4.83 volts.  
Telescope out function= 2.41 volts.  
Test between pin 32 and 02 wire.
- Pin 33 - Jib function enable. 12 volt input from wire 34A.  
Test between pin 33 and 02 wire.
- Pin 34 - Forward drive selected. Proportional output on wire 16 to forward drive valve 3H-16.  
0 volts to 7.5 volts depending on joystick position. Threshold= 1.5 volts. Test between pin 34 and 02 wire while operating forward drive.
- Pin 35 - Turret rotate right selected. Proportional output on wire 33 to turret rotate right valve 4H-33.  
0 volts to 5 volts depending on position of joystick. Threshold= .5 volts. Test between pin 10 and 02 wire while operating turret rotate right.





### 5.2-9 Fly Boom Switch Voltage References

TELESCOPE SWITCH WORKSHEET  
VOLTAGE DIVIDER CIRCUIT



### 5.2-10 Platform Controller Voltage References



## 5.3 Load Sensing System

### 5.3-1 Load Sensing System Overload Status

The platform load sensing system is a device that senses for an overload on the platform before the system disables boom and drive functions. This system is active when the MEWP is powered on.

If the platform is overloaded while in work mode (boom is raised greater than 15 degrees from horizontal or is extended greater than 6 inches), the load sensing system will disable all normal functions and signal the operator with an indicator light and an audible alarm.

If the platform is overloaded while in travel mode, the load sensing system will signal the operator with an indicator light and an audible alarm but will not disable any normal functions.

The following table shows the progression of warnings, indicated to the operator, up to the point of overload.

| Weight               | Indicator Light | Audible Alarm |         |         | Platform Function Controls |          |                                  |
|----------------------|-----------------|---------------|---------|---------|----------------------------|----------|----------------------------------|
|                      |                 | ANSI/CSA      | CE & AS | KC      | ANSI/CSA                   | CE & AS  | KC                               |
| 93% - 99%            | On              | Off           | Off     | Off     | Enabled                    | Enabled  | Enabled                          |
| 100%                 | Flashing        | Off           | Pulsing | Off     | Enabled                    | Disabled | Enabled                          |
| >100% in Work Mode   | Flashing        | Pulsing       | Pulsing | Pulsing | Disabled                   | Disabled | Disabled                         |
| >100% in Travel Mode | Flashing        | Pulsing       | Off     | Pulsing | Disabled                   | Enabled  | Boom: Disabled<br>Drive: Enabled |

1400AA

### WARNING

Do not operate the emergency power unit if the platform capacity is exceeded. If the platform is overloaded due to contact with an overhead obstruction, do one of the following:

- Remove the obstruction from the platform, then after a four-second delay normal functions can be resumed.
- Use the emergency power unit at the base control console to release the platform from the obstruction.

### WARNING

If the platform load sensing system is in fault mode (capacity zone lights flash alternately, overload light flashes and capacity zone border light illuminates), do the following:

- Ensure the platform is level and there are no obstructions contacting the platform.
- Shut the MEWP off using either the ignition switch or the e-stop. Restart the engine.

If the platform load sensing system remains in fault mode, the emergency power unit may be used to lower the platform from the base controls. Contact a qualified/competent person for repairs.


### 5.3-2 Dual Capacity Overload Module Function Table

| Position | Load in Platform       | Boom Function Availability |           |             |              | Inputs   |   |   | Outputs                                  |                                      |                              |                               |                                 |                                    |
|----------|------------------------|----------------------------|-----------|-------------|--------------|--|---|---|--|--------------------------------------|------------------------------|-------------------------------|---------------------------------|------------------------------------|
|          |                        | Boom Up                    | Boom Down | Boom Extend | Boom Retract | Load Cell Voltage measured across resistors 161 & 162 (3) (millivolts) | Boom Angle Wire 121 Limit sw. L54 (volts) | Boom Extension Wire 122 Limit sw. L55 (volts) | DOUT1 low capacity Wire '120' Wire '120' | DOUT2 Overload Indicator - Wire '82' | DOUT3 Border Lamp Wire '119' | SCOUT1 (Boom Down) Wire '13A' | SCOUT2 (Boom Extend) Wire '39A' | SCOUT3 (System Enable) Wire '162B' |
| A        | Platform Load (lbs/kg) |                            |           |             |              |  |   |   |  |                                      |                              |                               |                                 |                                    |
| @powerup | N/A                    | disable                    | disable   | disable     | disable      | N/A  | any                                       | any   | 1s pulse                                 | 1s pulse                             | 1s pulse                     | disable                       | disable                         | disable                            |
| 0        | up to 695/315          | allow                      | allow     | allow       | allow        | up to 18.8   | 0   | 12  | off                                      | off                                  | off                          | enable                        | enable                          | enable                             |
| 0        | 695/315 to 748/339     | allow                      | allow     | allow       | allow        | 18.9 to 19.9   | 0   | 12  | off                                      | on                                   | off                          | enable                        | enable                          | enable                             |
| 0        | over 748/339           | disable                    | disable   | disable     | disable      | over 20  | 0   | 12  | 0  | pulsing 1hz                          | off                          | enable                        | enable                          | disable                            |
| 1        | up to 695/315          | allow                      | allow     | allow       | allow        | up to 18.8   | 12  | 12  | off                                      | off                                  | off                          | enable                        | enable                          | enable                             |
| 1        | 695/315 to 748/339     | allow                      | allow     | allow       | allow        | 18.9 to 19.9   | 12  | 12  | off                                      | on                                   | off                          | enable                        | enable                          | enable                             |
| 1        | over 748/339           | disable                    | disable   | disable     | disable      | over 20  | 12  | 12  | 0  | pulsing 1hz                          | off                          | enable                        | enable                          | disable                            |
| 1        | up to 695/315          | allow                      | allow     | allow       | allow        | up to 18.8   | 12  | 0   | off                                      | off                                  | off                          | enable                        | enable                          | enable                             |
| 1        | 695/315 to 748/339     | allow                      | allow     | allow       | allow        | 18.9 to 19.9   | 12  | 0   | off                                      | on                                   | off                          | enable                        | enable                          | enable                             |
| 1        | over 748/339           | disable                    | disable   | disable     | disable      | over 20  | 12  | 12  | 0  | pulsing 1hz                          | off                          | enable                        | enable                          | disable                            |
| 0        | up to 500/227          | allow                      | allow     | allow       | allow        | 9 to 16  | 0   | 0   | on                                       | off                                  | off                          | enable                        | enable                          | enable                             |
| 0        | 500/227 to 538/244     | allow                      | allow     | allow       | allow        | 16.1 to 17.1   | 0   | 0   | on                                       | on                                   | off                          | enable                        | enable                          | enable                             |
| 0        | over 538/244 (1)       | allow                      | disable   | disable     | allow        | over 17.2 (1)  | 0   | 0   | off                                      | off                                  | pulsing 2 hz                 | disable                       | disable                         | enable                             |
| 0        | over 538/244 (2)       | disable                    | disable   | disable     | disable      | over 17.2 (2)  | 0   | 0   | on                                       | pulsing 1hz                          | off                          | enable                        | enable                          | disable                            |

note (1)  
note (2)

- Notes:** (1) existing load in platform in excess of 538 lbs. (244 kg.) moving into zone A0E1  
 (2) platform load below 538 lbs. (244 kg.) in zone A0E1 then load added so total becomes in excess of 538 lbs. (244 kg.)  
 (3) voltage across 161 & 162 resistors is approximate and will vary slightly from machine to machine.

**Legend:**  
 "A" is angle of boom  
 "E" is extension of boom






### 5.3-3 Calibration of Load Sensing System








#### NOTE

There is a time-out period of 10 minutes for each step in the calibration process (indicated by a solid green light). Should you exceed 10 minutes, the calibration process must be started over from the beginning.



#### Preparation

1. Ensure the aerial platform is on firm, level ground.
2. Fully retract  and lower  the boom.
3. Turn the engine off .
4. Pull out both emergency stop buttons  and flip the engine enable switch to the on position .
 

**Result:** The overload indicator light and audible alarm pulse two times.
5. Make sure the platform is unloaded and is free from any surface contact. Remove all options from the platform.
6. Open the base control box door, and locate the dual capacity module on the inside right wall of the control box.

### Calibrate the Tare Point (No Load)

7. Press and release the actuation button twice, then press it a third time, this time holding it for about 3 seconds.

**Result:** A solid yellow LED light turns on, and the green LED will start to flash.

8. Press the actuation button.

**Result:** The green LED will flash quickly indicating the tare weight is being calibrated. Wait for the light to stop flashing.

### Calibrate Trip Point 1

9. The yellow LED will remain solid and the red LED will begin flashing.

10. Load the platform to the Trip Point 1 calibration point (see table below). Press the Actuation button.

**Result:** The red LED will flash quickly indicating that Trip Point 1 is being calibrated. Wait for the red LED to stop flashing - this indicates that the calibration point has been stored.

### Calibrate Trip Point 2

11. The yellow LED will remain solid and the red AND green LEDs will begin flashing.

12. Load the platform to the Trip Point 2 calibration point (see table below). Press the Actuation button.

**Result:** The Red and Green LEDs will flash quickly indicating that Trip Point 2 is being calibrated. Wait for the Red and Green LEDs to stop flashing - this indicates that the calibration point has been stored.

13. The Red, Green, and Yellow LEDs will flash simultaneously for approximately 2 seconds. This indicates that calibration is complete.

14. The Green LED will become solid, which is normal operating mode.

| Model  | Trip Point 1        | Trip Point 2   |
|--------|---------------------|--|
| SJ86 T | 244 kg<br>(538 lbs) | 244 kg + 94 kg = 339 kg<br>(538 lbs + 210 lbs = 748 lbs) |


## 5.4 Boom

### 5.4-1 Check Wear Pads

1. Ensure the MEWP is on a firm level surface and is in the stowed position.
2. Start the engine from the base control console.
3. Raise the main boom to a comfortable working height (chest high), and then extend fly boom approximately 1 ft (30 cm).
4. Measure the thickness of each wear pad, and replace wear pad if it is less than 7/16 inches (11mm).
5. If the wear pad is within the specified thickness, shim it as necessary.

### 5.4-2 Shim Wear Pads

1. Ensure the MEWP is on a firm level surface and is in the stowed position.
2. Raise the main boom to a comfortable working height (chest high) and extend the fly boom until the wear pads are accessible.
3. Loosen the wear pad fasteners.
4. Shim the wear pads as necessary to obtain zero to 1/32" (0.8 mm) clearance and zero drag.




5. Extend and retract the fly boom through the entire range of motion and observe for loose points.

 **NOTE**

Always maintain squareness between the boom's outer and inner tubes.

### 5.4-3 Cable Carrier Repair

To repair the cable carrier, simply use a screwdriver. Snap each crossbar off from either side of the chain, either by hand or by using the screwdriver as a lever. Install new crossbars by snapping the links together.




### 5.4-4 Rotary Actuator Bolt Torque Procedure

 **WARNING**

Maintaining proper torque is essential to safe aerial platform operation. Improper bolt torque could result in an unsafe operating condition and component damage.

1. Set the torque wrench to 17 ft-lb and tighten the mounting bolts in a cross pattern sequence.



2. Set the torque wrench to 35 ft-lb and tighten mounting bolts with the same sequence.
3. Torque the center bolt to 480 ft-lb.

### 5.4-5 Boom Section Wear Pad Replacement

If wear pads inside the boom sections are worn and cannot be shimmed to meet the specification, they must be replaced. Wear pads that are worn past the specification can impair machine operation. For wear pad limit specification, refer [5.4-1 Check Wear Pads](#).

#### **WARNING**

**Use original or manufacturer-approved parts and components for the aerial platform.**

The boom sections must be disassembled to replace the wear pads. Typically the bottom platform-end and the top counterweight-end pads on each boom section wear out first. Check which ones need to be replaced before disassembly.

#### **NOTE**

*To disassemble the boom sections, the extension cylinder and cable assembly inside the boom must be removed first. See [5.4-17 Extension Cylinder and Cable Assembly Removal](#)*

To disassemble the boom sections, the fly boom and mid boom must be slid fully out of the main boom. Provide enough space at the platform end of the machine at least the length of boom assembly.

Preparation:

- Remove the jib boom and the platform before disassembly. Removing these components limits twisting when lifting, and provides better control when sliding the boom sections out. See [5.4-6 Platform and Jib Boom Removal](#). If the machine does not have a jib boom, just the platform is removed.
- Before beginning, place the machine in the proper shut down position, parked on level ground.
- Make sure the e-stops are pushed in and the key is off.
- Turn the main power disconnect switch off. Lock out the switch.

#### **CAUTION**

**There is a risk of personal injury or equipment damage if repositioning the boom with the platform removed. Use the base controls with auxiliary power (engine off) to reposition the boom safely.**

#### **IMPORTANT**

If boom repositioning is necessary during this procedure, select emergency power position from start-function enable-emergency power switch, then activate desired boom function.

**When operating on auxiliary power, do not operate more than one function at a time to avoid overloading the 12-volt auxiliary pump motor.**

#### **CAUTION**

**Risk of personal injury or equipment damage. Always use suitable lifting equipment and safe rigging practices when performing the following procedures.**

#### **NOTE**


*If boom repositioning is required with the platform removed and control cables disconnected, reconnect the two main (24 pin) control cables and the jib and platform rotate harness (as equipped) to the platform control box. See [5.4-20 Wire Rope Inspection](#).*

*The machine cannot operate with the two platform control harnesses disconnected.*




### 5.4-6 Platform and Jib Boom Removal


Before removing the platform and jib boom from the machine, the electrical harnesses routed across the platform swivel joint must be disconnected.




1. Disconnect the two 24-pin control cables from the bottom of the control box.




2. Remove the auxiliary AC receptacle box if its harness is bundled with the other harnesses. Remove the harness clamps.




3. Open the control console lid and disconnect the jib and platform rotate harness.
4. Remove tie wraps and make note of wire labels for reinstallation.
5. To release each wire, insert a small flat screwdriver into the slot beside it in the terminal strip.




6. Pull the disconnected harness out of the strain relief connector in the box.



7. Pull all harnesses through the cable guard on the swivel joint.




8. Mark and disconnect the hydraulic hoses for the jib cylinder and the platform rotary actuator. Use a suitable container or rags to catch any oil spillage. Cap hoses and ports to keep them clean.
9. Remove the hoses and wire cable bundle from the P-clamps on the side of the jib boom.



10. Using suitably rating lifting equipment and safe rigging practices, connect lifting slings to the jib boom and platform. Tension the slings enough to lightly take the weight off the mounting bracket pins.


11. Remove the pins mounting the jib boom to the fly boom and the slave cylinder.




12. Carefully move the jib/platform assembly away from the end of the machine. Set it down on suitable blocking nearby. Place it close enough to the end of the main boom so the control cables can be reconnected in the event boom repositioning is required.

### 5.4-7 Platform Removal (no Jib Boom)

Before removing the platform from the machine, disconnect the electrical harnesses routed across the platform swivel joint.




1. Disconnect the two 24-pin control cables from the control box.







- Remove the auxiliary AC receptacle box if its harness is bundled with the other harnesses. Remove the harness clamps.




- Open the control console lid and disconnect the jib and platform rotate harness.
- Remove tie wraps and make note of wire labels for reinstallation.
- To release each wire, insert a small flat screwdriver into the slot beside it in the terminal strip.



- Pull the disconnected harness out of the strain relief connector in the box.



- Pull all harnesses through the cable guard on the swivel joint.
- Remove the hoses and wire cables from the P-clamp on the side of the fly boom.
- Using suitably rated lifting equipment and safe rigging practices, attach slings to the platform assembly. Tension the slings to lightly support the platform.
- Remove the 8 bolts that secure the rotary actuator valve to the platform base mount.
- Remove the main pivot bolt.



- Carefully move the platform assembly away from the end of the machine. Set it down on suitable blocking nearby. Place it close enough to the end of the main boom so the control cables can be reconnected in the event boom repositioning is required.



## 5.4-8 Operating Machine Functions from Base Controls

### **CAUTION**

There is a risk of personal injury or equipment damage if repositioning the boom with the platform removed. Use the base controls with auxiliary power (engine off) to reposition the boom safely.

If boom repositioning is necessary with the platform removed, reconnect the two cable harnesses and the jib/platform rotate harness to the platform control box.

### **IMPORTANT**

If boom repositioning is necessary during this procedure, select emergency power position from start-function enable-emergency power switch, then activate desired boom function.


When operating on auxiliary power, do not operate more than one function at a time to avoid overloading the 12-volt auxiliary pump motor.

### **IMPORTANT**

Be aware that the short length of control cables connected to the platform control box limits boom movement.

Connect the jib and platform rotate harness as shown on the Platform Controls Wiring diagrams in Section 3.

1. Pull jib and platform rotate harness through the strain relief connector on the bottom of the box and tighten the connector. Make sure the wires can reach the terminal block on the left-hand side on the box. Note the color and markings for each wire.




2. Inserting a small flat screwdriver into the slot beside the wire position in the terminal strip depresses the spring mechanism. Insert the end of the wire, then pull out the screwdriver to secure it.
3. Once the wires are all connected, close the lid and turn the two box latches to fasten it.

To continue work:


- Place the boom in a horizontal (0°) position.
- Shut down the machine.
- Turn the main electrical disconnect switch off. Lock out the switch.

### 5.4-9 Fly Boom Section Removal


1. On the platform end of the boom, mark and remove the slave cylinder hoses on the top side of the fly boom tip. Crack the lines slowly to relieve any residual pressure. Use a suitable container or rags to catch any oil spillage. Cap hoses and ports to keep them clean.
2. Remove the fasteners for the cable/hose tube support on the side of the fly boom.



3. Remove the top and side wear pads and shims inside the platform end of the mid boom. Store the shims with their respective parts for reassembly later.



4. Place a suitable stand that can bear the weight of the fly boom ahead of the machine. Attach a lifting sling to the tip of the fly boom. Lift it up slightly, then remove the bottom wear pad.




5. Lift/slide the fly boom out 2/3 of the way. Pull it out straight to avoid binding. Set it down on the stand to re-sling as required. Balance the load as it is being removed.



**NOTE**


All the wear pads must be removed from the platform end of the mid boom so the fly boom section can be pulled all the way out. The wear pads on the counterweight end of the fly boom section would otherwise prevent removal.

6. Slide the fly boom completely out of the mid boom and set it down on suitable blocking.
7. Replace the wear pads on the counterweight end of the fly boom. Use Loctite 242 or 243 on the wear pad fasteners.




### 5.4-10 Mid Boom Section Removal

1. Place blocking inside the cable/hose tube to support the e-chain track when the main support bolt is removed. Cut the blocks about 5" (12 cm) high. Place them about 4 ft (1.2 m) apart.
2. Remove the main power track carrier bolt from the platform end of the mid boom. Allow the cable/hose tube to rest on the blocking. Secure it with a strap.




3. Locate the limit switch on the left-hand side of the main boom, at the platform end of the lower e-chain tube. Pull in the limit switch arm and place a piece of tape over the switch hole. The tape prevents the switch from being damaged as the fly boom is removed.




4. Place a suitable stand that can bear the weight of the mid boom about 2/3 the boom length ahead of the machine.
5. Connect lifting slings to the platform end of the mid boom.

6. Remove the top and side wear pads and shims inside the platform end of the main boom. Store the shims with their respective parts for reassembly later.




7. Slide the mid boom out 2/3 of the way. Slide it out straight to avoid binding.
8. Set it down on the stand and re-sling to lift from two points.
9. Remove bottom wear pads, support blocks and shims from the platform end of the main boom.



 **NOTE**


All the wear pads must be removed from the platform end of the main boom so the mid boom section can be pulled all the way out. The wear pads on the counterweight end of the mid boom section would otherwise prevent removal.

10. Slide the mid boom completely out of the main boom and set it down on suitable blocking.
11. Replace the wear pads on the counterweight end of the boom section. Install with the shims that were removed. Apply Loctite 242 or 243 to the wear pad fasteners.




### 5.4-11 Mid Boom Section Installation

1. Attach two lifting slings to the mid boom. Using suitable lifting equipment, slide the mid boom section slowly into the platform end of the main boom. Be careful not to damage the wear pads.
2. When it is about 1/3 of the way in, install the bottom wear pad. Apply Loctite 242 or 243 to the wear pad fasteners.
3. Place a suitable stand under the end of the boom. Lower it onto the stand and remove one lifting sling.
4. Continue sliding the boom all the way in until the holes in the mid boom nose and the cable/hose tube support line up.
5. Install the top and side wear pads and shims in the main boom nose. Apply Loctite 242 or 243 to the fasteners.
6. Install the main power track carrier bolt. Remove the blocking and strap supporting the cable/hose tube.




7. Remove the tape from the limit switch hole on the left-hand side of the main boom.





### 5.4-12 Fly Boom Section Installation


1. Attach two lifting slings to the fly boom. Using suitable lifting equipment, slide it slowly into the nose of the mid boom. Be careful not to damage the wear pads.
2. When it is about 1/3 of the way in, install the bottom wear pad. Apply Loctite 242 or 243 to the wear pad fasteners.
3. Place a suitable stand under the end of the boom. Lower it onto the stand and remove one lifting sling.
4. Continue sliding the boom all the way in until the holes in the boom tip and the e-chain support bracket line up.
5. Install the top and side wear pads and shims in the mid boom nose. Apply Loctite 242 or 243 to the wear pad fasteners.
6. Install the fasteners for cable/hose tube support in the fly boom. Connect the platform level hydraulic hoses.




### 5.4-13 Platform and Jib Boom Installation

For torque specifications, refer to [2.2 MEWP Torque Specifications](#).


1. Connect lifting slings to the jib assembly.
2. Using suitable lift equipment, move it into position and insert the jib pin and slave cylinder pin. Insert the keeper pins.



3. Connect the hydraulic hoses for the jib cylinder.



4. Connect the hoses for the platform rotary actuator.



5. Install the hoses and P-clamps to the side of the jib boom.

### IMPORTANT

Make sure all wiring cables are routed and secured to avoid pinching or chafing as the platform moves.

6. Connect the platform control console. Refer to the Platform Controls Wiring diagrams in Section 3.


### CAUTION

**Risk of personal injury or equipment damage.**  
Test equipment operation before putting machine into service. See Function Tests in the Operating Manual.

## 5.4-14 Platform Installation (no Jib Boom)

For torque specifications, refer to [2.2 MEWP Torque Specifications](#).

1. Connect lifting slings to the platform assembly.
2. Using suitable lifting equipment, move the platform into place.
3. Install the main pivot bolt pin, flat washer and hex nut. Tighten to the correct torque.
4. Install the bolts that secure the rotary actuator to the platform base mount. Apply Loctite 242 to the bolt threads. Tighten to the correct torque.



5. Connect the hydraulic hoses to the platform rotator.
6. Install the P-clamp for the hoses and wire cables to the side of the fly boom nose.

### IMPORTANT

Make sure all wiring cables are routed and secured to avoid pinching or chafing as the platform moves.

Connect the platform control console. Refer to the Platform Controls Wiring diagrams in Section 3.

### CAUTION


**Risk of personal injury or equipment damage.**  
Test equipment operation before putting machine into service. See Function Tests in the Operating Manual.

## 5.4-15 Platform Control Console Connection

Refer to the Platform Controls Wiring diagrams in Section 3 to properly identify control console wiring connections.

Once the platform is installed, make sure all harnesses to be connected to the platform control box are routed through the guard hoop on the platform base.

1. Connect the two platform control cable harnesses.
2. Pull the jib (if equipped) and platform rotate harness through the strain relief connector in the bottom of the platform control box. Make sure the wires can reach the terminal block on the left-hand side of the box.
3. Tighten the strain relief connector locknut to secure it.



4. Note the color and markings for each wire. Connect the wires as shown on the wiring diagram.
5. Tie-wrap the harnesses inside the control box as before.

### IMPORTANT

Make sure all wiring cables are routed and secured to avoid pinching or chafing as the platform moves.

### CAUTION

**Risk of personal injury or equipment damage. Perform a function and range of controls check before putting machine into service. See Function Tests in the Operating Manual.**

### 5.4-16 Extension Cylinder and Wire Rope Replacement

Inspecting the cable assembly and extension cylinder for wear requires completely removing them from inside the boom assembly. Adequate space must be provided to do so. See [5.4-20 Wire Rope Inspection](#).

#### **CAUTION**

Risk of personal injury or equipment damage if repositioning boom during this procedure. Use base controls with auxiliary power (engine off) to reposition safely.

#### **CAUTION**

Risk of personal injury or equipment damage. Always use suitable lifting equipment and safe rigging practices when performing the following procedures.

#### **IMPORTANT**

When operating on auxiliary power, do not operate more than one function at a time to avoid overloading the 12-volt auxiliary pump motor.


#### **IMPORTANT**

Prevent hydraulic system contamination by capping all hydraulic connections after disconnecting. Sample warning text.


### 5.4-17 Extension Cylinder and Cable Assembly Removal

- Place the boom in a horizontal (0°) position.
- Shut down the machine.

1. Extend/retract the boom to align the flange pins with the holes in the side of the main boom. The lower flange pins connect the wire rope terminal assembly to the fly boom. The upper flange pins connect the cylinder base to the mid boom.




2. Place the machine in the proper shut down position, parked on level ground. Make sure the e-stops are pushed in and the key is off. Turn the main disconnect switch to off position. Lock out the switch  $\bigcirc$ .
3. Loosen the wire ropes on the platform end of the machine first. Remove the jam nut, then use the flat on the end of wire rope anchor to hold it while backing off the main nut. Leave the main nut on the wire rope anchor about one full nut thread.






- Remove the boom end cover.



- Loosen the wire ropes on the counterweight end of the machine. Remove the jam nut, then use the flat on the end of wire rope anchor to hold it while backing off the main nut. Leave the main nut on the anchor about one full nut thread.



- When all wire ropes are slackened, the disc springs (washers) and spacers can be removed from each wire rope anchor. Remove the washers and spacers, then put the hex nut back on one full nut thread to temporarily hold the wire rope in place.


- Once the wire ropes are slackened, remove the boom flange pins and fasteners.



**NOTE**


The flange pins may not line up in the holes exactly, but can be moved into place using a pry bar once the cables are slackened.

- Use two 1/4-20 UNC bolts to help as a puller when removing the flange pins. Threaded holes are located in the flange pin collar. The bolts should be full thread with no shoulder, and at least 2 in. (50 mm) long.




- Remove the hex nuts from all 4 wire rope anchors.


10. Mark and disconnect the hoses from the extension cylinder. Cap hoses and ports to keep them clean.
11. Remove the extension cylinder base-end pin.




12. Place a lifting strap on the extension cylinder. Pull the cylinder out along with the upper wire ropes to about 1/3 of the way. The wire ropes can be tie-wrapped to the cylinder to help keep them from getting tangled.




13. Remove the mid boom pulleys and cable stops. Continue to pull the cylinder out.



14. Flip the wire rope terminal plate over so the tapered end faces the counterweight end of the machine. Flipping it over makes it easier to remove with the cylinder.




15. Pull the cylinder out 2/3 of the way. Allow the upper wire ropes to come out with the cylinder.

**NOTE**

*Make sure wire ropes do not get tangled or caught on other components.*

16. Lower the end of cylinder onto a support. Connect lifting straps at both ends of the extension cylinder.
17. Continue to slide the cylinder completely out of the boom. Balance the load as it is being removed.
18. Lower the cylinder onto suitable supports.

- Remove the cable stop and wire ropes from the extension cylinder pulley.



- Inspect the extension cylinder wear pads for wear or damage. Replace if required.
- Perform an inspection of the wire ropes at this time. See [5.4-20 Wire Rope Inspection](#).

### 5.4-18 Extension Cylinder and Wire Rope Assembly Installation


- Attach two lifting slings to the extension cylinder. Using suitable lifting equipment, raise and slide the end slowly into the counterweight end of the boom assembly. The upper wire ropes can be tie-wrapped to the cylinder to keep them from getting tangled. Be sure to remove the tie wraps as the cylinder is being installed.



**NOTE**


*Make sure the cables do not get tangled or caught on other components.*

- Orient the wire ropes correctly. Identify which cable ends go to the platform end, and which go to the counterweight end of the machine. The tapered end of the wire rope terminal plate is towards the platform end of the machine when installed. The shorter length wire ropes anchor at the platform end.
- Lift and slide the end of the cylinder into the boom, being careful not to tangle the wire ropes.
- Once the pulley end of the cylinder is into the boom, one lifting sling can be removed. Lower the cylinder onto a suitable stand or support and remove one sling. Connect the lifting sling to the end of the cylinder.
- Carefully feed the wire ropes in as the cylinder is being pushed in.
- Slide the cylinder 2/3 of the way in until the wire rope terminal plate has passed where the mid boom pulleys mount.




**Wire Rope Terminal Plate**

7. Route the platform end wire ropes between the main and mid booms, through to the anchor points at the platform end. Install one hex nut on each cable end.
8. Install the mid boom pulleys. Pull the slack cable and fit it onto the pulleys. Install the cable stops.




9. Continue sliding the cylinder inward, making sure the wire ropes do not get tangled.
10. Install the counterweight end of the wire ropes into the anchor points. Install one hex nut on each anchor to secure it.



**Counterweight-end Wire Ropes**

11. Install the flange pins for the cable support and the wire rope terminal plate into the side of the boom. If the flanges need to be rotated, thread two bolts into the puller holes and turn with a pry bar.




12. Install the extension cylinder base-end pin. Install the keeper pin to secure it.
13. Install the extension cylinder hydraulic hoses.



- Remove the hex nut on each cable end and install the 2 spacers and 12 disc springs. The orientation of the disc springs is important. They must be installed by reversing the direction of every second pair. Turn the hex nuts on one thread to secure them.

**IMPORTANT**

Reverse the direction of every second pair of disc springs. Orientation of the disc springs is critical for proper wire rope tension.




- Tighten all wire rope ends at the anchors until they are tensioned correctly. See 5.4-19 Proper Wire Rope Tension.
- Install the boom end cover.

**5.4-19 Proper Wire Rope Tension**

The wire rope assembly is tensioned correctly when the disc springs are fully compressed.

- With the jam nut removed, use the flat on the wire rope anchor to hold it while tightening the hex nut. Tighten the anchors equally until all the disc springs are fully compressed, then turn one additional 1/2 turn. Note: you will still see small gaps between reversed discs, even when fully compressed.




- When tensioned correctly, install the jam nuts on all the wire rope anchors.

**CAUTION**

There is a risk of personal injury or equipment damage. Test the equipment operation before putting the machine into service. See the Function Tests in the Operating Manual.

## 5.4-20 Wire Rope Inspection

- Perform a visual inspection of the wire ropes annually. Check for wear or damage. Make sure wire ropes are tensioned correctly. See [5.4-19 Proper Wire Rope Tension](#).
- A visual inspection can be performed by fully extending the boom, and inspecting the cables through the sight holes along the boom arm.



- Perform a full inspection of the wire rope assembly every ten years. To perform a full inspection, the extension cylinder and wire rope assembly must be fully removed from the boom assembly. See [5.4-17 Extension Cylinder and Cable Assembly Removal](#).


### IMPORTANT

Perform a full inspection of the wire ropes at the start of the 10th year of wire rope life. They must be inspected every 2 years if not replaced at that time.

Perform a visual inspection annually.

If a wire rope needs replacement, the entire wire rope assembly must be replaced immediately.


Check wire ropes for wear or damage. A wire rope with broken wires, severe corrosion, excessive stretch, deformed strands, variations in diameter (necking), or any change from its normal appearance, must be replaced.




**Cable in Good Condition**



**Cable with Broken Wires**



**Cable with Rust**



**Cable with Necking**

### Sheave Inspection

Check sheaves (pulleys) for wear or damage. For example, wobble (tilt), cracks, loose on pin, or excessive noise during operation.

### Sheave Pins Inspection

Check for loose or missing sheave (pulley) pins.

### 5.4-21 Limit Switch Checking and Adjusting


There are six limit switches on the SJ82 T and SJ86 T machines. Use the following procedures to check and adjust them.

**Preparation:**

- Park the machine on a flat, level surface.
- Provide enough room around the machine for lifting / swinging the boom and driving.

**Tools required:**

- Calibrated digital protractor (to measure boom angles)
- Multi-meter with continuity setting
- Level



**Components and limit switch locations**


- |   |   |
|---|---|
| <ol style="list-style-type: none"> <li>1. Fly Boom Section</li> <li>2. Mid Boom Section</li> <li>3. Main Boom Section</li> <li>4. Fly-in Limit Switch (LS3)</li> <li>5. Boom Extension (dual load) Limit Switch (LS5)</li> <li>6. High Drive / Tilt Override (LS2)</li> </ol> | <ol style="list-style-type: none"> <li>7. Boom Angle (dual load) (LS4)</li> <li>8. Directional Sensing Limit Switch (LS1)</li> <li>9. Cushion Limit Switch (LS6)</li> <li>10. Master Cylinder Link</li> <li>11. Steering Axle</li> <li>12. Counterweight</li> </ol> |
|---|---|

### 5.4-22 Directional Sensing Limit Switch (LS1)

LS1 detects when the turret is rotated more than 90° from being in line with the base. When rotated past 90°, the directions for forward-reverse travel and left-right steering are reversed. The platform controls remain natural and operate as indicated as the turret rotates about the base.

LS1 is normally closed and opens when the switch roller contacts a cam on the top of the rotary manifold. When rotating the turret, LS1 circuit opens as it rides up on the cam. It closes when the switch roller is off the cam.


LS1 is normally closed and held open when the counterweight is over the steering axle.



**Counterweight shown over steering axle**

1. LS1 Limit Switch
2. Steering Axle
3. Counterweight

LS1 is mounted on the rotary manifold in the base frame.




**LS1 location on rotary manifold (some parts hidden for clarity)**



#### NOTE

Make sure the switch roller rotates freely and the plunger is free to move as the turret rotates.



**Limit switch plunger and roller**

#### **WARNING**


Ensure there are no personnel or obstructions in the test area and there is sufficient room to drive the machine and reposition the boom.

#### Check Switch Operation:

1. Align the turret with the counterweight over the steering axle. Verify the machine operates as the controls indicate using the platform controls. Check that forward-reverse controls and left-right steering operate as indicated.
2. Locate the terminal strip inside the base control panel. Set the multi-meter to *continuity-check* mode.



- Place the multi-meter probes on terminal positions (09 Black) and (17 Black/white).



**LS1 terminal connections**

- Check that the circuit is open with the multi-meter.
- Rotate the turret around the base past 90° and stop. Verify machine directions continue to operate as the controls indicate.

**⚠ WARNING**

The drive orientation can change when the turret is swung 90 degrees off center of the normal driving position (roughly when boom is swung past the rear tire). Drive re-orientation does not occur while driving and rotating until the joystick is released for 6 seconds or when the footswitch is released.


- Verify the circuit is now closed with the multi-meter. Continuity is indicated when the turret is rotated past 90°. Check both clockwise and counterclockwise directions.

**5.4-23 High Speed Drive / Tilt Override Limit Switch (LS2)**

LS2 detects when the boom is raised above horizontal. The machine drives at normal speed with the boom fully lowered, but is limited to a slow drive speed of 0.5 mph (0.8 km/h) when the boom is raised.

LS2 is normally closed. It opens when it contacts a cam on the turret frame when the boom is raised up past horizontal. The switch roller contacts the cam and the system switches from normal to slow drive speed.


LS2 is the upper switch located on the rear, left-hand side of the turret frame.



**LS2 location on turret frame**

**NOTE**

Make sure the switch roller rotates freely and the switch arm is free to move as the boom raises and lowers.




**Limit switch arm and roller**

## **⚠ WARNING**

**Ensure there are no personnel or obstructions in the test area and there is sufficient room to drive the machine and reposition the boom.**

### **Check Switch Operation:**

1. Fully retract the boom assembly.
2. Position the main boom so it is horizontal. Use a level to verify.
3. Place a digital protractor on the underside of the main boom. Calibrate it to 0° (horizontal).
4. Locate the terminal strip inside the base control panel. Set the multi-meter to *continuity-check* mode.
5. Place the multi-meter probes on terminal positions **(09 Black)** and **(29 Black/white)**.



### **LS2 terminal connections**

6. Lower the boom below horizontal. Verify the switch roller is not contacting the cam on the frame and the switch circuit is closed (continuity). Adjust the switch position if required.
7. Raise the boom to horizontal. Verify the switch roller now contacts the cam and the switch circuit is open (no continuity).


8. Verify the machine only drives at slow drive speed when the boom is raised above horizontal.
9. Confirm proper limit switch operation by driving the machine with the boom fully lowered, and then with it raised above horizontal.

### 5.4-24 Fly-in Limit Switch (LS3)

LS3 limits machine drive speed to 1/2 mph (0.8 km/h) when the boom is extended.

LS3 is normally closed. A slotted hole in the mid boom trips the switch as the boom extends.


LS3 is the lower limit switch on the platform end of the main boom.



LS3 location on main boom

**NOTE**

Make sure the switch roller rotates freely and the switch arm is free to move as the boom extends and retracts.




Limit switch arm and roller

**WARNING**

Ensure there are no personnel or obstructions in the test area and there is sufficient room to reposition the boom.

**Check Switch Operation:**

1. Retract the boom fully.
2. Place the boom in a horizontal position (or slightly less than 0°).
3. Extend the boom outwards 4 ft (1.2 m). At this point, the limit switch has tripped and the contacts should be open.
4. Locate the terminal strip inside the base control panel. Set the multi-meter to *continuity-check* mode.
5. Place the multi-meter probes on terminal positions (59 black/white) and (29 black).
6. Verify the switch circuit is open and there is no continuity.



LS3 terminal connections


7. Retract the boom. Verify there now is continuity in the circuit.
8. Extend and retract the boom to check switch operation. The circuit should open and close when the switch roller passes through the slotted hole in the mid boom.
9. Perform a test drive to verify the machine drive speed is slowed with the boom extended.

### 5.4-25 Boom Angle (Dual Load) Limit Switch (LS4)

LS4 detects the angular position of the boom so the system can switch to and from the low and high capacity load zones, as the boom raises or lowers.

LS4 is normally closed. It is held open by a cam on the turret frame. When the boom is raised past 57°, the switch roller loses contact with the cam and the circuit closes.


When equipped with automatic platform load sensing (CE machines), an overload state can be detected automatically. The system does not allow the boom to further lift or extend into the 500 lb (227 kg) zone (1) when overloaded.



M62357AA

**Automatic platform load sensing**


When not equipped with automatic platform load sensing (ANSI machines), the operator must manually toggle the platform capacity selector switch (2) to further lift or extend the boom from the 750 lb (340 kg) zone into the 500 lb (227 kg) zone.



M62356AA

**Platform capacity selector switch**

LS4 is the lower switch located on the rear, left-hand side of the turret frame.




M62359AA

**LS4 location on turret frame**



**NOTE**

Make sure the switch roller rotates freely and the switch arm is free to move as the boom raises and lowers.



M62366AA

**Limit switch arm and roller**




**WARNING**

Ensure there are no personnel or obstructions in the test area and there is sufficient room to reposition the boom.

**Check Switch Operation:**

1. Position the main boom so it is horizontal. Use a level to verify.
2. Place a digital protractor on the underside of the main boom. Calibrate it to 0° (horizontal).
3. Position the boom angle at 57° from horizontal.
4. Locate the terminal strip inside the base control panel. Set the multi-meter to *continuity-check* mode.
5. Place the multi-meter probes on terminal positions shown below (as equipped):

|   |                                    |
|---|------------------------------------|
| Automatic platform load sensing (CE machines) | Wire 121 Black/White and 09 Black  |
| Standard load sensing (ANSI machines)         | Wire 121 Black/White and 09B Black |



**LS4 terminal connections**

6. Loosen the switch and move it so that the switch arm roller is just off the cam. At this point, the multi-meter should show the circuit is closed (continuity).
7. Adjust the switch position so that the roller is just on the edge of the cam and the circuit is open (no continuity). Verify with the multi-meter.

**NOTE**

The LS4 roller should not fall off the cam before reaching 57°. Additionally, continuity may not occur in the circuit until the boom angle reaches 58.5°.


8. Tighten the switch in this position, then raise and lower the boom to confirm the switch is operating correctly.

### 5.4-26 Boom Extension (Dual Load) Limit Switch (LS5)

LS5 enables the system to change to and from the low and high capacity load zones, as the boom extends or retracts.

LS5 is normally closed. The switch roller makes contact with a ramp on the side of the mid boom to open its contacts. When the boom is extended far enough, the switch roller rides up on the ramp, the contact opens, and the system changes from the high to the low capacity zone.

LS5 is the upper limit switch on the platform end of the main boom.




LS5 location on main boom



**NOTE**


Make sure the switch roller rotates freely and the switch arm is free to move as the boom extends and retracts.



M62365AA

Limit switch arm and roller


When equipped with automatic platform load sensing (CE machines), an overload state is detected automatically when the switch trips. The system then does not allow the boom to extend into the 500 lb (227 kg) zone (1).



M62357AA

Automatic platform load sensing

When not equipped with automatic platform load sensing (ANSI machines), the operator must manually toggle the platform capacity selector switch (2) from the 750 lb (340 kg) zone to the 500 lb (227 kg) zone.



M62356AA

**Platform capacity selector switch**

**WARNING**


Ensure there are no personnel or obstructions in the test area and there is sufficient room to reposition the boom.

**Check Switch Operation:**

1. Remove any load from the platform. Remove all tools and equipment.
2. Locate the terminal strip inside the base control panel. Set the multi-meter to *continuity-check* mode.
3. Fully extend the boom. The LS5 contact is normally closed, but with the boom extended the switch roller is riding up on the ramp on the side of the mid boom and its contact is open.

4. Place the multi-meter probes on terminal positions shown below (as equipped):

|   |                                   |
|---|-----------------------------------|
| Automatic platform load sensing (CE machines) | Wire 122 Black/White and 09 Black |
| Standard load sensing (ANSI machines)         | Wire 121 Black/White and 09 Black |



M62358AA

**LS5 terminal connections**


5. Observe the multi-meter display. There should be no continuity with the contact open.
6. Retract the boom and continue to observe the multi-meter. It should indicate no continuity until the switch roller loses contact with the ramp.
7. Stop retracting when the multi-meter shows continuity. At this point, the switch contact has closed.
8. Extend the boom again and observe the multi-meter as the boom extends. It should change from showing continuity back to no continuity when the roller arm contacts the ramp.

### 5.4-27 Lift Cushion Limit Switch (LS6)

LS6 slows the raising boom speed before the main lift cylinder reaches the stop at full extension.

LS6 is normally closed. As the lift cylinder approaches full extension, the switch roller makes contact with the master cylinder link. The switch trips to open the circuit.

LS6 is located on the inside of the turret on the left-hand side, near the lower end of the master cylinder link.



M62348AA

**LS6 location inside turret**


#### **⚠ WARNING**

**Ensure there are no personnel or obstructions in the test area and there is sufficient room to raise the boom.**

#### **Check Switch Operation:**

1. Position the main boom horizontal. Use a level to verify.
2. Place a digital protractor on a clean surface on the underside of the main boom. Calibrate it to 0° (horizontal).
3. Locate the terminal strip inside the base control panel. Set the multi-meter to *continuity-check* mode.

4. Place the multi-meter probes on terminal positions (**19 black/white**) and (**09 black**). The multi-meter should show the circuit is closed (continuity).



M62346AA

**LS6 terminal connections**

5. Raise the boom up all the way until the lift cylinder is fully extended. Observe if speed slows (LS6 has tripped) when the boom angle reaches 57°.
6. Check the multi-meter reading. There should be no continuity when the switch trips.




If raise speed does not slow as specified, adjust the limit switch using the following steps:

 **NOTE**

*Before performing any adjustment procedures, make sure LS6 is installed properly. Check angular position of the limit switch. Switch roller arm must not be close to the limits of its rotation and is free to swing to either side.*

*Make sure the switch roller rotates freely and is in full contact with the flat edge of the master cylinder link.*



M62349AA

**Limit switch arm and roller**


**Adjustment Procedure:**

1. Position the boom angle at 57° from horizontal.
2. Loosen the limit switch mounting screws.
3. Position the switch so that the roller is just touching the master cylinder link and the switch contact is open. Adjust the switch using both horizontal and vertical slots until an audible click sound is heard as the switch trips. The multi-meter should show no continuity.
4. Tighten the switch mounting screws.
5. Test the switch function by raising and lowering the boom.
6. Adjust the switch position as required so that it trips at 57° and boom movement slows as it approaches full extension.
7. Check repeatability by raising and lowering the boom.

## 5.5 Turret

### 5.5-1 Check and Replace the High Pressure Filter

1. Start the engine from the base control console.
2. Inspect the filter restriction indicator gauge **1**. The filter should be operating with the gauge pointing to the green area. If it is in the red area, the filter needs to be replaced.
3. To replace the filter, turn the engine off.
4. Place a suitable container under the filter.



5. Using a 30 mm box wrench on the filter housing nut **2**, loosen filter housing **3** and remove it from the filter head **4**.
6. Remove the filter element **5** from the filter head and install a new high pressure filter element.
7. Apply hydraulic oil to the o-ring on the high pressure filter housing.
8. Reinstall the housing, screwing it in fully, then backing it off by one quarter turn.


### 5.5-2 Adjust the Turret Rotation Gear Backlash



#### NOTE

The adjustment of the backlash must be performed on a flat level surface.


1. Loosen the mounting fasteners **1** on the swing drive.
2. Push the swing drive towards the rotation gear as close as possible (this will push the swing drive gear **2** into the rotation gear **3**).



3. Loosen the lock nut **4** on the adjustment bolt **5**.
4. Tighten the adjustment bolt clockwise until it contacts the plate of the swing drive.
5. Turn the adjustment bolt  $\frac{1}{2}$  turn counterclockwise, then tighten the lock nut on the adjustment bolt.
6. Pull the swing drive away from the rotation gear until it contacts the adjustment bolt.
7. Tighten the mounting fasteners on the swing drive.
8. Rotate the turret  $360^\circ$  and check for a smooth rotation of the turret.

### 5.5-3 Check the Swing Drive Oil

1. Remove the plug from the fill port **1** on the back of the swing drive.
2. Check the oil level. The oil level should be slightly below the port threads.
3. Add oil if needed. Refer to [2.10 Hydraulic Specifications & Gear Oil](#) for recommended oil types.




### 5.5-4 Change the Swing Drive Oil



#### NOTE

The oil change must be performed on a flat, level surface.


1. Remove the plug from the fill port **1**.
2. Place a suitable container under the drain port **2**.



3. Remove the plug from the drain port.
4. Allow the oil to drain.
5. Reinstall the drain plug.
6. Refill the swing drive with approximately 32 oz (1 L) of oil (refer to [2.10 Hydraulic Specifications & Gear Oil](#) for recommended oil types).
7. Reinstall the plug at the fill port.

### 5.5-5 Battery Replacement

1. Turn the main power disconnect switch ❶ to the off position.




2. Remove the positive and negative connectors from the batteries.
3. Remove the battery retainer bracket nuts and washers ❷.
4. Remove the bracket ❸.
5. Remove the batteries ❹.
6. Replace the battery pad ❺ if needed.
7. Replace the batteries and secure them with the bracket, j-hooks, washers and nuts.
8. Clean the terminal posts and clamps of the batteries, and apply acid-free and acid-resistant grease.
9. Re-connect the batteries with the positive and negative connector cables (ensure the clamps make good contact).

### 5.5-6 Turret Rotation Gear Bolt Torque Sequence

#### **⚠ WARNING**

Maintaining proper torque is essential to safe aerial platform operation. Improper bolt torque could result in an unsafe operating condition and component damage.

1. Set the torque wrench to 140 ft-lb (190 Nm) and tighten the mounting bolts in a criss-cross pattern sequence.




2. Set the torque wrench to 280 ft-lb (380 Nm) and tighten the mounting bolts with the same sequence.



### 5.5-7 Electronic Tilt Switch Setup Procedure

#### Tilt Switch Replacement




1. Park the MEWP on a firm level surface.
2. Disconnect the tilt switch from the 4 pin connector.



**NOTE**

Make sure the part number of the old tilt switch and new tilt switch are the same.

3. Remove the old tilt switch from the mount.






4. Install the new switch on the mount and connect the switch plug to the 4 pin connector.



**NOTE**

The tilt circuit is only powered when the controls are powered up.


5. Turn the main disconnect switch to the ON position .
6. Turn the base/off/platform key switch to the base position .

7. Pull out both emergency stop buttons .
8. Verify the switch is powered (red or green LED will be continually blinking).




9. Program the tilt switch:
  - a. Press and release the set to zero button 3 times. Observe LED flash codes as shown below.


- b. Only the red LED will blink for 4 seconds.




- c. Both LEDs will flash for 1 second. Results: The switch is learning the new zero position.




- d. Both LEDs will turn on solid for 1 second. Results: The new zero position has been learned.





- e. The green LED will flash and then the red LED will turn on solid for 2 seconds. Results: The switch is verifying the new zero position.




- f. Only the red LED will blink for 4 seconds.



10. Turn the main power disconnect switch to the off position .
11. Push in the emergency stop buttons .
12. Proceed to [Verify Tilt Circuit](#).




## Reprogramming the Existing Tilt Switch


Light Indicators The set to zero button is located on this face next to the harness



### NOTE


The tilt circuit is only powered when the controls are powered up.

1. Turn the main disconnect switch to the ON position .
2. Turn the base/off/platform key switch to the base position .
3. Pull out both emergency stop buttons .
4. Verify switch is powered (red or green LED will be continually blinking).




### 5. Reprogram the Tilt Switch

- a. Press and hold the set to zero button for 5 seconds.  
**Results:** Both LEDs will be OFF.



- b. Both LEDs will flash.




### IMPORTANT


Step “c” must be completed within a 5 second period, or the switch will automatically exit program mode and return to normal operation using the previously stored data.

- c. Press and release the set to zero button 3 times.
- d. If the 5 second period has expired prior to completion, repeat steps “a”, “b” and “c”.


- e. Observe program delay / stabilization time (only the red LED will blink for 4 seconds).




- f. Both LEDs will flash for 1 second.  
**Results:** The switch is learning the new zero position.




- g. Both LEDs will turn on solid for 1 second.  
**Results:** The new zero position has been learned.





- h. The green LED will flash and then the red LED will turn on solid for 2 seconds.  
**Results:** The switch is verifying the new zero position.




- i. The green LED will turn on solid.  
**Results:** The switch is ready for normal operation.



6. Turn the main power disconnect switch to the off position .
7. Push in the emergency stop buttons .
8. Proceed to [Verify Tilt Circuit](#).

### Verify Tilt Circuit

Light Indicators




### Operations of the Tilt Switch

The following describes the LED's and what they indicate.

|                 |   |
|-----------------|---|
| Green LED       | <p>illuminated whenever both tilt axes are within the specified degrees of the zero/ home learned position.</p> <p>Flashes when transitioning in or out of tilt angle limits, but built in time delay has not fully occurred.</p> |
| Red LED         | <p>illuminated whenever tilt on one or more axes is more than the specified degrees out from the zero/ home position.</p>   |
| Green & Red LED | <p>On together, no blinking when fault detected.</p>  |

### 5.5-8 Check Rotation Bearing for Axial Wear

1. Position the boom so that it is centered over the front drive and steer axle and is horizontal with the ground.
2. Extend the boom to its full extension length.
3. Mount a dial indicator on the chassis. Place the dial indicator set directly under the boom, close to the bearing teeth. Make sure to allow clearance as the turret assembly rotates.
4. Position the indicator arm or shaft so that the pointer touches the bottom surface of the turret weldment.



Check Axial Wear of the Rotation Bearing


5. Zero the dial indicator.
6. Rotate the turret 180° in the clockwise direction until the boom is centered over the rear axle. (Rotating the turret in the counterclockwise direction will cause the rotation gearbox pinion to impact the dial indicator).
7. If, when you are rotating the turret, the boom needs to be retracted or raised to avoid obstacles, be sure to again fully extend and level the boom when it is positioned over the rear axle. Do not be concerned with any dial indicator readings as the turret assembly rotates.
8. With the boom assembly rotation stopped and the boom centered over the rear axle, read the dial indicator and record the reading. This reading is the total amount of axial movement in the bearing assembly. If this reading is 0.100" (2.54 mm) or greater, the rotation bearing should be removed and replaced.

### 5.5-9 Resetting the Emergency Lowering Counter (CE only)


The emergency lowering counter increments each time the emergency power unit is activated while the platform is in work mode and overloaded.

To reset the counter:


1. Locate the terminal block with the integrated fuse holder inside the base control box.



2. Using any standard automotive fuse, insert it into the slot in the terminal block.



3. Remove the fuse.
4. Check the counter on the base control box door to verify it has been reset to zero.





## 5.6 Deutz Diesel Engines

Maintaining the engine components is essential to good performance and service life of the aerial platform.

### 5.6-1 Replace Engine Oil and Filter

Periodic replacement of the engine oil and filter is essential to good engine performance.



#### NOTE


Warm the engine to normal operating temperature before starting this procedure.



#### CAUTION

**Beware of hot engine components and hot oil. Contact with hot components may cause severe burns.**

1. Turn the engine off.
2. Remove the bolt securing the engine tray to the turret.



3. Swing the engine tray away from the turret.
4. Place a suitable container under the engine oil drain.

5. Remove the oil drain plug and allow all engine oil to drain into the container.

#### WARNING

**Dispose of oil in accordance with local and federal regulations.**

6. Install the oil drain plug with a new seal ring and tighten firmly.
7. Remove the oil filter and catch any escaping oil.
8. Clean inside the filter head.
9. Add clean engine oil to the oil filter.
10. Apply a thin layer of engine oil to the new oil filter gasket.
11. Install the filter and tighten it by hand.
12. Clean up any oil that may have spilled during this procedure.
13. Refill the engine with new oil as per the specifications (refer to the engine manual).
14. Swing the engine tray back to its original position.
15. Reinstall the engine tray bolt.
16. Start the engine from the base control console and allow the engine to run for 30 seconds, then stop the engine.
17. Check for oil leakage.
18. Check the engine oil level on the dipstick and add oil if needed.

### 5.6-2 Replace the Fuel Filter

1. Remove the bolt securing the engine tray to the turret.
2. Pull the locking pin down and swing the engine tray away from the turret.
3. Close the fuel shut-off valve.
4. Place a suitable container under the fuel filter.
5. Remove the fuel filter and catch any escaping fuel.

#### **WARNING**

**Dispose of fuel in accordance with local and federal regulations.**

6. Clean any dirt from filter carrier sealing surface.
7. Apply a thin layer of oil or diesel fuel to the rubber gasket of the new fuel filter.
8. Install the fuel filter and tighten it by hand, then tighten the filter cartridge with final half-turn.
9. Clean up any fuel that may have spilled during this procedure.
10. Open the fuel shut-off valve.
11. Check for fuel leakage.
12. Swing the engine tray back to its original position.
13. Reinstall the engine tray bolt.

### 5.6-3 Replace the Air Filter

Engine specifications require that this procedure be performed more often if dusty conditions exist. Refer to the engine manual.

#### **CAUTION**

**Perform this procedure with the engine off.**

1. Remove the mounting fasteners from the air filter canister, and remove the end cap.
2. Remove the filter from inside of the canister.
3. Clean the inside of the canister and gasket with a dry cloth.
4. Insert a new filter into the canister.
5. Reinstall the end cap.

### 5.6-4 Check the Engine Belt

The aerial platform will not operate properly with a loose or defective belt. Continuous usage may cause component damage.

#### **WARNING**

**Do not inspect the fan belt while the engine is running. Remove the key to prevent accidental operation.**

1. Inspect the engine belt for:
  - cracking
  - glazing
  - separation
  - breaks
2. For correct tension of the engine belt, refer to the engine manual.

### 5.6-5 Check the Oil Cooler (Deutz D2011 only)

1. Remove the cover from the side of the engine.
2. Inspect the oil cooler for leaks and physical damage.
3. Clean the oil cooler of any kind of debris.
4. Reinstall the cover.

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification   |
|------|--------|-----|------------|--|
| 8    | 132    | 1   | 2-2-6      | The air mass flow AFS_dm is greater than or equal to AFS_PhysRng.Min_C. Physical range check is low for air mass flow sensor.    |
| 9    | 172    | 2   | 2-2-6      | Air inlet filter temperature, plausibility error.  |
| 26   | 523891 | 14  | 2-6-3      | When AirHt_ctDefSRCLoOn_mp is lower than AirHt_ctMaxDef_C. DFC to SRC Low error when heater is on.                               |
| 28   | 523953 | 2   | 7-2-8      | Healing takes place if the condition for error detection is not present. Air temperature monitoring plausibility check array.    |
| 30   | 523955 | 2   | 7-2-8      | Healing takes place if the condition for error detection is not present. Air temperature monitoring plausibility check array.    |
| 36   | 523923 | 3   | 7-2-9      |  |
| 37   | 523924 | 3   | 1-6-7      | Short circuit to battery error of actuator relay 2.  |
| 38   | 523925 | 3   | 7-3-1      | Short circuit to battery of actuator relay 3.  |
| 40   | 523927 | 3   | 7-3-3      | Short circuit to battery of actuator relay 6.  |
| 41   | 523923 | 4   | 7-2-9      | Short circuit to ground error.<br>Detailed information not available.  |
| 42   | 523924 | 4   | 1-6-7      | Short circuit to ground of actuator relay 2.   |
| 43   | 523925 | 4   | 7-3-1      | Short circuit to ground of actuator relay 3.   |
| 44   | 523926 | 4   | 7-3-2      | Short circuit to ground of actuator relay 4.   |
| 45   | 168    | 3   | 3-1-8      | Sensor battery voltage error; signal range check is high.  |
| 46   | 168    | 4   | 3-1-8      | Sensor battery voltage error; signal range check is low.   |
| 47   | 168    | 2   | 3-1-8      | High battery voltage; warning threshold is exceeded.   |
| 48   | 168    | 2   | 3-1-8      | High battery voltage; Shot off threshold exceeded.   |
| 55   | 523910 | 14  | 6-9-5      | Air pump doesn't achieve air mass flow setpoint. Burner Control - burner air pump.   |
| 56   | 524013 | 7   | 8-5-6      | Burner Control. Burner does not start after several trials (burner flame lost detection).<br>Burner flame unintentional deleted. |
| 57   | 524020 | 14  | 8-6-3      | Burner Control: Power reduction due to low lambda. Engine power: Not enough oxygen for regeneration.                             |
| 58   | 523911 | 0   | 7-2-3      | Burner dosing valve (DV2); Overcurrent at the end of the injection phase.  |
| 59   | 523911 | 12  | 7-2-3      | Burner dosing valve (DV2); Powerstage over temperature.  |
| 60   | 523911 | 3   | 7-2-3      | Burner dosing valve (DV2); Short circuit to battery.   |
| 62   | 523911 | 4   | 7-2-3      | Burner dosing valve (DV2); Short circuit to ground.  |
| 63   | 523911 | 11  | 7-2-3      | Burner dosing valve (DV2); Short circuit high side powerstage.   |
| 64   | 523912 | 2   | 7-2-2      | Burner dosing valve (DV2) downstream pressure sensor; plausibility error.  |
| 66   | 523912 | 0   | 7-2-2      | Physical range check high for burner dosing valve (DV2) downstream pressure; Shut off regeneration.                              |

1513AA-1

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 69   | 523912 | 1   | 7-2-2      | Physical range check low for burner dosing valve (DV2) downstream pressure; Shut off regeneration.<br>When burner injector is actuated, the measured pressure does not rise above 1250mbar abs (expected: about 2400mbar).      |
| 72   | 523912 | 3   | 7-2-2      | Sensor error burner dosing valve (DV2) downstream pressure sensor; Signal range check high.   |
| 73   | 523912 | 4   | 7-2-2      | For engines < 4l:<br>Throttle valve error, Open load or short cut to battery, blocked valve or wrong control signal for valve.<br>For engines with Burner T4i:<br>Pressure Sensor error after valve (DV2), lower limit reached. |
| 74   | 523913 | 3   | 7-2-1      | Sensor error glow plug control diagnostic line voltage; Signal range check high.  |
| 75   | 523913 | 4   | 7-2-1      | Sensor error glow plug control diagnostic line voltage; Signal range check low.   |
| 76   | 523914 | 5   | 7-2-1      | Glow plug control; Open load.<br>Water pump control (PWM) only TTCD 6.1/7.8.  |
| 77   | 523914 | 12  | 7-2-1      | Glow plug control; Powerstage over temperature.   |
| 78   | 523914 | 3   | 7-2-1      | Glow plug control; Short circuit to battery. Water pump control (PWM).  |
| 79   | 523914 | 4   | 7-2-1      | Glow plug control; Short circuit to ground. Water pump control (PWM).   |
| 82   | 1235   | 14  | 2-7-1      | CAN-Bus 2 = CAN_C reports Bus-error (for engines <8L and CV52 it is the engine-CAN@250kbaud)<br>CAN Bus error passive; warning CAN C - engine CAN.  |
| 83   | 16     | 0   | 2-7-1      | No detail information.  |
| 84   | 639    | 14  | 2-7-1      | CAN-Bus 0: "BusOff-Status"  |
| 85   | 1231   | 14  | 2-7-1      | CAN-Bus 1: "BusOff-Status"  |
| 86   | 1235   | 14  | 2-7-1      | CAN-Bus 2 = engine bus "BusOff-Status"  |
| 87   | 16     | 0   | 2-7-1      | BusOff error CAN.   |
| 88   | 102    | 2   | 2-2-3      | Charged air pressure above warning threshold.   |
| 89   | 102    | 2   | 2-2-3      | Charged air pressure above shut off threshold.  |
| 90   | 110    | 2   | 2-2-5      | Defect fault check for absolute plausibility test.  |
| 92   | 110    | 0   | 2-2-5      | Physical range check high for coolant temperature.  |
| 93   | 110    | 1   | 2-2-5      | Physical range check low for coolant temperature.   |
| 96   | 110    | 3   | 2-2-5      | Sensor error coolant temperature; Signal range check high.  |
| 97   | 110    | 4   | 2-2-5      | Sensor error coolant temperature; Signal range check low.   |
| 98   | 110    | 0   | 2-3-2      | High coolant temperature; Warning threshold exceeded.   |
| 99   | 110    | 0   | 2-3-2      | Coolant temperature; System reaction initiated.   |
| 101  | 111    | 1   | 2-3-5      | Coolant level too low.  |
| 106  | 598    | 2   | 3-2-5      | Plausibility check for clutch.  |
| 121  | 1109   | 2   | 3-4-1      | Engine shut off demand ignored.   |

1513AA-2



## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 122  | 523698 | 11  | 5-9-1      | Shut off request from supervisory monitoring function.  |
| 124  | 523969 | 11  | 7-7-4      | Fault entry for override control mode.  |
| 125  | 523717 | 12  | 5-9-5      | Timeout error of CAN-transmit-frame AmbCon; Weather environments.   |
| 126  | 523603 | 9   | 3-3-8      | Timeout Error of CAN-receive-frame AMB; Ambient temperature sensor.   |
| 128  | 3224   | 9   | 5-9-7      | Timeout error of CAN-receive-frame AT1IG1; NOX sensor upstream.   |
| 129  | 3224   | 2   | 5-9-6      | DLC error of CAN-receive-frame AT1IG1Vol NOX sensor.  |
| 130  | 3224   | 9   | 5-9-7      | Timeout error of CAN-receive-frame AT1IG1Vol; NOX sensor.   |
| 133  | 523938 | 9   | 7-6-6      | Timeout error (BAM to packet) for CAN-receive-frame AT1IGCVol1.   |
| 134  | 523939 | 9   | 7-6-6      | Broadcast announce message of the calibration message of the upstream catalytic NOx sensor has failed.        |
| 135  | 523940 | 9   | 7-6-6      | Timeout error (PCK2PCK) for CAN-Receive-Frame AT1IGCVol1.   |
| 136  | 3234   | 2   | 1-1-4      | DLC error of CAN-Receive-Frame AT1O1.   |
| 137  | 3234   | 9   | 1-1-7      | Timeout error of CAN-Receive-Frame AT1OG1. NOX sensor (SCR-system downstream cat; DPF-system downstream cat). |
| 138  | 3234   | 2   | 1-1-4      | DLC error of CAN-Receive-Frame AT1O1Vol.  |
| 139  | 3234   | 9   | 1-1-7      | Timeout error of CAN-Receive-Frame AT1OG1Vol.   |
| 140  | 523941 | 9   | 7-6-7      | Timeout error (BAM to packet) for CAN-Receive-Frame AT1OGCVol2.   |
| 141  | 523942 | 9   | 7-6-7      | Calibration message 1 of the after catalyst Nox sensor has failed.  |
| 142  | 523943 | 9   | 7-6-7      | Timeout error (PCK2PCK) for CAN-Receive-Frame AT1OGCVol2.   |
| 153  | 523992 | 9   | 7-9-3      | Not used.   |
| 155  | 0      | 0   | -          | Not used.   |
| 164  | 523211 | 9   | 3-3-1      | Timeout error of CAN-Receive-Frame EBC1.  |
| 167  | 523704 | 12  | 6-1-5      | Timeout error of CAN-Transmit-Frame EEC3.   |
| 168  | 523935 | 12  | 7-6-3      | Timeout error of CAN-Transmit-Frame EEC3VOL1. Engine send messages.   |
| 169  | 523936 | 12  | 7-6-4      | Timeout error of CAN-Transmit-Frame EEC3VOL2. Engine send messages.   |
| 171  | 523212 | 9   | 3-3-3      | Timeout error of CAN-Receive-Frame ComEngPrt. Engine Protection.  |
| 172  | 523741 | 14  | 6-1-8      | Engine shut off request through CAN.  |
| 174  | 523213 | 12  | 3-3-4      | Timeout error of CAN-Transmit-Frame ERC1.   |
| 178  | 523706 | 12  | 6-2-3      | Timeout error of CAN-Transmit-Frame FIEco.  |
| 179  | 523240 | 9   | 5-2-7      | Timeout CAN-message FunModCtl. Function Mode Control.   |
| 193  | 523937 | 9   | 7-6-5      | Timeout DFC for NOxSensGlbReqTx.  |
| 196  | 3227   | 2   | 6-3-8      | DFC SAE J1939 error.  |
| 198  | 523216 | 9   | 3-3-7      | Timeout error of CAN-Receive-Frame PrHtEnCmd. Pre-heat command, engine command.                               |
| 202  | 523793 | 9   | 6-7-8      | Timeout error of CAN-Receive-Frame UAA10. AGS sensor service message.   |
| 203  | 523794 | 9   | 6-7-8      | Timeout error of CAN-Receive-Frame UAA11. AGS sensor data.  |
| 212  | 523803 | 9   | 6-7-8      | Timeout error of CAN-Receive-Message RxEngPres. Status Burner Air Pump.                                       |

1513AA-3

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification   |
|------|--------|-----|------------|--|
| 273  | 3219   | 2   | 6-4-9      | DFC SAE J1939 error.   |
| 281  | 523766 | 9   | 1-1-8      | Timeout error of CAN-Receive-Frame Active TSC1AE.  |
| 282  | 523767 | 9   | 1-1-8      | Timeout error of CAN-Receive-Frame Passive TSC1AE.   |
| 283  | 523768 | 9   | 1-1-9      | Timeout error of CAN-Receive-Frame Active TSC1AR.  |
| 284  | 523769 | 9   | 1-1-9      | Timeout error of CAN-Receive-Frame Passive TSC1AR.   |
| 291  | 523776 | 9   | 1-1-9      | Timeout error of CAN-Receive-Frame TSC1TE - active.  |
| 292  | 523777 | 9   | 1-1-9      | Passive timeout error of CAN-Receive-Frame TSC1TE. Setpoint.                                 |
| 293  | 523778 | 9   | 1-1-8      | Timeout error of CAN-Receive-Frame TSC1TR.   |
| 294  | 523779 | 9   | 1-1-8      | Passive timeout error of CAN-Receive-Frame TSC1TR.   |
| 299  | 523788 | 12  | 6-5-5      | Timeout error of CAN-Transmit-Frame TrbCH. Status Wastegate.                                 |
| 300  | 523605 | 9   | 1-1-8      | Timeout error of CAN-Receive-Frame TSC1AE. Traction Control.                                 |
| 301  | 523606 | 9   | 1-1-9      | Timeout error of CAN-Receive-Frame TSC1AR. Retarder.   |
| 305  | 898    | 9   | 1-1-8      | Timeout error of CAN-Receive-Frame TSC1TE. Setpoint.   |
| 306  | 520    | 9   | 1-1-9      | Timeout Error of CAN-Receive-Frame TSC1TR; control signal                                    |
| 313  | 523858 | 12  | 6-7-9      | Timeout error of CAN-Transmit-Frame UAA11.   |
| 322  | 523867 | 12  | 6-7-9      | Timeout error of CAN-Transmit-Frame UAA1 on CAN 2. Control burner air pump.                  |
| 360  | 523982 | 0   | 7-3-7      | Powerstage diagnosis disabled. High battery voltage.   |
| 361  | 523982 | 1   | 7-3-7      | Powerstage diagnosis disabled. Low battery voltage.  |
| 362  | 523090 | 2   | 3-2-9      | Engine brake Pre-Selection switch. Plausibility error.                                       |
| 376  | 630    | 12  | 2-8-1      | Access error EEPROM memory (delete).   |
| 377  | 630    | 12  | 2-8-1      | Access error EEPROM memory (read).   |
| 378  | 630    | 12  | 2-8-1      | Access error EEPROM memory (write).  |
| 381  | 411    | 4   | 6-9-3      | Physical range check low for EGR differential pressure.                                      |
| 384  | 2791   | 12  | 4-1-5      | Actuator EGR valve. Powerstage over temperature.   |
| 387  | 523612 | 12  | 5-5-5      | Internal software error ECU. Injection cut off.  |
| 388  | 190    | 0   | 2-1-4      | Engine speed above warning threshold.<br>Overspeed detection in component engine protection. |
| 389  | 190    | 0   | 2-1-4      | Engine speed above warning threshold (FOC-Level 1).  |
| 390  | 190    | 11  | 2-1-4      | Engine speed above warning threshold (FOC-Level 2).  |
| 391  | 190    | 14  | 2-1-4      | Engine speed above warning threshold (Overrun Mode).   |
| 411  | 108    | 11  | 2-9-2      | Ambient air pressure received from a CAN-bus is reported as defective.                       |
| 412  | 108    | 3   | 2-9-2      | Sensor error ambient air pressure. Signal range check high.                                  |
| 413  | 108    | 4   | 2-9-2      | Sensor error ambient air pressure. Signal range check low.                                   |
| 415  | 171    | 0   | 3-1-2      | Environment temperature sensor, temperature above upper physical threshold.                  |
| 416  | 171    | 1   | 3-1-2      | Environment temperature physical range check low.  |

1513AA-4

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification   |
|------|--------|-----|------------|--|
| 417  | 171    | 3   | 3-1-2      | Sensor error SCR-System environment temperature.<br>DPF-System air inlet temperature, signal range check high. |
| 418  | 171    | 4   | 3-1-2      | Sensor error SCR-System environment temperature.<br>DPF-System air inlet temperature, signal range check low.  |
| 419  | 190    | 8   | 2-1-2      | Sensor camshaft speed, disturbed signal.   |
| 420  | 190    | 12  | 2-1-2      | Sensor camshaft detection.<br>Out of range, signal disrupted, no signal.                                       |
| 421  | 190    | 2   | 2-1-3      | Offset angle between crank- and camshaft-sensor is too large.  |
| 422  | 190    | 8   | 2-1-2      | Sensor crankshaft detection.<br>Out of range, signal disrupted or no signal.                                   |
| 423  | 190    | 12  | 2-1-2      | Speed detection, out of range, signal disrupted or no signal.  |
| 455  | 975    | 5   | 2-3-8      | PWM-Signal fan, open load or short-circuit ground.   |
| 457  | 975    | 3   | 2-3-8      | PWM-Signal fan, short-circuit to battery.  |
| 458  | 975    | 4   | 2-3-8      | PWM-Signal fan, open load or short circuit to ground   |
| 459  | 1639   | 12  | 2-3-8      | Fan speed sensor, electrical error, signal disturbed or very low fan speed.                                    |
| 460  | 1639   | 0   | 2-3-8      | Sensor error fan speed.<br>Signal range check high or engine speed resp. Fan speed too big.                    |
| 461  | 1639   | 1   | 2-3-8      | Sensor error fan speed, signal range check low or fan speed too low.   |
| 462  | 523602 | 0   | 2-3-8      | High fan speed, warning threshold exceeded.  |
| 463  | 523602 | 0   | 2-3-8      | High fan speed, shut off threshold exceeded.   |
| 464  | 97     | 3   | 2-2-8      | Sensor error water in fuel, signal range check high.   |
| 465  | 97     | 4   | 2-2-8      | Sensor error water in fuel, signal range check low.  |
| 472  | 94     | 3   | 2-1-6      | Sensor error low fuel pressure, signal range check high.   |
| 473  | 94     | 4   | 2-1-6      | Sensor error low fuel pressure, signal range check low.  |
| 474  | 94     | 1   | 2-1-6      | Low fuel pressure, warning threshold exceeded.   |
| 475  | 94     | 1   | 2-1-6      | Low fuel pressure, shut off threshold exceeded.  |
| 483  | 174    | 11  | 2-2-7      | Fuel temperature not plausible.  |
| 486  | 523618 | 3   | 1-3-3      | Sensor error gearbox oil temperature, signal range check high.   |
| 487  | 523618 | 4   | 1-3-3      | Sensor error gearbox oil temperature, signal range check low.  |
| 488  | 523619 | 2   | 1-3-3      | Physical range check high for exhaust gas temperature upstream (SCR-CAT).                                      |
| 489  | 523619 | 2   | 1-3-3      | Shutoff condition.<br>No detailed information!   |
| 500  | 523915 | 0   | 1-6-5      | HCI dosing valve (DV1); overcurrent at the end of the injection phase  |
| 501  | 523915 | 12  | 1-6-6      | HCI dosing valve (DV1): Powerstage over temperature.   |
| 502  | 523915 | 3   | 1-5-9      | HCI dosing valve (DV1): Short circuit to battery.  |
| 503  | 523915 | 3   | 1-6-4      | Short circuit to battery high side, HCI dosing valve (DV1).  |
| 504  | 523915 | 4   | 1-5-9      | HCI dosing valve (DV1): Short circuit to ground.   |
| 505  | 523915 | 11  | 1-6-4      | HCI dosing valve (DV1): Short circuit high side powerstage.  |

1513AA-5

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 506  | 523916 | 2   | 7-1-9      | Sensor HCl dosing valve (DV1) downstream pressure: Plausibility error.                        |
| 508  | 523916 | 0   | 7-1-9      | HCl dosing valve (DV1) downstream pressure: Physical range check high. Shut off regeneration. |
| 511  | 523916 | 1   | 7-1-9      | HCl dosing valve (DV1) downstream pressure: Physical range check low. Shut off regeneration.  |
| 514  | 523916 | 3   | 7-1-9      | Sensor error HCl dosing valve (DV1) downstream pressure: Signal range check high.             |
| 515  | 523916 | 4   | 7-1-9      | Sensor error HCl dosing valve (DV1) downstream pressure: Signal range check low.              |
| 525  | 523917 | 4   | 7-1-8      | Sensor error DV1 & DV2 upstream pressure: Signal range check low.                             |
| 534  | 523918 | 3   | 7-1-7      | Sensor error DV1 & DV2 upstream temperature: Signal range check high.                         |
| 535  | 523918 | 4   | 7-1-7      | Sensor error DV1 & DV2 upstream temperature: Signal range check low.                          |
| 542  | 1638   | 2   | 3-1-4      | Hydraulic oil temperature check for Shut off condition.                                       |
| 543  | 676    | 11  | 263        | Cold start aid relay error.   |
| 544  | 676    | 11  | 263        | Cold start aid relay: Open load.  |
| 545  | 729    | 5   | 263        | Cold start aid relay open load.   |
| 547  | 729    | 12  | 263        | Cold start aid relay: Over temperature error.   |
| 549  | 729    | 3   | 263        | Intake Air Heater Device: Short circuit to battery.   |
| 551  | 729    | 4   | 263        |   |
| 559  | 523895 | 13  | 1-5-8      | Check of missing injector adjustment value programming (IMA) injector 1.                      |
| 560  | 523896 | 13  | 1-5-8      | Check of missing injector adjustment value programming (IMA) injector 2.                      |
| 561  | 523897 | 13  | 1-5-8      | Check of missing injector adjustment value programming (IMA) injector 3.                      |
| 562  | 523898 | 13  | 1-5-8      | Check of missing injector adjustment value programming (IMA) injector 4.                      |
| 563  | 523899 | 13  | 1-5-8      | Check of missing injector adjustment value programming (IMA) injector 5.                      |
| 564  | 523900 | 13  | 1-5-8      | Check of missing injector adjustment value programming (IMA) injector 6.                      |
| 565  | 523350 | 4   | 151        | Injector cylinder-bank 1: Short circuit.  |
| 566  | 523352 | 4   | 152        | Injector cylinder-bank 2: Short circuit.  |
| 567  | 523354 | 12  | 153        | Injector powerstage output defect.  |
| 568  | 651    | 5   | 154        | Injector 1 (in firing order): Interruption of electric connection.                            |
| 569  | 652    | 5   | 155        | Injector 2 (in firing order): Interruption of electric connection.                            |
| 570  | 653    | 5   | 156        | Injector 3 (in firing order): Interruption of electric connection.                            |
| 571  | 654    | 5   | 161        | Injector 4 (in firing order): Interruption of electric connection.                            |
| 572  | 655    | 5   | 162        | Injector 5 (in firing order): Interruption of electric connection.                            |
| 573  | 656    | 5   | 163        | Injector 6 (in firing order): Interruption of electric connection.                            |
| 575  | 523756 | 14  | 1-5-5      | Special pattern for special cases. No detailed information!                                   |
| 576  | 523757 | 14  | 1-5-6      | Special pattern for special cases. No detailed information!                                   |
| 577  | 523758 | 14  | 1-6-1      | Special pattern for special cases. No detailed information!                                   |

1513AA-6



## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification   |
|------|--------|-----|------------|--|
| 578  | 523759 | 14  | 1-6-2      | Special pattern for special cases No detailed information!                                 |
| 579  | 523760 | 14  | 1-6-3      | Special pattern for special cases No detailed information!                                 |
| 580  | 651    | 3   | 154        | Injector 1 (in firing order): Short circuit.   |
| 581  | 652    | 3   | 155        | Injector 2 (in firing order): Short circuit.   |
| 582  | 653    | 3   | 156        | Injector 3 (in firing order): Short circuit.   |
| 583  | 654    | 3   | 161        | Injector 4 (in firing order): Short circuit.   |
| 584  | 655    | 3   | 162        | Injector 5 (in firing order): Short circuit.   |
| 585  | 656    | 3   | 163        | Injector 6 (in firing order): Short circuit.   |
| 590  | 655    | 4   | 1-6-2      | High side to low side short circuit in the injector 5 (in firing order).                   |
| 591  | 656    | 4   | 1-6-3      | High side to low side short circuit in the injector 6 (in firing order).                   |
| 592  | 523615 | 5   | 135        | Metering unit (Fuel-System): Open load.  |
| 593  | 523615 | 12  | 135        | Metering unit (Fuel-System): Powerstage over temperature.                                  |
| 594  | 523615 | 3   | 135        | Metering unit (Fuel-System): Short circuit to battery, highside.                           |
| 595  | 523615 | 4   | 135        | Metering unit (Fuel-System): Short circuit to ground, high side.                           |
| 596  | 523615 | 3   | 135        | Metering unit (Fuel-System): Short circuit to battery, low side.                           |
| 597  | 523615 | 4   | 135        | Metering Unit (Fuel-System): Short circuit to ground, low side                             |
| 598  | 523615 | 3   | 1-3-5      | Metering unit, short circuit to battery.   |
| 599  | 523615 | 4   | 1-3-5      | Metering unit, short circuit to ground.  |
| 605  | 1323   | 12  | 2-4-1      | Too many recognized misfires in cylinder 2 (in firing order).                              |
| 607  | 1323   | 12  | 2-4-1      | Too many recognized misfires in cylinder 4 (in firing order).                              |
| 608  | 1323   | 12  | 2-4-1      | Too many recognized misfires in cylinder 5 (in firing order).                              |
| 609  | 1323   | 12  | 2-4-1      | Too many recognized misfires in cylinder 6 (in firing order).                              |
| 610  | 1322   | 12  | 2-4-1      |  |
| 611  | 1346   | 0   | 2-4-1      | Misfire detection monitoring No detailed information!                                      |
| 612  | 523612 | 12  | 555        | Internal ECU monitoring detection reported error.  |
| 613  | 523612 | 12  | 555        | ECU reported internal software error.<br>Internal ECU monitoring detection reported error. |
| 614  | 523612 | 12  | 555        | ECU reported internal software error.  |
| 615  | 523612 | 12  | 555        | ECU reported internal software error.  |
| 616  | 523612 | 12  | 555        | ECU reported internal software error.  |
| 617  | 523612 | 12  | 555        | ECU reported internal software error.  |
| 618  | 523612 | 12  | 555        | ECU reported internal software error.  |
| 619  | 523612 | 12  | 555        | Injection system,electrical error injectors.   |
| 620  | 523612 | 12  | 555        | ECU reported internal software error.  |
| 621  | 523612 | 12  | 555        | ECU reported internal software error.  |
| 623  | 523612 | 12  | 555        | ECU reported internal software error.  |

1513AA-7

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 624  | 523612 | 12  | 555        | ECU reported internal software error.   |
| 625  | 523612 | 12  | 555        | ECU reported internal software error.   |
| 627  | 523612 | 12  | 555        | ECU reported internal software error.   |
| 628  | 523612 | 12  | 555        | ECU reported internal software error.   |
| 629  | 523612 | 12  | 555        | Diagnostic fault check to report the accelerator pedal position error.  |
| 630  | 523612 | 12  | 555        | Diagnostic fault check to report the engine speed error.  |
| 631  | 523612 | 12  | 555        | Error in the plausibility of the injection energizing time.   |
| 632  | 523612 | 12  | 555        | Error in the plausibility of the start of energising angles.  |
| 633  | 523612 | 12  | 555        | Diagnostic fault check to report the error due to non plausibility in ZFC.                                    |
| 634  | 523612 | 12  | 555        | Diagnosis fault check to report the demand for normal mode due to an error in the Pol2 quantity.              |
| 635  | 523612 | 12  | 555        | Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol2 shut-off.          |
| 636  | 523612 | 12  | 555        | Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol3 efficiency factor. |
| 637  | 523612 | 12  | 555        | Internal ECU monitoring detection reported error.   |
| 638  | 523612 | 12  | 555        | Monitoring of Fuel Quantity Correction.   |
| 639  | 523612 | 12  | 555        | Diagnostic fault check to report the plausibility error in rail pressure monitoring.                          |
| 640  | 523612 | 12  | 555        | Diagnostic fault check to report the error due to torque comparison.  |
| 641  | 523612 | 12  | 555        | Diagnosis of curr path limitation forced by ECU monitoring level 2.   |
| 642  | 523612 | 12  | 555        | Diagnosis of lead path limitation forced by ECU monitoring level 2.   |
| 643  | 523612 | 12  | 5-5-5      | Diagnosis of set path limitation forced by ECU monitoring level 2.  |
| 644  | 523612 | 3   | 5-5-5      | Reported Over Voltage of Supply.  |
| 646  | 523612 | 4   | 5-5-5      | Reported UnderVoltage of Supply.  |
| 648  | 523008 | 1   | 4-2-4      | Manipulation control was triggered.   |
| 649  | 523008 | 2   | 4-2-4      | Timeout error in Manipulation control.  |
| 654  | 2634   | 12  | 7-5-7      | Early opening defect of main relay No detailed information!   |
| 656  | 2634   | 12  | 7-5-7      | DFC for stuck main relay error No detailed information!   |
| 659  | 3226   | 2   | 8-1-3      | Nox feed back fault detection No detailed information!  |
| 692  | 523752 | 0   | 7-5-8      | Plausibiliti error during Rich to Lean switch over No detail informationen!                                   |
| 693  | 523752 | 0   | 7-5-8      | Monitoring of Nox signal readiness No detail informationen!   |
| 714  | 523612 | 12  | 5-5-5      | Diagnostic fault check to report WDA active due to errors in query-/response communication.                   |
| 715  | 523612 | 12  | 5-5-5      | Diagnostic fault check to report ABE active due to undervoltage detection.                                    |
| 716  | 523612 | 12  | 5-5-5      | Diagnostic fault check to report ABE active due to overvoltage detection.                                     |
| 717  | 523612 | 12  | 5-5-5      | Diagnostic fault check to report WDA/ABE active due to unknown reason.  |

1513AA-8

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 720  | 98     | 2   | 2-1-1      | Plausibility Check.<br>No detailed information!                                       |
| 732  | 100    | 3   | 2-2-4      | Sensor error oil pressure; signal range check high.                                   |
| 733  | 100    | 4   | 2-2-4      | Sensor error oil pressure sensor; signal range check low.                             |
| 734  | 100    | 0   | 2-3-1      | High oil pressure; warning threshold exceeded.  |
| 735  | 100    | 0   | 2-3-1      | High oil pressure; shut off threshold exceeded.                                       |
| 736  | 100    | 1   | 2-3-1      | Low oil pressure; warning threshold exceeded.   |
| 737  | 100    | 1   | 2-3-1      | Low oil pressure; shut off threshold exceeded.  |
| 743  | 175    | 3   | 1-4-4      | Sensor error oil temperature; signal range check high.                                |
| 744  | 175    | 4   | 1-4-4      | Sensor error oil temperature; signal range check low.                                 |
| 745  | 175    | 0   | 1-4-4      | High oil temperature; warning threshold exceeded.                                     |
| 746  | 175    | 0   | 1-4-4      | High oil temperature; shut off threshold exceeded.                                    |
| 747  | 1237   | 2   | 1-4-5      | Override switch; plausibility error.  |
| 750  | 107    | 3   | 1-3-6      | Sensor error airfilter differential pressure; short circuit to battery.               |
| 751  | 107    | 0   | 1-3-6      | Sensor error airfilter differential pressure; short circuit to ground.                |
| 752  | 107    | 0   | 1-3-6      | Air filter differential pressure; air filter clogged.                                 |
| 753  | 523919 | 2   | 6-9-4      | DPF burner air pump pressure sensor, plausibility error.                              |
| 755  | 523919 | 0   | 6-9-4      | DPF burner air pump pressure sensor, pressure above upper shutoff threshold.          |
| 758  | 523919 | 1   | 6-9-4      | DPF burner air pump pressure sensor, pressure below lower shutoff threshold.          |
| 761  | 523919 | 3   | 6-9-4      | DPF burner air pump pressure sensor, short circuit to battery or open load.           |
| 762  | 523919 | 4   | 6-9-4      | DPF burner air pump pressure sensor, short circuit to ground.                         |
| 763  | 523920 | 2   | 7-1-6      | Exhaust gas pressure upstream burner, plausibility error.                             |
| 765  | 523920 | 0   | 7-1-6      | Exhaust gas pressure upstream burner, pressure above upper shutoff threshold.         |
| 770  | 523920 | 3   | 7-1-6      | Exhaust gas pressure upstream burner, short circuit to battery or open load.          |
| 771  | 523920 | 4   | 7-1-6      | Exhaust gas pressure upstream burner, short circuit to ground.                        |
| 772  | 102    | 2   | 2-2-3      | Pressure downstream charge air cooler, plausibility error.                            |
| 774  | 102    | 1   | 2-2-3      | Pressure downstream charge air cooler, pressure below lower physical threshold.       |
| 776  | 102    | 3   | 2-2-3      | Pressure downstream charge air cooler, short circuit to battery or open load.         |
| 777  | 102    | 4   | 2-2-3      | Pressure downstream charge air cooler, short circuit to ground.                       |
| 780  | 523699 | 3   | 1-1-3      | Boost pressure control; negative governor deviation below limit.                      |
| 781  | 523699 | 4   | 1-1-3      | Learning value too high. No detailed information!                                     |
| 785  | 523889 | 3   | 1-1-3      | Over temperature of device driver of pressure control valve. No detailed information! |

1513AA-9

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 791  | 411    | 0   | 6-9-3      | Delta pressure across venturi in EGR line above physical high limit.  |
| 793  | 411    | 0   | 6-9-3      | Plausibility Check fault for deviation of desired and actual EGR-mass flow, where the latter is calculated out of EGR Delta Pressure Sensor.  |
| 795  | 411    | 3   | 6-9-3      | Sensor error differential pressure Venturiunit (EGR), signal range check low.   |
| 796  | 411    | 4   | 6-9-3      | Sensor error differential pressure Venturiunit (EGR), signal range check high.  |
| 805  | 524025 | 14  | 8-4-5      | Particulate filter regeneration.<br>(3x) over the max. has been aborted allowed recovery time.<br>Regeneration after time X is not successful (the error occurs when the regeneration times). |
| 806  | 524058 | 2   | 8-4-4      | Particulate filter; regeneration not successful.  |
| 807  | 3253   | 2   | 6-9-2      | Differential pressure DPF, plausibility error.  |
| 809  | 3251   | 0   | 6-9-2      | Differential pressure DPF maximum value is exceeded.  |
| 810  | 3251   | 0   | 6-9-2      | Differential pressure sensor across DPF exceeds warning high limit.   |
| 812  | 3251   | 1   | 6-9-2      | Differential pressure DPF, pressure below lower shutoff threshold.  |
| 813  | 3251   | 1   | 6-9-2      | Differential pressure DPF, pressure below lower warning threshold.  |
| 814  | 3253   | 3   | 6-9-2      | Electrical error differential pressure B58 (DPF). (Signal range check high).  |
| 815  | 3253   | 4   | 6-9-2      | Electrical error differential pressure (DPF). signal range check low.   |
| 825  | 523009 | 9   | 2-5-3      | The pressure relief valve (PRV) has reached the number of allowed activations.  |
| 826  | 523470 | 2   | 1-4-6      | Pressure relief valve is forced to open, perform pressure increase.   |
| 827  | 523470 | 2   | 1-4-6      | Pressure Relief Valve (PRV) forced to open. Performed by pressure increase.   |
| 828  | 523470 | 12  | 1-4-6      | Pressure Relief Valve (PRV) forced to open. Shutoff conditions.   |
| 829  | 523470 | 12  | 1-4-6      | Pressure Relief Valve (PRV) forced to open. Warning conditions.   |
| 830  | 523470 | 14  | 1-4-6      | Open Pressure Relief Valve (PRV).   |
| 831  | 523470 | 11  | 1-4-6      | Pressure Relief Valve (PRV) error; Rail pressure out of tolerance range.  |
| 832  | 523470 | 11  | 1-4-6      | Rail pressure out of tolerance range.<br>The PRV can not be opened at this operating point with a pressure shock.   |
| 833  | 523009 | 10  | 2-5-3      | Open time of Pressure Relief Valve (PRV) for wear out monitoring had exceeded.  |
| 834  | 523906 | 5   | 7-6-1      | Electrical fuel pre - supply pump; open load.   |
| 835  | 523906 | 12  | 7-6-1      | Electrical fuel pre - supply pump. ECU powerstage over temperature.   |
| 836  | 523906 | 3   | 7-6-1      | Electrical fuel pre - supply pump; short circuit to battery.  |
| 837  | 523906 | 4   | 7-6-1      | Electrical fuel pre - supply pump. Short circuit to ground.   |
| 847  | 1176   | 0   | 1-3-9      | Pressure sensor upstream turbine, Physical Range Check high.  |
| 848  | 1176   | 1   | 1-3-9      | Pressure sensor upstream turbine, Physical Range Check low.   |
| 849  | 1176   | 3   | 1-4-1      | Pressure sensor upstream turbine, signal range check (SRC) high.  |
| 850  | 1176   | 4   | 1-4-1      | Pressure sensor upstream turbine, signal range check (SRC) low.   |
| 856  | 523613 | 0   | 1-3-4      | Rail pressure metering unit, Positive governor deviation.   |

1513AA-10



## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification   |
|------|--------|-----|------------|--|
| 857  | 523613 | 0   | 1-3-4      | Rail pressure metering unit, Rail pressure disrupted. Maximum positive deviation of rail pressure exceeded.                              |
| 858  | 523613 | 0   | 1-3-4      | Rail pressure metering unit, Rail pressure disrupted. Maximum positive deviation of rail pressure in metering unit exceeded (RailMeUn1). |
| 859  | 523613 | 0   | 1-3-4      | Rail pressure metering unit, Rail pressure below the target range. (RailMeUn2)<br>Railsystem leakage detected.(RailMeUn10)               |
| 861  | 523613 | 1   | 1-3-4      | Rail pressure metering unit, Minimum rail pressure exceeded (RailMeUn3). Negative deviation of rail pressure second stage (RailMeUn22).  |
| 862  | 523613 | 0   | 1-3-4      | Rail pressure metering unit, Maximum rail pressure exceeded.   |
| 864  | 523613 | 2   | 1-3-4      | Rail pressure metering unit, Setpoint of metering unit in overrun mode not plausible.  |
| 865  | 523613 | 0   | 1-3-4      | Setpoint of metering unit in overrun mode not plausible.   |
| 874  | 157    | 0   | 1-4-7      | Rail pressure raw value is intermittent. No detailed information!  |
| 875  | 157    | 1   | 1-4-7      | rail pressure raw value is above maximum offset. No detailed information!  |
| 876  | 523470 | 7   | 1-4-6      | Maximum rail pressure exceeded (PRV).  |
| 877  | 157    | 3   | 1-4-7      | Sensor error rail pressure. Sensor voltage above upper limit.  |
| 878  | 157    | 4   | 1-4-7      | Sensor error rail pressure. Sensor voltage below lower limit.  |
| 881  | 523633 | 11  | 1-4-9      | Longterm adaption factor below threshold.  |
| 882  | 523633 | 11  | 1-4-9      | Nox conversion rate insufficient (SCR-Cat defect, bad DEF quality).  |
| 883  | 523633 | 11  | 1-4-9      | Nox conversion rate insufficient (SCR-Cat defect, bad DEF quality); temperature range 1  |
| 887  | 3234   | 11  | 1-8-4      | DFC for plausibility error Min for NOx sensor downstream of SCR Cat.   |
| 889  | 3224   | 1   | 1-8-5      | DFC for plausibility error Max for NOx sensor upstream of SCR Cat.   |
| 892  | 4345   | 11  | 2-3-6      | Sensor backflow line pressure (SCR); plausibility error.   |
| 893  | 4343   | 11  | 8-7-1      | SCR Monitoring; Pressure stabilisation error, general pressure check error (SCR).  |
| 894  | 4374   | 13  | 8-7-2      | Pressure stabilisation error dosing valve (SCR).   |
| 897  | 523632 | 16  | 8-7-5      | Pump pressure SCR metering unit too high.  |
| 898  | 523632 | 18  | 8-7-6      | Pump pressure SCR metering unit too low.   |
| 899  | 523632 | 0   | 8-7-7      | Pressure overload of SCR-System.   |
| 900  | 523632 | 1   | 8-7-8      | Pressure build-up error SCR-System.  |
| 903  | 4365   | 0   | 8-8-1      | DEF tank temperature too high.   |
| 905  | 3241   | 0   | 8-8-3      | Sensor SCR catalyst upstream temperature too high; plausibility error.   |
| 908  | 3361   | 7   | 8-8-6      | DEF dosing valve blocked (SCR).  |
| 914  | 523720 | 2   | 1-4-8      | DEF supply module heater temperature; plausibility error (normal condition).   |
| 915  | 523720 | 2   | 1-4-8      | Sensor DEF supply module heater temperature; plausibility error (cold start condition).  |

1513AA-11

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 916  | 523721 | 2   | 6-8-9      | Sensor DEF supply module temperature; plausibility error (normal condition).  |
| 917  | 523721 | 2   | 6-8-9      | Sensor DEF supply module temperature; plausibility error (cold start condition).  |
| 918  | 523981 | 11  | 2-4-3      | SCR plausibility, OBD and diagnosis; Stuck in range check of DEF tank temperature sensor.<br>DEF-tank without heating function (heating phase). |
| 919  | 523330 | 14  | 1-3-1      | Immobilizer status; fuel blocked.   |
| 920  | 523330 | 14  | 1-3-1      | DFC to block the fuel by Sia. No detailed information!  |
| 921  | 523330 | 14  | 1-3-1      | DFC to indicate that TEN-code or UC-code received if ECU is learned. No detailed information!   |
| 922  | 523330 | 14  | 1-3-1      | DFC to indicate that no code is received via CAN. No detailed information!  |
| 923  | 523330 | 14  | 1-3-1      | DFC to indicate that wrong code is received. No detailed information!   |
| 925  | 523720 | 8   | 1-4-8      | DEF supply module heater temperature; duty cycle in failure range.  |
| 926  | 523720 | 8   | 1-4-8      | DEF supply module heater temperature; duty cycle in invalid range.  |
| 927  | 523721 | 11  | 6-8-9      | Urea supply module temperature measurement not available.   |
| 928  | 523722 | 8   | 6-9-1      | DEF supply module PWM signal; period outside valid range.   |
| 929  | 523722 | 8   | 6-9-1      | Detect faulty PWM signal from Supply Modul.   |
| 930  | 523721 | 8   | 6-8-9      | DEF supply module temperature; duty cycle in failure range.   |
| 931  | 523721 | 8   | 6-8-9      | Urea supply module temperature; duty cycle in invalid range.  |
| 932  | 29     | 3   | 1-2-6      | Handthrottle idle validation switch; short circuit to battery   |
| 935  | 91     | 3   | 2-2-6      | Sensor error accelerator pedal. signal range check high.  |
| 937  | 29     | 4   | 1-2-6      | Handthrottle; short circuit to ground.  |
| 940  | 91     | 4   | 2-2-6      | Sensor error accelerator pedal. Signal is below the range.  |
| 942  | 523921 | 3   | 7-1-4      | Sensor error burner temperature; signal range check high.   |
| 943  | 3532   | 3   | 1-2-7      | Sensor error DEF tank level; signal range check high.   |
| 944  | 523921 | 4   | 7-1-4      | Sensor error burner temperature; signal range check low.  |
| 946  | 1079   | 13  | 2-8-2      | Failure of sensor supply voltage 1.   |
| 947  | 1080   | 13  | 2-8-2      | Failure of sensor supply voltage 2.   |
| 948  | 523601 | 13  | 2-8-2      | Failure of sensor supply voltage 3.   |
| 956  | 677    | 3   | 5-1-2      | Starter relay high side. Short circuit to battery.  |
| 957  | 677    | 4   | 5-1-2      | Starter relay high side short circuit to ground.  |
| 958  | 677    | 5   | 5-1-2      | Starter relay low side no load error.   |
| 959  | 677    | 12  | 5-1-2      | Starter relay powerstage over temperature.  |
| 960  | 677    | 3   | 5-1-2      | Starter relay low side short circuit to battery.  |
| 961  | 677    | 4   | 5-1-2      | Starter relay low side short circuit to ground.   |
| 965  | 523922 | 3   | 7-1-5      | Burner shut of valve; short circuit to battery.   |
| 969  | 624    | 5   | 5-1-3      | SVS lamp; open load.  |

1513AA-12

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 970  | 624    | 12  | 5-1-3      | SVS lamp: powerstage over temperature   |
| 971  | 624    | 3   | 5-1-3      | SVS lamp; short circuit to battery  |
| 972  | 624    | 4   | 5-1-3      | SVS lamp; short circuit to ground   |
| 973  | 523612 | 14  | 5-5-5      | Softwarereset CPU SWReset_0   |
| 974  | 523612 | 14  | 5-5-5      | Softwarereset CPU SWReset_1   |
| 975  | 523612 | 14  | 5-5-5      | Softwarereset CPU SWReset_2   |
| 976  | 91     | 11  | 2-2-6      | Plausibility error between APP1 and APP2 or APP1 and idle switch.   |
| 978  | 29     | 2   | 1-2-6      | Plausibility error between sensor and idle switch, Acceleratio Pedal Detection.<br>In case of Hand Throttle with Low Idle Switch, it is the plausibility check between hand throttle and idle switch. |
| 980  | 523550 | 12  | 5-1-5      | Terminal 50 was operated too long.  |
| 981  | 172    | 3   | 2-2-6      | Air flow temperature sensor; short circuit to battery or open load.   |
| 982  | 172    | 4   | 2-2-6      | Air flow temperature sensor; short circuit to ground.   |
| 986  | 523921 | 0   | 7-1-4      | Burner temperature, temperature above upper shutoff threshold.  |
| 989  | 523921 | 1   | 7-1-4      | Burner temperature, temperature below lower shutoff threshold.  |
| 992  | 105    | 1   | 1-2-8      | Charged Air cooler down stream temperature. Temperature below lower physical threshold.   |
| 994  | 105    | 3   | 1-2-8      | Electrical error charged air temperature. Signal range check high.(SRC)   |
| 995  | 105    | 4   | 1-2-8      | Electrical error charged air temperature. Signal range check low.   |
| 996  | 105    | 0   | 2-3-3      | Charged air cooler temperature. System reaction initiated. High charged air cooler temperature. Warning threshold exceeded.   |
| 997  | 105    | 0   | 2-3-3      | High charged air cooler temperature. Shut off threshold exceeded.   |
| 998  | 105    | 11  | 1-2-8      | Diagnostic fault check for charged air cooler downstream temperature sensor<br>No detailed information!   |
| 1007 | 412    | 3   | 6-8-2      | Electrical error EGR cooler downstream temperature. Signal range check high.  |
| 1008 | 412    | 4   | 6-8-2      | electrical error EGR cooler downstream temperature. Signal range check low.   |
| 1011 | 523960 | 0   | 7-7-1      | Physical range check high for EGR cooler downstream temperature.  |
| 1012 | 523960 | 1   | 7-7-1      | Physical range check low for EGR cooler downstream temperature.   |
| 1014 | 51     | 6   | 5-9-4      | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8).<br>Signal range check high.   |
| 1015 | 520521 | 5   | 5-9-4      | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); signal range check low.   |
| 1016 | 51     | 7   | 5-9-4      | Actuator position for EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8) not plausible.  |
| 1022 | 51     | 6   | 5-9-4      | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); signal range check high   |

1513AA-13

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification   |
|------|--------|-----|------------|--|
| 1023 | 51     | 5   | 5-9-4      | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); signal range check low.                        |
| 1024 | 51     | 3   | 5-9-4      | Position sensor error of actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8).<br>Signal range check high. |
| 1025 | 51     | 4   | 5-9-4      | Position sensor error actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8).<br>Signal range check low.     |
| 1026 | 4769   | 2   | 6-8-4      | Temperature downstream DOC, plausibility error.  |
| 1029 | 4766   | 0   | 6-8-4      | Temperature downstream DOC, temperature above upper shutoff threshold.   |
| 1030 | 4766   | 0   | 6-8-4      | Temperature downstream DOC, temperature above upper warning threshold.   |
| 1034 | 4769   | 3   | 6-8-4      | Sensor error exhaust gas temperature downstream (DOC); signal range check high.                                    |
| 1035 | 4769   | 4   | 6-8-4      | Sensor error exhaust gas temperature downstream (DOC); signal range check low.                                     |
| 1036 | 4768   | 2   | 6-8-3      | Temperature upstream DOC, plausibility error.  |
| 1039 | 4765   | 0   | 6-8-3      | Temperature upstream DOC, temperature above upper shutoff threshold.   |
| 1040 | 4765   | 0   | 6-8-3      | Temperature upstream DOC, temperature above upper warning threshold.   |
| 1044 | 4768   | 3   | 6-8-3      | Electrical error exhaust gas temperature upstream (DOC); signal range check high.                                  |
| 1045 | 4768   | 4   | 6-8-3      | Electrical error exhaust gas temperature upstream (DOC); signal range check low.                                   |
| 1047 | 3248   | 4   | 6-8-5      | Sensor error particle filter downstream temperature; signal range check low.                                       |
| 1067 | 1180   | 3   | 5-5-6      | Sensor error exhaust gas temperature upstream turbine; signal range check high.                                    |
| 1069 | 4360   | 0   | 6-6-8      | Exhaust temperature upstream SCR-Cat, temperature above upper physical threshold.                                  |
| 1070 | 4360   | 1   | 6-6-8      | Sensed exhaust temperature before SCR-Cat is < physical low limit.   |
| 1071 | 4361   | 2   | 6-6-8      | Signal error for CAN message No detail informationen!  |
| 1166 | 523948 | 1   | 7-7-2      | Zerofuel calibration injector 3 (in firing order); minimum value exceeded.   |
| 1167 | 523949 | 1   | 7-7-2      | Zerofuel calibration injector 4 (in firing order); minimum value exceeded.   |
| 1168 | 523950 | 1   | 7-7-2      | Zerofuel calibration injector 5 (in firing order); minimum value exceeded.   |
| 1170 | 523612 | 12  | 5-5-5      | Internal software error ECU.   |
| 1180 | 168    | 0   | 3-1-8      | Physical range check high for battery voltage.   |
| 1181 | 168    | 1   | 3-1-8      | Physical range check low for battery voltage.  |
| 1183 | 172    | 1   | 2-2-6      | Air inlet filter sensor out of physical range check.   |
| 1187 | 523980 | 14  | 7-8-4      | Bad quality of reduction agent detected.   |
| 1193 | 1180   | 0   | 5-5-6      | Physical range check high for exhaust gas temperature upstream turbine.  |
| 1194 | 1180   | 1   | 5-5-6      | Physical range check low for exhaust gas temperature upstream turbine.   |

1513AA-14



## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 1219 | 524018 | 14  | 7-8-6      | HMI engine derate service state.<br>DPF wasn't regenerated, power reduction phase 1 (manuell regeneration request). |
| 1220 | 524022 | 14  | 7-8-6      | HMI engine derate stop state.<br>DPF wasn't regenerated, power reduction phase 2 (manuell regeneration request).    |
| 1222 | 190    | 14  | 2-1-2      | Camshaft- and Crankshaft speed sensor signal not available on CAN.  |
| 1223 | 51     | 5   | 5-9-4      | Actuator EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); open load.  |
| 1224 | 51     | 6   | 5-9-4      | Actuator EGR-Valve (2.9;3.6) or Throttle-Valve (6.1;7.8); over current.   |
| 1226 | 51     | 3   | 5-9-4      | EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to battery.                                      |
| 1227 | 51     | 3   | 5-9-4      | EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to battery.                                      |
| 1228 | 51     | 4   | 5-9-4      | EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to ground.                                       |
| 1229 | 51     | 4   | 5-9-4      | EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); short circuit to ground.                                       |
| 1230 | 51     | 6   | 5-9-4      | Actuator error EGR-Valve (2.9;3.6) or Throttle-Valve (4.1;6.1;7.8); Overload by short-circuit.                      |
| 1231 | 51     | 11  | 5-9-4      | Power stage overtemperature due to high current.  |
| 1232 | 51     | 4   | 5-9-4      | actuator AGR valve (2.9;3.6) throttle valve (4.1;6.1;7.8); Voltage below threshold.                                 |
| 1239 | 523984 | 3   | 7-8-8      | UB7; Short circuit to battery error of actuator relay 7.  |
| 1241 | 523986 | 4   | 1-7-6      | UB6; Short circuit to ground actuator relais 6.   |
| 1242 | 523987 | 4   | 7-9-1      | UB7; Short circuit to ground actuator relay 7.  |
| 1247 | 524019 | 11  | 8-6-2      | Burner Control; Air Line - Blocked Air Pump; air lines blocked.   |
| 1248 | 523910 | 9   | 6-9-5      | Burner Control; Air Pump - CAN Lost Air Pump; CAN communication lost.   |
| 1249 | 523910 | 7   | 6-9-5      | Air pump; CAN communication interrupted no purge function available.  |
| 1250 | 523910 | 12  | 6-9-5      | Air Pump; internal error.   |
| 1252 | 523910 | 0   | 6-9-5      | Air Pump; operating voltage error.  |
| 1254 | 524014 | 1   | 8-5-8      | Air inlet EPV - pressure too low.<br>Air pressure glow plug flush line; below limit.                                |
| 1255 | 524013 | 7   | 8-5-7      | Burner Control; Flame lost max.<br>Burner operation is interrupted too often.                                       |
| 1257 | 523915 | 7   | 8-5-3      | HCl dosing valve (DV1); blocked open.   |
| 1258 | 524016 | 11  | 8-5-9      | Burner Control; HFM - Electrical Fault HFM sensor; electrical fault.  |
| 1259 | 524016 | 2   | 8-5-9      | Burner Control; HFM - Plausibilitätsfehler 1 Amount of air is not plausible to pump speed.                          |
| 1261 | 523910 | 6   | 6-9-5      | Burner Control Air Pump; over current Air pump electrically overloaded.   |
| 1262 | 523922 | 7   | 8-5-4      | Burner Control; Shut-off Valve - Blocked closed Burner Shut Off Valve;<br>blocked closed.                           |
| 1263 | 524021 | 11  | 8-6-4      | Burner Control; Fuel line ShutOff downstream - broken Burner fuel line pipe<br>leak behind Shut Off Valve.          |

1513AA-15

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification   |
|------|--------|-----|------------|--|
| 1264 | 523922 | 7   | 8-5-5      | Burner Shut Off Valve; blocked open.   |
| 1285 | 524038 | 9   | 8-2-4      | Timeout error of CAN-Receive-Frame ComMS_Sys1TO (error memory Slave); Master-Slave internal CAN message. |
| 1286 | 524039 | 9   | 8-2-5      | Timeout error of CAN-Receive-Frame ComMS_Sys2TO (error memory Slave); Master-Slave internal CAN message. |
| 1287 | 524040 | 9   | 8-2-6      | Timeout error of CAN-Receive-Frame ComMS_Sys3TO (error memory Slave); Master-Slave internal CAN message. |
| 1288 | 524041 | 9   | 8-2-7      | Timeout error of CAN-Receive-Frame ComMS_Sys4TO (error memory Slave); Master-Slave internal CAN message. |
| 1289 | 524042 | 9   | 8-2-8      | Timeout error of CAN-Receive-Frame ComMS_Sys5TO (error memory Slave); Master-Slave internal CAN message. |
| 1290 | 524043 | 9   | 8-2-9      | Timeout error of CAN-Receive-Frame ComMS_Sys6TO (error memory Slave); Master-Slave internal CAN message. |
| 1291 | 524045 | 9   | 8-3-1      | Master Slave, Error of message counter CAN receive message ComMSMoFOvR; ComMSMoFOvR1CNT.                 |
| 1292 | 524046 | 9   | 8-3-2      | Master-Slave CAN; Error Checksum of CAN-Receive Message.   |
| 1293 | 524047 | 9   | 8-3-3      | Master-Slave CAN; Error of message length of CAN receive message ComMSMoFOvR; _ComMSMoFOvR1DLC.          |
| 1294 | 524048 | 9   | 8-3-4      | Timeout error CAN message ComMSMoFOvR1TO error memory Slave.   |
| 1299 | 523788 | 0   | 6-5-5      | Wastegate plausibility error off CAN transmit message.   |
| 1300 | 523788 | 0   | 6-5-5      | Timeout Error of CAN-Receive-Frame ComTrbChActr; Wastegate.  |
| 1302 | 524024 | 11  | 8-6-6      | Deviation of the exhaust gas temperature setpoint to actual value downstream (DOC) too high.             |
| 1324 | 523995 | 13  | 7-9-5      | Check of missing injector adjustment value programming (IMA) injector 7 (in firing order).               |
| 1325 | 523996 | 13  | 7-9-6      | check of missing injector adjustment value programming (IMA) injector 8 (in firing order).               |
| 1326 | 523997 | 4   | 7-9-7      | Injector cylinder bank 1 slave; short circuit.   |
| 1327 | 523998 | 4   | 7-9-8      | Injector cylinder bank 2 slave; short circuit.   |
| 1328 | 523999 | 12  | 7-9-9      | Injector powerstage output Slave defect.   |
| 1329 | 524000 | 5   | 1-7-7      | Injector 7 (in firing order); interruption of electric connection.                                       |
| 1330 | 524001 | 5   | 1-7-8      | Injector 8 (in firing order); interruption of electric connection.                                       |
| 1333 | 524000 | 3   | 1-7-7      | Injector 7 (in firing order); short circuit.   |
| 1334 | 524001 | 3   | 1-7-8      | Injector 8 (in firing order); short circuit.   |
| 1337 | 2797   | 4   | 5-6-5      | Timeout of Short-Circuit Ground Diagnosis Cyl. Bank 0; _IVDiaShCirGndToutBnk_0.                          |
| 1338 | 2798   | 4   | 5-6-6      | Timeout of Short-Circuit Ground Diagnosis Cyl. Bank 1; _IVDiaShCirGndToutBnk_1.                          |
| 1339 | 2797   | 4   | 5-6-5      | Injector diagnostic; Short circuit to ground cylinder bank 0.  |
| 1340 | 2798   | 4   | 5-6-6      | Injector diagnostic; Short circuit to ground cylinder bank 1.  |

1513AA-16

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification   |
|------|--------|-----|------------|--|
| 1341 | 524035 | 12  | 5-5-5      | Injector diagnostics; time out error in the SPI communication.   |
| 1342 | 524036 | 12  | 5-5-5      | Injector diagnostics Slave; time out error in the SPI communication.   |
| 1345 | 524069 | 9   | 8-9-6      | Timeout Error of CAN-Receive-Frame MSMon_FidFCCTO; Master-Slave CAN communication faulty.                                  |
| 1357 | 524052 | 11  | 8-3-6      | Error memory Slave reports FID MSMonFC2 (collective error).  |
| 1368 | 524052 | 11  | 8-3-6      | Error memory Slave reports FID MSMonFC3 (collective error).  |
| 1378 | 523919 | 2   | 6-9-4      | Sensor air pump airpressure; plausibility error.   |
| 1379 | 523920 | 2   | 7-1-6      | Sensor exhaust gas back pressure burner; plausibility error.   |
| 1380 | 3253   | 2   | 6-9-2      | Sensor differential pressure (DPF); plausibility error.  |
| 1381 | 164    | 2   | 8-3-9      | Rail pressure safety function is not executed correctly ().  |
| 1389 | 523922 | 5   | 7-1-5      | Burner Shut Off Valve; open load.  |
| 1390 | 523922 | 12  | 7-1-5      | Burner Shut Off Valve; powerstage over temperature.  |
| 1392 | 523922 | 4   | 7-1-5      | Burner Shut Off Valve; short circuit to ground.  |
| 1395 | 523921 | 2   | 7-1-4      | Burner temperature sensor; Plausibility Check for burner temperature sensor Sensor burner temperature; plausibility error. |
| 1398 | 1136   | 0   | 6-8-1      | Physical range check high for ECU temperature.   |
| 1402 | 4769   | 2   | 6-8-4      | Sensor exhaust gas temperature OxiCat downstream (normal operation); plausibility error.                                   |
| 1403 | 4769   | 2   | 6-8-4      | Sensor exhaust gas temperature OxiCat downstream (regeneration); plausibility error.                                       |
| 1411 | 1188   | 11  | 8-1-4      | Wastegate actuator; internal error.  |
| 1412 | 1188   | 11  | 8-1-4      | Wastegate actuator; EOL calibration not performed correctly.   |
| 1413 | 1188   | 13  | 8-1-4      | Wastegate actuator calibration deviation too large, recalibration required.  |
| 1414 | 1188   | 2   | 8-1-4      | Wastegate; status message from ECU missing.  |
| 1415 | 1188   | 7   | 8-1-4      | Wastegate actuator; blocked.   |
| 1417 | 1188   | 11  | 8-1-4      | Wastegate actuator; over temperature (> 135°C).  |
| 1418 | 1188   | 11  | 8-1-4      | Wastegate actuator; operating voltage error.   |
| 1423 | 51     | 0   | 5-9-4      | Warning threshold for an internal actuator error exceeded, < 4L EGR. actuator und >4L Air Intake Flap.                     |
| 1424 | 51     | 1   | 5-9-4      | Shut off threshold for an internal actuator error exceeded, < 4L EGR.actuator und >4L Air Intake Flap.                     |
| 1425 | 172    | 0   | 2-2-6      | air temperature within air filter box above maximum physical value.  |
| 1431 | 524028 | 2   | 8-1-5      | CAN message PROEGRActr; plausibility error.  |
| 1432 | 524029 | 2   | 8-1-5      | Timeout Error of CAN-Receive-Frame ComEGRActr - exhaust gas recirculation positioner.                                      |
| 1436 | 524034 | 5   | 8-1-6      | Disc separator; open load.   |
| 1437 | 524034 | 12  | 8-1-6      | Disc separator; powerstage over temperature.   |
| 1438 | 524034 | 3   | 8-1-6      | Disc separator; short circuit to battery.  |

1513AA-17

## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 1439 | 524034 | 4   | 8-1-6      | Disc separator; short circuit to ground.  |
| 1440 | 524030 | 7   | 8-1-5      | EGR actuator; internal error.   |
| 1441 | 524031 | 13  | 8-1-5      | EGR actuator, calibration error.  |
| 1442 | 524032 | 2   | 8-1-5      | EGR actuator; status message "EGRCust" is missing.                              |
| 1443 | 524033 | 7   | 8-1-5      | EGR actuator; due to overload in Save Mode.                                     |
| 1455 | 3711   | 12  | 7-1-1      | Temperature during stand-still main phase too low or too high.                  |
| 1458 | 523960 | 0   | 7-7-1      | High exhaust gas temperature EGR cooler downstream; warning threshold exceeded. |
| 1464 | 0      | 0   | -          |   |
| 1466 | 0      | 0   | -          |   |
| 1467 | 0      | 0   | -          |   |
| 1469 | 0      | 0   | -          |   |
| 1470 | 0      | 0   | -          |   |
| 1471 | 0      | 0   | -          |   |
| 1472 | 0      | 0   | -          |   |
| 1481 | 524025 | 5   | 8-4-5      | DPF system; operating voltage error.  |
| 1482 | 524044 | 9   | 1-8-8      | CAN message ComMS_Sys7 not received from slave.                                 |
| 1484 | 524068 | 2   | 8-9-5      | Master ECU and Slave ECU have been identified as the same types.                |
| 1485 | 524052 | 11  | 8-3-6      | Master ECU and Slave ECU data sets or software are not identical.               |
| 1486 | 523718 | 5   | 6-7-6      | SCR mainrelay; open load (only CV56B).  |
| 1488 | 523718 | 3   | 6-7-6      | SCR mainrelay; short circuit to battery (only CV56B).                           |
| 1489 | 523718 | 4   | 6-7-6      | SCR mainrelay; short circuit to ground (only CV56B).                            |
| 1661 | 524116 | 9   | 1-9-4      | Timeout error of CAN-Transmit-Frame SCR2.                                       |
| 1662 | 524117 | 9   | 9-4-1      | Timeout error of CAN-Transmit-Frame SCR3.                                       |
| 1663 | 524097 | 9   | 9-2-1      | Timeout error of CAN-Transmit-Frame DPFBrnAirPmpCtl.                            |
| 1664 | 524098 | 9   | 9-2-2      | Timeout error of CAN-Transmit-Frame ComDPFBrnPT.                                |
| 1665 | 524099 | 9   | 9-2-3      | Timeout error of CAN-Transmit-Frame ComDPFC1.                                   |
| 1666 | 524100 | 9   | 9-2-4      | Timeout error of CAN-Transmit-Frame ComDPFHisDat.                               |
| 1667 | 524101 | 9   | 9-2-5      | Timeout error of CAN-Transmit-Frame ComDPFTstMon.                               |
| 1668 | 524105 | 9   | 9-2-9      | Timeout error of CAN-Transmit-Frame ComEGRMsFlw (EGR Steller).                  |
| 1669 | 524108 | 9   | 9-3-2      | Timeout error of CAN-Transmit-Frame ComEGRTVActr (EGR actuator).                |
| 1670 | 524110 | 9   | 9-3-4      | Timeout error of CAN-Transmit-Frame ComETVActrTO.                               |
| 1671 | 524112 | 9   | 9-3-6      | Timeout ComIntake Throttle Valve Actr.  |
| 1672 | 524118 | 9   | 9-4-2      | Timeout error of CAN-Receive-Frame ComRxCM1.                                    |
| 1675 | 524103 | 9   | 9-2-7      | Timeout error of CAN-Receive-Frame ComRxDPFBrnAirPmp.                           |
| 1676 | 524104 | 9   | 9-2-8      | Timeout error of CAN-Receive-Frame ComRxDPFCtl.                                 |

1513AA-18



## 5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification  |
|------|--------|-----|------------|---|
| 1677 | 524106 | 9   | 1-9-5      | Timeout error of CAN-Receive-Frame ComRxEGRMsFlw1 (EGR actuator)        |
| 1678 | 524107 | 9   | 9-3-1      | Timeout error of CAN-Receive-Frame ComRxEGRMsFlw2 (EGR actuator).       |
| 1679 | 524109 | 9   | 9-3-3      | Timeout error of CAN-Receive-Frame ComRxEGRTVActr (EGR actuator).       |
| 1680 | 524111 | 9   | 9-3-5      | Timeout error of CAN-Receive-Frame ComRxETVActr.                        |
| 1681 | 524113 | 9   | 9-3-7      | Timeout error of CAN-Receive-Frame ComRxITVActr.                        |
| 1682 | 524120 | 9   | 9-4-4      | Timeout error of CAN-Receive-Frame ComRxSCRHtDiag.                      |
| 1683 | 524121 | 9   | 9-4-5      | Timeout error of CAN-Receive-Frame ComRxTrbChActr (wastegate actuator). |
| 1684 | 524122 | 9   | 9-4-6      | Timeout error of CAN-Receive-Frame ComRxUQSens (Urea quality).          |
| 1685 | 524123 | 9   | 9-4-7      | Timeout error of CAN-Receive-Frame ComSCRHtCtl.                         |
| 1686 | 524124 | 9   | 9-4-8      | Timeout error of CAN-Receive-Frame ComTxAT1IMG.                         |
| 1687 | 524125 | 9   | 9-4-9      | Timeout error of CAN-Receive-Frame ComTxTrbChActr (Wastegate actuator). |
| 1698 | 524133 | 2   | 9-5-6      | HMI system; set if restore button blocked.                              |
| 1699 | 524134 | 0   | 9-5-7      | DPF, ash load exceeds the shutoff threshold.                            |
| 1700 | 524134 | 0   | 9-5-7      | DPF, ash load exceeds the warning threshold.                            |
| 1701 | 524135 | 0   | 9-5-8      | DPF, soot load exceeds the shutoff threshold.                           |
| 1702 | 524135 | 14  | 9-5-8      | DPF, soot load exceeds the service request threshold.                   |
| 1703 | 524135 | 0   | 9-5-8      | DPF, soot load exceeds the warning threshold.                           |
| 1705 | 524156 | 9   | 9-7-2      | Timeout error of CAN-Receive-Frame ComRxEBC2.                           |
| 1706 | 524157 | 9   | 9-7-3      | Fan control; time out for fan governing.                                |
| 1708 | 524159 | 0   | 9-7-5      | Fan; short circuit battery or open load.                                |
| 1709 | 524159 | 1   | 9-7-5      | Fan; short circuit ground.  |
| 1710 | 524160 | 5   | 9-7-6      | Fan; in/outlet valve 1; open load.                                      |
| 1712 | 524160 | 3   | 9-7-6      | Fan; in/outlet valve 1; short circuit battery.                          |
| 1713 | 524160 | 4   | 9-7-6      | Fan; in/outlet valve 1; open load ground.                               |
| 1714 | 524161 | 5   | 9-7-7      | Fan; in/outlet valve 2; open load.                                      |
| 1716 | 524161 | 3   | 9-7-7      | Fan; in/outlet valve 2; short circuit battery.                          |
| 1717 | 524161 | 4   | 9-7-7      | Fan; in/outlet valve 2; open load ground.                               |
| 1718 | 524162 | 12  | 9-7-8      | Fan; fancontrol; angle sensor defect.                                   |
| 1719 | 524163 | 12  | 9-7-9      | Fan; fancontrol; fan or valve defect.                                   |
| 1752 | 2791   | 7   | 4-1-5      | EGR actuator, actuator blocked.   |
| 1753 | 2791   | 2   | 4-1-5      | EGR actuator, CAN error.  |
| 1754 | 2791   | 13  | 4-1-5      | EGR actuator, EOL calibration error.                                    |
| 1755 | 2791   | 12  | 4-1-5      | EGR Actuator, internal electrical fault.                                |
| 1756 | 2791   | 13  | 4-1-5      | EGR actuator, learning process aborted.                                 |
| 1757 | 2791   | 6   | 4-1-5      | EGR actuator current is above maximum threshold.                        |
| 1758 | 2791   | 3   | 4-1-5      | EGR actuator supply voltage is above the maximum threshold.             |

1513AA-19

5.6-6 Deutz TD2.9L Fault Codes

| Code | SPN    | FMI | Blink Code | Error Identification   |
|------|--------|-----|------------|--|
| 1759 | 2791   | 4   | 4-1-5      | EGR actuator supply voltage is below minimum threshold.          |
| 1760 | 2791   | 13  | 4-1-5      | EGR actuator, learning process out of range.                     |
| 1761 | 2791   | 7   | 4-1-5      | EGR actuator, broken spring detected.                            |
| 1762 | 2791   | 16  | 4-1-5      | EGR actuator, temperature high.                                  |
| 1763 | 2791   | 0   | 4-1-5      | EGR actuator, temperature critical high.                         |
| 1788 | 1188   | 7   | 8-1-4      | Turbocharger wastegate, mechanical blocking detected.            |
| 1789 | 1188   | 2   | 8-1-4      | Turbocharger wastegate, CAN Error.                               |
| 1790 | 1188   | 13  | 8-1-4      | Turbocharger wastegate, EOL calibration error.                   |
| 1791 | 1188   | 12  | 8-1-4      | Turbocharger wastegate, internal electrical error.               |
| 1792 | 1188   | 13  | 8-1-4      | Turbocharger wastegate, learning process aborted.                |
| 1793 | 1188   | 6   | 8-1-4      | Turbocharger wastegate, current above maximum threshold.         |
| 1794 | 1188   | 3   | 8-1-4      | Turbocharger wastegate, supply voltage above maximum threshold.  |
| 1795 | 1188   | 4   | 8-1-4      | Turbocharger wastegate, supply voltage below minimum threshold.  |
| 1796 | 1188   | 13  | 8-1-4      | Turbocharger wastegate, learning process out of range.           |
| 1797 | 1188   | 7   | 8-1-4      | Turbocharger wastegate, broken spring detected.                  |
| 1799 | 1188   | 0   | 8-1-4      | Turbocharger wastegate, temperature critical high.               |
| 1827 | 524141 | 7   | 1-9-2      | DEF dosing valve, dosing valve blocked.                          |
| 1857 | 523612 | 12  | 5-5-5      | Engine starter, plausibility error of starter release condition. |
| 1858 | 524147 | 7   | 9-6-6      | SCR-System, reverting valve blocked.                             |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |
|      |        |     |            |  |



1513AA-20

### 5.6-7 Diesel Particulate Filter (DPF) and Standstill Regeneration - Deutz TCD2.2 Engine




#### About the DPF and Standstill Regeneration

The DPF system is a closed diesel particulate filter system that collects the soot during the operation of the engine to decrease diesel particulate emissions.





As soon as the soot load is at 100%, the system starts a standstill regeneration request. The request is sent and shown ① on the screen of the Deutz engine display module ② (found below the engine control console) and identified by the flashing standstill lights on the base ③ and platform ④ controls.



### Standstill Regeneration Stages


| Standstill Lamps  3 4 | Engine Lamp  5 | Audible Alarm  6 | Engine Torque | Action Required  |
|--|---|---|---------------|--|
| Flashes slowly   | Off   | Pulsates slowly   | 100%          | Do the standstill operation at the next available opportunity, within 3 to 4 hours.  |
| Flashes slowly   | On  | Pulsates slowly   | 75%           | Do the standstill operation immediately.   |
| Flashes quickly  | Flashes   | Pulsates quickly  | 40%           | a. The standstill operation is no longer possible with on-machine controls. Contact an authorized repair facility.   |
|  |   |   |               | b. Failure to do the standstill has caused diesel particulate filter failure, and regeneration is no longer possible. Contact an authorized repair facility to replace the filter. |

### Do the Standstill Regeneration

1. Move the MEWP to an open, well-ventilated area, away from any flammable material. Park it on a firm level surface, and fully stow the MEWP.
2. While the engine runs, turn the off/base/platform switch  7 on the base controls to the base position.
3. Move the standstill switch  8 on the base controls to the right to start the standstill regeneration. The base functions will not operate while the standstill switch is turned on.
4. On the engine display module  2 press and hold the middle button  9 (below the regeneration symbol) for 7 seconds.




### WARNING

Do not touch hot engine components. Serious injury can occur if you touch hot surfaces.


5. The engine display module changes to the Regeneration Ongoing symbol  10, the standstill lights illuminate continuously, and the engine speed can change.
6. Standstill regeneration takes approximately 45 minutes. During this time you must not use the MEWP.

### IMPORTANT

Complete the standstill regeneration fully. If you interrupt the process, the standstill request continues.

7. When the standstill regeneration is complete, the Regeneration Ongoing symbol changes to Regeneration Complete  11, the standstill lights  3  4 go off, and the engine speed goes back to normal.
8. Move the standstill switch to the left. You can use the MEWP normally.

### IMPORTANT

Only use the standstill regeneration override switch  12 on the front of the platform control box when absolutely necessary to move the MEWP to park it in a safe location when the derated engine torque/rpm prevents sufficient torque to drive the MEWP.

It temporarily (for approximately 30 minutes) restores full engine power and speed.

Use of the derate override switch can cause diesel particulate filter failure.



## 5.7 Hydraulic Tank

Maintaining the hydraulic components and hydraulic oil at the proper level are essential to good performance and service life of the aerial platform.

### 5.7-1 Change the Hydraulic Tank Filter

1. Place a suitable container under the hydraulic tank filter.
2. Remove the oil filter and catch any escaping oil.

#### **WARNING**

**Dispose of hydraulic oil in accordance with local and federal regulations.**

3. Clean inside the filter head.
4. Apply a thin layer of clean hydraulic oil to the new oil filter gasket.
5. Install the filter and tighten it firmly.
6. Clean up any oil that may have spilled during this procedure.
7. Start the engine from the base control console.
8. Check for leakage.

### 5.7-2 Change the Hydraulic Oil

1. Turn the engine on and allow hydraulic oil to warm up.
2. Shut the engine off.
3. Place a suitable container under the hydraulic tank drain port.
4. Remove the oil drain plug and allow all of the hydraulic oil to drain into the container.

#### **WARNING**

**Dispose of hydraulic oil in accordance with local and federal regulations.**

5. Install the oil drain plug with new seal ring and tighten it firmly.
6. Refill the hydraulic tank with new oil as per the specifications (refer to [2.10 Hydraulic Specifications & Gear Oil](#)).
7. Check for leakage.
8. Clean up any oil that may have spilled during this procedure.
9. Check the hydraulic oil level on the sight gauge. The oil level should be at or slightly above the top mark on the sight gauge.

#### **NOTE**


*Samples of hydraulic oil should be drawn from the reservoir and tested annually. These samples should be taken when the oil is warmed through normal operation of the system. The sample should be analyzed by a qualified lubrication specialist to determine if it is suitable for continued use. Oil change intervals will depend on the care used in keeping the oil clean, and the operating conditions. Dirt and/or moisture contamination will dictate that the oil should be changed more often. Under normal use and operating conditions, the hydraulic oil should be changed every two years.*

## 5.8 Manifolds and Hydraulic Pumps

### 5.8-1 Hydraulic Brake Pressure Adjustment

Maintaining accurate hydraulic brake pressure is important when it comes to safe aerial platform operation.

1. Locate the pressure gauge **1** on the brake valve assembly.



#### IMPORTANT

Failure to remove the wiring may cause damage to components downstream.

2. Remove the wiring from two valves: axle lockout valve **2** wires 65 and 02, and two speed valve **3** wires 45 and 02. Mark the valves to ensure you put the wiring back in the correct positions later.


#### IMPORTANT

Valve damage will occur if tightened too much.

3. Locate the brake system pressure reducing valve PR1 **4**. Loosen the lock nut and turn the adjustment stem gently clockwise 2 full turns.
4. Start the engine from the platform control console and extend the boom slightly (approximately 12" (30 cm)) to achieve low speed drive.
5. Drive the MEWP forward or reverse. The pressure gauge reading should be 400 psi. Stop the aerial platform. Follow the next steps for adjusting the relief valve pressure if needed. If no adjustment is required, skip ahead to step 10.
6. Locate the brake system pressure reducing valve PR1 and turn the valve gently counterclockwise to the initial position.
7. Drive the MEWP forward or reverse. The pressure gauge reading should be 400 psi.
8. Stop the MEWP and adjust the pressure reducing valve PR1 1/4 turn at a time by turning it either clockwise to increase the pressure, or counterclockwise to decrease the pressure.
9. Repeat steps 7 and 8 until the brake pressure is achieved (400 psi) then tighten the lock nut on the brake system pressure reducing valve PR1.
10. Reinstall the wiring in the same positions it was removed from in step 3.
11. Test the brake and two speed functions.

## 5.8-2 Hydraulic Standby Pressure Adjustment


1. Locate the GP2 port **1** on either the top or bottom of the main manifold and remove the cap.



**Main Manifold and Pressure Gauge**

2. Connect a pressure gauge (600 psi) to the GP2 port.
3. Start the engine from the base control console and let it run for 2-5 minutes.
4. Check the reading on the gauge (standard pressure should be 330 psi) and follow the next steps for adjusting pressure if needed.


5. Locate the load sense compensator **2** on the system pump.



6. Loosen the lock nut.
7. Adjust the load sensing pressure by turning the adjusting stem either clockwise to increase pressure or counterclockwise to decrease pressure.
8. Tighten the lock nut after pressure is set to 330 psi.
9. Turn the engine off.
10. Remove the pressure gauge from the GP2 port and cap the port.

### 5.8-3 Hydraulic High Pressure Adjustment

1. Locate GP2 port ① on the main manifold and remove the cap.



**Main Manifold and Pressure Gauge**


2. Connect a pressure gauge (5000 psi) to the GP2 port.

#### **WARNING**

To protect the gauge, do not activate any controls during this procedure.

3. Start the engine from the base control console and let it run for 2-5 minutes.
4. Without driving, steer fully to one direction and then check the reading on the gauge. Standard pressure should be 3050 psi. Follow the next steps for adjusting the pressure, if needed.

5. Locate the pressure compensator ② on the system pump.




6. Loosen the lock nut.
7. Adjust the system pump pressure by turning the adjusting stem either clockwise to increase pressure or counterclockwise to decrease pressure.
8. Tighten the lock nut after pressure is set to 3050 psi.
9. Turn the engine off.
10. Remove the pressure gauge from the GP2 port and cap the port.



### 5.8-4 Hydraulic System Relief Valve Adjustment

To adjust the system relief valve (RV1), you are required to temporarily adjust the high pressure setting on the system pump to 3300 psi. Refer to [5.8-3 Hydraulic High Pressure Adjustment](#).


1. Locate the GP2 port **1** on the main manifold and remove the cap.



**Main Manifold and Pressure Gauge**

2. Connect a pressure gauge (5000 psi) to the GP2 port.
3. Start the engine from the base control console and let it run for 2-5 minutes.
4. Steer fully to one direction and then check the reading on the gauge. Standard pressure should be 3250 psi. Follow the next steps for adjusting pressure if needed.

5. Locate the system relief valve (RV1) **2**.




**Main Manifold**

6. Loosen the lock nut on the system relief valve. Turn the adjusting stem clockwise to increase pressure and counterclockwise to decrease pressure.
7. Tighten the lock nut on the system relief valve once 3250 psi is observed on the gauge. You must steer fully in one direction to activate pressure reading on gauge.
8. Reset the system pump to 3050 psi. Refer to [5.8-3 Hydraulic High Pressure Adjustment](#).

### 5.8-5 Turret Rotate Relief Valve Adjustment

1. Locate the GP2 port ① on the main manifold.
2. Connect a pressure gauge (5000 psi) to the GP2 port.




Main Manifold

3. Start the engine from the base control console and let it run for 2-5 minutes.
4. Raise the main boom to ensure the basket will not contact the ground.
5. Engage the turret transport lock.
6. Attempt to rotate the turret. The pressure should be 1250 psi. Follow the next steps for adjusting the pressure, if needed.
7. Locate the turret rotate relief valve RV2 ②.
8. Loosen the lock nut on the turret rotate relief valve RV2. Turn the adjusting stem clockwise to increase the pressure and counterclockwise to decrease the pressure.
9. Tighten the lock nut on the turret rotate relief valve RV2 once 1250 psi is observed on the gauge. You must activate the turret rotate to obtain a pressure reading on the gauge.
10. Disengage the turret transport lock.

### 5.8-6 Platform Level Relief Valve Adjustment

1. Locate the GP2 port ① on the main manifold.
2. Connect a pressure gauge (5000 psi) to the GP2 port.




Main Manifold

3. Start the engine from the base control console and let it run for 2-5 minutes.
4. Raise the main boom to ensure the basket will not contact the ground.
5. Fully raise or lower the platform level and check the reading on the gauge. The pressure should be 3000 psi. Follow the next steps for adjusting the pressure, if needed.
6. Locate the platform leveling relief valve RV3 ②.
7. Loosen the lock nut on the platform level relief valve RV3. Turn the adjusting stem clockwise to increase the pressure and counterclockwise to decrease the pressure.
8. Tighten the lock nut on the platform level relief valve RV3 once 3000 psi is observed on the gauge. You must fully raise or lower the platform level to activate a pressure reading on the gauge.

### 5.8-7 Fly Boom Relief Valve Adjustment

1. Locate the GP2 port ① on the main manifold and remove the cap.




**Main Manifold**

2. Connect a pressure gauge (5000 psi) to the GP2 port.
3. Start the engine from the base control console and let it run for 2-5 minutes.
4. Fully extend the boom and check the reading on the gauge. The pressure should be 1500 psi. Follow the next steps for adjusting the pressure, if needed.
5. Locate the fly boom relief valve RV4 ②.
6. Loosen the lock nut on the fly boom relief valve RV4. Turn the adjusting stem clockwise to increase the pressure and counterclockwise to decrease the pressure.
7. Tighten the lock nut on the fly boom relief valve RV4 once 1500 psi is observed on the gauge. You must fully extend the boom to activate a pressure reading on the gauge.

### 5.8-8 Test Charge Pump Pressure on Drive Pump

1. Locate test port TP3 ① on the drive pump.
2. Connect a pressure gauge (600 psi) to the test port.



**Drive Pump - TP3**

3. Start the engine from the base control console.

#### **⚠ WARNING**


**To protect the gauge, do not activate any controls during this procedure.**


4. Check the reading on the gauge. Standard pressure should be 313 ±31 psi.
5. Replace the charge pump relief valve RV10 ② if the standard pressure is not achieved.
6. Repeat steps 2, 3, and 4 after the charge pump relief valve is replaced.
7. If the pressure is still not in range, repair or replace the pump as necessary.

### 5.8-9 Test Forward Drive Pressure on Drive Pump

#### NOTE

Make sure the charge pump pressure test is completed first.

1. Locate test port TP1  on the drive pump.
2. Connect a pressure gauge (10000 psi) to test port TP1.



Drive Pump - TP1

3. Start the engine from the platform control console.
4. Unplug the brake solenoid power cable (26) on the brake valve.
5. Activate the drive function slowly forward with the engine at high speed. The wheels should not turn.

#### NOTE

Activating the drive function too quickly will stall the engine.


6. Check the reading on the gauge. The standard pressure should be 5000 psi.
7. Replace the pump if the pressure is not achieved.
8. Turn the engine off.
9. Remove the pressure gauge from the port, cap the port, and re-plug the brake solenoid power cable.

### 5.8-10 Test Reverse Drive Pressure on Drive Pump

#### NOTE

Make sure the charge pump pressure test is completed first.

1. Locate test port TP2  on the drive pump.



Drive Pump - TP2

Connect a pressure gauge (10000 psi) to test port TP2.

#### WARNING

To protect the gauge, do not activate any controls during this procedure.

2. Start the engine from the platform control console.
3. Unplug the brake solenoid power cable (26) on the brake valve.
4. Activate the drive function slowly in reverse with the engine at high speed. The wheels should not turn.

#### NOTE

Activating the drive function too quickly will stall the engine.



5. Check the reading on the gauge. The standard pressure should be 5000 psi.
6. Replace the pump if the pressure is not achieved.
7. Turn the engine off.



## 5.9 Axles

### 5.9-1 Change the Oil in the Axles

1. Place a suitable container under the axle.
2. Remove the fill plug.
3. Remove all three drain plugs to allow the oil to drain into the container.



4. Reinstall all of the drain plugs.
5. Remove the check plug.




#### NOTE

The axle is full when oil is leaking from the check port.

6. Refill the axle with new oil as per specifications Refer to [2.10 Hydraulic Specifications & Gear Oil](#).
7. Reinstall both of the fill and check plugs.


### 5.9-2 Check the Oil Level in the Torque Hubs

1. Drive the aerial platform to rotate the hub until the plug is in the 3 or 9 o'clock position. Shut off the engine.
2. Remove the plug and check the oil level. The oil level should be even with the bottom of the plug hole. Add oil if needed. Refer to [2.10 Hydraulic Specifications & Gear Oil](#) for oil specifications.




### 5.9-3 Change the Oil in the Torque Hubs

1. Start the engine and drive the boom until the fill/drain port of one of the hubs is in the 6 o'clock position. Shut off the engine. Place a container under the fill/drain port.
2. Remove the plug and allow all of the oil to drain, watching carefully to avoid spills.
3. Restart the engine and drive the boom until the drain plug is in the 3 or 9 o'clock position. Shut off the engine.
4. Refill the hub with new oil as per specifications. Refer to [2.10 Hydraulic Specifications & Gear Oil](#).
5. Repeat the above steps with the other three wheel hubs.




### 5.9-4 Check the Oil Level in the Axle Gearbox

1. Remove the fill plug ❶ from the gear box.
2. Check the oil level. It should be even with the bottom of the fill plug hole. Add oil if needed. Refer to [2.10 Hydraulic Specifications & Gear Oil](#) for oil specifications.



### 5.9-5 Change the Oil in the Axle Gearbox

1. Place a suitable container under the gearbox.
2. Remove the fill plug.
3. Remove the drain plug to allow oil to drain into the container.



4. Reinstall the drain plug.




#### NOTE

The gearbox is full when oil is leaking from the check port.


5. Refill the gearbox with new oil as per specifications. Refer to [2.10 Hydraulic Specifications & Gear Oil](#).
6. Reinstall the fill plug.

### 5.9-6 Brake Inspection


1. Remove the oil level plug from one of the braking axle arms, as shown below.



2. Insert a 4.5 mm (front steer axle) or 5.2 mm (rear rigid axle) feeler gauge into the drain port.



3. Use the gauge to check the gap between the disks (A). The minimum distance allowed is 4.5 mm (front) or 5.2 mm (rear). Reinstall the oil level plug.




4. Repeat the inspection on the other axle arm. If the gap is smaller than 4.5 mm (front) or 5.2 mm (rear) between the disks of either arm (i.e. the gauge doesn't fit), the brake disks must be replaced on both arms.
5. Repeat the procedure on the opposite axle.

### 5.9-7 Oscillating Cylinder Bolt Replacement

If upon inspection it is determined that the oscillating cylinder bolts have missing or damaged torque seal, the affected bolts must be replaced. If replacing more than one bolt, do so one at a time to prevent the cylinder from shifting.

1. Remove the affected bolt.
2. Clean the cylinder's corresponding internal threaded hole thoroughly.
3. Replace the removed bolt with a new 0.5"-13 x 1.75" grade 8 bolt, applying liquid blue Loctite 242 or 243 to the bottom half of the bolts.
4. Hand tighten the bolt.
5. Torque the new bolt to 80 ft-lbs.
6. Apply a line of torque seal to each new bolt extending from the bolt head over the washer and to the chassis wall.




## 5.9-8 Oscillating Cylinder Replacement


### **CAUTION**

The oscillating axle cylinder weighs approximately 43 lbs (19.5 kg), so a second person to assist with the removal and replacement would be helpful.

1. Wedge a block of wood between the front axle and the chassis, to prevent the axle from oscillating during the procedure.




2. Remove and set aside the base cover from the oscillating axle end of the chassis.




With a rag in hand to catch any leaking oil, slowly loosen the bleeder screw to release any trapped air within the cylinder, then tighten it again. Slowly loosen the oscillating axle cylinder hoses to release the pressure, then disconnect them fully, being sure to plug the hose ends.

3. Remove and set aside the cylinder fittings, ensuring they stay clean.




4. Remove and throw away the bolts and washers securing the cylinder to the chassis. Lift the cylinder away.
5. Lift a new cylinder into place and install new bolts (0.5"-13 x 1.75" grade 8) and 0.50" hardened washers, applying liquid blue Loctite 242 or 243 to the lower half of the bolts before installing them. Hand tighten the bolts.






- Adjust the oscillating cylinder position until there is continuous contact between the cylinder mounting surface and the mounting plate, and between the mounting plate and the cylinder shoulder, with no gaps. Torque the bolts to 80 ft-lbs [108 Nm].



- Apply a line of torque seal to each bolt extending from the bolt head over the washer and to the chassis wall.



- Reinstall the cylinder fittings, torquing the larger one to 24 ft-lbs [33 Nm] and the smaller one to 15 ft-lbs [20 Nm].
- Remove the plugs and reconnect the hoses to the cylinder fittings, torquing the larger hose end to 21 ft-lbs [28 Nm] and the smaller hose end to 12 ft-lbs [16 Nm].
- Reinstall the base cover and remove the block of wood.
- Turn the engine on and let it run for a few minutes to pressurize the cylinder, then turn it off again.
- Check the oil level using the hydraulic tank sight gauge. Add more hydraulic oil if needed.
- Bleed the cylinder (refer to the next procedure).

### 5.9-9 Bleed the Oscillating Axle Cylinders


If the axle oscillation system is not operating properly, the stability of the aerial platform is compromised and it may tip over.


Items you will need before starting:


- oil container
- hose (to reach from bleeders to bucket)


- Locate a bleeder on either side of the oscillating axle cylinder.
- Connect a hose to the bleeder nipple.
- Start the engine and slowly open the bleeder to allow the oil to flow in a continuous stream.
- Close the bleeder.
- Repeat the procedure with the other oscillating axle cylinder.

### 5.9-10 Test the Oscillating Axle Cylinders

1. Extend  the fly boom 1 ft (30) cm while on a firm, level surface.
  - **Result:** The steer axle should be locked.
2. Drive one of the steer tires up onto a 6" (15 cm) block or curb.
  - **Result:** An appropriate tilt of the MEWP chassis should occur.



3. Retract  the fly boom while in tilt position.
  - **Result:** The steer axles should unlock and the MEWP chassis should level itself to the ground.



## 5.10 Grease Points


Maintaining proper lubrication is essential for good performance and service life of the MEWP. If the bearing and gear of the MEWP are improperly greased, it could result in component damage.

### 5.10-1 Grease the Turret Ring Gear

1. Open the control side cowling, and locate the turret ring gear grease fitting beside the hydraulic tank.
2. Pump grease into the fitting, and continue pumping until new lube appears continuously around the grease seal lip of the ring gear.
3. Rotate the turret in increments of 4 to 5 inches (10 to 13 cm) at a time, and repeat step 2 until the entire bearing has been greased.

### 5.10-2 Grease the Turret Swing Drive

1. Apply open gear lube to each tooth of the swing drive gear, located under the turret.




### 5.10-3 Grease the Axles

1. Open the axle cover plates and locate the grease fittings.
2. Pump grease into the grease fittings.

### 5.10-4 Grease the Drive Shaft

1. Locate the grease fittings on the drive shaft u-joints, and pump grease into the fittings.





**TO PURCHASE THIS PRODUCT PLEASE CONTACT US**



**Equipment Financing and  
Extended Warranties Available**



**Discount-Equipment.com is your online resource for  
commercial and industrial quality parts and equipment sales.**

**561-964-4949**

**visit us on line @ [www.discount-equipment.com](http://www.discount-equipment.com)**

Select an option below to find your Equipment

**Search by Manufacturer**

**Search by Product Type**

**Request a Quote**

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar



[www.Discount-Equipment.com](http://www.Discount-Equipment.com)

To order go to [Discount-Equipment.com](http://Discount-Equipment.com)

**SKYJACK**<sup>™</sup>