

MAINTENANCE CHECKLIST

Made in America Since 1968

5000DL



Check cutting head for signs of wear, cracks, or other
damage. Replace if necessary.
Clean out dust and debris from motor cover/housing.
Check for misaligned, binding of moving parts,
broken parts and any other conditions that may affect
operation.
All maintenance, nameplates and safety stickers must
be in place and legible. Replace if necessary.
Make sure the operator's manual is with the machine.
Charge the 5000DL
1. Plug in the charger using the provided extension cord.
2. Charger will self test.

Confirm there is a flashing amber light indicating the charger is plugged into the proper voltage.

4. Confirm on of the amber "Current Output" lights is solid, indicating the charger is operating properly.

Before conducting any maintenance procedures, make sure you are wearing proper safety equipment and the machine is disconnected from power.

*Refer to Service Manual for precise schedule

WEEKLY RECOMMENDED MAINTENANCE
Read the manual before operating.
Check to ensure the 7 foot, 12 gauge charging cord is
with the machine and in good working condition.
Verify the 70 amp circuit breaker is working and in the
"On" position.
Verify 48-volt blue plugs are firmly connected.
Ensure the seat is securely fastened to the machine.
The seat has a safety switch. The operator must be
properly seated for the machine to run.
Sit on the machine. Release the E-stop. Push the green "ON" button to start the machine.
When the unit is powered on, push the two control
levers forward and the 5000DL will move forward. Pull
the two control levers backwards to move the machine
in reverse. Make sure the control levers return freely to the center position when not engaged.
Push the E-stop button to ensure the machine stops running. Then twist the button to the "up" position to
ensure it releases properly.
Check that the backup beeper is working.
Check hydraulic fluid level.
Remove filler plug located in front of right, rear tire.
Hydraulic fluid should be visible 1" below hole.
Reinsert filler plug.
Keep fittings and hoses tight. If a leak is noticeable,
re-tighten fitting. If leakage persists, remove the connection and inspect. Caution: Never check for
hydraulic leaks while machine is running.
Remove any glue, mastic and debris from the wheels,
debris deflector, and cutting head.
Keep swivel caster and drive wheels clean and free
of debris. Make sure they can move freely.
Ensure there are no carpet strings wound between
the wheels and drive motors, as this can damage
the seals and cause malfunctions. Clean as needed
and inspect before each use.

Check rear wheels for damage and excessive wear.



TO PURCHASE THIS PRODUCT PLEASE CONTACT US



Equipment Financing and Extended Warranties Available



Discount-Equipment.com is your online resource for commercial and industrial quality parts and equipment sales. 561-964-4949
visit us on line @ www.discount-equipment.com

Select an option below to find your Equipment

Search by Manufacturer

Search by Product Type

Request a Quote

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar