

# OPERATION MANUAL



**WHISPERWATT™ SERIES**  
**MODEL DCA70SSIU4F**  
**60Hz GENERATOR**  
**DEEP SEA CONTROLLER**  
**DSE8610 MKII-U2**  
**(ISUZU BR-4JJ1X DIESEL ENGINE)**

Revision #0 (08/11/22)



THIS MANUAL MUST ACCOMPANY THE EQUIPMENT AT ALL TIMES.

**TO PURCHASE THIS PRODUCT PLEASE CONTACT US**



**Equipment Financing and  
Extended Warranties Available**



**Discount-Equipment.com is your online resource for  
commercial and industrial quality parts and equipment sales.**

**561-964-4949**

**visit us on line @ [www.discount-equipment.com](http://www.discount-equipment.com)**

Select an option below to find your Equipment

**Search by Manufacturer**

**Search by Product Type**

**Request a Quote**

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar

## PROPOSITION 65 WARNING

---



## DCA70SSIU4F DSE8610 MKII Controller 60 Hz Generator

Proposition 65 Warning .....	2
Safety Decals .....	4
Safety Information .....	5–10
Specifications .....	11
Dimensions.....	12
Installation .....	14–15
General Information.....	16
Major Components .....	17
Control Panel.....	18
DSE8610 MKII-U2 Controller .....	20–21
Output Terminal Panel Familiarization .....	22–24
Load Application .....	25
Generator Outputs.....	26
Output Terminal Panel Connections .....	27–28
Inspection/Setup.....	29–34
Generator Start-Up Procedure (Manual) .....	35–40
Generator Start-Up Procedure (Auto Mode).....	41
Generator Shutdown Procedure.....	42
Generator Start-Up Procedure (Parallel Ops.) .	43–47
Maintenance .....	48–62
Troubleshooting (Generator).....	63
Troubleshooting (Engine).....	64–65
Generator Wiring Diagram (EE62815).....	66
Engine Wiring Diagram (EE62814).....	67
Battery Charger Wiring Diagram .....	68

### NOTICE

Specifications are subject to change without notice.

## SAFETY DECALS

Safety decals are attached to the generator as shown in Figure 1. Keep these safety decals clean at all times. When the safety decals become worn or damaged, contact Discount-equipment.

### NOTICE

For safety decal part numbers, refer to the DCA70SSIU4F Aggreko parts manual.




Figure 1. Safety Decals

## SAFETY INFORMATION

Do not operate or service the generator before reading the entire manual. Safety precautions should be followed at all times when operating this generator. Failure to read and understand the safety messages and operating instructions could result in injury to yourself and others.

### SAFETY MESSAGES

The four safety messages shown below will inform you about potential hazards that could injure you or others. The safety messages specifically address the level of exposure to the operator and are preceded by one of four words: **DANGER**, **WARNING**, **CAUTION** or **NOTICE**.

### SAFETY SYMBOLS

**⚠ DANGER**

Indicates a hazardous situation which, if not avoided, **WILL** result in **DEATH** or **SERIOUS INJURY**.

**⚠ WARNING**

Indicates a hazardous situation which, if not avoided, **COULD** result in **DEATH** or **SERIOUS INJURY**.








**⚠ CAUTION**

Indicates a hazardous situation which, if not avoided, **COULD** result in **MINOR** or **MODERATE INJURY**.

**NOTICE**

Addresses practices not related to personal injury.

Potential hazards associated with the operation of this generator will be referenced with hazard symbols which may appear throughout this manual in conjunction with safety messages.

Symbol	Safety Hazard
	Lethal exhaust gas hazards
	Explosive fuel hazards
	Burn hazards
	Overspeed hazards
	Rotating parts hazards
	Pressurized fluid hazards
	Electric shock hazards

# SAFETY INFORMATION

## GENERAL SAFETY

### ⚠ CAUTION

- **NEVER** operate this generator without proper protective clothing, shatterproof glasses, respiratory protection, hearing protection, steel-toed boots and other protective devices required by the job or city and state regulations.



- **NEVER** operate this generator when not feeling well due to fatigue or illness, or when on medication.
- **NEVER** operate this generator under the influence of drugs or alcohol.




- **ALWAYS** check the generator for loosened threads or bolts before starting.
- **NEVER** use the generator for any purpose other than its intended purposes or applications.

### NOTICE

- This generator should only be operated by trained and qualified personnel 18 years of age and older.
- Whenever necessary, replace nameplate, operation and safety decals when they become difficult to read.
- Manufacturer does not assume responsibility for any accident due to equipment modifications. Unauthorized modification of the generator will void all warranties.
- **NEVER** use accessories or attachments that are not recommended by MQ Power for this generator. Damage to the generator and/or injury to the user may result.
- **ALWAYS** know the location of the nearest fire extinguisher.
- **ALWAYS** know the location of the nearest first aid kit.



- **ALWAYS** know the location of the nearest phone or **keep a phone on the job site**. Also, know the phone numbers of the nearest **ambulance**, **doctor**, and **fire department**. This information will be invaluable in the case of an emergency.



## GENERATOR SAFETY

### ⚠ DANGER

- **NEVER** operate the generator in an explosive atmosphere or near combustible materials. An explosion or fire could result causing **severe bodily harm or even death**.



### ⚠ WARNING

- **NEVER** disconnect any **emergency or safety devices**. These devices are intended for operator safety. Disconnection of these devices can cause **severe injury, bodily harm or even death**. Disconnection of any of these devices will void all warranties.

### ⚠ CAUTION

- **NEVER** lubricate components or attempt service on a **running** generator.

### NOTICE

- **ALWAYS** ensure the generator is on level ground before use.
- **ALWAYS** keep the generator in proper running condition.
- Fix damage to the generator and replace any broken parts immediately.
- **ALWAYS** store the generator properly when it is not being used. The generator should be stored in a clean, dry location out of the reach of children and unauthorized personnel.



# SAFETY INFORMATION

## ENGINE SAFETY

### DANGER

- The engine fuel exhaust gases contain poisonous carbon monoxide. This gas is colorless and odorless, and can cause **death** if inhaled.

- The engine of this generator requires an adequate, free flow of cooling air. **NEVER** operate this equipment in any enclosed or narrow area where free flow of the air is restricted. If the air flow is restricted it will cause injury to people and property and serious damage to the equipment or engine.



- When operating the generator outdoors, **DO NOT** place the generator near doors, windows or vents that could allow carbon monoxide to enter and build up in occupied spaces.

### WARNING

- **NEVER** place hands or fingers inside the engine compartment when the engine is running.
- **NEVER** operate the engine with heat shields or guards removed.
- Keep fingers, hands, hair and clothing away from all moving parts to prevent injury.
- **NEVER** operate the generator with the doors open. Stop the engine before servicing.
- **DO NOT** remove the radiator cap while the engine is hot. High pressure boiling water will gush out of the radiator and severely scald any persons in the general area of the generator.
- **DO NOT** remove the coolant drain plug while the engine is hot. Hot coolant will gush out of the coolant tank and severely scald any persons in the general area of the generator.
- **DO NOT** drain the engine oil while the engine is hot. Hot oil will gush out and severely scald any persons near the generator.



- Operation of the generator may create sparks that can start fires around dry vegetation. A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

### CAUTION

- **NEVER** touch the hot exhaust manifold, muffler or cylinder. Allow these parts to cool before servicing the generator.



### NOTICE

- **NEVER** run the engine without an air filter or with a dirty air filter. Severe engine damage may occur. Service the air filter frequently to prevent engine malfunction.
- **NEVER** tamper with the factory settings of the engine or engine governor. Damage to the engine or generator can result if operating in speed ranges above the maximum allowable.



- Wet stacking is a common problem with diesel engines which are operated for extended periods with light or no load applied. When a diesel engine operates without sufficient load (less than 30-35% of the rated output), it will not operate at its optimum temperature. This will allow unburned fuel to accumulate in the exhaust system, which can foul the fuel injectors, engine valves and exhaust system, including turbochargers, and reduce the operating performance.

In order for a diesel engine to operate at peak efficiency, it must be able to provide fuel and air in the proper ratio and at a high enough engine temperature for the engine to completely burn all of the fuel.

Wet stacking does not usually cause any permanent damage and can be alleviated if additional load is applied to relieve the condition. It can reduce the system performance and increase maintenance. Applying an increasing load over a period of time until the excess fuel is burned off and the system capacity is reached usually can repair the condition. This can take several hours to burn off the accumulated unburned fuel.



## SAFETY INFORMATION

### FUEL SAFETY



- **NEVER** start the engine near spilled fuel or combustible fluids. Diesel fuel is extremely flammable and its vapors can cause an explosion if ignited.
- **ALWAYS** refuel in a well-ventilated area, away from sparks and open flames.
- **ALWAYS** use extreme caution when working with **flammable** liquids.
- **NEVER** fill the fuel tank while the engine is **running** or **hot**.
- **NEVER** overfill the fuel tank. Spilled fuel can ignite if it comes into contact with hot engine parts or sparks from the ignition system.
- Store fuel in appropriate containers, in well-ventilated areas and away from sparks and flames.
- **NEVER** use fuel as a cleaning agent.
- **NEVER** smoke around or near the equipment. Fire or explosion could result from fuel vapors or if fuel is spilled on a hot engine.



### TOWING SAFETY



- Check with your local county or state safety towing regulations, in addition to meeting **Department of Transportation (DOT) Safety Towing Regulations**, before towing your generator.
- Refer to the MQ Power trailer manual for additional safety information.
- In order to reduce the possibility of an accident while transporting the generator on public roads, **ALWAYS** make sure that the trailer that supports the generator and the towing vehicle are both mechanically sound and in good operating condition.
- **ALWAYS** shut down the engine before transporting.






- Make sure the hitch and coupling of the towing vehicle are rated equal to or greater than the trailer **gross vehicle weight rating**.
- **ALWAYS** inspect the hitch and coupling for wear. **NEVER** tow a trailer with defective hitches, couplings, chains, etc.
- Check the tire air pressure on both the towing vehicle and the trailer. **Inflate trailer tires as indicated on side wall of tire**. Also check the tire tread wear on both vehicles.
- **ALWAYS** make sure the trailer is equipped with **safety chains**.
- **ALWAYS** properly attach the trailer's safety chains to the towing vehicle.
- **ALWAYS** make sure the vehicle and trailer directional, backup, brake, and trailer lights are connected and working properly.
- DOT requirements include the following:
  - Connect and test electric brake operation.
  - Secure portable power cables in cable tray with tie wraps.
- The maximum speed for highway towing is **55 MPH** unless posted otherwise. Recommended off-road towing is not to exceed **15 MPH** or less depending on the type of terrain.
- Avoid sudden stops and starts. These can cause skidding or jackknifing. Smooth, gradual starts and stops will improve towing.
- Avoid sharp turns to prevent rolling.
- The trailer should be adjusted to a level position at all times when towing.
- Raise and lock the trailer wheel stand in the upright position when towing.
- Place **chock blocks** underneath the wheels to prevent **rolling** while parked.
- Place **support blocks** underneath the trailer's bumper to prevent **tipping** while parked.
- Use the trailer's swivel jack to adjust the trailer height to a level position while parked.

# SAFETY INFORMATION


## ELECTRICAL SAFETY

### DANGER

- **NEVER** touch the output terminals during operation. Contact with the output terminals during operation can cause **electrocution, electrical shock, or burn**. 
- The electrical voltage required to operate the generator can cause **severe injury or even death** through physical contact with live circuits. Turn the generator and all circuit breakers **OFF** before performing maintenance on the generator or making contact with the output terminals.
- **NEVER** insert any objects into the output receptacles during operation. This is extremely dangerous. The possibility exists of **electrical shock, electrocution or death**. 
- Backfeed to a utility system can cause **electrocution** and/or property damage. **NEVER** connect the generator to a building's electrical system without a transfer switch or other approved device. All installations should be performed by a **licensed electrician** in accordance with all applicable laws and electrical codes. Failure to do so could result in electrical shock or burn, causing **serious injury or even death**. 

## Power Cord/Cable Safety

### DANGER

- **NEVER** let power cords or cables **lay in water**.
- **NEVER** **stand in water** while AC power from the generator is being transferred to a load.
- **NEVER** use **damaged** or **worn** cables or cords when connecting equipment to the generator. Inspect the insulation for cuts.
- **NEVER** grab or touch a live power cord or cable with wet hands. The possibility exists of **electrical shock, electrocution or death**. 

- Make sure power cables are securely connected to the generator's output receptacles. Incorrect connections may cause electrical shock and damage to the generator.

## NOTICE

- **ALWAYS** make certain that the proper power or extension cord has been selected for the job. See the Cable Selection Chart in this manual.


## Grounding Safety

### DANGER


- **ALWAYS** make sure that electrical circuits are properly grounded to a suitable earth ground (ground rod) per the National Electrical Code (NEC) and local codes before operating the generator. **Severe injury or death by electrocution** can result from operating an ungrounded generator.
- **NEVER** use gas piping as an electrical ground.

## BATTERY SAFETY

### DANGER

- **DO NOT** drop the battery. There is a possibility that the battery will explode.
- **NEVER** expose the battery to open flames, sparks, cigarettes, etc. The battery contains combustible gases and liquids. If these gases and liquids come into contact with a flame or spark, an explosion could occur. 

### WARNING

- **ALWAYS** wear safety glasses when handling the battery to avoid eye irritation. The battery contains acids that can cause injury to the eyes and skin. 
- Use well-insulated gloves when picking up the battery.
- **ALWAYS** keep the battery charged. If the battery is not charged, combustible gas will build up.
- **ALWAYS** recharge the battery in a well-ventilated environment to avoid the risk of a dangerous concentration of combustible gases.
- If the battery liquid (dilute sulfuric acid) comes into contact with **clothing or skin**, rinse skin or clothing immediately with plenty of water.

# SAFETY INFORMATION

- If the battery liquid (dilute sulfuric acid) comes into contact with **eyes**, rinse eyes immediately with plenty of water and contact the nearest doctor or hospital to seek medical attention.

## CAUTION

- **ALWAYS** disconnect the **NEGATIVE** battery terminal before performing service on the generator.
- **ALWAYS** keep battery cables in good working condition. Repair or replace all worn cables.

## ENVIRONMENTAL SAFETY/DECOMMISSIONING

### NOTICE

Decommissioning is a controlled process used to safely retire a piece of equipment that is no longer serviceable. If the equipment poses an unacceptable and unrepairable safety risk due to wear or damage or is no longer cost effective to maintain (beyond life-cycle reliability) and is to be decommissioned (demolition and dismantlement), be sure to follow the rules below:

- **NEVER** pour waste or oil directly onto the ground, down a drain, or into any water source.
- Contact your country's Department of Public Works or recycling agency in your area and arrange for proper disposal of any electrical components, waste or oil associated with this equipment.
- When the life cycle of this equipment is over, remove the battery and bring it to an appropriate facility for lead reclamation. Use safety precautions when handling batteries that contain sulfuric acid.
- When the life cycle of this equipment is over, it is recommended that the frame and all other metal parts be sent to a recycling center.



Metal recycling involves the collection of metal from discarded products and its transformation into raw materials to use in manufacturing a new product.

Recyclers and manufacturers alike promote the process of recycling metal. Using a metal recycling center promotes energy cost savings.

## EMISSIONS INFORMATION

### NOTICE

The diesel engine used in this equipment has been designed to reduce harmful levels of carbon monoxide (CO), hydrocarbons (HC), and nitrogen oxides (NOx) contained in diesel exhaust emissions.

This engine has been certified to meet US EPA evaporative emissions requirements in the installed configuration.

Attempting to modify or make adjustments to the engine emission system by unauthorized personnel without proper training could damage the equipment or create an unsafe condition.

Additionally, modifying the fuel system may adversely affect evaporative emissions, resulting in fines or other penalties.

### Emission Control Label

The emission control label is an integral part of the emission system and is strictly controlled by regulations.

The label must remain with the engine for its entire life.

If a replacement emission label is needed, please contact Discount-equipment.

# SPECIFICATIONS

**Table 1. Generator Specifications**

<b>Model</b>	DCA70SSIU4F	
<b>Type</b>	Revolving field, self-ventilated, protected type synchronous generator	
<b>Armature Connection</b>	<b>Star with Neutral</b>	<b>Zigzag</b>
<b>Phase</b>	3Ø	1Ø
<b>Standby Output</b>	62 kW (77 kVA)	44 kW
<b>Prime Output</b>	56 kW (70 kVA)	40 kW
<b>3Ø Voltage (L-L/L-N) Voltage Selector Switch at 3Ø 240/139</b>	208Y/120, 220Y/127, 240Y/139	N/A
<b>3Ø Voltage (L-L/L-N) Voltage Selector Switch at 3Ø 480/277</b>	416Y/240, 440Y/254, 480Y/277	N/A
<b>1Ø Voltage (L-L/L-N) Voltage Selector Switch at 1Ø 240/120</b>	N/A	240/120
<b>Power Factor</b>	0.8	1.0
<b>Frequency</b>	60 Hz	
<b>Speed</b>	1,800 rpm	
<b>Aux. AC Power</b>	Single phase, 60 Hz	
<b>Subtransient</b>	0.085	
<b>Transient</b>	0.203	
<b>Synchronous</b>	1.942	
<b>Zero Sequence Reactance</b>	0.0081	
<b>Overload Protection</b>	OCR/Main Circuit Breaker	
<b>Aux. Voltage/Output</b>	120V/4.8 kW (2.4 kW × 2)	
<b>Dry Weight</b>	3,329 lb. (1,510 kg)	
<b>Wet Weight</b>	4,211 lb. (1,910 kg)	

**Table 2. Engine Specifications**

<b>Model</b>	Isuzu BR-4JJ1X Final Tier 4	
<b>Type</b>	4-cycle, water-cooled, direct injection, turbocharged and cooled EGR	
<b>No. of Cylinders</b>	4	
<b>Bore × Stroke</b>	3.76 in. × 4.13 in. (95.4 mm × 104.9 mm)	
<b>Displacement</b>	183 cu. in. (3.0 liters)	
<b>Rated Output</b>	86.5 hp at 1,800 rpm	
<b>Starting</b>	Electric	
<b>Coolant Capacity</b>	5.5 gal. (21.0 liters) <sup>1</sup>	
<b>Lube Oil Capacity</b>	3.96 gal. (15 liters) <sup>2</sup>	
<b>Lubricating Type Oil</b>	API service class CJ-4 SAE 15W-40 or JASO DH-2	
<b>DEF Tank Capacity</b>	7.4 gal. (28 liters)	
<b>Fuel Type</b>	#2 diesel fuel (ultra low sulfur diesel fuel only)	
<b>Fuel Tank Capacity</b>	103 gal. (390 liters)	
<b>Fuel Consumption</b>	4.4 gal. (16.6 L)/hr. at <b>full load</b>	3.5 gal. (13.4 L)/hr. at <b>3/4 load</b>
	2.6 gal. (9.8 L)/hr. at <b>1/2 load</b>	1.7 gal. (6.4 L)/hr. at <b>1/4 load</b>
<b>Battery</b>	27D (CCA 0°F 800A) × 1	

<sup>1</sup> Includes engine and radiator hoses

<sup>2</sup> Includes filters

# DIMENSIONS




Table 3. Dimensions			
Reference Letter	Dimension in. (mm)	Reference Letter	Dimension in. (mm)
A	33.86 (860)	E	33.78 (858)
B	29.45 (748)	F	105.12 (2,670)
C	38.19 (970)	G	68.30 (1,735)
D	32.28 (820)	H	37.40 (950)

[illegible]

## GENERATOR GROUNDING

**ALWAYS** refer to Article 250 (Grounding and Bonding) of the National Electrical Code (NEC).


### NOTICE

**ALWAYS** check with state, province, district, and municipalities for electrical grounding requirements before using the generator.

**EXAMPLE** of how to ground (Figure 3) the unit if the condition of use requires such a device:

## Connecting The Ground

Consult with local electrical and safety codes for proper connection based on condition of use. Refer to the Conductor Grounding Table, Article 250 of the NEC handbook.



**Figure 3. Typical Generator Grounding Application**

### NOTICE

Trailer-mounted generators are the sole responsibility of MQ Power.



## OUTDOOR INSTALLATION

Install the generator in an area that is free of debris, bystanders, and overhead obstructions. Make sure the generator is on secure, level ground so that it cannot slide or shift around. Also, install the generator in a manner so that the exhaust will not be discharged in the direction of nearby homes.

The installation site must be relatively free from moisture and dust. All electrical equipment should be protected from excessive moisture. Failure to do so will result in deterioration of the insulation and will result in short circuits and grounding.

Foreign materials such as dust, sand, lint, and abrasive materials have a tendency to cause excessive wear to engine and alternator parts.

### CAUTION

Pay close attention to ventilation when operating the generator inside tunnels and caves. The engine exhaust contains noxious elements. Engine exhaust must be routed to a ventilated area.

## INDOOR INSTALLATION

Exhaust gases from diesel engines are extremely poisonous. Whenever an engine is installed indoors the exhaust fumes must be vented to the outside. The engine should be installed at least two feet from any outside wall. Using an exhaust pipe which is too long or too small can cause excessive back pressure which will cause the engine to heat excessively and possibly burn the valves.

## MOUNTING

The generator must be mounted on a solid foundation (such as concrete) and set firmly on the foundation to isolate vibration of the generator when it is running. The generator must be mounted at least 6 inches above the floor or grade level as referenced in the National Fire Protection Association handbook (NFPA 110, Chapter 7, Section 7.4).

**DO NOT** remove the metal skids on the bottom of the generator. They are to resist damage to the bottom of the generator and to maintain alignment.

### GENERATOR

This generator (Figure 4) is designed as a high-quality, portable (requires a trailer for transport) power source for telecom sites, lighting facilities, power tools, submersible pumps and other industrial and construction machinery.

### OPERATING CONTROL PANEL

The “Operating Panel” is provided with the following:

■ DSE8610 MKII Controller (Monitors)

- Alarms (low, fuel, high coolant temperature)
- Battery Charge
- Battery Voltage
- Fuel Level
- Coolant Temperature
- Engine Speed
- Engine Run Time
- Engine Fuel Temperature
- Engine Fuel Pressure
- Engine Inlet Pressure
- Oil Pressure
- DEF Level Gauge
- Generator Load
- Voltage Output
- DEF Tank Level

■ Panel Light/Panel Light Switch

■ Control Power Switch

■ USB Service Connection Port

■ Contactor Closed Lamp

■ Contactor Open Lamp

■ 3-Pole, 200-Amp Main Circuit Breaker

### CONTROL BOX

The “Control Panel” is provided with the following:

■ Current Transformers

■ Overcurrent Relay

■ Starter Relay

### OUTPUT TERMINAL PANEL

The “Output Terminal Panel” is provided with the following:

■ Three 120/240V Output Receptacles (CS-6369), 50A

■ Three Auxiliary Circuit Breakers, 50A

■ Two 120V Output Receptacles (GFCI), 20A

■ Two GFCI Circuit Breakers, 20A

■ Five Output Terminal Lugs (3Ø power)

■ Engine Block Heater

■ Battery Charger (Option)

### OPEN-DELTA EXCITATION SYSTEM

Each generator is equipped with the state-of-the-art “Open-Delta” excitation system. The open-delta system consists of an electrically independent winding wound among stationary windings of the AC output section.

There are four connections of the open delta—A, B, C and D. During steady-state loads, the power from the voltage regulator is supplied from the parallel connections of A to B, A to D, and C to D. These three phases of the voltage input to the voltage regulator are then rectified and are the excitation current for the exciter section.

When a heavy load such as a motor starting or a short circuit occurs, the automatic voltage regulator (AVR) switches the configuration of the open delta to the series connection of B to C. This has the effect of adding the voltages of each phase to provide higher excitation to the exciter section and thus better voltage response during the application of heavy loads. The connections of the AVR to the AC output windings are for sensing only. No power is required from these windings.

The open-delta design provides virtually unlimited excitation current, offering maximum motor starting capabilities. The excitation does not have a “fixed ceiling” and responds according to the demands of the required load.

### ENGINE

This generator is powered by a 4-cylinder, 4-cycle, water-cooled, direct injection, turbocharged, EGR, DOC, SCR, Isuzu BR-4JJ1X diesel engine. This engine is designed to meet every performance requirement for the generator. Reference Table 2 for engine specifications.

In keeping with MQ Power’s policy of constantly improving its products, the specifications quoted herein are subject to change without prior notice.


### MICROPROCESSOR CONTROL SYSTEM

The microprocessor controls the RPMs of the engine. When the engine demand increases or decreases, the microprocessor system regulates the frequency variation to  $\pm 0.25\%$ .

### EXTENSION CABLES

When electric power is to be provided to various tools or loads at some distance from the generator, extension cords are normally used. Cables should be sized to allow for distance in length and amperage so that the voltage drop between the generator and point of use (load) is held to a minimum. Use the cable selection chart (Table 6) as a guide for selecting the proper extension cable size.


# MAJOR COMPONENTS



**Table 4. Generator Major Components**

ITEM NO.	DESCRIPTION
1	DOC/SCR Assembly
2	DEF Tank Assembly
3	Coolant Drain Plug
4	Oil Drain With Valve
5	Fuel Tank Assembly
6	Battery Assembly
7	Air Filter Assembly
8	Voltage Selector Switch Assembly
9	Output Terminal Panel Assembly
10	Emergency Stop Switch
11	Generator Assembly
12	Engine Assembly
13	DEF Supply Module Assembly
14	DSE8610 MK II Controller Assembly
15	Main Circuit Breaker

**Figure 4. Major Components**



**Figure 5. Control Panel**

The definitions below describe the controls and functions of the control panel (Figure 5).

1. **Panel Light Switch** — When activated, will turn on the control panel light.
2. **Panel Light** — For operation at night, the panel light illuminates the control panel for ease of reading meters and gauges. Make sure the panel light switch is in the **OFF** position when the light is not in use.
3. **Panel Release Knobs** — Turn these knobs counterclockwise to open and lay down the control panel.
4. **Main Circuit Breaker** — This three-pole, 200-amp main breaker is provided to protect the **U,V, and W** output terminal lugs from overload.
5. **Control Power Switch** — Provides power to the DSE 8610 MKII Controller. Place switch in the **ON** position for normal operation. Place in the **OFF** position when the generator is not in use.
6. **Contactor Open Lamp** — When lit (**GREEN**), indicates contactor switch is **OPEN**. Load is removed. Works in conjunction with the contactor open button located on the controller. Reference Figure 6.
7. **Contactor Closed Lamp** — When lit (**RED**), indicates contactor switch is **CLOSED**. Load is connected. Works in conjunction with the contactor closed button located on the controller. Reference Figure 6.
8. **Service Connection Port** — A USB cable can be plugged into this port for testing/configuration of the DSE 8610 MKII-U2 Controller via a remote computer. Additionally, the various operating parameters (such as coolant temperature, oil pressure, etc.) of the engine are available to be viewed or changed.
9. **DSE8610 MKII-U2 Controller** — This controller has been designed to allow the operator to start, stop and synchronize the generator, and if required, transfer the load to the generator either manually or automatically. Synchronizing and load sharing features are included within the controller, along with the necessary protections for such a system. The user also has the capability to view the system operating parameters via the LCD display. In addition, the controller will monitor engine operating parameters, indicating the operational status and engine fault conditions. Engine fault conditions will automatically shut down the engine, the indicated fault will be shown on the LCD screen.

[illegible]

# DSE8610 MKII-U2 DEEP SEA CONTROLLER




Figure 6. DSE8610 MKII Controller

The definitions below describe the controls and functions of the DSE8610 MKII Deep Sea Controller (Figure 6).

1. **Arrow Pushbuttons** — These four buttons are used to navigate through the front panel display menus and modify settings.
  - The **left** and **right** arrow buttons are used to navigate through the menu levels. The right arrow button is pressed to move downward through the menu levels and the left arrow button is pressed to move upward through the menu levels.
  - Within a level, the **up** and **down** arrow buttons are used to move among items within the menu level. Pressing the down arrow button moves to items lower in the list. Pressing the up arrow button moves to items higher in the list.
  - During a settings editing session, the up and down arrow buttons are used to raise and lower the value of the selected setting. The right and left arrow buttons move to different digits.
2. **Check Button** — When pressed, allows entry into the editor display menu. This pushbutton is used as a selection tool and to save changes.

3. **LCD Display** — This backlit display serves as the local information source for metering, alarms, pre-alarms, and protective functions. Display operation temperature is between  $-22^{\circ}\text{F}$  to  $+122^{\circ}\text{F}$  ( $-30^{\circ}\text{C}$  to  $+50^{\circ}\text{C}$ ).
4. **Status LEDs** — These four status LEDs are user configurable.
5. **Close Contactor Button** — Controls the operation of the generator load switch and is only active in the **Manual Mode** once the generator is available.
 

Pressing the **close contactor button** when the generator is available and with no load applied will automatically command the generator to synchronize and apply the load. Close contactor output becomes active.

If the generator bus is dead (no load) it will immediately close the contactor to connect the load. If the bus is already **live** and the MSE link is connected from another generator it will first synchronize then close its contactor then slowly ramp up to share the load if a load is present. Further presses of the close generator button have no effect.
6. **Close Contactor LED** — Indicates contactor is **CLOSED**.

# DSE8610 MKII-U2 DEEP SEA CONTROLLER

7. **Start Button** — Only active in the Stop/Reset and Manual modes. Pressing the Start button in Stop/Reset Mode powers up the engine's ECU but does not start the engine. This can be used to check the status of the CAN communication and to prime the fuel system.

Pressing the **START** button in Manual Mode starts the generator and runs it with no load applied.

8. **Alarm Mute/Lamp Test Button** — Press this button to silence the controller's audible alarm. If configured it will also disable the audible output. In addition this button also functions as a lamp test and illuminates all of the LEDs on the controller's front panel.

9. **Auto Mode LED** — Indicates unit is in **AUTO** mode.

10. **Auto Mode Button** — This button places the controller into Auto Mode. This mode allows the controller to control the various functions of the generator automatically. The controller monitors numerous start requests via inputs on the Multi-Set Communications (MSC) link. The controller will initiate any start request automatically.

While in **AUTO** mode the controller will be in standby awaiting a signal to start via the remote start terminals. Closure of the auto-start contacts will immediately start the engine. Once the generator is up to speed and voltage it will compare its voltage to the bus.

Once the generator is available, the controller automatically commands the generator to synchronise and apply the load. Close contactor output becomes active.

Upon removal of the start signal, the controller starts the **return delay timer** and once expired, the load is automatically ramped down from the generator and then removed. Close contactor output becomes inactive. The generator then continues to run for the duration of the **cooling timer** until it stops. The controller then waits for the next start event.

11. **Spare LED** — User Defined.

12. **Spare Button** — User Defined.

13. **Manual Mode LED** — Indicates unit is in manual mode.

14. **Manual Mode Button** — Places the controller into **manual mode**. Once in manual mode, the controller responds to the **start button** to start the generator and run it with no load applied.

To run the generator with a load applied, use the **close contactor** button. Once the generator is stable, up to speed and has the desired voltage, press the **close contactor button** to supply power to the load.

During warm up or cool down operations, when the engine is operating under no load, use the open contact button. The controller automatically ramps down the load from the generator and then removes load. Close contactor output becomes inactive.

15. **Stop/Reset Mode LED** — Indicates unit is in stop/reset mode.

16. **Stop Reset Mode Button** — This button when pressed places the controller into the **Stop/Reset Mode**. This clears any alarm conditions for which the triggering criteria has been removed.

If the engine is running and the **Stop/Reset** button is pressed, the controller commands to the contactor to open and remove load. A **five** minute cool down period will begin then shutdown the engine. To bypass the cool down period press the **Stop/Reset** button one more time.

17. **Open Contactor LED** — Indicates contactor is **OPEN**.

18. **Open Contactor Button** — Is only active in the **Manual Mode** and allows the operator to open the generator load switch.

Pressing the **open contactor button** when the generator has a load applied, automatically ramps down the load from the generator and then removes the load. Close contactor output becomes inactive. Further presses of the open generator button have no effect.



# OUTPUT TERMINAL PANEL FAMILIARIZATION

## OUTPUT TERMINAL PANEL

The Output Terminal Panel (Figure 7) shown below is located on the right-hand side (left from the control panel) of the generator. Lift up on the cover to gain access to receptacles and terminal lugs.

### NOTICE

Terminal lugs “O” and “Ground” are considered bonded grounds.

## OUTPUT TERMINAL FAMILIARIZATION

The “Output Terminal Panel” (Figure 7) is provided with the following:

- Three 240/120V Output Receptacles @ 50 amps
- Three Aux. Circuit Breakers @ 50 amps
- Two 120V GFCI receptacles @ 20 amps
- Two GFCI Circuit Breakers @ 20 amps
- Five Output Terminal Lugs (U, V, W, O, Ground)




Figure 7. Output Terminal Panel

# OUTPUT TERMINAL PANEL FAMILIARIZATION

## 120 VAC GFCI Receptacles

### NOTICE

It is recommended that the GFCI receptacles be tested when the generator is initially uncrated. The receptacles should then be tested daily at startup.

There are two 120 VAC, 20-amp GFCI (Duplex NEMA 5-20R) receptacles provided on the output terminal panel. These receptacles can be accessed in any **voltage selector switch** position. Each receptacle is protected by a 20-amp circuit breaker. These breakers are located directly above the GFCI receptacles. Remember the load output (current) of both GFCI receptacles is dependent on the load requirements of the U, V, and W output terminal lugs.

Pressing the **reset** button resets the GFCI receptacle after being tripped. Pressing the **test button** (See Figure 8) in the center of the receptacle will check the GFCI function. Both receptacles should be tested at least once a month. Reference the maintenance section in this manual for further testing of the GFCI receptacle.




Figure 8. 120 VAC GFCI Receptacle

## Twist-Lock Dual-Voltage 240/120 VAC Receptacles

There are three 240/120V, 50-amp, auxiliary twist-lock (CS-6369) receptacles (Figure 9) provided on the output terminal panel. These receptacles can **only** be accessed when the voltage selector switch is placed in the **single-phase 240/120V** position.




Figure 9. 240/120V Twist-Lock Auxiliary Receptacles

Each auxiliary receptacle is protected by a 50-amp circuit breaker. These breakers are located directly above the GFCI receptacles. Remember the load output (current) on both receptacles is dependent on the load requirements of the **output terminal lugs**.

## Removing the Plastic Face Plate (Hard Wire Hookup Panel)

The **Output Terminal Lugs** are protected by a plastic face plate cover (Figure 10). Unscrew the securing bolts and lift the plastic terminal cover to gain access to the terminal enclosure.

After the load wires have been securely attached to the terminal lugs, reinstall the plastic face plate.




Figure 10. Plastic Face Plate (Output Terminal Lugs)

# OUTPUT TERMINAL PANEL FAMILIARIZATION

## Connecting Loads

Loads can be connected to the generator by various methods, output terminal lugs, camlocks or the convenience receptacles (Figure 11). Make sure to read the operation manual before attempting to connect a load to the generator.

To protect the output terminals from overload, a 3-pole, 200-amp, **main** circuit breaker is provided. Make sure to switch **ALL** circuit breakers to the **OFF** position prior to starting the engine.




Figure 11. Connecting Loads

## Overcurrent Relay

An **overcurrent relay** (Figure 12) is connected to the main circuit breaker. In the event of an overload, both the circuit breaker and the overcurrent relay may trip. If the circuit breaker can not be reset, the **reset button** on the overcurrent relay must be pressed. The overcurrent relay is located inside the control box.




Figure 12. Overcurrent Relay

### NOTICE

Remember the **overcurrent relay** monitors the current flowing from the **U,V, and W Output Terminal Lugs** to the load.

In the event of a short circuit or overcurrent condition, it will automatically trip the 200-amp main breaker.

To restore power to the **Output Terminal Panel**, press the reset button on the overcurrent relay and place the **main** circuit breaker in the **closed** position (**ON**).

# LOAD APPLICATION

## SINGLE-PHASE LOAD

Always be sure to check the nameplate on the generator and equipment to ensure the wattage, amperage, frequency, and voltage requirements are satisfactorily supplied by the generator for operating the equipment.

Generally, the wattage listed on the nameplate of the equipment is its rated output. Equipment may require 130–150% more wattage than the rating on the nameplate, as the wattage is influenced by the efficiency, power factor and starting system of the equipment.

### NOTICE

If wattage is not given on the equipment's nameplate, approximate wattage may be determined by multiplying nameplate voltage by the nameplate amperage.

$$\text{WATTS} = \text{VOLTAGE} \times \text{AMPERAGE}$$

The power factor of this generator is 0.8. See Table 5 below when connecting loads.

**Table 5. Power Factor By Load**

Type of Load	Power Factor
Single-phase induction motors	0.4–0.75
Electric heaters, incandescent lamps	1.0
Fluorescent lamps, mercury lamps	0.4–0.9
Electronic devices, communication equipment	1.0
Common power tools	0.8

**Table 6. Cable Selection (60 Hz, Single-Phase Operation)**

Current in Amperes	Load in Watts		Maximum Allowable Cable Length			
	At 120 Volts	At 240 Volts	#10 Wire	#12 Wire	#14 Wire	#16 Wire
2.5	300	600	1,000 ft.	600 ft.	375 ft.	250 ft.
5	600	1,200	500 ft.	300 ft.	200 ft.	125 ft.
7.5	900	1,800	350 ft.	200 ft.	125 ft.	100 ft.
10	1,200	2,400	250 ft.	150 ft.	100 ft.	
15	1,800	3,600	150 ft.	100 ft.	65 ft.	
20	2,400	4,800	125 ft.	75 ft.	50 ft.	

CAUTION: Equipment damage can result from low voltage.

### NOTICE

Cable selection table is a general guideline. **ALWAYS** consult local and national electrical codes when sizing cables.

## THREE-PHASE LOAD

When calculating the power requirements for 3-phase power use the following equation:

$$\text{KVA} = \frac{\text{VOLTAGE} \times \text{AMPERAGE} \times 1.732}{1000}$$

### NOTICE

If 3Ø load (kVA) is not given on the equipment nameplate, approximate 3Ø load may be determined by multiplying voltage by amperage by 1.732.

### NOTICE

Motors and motor-driven equipment draw much greater current for starting than during operation.

An inadequately sized connecting cable which cannot carry the required load can cause a voltage drop which can burn out the appliance or tool and overheat the cable. See Table 6.

- When connecting a resistance load such as an incandescent lamp or electric heater, a capacity of up to the generating set's rated output (kW) can be used.
- When connecting a fluorescent or mercury lamp, a capacity of up to the generating set's rated output (kW) multiplied by 0.6 can be used.
- When connecting an electric drill or other power tools, pay close attention to the required starting current capacity.

When connecting ordinary power tools, a capacity of up to the generating set's rated output (kW) multiplied by 0.8 can be used.

### DANGER

Before connecting this generator to any building's electrical system, a **licensed electrician** must install an **isolation (transfer) switch**. Serious damage to the building's electrical system may occur without this transfer switch.

# GENERATOR OUTPUTS

## GENERATOR OUTPUT VOLTAGES

A wide range of voltages are available to supply voltage for many different applications. Voltages are selected by using the **voltage selector** switch (Figure 13). To obtain some of the voltages as listed in Table 7 (see below) will require a fine adjustment using the **voltage regulator (VR) control knob** located on the control panel.

### Voltage Selector Switch

The voltage selector switch (Figure 13) is located above the output terminal panel's Hard Wire Hook-Up Panel. It has been provided for ease of voltage selection..




Figure 13. Voltage Selector Switch

### CAUTION

**NEVER** change the position of the voltage selector switch while the engine is running. **ALWAYS** place the circuit breaker in the **OFF** position before selecting voltage. There exists the possibility of **electrocution, electrical shock, or burn**, which can cause **severe bodily harm or even death!**

Table 7. Voltages Available

UVWO Output Terminal Lugs	Voltage Selector Switch 3-Phase 240/139V Position			Voltage Selector Switch 3-Phase 480/270V Position		
	208V	220V	240V	416V	440V	480V
3Ø Line-Line						
1Ø Line-Neutral	120V	127V	139V	240V	254V	277V
Voltage Selector Switch Single-Phase 240/120V Position						
1Ø Line-Neutral/Line-Line	120V Line-Neutral	N/A	N/A	240V Line-Line	N/A	N/A

## Maximum Amps

Table 8 shows the **maximum** amps the generator can provide. **DO NOT** exceed the maximum amps as listed.

Table 8. Generator Maximum Amps

Rated Voltage	Maximum Amps
1Ø 120 volts	155.4 amps (4 wire) 168 amps x 2 (zigzag)
1Ø 240 volts	77.8 amps (4 wire) 168 amps (zigzag)
3Ø 240 volts	168 amps
3Ø 480 volts	84 amps
Main Line Circuit Breaker Rating	200 amps

## GFCI Receptacle Load Capability

The load capability of the GFCI receptacles is directly related to the voltage being supplied at either the output terminals or the three twist-lock auxiliary receptacles.

Table 9, and Table 10 show what amount of current is available at the GFCI receptacles when the output terminals and twist-lock receptacles are in use. Be careful that your load does not exceed the available current capability at the receptacles.

Table 9. 1Ø GFCI Receptacle Load Capacity

kW in Use Twist Lock (CS6369)	Available Load Current (Amps)
1Ø 240/120V	GFCI Duplex 5-20R 120V
40.4	0
39.2	5 amps/receptacle
38.0	10 amps/receptacle
36.8	15 amps/receptacle
35.6	20 amps/receptacle

Table 10. 3Ø Generator Maximum Amps

kVA in Use (UVWO Terminals)	Available Load Current (Amps)
3Ø 240/480V	GFCI Duplex 5-20R 120V
70.0	0 amps/receptacle
65.8	5 amps/receptacle
61.7	10 amps/receptacle
57.5	15 amps/receptacle
53.3	20 amps/receptacle

# OUTPUT TERMINAL PANEL CONNECTIONS


## UVWO TERMINAL OUTPUT VOLTAGES

Various output voltages can be obtained using the UVWO output terminal lugs. The voltages at the terminals are dependent on the position of the **Voltage Selector Switch** and the adjustment of the **Voltage Regulator Control Knob**.

Remember the voltage selector switch determines the **range** of the output voltage. The voltage regulator (VR) allows the user to increase or decrease the selected voltage.


### 3Ø-240V UVWO Terminal Output Voltages

1. Place the voltage selector switch in the 3Ø 240/139 position as shown in Figure 14.



**Figure 14. Voltage Selector Switch  
3Ø-240/139V Position**


2. Connect the load wires to the UVWO terminals as shown in Figure 15.



**Figure 15. UVWO Terminal Lugs**

### 3Ø-208V/1Ø-120V UVWO Terminal Output Voltages

1. Place the voltage selector switch in the 3Ø 240/139 position as shown in Figure 14.
2. Connect the load wires to the UVWO terminals as shown in Figure 16.




**Figure 16. UVWO Terminal Lugs  
3Ø-208/1Ø-120V Connections**

### NOTICE

To achieve a 3Ø 208V output the voltage selector switch must be in the 3Ø-240/139 position and the voltage regulator must be adjusted to 208V.

### 3Ø-480/277V UVWO Terminal Output Voltages

1. Place the voltage selector switch in the 3Ø 480/277 position as shown in Figure 17.



**Figure 17. Voltage Selector Switch  
3Ø-480/277V Position**



## OUTPUT TERMINAL PANEL CONNECTIONS

2. Connect the load wires to the UVWO terminals as shown in Figure 18.




Figure 18. UVWO Terminal Lugs 3Ø-480V Connections

2. Connect the load wires to the UVWO terminals as shown in Figure 20.




Figure 20. UVWO Terminal Lugs 1Ø-240/120V Connection

### NOTICE

**ALWAYS** make sure that the connections to the UVWO terminals are **secure** and **tight**. The possibility of arcing exists, that could cause a fire.

### 1Ø-240/120V UVWO Terminal Output Voltages

1. Place the voltage selector switch in the 1Ø 240/120 position as shown in Figure 19.




Figure 19. Voltage Selector Switch 1Ø-240/120V Position




## ENGINE OIL CHECK

### NOTICE


This **Isuzu** engine is equipped with a low oil shutdown capability. A built-in sensor will automatically turn off the engine should the oil level fall below a safe operating condition. Make sure the generator is placed on level ground. Placing the generator on level ground will ensure that the low oil sensor functions properly.

1. To check the engine oil level, place the generator on secure, level ground with the engine stopped.
2. Remove the dipstick from its holder (Figure 21) and wipe it clean.



**Figure 21. Engine Oil Dipstick**

3. Reinsert the dipstick, then remove the dipstick from its holder. Check the oil level shown on the dipstick (Figure 22).



**Figure 22. Engine Oil Dipstick**


4. Verify that the engine oil level is maintained between the **H** and **L** markings on the dipstick as referenced in Figure 22A.

5. If the engine oil level is low (Figure 22C), remove the oil filler cap (Figure 23) and fill to a safe operating level (max) as indicated by the dipstick (Figure 22A).

### NOTICE

When adding engine oil **DO NOT** overfill (Figure 22B).


6. Fill with recommended type oil as listed in Table 11. Maximum oil capacity is 15.8 quarts (15 liters).



**Figure 23. Engine Oil Filler Port**

When checking the engine oil, be sure to check if the oil is clean. If the oil is not clean, drain the oil as referenced in the maintenance section of this manual.

**Table 11. Recommended Motor Oil**



## FUEL CHECK

### DANGER



Fuel spillage on a **hot** engine can cause a **fire** or **explosion**. If fuel spillage occurs, wipe up the spilled fuel completely to prevent fire hazards. **NEVER** smoke around or near the generator. **ALWAYS** shut down the engine prior to cleaning up any spilled fuel.

## Refilling the Fuel System

### NOTICE

**DO NOT** refuel while the engine is running.

### CAUTION

**ONLY** properly trained personnel who have read and understand this section should refill the fuel tank system.

**ALWAYS** fill the fuel tank (Figure 24) with clean, fresh #2 diesel fuel. **DO NOT** fill the fuel tank beyond its capacity.

Pay attention to the fuel tank capacity when replenishing fuel. The fuel tank cap must be closed tightly after filling. Handle fuel in a safety container. If the container does not have a spout, use a funnel. Wipe up any spilled fuel immediately.




Figure 24. Fuel Tank

## REFUELING PROCEDURE:

### WARNING



**Diesel fuel** and its vapors are dangerous to your health and the surrounding environment. Avoid skin contact and/or inhaling fumes.

1. **Level Tanks** — Make sure fuel cells are level with the ground. Failure to do so will cause fuel to spill from the tank before reaching full capacity (Figure 25).

### CAUTION

**ALWAYS** place the trailer on firm, level ground before refueling to prevent spilling and maximize the amount of fuel that can be pumped into the tank.




Figure 25. Only Fill on Level Ground

### NOTICE

**ONLY** use #2 diesel fuel when refueling.

2. Open cabinet doors on the “right side” of the generator (from the generator control panel position). Remove the fuel cap and fill the tank (Figure 26).




Figure 26. Fueling the Generator

3. **NEVER overfill the fuel tank** — It is important to read the fuel gauge when filling the trailer fuel tank. **DO NOT** wait for fuel to rise in the filler neck (Figure 27).

FUEL GAUGE LOCATED  
ON CONTROL PANEL




Figure 27. Full Fuel Tank

## CAUTION

**DO NOT OVERFILL** the fuel system. Leave room for fuel expansion. Fuel expands when heated (Figure 28).




Figure 28. Fuel Expansion

## DEF REFUELING

### NOTICE

**ONLY** fill the DEF tank with **diesel exhaust fluid**. Any other type of fluid may cause severe engine damage.

**Diesel exhaust fluid** is an aqueous solution made with 32.5% high purity **urea** (carbamide) and 67.5% **deionized water**. DEF is used as a consumable in **selective catalytic reduction** (SCR) in order to lower NO<sub>x</sub> concentration from diesel exhaust emissions.

1. Make sure the engine is **OFF**.
2. Remove the filler cap from the DEF tank (Figure 29).




Figure 29. DEF Tank Filling

3. Upon initial start-up, **completely fill** the DEF tank with DEF fluid. **DO NOT** overfill.

### DEF Refueling (Continuous Operation)


It is recommended to **shut down the engine** prior to refilling the DEF tank. However, in special applications where shutdown is not possible, it is recommended to **ONLY** refill the DEF tank when the fluid level has been consumed down to 50%.

The DEF level sending unit requires a gradual DEF level decrease during continuous operation to validate proper operation. Failure of this sensor to report the decrease could result in an engine shutdown. An engine service technician would be required to remedy the shutdown.

## COOLANT (ANTIFREEZE/SUMMER COOLANT/WATER)

**Isuzu** recommends antifreeze/summer coolant for use in their engines, which can be purchased in concentrate (and mixed with 50% demineralized water) or pre-diluted. See the **Isuzu Engine Owner's Manual** for further details.

**WARNING**




If adding coolant/antifreeze mix to the radiator, **DO NOT** remove the radiator cap until the unit has completely cooled. The possibility of **hot!** coolant exists which can cause severe burns.

Day-to-day addition of coolant is done from the recovery tank. When adding coolant to the radiator, **DO NOT** remove the radiator cap until the unit has completely cooled. See Table 12 for engine, radiator, and recovery tank coolant capacities.

**NOTICE**

Normally, only the coolant level in the recovery tank needs to be checked. However, the radiator cap should be opened once a week to verify that coolant is visible (full) inside the radiator.

1. Verify that the coolant level in the coolant recovery tank is between the **FULL** and **LOW** markings as shown in Figure 30.



**Figure 30. Coolant Recovery Tank**

Table 12. Coolant Capacity	
Engine and Radiator	5.5 gal. (21 liters)
Reserve Tank	0.29 gal. (1.1 liters)


## Operation in Freezing Weather

When operating in freezing weather, be certain the proper amount of antifreeze (Table 13) has been added.

Table 13. Coolant Concentration		
Climate	Outside Temperature	Long-Life Coolant Concentration
Warm	10°F (-12°C) or Above	30%
Cold	-22°F (-30°C) or Above	50%

## Cleaning the Radiator

The engine may overheat if the radiator cooling fins (Figure 31) become overloaded with dust or debris. Periodically clean the radiator fins with compressed air. Cleaning inside the machine is dangerous, so clean only with the engine turned off and the **negative** battery terminal disconnected.



**Figure 31. Radiator (Cooling Fins)**

## AIR CLEANER

Periodic cleaning/replacement of the air cleaner is necessary. Inspect the air cleaner (Figure 32) in accordance with the maintenance section of this manual or the **Isuzu Engine Owner's Manual**.




Figure 32. Air Cleaner

## FAN BELT TENSION

A slack fan belt may contribute to overheating, or to insufficient charging of the battery. Inspect the fan belt for damage and wear and adjust it in accordance with the maintenance section of this manual or the **Isuzu Engine Owner's Manual**.

The fan belt tension is proper if the fan belt bends 0.17–0.20 in. (4.2–5.0 mm) when pressed with the thumb as shown in Figure 33.




Figure 33. Fan Belt Tension

Table 14. Fan Belt Deflection

Belt	Standard Value (Amount of Deflection)	Standard Value (Vibration Frequency)
New	0.17–0.20 in. (4.2–5.0 mm)	220–244 Hz
Used	0.26–0.29 in. (6.6–7.4 mm)	182–206 Hz

## CAUTION



**NEVER** place hands near the belts or fan while the generator set is running.

## BATTERY

This unit is of negative ground. **DO NOT** connect in reverse. Always maintain battery fluid level between the specified marks. Battery life will be shortened if the fluid levels are not properly maintained. Add only distilled water when replenishment is necessary.

**DO NOT** overfill. Check to see whether the battery cables are loose. Poor contact may result in poor starting or malfunctions. **ALWAYS** keep the terminals firmly tightened. Coat the terminals with an approved battery terminal treatment compound. Replace the battery with only the recommended type battery. The battery type used in this generator is BCI Group 27.

The battery is sufficiently charged if the specific gravity of the battery fluid is 1.28 (at 68°F). If the specific gravity should fall to 1.245 or lower, it indicates that the battery is dead and needs to be recharged or replaced.


Before charging the battery with an external electric source, be sure to disconnect the battery cables.

## Battery Cable Installation

**ALWAYS** be sure the battery cables (Figure 34) are properly connected to the battery terminals as shown below. The **red cable** is connected to the positive terminal of the battery, and the **black cable** is connected to the negative terminal of the battery.

### **CAUTION**

**ALWAYS** disconnect the negative terminal **FIRST** and reconnect the negative terminal **LAST**.



**Figure 34. Battery Connections**

When connecting the battery do the following:

1. **NEVER** connect the battery cables to the battery terminals when the generator is in either the **MANUAL** or **AUTO** mode. **ALWAYS** make sure the generator is **OFF**.
2. Place a small amount of battery terminal treatment compound around both battery terminals. This will ensure a good connection and will help prevent corrosion around the battery terminals.

### **NOTICE**

If the battery cable is connected incorrectly, electrical damage to the generator will occur. Pay close attention to the polarity of the battery when connecting the battery.

### **CAUTION**

Inadequate battery connections may cause poor starting of the generator, and create other malfunctions.

## ALTERNATOR

The polarity of the alternator is negative grounding type. When an inverted circuit connection takes place, the circuit will be in short circuit instantaneously, resulting in alternator failure.

**DO NOT** put water directly on the alternator. Entry of water into the alternator can cause corrosion and damage the alternator.

## WIRING

Inspect the entire generator for bad or worn electrical wiring or connections. If any wiring or connections are exposed (insulation missing) replace wiring immediately.

## PIPING AND HOSE CONNECTIONS

Inspect all piping, oil hose, and fuel hose connections for wear and tightness. Tighten all hose clamps and check hoses for leaks.

If any hose (**fuel or oil**) lines are defective replace them immediately.



# GENERATOR START-UP PROCEDURE (MANUAL)

## BEFORE STARTING


### ⚠ CAUTION

The engine's exhaust contains harmful emissions. **ALWAYS** have adequate ventilation when operating. Direct exhaust away from nearby personnel.

### ⚠ WARNING


**NEVER** manually start the engine with the **main, GFCI or auxiliary** circuit breakers in the **ON** (closed) position.

1. Place the **main, GFCI, and aux.** circuit breakers (Figure 35) in the **OFF** position prior to starting the engine.




**Figure 35. Main, Aux. and GFCI Circuit Breakers (OFF)**

2. Connect the load to the **receptacles** or the **output terminal lugs** as shown in Figure 11. These load connection points can be found on the output terminal panel and the output terminal panel's hard wire hookup panel.
3. Tighten terminal nuts securely to prevent load wires from slipping out.
4. Close all engine enclosure doors (Figure 36).



**CORRECT**




**INCORRECT**

**Figure 36. Engine Enclosure Doors**


## STARTING (MANUAL)

1. Place the main circuit breaker in the **ON** position.




**Figure 37. Main Circuit Breaker (On)**

2. Make sure the **voltage selector switch** has been configured for the desired output voltage.



**Figure 38. Voltage Selector Switch**

3. Place the **power switch** (Figure 39) on the control panel to the **ON** position (UP) and allow the controller to boot up.



**Figure 39. Power Switch**



# GENERATOR START-UP PROCEDURE (MANUAL)

- Press the **OFF** and **CHECK** buttons simultaneously to enter the **configuration** display menu.




Figure 40. OFF/Check Buttons

- Next, press the right arrow **once** to access the "Alt Config Menu".




Figure 41. Alt Config Menu

- Verify that the "**VOLTAGE CONFIG**" screen (Figure 42) is displayed.




Figure 42. Voltage Config Screen

- Use the **UP/DOWN** arrows (Figure 42) to select the desired output voltage.
- Verify that the selected voltage being displayed on the Voltage Config Screen (Figure 42) is the same voltage as indicated by the voltage selector switch (Figure 38).
- If the voltages do not agree, select the voltage that is indicated by the voltage selector switch.
- When the two voltage settings are the same, press the **CHECK** button (Figure 43) to enter the selection.



Figure 43. Check Button

- Next, press the **MANUAL** button (Figure 44) on the controller.




Figure 44. Manual Mode Button

- Press the **START** button (Figure 45) and verify that the engine starts.




Figure 45. Start Button (Manual Mode)

## NOTICE

If the engine fails to start within a specified number of attempts, a warning on the controller will be displayed. Refer to the troubleshooting section of this manual to correct the problem.

- After starting, allow the engine to ramp up to rated speed. Allow the safety delay countdown sequence to finish. Once the countdown sequence has been completed, the generator is available for use.

# GENERATOR START-UP PROCEDURE (MANUAL MODE)

## NOTICE

In cold weather conditions let the engine idle longer before use.

14. Listen for any abnormal noises. If any abnormalities exist, shut down the engine and correct the problem. Also check the generator for any fluid leaks and controller display for any possible errors.
15. Make sure the **voltage** and **frequency** are set to the desired setting.
16. Press the contactor **CLOSE** button (Figure 46).




Figure 46. Contactor Close Button (Manual Mode)

17. Verify that the contactor **CLOSED** lamp (Figure 47) is lit (RED).




Figure 47. Contactor Closed Lamp

18. Next, verify that the **main status screen** (Figure 48) is displayed.




Figure 48. Main Status Screen

## Frequency Verification

Press the **right arrow button twice** and verify that the "Generator" screen is displayed, then press the **down arrow button three times** and verify that the 60-cycle output frequency is displayed in **HERTZ** as shown in Figure 49.




Figure 49. Frequency Screen

## Voltage Verification

From the main status screen, press the **right arrow button twice** and verify that the "Generator" screen is displayed, then press the **down arrow button one time** and verify that the generator's voltage output is displayed in **VOLTS** as shown in Figure 50.




Figure 50. Output Voltage Screen

# GENERATOR START-UP PROCEDURE (MANUAL MODE)

## Load Current Verification

From the main status screen, press the **right arrow button twice** and verify that the "Generator" screen is displayed, then press the **down arrow button four times** and verify that the generator's load current screen is displayed in **AMPS** as shown in Figure 51.

### NOTICE

The load current value (Figure 51) will indicate **zero amps** with no load applied. When a load is applied, the value on the LCD screen will indicate the amount of current that the load is drawing from the generator.




Figure 51. Output Current Screen (Load)

## Engine Oil Pressure Verification

From the main status screen, press the **right arrow button once** and verify that the "Engine" screen is displayed, then press the **down arrow button twice** and verify that the engine's oil pressure screen is displayed as shown in Figure 52.

Under normal operating conditions the engine oil pressure reading should be between 42.1 and 85.6 psi (290–590 kPa).




Figure 52. Engine Oil Pressure Screen

## Engine Coolant Temperature Verification

From the main status screen, press the **right arrow button once** and verify that the "Engine" screen is displayed, then press the **down arrow button three times** and verify that the engine's coolant temperature screen is displayed as shown in Figure 53.

Under normal operating conditions the engine coolant temperature should be between 167°–194°F (75°–90°C).




Figure 53. Engine Coolant Temperature Screen

# GENERATOR START-UP PROCEDURE (MANUAL MODE)

## Engine Speed Verification

From the main status screen, press the **right arrow button once** and verify that the "Engine" screen is displayed, then press the **down arrow button one time** and verify that the engine's speed screen is displayed as shown in Figure 54

Under normal operating conditions this speed is approximately 1,800 rpm.




Figure 54. Engine Speed Screen

## Engine Fuel Level Verification

From the main status screen, press the **right arrow button once** and verify that the "Engine" screen is displayed, then press the **down arrow button six times** and verify that the engine's fuel level screen is displayed as shown in Figure 55.




Figure 55. Engine Fuel Level Screen

## DEF Level Verification (If Applicable)

From the main status screen, press the **right arrow button once** and verify that the "Engine" screen is displayed, then press the **down arrow button sixteen times** and verify that the engine's DEF tank level screen is displayed as shown in Figure 56.




Figure 56. Engine DEF Tank Level Screen

## Alarm Screen

From the main status screen, press the **right arrow button four times** and verify that the "Alarm" screen is displayed.




Figure 57. Alarm Screen

# GENERATOR START-UP PROCEDURE (MANUAL MODE)

## Additional Engine Operating Parameters


From the main status screen, press the **right arrow button** **once** and verify that the "Engine" screen is displayed

Additional engine parameters such as the ones shown below can be accessed by pressing the **down arrow button**

- Battery Voltage
- Engine Run Time
- Engine Inlet Temperature
- Engine Fuel Temperature
- Engine Turbo Pressure
- Engine Fuel Pressure
- Engine Percent Torque
- Inter-Cooler temperature
- Atmospheric Pressure
- Electrical Potential
- Percent Heat Status

## Auxiliary/GFCI Circuit Breakers

1. Place **auxiliary** and **GFCI** circuit breakers in the **ON** position (Figure 58).



**Figure 58. Auxiliary and GFCI Circuit Breakers (ON)**

2. The generator will run until manually stopped or an abnormal condition occurs.

# GENERATOR START-UP PROCEDURE (AUTO MODE)

## STARTING (AUTO MODE)

### DANGER



Before connecting this generator to any building's electrical system, a **licensed electrician** must install an **isolation (transfer) switch**. Serious damage to the building's electrical system may occur without this transfer switch.

### CAUTION

When connecting the generator to an isolation (transfer) switch, **ALWAYS** have power applied to the generator's internal battery charger. This will ensure that the engine will not fail due to a dead battery.

### NOTICE

When the generator is set in the **AUTO** mode, the generator will **automatically start** in the event of commercial power falling below a prescribed level by means of a contact closure that is generated automatically by a transfer switch.

### WARNING

When running the generator in the **AUTO** mode, remember the generator can start up at any time without warning. **NEVER** attempt to perform any maintenance when the generator is in the auto mode.

### NOTICE

When the generator is placed in the **AUTO** mode, the engine glow plugs will be warmed and the engine will start automatically.

When starting the generator in **AUTO** mode use the "Manual Start-Up" procedure except where noted (see below).

1. Perform steps 1 through 4 in the "Before Starting" section and steps 1 through 3 in the "Manual Starting" section.
2. Press the **AUTO** button (Figure 59) on the controller.



Figure 59. Auto Button

3. Once in **AUTO** mode, the controller monitors the auto start contacts awaiting a closure. A closed contact signal will start the engine, automatically closing the contactor. Reference Figure 47.

If an open contact signal is transmitted this will cause the engine to shutdown and the **OPEN** contactor lamp will be lit (**GREEN**).




Figure 60. Contactor Open Lamp

4. Continue operating the generator as outlined in the Manual Start-Up procedure (start at step 15).

# GENERATOR SHUTDOWN PROCEDURE


## NORMAL SHUTDOWN PROCEDURE

### WARNING

**NEVER** stop the engine suddenly except in an emergency.


To shut down the generator, use the following procedure:

1. Place the load's **ON/OFF** switch in the **OFF** position.
2. Press the **contactor OPEN** button (Figure 61).




**Figure 61. Contactor Open Button**

3. Verify that the **OPEN** contactor lamp (Figure 62) is lit (**GREEN**).




**Figure 62. Contactor Open Lamp**

4. Place the **MAIN, GFCI and LOAD** circuit breakers as shown in Figure 63 to the **OFF** position.



**Figure 63. Main, Aux. and GFCI Circuit Breakers (OFF)**

5. With no load applied, allow the engine to cool down for 5 minutes.
6. Press the **OFF** button (Figure 64) to shutdown the generator.



**Figure 64. Off Button (Manual Mode)**


1. Remove all loads from the generator.
2. Inspect the entire generator for any damage or loosening of components that may have occurred during operation.

## EMERGENCY SHUTDOWN PROCEDURE

### NOTICE

The Emergency Stop Pushbutton Switch should only be used to stop the engine in case of an emergency or to lock out operation during service. The emergency stop switch should **NEVER** be used for routine stopping of the engine.

1. To stop the engine in the event of an emergency, push the **Emergency Stop Pushbutton Switch** (Figure 65). Activating the Emergency Stop Switch will cause the contacts on the main breaker to **OPEN**.



**Figure 65. Emergency Stop Button**

2. The emergency stop switch is a push-locked type switch. The switch contact can only be released by rotating the button in the clockwise direction. The engine can not be restarted until the contact is released (**closed**).



# GENERATOR START-UP PROCEDURES (PARALLEL OPERATION)




Figure 66. MSC Communication Cable Connections (Three or More Generators)

# GENERATOR START-UP PROCEDURES (PARALLEL OPERATION)

## MANUAL PARALLEL OPERATION (2 OR MORE UNITS)

### NOTICE

To ensure stable operation of multiple generator units connected in parallel and working as one unit, it is necessary to maintain equal voltage, frequency, and engine governor characteristics between them.

For this reason, it is necessary to perform parallel operation using generator units with identical alternator pitch and brand-compatible controllers. **Therefore, using multiple units of the same model generator for paralleling is recommended.**

### NOTICE

If the preset voltage (set on the voltage selector switch) is different between the paralleling units, the main circuit breakers **will not turn on**.

## Preparation

### NOTICE

Make sure the engines of all generator units in the system are turned **OFF** before connecting the units.


1. Make sure the spacing between each generator output terminal panel does not exceed **50 ft. (15.14 m)**. Referece Figure 66.
2. For parallel operation a Mult-Set Communication (MSC) cable must be connected between the generators being paralleled.
3. Connect the **three wires** from the MSC cable between the generators in accordance with Figure 66 and Table 15 via the 6-position terminal block located on the output terminal panel.
4. Continue connecting all remaining generators in the same manner, until all of the generators in the system oare connected via the MSC cable.

Table 15. MSC Cable Connections

CONNECTIONS		GENERATOR 2 Terminal #					
		1	2	3	4	5	6
GENERATOR 1 Terminal #	1	SH					
	2		L (BLK)				
	3			H (WHT)			
	4						
	5						
	6						
GENERATOR 3 Terminal #	1				SH		
	2					L (BLK)	
	3						H (WHT)
	4						
	5						
	6						


# GENERATOR START-UP PROCEDURES (PARALLEL OPERATION)

- For the two outer most generators place the parallel signal switch (Figure 67) in the **END** position.




**Figure 67. Parallel Signal Switch (End)**

- For the inner most generators place the parallel signal switch (Figure 68) in the **MIDDLE** position.




**Figure 68. Parallel Signal Switch (Middle)**

- Connect the **output terminals** on each paralleled unit to the load using properly sized power cables.
- Place the **power switch** ( ) on the control panel to the **ON** position (UP) and allow the controller to boot up.




**Figure 69. Power Switch**

- Make sure the **voltage selector switch** has been configured for the desired output voltage.



**Figure 70. Voltage Selector Switch**

- From the "Alt Config Menu (Figure 41), verify that the "VOLTAGE CONFIG" screen (Figure 71) is displayed.



**Figure 71. Voltage Config Screen**

- Verify that the selected voltage being displayed on the Voltage Config Screen (Figure 71) is the same voltage as indicated by the voltage selector switch (Figure 70).
- If the voltages do not agree, select the voltage that is indicated by the voltage selector switch.
- When the two voltage settings are the same, press the **CHECK** button (Figure 72) to enter the selection.



**Figure 72. Check Button**

- Operate the generator as outlined in the "Manual Starting Procedure" referencing steps 9 through 13.
- Repeat steps 7 through 13 in this section for all remaining generators.
- On generator #1, press the close contactor button.
- On generator #2, press the close contactor button and verify that the initializing synchroscope screen (Figure 73) is displayed as it closes the contactor.

# GENERATOR START-UP PROCEDURES (PARALLEL OPERATION)

18. Repeat step 17 for all remaining generators.
19. Allow all generators to synchronize. This synchronization process will be repeated for all remaining generators.
20. Shutdown the generators as referenced in the "Normal Shutdown Procedure" section.

## SYNCHROSCOPE

Initially the synchroscope screen shows the difference between the bus and generator supplies. Figure 73 indicates a frequency mismatch of +0.9 Hz and a voltage mismatch of +0.2 V.




Figure 73. Frequency/Voltage Mismatch

In addition, Figure 73 also indicates that the generator frequency is **too high** as shown by the arrow mark and must be reduced. The voltage is high, but is within the limits set for synchronizing, indicated by the check mark.

When both the frequency and the voltage differences are within acceptable limits, the phase matching begins (Figure 74). The **moving bar** shows the phase difference between the two supplies. The engine speed is automatically adjusted, altering the phase until the moving bar enters the center of the scope (Figure 75).




Figure 74. Phase Matching Initialization

The engine speed is automatically adjusted, altering the phase until the moving bar enters the center of the scope (Figure 75).




Figure 75. Frequency/Voltage In Sync

## AUTO PARALLEL OPERATION (2 OR MORE UNITS)

1. Operate the generator as outlined in the "Manual Starting Procedure" referencing steps 1 through 5.
2. Verify that the **auto start contacts** on all generators are jumpered as shown in Figure 76. If the auto start contacts are not jumpered **add jumper wire**.





Figure 76. Auto Start Contacts (Jumpered)


3. Press the **CHECK** button to enter the **editor** display menu.

# GENERATOR START-UP PROCEDURES (PARALLEL OPERATION)



**Figure 77. OFF/Check Buttons**

- Using the down arrow button scroll down to the **load demand priority** page (Figure 78).




**Figure 78. Load Priority Page**

- On generator #1 (master) set the priority to 1 (Figure 78). On generator #2 set the priority to 2. Repeat this procedure for all the remaining generators.
- To exit press the check button (Figure 79).



**Figure 79. Check Button**

- Press the **AUTO** button (Figure 80) on all controllers in the system.



**Figure 80. Auto Button**

- Priority 1, generator #1 (master) will start and close the contactor. The remaining generators will start and sync automatically based on power (load) demand.
- Prior to opening the auto start contacts, shutdown the generators as referenced in the "Normal Shutdown Procedure" section.
- Remove the auto start jumper wire as shown in Figure 76.

# MAINTENANCE

Table 16. Inspection/Maintenance		10 Hrs. DAILY	250 Hrs.	500 Hrs. or Every 12 Months	3,000 Hrs or Every 36 Months	OTHER
Engine	Check Engine Oil and Coolant Levels	X				
	Check Fuel Filter/Water Separator Bowl	X				
	Check Air Cleaner/Element	X				
	Clean Air Cleaner/Element		X			
	Check for Leaks/Hoses/Clamps	X				
	Check for Loosening of Parts	X				
	Change Engine Oil and Oil Filter * 1		X			
	Clean Unit, Inside and Outside		X			
	Replace Fuel Filter Elements			X		
	Check Engine Mounts			X		
	Service Battery			X		
	Check Air Intake Hoses			X		
	Check Fan Belt Condition (Replace if Necessary)	X				
	Check Automatic Belt Tensioner	X		X		
	Check Electrical Ground Connection			X		
	Clean Radiator, Check Cooling System			X		
	Coolant Solution Analysis, Add SCAs as Required			X		
	Pressure Test Cooling System			X		
	Check Engine Speed			X		
	Test Thermostats				X	
	Check and Adjust Engine Valve Clearance					1,000 hrs.
	Test Glow Plugs				X	
	Replace DEF Filter (In Supply Module)					3,000 hrs.
	Check SCR System*2					4,500 hrs.
	Inspect Dosing Module (SCR System)					4,500 hrs.
	Flush and Refill Cooling System*3					1 yr. or 2,000 hrs.
	Clean Inside of Fuel Tank					1,000 hrs.
	Clean DEF Tank					As Required
	Replace Air Cleaner Elements *4					As Required
Generator	Measure Insulation Resistance Over 3M Ohms		X			
	Check Rotor Rear Support Bearing			X		

\*1 During initial operation of a new engine, change oil and filter between a minimum of 100 hours and a maximum of 250 hours. Service interval depends on type of oil.

\*2 Perform inspection and maintenance of Urea SCR system every 4,500 hours. The system does not need to be replaced/exchanged if no problem is found. Do not make any modifications or changes, nor remove the emission control system and related parts. Please contact Discount-equipment for SCR maintenance.

\*3 Use fully formulated antifreeze/coolant.

\*4 Replace primary air filter element when restriction indicator shows a vacuum of 635 mm (25 in. H<sub>2</sub>O).

\*5 Add "Supplemental Coolant Additives" (SCAs) to recharge the engine coolant.

\*6 Accumulation of carbon (soot, unburned fuel) in the exhaust pipe line and muffler could cause not only system derates but also could lead to fire incident. To destroy the soot and unburned fuel, run the unit at rated power for some period of time until the exhaust gas become mostly colorless every 250 hours of operation time. The carbon will be easier to be generated when the unit operates at less than 30% of rated power. In this case, perform the above procedures at a shorter interval time.

\*7 Applying a large load at one time to the unit when carbon deposits have accumulated in the exhaust system could produce fire/sparks which could lead to abnormal combustion. Therefore it is recommended to **apply the load gradually** and observe the exhaust gas color (colorless) during the process.

\*8 Fire or sparks may emit from the exhaust gas outlet during the **carbon emission accumulation check** (load). Make sure the area surrounding the unit is free from any **flammable** material.



## GENERAL INSPECTION

Prior to each use, the generator should be cleaned and inspected for deficiencies. Check for loose, missing or damaged nuts, bolts or other fasteners. Also check for fuel, oil, and coolant leaks. Use Table 16 as a general maintenance guideline **Engine Side** (Reference Engine Instruction Manual).

## AIR CLEANER

### NOTICE

If the engine is operating in very **dusty** or **dry** grass conditions, a clogged air cleaner will result. This can lead to a loss of power, excessive carbon buildup in the combustion chamber and high fuel consumption. Change air cleaner more **frequently** if these conditions exist.

Every 250 hours: Remove the air cleaner element (Figure 81) and clean the heavy-duty paper element with a light spray of compressed air. Replace the air cleaner as needed.

This Isuzu diesel engine is equipped with a replaceable, high-density, paper air cleaner element. This air cleaner is also equipped with an inner element (secondary) that is used as a backup filter should the primary element become damaged.

### CAUTION



Wear protective equipment such as approved safety glasses or face shields and dust masks or respirators when cleaning air filters with compressed air.




Figure 81. Air Cleaner

## Primary and Secondary Air Cleaner Elements

1. Release the latches (Figure 81) that secure the cover to the air cleaner body.
2. Remove the air cleaner cover and set it aside.
3. Remove both the primary and secondary air cleaner elements.
4. Check the air cleaner daily or before starting the engine.
5. Check for and correct heavy buildup of dirt and debris along with loose or damaged components.

### NOTICE

Operating the engine with loose or damaged air cleaner components could allow unfiltered air into the engine causing premature wear and failure.

6. To clean the primary element (paper air filter) as referenced in Figure 81, tap the filter element several times on a hard surface to remove dirt, or blow compressed air, not to exceed 30 psi (207 kPa, 2.1 kgf/cm<sup>2</sup>), through the filter element from the inside out.
7. Clean the secondary element (paper air filter) as referenced in step 6.
8. Replace both elements if they are damaged or excessively dirty.
9. Clean the inside of the air cleaner body.
10. Reinstall the primary and secondary air filter elements back into the air cleaner body.
11. Reinstall the air cleaner cover and secure with latches.

### NOTICE

**DO NOT** run the engine with the air cleaner removed or without an element.




## Air Filter Dust Indicator

### NOTICE

The air filter should not be changed until the indicator reads **RED**. Dispose of the old air filter. It may not be cleaned or reused.

The air filter indicator (Figure 82) is attached to the air filter. When the air filter element is clogged, air intake restriction becomes greater and the air filter indicator signal shows **RED**. When the indicator is red, replace the filter immediately. After changing the air filter, **press** the air filter indicator button to reset.

PUSH BUTTON TO RESET




**Figure 82. Air Filter Dust Indicator**

## DRAINING THE FUEL FILTER ELEMENT

### NOTICE

Inspect the fuel filter **daily**. If the fuel filter (Figure 83) has collected a significant amount of water and sediment at the bottom of the cup, it should be drained off immediately.

1. Loosen the air bleeder plug (Figure 83) on the fuel filter body.
2. To discharge the fuel inside the fuel filter, **OPEN** the drain valve on the fuel filter by turning the knob **counterclockwise** (Figure 83A) approximately 3-1/2 turns until the valve drops down 1 inch (25.4 mm) and draining occurs (Figure 83B).




**Figure 83. Draining Fuel Filter**

3. Let the residue or foreign substances inside the case flow into a suitable container.
4. At completion of draining, **CLOSE** the drain valve (Figure 83C).

## FUEL FILTER ELEMENT REPLACEMENT

1. Use a filter wrench to remove the element case (Figure 84) from the fuel filter body.




**Figure 84. Fuel Filter Replacement**

2. Wipe the inside of the filter body with a clean cloth to remove any foreign matter or debris that may have accumulated.
3. Insert the new fuel filter element into the element case.
4. Replace both O-rings. Coat each O-ring with a small amount of clean 15W-40 engine oil.
5. Reinstall the element case first by hand until it makes contact with the fuel filter body surface.
6. Torque the element case to 22.4 lbf·ft (30 N·m).
7. Torque the drain plug to 1.4 lbf·ft (2.0 N·m).
8. Remove the air from the fuel system. Reference the Isuzu Owner's Manual, "Bleeding the Fuel System."

## ELECTROMAGNETIC FUEL PUMP (500 HOURS)

The filter inside the fuel pump (Figure 85) is either a paper type or steel mesh type depending on the fuel pump type. Clean or replace the fuel pump filter as follows:

1. Disconnect any electrical connections that are attached to the fuel pump.
2. Prepare a fuel collector to drain the fuel into. Secure any fuel lines to prevent fuel from spilling.
3. Remove the fuel pump from the generator enclosure.
4. Remove the filter and gasket from the fuel pump housing.



**Figure 85. Electromagnetic Fuel Pump**

### NOTICE

When the fuel pump filter is removed, always make sure to replace both gaskets and clean the magnet portion inside the cover.

5. Clean or replace the fuel pump filter. Replace both gaskets.
6. Reassemble the fuel pump and mount it back onto the generator enclosure.
7. Reconnect all fuel lines and electrical components.
8. Check for fuel leaks.

## DRAINING THE CONTAINMENT TANK

1. This generator is equipped with an environmental containment tank. Inspect this tank regularly.
2. If the tank becomes full with fluids, remove the drain bolt (Figure 86), then allow the fluids to drain into a suitable container.




Figure 86. Draining Containment Tank

## CLEANING INSIDE THE FUEL TANK

If necessary, drain the fuel inside the fuel tank completely. Using a spray washer (Figure 87) wash out any deposits or debris that have accumulated inside the fuel tank.




Figure 87. Fuel Tank Cleaning

## FUEL TANK INSPECTION

In addition to cleaning the fuel tank, the following components should be inspected for wear:

- **Rubber Suspension** — Look for signs of wear or deformity due to contact with oil. Replace the rubber suspension if necessary.
- **Fuel Hoses** — Inspect nylon and rubber hoses for signs of wear, deterioration or hardening.
- **Fuel Tank Lining** — Inspect the fuel tank lining for signs of excessive amounts of oil or other foreign matter.

## DRIVE BELT (DAILY)

### Drive Belt Tension

A slack drive belt (Figure 88) may contribute to overheating or insufficient charging of the battery. Adjust the drive belt in accordance with the Isuzu Operator's manual.

### Drive Belt Inspection

Inspect the drive belt for damage and wear. Horizontal cracks (across the belt) are acceptable. Vertical (direction of belt ribs) cracks that intersect with horizontal cracks are not acceptable.

Also, examine the belt and determine if it is **oil soaked** or **"glazed"** (a hard shiny appearance on the sides of the belt). Either of these two conditions can cause the belt to run hot, which can weaken it and increase the danger of it breaking.

If the drive belt exhibits any of the above wear conditions, replace the drive belt immediately.




Figure 88. Drive Belt Inspection

## DRAINING ENGINE OIL

1. Run the engine until the engine coolant reaches a temperature of 140°F (60°C). Turn the engine off.
2. Remove the oil dipstick from its holder.
3. Remove the **oil drain cap** (Figure 89).
4. Place the **oil drain valve** in the **OPEN** position and allow the oil to drain into a suitable container.





Figure 89. Draining Engine Oil

5. After the engine oil has been completely drained, reinstall the oil drain cap and tighten securely.
6. Place the **oil drain valve** in the **CLOSED** position.

## ENGINE OIL FILTER REPLACEMENT

1. Clean the area around the lubricating oil filter head.
2. Using an oil filter wrench (Figure 90), remove the engine oil filter.



**Figure 90. Oil Filter Removal**

3. Coat the rubber seal (gasket) surface of the oil filter (Figure 90) with clean 15W-40 engine oil.
4. Install the new oil filter (main) first by hand until it makes contact with the filter head surface. Tighten it another 3/4 turn using the filter wrench.
5. Fill the engine crankcase with high-quality detergent oil classified "For Service CI-4." Fill to the upper limit of the dipstick. **DO NOT** overfill. Reference Table 2 for engine crankcase oil capacity.
6. Run the engine for several minutes. Watch for oil leakage. Shut the engine down and allow it to sit for several minutes. Top off the oil to the upper limit on the dipstick.

## DRAINING ENGINE COOLANT


### WARNING



**DO NOT** remove the pressure cap from the radiator when the engine is hot! Wait until the coolant temperature is below 120°F (50°C) before removing the pressure cap.


Heated coolant spray or steam can cause severe scalding and personal injury.

1. Remove the radiator pressure cap (Figure 91) only if the coolant temperature is below 120°F (50°C).



**Figure 91. Radiator Pressure Cap Removal**

2. Open the cabinet door and remove the coolant drain bolt and O-ring (Figure 92), then allow the coolant to drain into a suitable container.



**Figure 92. Draining Radiator Coolant**

## FLUSHING OUT THE RADIATOR AND REPLACING COOLANT

- Open both cocks located at the crankcase side and at the lower part of the radiator and drain the coolant. Open the radiator cap while draining. Remove the overflow tank and drain.
- Check hoses for softening and kinks. Check clamps for signs of leakage.
- Tighten both cocks and replace the overflow tank.
- Replace with coolant as recommended by the engine manufacturer.
- Close the radiator cap tightly.
- Flush the radiator by running clean tap water through the radiator until signs of rust and dirt are removed. **DO NOT** clean the radiator core with any objects, such as a screwdriver.

**WARNING**

Allow the engine to **cool** when flushing out the radiator. Flushing the radiator while hot could cause serious burns from water or steam.

## RADIATOR CLEANING

The radiator (Figure 93) should be sprayed (cleaned) with a high-pressure washer when excessive amounts of dirt and debris have accumulated on the cooling fins or tube. When using a high-pressure washer, stand at least 5 feet (1.5 meters) away from the radiator to prevent damage to the fins and tube.



Figure 93. Radiator Cleaning

## TESTING THE GFCI RECEPTACLE

### NOTICE

The GFCI receptacle is designed to interrupt power when a ground fault exists to prevent injuries and shock hazards. **DO NOT** use the GFCI receptacle if the test below fails. Consult a qualified electrician for repair or replacement of the GFCI receptacle. Test the GFCI receptacle **at least once a month**.

1. Start the generator as outlined in the start-up procedure in this manual.
2. Place a GFCI circuit breaker (Figure 94) in the **ON** position.




Figure 94. GFCI Circuit Breaker

3. Verify that the status LED on the corresponding GFCI receptacle (Figure 95) is **ON (GREEN)**.






Figure 95. GFCI Receptacle (ON)

4. Press the **TEST** button (Figure 96) on the GFCI receptacle and verify that the status LED turns **OFF**.




**Figure 96. GFCI Receptacle (OFF)**

5. Press the **RESET** button (Figure 97) to restore power to the GFCI receptacle and verify that the status LED is **ON (GREEN)**.



**Figure 97. GFCI Receptacle (ON/Restore)**

6. If the status LED (Figure 98) is **flashing (RED)**, **DO NOT** use the GFCI receptacle and replace it immediately.



**Figure 98. GFCI Receptacle (RED Flashing LED)**

7. Repeat the above procedure for any other GFCI receptacles.

### GENERATOR STORAGE

For long-term storage of the generator the following is recommended:

- Drain the fuel tank completely. Treat with a fuel stabilizer if necessary.
- Completely drain the oil from the crankcase and refill if necessary with fresh oil.
- Clean the entire generator, internal and external.
- Cover the generator and store in a clean, dry place.
- Disconnect the battery.
- Make sure engine coolant is at the proper level.
- If the generator is mounted on a trailer, jack the trailer up and place it on blocks so the tires do not touch the ground, or block and completely remove the tires.



## ENGINE BLOCK HEATER AND INTERNAL BATTERY CHARGER 120 VAC INPUT RECEPTACLES

This generator comes equipped with an **engine block heater**. An **internal battery charger** is available as an **option**. These components are provided with electrical power cords to connect to a commercial power source.

The engine block heater and internal battery charger both require 120 VAC in order to operate. A receptacle (Figure 99) has been provided on the output terminal panel to allow commercial power to be applied.

These receptacles will **ONLY** function when commercial power has been supplied to them (Figure 99). To apply commercial power to these receptacles, a power cord of adequate size will be required (See Table 6).

When using the generator in **hot** climates there is no reason to apply power to the engine block heater. However, if the generator will be used in **cold** climates it is always a good idea to apply power to the engine block heater at all times.

If the generator will be used daily, the battery should normally not require charging. If the generator will be idle (not used) for long periods of time, apply power to the battery charger receptacle via commercial power using a power cord of adequate size.

### NOTICE

If the generator will be idle (not used) for long periods of time and to ensure adequate starting capability, always have power applied to the generator's internal battery charger.




Figure 99. Engine Block Heater and Battery Charger

## EMISSION CONTROL

The emission control system employed with the Isuzu BR-4JJ1X diesel engine consists of a Diesel Oxidation Catalyst (DOC).

This device oxidizes large amounts of harmful nitrogen oxides (NOx) and particulate matter (PM) which are emitted by diesel engines. These exhaust emissions pose serious environmental and health risks. No maintenance or service is required for the DOC device used on this generator.

### Diesel Oxidation Catalyst (DOC)

The DOC (Figure 100) does not filter particles, it oxidizes them. This catalyst (honeycomb-like structure) uses a chemical process to break down pollutants in the exhaust stream into less harmful components. In general this catalyst collects/burns accumulated particulates. The DOC contains palladium and platinum which serve as catalysts to oxidize hydrocarbons and carbon monoxide.

## EMISSION CARBON CHECK

Deposition of carbon (soot, unburned fuel) in the exhaust pipe line and muffler could cause not only system derates but also could lead to fires.

To reduce soot and unburned fuel, run the unit at rated power until the exhaust gas becomes mostly colorless every 250 hours of operation time. More carbon will be generated when the unit operates at less than 30% of rated power. In this case, perform the above procedures more frequently.

### NOTICE

Applying a large load suddenly to the unit when carbon deposition has been generated in the exhaust system could produce sparks and will lead to abnormal combustion. Therefore, apply load gradually and observe the exhaust gas color during the process.




Figure 100. Diesel Oxidation Catalyst (DOC)

## SELECTIVE CATALYTIC REDUCTION (SCR)

Diesel engines can be run with a lean burn air-to-fuel ratio, to ensure the full combustion of soot and to prevent the exhaust of unburnt fuel. The excess of air necessarily leads to generation of nitrogen oxides ( $\text{NO}_x$ ), which are harmful pollutants, from the nitrogen in the air. **Selective Catalytic Reduction** is used to reduce the amount of  $\text{NO}_x$  released into the atmosphere.

**Diesel Exhaust Fluid** (DEF) from a separate tank is injected into the exhaust pipeline, where the aqueous urea vaporizes and decomposes to form ammonia and carbon dioxide. Within the SCR catalyst, the  $\text{NO}_x$  are catalytically reduced by the ammonia ( $\text{NH}_3$ ) into water ( $\text{H}_2\text{O}$ ) and nitrogen ( $\text{N}_2$ ), which are both harmless; these are then released through the exhaust.

The SCR system creates a certain amount of ammonia ( $\text{NH}_3$ ) that is stored in SCR catalyst. During purging operations the increase in temperature at regular intervals eliminates the stored ammonia.

The process of keeping accurate ammonia storage amounts is by counting urea injection quantities from the Dosing Control Unit (DCU).

The SCR active symbol (Figure 101) will be displayed on the Deep Sea controller during operation when either an **automatic** or **forced** system purge operation is in process.



Figure 101. SCR Symbol

### NOTICE

During urea SCR system purging, **white smoke** may be temporarily emitted from the exhaust tailpipe. This should not be considered a failure. In addition, the smell of **ammonia** during the purging process should not be considered a failure.

If the purging process is underway while running a light load (0–30%) the unit may produce unusual sounds. This should not be considered a failure or malfunction.

## SCR SYSTEM PURGE GUIDELINES

### Auto Purge Operation

The **auto purge** operation process will be performed automatically. No operator intervention is required.

### Forced Purge Operation

When an auto purge operation has failed, the engine will require a **forced purge** to be induced. A qualified technician must be on-site with an Isuzu **Diagnostic Service Tool** (IDST) tool to perform the operation.

Once the engine has reached the proper operating temperature, the **Diesel Particulate Diffuser** (DPD) mode will display 80. Press the start button on the Deep Sea controller to begin the regeneration process.

### NOTICE

**DO NOT** perform purging in conditions where it may be unsafe due to high exhaust temperatures.






For safe operation of equipment, safety of the surrounding area, and the prevention of bodily harm, use the guidelines below when system purging is required:

### NOTICE

The area above and around the generator during the purging process should be free of any type of debris, flammable or combustible materials, as temperatures during the purging process can reach as high 1,022°F (550°C).

- **DO NOT** operate the unit in an area with poor ventilation.
- If operating the engine indoors, install exhaust/ventilation equipment and ensure that there is sufficient ventilation.
- If you begin to feel sick, stop the unit immediately and ventilate the area.
- Due to the exhaust emission reduction functions of the exhaust system, exhaust emissions from the tailpipe have a different smell from those emitted from engines without urea SCR systems.

Shown below in Table 17 are the regeneration symbols. These symbols show the various ECU functions. The symbols flash at different rates to show the status of the ECU function. For more detailed information refer to the engine manufacturer owners manual.

Table 17. Engine Symbols	
SYMBOL	DESCRIPTION
	<b>Check Engine Symbol (Yellow)</b> This symbol is displayed when an engine fault occurs. Check active <b>Diagnostic Trouble Codes</b> (DTC).
	<b>Check Engine Symbol (Red)</b> This symbol is displayed when an engine fault occurs. The engine will undergo an emergency stop. Check active <b>Diagnostic Trouble Codes</b> (DTC).
	<b>HEST Symbol</b> This symbol indicates that the <b>High Exhaust System Temperature</b> is active.
	<b>DEF Warning Symbol</b> This symbol is displayed when the DEF tank level is low (less than 10%) or the DEF quality is poor. Refer to the Diesel Exhaust Fluid (DEF) Maintenance section for more information.
	<b>SCR Purge Symbol</b> This symbol is displayed during both automatic and forced purge operation.

## DIESEL EXHAUST FLUID (DEF)

If the **diesel exhaust fluid** (DEF) symbol (Figure 102) is displayed during Deep Sea controller operation, it indicates the following:


- DEF tank level is below 10%.
- DEF quality is poor. Check DEF tank level and check active **diagnostic trouble codes** (DTC).



**Figure 102. DEF Level Symbol**

The amount of fluid in the DEF tank will be displayed on the Deep Sea controller screen (Figure 103)

From the main status screen, press the **right arrow button once** and verify that the "Engine" screen is displayed, then press the **down arrow button sixteen times** and verify that the engine's DEF tank level screen is displayed.



**Figure 103. DEF Tank Level Screen**

### NOTICE

The unit will enter emergency shutdown when the DEF level has reached 0% and emergency protective measures are necessary. When this condition occurs, inspection and repair should generally be performed promptly.

### NOTICE

**Inducement**-when the system senses improper usage such as no supply of DEF, use of poor quality DEF, problems with DEF jets, or disconnection of sensors, a warning will be issued before the situation becomes critical. If the warnings are ignored and the unit enters intermittent operation, the emergency shutdown will activate.

## PROTECTION DEVICES

### Automatic Shutdown System

This unit is equipped with engine protection devices that automatically shut down the engine. If any of the faults shown in Table 18 occur. A message will be displayed on the Deep Sea controller screen indicating the cause of the shutdown.

After the automatic shutdown, check all Diagnostic Trouble Codes (DTC) displayed on the Deep Sea controller screen. Reference the Troubleshooting (Diagnostics) section in this manual.

Before attempting to restart the generator, press the **OFF** button on the Deep Sea controller and place all circuit breakers in the **OFF** position.

Allow sufficient time for adequate cooling of the generator before troubleshooting. Perform an overall inspection of the generator and correct the problem that caused the shutdown before restarting the generator. If necessary, contact Discount-equipment for additional technical support.

Restart the generator as referenced in the Generator Startup Procedure (Manual Start).

#### NOTICE

Although the unit is equipped with engine protection devices, regularly scheduled **preventative maintenance** is strongly advised.

**Table 18. Automatic Engine Shutdown System**

Operating Parameter	Operating Condition/Set Point
Low Oil Pressure <sup>1</sup>	Set Point: 14.2 psi (98 kPa)
High Water Temperature	Set Point: 212°F (100°C)
Low Coolant Level	Falls Below Specified Level
Exhaust System Severe Malfunction	Reference Exhaust System, DEF, Regeneration Sections
Over Voltage	Set Point: 110%
Under Voltage	Set Point: 75%
High Power (kW)	Set Point: 115%
Over Frequency (Hz)	Set Point: 110%
Under Frequency (Hz)	Set Point: 90%
Overspeed	Approximately +15%
Over Current <sup>2</sup>	Load Capacity Exceeded
<sup>1</sup> Reference Deep Sea controller screen for cause of shutdown with associated DTC.	
<sup>2</sup> Main circuit breaker will trip.	

## TROUBLESHOOTING (GENERATOR)

Practically all breakdowns can be prevented by proper handling and maintenance inspections, but in the event of a breakdown, use Table 19 shown below for diagnosis of the generator. If the problem cannot be remedied, consult Discount-equipment.

Table 19. Generator Troubleshooting		
Symptom	Possible Problem	Solution
No Voltage Output	AC Voltmeter defective?	Check output voltage using a voltmeter.
	Is wiring connection loose?	Check wiring and repair.
	Is AVR defective?	Replace if necessary.
	Defective Rotating Rectifier?	Check and replace.
	Defective Exciter Field?	Check for approximately 19 ohms across J & K on CN1.
Low Voltage Output	Is engine speed correct?	Place engine throttle engine speed switch in "High" position.
	Is wiring connection loose?	Check wiring and repair.
	Defective AVR?	Replace if necessary.
High Voltage Output	Is wiring connection loose?	Check wiring and repair.
	Defective AVR?	Replace if necessary.
Circuit Breaker Tripped	Short Circuit in load?	Check load and repair.
	Over current?	Confirm load requirement and reduce.
	Defective circuit breaker?	Check and replace.
	Overcurrent Relay actuated?	Confirm load requirement and replace.




## TROUBLESHOOTING (ENGINE)

Troubleshooting (Engine)		
Symptom	Possible Problem	Solution
Engine will not start or start is delayed, although engine can be turned over.	No fuel reaching injection pump?	Add fuel. Check entire fuel system.
	Defective fuel pump?	Replace fuel pump.
	Fuel filter clogged?	Replace fuel filter and clean tank.
	Faulty fuel supply line?	Replace or repair fuel line.
	Compression too low?	Check piston, cylinder and valves. Adjust or repair per engine repair manual.
	Fuel pump not working correctly?	Repair or replace fuel pump.
	Oil pressure too low?	Check engine oil pressure.
	Low starting temperature limit exceeded?	Comply with cold starting instructions and proper oil viscosity.
	Defective battery?	Charge or replace battery.
	Air or water mixed in fuel system?	Check carefully for loosened fuel line coupling, loose cap nut, etc.
At low temperatures engine will not start.	Engine oil too thick?	Refill engine crankcase with correct type of oil for winter environment.
	Defective battery?	Replace battery.
Engine fires but stops as soon as starter is switched off.	Fuel filter blocked?	Replace fuel filter.
	Fuel supply blocked?	Check the entire fuel system.
	Defective fuel pump?	Replace fuel pump.
Engine stops by itself during normal operation.	Fuel tank empty?	Add fuel.
	Fuel filter blocked?	Replace fuel filter.
	Defective fuel pump?	Replace fuel pump.
	Mechanical oil pressure shutdown sensor stops the engine due to low oil?	Add oil. Replace low oil shutdown sensor if necessary.
Low engine power, output and speed.	Fuel tank empty?	Add fuel.
	Fuel filter clogged?	Replace fuel filter.
	Fuel tank venting is inadequate?	Ensure tank is adequately vented.
	Leaks at pipe unions?	Check threaded pipe unions. Tape and tighten unions as required.
	Speed control lever does not remain in selected position?	See engine manual for corrective action.
	Engine oil level too full?	Correct engine oil level.
	Injection pump wear?	Use No. 2-D diesel fuel only. Check the fuel injection pump element and delivery valve assembly and replace as necessary.

## TROUBLESHOOTING (ENGINE)

Troubleshooting (Engine) - continued		
Symptom	Possible Problem	Solution
Low engine power output and low speed, black exhaust smoke.	Air filter blocked?	Clean or replace air filter.
	Incorrect valve clearances?	Adjust valves per engine specification.
	Malfunction at injector?	See engine manual.
Engine overheats.	Too much oil in engine crankcase?	Drain off engine oil down to upper mark on dipstick.
	Entire cooling air system contaminated or blocked?	Clean cooling air system and cooling fin areas.
	Fan belt broken or elongated?	Change belt or adjust belt tension.
	Coolant insufficient?	Replenish coolant.
	Radiator net or radiator fin clogged with dust?	Clean net or fin carefully.
	Fan, radiator, or radiator cap defective?	Replace defective part.
	Thermostat defective?	Check thermostat and replace if necessary.
	Head gasket defective or water leakage?	Replace parts.

# GENERATOR WIRING DIAGRAM (EE62815)




SYMBOL	DESIGNATION
Ar	MAIN GENERATOR ARMATURE WINDING
Fg	MAIN GENERATOR FIELD WINDING
ExAr	EXCITER ARMATURE WINDING
ExFg	EXCITER FIELD WINDING
Re	RECTIFIER
AVR	AUTOMATIC VOLTAGE REGULATOR
CT 1,2,3	CURRENT TRANSFORMER 150: 5A
CB1	CIRCUIT BREAKER, 3P 200A
CB2, 3, 4	CIRCUIT BREAKER, 2P 50A
CB5, 6	CIRCUIT BREAKER, 1P 20A
CON 1, 2, 3	RECEPTACLE, CS6369, 250 VAC @ 50 AMPS
CON 4, 5	RECEPTACLE, GFCI, 125 VAC @ 20 AMPS X 2
OC	OVER CURRENT RELAY
SW	SELECTOR SWITCH
RY1-RY2	RELAY UNIT
CB7-CB8	CIRCUIT BREAKER, 3P 10A
CB9	CIRCUIT BREAKER, 2P 10A
CONTACTOR	CONTACTOR, UL ABB AF40, 240 COIL

CURRENT TRANSFORMERS (CT1 ~ 3)	
REF. DES.	MARK AT CT
k	X1
I	NO MARK
K	H1
L	NO MARK

NOTE: EACH CABLE IS PASSED TWICE THROUGH CURRENT TRANSFORMERS CT1, CT2 AND CT3.

**CONNECTOR ARRANGEMENT  
(WIRING VIEW)**




WIRE SIZE	CODE/WIRE COLOR			
22: 22 mm <sup>2</sup>	B	BLACK	R	RED
14: 14 mm <sup>2</sup>	L	BLUE	W	WHITE
5.5: 5.5 mm <sup>2</sup>	BR	BROWN	Y	YELLOW
2: 2 mm <sup>2</sup>	G	GREEN	LB	LIGHT BLUE
	GR	GRAY	LG	LIGHT GREEN
	V	VIOLET	O	ORANGE
	P	PINK		


WITH NO DESIGNATION USE WIRE SIZE 1.25 mm<sup>2</sup>  
WITH DESIGNATED COLOR

# ENGINE WIRING DIAGRAM (EE62814)

## ENGINE WIRING DIAGRAM EE62814



# BATTERY CHARGER WIRING DIAGRAM



## NOTES:

- 1 INLET RECEPTACLE & CORD, NEMA 5-15P, 15 AMP, 125V, P/N EE62076
- 2 RECEPTACLE IS MOUNTED ON OUTPUT TERMINAL PANEL ASSY.

**TO PURCHASE THIS PRODUCT PLEASE CONTACT US**



**Equipment Financing and  
Extended Warranties Available**



**Discount-Equipment.com is your online resource for  
commercial and industrial quality parts and equipment sales.**

**561-964-4949**

**visit us on line @ [www.discount-equipment.com](http://www.discount-equipment.com)**

Select an option below to find your Equipment

**Search by Manufacturer**

**Search by Product Type**

**Request a Quote**

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar