


# ***Operator's Manual***



# **TB37**

P/N 0172094  
February, 2001

# ***Snorkel***

---

# DANGER

---

**The aerial platform is not electrically insulated. Death or serious injury can result from contact with, or inadequate clearance from, an energized conductor.**

**Do not go closer than the minimum safe approach distance as defined by the Minimum Safe Approach Distance section in Chapter 3–Safety.**

Regard all conductors as energized.

Allow for electrical wire sag and aerial platform sway.

If the platform, booms, or any part of the aerial platform contacts a high-voltage electrical conductor, the entire machine can become electrically charged.

If that happens, remain on the machine and do not contact any other structure or object. This includes the ground, adjacent buildings, poles, and any other objects that are not part of the aerial platform.

Such contact could make your body a conductor to the other object, creating an electrical shock hazard resulting in death or serious injury.

If an aerial platform is in contact with an energized conductor the platform operator must warn ground personnel in the vicinity to stay away. Their bodies can conduct electricity creating an electrical shock hazard resulting in death or serious injury.

Do not approach or leave the aerial platform until the electricity has been turned off.

Do not attempt to operate the lower controls when the platform, booms, or any part of the aerial platform is in contact with a high-voltage electrical conductor or if there is an immediate danger of such contact.

Personnel on or near an aerial platform must be continuously aware of electrical hazards, recognizing that death or serious injury can result from contact with an energized conductor.

## CALIFORNIA

### Proposition 65 Warning

Battery posts, terminals and related accessories contain lead and lead components, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

## CALIFORNIA

### Proposition 65 Warning

Diesel and gasoline engine exhaust and some of its constituents are known by the State of California to cause cancer, birth defects or other reproductive harm.

# Table of Contents

## Chapter 1. Introduction

---

Aerial Platform Features . . . . .	1-1
Options . . . . .	1-1
Operator's Manual . . . . .	1-1
Safety Alerts . . . . .	1-1
Notes . . . . .	1-2
Operation . . . . .	1-2
Maintenance . . . . .	1-2
Manual of Responsibilities . . . . .	1-2
Additional Information . . . . .	1-2

## Chapter 2. Specifications

---

Component Identification . . . . .	2-1
Working Envelope . . . . .	2-2
General Specifications . . . . .	2-3
Engine Specifications . . . . .	2-4
Engine Oil Viscosity . . . . .	2-4

## Chapter 3. Safety

---

Electrocution Hazards . . . . .	3-1
Minimum Safe Approach Distance . . . . .	3-1
Prestart Inspection . . . . .	3-2
Work Place	
Inspection and Practices . . . . .	3-2
Operation . . . . .	3-2
Tip-Over and Falling Hazards . . . . .	3-2
Electrical System . . . . .	3-3
Hydraulic System . . . . .	3-3
Engine and Fuel	
Handling Precautions . . . . .	3-3
Placards and Decals . . . . .	3-4

## Chapter 4. Safety Devices

---

Emergency Stop Controls . . . . .	4-1
Emergency Power System . . . . .	4-1
Emergency Lowering Knob . . . . .	4-1
Ground Controls Switch . . . . .	4-2
Platform Foot Switch . . . . .	4-2
Guardrails . . . . .	4-2
Lanyard Anchors . . . . .	4-2
Ground Fault Circuit Interrupter . . . . .	4-2
Tilt Alarm . . . . .	4-2
Engine Protection Systems . . . . .	4-2
High Engine Temperature Alarm . . . . .	4-3
Low Oil Pressure Alarm . . . . .	4-3
Horn . . . . .	4-3
Drive Motion Alarm . . . . .	4-3
Flashing Light . . . . .	4-3
Driving Lights . . . . .	4-3
Platform Work Lights . . . . .	4-3

## Chapter 5. Gauges and Displays

---

Hour Meter . . . . .	5-1
Engine Temperature Gauge . . . . .	5-1
Ammeter . . . . .	5-1

Engine Air Filter Gauge . . . . .	5-1
Fuel . . . . .	5-1
Engine Oil . . . . .	5-2
Hydraulic Fluid Filter Gauge . . . . .	5-2
Fluid Level and Temperature Gauge . . . . .	5-2

## Chapter 6. Controls

---

Battery Disconnect Switch . . . . .	6-1
Lower Controls . . . . .	6-1
Start Switch . . . . .	6-1
Emergency Stop Switch . . . . .	6-1
Controls Switch . . . . .	6-1
Ground Controls Switch . . . . .	6-1
Rotation Switch . . . . .	6-2
Boom Elevation Switch . . . . .	6-2
Boom Switch . . . . .	6-2
Platform Level Switch . . . . .	6-2
Platform Rotator Switch . . . . .	6-2
Engine/Emergency Power Switch . . . . .	6-2
Throttle Switch . . . . .	6-2
Fuel Switch . . . . .	6-2
Circuit Breaker Reset Buttons . . . . .	6-2
Upper Controls . . . . .	6-3
Anti-Restart Master Switch . . . . .	6-3
Emergency Stop Button . . . . .	6-3
Speed Knob . . . . .	6-3
Swing Switch . . . . .	6-3
Boom Up/Down Switch . . . . .	6-3
Boom Extend/Retract Switch . . . . .	6-4
Level Switch . . . . .	6-4
Steer Switch . . . . .	6-4
Drive Joystick . . . . .	6-4
Drive Range Switch . . . . .	6-4
Engine/Emergency Power Switch . . . . .	6-4
Throttle Switch . . . . .	6-4
Platform Rotator Switch . . . . .	6-4
Horn Button . . . . .	6-4
Platform Foot Switch . . . . .	6-4
Machine/Generator Switch . . . . .	6-5
Dual Fuel . . . . .	6-5
Driving and Platform Work Lights . . . . .	6-5

## Chapter 7. Prestart Inspection

---

Operator's Manual . . . . .	7-1
Engine . . . . .	7-1
Oil Level . . . . .	7-1
Coolant . . . . .	7-1
Radiator . . . . .	7-1
Fuel Tank . . . . .	7-2
Fuel Line . . . . .	7-2
Air Filter . . . . .	7-2
Charging System . . . . .	7-2
Cold Weather Start Kit—Block Heater . . . . .	7-3

# Table of Contents

---

Electrical System	7-3
Emergency Power Battery	7-3
Battery Fluid Level	7-3
Battery Terminals	7-3
Cables and Wiring Harness	7-3
Hydraulic System	7-4
Fluid Level	7-4
Fluid Filter	7-4
Hoses, Tubes, and Fittings	7-4
Tires and Wheels	7-4
Air Filled	7-5
Foam Filled	7-5
Lower Control Station	7-5
Operating Controls	7-5
Emergency Stop	7-5
Emergency Power	7-5
Emergency Lowering	7-6
Level Sensor	7-6
Flashing Light	7-6
Sandblast Protection Kit	7-6
Structures	7-7
Weldments	7-7
Slide Pads	7-7
Fasteners	7-7
Upper Control Station	7-7
Guardrail System	7-7
Lanyard Anchors	7-8
Operating Controls	7-8
Emergency Stop	7-8
Emergency Power	7-8
Horn	7-8
Electrical Power Outlet	7-8
Drive Motion Alarm	7-9
Driving and Work Lights	7-9
Platform Control Cover	7-9
Tow Kit	7-9
Placards and Decals	7-9
Prestart Inspection Check List	7-13

## Chapter 8. Operation

---

Cold Weather Start-Up	8-1
Engine Cold Weather Start Kit	8-1
Ford—Block Heater	8-1
Deutz—Manifold Preheater	8-1
Hydraulic System	
Cold Weather Warm-Up	8-1
Preparing for Operation	8-2
Lower Controls	8-2
Upper Controls	8-2
Boom Operation	8-2
Driving and Steering	8-3
Drive Speeds	8-3
Four-Wheel Drive	8-4
Electrical Power Outlet	8-4
AC Generator	8-4
Dual Fuel	8-4
Driving Lights	8-4
Platform Work Lights	8-5

## Chapter 9. Stowing and Transporting

---

Stowing	9-1
Transporting	9-1
Driving	9-1
Winching	9-2
Hoisting	9-2
Securing for Transport	9-3

## Chapter 10. Emergency Operation

---

Emergency Power System	10-1
Lower Controls	10-1
Upper Controls	10-1
Emergency Lowering	10-2
Towing	10-2

## Chapter 11. Troubleshooting

---

Troubleshooting Chart	11-1
-----------------------	------

## Appendix A. Glossary

---

# Chapter 1. Introduction

## Aerial Platform Features

The aerial platform is a boom-supported elevating work platform used to raise personnel, their tools, and material to the workstation. The booms are raised and lowered with hydraulic cylinders. Hydraulic motors on the drive wheels provide power to move the aerial platform.

The standard machine includes the following features.

- Proportional drive control
- Pneumatic tires
- Gasoline liquid cooled engine
- High engine temperature shut down
- Low oil pressure shut down
- Hour meter
- Ammeter
- Coolant temperature gauge
- Hydraulic oil level and temperature gauges
- Battery operated emergency power system
- Manual lowering valve
- Tilt alarm
- 360° continuous turntable rotation
- Tie-down lugs
- Lifting lugs
- AC electrical outlet with GFCI at platform
- 5' steel 600 lb capacity platform
- Gravity gate
- Five year warranty

The aerial platform has been manufactured to conform to all applicable requirements of the following organizations.

- Occupational Safety and Health Administration (OSHA)
- American National Standards Institute (ANSI)
- Canadian Standards Association (CSA)

## Options

The following options may be provided on the machine.

- Four-wheel drive
- Road tread tires
- Foam filled tires
- Drive motion alarm
- Diesel air cooled engine
- Dual fuel with 12 gallon gasoline tank
- Dual fuel with 20 gallon gasoline tank

- Flashing light
- Driving lights
- Platform work lights-flood or halogen
- Horn
- Platform control cover
- Swinging platform gate
- 8' aluminum 600 lb capacity platform
- 8' aluminum 600 lb capacity platform with guardrails
- 8' steel 500 lb capacity platform
- 5' aluminum 650 lb platform
- 5' steel 600 lb platform
- Sandblast protection kit
- Cold weather start kit
- Tow kit
- AC generator

## Operator's Manual

This manual provides information for safe and proper operation of the aerial platform. Because it covers more than one model, some figures may only represent what is actually on the machine. Read and understand the information in this Operator's Manual before operating the aerial platform on the job.

Additional copies of this manual may be ordered from Snorkel. Supply the model and manual part number from the front cover to assure that the correct manual will be supplied.

All information in this manual is based on the latest product information at the time of publication. Snorkel reserves the right to make product changes at any time without obligation.

## Safety Alerts

A safety alert symbol is used throughout this manual to indicate danger and caution instructions. Follow these instructions to reduce the likelihood of personal injury and property damage. The terms danger and caution indicate varying degrees of personal injury or property damage that can result if the instruction is not followed.

### **▲ DANGER**

**Indicates a situation which if not avoided can result in death or serious injury.**

### **▲ CAUTION**

**Indicates a situation which if not avoided can result in minor injury or property damage.**

# Chapter 1. Introduction

---

## Notes

Notes are used to provide special information or helpful hints to assist in aerial platform operation, but do not indicate a hazardous situation.

## Operation

The aerial platform has built-in safety features and has been factory tested for compliance with Snorkel specifications and industry standards. However, any personnel lifting aerial platform can be potentially dangerous in the hands of untrained or careless operators.

### **▲ DANGER**

**The potential for an accident increases when the aerial platform is operated by personnel who are not trained and authorized. Death or serious injury can result from such accidents. Read and understand the information in this manual and on the placards and decals on the machine before operating the aerial platform on the job.**

Training is essential and must be performed by a qualified person. Become proficient in knowledge and actual operation before using the aerial platform on the job. You must be trained and authorized to perform any functions of the aerial platform. Operation of the aerial platform must be within the scope of the machine specifications.

The operator bears ultimate responsibility for following all manufacturer's instructions and warnings, regulations and safety rules of their employer and/or any state or federal law.

## Maintenance

Every person who maintains, inspects, tests, or repairs the aerial platform must be qualified to do so. Following the daily prestart inspection in this Operator's Manual will help keep the aerial platform in optimum working

condition. Other maintenance functions must be performed by maintenance personnel who are qualified to work on the aerial platform.

Do not modify this aerial platform without prior written consent of the Snorkel Engineering Department. Modification may void the warranty, adversely affect stability, or affect the operational characteristics of the aerial platform.

## Manual of Responsibilities

All owners and users of the aerial platform must read, understand, and comply with all applicable regulations. Ultimate compliance to OSHA regulations is the responsibility of the user and their employer.

ANSI publications clearly identify the responsibilities of all personnel who may be involved with the aerial platform. A reprint of the "Manual of Responsibilities for Dealers, Owners, Users, Operators, Lessors and Lessees of ANSI/SIA A92.5-1992 Boom-Supported Elevating Work Platforms" is available from Snorkel dealers or from the factory upon request.

Copies are also available from:

Scaffold Industry Association  
20335 Ventura Blvd. Suite 310  
Woodland Hills, CA 91364-2471 USA

## Additional Information


For additional information contact your local dealer or Snorkel at:

Snorkel International, Inc.  
P.O. Box 1160  
St. Joseph, MO 64502-1160 USA  
816-364-0317


<http://www.snorkelusa.com>

## Chapter 2. Specifications

### Component Identification



## Working Envelope





## General Specifications

### Aerial Platform

Working height	43' (13.1 m)
Maximum platform height	37' (11.3 m)
Horizontal reach	32' (9.8 m)
Main boom	
Articulation	-18° to +75°
Extension	12' (3.6 m)
Turntable rotation	360° continuous
Turning radius, inside	5' 2" (1.6 m)
Wheelbase	8' (2.4 m)
Ground clearance	10" (25 cm)
Maximum wheel load	5,500 lbs (2,495 kg)
Maximum ground pressure	54 psi (3.8 kg/cm <sup>2</sup> )
Weight, GVW	
Approximate	10,500 lbs (4,763 kg)
Stowed width	7' 11.5" (2.4 m)
Stowed length	26' 2" (8 m)
Stowed height	7' 6" (2.3 m)

### Platform

Dimensions	
Standard	30" x 60" (76 cm x 152 cm)
Optional	30" x 96" (76 cm x 244 cm)
Guardrail height	30" x 96"
Rated work load	
Standard	600 lb (272 kg)
Optional	500 lb (227 kg)
Optional	650 lb (295 kg)
Rotation	180°
Maximum number of occupants	2 people
Optional AC generator	120 V, 17.4 amp

### Function Speed

Turntable rotation	90 to 100 seconds
Main boom	
Up	40 to 45 seconds
Down	40 to 45 seconds
Extend	35 to 45 seconds
Retract	30 to 40 seconds
Platform rotation	16 to 20 seconds
Drive	
High, booms stowed	3.0 mph (4.8 km/h)
Low, booms elevated	1.0 mph (1.6 km/h)

### Drive System

Standard	2-wheel drive
Optional	4-wheel drive
Gradeability	25%

### Tires, 10 ply

Pneumatic	12" x 16.5" (30 cm x 42 cm)
Flotation	15" x 19.5" (38 cm x 50 cm)
Foam filled	Pneumatic or Flotation

### Electrical System

Voltage	12 V DC negative chassis ground
Source	
Gas engine	1 - 12 V 600 CCA battery
Diesel engine	2 - 12 V 600 CCA batteries
Fluid recommended	distilled water

### Hydraulic System

Maximum pressure	2,500 psi (17,237 kPa)
Reservoir capacity	16.5 US gal (62.4 l)
System capacity	20 US gal (75.7 l)
Maximum operating temperature	200°F (93°C)
Hydraulic fluid recommended	
Above 10°F (-13°C)	Mobil DTE-13M (ISO VG32)
Below 10°F (-13°C)	Mobil DTE-11M (ISO VG15)

### Engine

Gasoline and/or LPG	Ford VSG-413
Diesel	Deutz F3L-1011

### Fuel Tank Capacity

Gasoline or diesel	20 US gal (75.7 l)
LPG	43.5 lbs (19.7 kg)
Dual fuel gasoline	20 US gal (75.7 l) 12 US gal (45.4 l)

### Ambient Air Temperature Operating Range

Fahrenheit	0°F to 110°F
Celsius	-18°C to 43°C

### Maximum Wind Speed

Gust or steady	28 mph (45 km/h)
----------------	------------------


# Chapter 2. Specifications

## Engine Specifications

	Ford VSG-413		Deutz F3I-1011
Fuel type	Gasoline	LPG	Diesel
Fuel grade	Unleaded gasoline 87 octane  Do not use gasoline blends with more than 5% methanol by volume, or blends that do not contain cosolvents and corrosion inhibitors.	Commercial LP gas	<ul style="list-style-type: none"> <li>• DIN 51 601 (February 1986)</li> <li>• BS 2869: A1 and A2 (with A2 refer to Deutz manual about sulfur content)</li> <li>• ASTM D 975-88: 1-D and 2-D</li> <li>• CEN EN 590 or DIN EN 590</li> <li>• NATO Code F-54 and F-75</li> <li>• For operating temperatures below 32°F (0°C) use winter grade diesel.</li> </ul>
Displacement	79.3 cu. in. (1,300 cc)		125 cu. in. (2,049 cc)
Coolant	50% water/50% anti-freeze (ethelene glycol)		Air
Operating temperature	160°F (71°C) to 190°F (88°C)		172°F (78°C) to 203°F (95°C)
Oil capacity	3.5 qt USA (3.25 l)		1.59 U.S. gal. (6.0 l)
Oil grade	API: SG, SG/CC or SG/CD		API: CD grades or higher
Oil viscosity	See Engine Oil Viscosity		
Running time	One full tank of gas, diesel, or LPG will last for eight hours under normal working conditions.		

## Engine Oil Viscosity

**Ford VSG-413**




Single Viscosity

Multi Viscosity

Note: Not recommended for severe service, including high RPM operation.

**Deutz F3I-1011**



Only with engine oil preheating.

## Chapter 3. Safety

Knowledge of the information in this manual, and proper training, provide a basis for safely operating the aerial platform. Know the location of all controls and how they operate to act quickly and responsibly in an emergency.

Safety devices reduce the likelihood of an accident. Never disable, modify, or ignore any safety device. Safety alerts in this manual indicate situations where accidents may occur.

If any malfunction, hazard or potentially unsafe condition relating to capacity, intended use, or safe operation is suspected, stop aerial platform operation and seek assistance.

The operator bears ultimate responsibility for following all manufacturer's instructions and warnings, regulations and safety rules of their employer and/or any state or federal law.

### Electrocution Hazards

The aerial platform is made of metal components and is not insulated. Regard all conductors as energized. Do not operate outside during a thunderstorm.

### Minimum Safe Approach Distance

Minimum safe approach distances to energized power lines and their associated parts must be observed while operating the aerial platform.

### ▲ DANGER

**The aerial platform is not electrically insulated. Death or serious injury can result from contact with, or inadequate clearance from, an energized conductor. Do not go closer than the minimum safe approach distance as defined by ANSI.**

ANSI publications define minimum distances that must be observed when working near bus bars and energized power lines. Table 1 and Figure 3 are reprinted courtesy of Scaffold Industry Association, ANSI/SIA A92.5, page 23.

Voltage range (phase to phase)	Minimum safe approach distance	
	(Feet)	(Meters)
0 to 300V	Avoid contact	
Over 300V to 50kV	10	3.05
Over 50kV to 200kV	15	4.60
Over 200kV to 350kV	20	6.10
Over 350kV to 500kV	25	7.62
Over 500kV to 750kV	35	10.67
Over 750kV to 1000kV	45	13.72

Table 1—Minimum Safe Approach Distance




Figure 3—Minimum Safe Approach Distance

### Prestart Inspection

Perform a prestart inspection before each shift as described in Chapter 7. Do not use the aerial platform on the job unless you are trained and authorized to do so.

### Work Place Inspection and Practices

Do not use the aerial platform as a ground connection when welding. The welding ground clamp must be attached to the same structure that is being welded. Electrical current flow can be very intense, causing serious internal damage to some components.

Inspect the area before and during aerial platform use. The following are some potential hazards that may be in the work place.

- Debris
- Slopes
- Drop-offs or holes
- Bumps and floor obstructions
- Overhead obstructions
- Unauthorized persons
- High voltage conductors
- Wind and weather conditions
- Inadequate surface and support to withstand load forces applied by the aerial platform in all operating configurations

Before using the aerial platform in any hazardous (classified) location, make certain it is approved and of the type required by ANSI/NFPA 505 for use in that particular location.

Know and understand the job site traffic-flow patterns and obey the flagmen, road signs, and signals.

While operating the aerial platform, a good safety practice is to have qualified personnel in the immediate work area to:

- Help in case of an emergency
- Operate emergency controls as required
- Watch for loss of control by platform operator
- Warn the operator of any obstructions or hazards that may not be obvious to them
- Watch for soft terrain, sloping surfaces, drop-offs, etc. where stability could be jeopardized
- Watch for bystanders and never allow anyone to be under, or to reach through the booms while operating the aerial platform

### ▲ DANGER

**Pinch points may exist between moving components. Death or serious injury can result from becoming trapped between components, buildings, structures, or other obstacles. Make sure there is sufficient clearance around the machine before moving the chassis, booms, or platform. Allow sufficient room and time to stop movement to avoid contact with structures or other hazards.**

Always look in the direction of movement. Drive with care and at speeds compatible with the work place conditions. Use caution when driving over rough ground, on slopes, and when turning. Do not engage in any form of horseplay or permit riders any place other than in the platform.

Secure all accessories, containers, tools, and other materials in the platform to prevent them from accidentally falling or being kicked off the platform. Remove all objects that do not belong in or on the aerial platform.

Never steady the platform by positioning it against another platform. Do not use boards, or other temporary means to support or level the aerial platform.

Do not operate the aerial platform if it is damaged or not functioning properly. Qualified maintenance personnel must correct the problem before putting the aerial platform back into service.

### Operation

Use three points of support when entering or exiting the platform. For example, use two hands and one foot when climbing into the platform.

Never cover the platform floor grating or otherwise obstruct your view below. Make sure the area below the platform is free of personnel before lowering.

Keep both feet positioned firmly on the platform floor. Operate the controls slowly and deliberately to avoid jerky and erratic operation. Always stop the controls in neutral before going in the opposite direction.

Do not dismount while the aerial platform is in motion or jump off the platform.

Properly stow the aerial platform and secure it against unauthorized operation at the end of each work day, before transporting, or if it is left unattended.

### Tip-Over and Falling Hazards

Operate the aerial platform only on a firm, flat, level surface capable of withstanding all load forces imposed by the aerial platform in all operating conditions. Raise the booms only when the aerial platform is on level ground.

**▲ DANGER**

**The aerial platform can tip over if it becomes unstable. Death or serious injury can result from a tip-over accident. Do not drive or position the aerial platform for elevated use near any drop-off, hole, slope, soft or uneven ground, or other tip-over hazard.**

All platform occupants must wear a fall restraint device connected to a lanyard anchor point.

It is best not to transfer from the platform to another structure or from the structure to the platform, unless that is the safest way to do the job. Judge each situation separately taking the work environment into account. If it is necessary to transfer from the platform to another structure the following guidelines apply:

1. Where possible, place the platform over a roof or walking structure to do the transfer.
2. Transfer your anchorage from one structure to the other before stepping across.
3. Remember that you might be transferring to a structure where *personal fall arrest* is required.
4. Use the platform entrance, do not climb over the guardrails.

Do not operate the aerial platform in windy or gusty conditions. Do not add anything to the aerial platform that will increase the wind loading such as billboards, banners, flags, etc.

Never operate the aerial platform without all parts of the guardrail system in place and the gate closed. Make sure that all protective guards, cowlings, and doors are securely fastened.

Do not exceed the platform capacity as indicated on the platform rating placard on the platform. Do not carry loads that extend beyond the platform guardrails without prior written consent from Snorkel.

Do not operate the aerial platform from trucks, trailers, railway cars, floating vessels, scaffolds, or similar equipment unless the application is approved in writing by Snorkel.

Do not use the aerial platform as a crane, hoist, jack, or for any purpose other than to position personnel, tools, and materials.

Do not climb on the guardrails or use ladders, planks, or other devices to extend or increase the work position from the platform.

Take care to prevent rope, electrical cords, and hoses, etc., from becoming caught in or on the aerial platform. If the platform or booms becomes caught on an adjacent structure or other obstacle and is prevented from normal motion, reverse the control to free the platform. If control reversal does not free the platform, evacuate the platform before attempting to free it.

**Electrical System**

Charge the batteries in a well-ventilated area free of flame, sparks, or other hazards that might cause fire or explosion.

Do not operate any of the aerial platform functions while the battery charger is plugged in.

**▲ DANGER**

**Batteries give off hydrogen and oxygen that can combine explosively. Death or serious injury can result from a chemical explosion. Do not smoke or permit open flames or sparks when checking the batteries.**

**Battery acid can damage the skin and eyes. Serious infection or reaction can result if medical treatment is not given immediately. Wear face and eye protection when working near the batteries.**

Batteries contain sulfuric acid that can damage your eyes or skin on contact. Wear a face shield, rubber gloves, and protective clothing when working around batteries. If acid contacts your eyes, flush immediately with clear water and get medical attention. If acid contacts your skin, wash off immediately with clear water.

**Hydraulic System**

The hydraulic system contains hoses with hydraulic fluid under pressure.

**▲ DANGER**

**Hydraulic fluid escaping under pressure can have enough force to inject fluid into the flesh. Serious infection or reaction can result if medical treatment is not given immediately. In case of injury by escaping hydraulic fluid, seek medical attention at once.**

Do not place your hand or any part of your body in front of escaping hydraulic fluid. Use a piece of cardboard or wood to search for hydraulic leaks.

**Engine and Fuel Handling Precautions**

Refer to the engine manufacturer's Operator's Manual for complete information on safe engine operation, maintenance, and specifications.

**▲ DANGER**

**Engine exhaust contains carbon monoxide, a poisonous gas that is invisible and odorless. Breathing engine exhaust fumes can cause death or serious illness. Do not run the engine in an enclosed area or indoors without adequate ventilation.**

Operate dual fuel machines on LPG fuel when indoors to reduce exhaust fumes and carbon monoxide.

## Chapter 3. Safety

---

Be careful not to run the diesel fuel tank empty. Bleed the fuel system if air enters the lines between the tank and the injection pump.

Allow the engine to return to idle before shutting the engine off.

Do not smoke or permit open flames while fueling or near fueling operations.

Never remove the fuel cap or fill the fuel tank while the engine is running or hot. Never allow fuel to spill on hot machine components.

Maintain control of the fuel filler nozzle when filling the tank. Spilled fuel is a potential fire hazard.

Do not fill the fuel tank to capacity. Allow room for expansion.

Clean up spilled fuel immediately.

Tighten the fuel tank cap securely. If the fuel cap is lost, replace it with an approved cap from Snorkel. Use of a non-approved cap without proper venting may result in pressurization of the tank.

Never use fuel for cleaning purposes.

For diesel engines, use the correct fuel grade for the operating season.

### **▲CAUTION**

**Engine coolant escaping under pressure can cause serious burns. Shut the engine off and let it cool before removing the radiator cap.**

Let the engine and radiator cool before adding coolant.

### **Placards and Decals**

The aerial platform is equipped with placards and decals that provide instruction for operation and accident prevention. Do not operate the aerial platform if any placards or decals are missing or not legible.



## Chapter 4. Safety Devices

This aerial platform is manufactured with safety devices, placards, and decals to reduce the likelihood of an accident. For the safety of all personnel, do not disable, modify, or ignore any safety device. Safety devices are included in the daily prestart inspection.

### **▲ DANGER**

**The potential for an accident increases when safety devices do not function properly. Death or serious injury can result from such accidents. Do not alter, disable, or override any safety device.**

If any safety devices are defective, remove the aerial platform from service until qualified maintenance personnel can make repairs.

### Emergency Stop Controls

There is an emergency stop control at the lower and upper controls.

At the lower controls, the emergency stop is a two-position toggle switch with a red safety guard (refer to Figure 4.1). Push the guard down over the toggle switch to disconnect power to all control circuits. Lift the guard and push the toggle switch up to restore power.




Figure 4.1—Lower Controls

#### Note

*The lower controls override the upper controls. If the upper control emergency stop button is engaged, the lower controls can still be used to operate the aerial platform.*

At the upper controls, the emergency stop is a two-position push button (refer to Figure 4.2).

Push the emergency stop button in to disconnect power to all control circuits. Pull the button out to restore power.




Figure 4.2—Upper Controls

### Emergency Power System

The emergency power system includes a back-up pump, motor, and battery. Use this system to operate the boom and turntable functions to lower the platform if the main power system fails due to engine or pump failure.

Hold the emergency power switch (refer to Figure 4.1 and 4.2) down to activate the emergency power system.

The length of time the pump can be operated depends on the capacity of the battery.

### Emergency Lowering Knob

The emergency lowering knob may be used to lower the booms if the engine will not start and the emergency power system will not work. The knob is on the base end of the main boom lift cylinder and can be accessed through the hole to the left of the battery disconnect switch (refer to Figure 4.3).




Figure 4.3—Emergency Lowering Knob

The knob may be turned to open the cylinder bleed down valve for emergency lowering.

## Chapter 4. Safety Devices

### Ground Controls Switch

The ground controls switch (refer to Figure 4.1) prevents boom and platform movement if a control switch on the lower control panel is accidentally moved.

Hold the switch in the controls on position to operate the machine from the lower controls.

### Platform Foot Switch

The platform foot switch (refer to Figure 4.4) prevents boom and platform movement if a control on the upper control panel is accidentally moved.




Figure 4.4—Platform

Step down on the platform foot switch to activate the boom and platform controls.

### Guardrails

The guardrail system includes a top rail, mid rail, and toeboards around the sides of the platform (refer to Figure 4.4).

A gravity gate or an optional swinging gate allows for access to the platform. The gates close automatically after entering or exiting the platform. The gate is part of the guardrail system and must be securely fastened after entering the platform.

### Lanyard Anchors

Two lanyard anchors for fall restraint anchorage are provided below the upper controls at the front of the platform (refer to Figure 4.4).

#### Note

*The lanyard anchors are not for lifting or tying the machine down.*

All personnel in the platform must connect their fall restraint device to a lanyard anchor before raising the plat-

form. Do not use the aerial platform for *personal fall arrest* anchorage.

### Ground Fault Circuit Interrupter

The electrical power outlet (refer to Figure 4.5), at the platform contains a ground fault circuit interrupter (GFCI) to help prevent accidental conductor grounding.




Figure 4.5—Electrical Power Outlet

### Tilt Alarm

If the aerial platform chassis is out of level more than five degrees when the main boom is raised or extended, an alarm will sound.

#### ▲ DANGER

**The aerial platform can tip over if it becomes unstable. Death or serious injury can result from a tip-over accident. Do not drive or position the aerial platform for elevated use near any drop-off, hole, slope, soft or uneven ground, or other tip-over hazard.**

Completely lower and retract the main boom and then drive to a level surface when the tilt alarm sounds.

The tilt alarm is for added protection and does not justify operating on anything other than firm, flat, level surfaces.

### Engine Protection Systems

A constant tone alarm will sound to warn against high engine temperature or low oil pressure.

The engine will shut-down if the operating temperature exceeds a preset level or if the oil pressure is too low for safe operation. An engine temperature gauge is below the lower control panel (refer to Figure 4.6).






Figure 4.6—Engine Gauges

### High Engine Temperature Alarm

If the coolant in a Ford engine exceeds 220°F (140°C) an alarm will sound and the engine will shut off.

If the oil in a Deutz engine exceeds 230°F (110°C) an alarm will sound and the engine will shut off. Any time there is no alternator current being produced, an alarm will sound and the engine will shut off. This prevents high engine temperature if the fan belt breaks.

Do not restart the engine until the condition that caused the overheating has been corrected.

### Low Oil Pressure Alarm

The low oil pressure alarm sounds when the engine oil pressure is near the lower limit for safe engine operation. If the alarm sounds, lower the platform to the ground and then turn the engine off. Do not restart the engine until the condition that caused the low oil pressure has been corrected.

If the engine oil pressure falls below a safe operating value the engine will shut off. The engine can be restarted with low oil pressure, but it will only run a few seconds before it shuts off again.

### Horn

The optional horn may be used to warn personnel on the ground. The horn is operational when the machine is set up for operation from the upper controls.

### Drive Motion Alarm

An optional drive motion alarm may be provided on the machine. When the drive/steer control is moved out of neutral, the alarm sounds to warn personnel in the work area to stand clear.

### Flashing Light

An optional red or amber flashing light may be located on the top of the boom (refer to Figure 4.7). The flashing light warns personnel that the aerial platform is in the area.



Figure 4.7—Flashing Light

The light flashes at about one flash per second when the engine is running.

### Driving Lights

Optional headlights and blinking tail lights may be installed on the machine. The headlights are located on the top of the front cowling. The tail lights are mounted on the sides of the rear cowling.

Driving lights help improve visibility while driving the aerial platform and help others see it too. Driving lights are not for driving on public roadways.

### Platform Work Lights

Optional platform work lights may be located on the top rail of the platform, one on each side of the upper control panel.

Use the platform lights to improve visibility while working aloft in dimly lit areas. Do not use the platform work lights to drive on public roadways.

## Chapter 5. Gauges and Displays

The aerial platform is equipped with several gauges to monitor the condition of the machine before and during operation.

### Hour Meter

The hour meter is located below the lower controls (refer to Figure 5.1). It measures the accumulated engine operating time.




Figure 5.1—Lower Controls

### Engine Temperature Gauge

The temperature gauge is located below the lower control panel (refer to Figure 5.1).

On liquid cooled engines it shows the temperature of the water and antifreeze mixture in the engine block. The gauge on air cooled engines shows the temperature of the engine oil as the oil leaves the filter.

### Ammeter

The ammeter is located below the lower control panel (refer to Figure 5.1). The ammeter displays the level of current flow from the alternator to the batteries.

After the engine has been running for a few minutes under normal operating conditions, the ammeter gauge indicator should read "0."

### Engine Air Filter Gauge

The air filter gauge (refer to Figure 5.2) is located above the lower control panel on the air cleaner. The gauge measures the air pressure between the intake manifold and the air filter.




Figure 5.2—Air Filter Gauge

When the area inside the clear section of the indicator is red, it's time to change the filter element.

### Fuel

The fuel gauge is located on top of the tank (refer to Figure 5.3). The gauge indicates the fluid level in fractions-of-a-full-tank.





Figure 5.3—Gasoline or Diesel Fuel Tank

#### Note

*Do not run a diesel fuel tank empty. Air in the fuel line makes the engine hard to start.*

LPG tanks have a fuel gauge that has two scales. One scale measures the fuel level when the tank is mounted vertical and the other is used when the tank is mounted horizontal (refer to Figure 5.4).




**Figure 5.4—LPG Fuel Gauge**

The LPG tank is mounted horizontally at the rear of the turntable. Read the horizontal scale to determine the fuel level.

### Engine Oil

The engine oil level is measured with a dipstick (refer to Figure 5.5). Oil sump and filter capacities in the engine specification charts are approximate. The dipstick is the only way to accurately determine the engine oil level. The engine oil level should always be between the add and full marks on the dipstick.




**Figure 5.5—Engine Oil Dipstick**

The dipstick is visible behind the lower control panel.

### Hydraulic Fluid Filter Gauge


The fluid filter gauge (refer to Figure 5.6) is located on the return line filter on top the reservoir. The reservoir is behind the door on the right side of the turntable. The gauge indicates the condition of the filter. When the needle on the gauge is in the red zone, it is time to change the filter.



**Figure 5.6—Fluid Filter Gauge**

### Fluid Level and Temperature Gauge

A gauge on the end of the reservoir displays the level and temperature of the hydraulic fluid (refer to Figure 5.7).



**Figure 5.7—Hydraulic Reservoir**

If the temperature rises above 200°F (93°C) stop machine operation and let the fluid cool before resuming operation.

## Chapter 6. Controls

Controls to position the platform are located on the lower control panel on the turntable and on the upper control panel in the platform. Drive controls are located on the upper control panel only.

### Battery Disconnect Switch

The battery disconnect is located behind the door on the right side of the turntable above the battery (refer to Figure 6.1).



Figure 6.1—Battery Disconnect Switch

The battery disconnect removes electrical power from all electrically controlled functions when in the off position. Place the switch in the on position to electrically connect the battery to the electrical system.

### ⚠CAUTION

**Only authorized personnel should operate the aerial platform. Unqualified personnel may cause injury to coworkers or property damage. Lock the battery disconnect switch in the off position before leaving the aerial platform unattended.**

Turn the battery disconnect switch off to prevent unauthorized use of the aerial platform.

### Lower Controls

The lower controls (refer to Figure 6.2) are located on the left side of the turntable. Boom and platform functions can be operated from the lower controls. The following are located on the lower control panel.

- Start switch
- Emergency stop switch
- Controls switch
- Ground controls switch
- Rotation switch
- Boom elevation switch
- Top boom switch
- Boom switch

- Platform level switch
- Platform rotator switch
- Engine/emergency power switch
- Throttle switch
- Fuel switch



Figure 6.2—Lower Controls

### Start Switch

The start switch works like an automobile ignition switch. Hold it at start until the engine starts, then release it to on. If the engine dies, the key must be turned to off before it will go back to start.

An alarm sounds when the switch is turned on to warn others that the machine engine is being started.

### Emergency Stop Switch

The emergency stop is a two-position toggle switch with a red safety guard. Push the red safety guard down over the toggle switch to disconnect power to all control circuits. Lift the guard and push the toggle switch up to the on position to restore power.

### Controls Switch

Use the controls switch to select between lower control and upper control operation. Place the switch in the platform position to operate the aerial platform from the upper controls and in the ground position for lower controls operation.

### Ground Controls Switch

Hold the switch in the on position to operate the machine from the lower controls.

This switch is spring returned to the off position.



## Chapter 6. Controls

### Rotation Switch

The rotation switch is used to rotate the turntable in a clockwise or counterclockwise direction. The switch is spring returned to the center off position.

Hold the switch to the right to rotate the turntable counterclockwise. Hold the switch to the left to rotate the turntable clockwise.

### Boom Elevation Switch

The boom elevation switch is used to raise or lower the main boom. The switch is spring returned to the center off position.

Hold the switch up to raise the main boom. Hold the switch down to lower the main boom.

### Boom Switch

The boom switch is used to extend or retract the tip boom. The switch is spring returned to the center off position.

Hold the switch to the left to extend the tip boom. Hold the switch to the right to retract the tip boom.

### Platform Level Switch

The platform level switch is used to level the platform floor with respect to the ground. The switch is spring returned to the center off position.

Hold the switch up to tilt the platform floor upward or away from the ground. Hold the switch down to tilt the platform floor downward or toward the ground.

### Platform Rotator Switch

The platform rotator switch is used to rotate the platform relative to the end of the tip boom. The switch is spring returned to the center off position.

Hold the switch to the right to rotate the platform counterclockwise. Hold the switch to the left to rotate the platform clockwise.

### Engine/Emergency Power Switch

Hold the emergency power switch down to operate aerial platform functions using the emergency power system. Release the switch to disengage the emergency power system.

#### Note

*The emergency power system is for lowering the platform during an emergency and is not intended for normal machine operation.*

If the engine is running, it will stop when the switch is placed in the emergency power position.

### Throttle Switch

The throttle switch is used to set the engine throttle speed to either low or high idle.

Place the switch in the low position for normal machine operation and in the high position for engine or hydraulic system warm-up.

### Fuel Switch

Engines on machines with the dual fuel option can be operated using gasoline or liquefied petroleum gas (LPG). Dual fuel machines have a gasoline tank behind the door on the right side of the turntable and an LPG tank at the rear of the turntable.

The fuel switch (refer to Figure 6.2) may be used to select between gasoline and LPG operation.

Place the switch up to operate on LPG and down to operate the engine using gasoline.

### Circuit Breaker Reset Buttons

The lower control panel electrical system has a circuit breaker for the main, throttle, and run circuits. There is a reset button for each circuit breaker below the lower control panel (refer to Figure 6.3).




Figure 6.3—Lower Control Gauge Panel

The upper control panel has a circuit breaker for the main and drive circuits. The circuit breakers are on the front of the upper control panel (refer to Figure 6.4).




Figure 6.4—Upper Control Panel Front

The circuit breakers protect the electrical wiring and components from electrical overload in case of a short circuit or other fault.

### ▲CAUTION

**A tripped circuit breaker indicates a malfunction in the electrical system. Component damage can result if the cause of the malfunction is not corrected. Do not operate the aerial platform if the circuit breaker trips repeatedly.**

Push the button to reset the circuit breaker.

## Upper Controls

The upper controls (refer to Figure 6.5) are located on the control panel at the platform. Boom, platform, and drive functions can be operated from the upper controls. The following controls are located on the upper control panel.

- Anti-restart master switch
- Emergency stop button
- Speed knob
- Swing switch
- Boom up/down switch
- Boom extend/retract switch
- Level switch
- Steer switch
- Drive joystick
- Drive range switch
- Engine/emergency power switch
- Throttle switch
- Platform rotator switch




Figure 6.5—Upper Control Panel

### Anti-Restart Master Switch

The machine engine can be started from the platform using the anti-restart master switch on the front of the upper control panel (refer to Figure 6.4).

This switch is similar to an automobile ignition switch. Turn the switch to start until the engine starts, then release it to on. If the engine dies, the switch must be turned to off before it can be turned back to start.

An alarm sounds when the switch is turned on to warn others that the machine engine is being started.

#### Note

*On some machines it may be necessary to pause about three seconds in the on position before going to start so the starter can engage.*

Turn the switch to off to turn the engine off and save fuel if the platform is to stay in a particular position for a long time.

## Emergency Stop Button

The emergency stop is a two-position, red push button on the top of the upper control panel. Push the button in to disconnect power to all control circuits at the upper controls. Pull the button out to restore power.

#### Note

*The lower controls override the upper controls. If the upper control emergency stop button is engaged the lower controls can still be used to operate the aerial platform.*

Push the emergency stop button in when the upper controls are not in use to protect against unintentional operation.

## Speed Knob

Use the boom speed control knob to control the speed of the following boom functions.

- Turntable swing clockwise/counterclockwise
- Main boom raise/lower

Set the knob to slow when beginning a boom movement. The speed may be increased by slowly rotating the knob toward fast. For smooth operation, rotate the knob to slow when ending boom movement.

## Swing Switch

The swing switch is used to rotate the turntable in a clockwise or counterclockwise direction. The switch is spring returned to the center off position.

Hold the switch to the right to rotate the turntable counterclockwise. Hold the switch to the left to rotate the turntable clockwise.

## Boom Up/Down Switch

The boom up/down switch is used to raise or lower the main boom. The switch is spring returned to the center off position.

Hold the switch up to raise the main boom. Hold the switch down to lower the main boom.

## Chapter 6. Controls

### Boom Extend/Retract Switch

The boom extend/retract switch is used to extend or retract the tip boom. The switch is spring returned to the center off position.

Hold the switch down to extend the tip boom. Hold the switch up to retract the tip boom.

### Level Switch

The level switch is used to level the platform floor with respect to the ground. The switch is spring returned to the center off position.

Hold the switch up to tilt the platform floor upward or away from the ground. Hold the switch down to tilt the platform floor downward or toward the ground.

### Steer Switch

The steer switch is used to steer right and left. The switch is spring returned to the center off position. The steering and drive functions may be operated simultaneously.

#### Note

*The steering wheels are not self-centering. Set the steering wheels straight ahead after completing a turn.*

Hold the switch to the right to turn right and to the left to turn left as indicated by the directional arrows on the chassis.

### Drive Joystick

The drive joystick is used to control forward and reverse motion of the aerial platform.

Hold the joystick forward to move the aerial platform forward and backward to move in reverse as indicated by the directional arrows on the chassis.

### Drive Range Switch

The drive range switch has two positions to select drive wheel operation:

- HI—high speed and low torque operation.
- LO—low speed and high torque operation.

### Engine/Emergency Power Switch

Place the switch in the engine position for aerial platform engine operation.

Place the switch in the emergency power position to operate aerial platform functions using the emergency

power system. Place the switch in the off position to disengage the emergency power system.

#### Note

*The emergency power system is for lowering the platform during an emergency and is not intended for normal machine operation.*

If the engine is running, it will stop when the switch is placed in the emergency power position.

### Throttle Switch

The throttle switch is used to set the engine throttle speed to either low or high idle.

Place the switch in the low position for normal machine operation and in high to drive at maximum speed.

### Platform Rotator Switch

The platform rotator switch (refer to Figure 6.6) is used to rotate the platform relative to the end of the tip boom. The switch is spring returned to the center off position.



Figure 6.6—Upper Control Panel Side

Hold the switch to the right to rotate the platform counterclockwise. Hold the switch to the left to rotate the platform clockwise.

### Horn Button

The optional horn button is on the right side of the upper control panel. Press the button to sound the horn.

### Platform Foot Switch

The upper controls are interlocked through the platform foot switch (refer to Figure 6.7). Step down on and hold the platform foot switch to activate the drive and boom functions from the upper controls.




Figure 6.7—Platform

### Machine/Generator Switch

The switch for the optional generator is located on the upper front of the control panel (refer to Figure 6.8).




Figure 6.8—Upper Control Panel Front

With the engine running, place the switch in the generator position to provide electrical power to the electrical outlet at the platform.

Machine functions will not operate while the switch is in the generator position.

### Dual Fuel

Engines on machines with the dual fuel option can be operated using gasoline or liquefied petroleum gas (LPG). Dual fuel machines have a gasoline and an LPG tank on the left side of the chassis.

The switch to select between gasoline and LPG operation is on the lower control panel (refer to Figure 6.9).




Figure 6.9—Lower Controls

Place the switch up to operate on LPG and down to operate the engine using gasoline.

### Driving and Platform Work Lights

The control for the optional driving lights is on the back of each light. Place the switch in the on position to operate the driving lights.

The control for the optional platform work lights is on the back of each light.



## Chapter 7. Prestart Inspection

Potential service and safety problems may be detected by inspecting the aerial platform. This chapter includes information on properly inspecting the aerial platform and includes a prestart inspection check list at the end of the chapter to ensure that no areas are overlooked.

### **▲ DANGER**

**The potential for an accident increases when operating an aerial platform that is damaged or malfunctioning. Death or serious injury can result from such accidents. Do not operate the aerial platform if it is damaged or malfunctioning.**

Perform a prestart inspection at the beginning of each shift, before using the aerial platform on the job. The inspection site must have a smooth and level surface.

### Operator's Manual

The manual holder is located in the engine compartment (refer to Figure 7.2) on the left side of the machine. Make certain it is securely fastened in place.




Figure 7.2—Operator's Manual Holder

Check to see that the proper Operator's Manual is in the holder. The manual should be complete with all pages intact and in readable condition.

### Engine

Open the engine compartment doors on both sides of the machine and visually inspect the engine and its components with the engine off.

#### Oil Level

Check the engine oil level before starting the engine so the oil has drained to the pan. The proper oil level is between the add and full marks on the dipstick.

The distance between the top and bottom dipstick marks corresponds to about 1 quart US (1 l). Add oil, if necessary, before starting the engine.

### Coolant

Ford engines are liquid cooled. When the engine is cold, there should be about 1" (2.5 cm) of coolant in the bottom of the reservoir (refer to Figure 7.2).

### **▲ CAUTION**

**Engine coolant escaping under pressure can cause serious burns. Shut the engine off and let it cool before removing the radiator cap.**

Add coolant, if necessary, when the engine is cold and not running. When running at operating temperature the coolant should be at the Hot level.

Deutz engines are air cooled. Visually inspect the air intake and fan (refer to Figure 7.3) to be sure they are free of obstructions that could stop or slow the flow of air. Inspect the fan belt to see that it is in place and not cracked.




Figure 7.3—Deutz Air Intake

### Radiator

Inspect the radiator hoses and clamps for wear, leakage, or damage (refer to Figure 7.4). Make sure the hoses are not hardened, cracked, or feel spongy. Make sure the cap is in place and tight.




Figure 7.4—Radiator

## Chapter 7. Prestart Inspection

Coolant leaks are easily visible on the ground. Check under the chassis for coolant that has leaked.

Make sure the radiator core and ventilation openings on the cover are free of bugs, dirt, or foreign material that might restrict airflow.

### Fuel Tank

Check the fuel level (refer to Figure 7.5) and add fuel if necessary. Make sure the cap is securely fastened on gasoline or diesel tanks.




Figure 7.5—Gasoline or Diesel Tank

Use the following procedure to change the LPG tank.

1. Close the shutoff valve (refer to Figure 7.6).




Figure 7.6—LPG Tank

2. Remove the fuel line from the tank using the quick disconnect fitting.
3. Pull up on each latch to release the straps from the tank.
4. Carefully lift the tank from the cradle.
5. Place a full tank in the cradle making sure the slot in the tank aligns with the pin.
6. Latch both straps to secure the tank.

7. Connect the fuel line and open the shutoff valve.

### Fuel Line

Visually inspect the entire length of the fuel line. Start at the fuel tank and trace the line (refer to Figure 7.5) to the engine inspecting for leaks and damage.

### Air Filter

The air filter gauge (refer to Figure 7.7) has an indicator to show when the filter needs replaced.




Figure 7.7—Air Filter

To inspect the air filter:

1. Turn the battery disconnect switch on and close the cowling door.
2. On dual fuel machines, set the fuel switch to either LPG or gasoline.
3. At the lower controls, place the emergency stop switch in the on position.
4. Insert the key into the master switch and turn the engine on.
5. Check the clear zone after running the engine for 30 seconds.
  - If the indicator is red, replace the filter.
  - If the indicator is clear, the filter is OK.
6. Shut off the engine.

### Charging System

When the engine is running, the ammeter needle (refer to Figure 7.8) should be to the right of "0." Left of the "0" is discharging.




Figure 7.8—Ammeter

### Cold Weather Start Kit—Block Heater

If the machine is equipped with an optional engine block heater, visually inspect the heater and power cord. Inspect for leaks around the heater and for damage to the power cord.

### Electrical System

Electrical power is supplied from either one or two, 335 amp, 12 volt batteries. These batteries supply 12 volt DC electrical power to operate the aerial platform electrical and electrohydraulic components.

Machines with gasoline engines have one battery and machines with diesel engines have two batteries.

### ⚠ DANGER

**Batteries give off hydrogen and oxygen that can combine explosively. Death or serious injury can result from a chemical explosion. Do not smoke or permit open flames or sparks when checking the batteries.**

### ⚠ CAUTION

**Even with low voltage electrical systems, severe arcing can occur. Electrical shock or component damage can result from contact with energized conductors. Use caution when working with any electrical device.**

The batteries are behind the door on the right side of the turntable.

### Emergency Power Battery

The emergency power battery (refer to Figure 7.9) is behind the door on the right side of the chassis. The battery is automatically charged when the engine is running.




Figure 7.9—Emergency Power Battery

Include the emergency power battery when inspecting and servicing the electrical system.

### Battery Fluid Level

Remove the caps from each battery (refer to Figure 7.9). Visually check the battery fluid level. If the level is not within  $\frac{1}{4}$ " (6 mm) of the bottom of the filler neck inside each hole, add distilled water.

Replace the caps on the batteries. The caps must be in place and tight during machine operation.

### Battery Terminals

Check the top of the batteries, the terminals, and cable ends (refer to Figure 7.9). They should be clean and free of corrosion and dirt. Clean the top of the batteries if necessary. Clean the terminals and cable ends with a wire brush or terminal cleaning tool. All cable ends must be securely fastened to the terminals.

### Cables and Wiring Harness

Inspect all cables and wiring for wear and/or physical damage such as loose connections, broken wires, and frayed insulation. Check the wiring in areas where a change in routing direction may cause them to become pinched (refer to Figure 7.10). Make sure the cables and wires are properly routed to avoid sharp edges, pinching, and scuffing.





Figure 7.10—Cables and Wiring Harness

### Hydraulic System

Hydraulic power is supplied from an engine driven variable displacement piston pump.

#### ⚠ DANGER

Hydraulic fluid escaping under pressure can have enough force to inject fluid into the flesh. Serious infection or reaction can result if medical treatment is not given immediately. In case of injury by escaping hydraulic fluid, seek medical attention at once.

The hydraulic reservoir is behind the door on the left side of the turntable. The pump is mounted on the engine.

### Fluid Level

Check the hydraulic reservoir fluid level with the aerial platform stowed on a level surface. The fluid level must be between the full and add marks as viewed on the sight glass (refer to Figure 7.11).




Figure 7.11—Fluid Level Indicator

#### ⚠ CAUTION

Not all hydraulic fluid is suitable to use in the hydraulic system. Some have poor lubricating characteristics and can increase component wear. Only use hydraulic fluid as recommended.

If necessary, remove the filler cap and add fluid of the proper type. Refer to Chapter 2 for the proper type and grade of hydraulic fluid to use. The need to regularly add fluid indicates a leak that should be corrected.

The sight glass on the reservoir has an internal thermometer to measure the fluid temperature. The temperature should be less than 200°F (93°C).

### Fluid Filter

Checking the condition of the hydraulic fluid filter is part of the machine maintenance schedule and should not be performed by the operator.

### Hoses, Tubes, and Fittings

Inspect all hydraulic hoses, tubes, and fittings for wear, leakage, or damage (refer to Figure 7.12). Make sure the hoses are properly routed to avoid sharp edges, kinking, and scuffing. Inspect the tubes for dents or other damage that may restrict fluid flow. Make sure all hoses and tubes are held firmly in their support brackets.



Figure 7.12—Hose, Tubes, and Fittings

Hydraulic fluid leaks are easily visible on the ground. Check under the chassis for fluid that has leaked.

### Tires and Wheels

Visually inspect the tires and wheels (refer to Figure 7.13) to make sure they are suitable for service. Check the wheel lug nuts to see that none are missing, damaged, or loose.



Figure 7.13—Tires and Wheels

The aerial platform may have air or foam filled tires. Air filled tires have a tire pressure decal near the valve stem. The valve stem also has a valve core like an automobile tire. Foam filled tires do not have a pressure decal or a valve core. Different types of tires have different inspection requirements.

### Air Filled

Check air filled tires very carefully for wear, cuts, punctures, or imbedded objects.

### ▲ DANGER

**The aerial platform can tip over if it becomes unstable. Death or serious injury can result from a tip-over accident. Do not operate the aerial platform if a tire is leaking air or is in poor condition where a blow out could occur.**

Test the air pressure with a pressure gauge to make sure the tires are properly inflated. Check the tires several times throughout the day to see that they are properly inflated.

### Foam Filled

Inspect for large holes or cuts where foam is coming out of the tire. Look for large imbedded objects, such as angle iron, that can rip a tire open.

Punctures caused by bolts, screws, or nails are not a problem for foam filled tires.

### Lower Control Station

With no personnel in the platform, test the operation of each control from the lower controls (refer to Figure 7.14).




Figure 7.14—Lower Controls

### Operating Controls

Use the following procedure to operate the machine from the lower controls.

1. Turn the battery disconnect switch on.
2. At the lower controls, lift the emergency stop safety guard up, and push the toggle switch up to the on position.
3. Insert the key into the master switch and turn the switch to start until the engine starts, then release it.
4. Let the engine warm to operating temperature.
5. Hold the ground controls switch in the on position.

### ▲ DANGER

**Pinch points may exist between moving components. Death or serious injury can result from becoming trapped between components, buildings, structures, or other obstacles. Make sure all personnel stand clear of the aerial platform while performing the prestart inspection.**

6. Test the operation of each function in both directions.

#### Note

*When checking the turntable rotation function in the clockwise direction, the turntable will rotate toward you.*

### Emergency Stop

Push the emergency stop safety guard down to turn off the engine. The lower control functions should not operate with the emergency stop in this position.

### Emergency Power

Place the battery disconnect switch, the emergency stop switch, and the master switch in the on position.

Hold the engine/emergency power switch in the emergency power position and the ground controls switch in the on position to operate the aerial platform from the lower controls using the emergency power system.

## Chapter 7. Prestart Inspection

### Emergency Lowering

The main boom can be lowered in an emergency using the emergency lowering knob. The emergency lowering knob is at the base of the main boom lift cylinder.

Use the following procedure to test the emergency lowering system.

1. Use the lower controls to raise the main boom boom until the emergency lower knob is visible in the access hole as shown in Figure 7.15.




Figure 7.15—Emergency Lowering Knob

2. Turn the engine off.

#### ▲ DANGER

Pinch points may exist between moving components. Death or serious injury can result from becoming trapped between components. Stand clear of moving components while test operating the machine.

3. Slowly turn the knob to open the bleed down valve. The boom should slowly lower by gravity.

#### ▲ DANGER

The potential for an accident increases when safety devices do not function properly. Death or serious injury can result from such accidents. Fully close the emergency lowering knob before operating the aerial platform.

4. Turn the knob to close the cylinder bleed down valve.

### Level Sensor

Use the following procedure to test the level sensor.

1. Position the aerial platform on a smooth, flat, level surface.
2. Remove all persons and materials from the platform.
3. Start the engine and raise the main boom about 8' (2.4 m) so the boom switch arm on the right side of the turntable no longer contacts the boom (refer to Figure 7.16).




Figure 7.16—Boom Switch

4. Open the door on the left side of the turntable to access the level sensor (refer to Figure 7.17).




Figure 7.17—Level Sensor

5. Pull the level sensor to the side as far as possible to activate the tilt alarm.

#### ▲ DANGER

The potential for an accident increases when safety devices do not function properly. Death or serious injury can result from such accidents. Do not alter, disable, or override any safety device.

6. If the alarm does not sound, remove the machine from service until the problem is corrected.
7. Lower the main boom.

### Flashing Light

If the machine is equipped with an optional flashing light, visually check to see that it flashes. The light should flash when the engine is running.

### Sandblast Protection Kit

The optional sandblast protection kit protects the cylinders from abrasion while sandblasting or from paint overspray. Rubber covers protect each cylinder rod as it extends and retracts. The covers prevent sand and paint from damaging the cylinder seals and rod.



Inspect the covers while operating the machine to ensure they are securely fastened and completely cover the cylinder rod. Make sure there are no holes in the covers.

### Structures

Visually inspect all weldments and related components. It is important to inspect the fasteners that connect the components.

### Weldments

Visually inspect all weldments for abnormal wear, abrasion, or deformation that could cause interference between moving parts.

Inspect the welds on the structural components. Pay particular attention to boom welds. The area to be inspected should be clean and free of dirt and grease. Look for visible cracks in the weld and at the weld to parent material joint. A bright light may be used to provide adequate visibility of the inspection area.

### Slide Pads

The main boom has slide pads (refer to Figure 7.18) between the main and tip boom sections.




Figure 7.18—Slide Pads

Use the lower controls to raise the main boom about 6' (1.8 m). Extend the tip boom about 1' (30 cm). Visually inspect the slide pads to make sure they are in place and are not obviously loose.

Inspect the surface where the pads contact the intermediate and tip booms. The paint must be in place with no signs of bare metal.

### Fasteners

Visually inspect all fasteners to see that none are missing or loose.

Pay particular attention to all of the bolts, nuts, rollpins, collars, and snap rings that connect the booms and cylinders. They should all be present, tight, and not damaged in any way.

Raise the main boom to access the rotation bearing bolts in the turntable (refer to Figure 7.19).




Figure 7.19—Rotation Bearing Bolts

Inspect the rotation bearing bolts to ensure that none are missing, damaged, or loose.

### Upper Control Station

Inspect the platform and upper controls only if all functions operated properly from the lower controls.

### Guardrail System

The guardrail system (refer to Figure 7.20) includes the top rail, mid rail, toeboards and a gravity gate or optional swinging gate.




Figure 7.20—Guardrail System

Inspect all components of the guardrail system. The rails and toeboards must all be in place and free of any damage or deformation. Visually check the rail and toeboard welds for cracks. All bolts and nuts fastening the platform in place must be present and not show any signs of looseness.

Inspect the gravity gate to be sure it is present, is not damaged, and moves freely.

Inspect the optional swinging gate to see that it swings freely, closes firmly, and is not deformed in any way. Make sure the spring closes and secures the gate when the gate is closed.

## Chapter 7. Prestart Inspection

### Lanyard Anchors

There are two lanyard anchors below the upper control panel (refer to Figure 7.20).

Visually inspect the lanyard anchors to make sure they are in place, are not deformed and are securely fastened to the platform.

### Operating Controls

Use the following procedure to operate the machine from the upper controls.

1. Turn the battery disconnect switch on.
2. At the lower controls, place the emergency stop switch and the master switch in the on position. Place the control switch in the platform position.
3. At the upper controls (refer to Figure 7.21), pull the emergency stop button out.




Figure 7.21—Upper Controls

4. Turn the anti-restart master switch to start until the engine starts, then release it.
5. Let the engine warm to operating temperature.

### **⚠ DANGER**

Pinch points may exist between moving components. Death or serious injury can result from becoming trapped between components, buildings, structures, or other obstacles. Make sure all personnel stand clear of the aerial platform while performing the prestart inspection.

6. Test the platform foot switch by moving a boom function switch without stepping on the foot switch. If movement occurs the interlock is not functioning properly. Do not operate the machine until the problem is corrected.
7. Test the operation of each control in both directions from the upper controls.

8. The drive range switch and maximum travel speeds are interlocked through a limit switch on the turntable that senses the main boom position. When the main boom is raised approximately 8' (2.4 m) the machine should travel in low speed only. To operate in high speed the booms must be stowed.

### Emergency Stop

Push the emergency stop button in to turn off the engine. The upper control functions should not operate with the emergency stop in this position.

### Emergency Power

Pull the emergency stop button up and place the anti-restart master switch in the on position.

Hold the engine/emergency power switch in the emergency power position and step on the platform foot switch to operate the aerial platform from the upper controls using the emergency power system.

### Horn

Press the horn button to ensure that it sounds to warn personnel in the area.

### Electrical Power Outlet

Connect a source of 125 volt AC power to the power-input connector on the left side of the lower control panel (refer to Figure 7.22).





Figure 7.22—Power-Input Connector

Some machines may have an electrical outlet at the platform, but no power-input connector. In that case, power is supplied by an optional AC generator. An external power source is not required.

With the engine running, place the machine/generator control (refer to Figure 7.23) in the generator position to provide electrical power to the two electrical outlets at the platform and to the outlet on the end of the generator housing.






**Figure 7.23—Upper Control Panel Front**

Plug an electrical tool into the receptacle at the platform and at the generator and try to operate the tool to verify proper operation of the outlet.

The outlet is equipped with a ground fault circuit interrupter (GFCI). Use the following procedure to test the GFCI.

1. Push the black test button (refer to Figure 7.24).



**Figure 7.24—Electrical Power Outlet**

2. Plug an electrical tool into the outlet and verify the power is off.
  - If the power was off, push the reset button to restore power.
  - If the power was on, repair or replace the receptacle.

### Drive Motion Alarm

The machine may be equipped with an optional drive motion alarm. Drive in both the forward and reverse directions to ensure that the alarm sounds to warn personnel in the area that the aerial platform is in motion.

### Driving and Work Lights

The machine may be equipped with driving lights and/or platform working lights. Turn the engine on and use the switch on the back of each light to momentarily turn it on to see that it works.

### Platform Control Cover

The machine may be equipped with an optional platform control cover. Inspect the cover to ensure it fits properly over the control panel.

### Tow Kit

The machine may be equipped with an optional tow kit. Inspect the tow bar and steering arm to verify the components are present and in working condition.

### Placards and Decals

Inspect all safety and operational placards and decals. Make certain they are in place, in good condition, and are legible.

The placards and decals may be cleaned with soap and water, and a soft cloth if the words or pictures cannot be seen.

### **▲CAUTION**


**Solvents may contain hazardous ingredients. Follow the manufacturer's label for proper use and disposal. Wear protective gloves and splash-proof safety glasses when using solvents.**

Wet paint overspray may be removed using a natural biodegradable solvent and a soft cloth.

Replace any missing or illegible placards or decals before operating the aerial platform. Placard and decal kits are available from Snorkel dealers.

The safety related placards and decals are illustrated on the following pages.


# Chapter 7. Prestart Inspection




Right Side



0074311



0323896




Lower Control Door

<b>Snorkel</b>		SERIAL NUMBER	
MODEL NUMBER		SLOPE SENSOR ALIGNMENT	deg
MONTH/YEAR OF MANUFACTURE		MAXIMUM WHEEL LOAD	lbs kg
MAXIMUM MACHINE WEIGHT	lbs kg	ENGINE POWERED MODELS	hp kW
BATTERY POWERED MODELS ONLY		BATTERY MODELS ONLY	V Ah
MAXIMUM ALLOWABLE MANUAL FORCE (SIDE PULL)	lbs N	MAXIMUM ALLOWABLE WING SPEED	m/h m/s
PLATFORM SIZE	in cm	MAXIMUM PLATFORM HEIGHT	ft m
MAXIMUM PLATFORM HEIGHT	ft m	MAXIMUM DRIVE HEIGHT	ft m
RATED NUMBER OF OCCURRINGS		UNRESTRICTED PLATFORM CAPACITY	lbs kg
<b>CAUTION</b>			
Do not remove any weight from this machine. Any weight added must be distributed equally on each axle. Proper stability and axle weights of this machine are based on the platform size shown above.			
Axle weights with machine in the stored / travel position:			
STEER AXLE	lbs	kg	
DRIVE AXLE	lbs	kg	


0070901




0323897




**Lower Control Door (Open)**




**Rear of Turntable**




**Right Side of Turntable**




**Rear View**




**Top View of Radiator**




0074316




0074210



0081441



0082203




0323896



0151410

# Chapter 7. Prestart Inspection



**⚠ DANGER**

**ELECTROCUTION HAZARD**

**THIS MACHINE IS NOT ELECTRICALLY INSULATED.**

- Death or serious injury can result from contact or inadequate clearance to electrical power lines and apparatus.
- Maintain 10 feet minimum clearance from electrical power lines and apparatus.
- Allow for sway, rock, and sag.

0323899

0323899

**⚠ DANGER**

A RUNAWAY SNORKELIFT CAN CAUSE DEATH OR SERIOUS INJURY. CHECK WITH TOW VEHICLE MANUFACTURER OR MANUFACTURER LITERATURE TO SEE THAT TOW VEHICLE CAN SAFELY TOW AND STOP TOTAL WEIGHT OF SNORKELIFT ON THE STEEPEST GRADE YOU WILL ENCOUNTER. REMEMBER, SNORKELIFT DOES NOT HAVE BRAKES WHEN IT IS TOWED.

BE CERTAIN TOW VEHICLE BRAKES ARE SET AND TOW BAR IS CONNECTED TO BOTH TOW VEHICLE AND SNORKELIFT BEFORE YOU TURN SNORKELIFT DISCONNECT PLATES OVER.

AT THE END OF THE TOW, BEFORE YOU DISCONNECT THE SNORKELIFT FROM THE TOWING VEHICLE, TURN THE DISCONNECT PLATES BACK OVER SO THE NIPPLES ARE OUT. THAT WILL PREVENT THE MACHINE FROM ROLLING WHEN YOU DISCONNECT IT FROM THE TOW VEHICLE.

DO NOT EXCEED 10 MPH (16 KM/H) WHEN TOWING. AVOID SHARP TURNS.

0082160

0082160

**⚠ DANGER**


**ELECTROCUTION HAZARD**

**KEEP CLEAR**

Death or serious injury can result from touching this machine if this machine is in contact with electrical power lines or apparatus.

0323896

0323896



**⚠ DANGER** **ELECTROCUTION HAZARD**

This machine is not electrically insulated.

0072531


0072531

**⚠ DANGER**


**DO NOT RIDE IN PLATFORM WHILE UNIT IS BEING TOWED.**

0082164

0082164



0170311



**⚠ DANGER**

**ELECTROCUTION HAZARD**

**THIS MACHINE IS NOT ELECTRICALLY INSULATED.**

- Death or serious injury can result from contact or inadequate clearance to electrical power lines and apparatus.
- Maintain 10 feet minimum clearance from electrical power lines and apparatus.
- Allow for sway, rock, and sag.

0323899

0323899

**Prestart Inspection Check List**

Item	Inspect for	Ok
<b>Operator's manual</b>	In manual holder	
<b>Engine</b>		
Oil level	Between full and add marks	
Coolant	Liquid cooled engines-proper fluid level Air cooled engines-air intake and fan free of obstructions/belt in good condition	
Radiator	Cap tight, good condition and clean	
Fuel tank and line	Tank full, cap in place and tight/no leaks	
Air filter	Green indicator	
Charging system	Proper operation	
Cold weather start kit	No damage or deformation	
<b>Electrical system</b>		
Emergency power battery	Condition and charged for proper operation	
Battery fluid level and terminals	Proper level/clean, connectors tight	
Cables and wiring harness	No wear or physical damage	
<b>Hydraulic system</b>		
Fluid level	Between full and add marks	
Fluid filter	Verify operation in the green zone	
Hoses, tubes, and fittings	No leaks	
Cold weather warm-up kit	Proper operation	
<b>Tires and wheels</b>		
Air filled	Good condition, proper inflation	
Foam filled	Good condition	
<b>Lower control station</b>		
Operating controls	Proper operation	
Emergency stop and emergency power	Shuts off lower controls/proper operation	
<b>Emergency lowering</b>	Proper operation	
<b>Level sensor</b>	Sounds tilt alarm	
<b>Flashing light</b>	Proper operation	
<b>Sandblast protection kit</b>	In place and proper operation	
<b>Structures</b>		
Weldments	Welds intact, no damage or deformation	
Slide pads	In place, no damage or deformation	
Fasteners	In place and tight	
<b>Upper control station</b>		
Guardrail system and lanyard anchors	No damage or deformation	
Operating controls	Proper operation	
Emergency stop and emergency power	Shuts off upper controls/proper operation	
Horn	Sounds when activated	
Electrical power outlet	Proper operation	
Drive motion alarm	Sounds when aerial platform moves	
Driving and work lights	Proper operation	
Platform control cover	In place and proper operation	
<b>Tow kit</b>	In place, no damage or deformation	
<b>Placards and decals</b>	In place and readable	

## Chapter 8. Operation

The aerial platform may be operated from either the lower or upper controls.

### ▲ DANGER

**The aerial platform is not electrically insulated. Death or serious injury can result from contact with, or inadequate clearance from, an energized conductor. Do not go closer than the minimum safe approach distance as defined by ANSI.**

**Pinch points may exist between moving components. Death or serious injury can result from becoming trapped between components, buildings, structures, or other obstacles. Make sure there is sufficient clearance around the machine before moving the chassis, booms, or platform. Allow sufficient room and time to stop movement to avoid contact with structures or other hazards.**

**The aerial platform can tip over if it becomes unstable. Death or serious injury can result from a tip-over accident. Operate the aerial platform on a firm, flat, level surface. Avoid travel speeds and/or rough terrain that could cause sudden changes in platform position.**

The platform rated work load is the total weight of the personnel and equipment that may be lifted in the platform. The work loads are stated on the platform rating placard mounted on the toeboard at the front of the platform.

### ▲ DANGER

**The aerial platform can tip over if it becomes unstable. Death or serious injury can result from a tip-over accident. Do not exceed the capacity values indicated on the platform rating placard.**

Capacity values indicate the rated lifting capacity and do not indicate aerial platform stability.

The operator bears ultimate responsibility for ensuring that the aerial platform is properly set up for the particular conditions encountered.

### Cold Weather Start-Up

If the ambient temperature is 32°F (0°C) or below, the engine and hydraulic system oil may need to be warmed before operation. Do not operate the engine at more than a fast idle until the engine and hydraulic oil has had a chance to warm. The engine may be equipped with an optional cold weather start kit.

Cold, thick hydraulic oil does not flow well and may cause delay in response to control movement and low voltage output of the AC generator. Cold hydraulic oil may also cause cavitation and pump damage. The hydraulic system may be equipped with an optional cold weather warm-up kit.

### Engine Cold Weather Start Kit

The optional engine cold weather start kit may be an engine block heater or a manifold air pre-heater. The type of starting assist system depends on the engine manufacturer.

The last two letters of the model number stamped on the serial number placard indicates the engine manufacturer (refer to Figure 8.1). The serial number placard is mounted on the front of the turntable.

Last Two Letters of Model Number	Engine Manufacturer	Type of Cold Weather Start System
FO	Ford	Engine block heater
DZ	Deutz	Manifold air pre-heater

Figure 8.1—Engine Manufacturer/Start System

Refer to the engine manufacturer below for specific cold weather start-up information for that particular engine type and cold weather start system.

#### Ford—Block Heater

Plug the heater cord into a 125 Volt AC, 600 watt source eight hours before starting the engine. The heater will warm the engine block to make cold weather starting easier.

Unplug the power cord before starting the engine.

#### Deutz—Manifold Preheater

At the lower controls, hold the manifold heater switch on for about a minute before turning the master switch to start the engine. A glow plug in the manifold preheats the air to help start the engine. Continue to hold the switch while starting the engine. Do not release the switch until the engine starts.

If the engine does not start within 20 seconds, continue to hold the manifold heater switch and turn the master switch off. Wait for one minute before trying to start the engine again.

### Hydraulic System Cold Weather Warm-Up

The hydraulic oil may be warmed by bottoming out the main boom cylinder. Operate the main boom down function while the machine is stowed. With the cylinder bottomed out the oil flow will produce heat to warm the hydraulic oil.

### ▲ CAUTION

**Not all hydraulic fluid is suitable to use in the hydraulic system. Some have poor lubricating characteristics and can increase component wear. Only use hydraulic fluid as recommended.**



## Chapter 8. Operation

Use cold weather hydraulic oil as recommended in the machine General Specifications in temperatures of 10°F (0°C) or below.

### Preparing for Operation

Use the following procedure to prepare the aerial platform for operation.

1. Perform a prestart inspection as described in Chapter 7.
2. Place the battery disconnect switch in the on position.
3. Close and latch the doors.
4. Before painting or sandblasting make sure the sandblast protection kit and the platform control cover are properly installed. These options, when used properly will protect the control placards and cylinder rods from paint overspray and abrasion while sandblasting.

### Lower Controls

The lower controls override the upper controls. This means that the lower controls can always be used to operate the platform regardless of the position of the upper control emergency stop button.

Boom, turntable, and platform functions may be operated from the lower controls. The lower controls may be used for initial set up of the aerial platform and raising and lowering the platform while testing or inspection.

Use the following procedure to operate boom, turntable, or platform functions using the lower controls.

1. On dual fuel machines, set the fuel switch to either LPG or gasoline.
2. Open the shut-off valve on the tank if using LPG.
3. Place the emergency stop switch (refer to Figure 8.2) in the on position and place the controls switch in the ground position.




Figure 8.2—Lower Controls

4. Turn the start switch to start, then release it to on. The engine will not start if the switch is left in the on position for 30 seconds or longer before turning it to start. The switch must be turned back to off before the engine will start.
5. Let the engine warm to operating temperature.
6. Hold the ground controls switch in the on position. This switch must be held up while operating the control toggle switches.
7. Hold the appropriate toggle switch in the desired direction.
8. Release the function toggle switch to stop movement.
9. Place the ground controls switch in the off position when no functions are being operated.

### Upper Controls

The upper controls may be used for driving the aerial platform and positioning the booms and platform while on the job.

Use the following procedure to operate machine functions using the upper controls.

1. At the lower controls, place the emergency stop switch in the on position and turn the start switch on. Place the controls switch in the platform position.
2. On dual fuel machines, set the fuel switch to either LPG or gasoline.
3. Open the shut-off valve on the tank if using LPG.
4. Enter the platform and securely close the gate.
5. Attach the fall restraint lanyard to one of the anchor points.
6. Pull the emergency stop button out (refer to Figure 8.3).
7. Turn the anti-restart master switch to start, then release it to on. The engine will not start if the switch is left in the on position for 30 seconds or longer before turning it to start. The switch must be turned back to off before the engine will start.
8. Let the engine warm to operating temperature.

### Boom Operation

Use the following procedure to operate the turntable, boom, or platform functions.

1. Turn the boom speed knob to slow.
2. Step down on the platform foot switch. This switch must be held down to operate the upper controls.
3. Hold the appropriate toggle switch in the desired direction. Always look in the direction of movement.
4. Gradually turn the boom speed knob to control the turntable and boom function speed.
5. Release the foot switch or the function toggle switch to stop movement.




Figure 8.3—Upper Controls

## Driving and Steering

### ⚠ DANGER

The aerial platform can tip over if it becomes unstable. Death or serious injury can result from a tip-over accident. Do not drive an elevated aerial platform on soft, uneven, or sloping surfaces. Do not drive a fully stowed machine on grades that exceed 25 percent.

A fully stowed machine may be operated on grades up to 25 percent. A grade of 25 percent is a 30" (7.62 m) vertical rise in 10' (3.05 m) horizontal length.

### ⚠ DANGER

Death or serious injury can result from improperly driving or steering the aerial platform. Read and understand the information in this manual and on the placards and decals on the machine before operating the aerial platform on the job.

The blue and yellow arrows on the chassis indicate the direction the chassis will move when the drive or steer control is moved toward the corresponding color.

When the machine is in the stowed position, with the booms centered between the rear wheels, the direction of drive and steer control movement corresponds with the direction of chassis movement.

When the turntable is rotated from the stowed position, with the booms to either side of or in front of the chassis, the direction of control movement does not correspond with the direction of chassis movement.

To avoid confusion, always drive to the work area or move between work areas with the turntable and booms in the stowed position. After arriving at the work area, the booms may be positioned to the side or the front of the chassis for final positioning. Always look in the direction of movement as indicated by the directional arrows on the chassis.

Use the following procedure to operate the drive and steer functions.

1. Determine the desired drive range for the specific driving conditions.
  - Use high range when traveling across firm, flat, level surfaces. High range can only be activated when the booms are stowed. High range is for high speed, low torque operation.
  - Use low range for driving on loading ramps or other steep grades and when safety considerations demand slow deliberate machine movement. Low range is for low speed, high torque operation.
2. Step down on the platform foot switch.
3. Push the drive joystick forward to move the chassis forward, the direction of the blue arrow. Pull the joystick backward to move the chassis backward, the direction of the yellow arrow. The drive speed is proportional to the joystick position.
4. To stop drive motion, return the joystick to neutral.
5. Place the steer switch in the color-coded direction necessary to turn left or right as indicated by the arrows on the chassis.

#### Note

The steering wheels are not self-centering. Set the steering wheels straight ahead after completing a turn.

6. After driving to the desired location, release the foot switch, or push the emergency stop button to apply the parking brakes.

### Drive Speeds

The drive speed is proportional to the joystick position. The farther the joystick is moved, the faster the travel speed.

Always slow down and shift the drive system to low range before traveling over rough terrain or any sloped surface.



## Chapter 8. Operation

Drive speed ranges are interlocked through a limit switch that senses the main boom position. When the boom is elevated, only the slowest drive speed will work regardless of the drive range switch position. To avoid a sudden speed change from high to low elevated boom speed, always bring the machine to a stop before raising the booms from the stowed position.

### ▲ DANGER

**The potential for an accident increases when safety devices do not function properly. Death or serious injury can result from such accidents. Do not alter, disable, or override any safety device.**

Do not use the aerial platform if it drives faster than 1.0 miles per hour (44' in 30 seconds) when the booms are elevated from the stowed position.

### Four-Wheel Drive

The machine may be equipped with a four-wheel drive system. This system operates full time and requires no action by the operator.

Four-wheel drive machines have a "4x4" decal on each side of the chassis and all four of the wheel hubs are drive hubs and look the same.

### Electrical Power Outlet

The electrical outlet at the platform has 2, 3-prong, 125 volt AC electrical connectors. Their combined output is limited by a 15 amp circuit breaker.

Power may be supplied to the outlet using an external power source or by operating the optional AC generator.

To use the outlet, plug a source of power into the power-input connector on the left side of the lower control panel. Unplug the source of power before moving the aerial platform.

### AC Generator

The generator can be used to supply power to the electrical outlet only when the engine is running and the machine is stationary. The machine functions will not operate when the machine/generator selector switch is in the generator position.

### ▲ CAUTION

**Cold hydraulic oil does not flow well and may produce low generator output voltage. Low outlet voltage can damage some electrical power tools and equipment. Warm the hydraulic oil before operating the generator.**

Do not operate the generator unless the hydraulic oil temperature is at least 100°F (38°C). Refer to Cold Weather Start-Up for a hydraulic oil warm-up procedure.

Use the following procedure to supply power to the electrical power outlet if the machine is equipped with the optional generator.

1. Plug the generator cord into the outlet on the left side of the lower control panel.
2. Start the engine and place the machine/generator selector switch (refer to Figure 8.3) in the generator position.

The engine will run at high idle while the generator is operating. The generator will continue to operate as long as the engine is running and the switch is in the generator position.

### Dual Fuel

The dual fuel switch is located on the front of the lower control panel (refer to Figure 8.4).



Figure 8.4—Lower Controls

Before starting the engine, place the fuel switch in the gasoline or the LPG position. Open the shut-off valve on the LPG gas tank if using LPG. Always keep the LPG tank shut-off valve closed when not using LPG.

To switch from gasoline to LPG with the engine running:

1. Open the shut-off valve on the LPG tank.
2. Place the fuel switch in the off position until the engine starts to die.
3. Place the fuel switch in the LPG position.

To switch from LPG to gasoline with the engine running:

1. Place the fuel switch in the gasoline position.
2. Close the shut-off valve on the LPG tank.

### Driving Lights

The optional driving lights are for use in dimly lit areas and are not intended for driving on public roadways. There are two headlights at the front of the chassis and two blinking taillights at the rear of the chassis.

The lights are operational when the battery disconnect switch and the master switch are turned on.

*Note*

*Working with the driving or platform work lights on, while the engine is off, can discharge the batteries enough that the engine will not start or the emergency power system will not operate. If the engine cannot be left running while the lights are on, start and run the engine for at least 15 minutes each hour.*

### **Platform Work Lights**

The optional platform work lights are located on the top rail of the platform. The direction a light points can be adjusted by using two  $\frac{1}{2}$ " wrenches to loosen the clamp below the light.

The lights are operational when the upper controls emergency stop button is pulled up and the anti-restart master switch is turned on.

The engine speed increases to high idle when the platform work lights are turned on.

## Chapter 9. Stowing and Transporting

To prevent unauthorized use and damage, properly stow the aerial platform at the end of each work day. It must also be properly stowed while transporting.

### Stowing

The properly stowed position is shown in Figure 9.1.



Figure 9.1—Stowed TB 37

Use the following procedure to properly stow the aerial platform.

1. Rotate the platform so it is perpendicular to the end of the boom.
2. Fully retract and lower the main boom.
3. Center the booms between the rear wheels.
4. If the engine has just been under load and is hot, set the throttle switch to low and let the engine idle for five minutes.
5. Turn the anti-restart switch off and place the platform control box cover over the upper controls if the machine is equipped with that option.
6. Turn the lower controls emergency stop and the master switch off and remove the key.
7. Turn the battery disconnect switch off.
8. On dual fuel machines, close the shut-off valve on the LPG tank.
9. Close and latch the cowling doors.

### Transporting

The aerial platform may be moved on a transport vehicle. Depending on the particular situation, the aerial platform may be driven, winched, or hoisted onto a vehicle such as a truck or trailer. Driving is the preferred method.

### ▲ DANGER

**The aerial platform can tip over if it becomes unstable. Death or serious injury can result from a tip-over accident. Do not drive on ramps that exceed 25 percent grade, or where conditions of the ramp could cause driving to be hazardous.**

Drive the aerial platform onto the transport vehicle if the ramp incline is within the 25 percent grade capability of the aerial platform.

A 25 percent grade is a 30" (7.62 m) vertical rise in 10' (3.05 m) horizontal length.

Use a winch to load and unload the aerial platform on ramps that exceed 25 percent grade. A winch may also be used when conditions of the ramp could cause driving to be hazardous.

The equipment used to load, unload, and transport the aerial platform must have adequate capacity. Refer to Chapter 2 to determine the approximate weight of the aerial platform.

The user assumes all responsibility for choosing the proper method of transportation, and the proper selection and use of transportation and tie-down devices, making sure the equipment used is capable of supporting the weight of the aerial platform and that all manufacturer's instructions and warnings, regulations and safety rules of their employer, the DOT and/or any other state or federal law are followed.

### Driving

Use the following procedure to drive the aerial platform onto the transport vehicle.

1. Locate the transport vehicle so it is in a straight line with the loading ramp.
2. Chock the vehicle wheels so it cannot roll away from the ramp while the machine is loaded.
3. Remove any unnecessary tools, materials, or other loose objects from the platform.
4. Drive the machine to the foot of the loading ramp with the front wheels nearest the ramp. Make sure the machine is centered with the ramps and that the steering wheels are straight.
5. Rotate the platform so it is perpendicular to the boom.
6. Retract the tip boom and raise the main boom so it is horizontal.
7. Rotate the turntable slightly to the side so you can see the front wheels.
8. Verify that the machine wheels, loading ramps, and transport vehicle are aligned.

## Chapter 9. Stowing and Transporting

### ▲ DANGER

The aerial platform can tip over if it becomes unstable. Death or serious injury can result from a tip-over accident. Set the drive range to low before driving up or down a grade.

9. Place the drive range switch in the low position.
10. Drive the aerial platform onto the transport vehicle in a straight line through the grade transitions with minimal turning.
11. Rotate the turntable to align the main boom between the rear wheels.
12. When driving down the ramp, always back the machine with the platform on the downhill side only.

### Winching

Use the following procedure to winch the aerial platform onto the transport vehicle.

1. Locate the transport vehicle so the aerial platform will not roll forward after it is loaded.
2. Remove any unnecessary tools, materials, or other loose objects from the platform.
3. Drive the machine to the foot of the loading ramp with the front wheels nearest the ramp. Make sure the machine is centered with the ramps and that the steering wheels are straight.
4. Properly stow the aerial platform.
5. Attach the winch to the tie-down lugs (refer to Figure 9.2) on the front of the chassis.




Figure 9.2—Tie-Down Lugs

6. At each drive wheel, remove the two bolts from the disconnect plate (refer to Figure 9.3). Turn the plate over so the nipple points inward. Reinstall the two bolts.




Figure 9.3—Drive Wheel

7. Use the winch to position the aerial platform on the transport vehicle.

### ▲ DANGER

The aerial platform is free to move when the drive hubs are disabled. Death or serious injury can result. Re-enable the drive hubs before operating the aerial platform.

8. At each drive wheel, remove the two bolts and return the plate to its original position as shown in Figure 9.3.
9. Start the engine and operate the drive control in forward and reverse several times to engage the drive hubs.

### Hoisting

Use a four point sling arrangement attached to the lifting lugs when hoisting the aerial platform. Machine damage can occur if the sling is attached to the booms, turntable, or platform.

### ▲ DANGER

The potential for an accident increases when the aerial platform is lifted using improper equipment and/or lifting techniques. Death or serious injury can result from such accidents. Use proper equipment and lifting techniques when lifting the aerial platform.

Know the weight of the aerial platform and the capacity of the lifting devices before hoisting. Lifting devices include the hoist or crane, chains, straps, cables, hooks, sheaves, shackles, slings, and other hardware used to support the machine. The gross vehicle weight is stamped on the serial number placard and is listed in Chapter 2.



The user assumes all responsibility for making sure the equipment used is capable of supporting the weight of the aerial platform and that all manufacturer's instructions and warnings, regulations and safety rules of their employer and/or any state or federal law are followed.

Use the following procedure to hoist the aerial platform onto the transport vehicle.

1. Properly stow the aerial platform.

### Note

*The lifting lugs at the rear of the chassis are farther apart than those at the front. Rotating the turntable 180° will place the counterweight at the rear of the chassis. This will reduce the number of spreader bars needed by one and sometimes two.*

2. Inspect the lifting lugs (refer to Figure 9.4) to make sure they are free of cracks, rust, and are in good condition. Have any damage repaired by a qualified service technician before attempting to hoist the machine.



**Figure 9.4—Lifting Lugs**

3. Remove all personnel, tools, materials, or other loose objects from the platform.
4. Connect the chains or straps to the lifting lugs using bolted shackles. Hooks that fit properly in the lugs and that have latching mechanisms to prevent them from falling out under a slack line condition may also be used.

Do not run the sling cable through the lifting lugs. Cable damage and/or failure can result from the cable contacting the sharp corners of the lug. There is no effective way of putting a corner protector in the hole of the lifting lug.

5. Use spreader bars of sufficient length to keep the chains, straps, or cables from contacting the turntable or booms. When using cables, use rigid corner protectors at any point where the cable contacts sharp corners to prevent damaging the cable. Careful rigging of the spreaders is required to prevent machine damage.

6. Adjust the length of each chain or strap so the aerial platform remains level when raised off the ground.
7. Use the hoist or crane to carefully raise and position the aerial platform onto the transport vehicle.

### Securing for Transport

Use the following procedure to secure the aerial platform on the transport vehicle.

1. Chock the wheels.
2. Raise the main boom about 1' (0.3m).
3. Place a large wood block under the rotator pylon. Lower the rotator pylon onto the wood block.
4. Remove all personnel, tools, materials, or other loose objects from the platform.
5. Turn the anti-restart switch off and place the platform control box cover over the upper controls if the machine is equipped with that option.
6. Place the lower controls emergency stop switch in the off position. Turn the master switch off and remove the key.
7. Turn the battery disconnect switch off.
8. Close the shut-off valve on the LPG tank on LPG .
9. Close and latch the cowling doors.
10. Use a rubber strap (refer to Figure 9.5) to prevent the doors from coming open while the machine is transported.



**Figure 9.5—Securing Cowling Doors**

11. Use wire-ties to fasten the platform gate to the guardrails to prevent the gate from bouncing. Also, use wire-ties to fasten the platform foot switch to the platform floor.
12. Determine if the platform is made of steel or aluminum. Steel platforms have toeboards with rolled edges an aluminum platforms have toeboards with straight edges.



### ⚠CAUTION

Aluminum toeboards are not strong enough to use when securing the platform to the transport vehicle. Damage to the platform will occur if the nylon strap is placed over the toeboards. Thread the strap through the platform mounting bracket or over the mid rail when securing an aluminum platform.

13. Use a nylon strap to securely fasten the platform against the wood block. On steel platforms, thread the strap over the toeboard as shown in Figure 9.6.
14. On aluminum platforms, thread the strap over the platform mounting bracket or the mid rail as shown in Figure 9.6.


### ⚠CAUTION

Ratchets, winches, and come-alongs can produce enough force to damage machine components. Do not over tighten the straps or chains when securing the aerial platform to the transport vehicle.

15. Use chains or straps to securely fasten the aerial platform to the transport vehicle using the tie-down lugs as attachment points. Proper tie-down and hauling are the responsibility of the carrier.



Steel



Aluminum

Figure 9.6—Platform

## Chapter 10. Emergency Operation

If the main hydraulic system fails, the aerial platform may be lowered and stowed using the emergency power system. The main boom may be lowered using the emergency lowering knob. The machine may be towed if the drive system fails. Refer to Emergency Power System, Emergency Lowering, or Towing for the appropriate procedure.

### Emergency Power System

The emergency power system can be used to operate the machine from the lower or upper controls.

#### ⚠CAUTION

The emergency power system is for emergency lowering and stowing only. The length of time the pump can be operated depends on the capacity of the battery. Do not use this system for normal operation.

Only use the emergency power system if the main power system fails.

### Lower Controls

Use the following procedure to operate the machine using the emergency power system from the lower controls.

1. Place the battery disconnect switch in the on position (refer to Figure 10.1).



Figure 10.1—Battery Disconnect Switch

2. Place the key in the master switch (refer to Figure 10.2) and turn the start switch on.




Figure 10.2—Lower Controls

3. Place the emergency stop switch in the on position.
4. Place the controls switch in the ground position.
5. Hold the ground controls switch in the on position while holding the engine/emergency power switch in the emergency power position.
6. Hold the appropriate function toggle switch in the desired direction.

### Upper Controls

For the upper controls to be operational:

- the battery disconnect switch must be in the on position.
- the master switch at the lower controls must be turned on.
- the emergency stop button at the lower controls must be in the on position.
- the controls switch at the lower controls must be in the platform position.

Use the following procedure to operate the machine using the emergency power system from the upper controls.

1. Pull the emergency stop button out (refer to Figure 10.3).
2. Turn the anti-restart switch on.
3. Step down on the platform foot switch (refer to Figure 10.4).



Figure 10.3—Upper Controls




Figure 10.4—Platform Foot Switch

4. Hold the engine/emergency power switch in the emergency power position.
5. Hold the appropriate function toggle switch in the desired direction.

## Emergency Lowering

The main boom can be lowered in an emergency using the emergency lowering knob at the base of the lift cylinder. The emergency lowering knob allows the main boom to be lowered only. Only use this method if the engine will not start and the emergency power system will not work.

### ▲ DANGER

Pinch points exist between boom components and between the booms and turntable. Death or serious injury can result if the booms or platform lowers onto personnel. Make sure all personnel stand clear while lowering the booms.

Use the following procedure to manually lower the main boom.

1. Slowly turn the knob (refer to Figure 10.5) to open the bleed down valve. Control the rate of descent by turning the knob.




Figure 10.5—Emergency Lowering Knob

### ▲ DANGER

The potential for an accident increases when safety devices do not function properly. Death or serious injury can result from such accidents. Fully close the emergency lowering knob before operating the aerial platform.

2. Turn the knob to close the cylinder bleed down valve.

## Towing

The aerial platform may be towed at slow speeds using the optional tow kit. The tow vehicle must have sufficient capacity to safely tow and stop itself and the aerial platform on the steepest grade and type of surface that may be encountered. Refer to Chapter 2 for the gross vehicle weight of the aerial platform.

### ▲ DANGER

The aerial platform is free to move when the drive hubs are disabled. Death or serious injury can result. Securely fasten the tow vehicle to the aerial platform before disabling the drive hubs.

Use the following procedure to manually disengage the drive hubs and tow the machine.

1. With the machine in the stowed position, remove the tow bar from the storage cradles at the rear of the chassis and lay the tow bar near the front of the chassis.

### ▲ DANGER

Pinch points may exist between machine components. Death or serious injury can result from becoming trapped between components. Do not attach the tow bar to the tow vehicle until the counterweight is to the side of the chassis.

2. Rotate the turntable, until the counterweight is to the side of the chassis, to allow room to attach the tow bar.
3. Attach the tow bar to the front steering arm with the tow pin and snap pin.
4. Attach the tow bar to the tow vehicle.
5. Rotate the turntable so the counterweight is back at the front of the chassis. Raise the platform about 3' (1 m) above the ground.
6. Shut the engine off and turn the battery disconnect switch off.
7. At each drive wheel, remove the two bolts from the disconnect plate (refer to Figure 10.6). Turn the plate over so the nipple points inward. Reinstall the two bolts.




Figure 10.6—Drive Wheel

8. Pull the steering float valve knob out. The knob is located behind the rear door on the right side of the turntable next to the fuel tank.
9. Do not exceed 10 mile per hour (16 km/h) when towing. Use caution when traveling around a curve or when turning a corner. If the tow bar contacts the chassis the steering mechanism might be damaged or the tow vehicle and the aerial platform could jackknife.

### ▲ DANGER

The aerial platform is free to move when the drive hubs are disabled. Death or serious injury can result. Re-enable the drive hubs before operating the aerial platform.

10. Push the steering float valve knob in.
11. At each drive wheel, remove the two bolts and return the plate to its original position as shown in Figure 10.6.
12. Unfasten the tow vehicle from the machine and replace the tow bar on the storage cradles.
13. Verify that the drive system operates properly.



## Chapter 11. Troubleshooting

The troubleshooting chart may be used to locate and eliminate situations where machine operation may be interrupted. If the problem cannot be corrected with the

action listed, stow the machine and remove it from service. Repairs must be made by qualified maintenance personnel.

### Troubleshooting Chart

Symptom	Possible Cause	Corrective Action
Engine will not start from lower or upper controls.	Out of fuel.	Add correct type of fuel.
	Engine is cold.	Gasoline engine—plug the block heater into a 125 Volt AC, 600 watt source eight hours before starting the engine.
		Diesel engine—hold the manifold heater switch on for about a minute before starting the engine. Hold the switch on until the engine starts.
	High engine temperature.	Let engine cool. Do not restart the engine until the cause of overheating has been corrected.
	Low oil pressure.	Do not try to start the engine until the cause of low oil pressure has been corrected. The engine can be restarted with low oil pressure, but it will only run a few seconds before it shuts off again.
Engine will not start from lower controls.	Selector switch is in the platform position.	Place the switch in the ground position.
	The start switch was left in the on position for 30 seconds or longer before turning it to start.	Turn the start switch back to off, then to start within 30 seconds.
Engine will not start from upper controls.	Selector switch is in the ground position.	Place the switch in the platform position.
	Platform foot switch is activated	Do not step on foot switch while starting the engine.
	The anti-restart master switch was left in the on position for 30 seconds or longer before turning it to start.	Turn the anti-restart switch back to off, then to start within 30 seconds.
Engine dies when the controls switch at the lower controls is placed in the platform position.	Upper controls are not set-up properly.	At the upper controls, pull the emergency stop button upward and turn the anti-restart master switch on.



## Chapter 11. Troubleshooting

Symptom	Possible Cause	Corrective Action
Constant tone alarm sounds while the engine is running.	High engine temperature.	Lower the platform and reduce the engine speed to idle for five minutes. Turn the engine off and let it cool. Do not restart the engine until the cause of overheating has been corrected.
	Low oil pressure.	Lower the platform and turn the engine off. Do not restart the engine until the cause of low oil pressure has been corrected.
	No alternator current/broken fan belt.	Turn the engine off. Do not restart the engine until the cause of no alternator current has been corrected or the fan belt is replaced.
Constant tone alarm sounds and engine shuts off.	High engine temperature.	Let the engine cool. Do not restart the engine until the cause of overheating has been corrected.
	Low oil pressure.	Do not restart the engine until the cause of low oil pressure has been corrected. The engine can be restarted with low oil pressure, but it will only run a few seconds before it shuts off again.
All functions stop working.	Low fluid level in reservoir.	Check fluid level. Add correct type of fluid if necessary.
	Engine or pump failure.	Manually stow the machine using the emergency power system or the emergency lowering knob.
	Circuit breaker is tripped.	Push circuit breaker button in to reset.
	Electrical system malfunction.	Manually lower the boom using the emergency lowering knob.
Lower controls do not work.	Battery disconnect switch turned off.	Place switch in the on position.
	Emergency stop switch at lower controls is pushed down to the off position.	Push emergency stop switch upward to the on position.
	Controls switch is in the platform position.	Place the switch in the ground position.
	Ground controls switch not held in the on position.	Hold the ground controls switch in the on position while operating the control toggle switches.
Upper controls do not work.	Battery disconnect switch turned off.	Place switch in the on position.
	Emergency stop switch at lower and upper controls is in the off position.	Place the emergency stop in the on position.
	Control switch at lower controls is in the ground position.	Place switch in the platform position.
	Platform foot switch not engaged.	Step down on platform foot switch while operating controls.

## Chapter 11. Troubleshooting

Symptom	Possible Cause	Corrective Action
Boom and drive functions seem sluggish.	Hydraulic oil is cold and thick.	Use cold weather hydraulic oil as recommended for weather conditions. Warm oil before operating the machine.
Turntable and main boom functions do not work from upper controls.	Boom speed knob set too slow.	Turn knob toward fast.
Booms drift down.	Hydraulic system malfunction.	Stow the machine and do not operate until repairs are made.
Drive functions do not work.	Load capacity exceeded.	Remove load from platform. Refer to platform capacity placard for maximum capacity.
	Machine on too steep a grade.	Lower the booms and drive to a level surface.
	Drive hubs are disengaged.	Turn drive wheel disconnect plates around so nipples point outward.
	Low hydraulic system pressure.	Stow the machine and do not operate until repairs are made.
Wheels will not turn when winching.	Drive hubs are engaged.	Turn drive wheel disconnect plates around so nipples point inward.
Only slow drive speed works.	The booms are elevated.	Completely lower the booms.
	High range not selected.	Place the drive range switch in the high position.
Steer wheels do not work.	Optional tow kit steering float valve is open.	Push the steering float valve knob in.
Tilt alarm does not work.	Booms are stowed.	Normal operation. The tilt alarm is not active until the booms are elevated.
Circuit breaker will not reset.	Electrical circuit has not had time to cool.	Wait a minute or two for circuit to cool, then push circuit breaker button in to reset.
	Electrical system malfunction.	Do not operate machine until repairs are made.
Electrical outlet does not work.	Power supply not plugged in.	Plug a source of power into the power-input connector at rear of chassis.
	GFCI is tripped.	Push reset button on outlet.
	Machine/generator switch not in the generator position.	With engine running, place the machine/generator switch in the generator position.
	Power cord to platform is not plugged into the AC generator.	Plug power cord into the outlet on the left side of the lower control panel.
Low AC generator output voltage.	Hydraulic oil is cold and thick.	Use cold weather hydraulic oil as recommended for weather conditions. Warm oil before operating the machine.

## Chapter 11. Troubleshooting

---

<b>Symptom</b>	<b>Possible Cause</b>	<b>Corrective Action</b>
Hydraulic fluid temperature 200°F (93°C) or more.	Prolonged driving or boom operation.	Stop operation until fluid cools.
	High pressure fluid return to reservoir caused by kinked or twisted hose.	Remove the kink or twist from the hose. Let fluid cool before resuming operation.
	Hydraulic system component failure.	Stow the machine and do not operate until repairs are made.
Severe hydraulic leak.	Failure of hose, tube, fitting, seal, etc.	Do not operate machine until repairs are made.

## Appendix A. Glossary

**aerial platform**—a mobile device that has an adjustable position platform, supported from ground level by a structure.

**authorized personnel**—personnel approved as assigned to perform specific duties at a specific location.

**base**—the relevant contact points of the aerial platform that form the stability support (e.g. wheels, casters, outriggers, stabilizers).

**boom**—a movable cantilever beam which supports the platform.

**center of gravity**—the point in the aerial platform around which its weight is evenly balanced.

**chassis**—the integral part of the aerial platform that provides mobility and support for the booms.

**fall restraint**—a system that is used while working on a boom lift within the boundaries of platform guardrails to provide restraint from being projected upward from the platform. This system includes a harness or belt, lanyard, and a lanyard anchor. Federal OSHA, ANSI, and Snorkel require the use of additional fall protection beyond the platform guardrails on boom supported aerial platforms.

**floor or ground pressure**—the maximum pressure, expressed in pounds per square inch, a single wheel concentrates on the floor or ground.

**gradeability**—the maximum slope that the aerial platform is capable of travel.

**ground fault circuit interrupter**—a fast-acting circuit breaker that opens to stop electrical circuit flow if it senses a very small current leakage to ground. Also called GFCI. The GFCI is used to protect personnel against a potential shock hazard from defective electrical tools or wiring.

**guardrail system**—a vertical barrier around the platform to prevent personnel from falling.

**hazardous location**—any location that contains, or has the potential to contain, an explosive or flammable atmosphere as defined by ANSI/NFPA 505.

**lower controls**—the controls located at ground level for operating some or all of the functions of the aerial platform.

**main boom**—a boom assembly located between the turntable and the platform.

**maximum travel height**—the maximum platform height or the most adverse configuration(s) with respect to stability in which travel is permitted by the manufacturer.

**maximum wheel load**—the load or weight that can be transmitted through a single wheel to the floor or ground.

**Minimum Safe Approach Distance**—the minimum safe distance that electrical conductors may be approached when using the aerial platform. Also called M.S.A.D.

**operation**—the performance of any aerial platform functions within the scope of its specifications and in accordance with the manufacturer's instructions, the users work rules, and all applicable governmental regulations.

**personal fall arrest system**—a fall protection system that is used while working on an unprotected edge (such as a roof top with no guardrail). This system includes a harness, lanyard or other connecting device, a fall arrestor, an energy absorber or decelerator, an anchorage connector, and a secure anchorage such as a building beam, girders or columns. An aerial platform is not a fall arrest anchorage.

**platform**—the portion of an aerial platform intended to be occupied by personnel with their tools and materials.

**platform height**—the vertical distance measured from the floor of the platform to the surface upon which the chassis is being supported.

**qualified person**—a person, who by reason of knowledge, experience, or training is familiar with the operation to be performed and the hazards involved.

**rated work load**—the designed carrying capacity of the aerial platform as specified by the manufacturer.

**stow**—to place a component, such as the platform, in its rest position.

**tip boom**—a telescopic boom section that extends and retracts from within the main boom.

**turntable**—the structure above the rotation bearing which supports the main boom. The turntable rotates about the centerline of rotation.

**unrestricted rated work load**—the maximum designed carrying capacity of the aerial platform allowed by the manufacturer in all operating configurations.

**upper controls**—the controls located on or beside the platform used for operating some or all of the functions of the aerial platform.

**working envelope**—the area defined by the horizontal and vertical limits of boom travel that the platform may be positioned in.



# Index

## A

---

additional information, 1-2  
ambient air temperature operating range, 2-3  
American National Standards Institute (ANSI), 1-1, 3-1  
ammeter, 5-1, 7-2  
ANSI/NFPA 505, 3-2

## B

---

batteries, 2-3, 7-3  
  cable ends, 7-3  
  charging, 3-3, 7-2  
  disconnect switch, 6-1, 7-5, 8-2, 9-1, 10-1  
  distilled water, 7-3  
  terminals, 7-3  
  water level, 7-3  
boom elevation switch, 6-2  
boom extend/retract switch, 6-4  
boom speed control knob, 6-3  
boom switch, 6-2  
boom up/down switch, 6-3

## C

---

cables and wiring harness, 7-3  
Canadian Standards Association (CSA), 1-1  
cold weather start kit, 7-3, 8-1  
  Deutz—manifold preheater, 8-1  
  Ford—block heater, 8-1  
cold weather start-up  
  engine, 8-1  
  hydraulic system, 8-1  
component identification, 2-1  
control selector switch, 6-1, 8-2

## D

---

drive motion alarm, 4-3, 7-9  
drive range switch, 6-4  
drive speed, 2-3, 8-3  
drive system, 2-3  
driving, 8-3  
  directional arrows on the chassis, 8-3  
  drive joystick, 6-4  
driving lights, 6-5, 8-4  
dual fuel, 6-5, 8-4  
dual fuel switch, 6-2

## E

---

electrical hazard  
  see inside front cover  
electrical power outlet, 4-2, 6-5, 7-8, 8-4  
  AC generator, 6-5, 7-8, 8-4  
  accidental conductor grounding, 4-2  
  ground fault circuit interrupter, 4-2, 7-9  
  power-input connector, 7-8, 8-4  
electrical system, 2-3, 3-3, 7-3  
  battery fluid level, 7-3  
  battery terminals, 7-3

  cables and wiring harness, 7-3  
  emergency power battery, 7-3  
electrocution hazards, 3-1  
  minimum safe approach distance, 3-1  
emergency lowering, 7-6  
  emergency lowering knob, 7-6  
  testing, 7-6  
emergency lowering knob, 4-1  
emergency operation, 10-1  
  emergency lowering, 10-2  
  emergency power system, 10-1  
  towing, 10-2  
emergency power system, 4-1, 10-1  
  emergency power battery, 4-1, 7-3  
  emergency power switch, 4-1, 6-2, 6-4  
emergency stop controls, 4-1  
  lower controls, 4-1, 6-1, 7-5, 8-2  
  upper controls, 4-1, 6-3, 7-8, 8-2  
engine, 2-3, 7-1  
  air filter, 7-2  
  charging system, 7-2  
  cold weather start kit, 7-3, 8-1  
  cold weather start-up, 8-1  
  coolant, 7-1  
  fuel line, 7-2  
  fuel tank, 7-2  
  lower controls start switch, 6-1, 8-2  
  oil level, 7-1  
  radiator, 7-1  
  upper controls anti-restart master switch, 6-3, 8-2  
engine air filter gauge, 5-1  
engine and fuel handling precautions, 3-3  
  diesel fuel tank, 3-4  
  dual fuel machines, 3-3  
engine block heater  
  cold weather start kit, 7-3  
engine oil dipstick, 5-2  
engine oil viscosity, 2-4  
  Deutz, 2-4  
  Ford, 2-4  
engine protection systems, 4-2  
  high engine temperature alarm, 4-3  
  low oil pressure alarm, 4-3  
engine specifications, 2-4  
engine temperature gauge, 5-1

## F

---

fall restraint device, 3-3, 4-2, 8-2  
  lanyard anchor, 3-3, 4-2, 8-2  
fasteners, 7-7  
  rotation bearing bolts, 7-7  
flashing light, 4-3, 7-6  
fluid level and temperature gauge, 5-2  
four-wheel drive, 8-4  
fuel tank capacity, 2-3  
function speed, 2-3

## G

---

general specifications, 2-3

# Index

---

ground controls switch, 6-1, 8-2  
ground fault circuit interrupter, 7-9  
    reset button, 7-9  
    test button, 7-9  
guardrail system, 4-2, 7-7  
gravity gate, 4-2, 7-7  
mid rail, 4-2, 7-7  
swinging gate, 4-2, 7-7  
toeboards, 4-2, 7-7  
top rail, 4-2, 7-7

## H

---

hazardous (classified) location, 3-2  
    ANSI/NFPA 505, 3-2  
hoisting, 9-2  
    lifting devices, 9-2  
    lifting lugs, 9-2  
    slings, 9-3  
    spreader bars, 9-3  
    user responsibility, 9-3  
horn, 4-3, 6-4, 7-8  
hour meter, 5-1  
hydraulic fluid filter gauge, 5-2  
hydraulic system, 2-3, 3-3  
    fluid filter, 7-4  
    fluid level, 7-4  
    hoses, tubes, and fittings, 7-4  
hydraulic system cold weather warm-up, 8-1  
hydraulic system failure, 10-1

## J

---

joystick, 6-4

## L

---

lanyard anchor, 3-3, 4-2, 7-8, 8-2  
level sensor, 7-6  
    testing, 7-6  
level switch, 6-4  
lifting lugs, 9-3  
lower control station, 7-5  
    lower controls, 6-1, 7-5, 8-2, 10-1

## M

---

maintenance, 1-2  
manual of responsibilities, 1-2  
    copies, 1-2  
    employer, 1-2  
    owners, 1-2  
    users, 1-2  
maximum wind speed, 2-3  
minimum safe approach distance, 3-1  
    see inside front cover

## N

---

notes, 1-2

## O

---

Occupational Safety and Health Administration  
(OSHA), 1-1  
operation, 1-2, 3-2, 8-1

AC generator, 8-4  
boom operation, 8-2  
cold weather start-up, 8-1  
driving, 8-3  
driving lights, 8-4  
dual fuel, 8-4  
electrical power outlet, 8-4  
emergency power, 10-1  
four-wheel drive, 8-4  
lower controls, 8-2  
platform work lights, 8-5  
preparing for operation, 8-2  
steering, 8-3  
upper controls, 8-2  
operator's manual, 1-1, 3-1, 7-1  
    manual holder, 7-1  
    notes, 1-2  
    part number, 1-1  
    safety alerts, 1-1  
operators, 1-2  
    responsibility, 1-2, 3-1, 8-1  
    training, 1-2  
options, 1-1  
    AC generator, 6-5, 7-8, 8-4  
    cold weather start kit, 7-3, 8-1  
    diesel air cooled engine, 2-4, 7-1  
    drive motion alarm, 7-9  
    driving lights, 4-3, 6-5, 7-9, 8-4  
    dual fuel, 6-5, 8-2  
    flashing light, 4-3, 7-6  
    flotation tires, 2-3, 7-5  
    foam filled tires, 2-3, 7-5  
    four-wheel drive, 8-4  
    gasoline engine, 2-4, 7-1  
    horn, 4-3, 7-8  
    LPG engine, 2-4, 7-1  
    platform, 2-3  
    platform control cover, 7-9  
    platform work lights, 4-3, 6-5, 7-9, 8-5  
    swinging platform gate, 4-2, 7-7  
    tow kit, 7-9, 10-2

## P

---

personal fall arrest, 3-3  
placards and decals, 3-4, 7-9  
    cleaning, 7-9  
    safety related, 7-9  
platform, 2-3, 3-2, 3-3, 7-7, 8-2, 9-1  
    capacity, 3-3, 8-1  
    foot switch, 4-2, 6-4, 7-8, 8-2  
    guardrail height, 2-3  
    guardrail system, 4-2  
        gravity gate, 4-2, 7-7  
        mid rail, 4-2, 7-7  
        swinging gate, 4-2, 7-7  
    toeboards, 4-2, 7-7  
    top rail, 4-2, 7-7  
    guardrails, 3-3, 7-7  
    maximum number of occupants, 2-3  
    occupants, 3-3  
    rated work load, 2-3, 8-1  
    rotation, 2-3, 6-4

- transfer from, 3-3
- platform control cover, 7-9
- platform level switch, 6-2
- platform rotator switch, 6-2, 6-4
- platform work lights, 4-3, 8-5
- prestart inspection, 1-2, 3-2, 7-1, 8-2
  - check list, 7-13

## R

---

- radiator, 7-1
  - airflow, 7-2
  - cap, 7-1
- reservoir, 7-4
  - filler cap, 7-4
  - fluid level, 7-4
  - sight glass, 7-4
  - thermometer, 7-4
- rotation switch, 6-2

## S

---

- safety alerts, 1-1, 3-1
  - caution, 1-1
  - danger, 1-1
  - safety alert symbol, 1-1
- safety devices, 3-1, 4-1
  - defective, 4-1
- safety related placards and decals, 7-9
- sandblast protection kit, 7-6, 8-2
- Scaffold Industry Association, 1-2, 3-1
  - ANSI/SIA A92.5, 3-1
- steer switch, 6-4
- steering, 6-4, 8-3
  - directional arrows on the chasis, 8-3
- stowed length, 2-3
- stowed width, 2-3
- stowing, 9-1

- structures, 7-7
  - fasteners, 7-7
  - slide pads, 7-7
  - weldments, 7-7
- swing switch, 6-3
- swinging platform gate, 4-2, 7-7

## T

---

- throttle switch, 6-2, 6-4
- tie-down lugs, 9-2
- tilt alarm, 4-2, 7-6
- tip-over and falling hazards, 3-2
- tires
  - air filled, 7-5
  - foam filled, 7-5
- tow kit, 7-9, 10-2
- transporting, 9-1
  - driving, 9-1
  - hoisting, 9-2
  - securing, 9-3
  - user responsibility, 9-1
  - winching, 9-2
- turntable rotation, 2-3

## U

---

- upper control station, 7-7
  - upper controls, 6-3, 7-8, 8-2, 10-1

## W

---

- warranty
  - see inside back cover
- wheelbase, 2-3
- wheels, 7-4
  - lug nuts, 7-4
- windy or gusty conditions, 3-3
- work place inspection and practices, 3-2
- working envelope, 2-2