



Operating Instructions

 **TEREX | SCHAEFF**

Wheel Loader
SKL 824

Keep behind driver's seat for later use!

AUSGABE • EDITION

2004-02

GÜLTIG AB FZ-ID.NR. • VALID FROM SERIAL NO. • A PARTIR DU NO. DE SERIE

824/0099>

SCHAEFF-TEREX GMBH&CO KG • D-74595 LANGENBURG

Hauptverwaltung/Verkauf Direction générale/Vente Central administration/Sales	Kundendienst Service après-vente Service department	Ersatzteile Pièces de rechange Spare parts
Schaeff-Terex GmbH & Co KG Postfach 61 • D-74595 Langenburg Schaeffstr. 8 • D-74595 Langenburg Phone 07905/58-0 Fax 07905/58-114	Terex Deutschland GmbH Postfach 12 64 • D-91534 Rothenburg Erlbacher Str. 113 • D-91541 Rothenburg Phone 09861/972-451 Fax 09861/972-460	Schaeff Ersatzteile-Service GmbH & Co KG Postfach 12 64 • D-91534 Rothenburg Erlbacher Str. 115 • D-91541 Rothenburg Phone 09861/972-0 Fax 09861/972-410

Order no.:

5 780 110 012

englisch

Table of Contents

1 Introduction	1
1.1 Warranty and Maintenance	2
1.2 Copyright.....	2
1.3 Notes on using the instruction book.....	2
1.4 Environmental requirements	3
1.5 Pictograms	3
2 Safety and Prevention of Accidents	5
2.1 Introductory remarks	5
2.2 Proper use.....	5
2.3 General safety notes	6
2.4 Operation	6
2.5 Danger zone.....	7
2.6 Transport of persons	7
2.7 Stability	7
2.8 Travel operation.....	8
2.9 Operation	8
2.10 Guides	9
2.11 Danger of falling objects	9
2.12 Working in the vicinity of underground power lines	9
2.13 Working in the vicinity of overhead power lines	10
2.14 Operation in closed rooms	10
2.15 Work stoppages	10
2.16 Change of work attachments, maintenance, repair	11
2.17 Recovery, loading, transportation	12
2.18 Monitoring and inspections	12
2.19 Fire protection.....	13
2.20 Emergency exit	13
2.21 Other dangers.....	13
3 Technical data	15
3.1 Views.....	15
3.2 Diesel engine.....	18
3.3 Electrical system.....	18
3.4 Travel drive	18
3.5 Brakes	19
3.6 Hydraulic system	19
3.7 Axles.....	20
3.8 Tires	20
3.9 Fuels, lubricants and coolants.....	21
3.9.1 Filling quantities	21
3.9.2 Fuel, lubricant and coolant specifications.....	22
3.10 Permissible loads in compliance with German Regulations (StVZO).....	23
3.11 Sound level values, vibration.....	23
3.12 Dimensions and weights	23
3.13 Front loader installation	24
3.14 Buckets	24
3.15 Fork lift attachment.....	25
3.16 Optional accessories	26

Table of Contents

4 Operation	27
4.1 First commissioning	27
4.2 Operator controls and display elements	28
4.3 Engine	32
4.3.1 Starting the engine	32
4.3.2 Monitoring during operation	33
4.3.3 Switching off the engine	33
4.4 Driver's seat / Steering wheel tilt adjustment	34
4.5 Heating / Ventilation	35
4.6 Light switch in compliance with StVZO	35
4.7 Hydroinflation of tires.....	36
4.8 Driving, steering and braking	37
4.8.1 Driving	37
4.8.2 Steering	39
4.8.3 Braking	39
4.8.4 Road travel.....	40
4.8.5 Parking the machine	41
5 Loading Operation	43
5.1 General	43
5.2 Loader operation.....	43
5.3 Changing work attachments.....	45
5.3.1 General.....	45
5.3.2 Assembly of work attachments.....	46
5.4 Notes on how to work with the machine	48
5.4.1 Loading	48
5.4.2 Scraping, grading.....	48
5.4.3 Excavation work	48
6 Recovery and Transport of the Machine	49
6.1 Recovery of the machine	49
6.2 Loading the machine using a crane	50
6.3 Transporting the machine	50
7 Care and Maintenance	51
7.1 General notes	51
7.2 Intervals	51
7.3 Regular oil analyses	52
7.4 Warranty	52
7.5 Inspection parts and aids.....	53
7.6 Care and cleaning.....	54
7.7 Notes for winter operation.....	54
7.8 Checking, maintenance and inspection plans.....	57
7.8.1 Initial inspection (delivery/ handing-over inspection)	57
7.8.2 Daily and weekly tasks	58
7.8.3 Overview of lubricating points	60
7.8.4 Inspection plan	62

Table of Contents

7.9 Inspection and maintenance work	64
7.9.1 Engine oil	64
7.9.2 Engine oil filter	65
7.9.3 Engine oil cooler	65
7.9.4 Fuel system	66
7.9.5 Air filter, air intake	68
7.9.6 V-belts	71
7.9.7 Checking the valve lash	72
7.9.8 Brakes	73
7.9.9 Hydraulic oil	74
7.9.10 Hydraulic oil cooler	75
7.9.11 Hydraulic oil filter	76
7.9.12 Breather	77
7.9.13 Axles	78
7.9.14 Wheels	80
7.9.15 Injection valves	81
7.9.16 Toothed belt for engine	81
7.9.17 Electrical equipment	81
7.9.18 Cab ventilation dust filter	82
7.9.19 Windshield washer system	82
7.10 Shutdown	83
7.10.1 Preservation (temporary shutdown)	83
7.10.2 During shutdown	83
7.10.3 After shutdown	83
8 Trouble-Shooting	85
8.1 General	85
8.2 Engine	85
8.3 No steering movement	85
8.4 Insufficient performance of service brake	85
8.5 Insufficient performance of parking brake	85
8.6 Hydrostatic travel drive has no neutral position	85
8.7 Hydraulic oil exceeds max. admissible temperature	86
8.8 Sluggish acceleration and deceleration, too little propulsive power	86
8.9 Transmission works in one direction only	87
8.10 Transmission works in neither direction	87
8.11 Loader installation is not working	87
8.12 Decrease in machine's performance (loader installation)	88
8.13 Working cylinders are not working satisfactorily	88
8.14 Trouble in the electrical system	88
9 Appendix	89
9.1 Electrical system	89
9.2 Hydraulic system	102
9.3 Equipment options	107

Table of Contents

1 Introduction

You decided to buy a **TEREX Schaeff SKL 824 Wheel Loader**.

The confidence placed in this model will be rewarded by the efficient and economical performance of the machine.

These operating instructions contain all information necessary for the correct use of the machine.

Please read them carefully before putting the machine into operation and make sure that they are kept at hand at all times.

Should you need further explanations or should anything be unclear, please contact your dealer immediately.

Special equipment and attachments are not included in these operating instructions.

We reserve the right to make improvements on the machine within the scope of impending technical developments, without incurring any obligation to change these operating instructions.



*Any modifications of **TEREX Schaeff**-products and their equipment using extras and work attachments which are not included in our product range require our written approval. If our approval is not sought, our warranty expires, as does our product liability for any resulting consequential damage.*

Please state the vehicle type and the vehicle identification number when making inquiries or orders, and in all written correspondence.



*The **vehicle identification number** of the machine is stamped on the identification plate (1/1).*




Fig. 1-Identification plate

1 Introduction

1.1 Warranty and Maintenance

The warranty period covers 12 (twelve) months, beginning with the day the machine is handed over or put into operation.

Safe working conditions and good working order of the machine are prerequisites for efficient work. Your **TEREX Schaeff** - Wheel Loader fulfills these requirements when correctly handled and when serviced and maintained as specified.

Careful observation of the machine whilst in function and the use of the specified fuels, lubricants and coolants will prevent malfunction.

Trained specialist personnel are responsible for any servicing of the machine which requires expert knowledge. Inspections and repairs must therefore be carried out by your dealer's customer service.

In respect of possible claims for damages during the warranty period, all work specified in the maintenance and inspection plan must be carried out at the specified intervals.

After the warranty period, too, regular maintenance must be performed to ensure that the machine is constantly in good working order and enjoys a reasonable service life.

Insist that only **original TEREX Schaeff-spare parts** are used in the event of any repair work. In this way, you will have a product of lasting high quality, thereby ensuring that your machine maintains its original condition.

1.2 Copyright

This instruction book is intended for use by personnel responsible for operation, maintenance, repair and supervision of the machine.

The instruction book is copyrighted. It shall not, either in whole or in part, be reproduced, transmitted or used for the purpose of competition without our prior written permission.

1.3 Notes on using the instruction book

References to pictures and items

The references to pictures and items contained in the text, such as "Figure 12/4" or "12/4" mean Figure 12, item 4 (Bild = Figure).

The figures shown in this list partly contain additional equipment.

"DANGER" Symbol



This symbol is employed for a high risk of injury to persons. It is essential that the safety notes are observed.

"WARNING" Symbol



This symbol is employed for information whose non-compliance may lead to severe material damage. It is essential that the safety notes are observed.

"ATTENTION" Symbol



This symbol is employed for information containing important notes about the correct use and / or how to proceed. Non-compliance may lead to malfunction.

1.4 Environmental requirements

Applicable environmental requirements must be observed for all tasks performed on and with the machine.

During installation, repair and maintenance tasks, particular care must be taken that substances that would damage the environment such as

- Lubricating grease and oil
- Hydraulic oil
- Fuel
- Coolants
- Cleaning fluids containing solvents















are not allowed to come in contact with the soil or the water system.

These substances must be stored in suitable containers and must be properly transported, collected and disposed of.

















If the substances listed above do reach the soil, the leak or outlet must be stopped immediately and the fluid must be cleaned up with a suitable absorbent material. If necessary, the soil involved must be removed. Absorbent materials and removed soil must be disposed of properly. Applicable environmental requirements must be observed.












1.5 Pictograms

The following table explains the meaning of the pictograms which may be attached to your machine.

Symbol	Description
	Danger
	In Operating Instructions: Warning On machine: Caution
	Attention
	Battery charge indicator
	Pre-heating
	Engine oil pressure
	Engine oil temperature
	Engine oil level
	Coolant temperature
	Coolant level
	Air filter
	Hydraulic oil Hydraulic oil level
	Hydraulic oil temperature
	Hydraulic oil filter clogging indicator

1 Introduction

Symbol	Description
	Horn
	Fuel Fuel level
	Fan Heater / Ventilation
	Windshield wash/ wipe system
	Parking brake
	Direction indicator, left/ right
	Working floodlight(s)
	High beam indicator
	Rotating beacon
	Direction of travel, forward/ reverse
	Travel speed, fast
	Travel speed, slow
	Working hydraulics cut-off
	Unlocked
	Locked
	Float position

Symbol	Description
	Hazard warning system
	Operating hour meter Operating hours
	Lashing points
	Fixing points for loading by crane
	First-aid kit
	Fire extinguisher
	On machine: Safety distance
	Danger of crushing
	Danger of injury
	Observe notes in Operating Instructions
	Grease gun Lubricating point

2 Safety and Prevention of Accidents

2.1 Introductory remarks



Certificate of Conformity

The machine complies with the fundamental requirements stipulated in the applicable European guidelines.

Conformity has been proven. The respective documents and the original of the Certificate of Conformity are deposited with the manufacturer.

A copy of the Certificate of Conformity is attached to the sales documents.

Before putting the earth-moving machine into operation, read these operating instructions carefully and strictly observe the indicated references for safe operation.

National safety regulations - e.g. the Accident Prevention Regulations, "Earth-Moving Machinery" (BGR 500, Chapter 2.12) and "Vehicles" (BGV D29) in the Federal Republic of Germany - must also be complied with when operating the earth-moving machine.

In addition to the operating instructions, legal regulations governing road traffic and road safety measures must also be observed. Such requirements could also apply in respect of handling hazardous goods or the wearing of personal safety gear, for example.

Furthermore, safety laws governing work in particular locations (tunnels, adits, quarries, pontoons, contaminated areas, etc.) must likewise be observed.

2.2 Proper use

The earth-moving machine with standard loader bucket equipment is intended solely for work which is suitable for the function of the machine and its work implements.

Such work involves loosening, taking up, transporting and dumping soil, rock or other materials as well as loading these materials on trucks, conveyor belts or other means of transport, when the transport of the material is normally done by positioning the earth-moving machine.

The mounting of special work implements such as multi-purpose buckets, side-dump buckets, sweepers, fork lift attachments, etc. allows the machine to perform above mentioned work.

Any usage above and beyond that specified here, e.g. the transport of persons or the usage of the lift equipment as work platform, and any non-compliance with the manufacturer's instructions is regarded as improper use. The manufacturer shall not be liable for damage resulting from improper use. This risk is borne solely by the plant operator.

Compliance with the operating and maintenance instructions, the performance of maintenance work as specified and adherence to replacement intervals all form part of the concept of proper use.

2 Safety and Prevention of Accidents

2.3 General safety notes

It is important to refrain from any working methods which impair safety.

The earth-moving machine is only to be used if it is in a safe, operational condition.

The manufacturer's instructions must be complied with for operation, maintenance, repair, assembly and transportation.

The plant operator must provide additional special safety instructions, wherever necessary, for specific local conditions.

The operating instructions and any information pertaining to safety must be carefully kept in the driver's cab.

The operating instructions and safety notes must be complete and fully readable.

Safety devices on earth-moving machines shall not be deactivated or removed.

Protective work clothing must be worn during operation. Rings, scarves and unbuttoned jackets are to be avoided. Protective goggles, protective boots, helmets, gloves, reflecting jackets, ear-muffs, etc. may be required.

Before commencing work, information must be obtained on first aid and possible means of rescue (ambulance, fire brigade, helicopters).

A check must be carried out to ensure that the first aid box is at hand and that its contents comply with regulations.

Personnel must be aware of the location and method of operation of the fire extinguishers on the earth-moving machine as well as on-site fire-warning and fire-fighting equipment.

Loose parts such as tools or other accessories must be secured to the earth-moving machine.

Open doors, windows, covers, flaps, etc. must be closed or secured so that they cannot slam shut.

2.4 Operation

Earth-moving machines are only to be independently operated and serviced by persons who

- are physically and mentally suitable
- have been instructed in the operation or maintenance of earth-moving machines and have demonstrated this ability to the plant operator
- can be expected to perform their allocated duties reliably

All such persons must be of the legal minimum age.

They must be designated by the plant operator to operate or service the earth-moving machine.

Operating equipment is only to be operated from the driver's seat.

The earth-moving machine is only to be ascended and entered using the entrances and surfaces intended for this purpose.

It is the driver's responsibility to ensure that the operator's stand, entrances and other surfaces of the earth-moving machine which have to be stepped on are free of dirt, grease, oil, ice and snow.

2.5 Danger zone

- No one is to enter the danger zone of earth-moving machines.
- The danger zone encompasses the area around the earth-moving machine in which persons may be injured by movements of the earth-moving machine during operation, its work implements and attachments, or by swinging out or falling loads.
- The machine operator is only to work the earth-moving machine if the danger zone is free of personnel.
- The machine operator must give a warning signal to persons who may be in danger.
- The machine operator shall stop work with the earth-moving machine if anyone remains in the danger zone despite the warning.
- To ensure no danger of crushing, a sufficient safety distance (min. 0.5 m) must be kept from solid objects, e.g. buildings, excavation slopes, scaffolding, other machines, etc.
- If the above safety distance cannot be maintained, the area between solid objects and the working zone of the earth-moving machine must be blocked off.
- If conditions are such that the machine operator's view of the driving and working zone is restricted, he must be guided or the driving and working zone must be marked by a solid barricade.

2.6 Transport of persons

The transport of persons on the machine is forbidden.

2.7 Stability

- The earth-moving machine must be used, driven and operated in such a manner that its stability against overturning is ensured at all times.
- The machine operator must drive at speeds which are suitable for local conditions.
- The permitted payload of the earth-moving machine shall not be exceeded.
- The earth-moving machine must remain at a sufficient distance from the edges of quarries, pits, mounds and slopes to ensure there is no risk of falling.
- Earth-moving machines must be secured so that they cannot roll or slip when in the vicinity of excavations, shafts, ditches, pits and slopes.

2 Safety and Prevention of Accidents

2.8 Travel operation

Before putting the earth-moving machine into operation, the driver's seat, mirrors and operator's controls must be adjusted so as to ensure safe working.

A safety belt (seat belt), if installed, must always be fastened.

The windows must be clean and free of ice.

Driving tracks must be designed so as to ensure smooth, safe operation, i.e. they must be sufficiently wide, on ground which has as few slopes as possible and sufficient carrying capacity.

Downhill tracks must be set out in such a way that earth-moving machines can be safely braked.

Before driving downhill, the appropriate transmission mode for the terrain must be selected and the gear lever shall not be moved during downhill travel (high gear or low gear).

On steep drops and uphill gradients, the load must be carried on the uphill side, if possible, to increase stability.

The carrying capacity of bridges, cellar roofs, vaults, etc. must be verified before the earth-moving machine can drive over them.

The internal dimensions of constructions must be noted before entering underground passages, tunnels, etc.

It is the plant operator's responsibility to ensure that equipment such as first-aid box, warning triangle, hazard lights are kept with the machine in compliance with the traffic regulations valid in the user's country (e.g. in Germany "StVZO") and that the driver has the appropriate license as required by the national traffic laws of the country in question.

Outside areas covered by general traffic regulations, e.g. on construction sites, traffic regulations should be applied in the proper manner. This should also apply with regard to drivers' licenses.

2.9 Operation

Daily before commencing work and after every change of work attachments, the machine operator must check the correct fastening of the work attachments as well as the correct lock of the quick-mount hitch. Work attachments are to be carefully moved at low height. During this check the danger zones of earth-moving machines have to be free of personnel.

The machine operator is only to swing the work equipment over occupied driver's seats, operator consoles and workplaces of other machines if these are protected by canopies (FOPS).

If a cab does not have the required protection, the driver of this vehicle must leave the driver's stand when equipment has to be slewed overhead.

The vehicles must be loaded in such a manner as to ensure that there is no overloading and no material can be lost during travel. The vehicle must be loaded from the lowest possible height.

At dumping points, earth-moving machines are only to be operated if suitable measures have been taken to prevent rolling or falling.

2.10 Guides

Guides must be easily recognizable, e.g. by means of reflective clothing. They must remain within the machine operator's field of sight.

While guiding the machine, guides shall not be given other jobs which may distract them from their task.

2.11 Danger of falling objects

Earth-moving machines are only to be used where there is a danger of falling objects if the driver's stand has a canopy (FOPS). A front guard must be employed if there is a risk of materials breaking into the cab.

In front of walls e.g. of stacked materials, earth-moving machines must be positioned and operated in such a way that the driver's seat and entry to the driver's seat are not situated on the side facing the wall.

Demolition work is only to be performed by earth-moving machines where there is no danger to persons and if the machine is equipped with canopy, cab-mounted front guard and the appropriate work implement.

See regulations book "Demolition work" (ZH 1/614) published by the Tiefbau-Berufsgenossenschaft (the employer's liability insurance association).

2.12 Working in the vicinity of underground power lines

Before commencing excavating work using earth-moving machines, it must be determined whether any underground power lines are present in the intended working zone which may present a danger to persons.

If underground power lines are present, their exact position and course must be determined in consultation with the proprietor or operator of the lines, and the necessary safety precautions decided and implemented.

The course of power lines in the work area must be clearly marked, under supervision, before commencing any earth-moving work. If the position of lines cannot be determined, search ditches must be dug - manually, if needed.

If underground power lines are encountered unexpectedly or they or their protective covers are damaged, the machine operator must discontinue work immediately and notify the supervisor.

2 Safety and Prevention of Accidents

2.13 Working in the vicinity of overhead power lines

When the earth-moving machine is being used in the vicinity of overhead power lines and trolley wires, a safety distance which varies depending upon the nominal voltage of the overhead line must be maintained between the lines and the earth-moving machine and its work equipment, to prevent current overspill. This also applies to the distance between these lines and attached implements or loads.

The safety distances specified below must be complied with

Nominal voltage in Volt	Safety distance in meters
- 1000 V	1.0 m
over 1 kV - 110 kV	3.0 m
over 110 kV - 220 kV	4.0 m
over 220 kV - 380 kV	5.0 m
nom. voltage unknown	5.0 m

In the observation of safety distances, all working movements of earth-moving machines, e.g. positions of the work equipment and the dimensions of attached loads must be taken into consideration. Uneven ground which would cause the earth-moving machine to be inclined and thus nearer to overhead lines must also be taken into account.

During work in windy conditions, both overhead lines and work equipment may swing out, thus reducing the safety distance.

If it is impossible to maintain sufficient distance from overhead power lines and trolley wires, the plant operator must consult with the proprietor or operator of the overhead lines to find other safety precautions to prevent current overspill. Such measures could be, e.g.

- Switching off the current
- Re-routing the overhead line
- Cabling, or
- Limiting the work zone of earth-moving machines.

2.14 Operation in closed rooms

If earth-moving machines are to be used in closed rooms, these areas must be sufficiently ventilated and the special regulations observed.

2.15 Work stoppages

Before rest periods and at the end of the working day, the driver of the earth-moving machine must park the machine on ground which has sufficient carrying capacity and is as level as possible, and must secure it against unintended movement.

Before rest periods and at the end of the working day, the driver must lower the work equipment onto the ground or secure it so that it cannot move.

The driver shall not leave the earth-moving machine when the work equipment has not been lowered to the ground or secured.

Earth-moving machines are only to be parked in places where they do not present an obstacle, e.g. on the construction site or to plant traffic. Warning devices, e.g. triangles, warning cordons, flashing or hazard lights are to be used if necessary.

Before leaving the operator stand, the driver must bring all operating equipment into home position, switch off the working hydraulics and apply the brakes.

If the driver is leaving the earth-moving machine unattended, he must first turn off the engine and ensure that it cannot be started up by unauthorized persons (e.g. removing ignition keys).

2.16 Change of work attachments, maintenance, repair

Earth-moving machines are only to be converted, maintained or serviced under the guidance of a suitable person designated by the plant operator and following the manufacturer's operating instructions.

After every change of work attachments, the driver must convince himself that the quick-mount hitch is correctly fastened and locked.

Work on e.g.

- braking
- steering
- hydraulic
- electric systems

of the machine is only to be carried out by expert personnel specially trained in these areas.

Stability must be ensured during all type of work on the machine at all times.

The work equipment must be secured against movement by lowering it to the ground or equivalent measures, e.g. cylinder supports, trestles. With the engine running, the unprotected articulation range of articulated loaders shall not be entered.

When jacking up earth-moving machines, jacking devices must be positioned so that they cannot slip. Jacks must be positioned and applied absolutely straight, without tilting.

Raised earth-moving machines must be supported by suitable structures such as crosswise stacks of planks, square timbers or steel trusses.

Earth-moving machines which are raised with work equipment must be stabilized by a supporting structure immediately after lifting. Work under raised machines which are only supported by their hydraulics is forbidden.

The engine/motor(s) must be turned off prior to all maintenance and repair work. These requirements are only to be ignored in the case of maintenance or repair work which cannot be performed without the engine/motor(s) running.

When performing maintenance and repair work on the hydraulic system, it must be relieved of pressure. With the engine turned off, lower the work equipment to the ground and actuate all hydraulic control levers until there is no pressure in the hydraulic system.

Before working on the electrics or when performing arc-welding on the machine, the connection to the battery must be disconnected.

When disconnecting the battery, first the negative pole then the positive pole must be disconnected. The battery must be re-connected in reverse order.

During repair work around the battery, the battery must be covered with insulating material; tools should never be placed on or near the battery.

Protective devices of moving machine parts are only to be opened or removed if the drive has been switched off and cannot be switched on again by unauthorized persons.

Protective devices are e.g. engine/motor covers, doors, protective grating, trim.

Upon completion of assembly, maintenance or repair work, all protective devices must once more be attached in the proper manner.

Load-bearing parts of earth-moving machines are only to be welded following consultation with the manufacturer and in accordance with recognized welding principles.

Protective structures (ROPS; FOPS) are not to be welded or drilled in any way.

2 Safety and Prevention of Accidents

Before commencing work on the hydraulic system, the operating pressure, pilot pressure, back pressure and pressure inside the tank must be let off.

Alterations, such as welding of the hydraulic system, are only to be undertaken with the manufacturer's permission.

Swallowing lubricants, or long and repeated skin contact, can be hazardous to health. When used properly, there is no particular danger to health. The safety specification sheets from the mineral companies must be observed.

Only the hoses specified by the manufacturer are to be used.

Hydraulic hoses must be routed and assembled by expert personnel.

In the vicinity of fuel or batteries, smoking and naked flames are prohibited.

2.17 Recovery, loading, transportation

Earth-moving machines are only to be loaded onto recovery vehicles if adequate towing vehicles are used.

The tow fixing points specified by the manufacturer must be employed.

For loading and transportation, earth-moving machines and all necessary auxiliary equipment must be secured against unwanted movement.

The traveling gear and track-laying gear of earth-moving machines must be sufficiently cleaned of mud, snow and ice to ensure that ramps can be driven up without risk of slipping.

When transporting the earth-moving machine on trucks, flatbed trailers, or by rail, it must be sufficiently secured with chocks and by attachment to the lashing points.

Before setting off, the route to be taken must be examined to determine whether the roads are wide enough, entrances and passages under bridges are large enough and that roads and bridges have sufficient carrying capacity.

2.18 Monitoring and inspections

The machine must be submitted to a general inspection in compliance with the existing UVV-regulations (Accident Prevention Regulations). This inspection must be carried out by an expert (e.g. machine engineer or machine foreman):

- before the machine is put into operation for the first time and before the machine is again put into operation after essential modifications have been made
- at least once a year
- in the meantime, in compliance with operating conditions and local environments

The results of this inspection have to be recorded in writing and this record has to be kept until the next inspection takes place.

Prior to every work shift, the machine operator must check the earth-moving machine in compliance with the inspection and maintenance plan.

Hydraulic hoses must be replaced as soon as the following damage is recognized:

- Damage to the outer layer which reaches the intermediate layer
- Embrittled patches on the outer layer
- Deformations when under pressure or without pressure which differ from the original shape of the installed hose
- Leaks
- Damage to hose fittings or to the connection between the fitting and the hose

The coolant level is only to be checked after the engine has cooled down; the cap must be turned carefully to let off excess pressure.

Prior to operations, the machine operator must check the function of the safety devices.

The machine operator must advise the supervisor immediately - and his replacement, if there is a change of operator - with regard to any shortcomings.

In the event of shortcomings which jeopardize the operating safety of the earth-moving machine, it shall not be used until these have been eliminated.

2.19 Fire protection

- Before refueling the tank of the machine, the engine must be stopped. Exercise special caution as long as the engine is hot.
- Never smoke or handle open flames whilst refueling the tank of the machine.



The fire extinguisher must be kept in the cab and the fire extinguisher symbol be attached.

2.20 Emergency exit

The right-hand cab door acts as an emergency exit.

2.21 Other dangers

Failure of hydraulic system

If the hydraulic system fails because the diesel engine is not running, the hydraulic pump is damaged or hydraulic oil has been lost, only the **EMERGENCY functions**

- manual steering (without power assistance) and
- lower work equipment (only if ignition is switched on)

can still be performed.

2 Safety and Prevention of Accidents

3 Technical data

3.1 Views




Fig. 3 - Dimensioned drawing, machine equipped with general-purpose bucket
365/70 R18 tires

3 Technical Data




Fig. 4 - Dimensioned drawing, machine equipped with multi-purpose bucket

365/70 R18 tires





Fig. 5 - Dimensioned drawing, machine equipped with fork lift attachment
365/70 R18 tires

3 Technical Data

3.2 Diesel engine

Make	Deutz
Type	F4M2011
Design	4 cylinders in line Four-stroke diesel engine with direct injection optimized for emissions reduction (COM II/EPA II)
Displacement	3,100 cm ³
Power in compliance with DIN 70020	37.0 kW at n = 2,300 rpm
Max. torque	185 Nm / 1,700 rpm
Specific fuel consumption at nominal engine speed	216 g/kWh
Cooling	Engine oil / air with external oil cooler
Heating	Fresh air with heat exchanger connected to engine oil circuit

3.3 Electrical system

Operating voltage	12 V
Battery	12 V / 74 Ah / 680 A (EN) / 400 A (DIN)
Generator	14 V 55 A
Starter	2.3 kW
Starting aid	Heater plug
Lighting system	to German Regulations Authorizing the Use of Vehicles for Road Traffic (StVZO)

3.4 Travel drive

Travel drive	Variable displacement pump, flange-mounted directly onto diesel engine, two-stage variable displacement motor with power shift on rear axle reduction gear.			
	High-speed version featuring a rear axle manual transmission shiftable in standstill position. Suction return filter in the form of a tank insert filter.			
Travel speeds	Forward — reverse			
	SKL 824		SKL 824 S	
			Transmission range I	
			Transmission range II	
	Gear range "Work"	0 – 7 km/h	0 – 6.5 km/h	0 – 13 km/h
	Gear range "Road"	0 – 20 km/h	0 – 18 km/h	0 – 36 km/h

Power transmission	Hydrostatic travel drive with advanced driving automatics. Automatic adjustment of propulsive force and speed. Continuous speed regulation forward and in reverse. Four-wheel drive via propeller shaft connection.
Max. operating pressure — travel	440 bar

3.5 Brakes

Service brake	Hydraulically actuated center-mounted drum brake, combined with hydrostatic brake of travel drive. The brake acts on all four wheels via four-wheel drive.
Parking brake	Mechanically actuated center-mounted drum brake on front axle.
Auxiliary brake	The hydrostatic travel drive in the closed circuit acts as an additional non-wearing brake.

3.6 Hydraulic system

Hydraulic pump	Gear pump on the throughdrive of the variable displacement pump. Max. pump capacity: 41 l/min Operating pressure, steering: 175 bar Operating pressure, loading: 250 bar
Priority valve	Priority supply of hydraulic oil to steering through load-sensing system , ensuring that all the available oil can be provided if necessary. Rapid steering movements are possible even at low engine revs.
Steering	Fully hydraulic, proportionally acting articulated steering. One double-acting steering cylinder.
Total steering angle	80°
Loader installation	Double-acting work cylinders, one lift cylinder and one tilt cylinder. Control valve with 3 control circuits. Electro/hydraulically operated float position for "Lower" work function. Single, four-way control lever (joystick) with integrated direction-of-travel switch, float position switch and a switch for additional control circuit.
Additional control circuit	Max. oil flow 41 l/min Max. operating pressure 230 bar
Hydraulic oil cooler	Thermostatically controlled.

3 Technical Data

3.7 Axles

Front axle	Rigidly mounted planetary drive axle with self-locking differential and integrated center-mounted drum brake.
Rear axle (standard)	Oscillating planetary drive axle with self-locking differential and integrated reduction gear.
Rear axle (high-speed version)	Oscillating planetary drive axle with self-locking differential and integrated 2-stage reduction gear.
	Angle of oscillation $\pm 12^\circ$

3.8 Tires

Tire size	Type	Profile	Tire pressure, front	Tire pressure, rear
365/70	R 18	SPT 9	2.0	1.8
12.5-18	MPT 10 PR	E 91-2	2.0	1.8
335/80	R 18 XM	27 TL Michelin	2.0	1.8
365/70	R 18	MPT 70E	2.0	1.8



Special tires available on request!

The use of solid tires or foamed tires requires special measures and is subject to restrictions.



The tire pressure refers to standard equipment.

During fork lift operations, the tire pressure of the front wheels must be increased by at least 0.5 bar.




3.9 Fuels, lubricants and coolants

3.9.1 Filling quantities

All values stated are approximate.				
Fuel tank	approx.	75.0	l	Diesel fuel
Engine with oil filter	approx.	13.0	l	Engine oil (change quantity)
Hydraulic oil, tank and system	approx.	49.0*	l	Hydraulic oil
Hydraulic oil tank	approx.	40.0	l	Hydraulic oil (change quantity)
Service brake	approx.	0.25	l	ATF-oil
Front axle center housing	approx.	3.5	l	Transmission oil
Rear axle center housing and transmission (standard)	approx.	4.0	l	Transmission oil
Rear axle center housing and transmission (high-speed version)	approx.	4.5	l	Transmission oil
Wheel hubs, front/ rear axles	each approx.	0.3	l	Transmission oil
* The hydraulic oil quantity depends on the equipment level of the machine.				
The level marking is always the decisive factor.				



3 Technical Data

3.9.2 Fuel, lubricant and coolant specifications

Application	Code designation in compliance with Bi ¹⁾	Prescribed fuels, lubricants and coolants for Central Europe		Remarks
		Designation	Specification, Standards, Quality	
Engine	--	Diesel fuel	EN 590 ASTM D975 1-D / 2-D	 Before using RME-fuels (rape oil methyl ester), it is essential to consult your responsible TEREX Schaeff-dealer for further details.
Engine	EO 1540 A	Engine oil	SAE 15W-40 API CF4 ACEA E3 or E2	See also engine manufacturer's instructions
Hydraulic system	HYD 1040	Hydraulic oil or multi-grade engine oil	HVLP 46 or SAE 10W-40	The following viscosity limit values must be kept (in compliance with ASTM 445) at 100 °C min. 8 mm ² /s (cSt) at -10 °C approx. 1,500 mm ² /s (cSt)
	BIO-E-HYD-HEES	Biodegradable hydraulic oil on synthetic ester base	Filling in compliance with customer specifications. Brand label on machine.  Do not mix biodegradable oils of different suppliers.	The same viscosity specifications apply as for mineral hydraulic oils.  When changing from mineral to biodegradable hydraulic oils, the tank and hydraulic system must be completely drained, cleaned and flushed. For further details before changing oils, please consult your responsible TEREX Schaeff - dealer .
Axles	GO 90 LS	Transmission oil	SAE 85W-90LS API-GL 5	Alternative recommendations SAE 90LS SAE 80W-90LS
Lubricating points	MPG-A	Multi-purpose, lithium-soap based grease	K2K-30 DIN 51825	
Brake	ATF	Brake oil	ATF Type A Suffix A Dexron-IID	

¹⁾ In conformity with the regulation lubricants of the Main Association of the German Building Industry e.V.

Alternative recommendation for other temperature ranges

Engine oil in compliance with API CG 4 or CF 4 and in compliance with ACEA E3 or E2	Hydraulic oil in compliance with DIN 51524.T3 HVLP
 <p>Viskode</p> <p>Umgebungstemperatur/Ambient temperature/Température ambiante</p>	 <p>Viskohyd</p> <p>Umgebungstemperatur/Ambient temperature/Température ambiante</p>

3.10 Permissible loads in compliance with German Regulations (StVZO)

Permissible gross weight	⇨ see identification plate or ⇨ General Operating License
Permissible axle load, front	
Permissible axle load, rear	

3.11 Sound level values, vibration

Sound level values in compliance with directive 2000/14/EC and EN 474		
Guaranteed sound power level	$L_{W(A)} =$	101 dB (A)
Sound pressure level (at driver's ear)	$L_{P(A)} =$	76 dB (A)
Vibration values in compliance with directive 98/37/EEC and EN 474		
Weighted r.m.s. value of acceleration is below	0.5 m/s^2	for entire body
and	2.5 m/s^2	for upper limbs

3.12 Dimensions and weights

Values refer to general-purpose bucket and 365/70 R18 tires		
Operating weight, standard equipment: approx.	kg	3,900
Total length on ground	mm	4,780
Total width	mm	1,700
Height over cab	mm	2,610
Wheel base	mm	1,950
Tread width, front and rear	mm	1,330
Rear overhang angle	°	35
Ground clearance beneath propeller shaft	mm	410
Turning radius at outside edge of bucket in transport position	mm	3,870
Turning radius at inside edge of tires	mm	1,830

3 Technical Data

3.13 Front loader installation

Values based on general-purpose bucket and 365/70 R18 tires			
Width of bucket		mm	1,700
Capacity in compliance with DIN/ISO 754 (max. density = 1.8 t/m ³)	approx.	m ³	0.65
Payload in bucket		kg	1,170
Dumping height at 45° dumping angle	approx.	mm	2,515
Dumping reach at max. dumping height	approx.	mm	580
Max. bucket hinge pin height	approx.	mm	3,120
Tilt-back angle		°	50
Dumping angle at max. dumping height		°	45
Digging depth, horizontal bucket	approx.	mm	70
Lift capacity at ground level	approx.	N*	33,000
Ripping force at cutting edge of bucket	approx.	N*	37,000
Tipping load, straight	approx.	kg*	2,750
Tipping load, articulated	approx.	kg*	2,475
Work cycle times, lift		sec.	4.9
Work cycle times, lower		sec.	3.4
Dumping in uppermost position, in/ out		sec.	1.1
* in compliance with ISO 8313			
Stability in conformity with DIN 24094			

3.14 Buckets

	Width mm	Capacity, heaped m ³	Max. density (γ) per t/m ³
General-purpose bucket	1,700	0.65	1.8
Multi-purpose bucket	1,700	0.60	1.6
Earth bucket	1,700	0.72	1.6
Light-material bucket	1,700	0.8	1.2
Light-material bucket	1,850	1.0	0.8
Side-dump bucket	1,750	0.5	1.6
High-tip bucket	1,850	0.65	1.2

3.15 Fork lift attachment

Fork connection in compliance with ISO/FEM Class 2 Form B DIN 15 173 and ISO 2328 respectively		
Width of fork carrier	mm	1,240
Length of forks	mm	900
Fork cross section	mm	100 x 40
Length of forks	mm	1,120 (option — payload reduced by additional weight of approx. 30 kg)
Fork cross section	mm	100 x 45
Max. stacking height	mm	2,965

The stated carrying capacity is based on the machine traveling over level ground, with a stability factor of 1.25 or 80% of the tipping load.

The payloads are valid for the machine fitted with 365/70 R 18 SPT 9 tires and the equipment condition as described in compliance with ISO 6016.

Total lift range			S=2.0	S=1.25
		kg	960	1550
		lbs	2110	3410
		kg	1030	1650
		lbs	2270	3630

Transport position			S=1.67	S=1.25
		kg	1340	1800
		lbs	2950	3960
		kg	1400	1900
		lbs	3080	4180



When screw-on rear axle weights or rear tires with hydroinflation are used.



During fork lift operations, the tire pressure of the front wheels must be increased by at least 0.5 bar.

3 Technical Data

3.16 Optional accessories

- Orthopedic air-cushioned driver's seat
- Fire extinguisher
- Height and tilt-adjustable steering wheel
- Pressurized cab
- Air conditioning
- Engine-independent diesel heater with timer
- Diverse electrical accessories such as working floodlights, rotating beacon, radio, etc.
- FOPS-roof guard
- Sliding window, right-hand door
- Diesel exhaust cleaner
- Catalytic converter
- High-speed version
- Anti-theft device
- Back-up alarm system
- Electric tank refueling pump
- Quick-attach system, hydraulically actuated
- Snow blade
- Sweeper
- Load hook for attaching to forks
- Rear axle weights
- Outlet for hydraulic hand hammer
- Filling with biodegradable hydraulic oil

- Further optional equipment available on request! -



*Any modifications of **TEREX Schaeff** products and their equipment using extras and work attachments which are not included in our product range require our written approval. If our approval is not sought, our warranty expires, as does our product liability for any resulting consequential damage.*

4 Operation

4.1 First commissioning



The machine must be entered from the left-hand side as seen in the direction of travel.

The right-hand cab door acts as an emergency exit.

If the cab is entered by the right-hand door, the joystick may be operated unintentionally.

If you are not familiar with the operator controls and display elements of this machine, read this Chapter carefully **before** operating the machine.

This Chapter deals with all functions.

Before driving and working with the machine it is necessary to thoroughly familiarize yourself with the operator controls and display elements.

Each time before putting the machine into operation it must be subjected to a thorough visual inspection. Ensure that there is no damage, loose or missing screws, oil accumulation, oil or fuel leakage. Faults must be remedied immediately. In the event of shortcomings which jeopardize the operating safety, the machine is not to be put into operation until these have been eliminated.

Each time before putting the machine into operation, the inspections in compliance with Chapter 7.8 must be carried out.

4 Operation

4.2 Operator controls and display elements

The following list includes non-standard equipment!




Fig. 10.1-Operator controls

<i>Legende - Fig. 10.1-Operator controls</i>	
1	Direction indicator — horn — low/high beam (steering column mounted switch)
2	Brake inching pedal
3	Accelerator pedal
4	Tilt adjustment of steering wheel (option: height adjustment)
5	Actuation of additional control circuit
6	Control lever — loader installation
7	Direction-of-travel pre-selection (without function if working hydraulics are disabled)
8	Impulse mode — float position
9	Parking brake
10	Socket
11	Fuse carrier
12	Fan: fresh air/ re-circulating air
13	Radio
14	Control rod for mechanical quick-attach system
15	Washer tank

4 Operation







Fig. 10.2-Instrument panel

20	not assigned
21	ORANGE — pre-heating monitor
22	RED — battery charge indicator
23	RED — parking brake
24	GREEN — travel direction, forward
25	Coolant temperature
26	Operating hour meter
27	Fuel gauge
28	GREEN — travel direction, reverse
29	GREEN — direction indicator
30	BLUE — high beam
31	RED — engine oil pressure
32	RED — air filter indicator
33	Travel speed — fast/slow
34	Change-over switch for high gear  <i>Only press when machine is at standstill!</i>
35	Multi-function switch with lock for work equipment cut-off and change-over of the direction-of-travel pre-selection switches from Pos. 07 to Pos. 36  <i>Only press when machine is at standstill!</i>
36	Pre-selection of travel direction — Function <u>only</u> active if working hydraulics are disabled
37	not assigned *
38	not assigned *
39	not assigned *
40	Windshield wash function front/rear
41	Windshield wiper, front
42	Windshield wiper, rear

43	Switch for air conditioning and temperature control
44	Fan switch – heater
45	not assigned *
46	not assigned *
47	Pre-selection switch for actuation of additional control circuit (Pos. 5)
48	Pre-selection switch for float position — OFF/Impulse/Continuous mode
49	not assigned *
50	Pre-heat/starter switch
51	Hazard warning switch
52	Working floodlight, front
53	Working floodlight, rear
54	not assigned *
55	not assigned *
56	not assigned *
57	Heater control
58	Monitor — manual transmission indicator range I
59	Monitor — manual transmission indicator range II
60	Monitor — manual transmission indicator range — disabled  <i>If this symbol comes up, the manual transmission is in an intermediate position. The machine is not ready for operation! This can be remedied by performing brief steering movements until the manual transmission engages.</i>
61	Speed indicator

* for non-standard equipment

4 Operation

4.3 Engine

4.3.1 Starting the engine



Each time before putting the machine into operation, the inspections in compliance with Chapter 7.8 must be carried out.



Before switching on the engine, ensure that no one is in the immediate vicinity of the machine or in the danger zone.

- All control levers must be put into neutral position.
- Parking brake (11/9) applied, direction-of-travel pre-selectors (11/7; 11/36) in position "O".
- Insert ignition key in glow-plug and starter switch (11/50).
- Turn clockwise to "1", the indicator lamps (11/22; 11/31) light up.
- Pre-ignition starts; the indicator lamp (11/21) lights up.
- Press the accelerator pedal (11/3) completely down for normal start and to the quarter-open position for hot start.
- After the indicator lamp (11/21) has gone out, turn the pre-heat/starter switch to "Start". As soon as the engine is running, turn the ignition key to "1" and decrease the revs to low idle speed. The indicator lamps should go out.
- If the engine has not started after max. 20 seconds, turn the ignition key to "1" or "0", and pause for at least 1 minute before trying again. Repeat the start-up procedure.



Do not drive the engine at full throttle straight away. Drive with restraint until the operating temperature of the engine has been reached.




Fig. 11-Operation

4.3.2 Monitoring during operation



If the engine and the machine are put into operation **without** prior remedy of the fault, severe damage to the engine may result!

- If the battery charge (12/22) or engine oil pressure indicator lamp lights up (12/31), switch off the engine immediately and determine the cause, or call for service personnel.
- If the permitted engine oil temperature (12/25) is exceeded, stop work, open the engine hood and keep the engine running at low idle to allow it to cool down.

Once the engine has cooled down, turn it off and determine the cause of overheating, or call for service personnel.

- If the air filter indicator lamp (12/32) lights up, perform the necessary air filter maintenance.




Fig. 12-Operation

4.3.3 Switching off the engine



Do not switch the engine off when running at full throttle, but allow it to run for a short time without load at low idle-running speed.

- Turn the ignition key to "0".
- The engine stops automatically.

4 Operation

4.4 Driver's seat / Steering wheel tilt adjustment

Driver's seat

- The comfort seat is spring-mounted with oil-pressure operated shock absorbers.
- The seat meets international quality and safety standards in compliance with ISO 7096 and ISO 6683 (Fig. 13).
 1. Horizontal adjustment
 2. Weight adjustment
 3. Seat back adjustment
 4. Vertical adjustment

Raising seat:

Raise seat until it clicks audibly into place.

Lowering seat:

Raise seat as far as the stop; it then sinks to its lowest position.

Tilt adjustment of steering wheel

- Press lever (14/4) downward.
- Adjust steering wheel tilt-wise.
- Release lever.

Height adjustment of steering wheel (option)

- Draw lever (14/4) upward.
- Adjust steering wheel height-wise.
- Release lever.




Fig. 13-Driver's seat




Fig. 14-Operation

4.5 Heating / Ventilation

Heating

- The heater is connected to the engine oil circuit.
- The fan is operated using the switch (15/44). Temperature is adjusted using the switch (15/43) and can be operated with fresh air and re-circulating air.
- Open aspirating hole (15/12) for re-circulating air mode.
- The air is distributed and aimed as desired by adjusting the air vents.

Ventilation

- In ventilation mode, the valve towards the engine oil circuit remains closed.
- The fan is operated using the switch (15/44).
- The air is distributed and aimed as desired by adjusting the air vents.

Air conditioning (option)

- Operate the air conditioning system using the switch (15/43).

4.6 Light switch in compliance with StVZO

The loader's lighting is switched on and off by turning the steering column mounted switch (15/1).

- | | |
|------------------|------------------------------|
| Setting 0 | Light off |
| Setting 1 | Parking light |
| Setting 2 | Headlamps
(low/high beam) |
- Switch from one to another by lifting the steering column mounted switch (15/1).
- Blue indicator lamp (15/30) lights up for high beam.




Fig. 15 Operation

4 Operation

4.7 Hydroinflation of tires

When the loader is used with a fork lift attachment, the rear wheels may be filled with a water/antifreeze mixture to increase the lifting capacity.

Prepare the mixture in an appropriately sized container. Allow it to cool and stir until there are no more lumps.



Always pour magnesium chloride into the water, not the other way round!

Do not allow the solution to come into contact with eyes, skin or clothing - caustic substance!

Recommendation when filled to 75% with antifreeze protection to -30 °C.			
<i>Values per wheel:</i>			
Type of tire	MgCl₂ ca. kg	H₂O l	Total kg
365/70 SPT	55	70	125
12,5-18 MPT	45	58	104
335/80 XM	59	72	131
365/70 MPT	55	68	123

MgCl₂ = magnesium chloride

H₂O = water

4.8 Driving, steering and braking

4.8.1 Driving



When driving on public roads, the wheel loader, as a self-propelled work machine, is subject to legal regulations valid in the user's country (e.g. in the Federal Republic of Germany, StVZO and StVO).



The vehicle has **two** pre-selection switches for the travel direction which are alternately active.

Change-over by means of the multi-function switch (16/35).

One pre-selection switch for the travel direction (16/36) is located on the instrument panel and another such switch on the joystick (16/7) for the working hydraulics.

The multi-function switch (16/35) is only to be pressed if the machine is at a standstill and when both travel direction pre-selection switches are in neutral position. If the two direction-of-travel pre-selection switches are pressed in a contradictory manner, the machine stops.

When **driving on roads**, the joystick (16/7) for the work equipment must be deactivated by operating the multi-function switch (16/35).

By doing so, the travel direction pre-selection switch on the joystick (16/7) is without function, too.

The direction of travel is pre-selected using the switch (16/36) on the instrument panel.

In **working mode**, the joystick (16/7) for the work equipment must be activated using the multi-function switch (16/35).

By doing so, the switch (16/36) on the instrument panel is without function.

The direction of travel is pre-selected using the travel direction pre-selection switch on the joystick (16/7).




Fig. 16-Operation

4 Operation

Driving off

- Set the travel direction pre-selection rocker switch located on the joystick (17/7) and the instrument panel (17/36) to “O” (neutral position).
- The indicator lamps (17/24 & 17/28) must not light up.
- Start the engine.
- Raise the lift frame as far as the “Travel” height mark (18/1).
- Select “fast” or “slow” range (17/33) as required.
- High-speed version (option) — Select gear range I or II
Observe the indicator lamp (17/58-60).
- Release the parking brake (17/9).
- Set the desired travel direction using the pre-selection switches for the travel direction (17/7 or 17/36).
- The indicator lamp (17/24 or 17/28) lights up.
- Press the accelerator pedal (17/3). The machine only drives off once a certain engine speed is reached.
- Travel speed is increased and decreased using the accelerator pedal. Travel speed directly depends on engine speed.
- The direction of travel may be changed quickly by operating the pre-selectors (17/7; 17/36).

Coming to a halt

- Travel speed is reduced by releasing the accelerator pedal. The hydrostatic travel drive acts as a non-wearing auxiliary brake.
- Operate the braking inching pedal (17/2) as required.
- See also Chapter 4.8.3, “Brakes”.




Fig. 17-Operation




Fig. 18-Height mark

4.8.2 Steering

- The wheel loader has fully hydraulic, proportionally acting articulated steering.
- Priority supply of hydraulic oil to steering through load-sensing system.



In the event of steering malfunctions, determine the cause immediately (see trouble-shooting table) and call for service personnel if necessary.

4.8.3 Braking

Service brake and auxiliary brake

- To bring the machine to a halt, release the accelerator pedal (19/3). The hydrostatic travel drive then acts as an auxiliary brake.
- Press the brake inching pedal (19/2) as required.

Parking brake

- Only apply the parking brake (19/9) if the machine is stationary.



With the parking brake (19/9) applied, the transmission is disabled.

Brake inching mechanism

- The machine features a brake inching mechanism altering the relationship between travel speed and engine speed.
- When the brake inching pedal (19/2) is pressed, travel speed is reduced - irrespective of engine speed - until the machine comes to a stop.

This permits sensitive driving at maximum engine speed, e.g. when loading a truck, where fast working cycles are required.




Fig. 19-Operation

L824-019

4 Operation

4.8.4 Road travel

Before driving on open roads, the following points have to be observed:



The wheel loader must be equipped as stipulated by the regulations authorizing the use of vehicles for road traffic in the user's country.

- Empty the bucket and tilt back completely.
- Attach the protective device on the front bucket edge.
- Secure the side-dump bucket with socket pins.
- Completely retract the high-tip bucket.
- Fold the forks of the fork lift attachment upward, lock in place and secure against lateral shifting.



Rigid forks must be dismantled!

- Raise the lift frame as far as the height mark (18/1) until sufficient ground clearance is secured.
- Set the direction-of-travel pre-selection switches on the joystick (20/7) and the instrument panel (20/36) to "0" (neutral position).
- Switch off the working hydraulics (20/35).



Only press if machine is stationary!

- Check the function of the direction indicators, hazard warning lights, horn, low/high beam.
- Close the cab door.




Fig. 18 Height mark




Fig. 20 Operation

4.8.5 Parking the machine

- Set the direction-of-travel pre-selection rocker switches (21/7 and 21/36) to "0".
- Lower the work equipment to the ground.
- Switch off working hydraulics (21/35).
- Apply the parking brake (21/9).
- Switch off the engine and remove the ignition key.
- Lock the cab after finishing work to keep **unauthorized persons** from getting in.



If necessary, secure the machine with chocks so that it cannot roll away.




Fig. 21-Operation

5 Loading Operation

5.1 General



Every day before commencing work, and after each change of equipment, a check must be carried out to ensure that the work attachment is correctly fastened, and the quick-mount hitch is properly locked.

The bucket must be moved carefully at a low height.

- Before commencing loading work, memorize the lever controls well.
- During loading work, driving and work movements should flow in smooth succession.
- Drive slowly when familiarizing yourself with the controls.

5.2 Loader operation

- Switch on the work equipment (22/35).

Operation — Bucket

- With joystick (22/6)

Operation — Additional control circuit

- Switch on additional control circuit (22/47) — Step 1.
- Press right-hand / left-hand push-button switch (22/5), e.g. open/ close multi-purpose bucket.



The additional control circuit must always be switched off unless additional equipment is actuated.

Continuous operation of additional control circuit

- Set the additional control circuit (22/47) to step 2. The red indicator lamp lights up.



Observe the operating direction of the attachment (e.g. direction of rotation of sweeper).



The additional control circuit must always be switched off unless additional equipment is actuated.




Fig. 22 Operation

5 Loading Operation

Operation of float position



The float position must always be switched off unless actuated.

Set switch (23/48) to "0".

Impulse mode

- Set float position switch (23/48) to "1".
- Place bucket on ground.
- Press switch (23/8).
Float position is activated.

Continuous mode

- Place bucket on ground.
- Set switch (23/48) to "2". The green indicator lamp lights up.




Fig. 23-Operation

5.3 Changing work attachments

5.3.1 General

To achieve maximum utilization of the machine for a variety of applications, a great number of work attachments and accessories are available.

The machine is equipped with a quick-attach system, to shorten the time it takes to change attachments.

When mounting a multi-purpose bucket, front sweeper, etc., an additional control circuit is required.



*It is possible to use, under certain circumstances, the work attachments of predecessor models for our machines. When mounting the work attachments of predecessor models they may have to be adjusted and/ or are subject to utilization restrictions. The mounting of work attachments which are not included in our product range requires our written approval. It is **essential** to consult your dealer **before** mounting such a work attachment.*



When attachments have been removed, they must be secured against overturning to avoid possible injury to persons.

5 Loading Operation

5.3.2 Assembly of work attachments



The bearings of the lift frame, the work attachment and the quick-mount hitch must be free from dirt.

Before disconnecting hydraulic connections, the system must be released from pressure.

Procedure for changing directly mounted work attachments



In the event of a hydraulically actuated attachment, first of all the hydraulic connection must be disconnected (system must be without pressure).

- Rest the attachment on the ground so that it cannot overturn.
- Remove the pin of the linkage and the pin of the lift frame.
- Move the lift frame out of the work attachment and insert a new one.

Procedure for changing work attachments with mechanical quick-attach system



In the event of a hydraulically actuated attachment, first of all the hydraulic connection must be disconnected (system must be without pressure).

- Lower the work attachment to the ground so that it cannot overturn.
- Raise pin (24/2) and open the quick-mount hitch using the control rod (24/1) until the locking bolts are completely retracted.
- Check the function of the quick-mount hitch lock and lubricate the pins if required.
- Attach another work attachment and close the quick-mount hitch until the locking bolts are completely extended and the pin clicks in.
- Ensure that the work tool and the lock are properly seated.
- The control rod is kept in the left-hand storage box in the driver's cab.




Fig. 24-Quick-mount hitch

Procedure for changing work attachments with hydraulic quick-attach system

- Lower the work attachment to the ground so that it cannot overturn.
- Switch off the diesel engine.
- Operate the push-button switches (25/5) for pressure relief.
- In the case of a hydraulically actuated work attachment, the hydraulic connections on both manifold blocks must be disconnected.
- Set ball valve (26/1) to “Unlock quick-mount hitch” position.
- Start the diesel engine.
- Unlock the quick-mount hitch (25/5) and move out of the work attachment.
- Take up new work attachment and lock by pressing the push-button switch (25/5).



Visual check to ensure that the quick-mount hitch is correctly locked.

- Switch off diesel engine.
- Operate push-button switches (25/5) for pressure relief.
- Set ball valve (26/1) to “Quick-mount hitch locked”.
- Connect hydraulically actuated work attachment to connection of additional control circuit.



The additional control circuit (25/47) must be switched off unless a hydraulically actuated additional attachment is connected.




Fig. 25-Operation




Fig. 26-Hydraulic quick-attach system

5 Loading Operation

5.4 Notes on how to work with the machine

5.4.1 Loading

- During transport, the bucket - either filled or empty - must be kept as close to the ground as possible.
- If possible, avoid long transport distances!



For loading, lower the bucket and position the cutting edge parallel to the ground. Reduce speed by inching as required.

Penetrate the bucket in the material to be loaded.

As soon as the bucket is filling, slightly raise the lift frame and tilt back the bucket.

For dumping, raise the bucket until it is above the location where to unload the material and then start to unload.

5.4.2 Scraping, grading

- Lower the lift frame and move the cutting edge in the ground with flat angle of inclination. Do not penetrate too deeply to ensure jolt-free removal of earth.
- During this work, the depth is only to be leveled by moving the bucket in and out.

5.4.3 Excavation work

- To excavate the ditch for the foundation, attempt to dig layers which are as regular as possible.
- Plan the excavation in such a way as to enable the machine to leave the ditch for the foundation forward with the full bucket.
- Attempt to keep the outward run of the ditch for the foundation as flat as possible.

6 Recovery and Transport of the Machine

6.1 Recovery of the machine

Towing of the wheel loader must be restricted to clearing a junction or a road, to prevent damage to the hydrostatic travel drive.

If possible, let the diesel engine run at low idle during towing.

Towing lugs:

Front: right and left on the axle plates

Rear: right and left, bottom, side plates of the rear end



Max. load capacity of towing lugs approx. 4,300 kg.

- Whenever the wheel loader has to be towed, for whatever reason, the "Travel" oil circuit must be opened so that the hydrostatic transmission no longer acts as an auxiliary brake.
- At the two high-pressure relief valves (27/1) with bypass (in the connecting plate of the hydraulic pump), loosen the nut (28/2) and screw in screw (28/1) until it is level with the nut.
- Tighten the nut (28/1).
- After towing, screw back screw (28/2) until the stop.
- Re-tighten the nut (28/1).



Absolute cleanliness is essential when working on the hydraulic system. Always secure the machine with chocks and relieve the hydraulic system of pressure before carrying out maintenance and repair work.




Fig. 27 Hydraulic pump




Fig. 28-HP-relief valve

6 Recovery and Transport

6.2 Loading the machine using a crane



Use a crane harness and a crane with sufficient lifting capacity!

To load the machine by use of a crane, the following steps must be taken:

- Empty the bucket and tip back.
- Move the lift frame to travel position.
- Apply the pin of the articulation lock (29/1).
- Turn off the engine.
- Dismount from the machine and close the doors.
- Attach the loader to the hoisting appliance at the specified, marked points (Fig. 29) in the correct manner.

6.3 Transporting the machine

To transport the machine onto a flat bed trailer, railway goods wagon, etc. the following steps must be taken:

- Empty and fold in the bucket.
- Move the machine onto the flat bed trailer, goods wagon, etc., or lift by crane if required.
- Apply the articulation lock (30/1).
- Place the work equipment on the ground.
- Stop the engine.
- Dismount from the machine and close the doors.
- Attach the machine at the points illustrated (Fig. 30) in the correct manner.



Be aware of the total transport height.

Risk of accident when driving in tunnels, under bridges, etc.!




Fig. 29-Loading the machine using a crane




Fig. 30-Lashing for transport

7 Care and Maintenance

7.1 General notes

The good operating condition and life expectancy of machines are largely influenced by care and maintenance.

For this reason, it is in every machine owner's interest to perform the specified maintenance work and comply with the service intervals. This Chapter deals in detail with periodic maintenance, inspection and lubricating tasks.

The type-specific maintenance and inspection plan lists all work to be performed on the machine at regular intervals. Maintenance and inspection plans for this purpose are contained in every instruction book.

It is essential that the recommendations in Chapter 2, "Safety and Prevention of Accidents" are observed.

7.2 Intervals

First inspection	once before first putting into operation	Chapter 7.8.1
Daily jobs	every 10 operating hours or every work shift ¹⁾	Chapter 7.8.2
Weekly jobs	weekly or after 50 operating hours ¹⁾	Chapter 7.8.2
100 operating hours	once after first putting into operation ²⁾	Chapter 7.8.4
Every 500 operating hours	after every 500 operating hours or 6 months	Chapter 7.8.4
Every 1,000 operating hours	after every 1,000 operating hours or 12 months	Chapter 7.8.4
Every 2,000 operating hours	after every 2,000 operating hours or 2 years	Chapter 7.8.4
¹⁾ whichever comes first		
²⁾ also applicable when new or overhauled diesel engines are put into operation		

7 Care and Maintenance

7.3 Regular oil analyses

Oil analyses are not intended as a substitute for the oil change intervals but – apart from a possible reduction of maintenance costs and as a form of preventive maintenance – they take into account the increasing environmental awareness.

Advantages of an oil analysis

- Extension of the oil change intervals under standard or light-duty operating conditions.
- Minimum wear of high-quality components with optimum use of the lubricants.
- Periodic laboratory analyses enable an early detection of imminent damage.
- Repairs performed before they actually become absolutely necessary help prevent serious and unexpected damage.
- Sequential damage can be avoided.

Oil analysis intervals

Periodic oil analyses reveal trends in the condition of the oil and the machine.

When the scheduled oil change intervals have been reached, the oils should be analyzed in the following intervals to check their quality and thus extend the oil change intervals:

- Hydraulic oil: 1,000 operating hours
- Transmission oil: 500 operating hours
- Engine oil: 100 operating hours

Based on the first results, the laboratory recommends the interval for the next sampling.

Ask your **TEREX Schaeff** dealer for an information booklet detailing the scope and procedures of the oil analysis.

7.4 Warranty

During the warranty period thorough inspections are stipulated, which must be carried out by trained specialist dealer personnel.



The inspections are obligatory and must be paid for.

The performance of inspections as specified must be confirmed on the inspection cards in the warranty / handing over certificate.

If they are omitted, the warranty may be subject to restrictions.

7.5 Inspection parts and aids

Service parts	Spare parts number
Hydraulic oil filter insert, suction filter	5 003 660 417
Breather with screen element	5 003 650 362
Engine oil filter	5 411 656 547
Fuel filter with seal	5 411 656 301
Air filter - main cartridge	5 501 660 912
Air filter - safety cartridge	5 501 660 914
V-belt 10 x 1,275	5 411 657 050
Cylinder head cover gasket	5 411 656 457
Service Packs	
Service Pack "Classic" — inspection after 100 h	MPS 824 001C
Service Pack "Classic" — inspection every 500 h	MPS 824 002C
Service Pack "Classic" — inspection every 1,000 h	MPS 824 003C
Extras	
TEREX Schaeff hydraulic oil, mineral	4 312 005 050
TEREX Schaeff hydraulic oil, biodegradable	For further information, please contact your TEREX Schaeff dealer
Transmission oil	4 314 005 775
Engine oil	4 312 905 759



Maintenance parts for inspections should be ordered well in advance!

*Observe our offer about **Service Packs** for inspections. **Contact your dealer!***

Lubricants

- The machine's life expectancy and operating condition largely depend on the use of the specified lubricants and compliance with the service intervals.
- If lubricants which do not conform to our recommendations are used, consequential damage may occur for which we will not assume liability, even inside the warranty period.
- For lubricant specifications see Chapter 3.9.

7 Care and Maintenance

7.6 Care and cleaning



The machine must be cleaned on a suitable surface with an oil separator.

- Neither a steam-jet appliance nor a high-pressure cleaning apparatus are to be used for cleaning during the first two months after the machine is used for the first time or when newly painted to avoid damage to the paint.
- Do not use aggressive detergents for cleaning the machine. We recommend using commercially available cleaning agents for passenger cars.
- When cleaning with a steam-jet appliance, the hot water jet is not to exceed 80 °C and a spray pressure of 70 bar.
- Linings (insulating materials, etc.) are not to be exposed directly to water, steam or high-pressure jets.
- When cleaning with water or steam jets, take care not to spray exhaust-gas and air filter openings.
- If cleaning the engine with water or steam jets, do not expose sensitive engine parts, such as generator, cabling, oil pressure switch, etc. directly to the jet.
- After each wet clean, the machine must be lubricated in accordance with the lubricating plan and a test of all work cycles, steering and driving functions carried out.

7.7 Notes for winter operation

The following points - and the relevant notes in the engine instruction book - should be observed during winter operation.

Hydraulic oil

- If the machine is not used for longer periods at temperatures around and below freezing, warm up the engine by running at medium revs for approx. 3-5 min.

Engine oil

- The oil viscosity (SAE class) should be selected in compliance with the ambient temperature at the machine's place of operation.

Battery charge

- A good cold start performance requires a well-charged battery. By warming the battery to approx. +20° (remove the battery after the engine has been turned off and store it in a warm room), the minimum starting temperatures can be lowered by 4-5 °C.
- When installing the battery, ensure good contact of terminal connections.
- Only tighten terminal screws so that they are "hand-tight", to prevent deformation of the terminal posts!

Fuel

- Only use commercially available brand-name diesel fuel with a sulfur content of less than 0.5 %.
- In winter, only use winter diesel fuel to prevent clogging of the fuel system due to paraffin separation. Even if winter diesel fuel is used, disturbing paraffin separations (jelling) can occur at very low temperatures.
- If only summer diesel is available, or if winter diesel must be used at very low temperatures, we recommend the addition of petroleum (Fig. 36) or additives.
- These mixtures should only be used temporarily, **not for longer periods.**



Only mix the components in the tank. First fill in the necessary quantity of petroleum, then add the diesel.



Additives should be chosen in compliance with the recommendations of your fuel supplier.



Petrol is not to be added.

Danger of explosion!




Fig. 36 - Table for the addition of petroleum or additives

A = Summer diesel

B = Winter diesel

C = Added proportion of petroleum

D = Outside temperature

7 Care and Maintenance

7.8 Checking, maintenance and inspection plans

7.8.1 Initial inspection (delivery/ handing-over inspection)




Fig. 31 Initial inspection

Jobs to be carried out by trained dealer service personnel

		Chapter
1	Check whether machine-specific instruction book is in the machine	--
2	Check engine oil level	7.9.1
3	Hydraulic oil level	7.9.9
4	Check fuel level	7.9.4
5	Oil level check: differential and axle hubs	7.9.13
6	Check tire pressure and tightness of wheel nuts	7.9.14
7	Check brake oil level	7.9.8
8	Battery: electrolyte level and charge condition	7.9.17
9	Top up windshield washer system	7.9.19
10	Grease machine (all lubricating points)	7.8.3
11	Test run, hydraulic function check and test work	--
12	Visual inspection for tightness of all hoses, pipes, cylinders, etc.	--
13	Check function of electrical indicating and warning elements, and the lighting system	--
14	Initial delivery/ handing-over certificate and return to manufacturer	--

7 Care and Maintenance

7.8.2 Daily and weekly tasks

Inspection and maintenance jobs to be performed by operating personnel:








Fig. 32 Inspection and maintenance plan

Daily		Chapter
1	Check hydraulic oil level	7.9.9
2	Check engine oil level	7.9.1
3	Check fuel level (fuel gauge on instrument panel)	7.9.4
4	Check water level for windshield wiper	7.9.19
5	General visual inspection for material cracks, external damage, completeness, etc.	--
6	Check for leaks in: pipes, hoses, control valve, hydraulic pumps, cylinders, etc.  <i>When tightening hoses or pipeline connections, counterlock fittings to prevent turning.</i>	--
7	Check electrical indicating and warning elements, and the lighting system	--
8	Check smooth running of operator controls	--

Weekly		Chapter
11	Clean cooling fins of the hydraulic oil cooler  <i>In case of extreme exposure to dust, shorten cleaning intervals.</i>	7.9.10
12	Clean cooling fins of the engine oil cooler  <i>In case of extreme exposure to dust, shorten cleaning intervals.</i>	7.9.3
13	Check that door catches function perfectly	--
14	Check tire pressure and tightness of wheel nuts	7.9.14
15	Check fastening of axles and propeller shaft	--
16	Check bushings and bolts of the work equipment	--
17	Check bolts, bushings and the linkage of the articulated steering	--
18	Check that pneumatic springs of engine hood function perfectly	--
19	Drain fuel filter	7.9.4
20	Check brake oil level	7.9.8
21	Check function of brakes	--
22	Check if the dust filter for cab ventilation is dirty and clean if required  <i>In case of extreme exposure to dust, shorten cleaning intervals.</i>	7.9.18
23	Check function, condition and completeness of safety devices	--
24	Grease machine in compliance with overview of lubricating points	7.8.3

7 Care and Maintenance

7.8.3 Overview of lubricating points



Replace damaged grease nipples immediately and check if grease passes through!




Fig. 33 Lubrication chart

Grease all lubricating points with multi-purpose grease.

The intervals stated are valid for one-shift operation

Item	Lubricating point	Qty.	daily	weekly	Chapter
1	Tilt cylinder - Tilt lever	1		X	--
2	Lift frame - Tilt lever	1		X	--
3	Lift cylinder - Lift frame	1		X	--
4	Tilt cylinder - Front end	1		X	--
5	Lift frame - Front end	2		X	--
6	Lift cylinder - Front end	1		X	--
7	Lift frame - Quick-mount hitch	2		X	--
8	Linkage - Quick-attach system	1		X	--
9	Tilt lever - Linkage	1		X	--
10	Quick-mount hitch, mechanical	3		X	--
	Quick-mount hitch, hydraulic	2		X	--
11	Steering cylinder - Front end	1		X	--
12	Pivot point	3		X	--
13	Steering cylinder - Rear end	1		X	--
14	Rear axle bearing	1		X	--
15	Door hinges	4		X	--
16	Multi-purpose bucket	2		X	--
17	Multi-purpose bucket cylinder	4		X	--





We recommend that for special operations, e.g. on sandy ground, the lubrication intervals are shortened. Increased frequency of lubrication helps self-cleaning of bearing points.

7 Care and Maintenance

7.8.4 Inspection plan

To be carried out by trained specialist dealer personnel

O = <i>Checking, Maintenance</i> X = <i>Replace</i>		Operating hours				2x min. yearly	1x min. yearly	Chapter
		after 100	every 500	every 1,000	every 2,000			
Perform work with machine at operating temperature								
1	Check whether machine-specific instruction book is in the machine	O	O				--	
2	Change engine oil			X			7.9.1	
3	Change engine oil filter			X			7.9.2	
4	Drain water from fuel tank	O	O			O	7.9.4	
5	Change fuel filter			X			7.9.4	
6	Clean fuel pump and screen filter			O			7.9.4	
7	Check air intake	O	O				7.9.5	
8	Change air filter - main cartridge	to service indicator					X	7.9.5
9	Change air filter - safety cartridge	as required ¹⁾						7.9.5
10	Clean cooling fins of hydraulic oil cooler  <i>In case of high exposure to dust, shorten the cleaning intervals.</i>	O	O			O	7.9.10	
11	Clean cooling fins of engine oil cooler  <i>In case of high exposure to dust, shorten the cleaning intervals.</i>	O	O			O	7.9.3	
12	Check V-belt tension	O		O			7.9.6	
13	Check engine mounts and pump attachments	O	O				--	
14	Check engine speed adjustment, top-end and low idle speed	O	O				--	
15	Check valve lash of engine and adjust if necessary			O			7.9.7	
16	Check injection valves				O		7.9.15	
17	Check fuel leak-oil pipe and replace if necessary			O	X ¹⁾		7.9.4	
18	Replace toothed belt ³⁾						7.9.16	
19	Check crankcase breather in valve cover				O		--	
20	Check acid level and battery connections	O	O				7.9.17	
21	Check condition of tires, tire pressure and tightness of wheel nuts	O	O				7.9.14	
22	Check secure fastening of axles and propeller shaft	O	O				--	
23	Check bearing bushings and bolts of work equipment and replace if necessary	O	O				--	
24	Check bushings and bolts of the articulation and the articulated steering and replace if necessary.	O	O				--	
25	Check that door catches function perfectly, and replace if necessary	O	O				--	
26	Clean or replace the dust filter for cab ventilation	O		X			X 7.9.18	

O = <i>Checking, Maintenance</i> X = <i>Replace</i>		Operating hours				2x min. yearl y	1x min. yearl y	Chapte r
		after 100	every 500	every 1,000	every 2,000			
Perform work with machine at operating temperature								
27	Check electrical indicating and warning elements, and lighting system	O	O				--	
28	Check smooth running of operator controls and adjust if necessary	O	O				--	
29	Check tightness of all pipes, hoses, control valve, hydraulic pumps, cylinders, etc.  <i>When tightening hose and pipe connections, screw-in couplings must be locked to prevent rotation.</i>	O	O				--	
30	Check or change hydraulic oil	O	O	X ²⁾			X 7.9.9	
31	Replace insert of hydraulic oil return suction filter	X	X			X	7.9.11	
32	Replace breather			X			X 7.9.12	
33	Check function of brakes and replace brake oil	O	O		X		X 7.9.8	
34	Bleed brake	O	O				7.9.8	
35	Rear axle differential with transmission / option: manual transmission: oil check or oil change	X	O	X			X 7.9.13	
36	Front axle differential - oil check or oil change	X	O	X			X 7.9.13	
37	Wheel hubs of front and rear axles: oil check or oil change	X	O	X			X 7.9.13	
38	Grease machine in compliance with overview of lubricating points	O	O				7.8.3	
39	Check function, condition and completeness of safety equipment	O	O				--	
40	Hydraulic function check with pressure function test	O	O				--	
41	Test run and test work	O	O				--	
42	Initial inspection cards and return to manufacturer	O	O ⁴⁾				7.4	

1) at least every 2 years

2) Extension of oil change intervals in compliance with oil sample analysis and lab report.

For further information see Chapter 7.3

3) Every 5 years or 5,000 operating hours respectively

4) within warranty



Observe our offer about **Service Packs** for inspections. **Contact your dealer!**

7 Care and Maintenance

7.9 Inspection and maintenance work

7.9.1 Engine oil

Checking the engine oil level

- Check the oil level daily before starting, with the machine parked on level ground.
- The notches on the oil dipstick (35/1) indicate the min. and max. oil levels.
- If necessary, top up engine oil. Unscrew the cap (35/2) and top up oil using a clean container.

Changing engine oil



Collect the waste oil, do not allow it to seep into the ground.

Dispose of in compliance with regulations!

- Run the engine until it reaches operating temperature, engine oil temperature approx. 80 °C.
- Park the machine on a level surface.
- Stop the engine.
- Remove the cover on the bottom of the rear end.
- Place suitable oil drip pans below the opening.
- Screw the oil drain hose onto the oil-change valve (35/3).



Danger of scalding when hot oil is drained!

- Open the drain plug (35/5) on the oil cooler.
- Remove the oil drain hose and screw the protective cap onto the valve.
- Carefully close the drain plug on the oil cooler.
- Close the service opening with the cover.
- To change the engine oil filter (35/4), see Chapter 7.9.2.

- Top engine oil up to the “MAX” mark on the oil dipstick (35/1) using the filler hole (35/2).
- Start the engine and run at low idle speed for approx. 2 min.
- Open the vent valve (35/6) to eliminate air from the oil cooler.
- Switch off the engine.
- Check the oil level and top up oil if necessary (empty cooler has filled with oil).
- Start the engine and run at low idle speed for approx. 2 minutes.
- Switch off the engine.
- Check the oil level and top up oil if required.





Fig. 35 Engine oil

7.9.2 Engine oil filter

The engine oil filter must be replaced with every engine oil change.

- Place oil drip pan below the engine oil filter.
- Clean the outside of the engine oil filter.
- Unscrew the filter cartridge (36/4) using a commercially available tool and check that the fastening stud is firmly secured in the filter head.
- Dispose of the filter cartridge in compliance with regulations.
- Check filter head condition and clean.
- Fill the new filter with oil, wet the sealing ring with oil and tighten firmly by hand
- After a test run, check the tightness of the engine oil filter cartridge.



L824-036

Fig. 36 Engine oil filter

7.9.3 Engine oil cooler



Only clean the cooler with the engine switched off and cooled down!


- Clean the engine oil cooler (37/1) from the outlet side with compressed air.



If necessary, clean with cold detergent or steam jet on a suitable surface with an oil separator.

Do not expose the generator directly to the water or steam jet.

Bring engine to operating temperature to prevent corrosion.



L824-037

Fig. 37 Engine oil cooler

7 Care and Maintenance

7.9.4 Fuel system

Checking the fuel level

- Check the fuel level on the fuel gauge (38/27).
- To prevent condensation from forming before the machine is next put into operation, top up the fuel every day after use.

Draining water from the fuel filter

- Open the fuel filter on the water drain pipe (39/2) until pure fuel escapes.
- Close again the water drain pipe.

Replacing the fuel filter

- Clean the outside of the fuel filter (39/1).
- Release the filter cartridge using a commercially available tool and unscrew. Ensure that the fastening stud is firmly secured in the filter head.



Collect the fuel and dispose of in compliance with regulations!

- Dispose of the filter cartridge in compliance with regulations.
- Check filter head condition and clean.
- Wet the seal on the new filter with oil or fuel respectively and tighten firmly by hand.
- Check tightness.



The fuel system does not have to be vented.

Fuel tank

- Drain water from the fuel tank through the drain plug (40/1).
- Clean the filler screen (40/2) and check for damage.




Fig. 38 Operation




Fig. 39 Fuel filter




Fig. 40 Fuel tank

Cleaning the fuel pump screen filter

- Close the fuel shut-off.
- Loosen the hex head screw (41/1) and unscrew.
- Take out the fuel screen (41/2 — cover and screen in one unit).
- Clean the fuel screen in fuel. Replace if required.
- Insert the seal rings properly (41/3; 41/4).
- Mount the cover fuel screen (41/2) and tighten the screw.
- Open the fuel shut-off.
- Check the tightness.




Fig. 41 Fuel pump

Replacing the fuel leak-oil pipe

- Close the fuel shut-off.
- Separate the rubber hoses (42/3) from the injection valves.
- Separate the rubber hose (42/1) from the fuel tank.
- Separate the rubber hoses (42/4; 42/3; 42/1) from the couplings (42/2).
- Dispose of the rubber hoses (42/4; 42/3; 42/1) in compliance with regulations.
- Connect the new rubber hoses with the couplings.
- Connect the rubber hoses (42/3) to the injection valves.
- Connect the rubber hose (42/1) to the fuel tank.
- Open the fuel shut-off.
- Check tightness.




Fig. 42 Fuel leak-oil pipes

7 Care and Maintenance

7.9.5 Air filter, air intake



All maintenance work on the air intake system must be carried out with the engine off.

Do not start the engine while the filter cartridge is removed.

7.9.5.1 Dust extraction valve

- Dust extraction valves (43/1) are largely maintenance-free.
- Any baked-on dust can be removed by squeezing the valve together.

7.9.5.2 Air intake

- Check the air filter attachment and retaining straps for damage.
- Check the tightness of the air intake between the air filter and the engine.
- Examine rubber parts for damage.



Replace damaged parts immediately.

7.9.5.3 Cartridge maintenance interval

Air filter — Main cartridge

- The air filter main cartridge must be replaced as soon as the filter maintenance indicator lamp (44/32) on the instrument panel lights up during operation.
- Brief delay in maintenance does not result in lower filter efficiency.

Air filter — Safety cartridge

The air filter safety cartridge must be replaced in the following cases:

- After the fifth maintenance of the main cartridge
- After 2 years of operation at the latest
- If the service indicator switches on after the main cartridge has just been serviced
- If the main cartridge is damaged
- If the safety cartridge is damaged




Fig. 43-Air filter




Fig. 44-Operation

7.9.5.4 Replacing cartridges

Main cartridge

- Release the wire fasteners (45/1) and remove the bottom of the housing (45/4).
- Withdraw the main cartridge (45/2) by twisting slightly to and fro.
- Check whether the safety cartridge (45/3) must be replaced.



Remove safety cartridge **only** in the case of necessary maintenance work. Only open the seal (45/5) of the safety cartridge for the purpose of replacement.

- Note down the date of maintenance in the appropriate sections of the safety cartridge (45/3).
- Insert the new or cleaned main cartridge carefully into the filter housing starting with the open side and check that it is correctly positioned.
- Fit the lower part of the housing. (Pay attention to the position of the dust extraction valve).
- Place the wire fasteners in the groove of the flange on the filter housing and tighten.

Safety cartridge

- Remove the main cartridge.



Do not clean the safety cartridge and, once it has been removed, **do not use it again**.

- Using a suitable tool (e.g. screwdriver), pierce the seal (45/5) of the safety cartridge (45/3) from the inside, then lift up the two clips (45/6).
- Grasp the safety cartridge (45/3) by the two clips (45/6), withdraw by twisting slightly to and fro, and dispose of it.
- Insert a new safety cartridge and check that it is correctly positioned.
- Install the main cartridge.




Fig. 45-Air filter cartridge replacement

HR32-053

7 Care and Maintenance

7.9.5.5 Cleaning the main cartridge



Never wash or brush out the main cartridge.

When blowing out, ensure that dust does not land on the inside of the main cartridge.

- The main cartridge can be cleaned up to five times if necessary. It must be replaced once it reaches its maximum service life of two years, at the latest. The number of times it is cleaned must be marked.
- For cleaning (46/1), a pipe the end of which is bent at 90° should be attached to a compressed-air pistol. It must be sufficiently long to reach the floor of the cartridge. Blow out the main cartridge from the inside to the outside with dry compressed air (max. 5 bar) by moving the pipe up and down in the cartridge. Continue until no more dust escapes.
- Check the clean main cartridge for damage to the paper bellows and rubber seals (46/2). Tears and perforations in the paper bellows can be determined using a torch.



Never continue to use damaged main cartridges. If in doubt, use a new one.




Fig. 46 Cleaning the main cartridge

7.9.6 V-belts

Checking the condition of V-belts



Only check and tension V-belts with the engine off!

Danger of injury!

- Visual check of the complete V-belts.



Replace worn or damaged V-belts immediately.

Checking the V-belt tension



To check the V-belt tension, a tension gauge is recommended. Check the tension in compliance with the manufacturer's operating instructions.

Checking the V-belt tension without a tension gauge

- To check the tension, press the V-belt with your thumb in the middle of the greatest free length, and measure the sag.
- Using medium thumb pressure of approx. 45 N, the V-belt sag (A) should equal 10 – 15 mm.

Tensioning V-belts

- Slacken the fastening screws (47/1).
- Rotate the generator (47/2) until the tension is correct.
- Tighten the fastening screws.
- Check the tension once more.

Replacing V-belts

- Slacken the fastening screws (47/1).
- Swivel the generator against the direction of tensioning.
- Remove the used V-belt and fit new one.
- Swivel the generator (47/2) in the direction of the arrow until the V-belt tension is correct.
- Re-tighten fastening screws.
- Check tension once again.



When new V-belts are fitted, their tension must be checked and adjusted if necessary after the first 15 min.




Fig. 47 V-belts

7 Care and Maintenance

7.9.7 Checking the valve lash

- The valve lash (48/1) is tested by means of a reed gauge placed between the upper part of the valve stem (48/3) and the rocker arm (48/2) on the cold engine.
- The correct valve lash is
 - 0.30 mm for the inlet valve and
 - 0.50 mm for the exhaust valve.

Valve setting

- Remove the cylinder head cover.

Crankshaft position 1:

- Turn the crankshaft until both valves intersect at the 1st cylinder (exhaust valve not yet closed, inlet valve begins to open).
- The valves marked black can be adjusted. To check the completed adjustment, mark the respective rocker arm with chalk.

If required, adjust valve lash. To do so, proceed as follows:

- ⇒ Slacken the lock nut (48/4).
- ⇒ Using a screwdriver, adjust the setting screw (48/5) in such a manner that the correct valve lash (48/1) is obtained when the lock nut is tightened.

Crankshaft position 2:

- Turn the crankshaft further by one full turn (360°).
- The valves marked black can now be adjusted.
- Re-mount the cylinder head cover with the new seal.




Fig. 48 Valve setting

Crankshaft position 1

Crankshaft position 2

7.9.8 Brakes

Checking the brake oil level

- Visual inspection (49/1) of the brake oil level.



Only top up with ATF-oil!

Changing brake oil and bleeding the brake




*Collect the waste oil, do not allow it to seep into the ground. **Dispose of in compliance with regulations!***




A bleeding device must be employed when changing brake oil and bleeding brakes.

- Remove the cover up front above the axle.
- Release the bleeder screw (50/1), connect the bleeder hose and insert it into collecting bottle.
- Connect the bleeding device on the brake oil container (49/1).
- Change brake oil and bleed the brake in compliance with the bleeding device instruction book.
- Remove the bleeder hose and re-tighten the bleeder screw.
- Release the bleeder screw (50/2) on the inch valve of the "travel" hydraulic pump; connect the bleeder hose and insert it in the collecting bottle.
- Start to bleed.
- Remove the bleeder hose and tighten the bleeder screw.
- Dismount the bleeding device and close the brake oil container with its original cover.
- Re-fit the cover up front.



L824-049

Fig. 49 Brake oil



L824-050

Fig. 50 Bleeding the brake

7 Care and Maintenance

7.9.9 Hydraulic oil

Checking the hydraulic oil level

- Check the oil level using the oil dipstick (51/1).
Top up hydraulic oil if required.

Hydraulic oil change



Danger of scalding from hot oil!

- Retract all hydraulic cylinders.
- Stop the engine.
- Unscrew the oil dipstick (51/1).
- Remove the drain plug (51/4) from the hydraulic oil tank and drain oil into a clean container.



Collect the waste oil, do not allow it to seep into the ground. Dispose of in compliance with regulations!

- Flush and clean the hydraulic oil tank as required (to do so, remove the complete suction filter, 51/2).
- Screw back on the drain plug carefully.
- Fill up with clean hydraulic oil via the breather. To do so, remove filter head (51/3).
- Screw back on the breather head.
- Screw back in the oil dipstick.






Fig. 51 Hydraulic oil tank

7.9.10 Hydraulic oil cooler

 *Dirt accumulation in coolers causes the hydraulic oil to overheat. Only clean coolers with the engine turned off and cooled down.*

- The cooler for hydraulic oil (52/1) is cleaned from the outlet side with compressed air.

 *If necessary, clean the machine using cold detergent or a steam jet device on a suitable surface with an oil separator. Do not expose the generator to direct water or steam jet.*

After cleaning, bring the engine to operating temperature to prevent corrosion.




Fig. 52 Hydraulic oil cooler

7 Care and Maintenance

7.9.11 Hydraulic oil filter



After a larger repair job, following the test run the filter cartridge of the hydraulic oil filter must be renewed as well.

Replacing the filter insert

- Unscrew the oil dipstick (51/1).
- With the aid of a tool, remove the filter cover (53/1).
- Remove the filter element (53/5) along with the inlet connection (53/3) by pulling and turning at the same time.
- Remove the filter element from the inlet connection and dispose of in compliance with regulations.
- Ensure that the seal (53/2) in the cover and the O-ring (53/4) on the inlet connection are in faultless condition and replace any damaged parts.
- Insert a new filter element on the inlet connection and insert together in filter.
- Screw on the filter cover (53/1) and tighten (20 Nm).
- Screw back in the oil dipstick.
- Check the tightness of the filter by means of a test run.




Fig. 51 Hydraulic oil tank




Fig. 53 Hydraulic oil filter

7.9.12 Breather



Replace the breather if it is dirty, e.g. due to hydraulic oil vapor.

- Unscrew the oil dipstick (54/1).
- Remove the breather (54/2) and dispose of in compliance with regulations.
- Clean the screen (54/4) and check for damage. Replace if required.
- Screw in new breather (54/2) with O-ring (54/3) and tighten by hand.
- Screw back in the oil dipstick.




Fig. 54 Breather

7 Care and Maintenance

7.9.13 Axles

General

The axle oil must be changed at operating temperature.



Collect waste oil, do not allow it to seep into the ground.

Dispose of in compliance with regulations!



After filling the axles with oil, move the machine for approx. 5 minutes, to ensure that the oil is evenly distributed.

Check the oil level again, and top up if necessary.

7.9.13.1 Front axle differential

Checking the axle oil level

- Remove the inspection plug (55/1), check and top up oil if required.

Changing axle oil

- Park the machine on level ground.
- Open the inspection/ filler plug (55/1).
- Open the drain plug (55/2) on the differential and drain oil.
- Flush out the axle if necessary.
- Carefully close the drain plug.
- Pour in oil via the inspection/ filler hole until oil escapes.
- Carefully close the inspection/ filler plug.




Fig. 55 Front axle

7.9.13.2 Differential of rear axle with transmission

Checking the axle oil level

- Remove the inspection plug (56/1), check and top up oil if required.

Changing axle oil



The rear axle differential and the transmission have combined oil filling.

- Park the machine on level ground.
- Open the inspection/ filler plug (56/1).
- Open the drain plugs on the differential (56/2) and the transmission (56/3) and drain the oil.
- Flush out the axle if necessary.
- Carefully close both drain plugs.
- Pour in oil via the inspection/ filler hole (56/1) until oil escapes.
- Carefully close the inspection/ filler plug.




Fig. 56 Rear axle

7 Care and Maintenance

7.9.13.3 Wheel hub

Checking the axle oil level

- Remove the inspection plug (57/1), check and top up oil if required.

Changing axle oil



The wheel hub has a combined inspection, filler and drain plug!

- Turn the wheel until the screw plug (57/1) on the hub is at the bottom.
- Open the screw plug and catch the escaping oil.
- Flush out if necessary.
- Turn the wheel to the filling and inspection position: The inspection mark must be horizontal.
- Fill in oil up to the lower edge of the hole.
- Carefully close the screw plug.




Fig. 57 Wheel hub

7.9.14 Wheels

Checking the tire pressure

- Check the tire pressure in accordance with the pressure chart, Chapter 3.8.

Tightness of wheel nuts

- During the first 50 operating hours, check the tightness of the wheel nuts (M18 x 1.5) daily, and subsequently every week, and tighten to the correct torque if necessary.



Tightening torque: 325 Nm

- When fitting a wheel, tighten the nuts to the correct torque crosswise in several stages.

7.9.15 Injection valves

- Injection valves must be checked by your service specialist.

7.9.16 Toothed belt for engine

- The toothed belt must be replaced by your service specialist.

7.9.17 Electrical equipment

Battery



The instructions of the battery manufacturer must be observed when using the battery for the first time.

- The acid level should be approx. 10 mm above the edges of the plates. If necessary, top up with pure distilled water.
- Only check the battery with the engine off.



With maintenance-free batteries, this check can be omitted.

Removing the battery

- Disconnect first the battery ground cable (-), then the positive cable (+).
- Detach the clamping bracket (59/1).
- Lift out the battery.

Installing the battery

- Lay the battery in the machine and secure with the clamping bracket.
- First connect the positive cable (+), then the battery ground cable (-).



Ensure that the negative terminal is connected to the negative pole (-) and the positive terminal to the positive pole (+).

In winter, in particular, the battery charge should be closely monitored.

Lighting and warning equipment

- Check the correct function of the lighting equipment.
- Check the correct function of the indicator lamps.
- Check the correct function of the warning equipment.




Fig. 59 Battery

7 Care and Maintenance

7.9.18 Cab ventilation dust filter

- The air intake for the heating and the fresh air supply of the cab features a dust filter or optionally a charcoal/ pollen filter.

Removal

- Remove the ventilation grid (60/1).
- Remove the angle bracket (60/2).
- Take out the dust filter (60/3).
- Clean the filter or replace it.

Cleaning the dust filter



Never wash or brush out the filter!

- Knock the filter with the intake side (side covered by expanded metal) several times on a flat and hard surface.
- Using dry compressed air (max. 5 bar), blow against the direction of flow.
- Check the filter for damage to the paper bellows and seals.



Never continue to use damaged filters!

Re-installation

- Re-insert new or cleaned dust filter until the stop.



Observe the mounting position!

The air flow arrows must point towards the cab.

- Fasten the dust filter with the angle bracket.
- Re-fit the ventilation grid.

7.9.19 Windshield washer system

- Top up the washer tank (61/1) as required.
- Add antifreeze when temperatures are around or below freezing.




Fig. 60-Dust filter for cab ventilation




Fig. 61 Windshield washer tank

7.10 Shutdown

7.10.1 Preservation (temporary shutdown)

To prevent damage (corrosion, etc.) from storage during shutdown periods over three months, certain preservation measures must be taken:

- We recommend keeping the machine in a dry, dust-free room during the storage period.
- Clean the inside and outside of the machine thoroughly, including the engine.
- Lubricate the machine in compliance with the lubrication plan.
- Check the oil levels of all assemblies, such as axles, transmission(s), etc. and top up if necessary.
- Check the hydraulic oil level and top up if necessary.
- Repair paint damage.
- Fill the diesel tank completely, to prevent corrosion of the tank walls.
- Check the antifreeze level in the coolant and adjust if necessary.
- Perform all the preservation measures contained in the diesel engine operating instructions.
- Check the tire pressure in compliance with the prescribed value and protect the tires from direct sunlight.
- Treat bare piston rods with a commercially available anti-corrosion agent.
- Remove and clean the battery and keep it in compliance with regulations in a dry - in winter, frost-proof - room. Coat connections with a little pole grease.
- Seal off the air intake opening of the air filter system and the exhaust pipe opening.

7.10.2 During shutdown

- When the machine is out of use for 6 months, after this time all assemblies must be brought to operating temperature and maneuvered for approx. 15 minutes.
- Beforehand, the anti-corrosion coat must be removed from the piston rods, and the openings of the air filter system and the exhaust pipe freed.
- After the maneuvering cycle, preserve the machine once more as previously described.

7.10.3 After shutdown

Before putting the machine into operation once more, the following measures must be carried out:

- Anti-corrosion coat must be cleaned from the piston rods.
- Seal off the air intake opening of the air filter and the exhaust pipe opening.
- Remove the air filter insert, check its condition and replace if necessary.
- Check the condition of the air filter main cartridge / safety cartridge and replace if required.
- Clean the machine with a neutral detergent.
- Check and - if required - re-charge and re-install the battery.
- Carry out all measures for putting the diesel engine back into operation stated in the engine operating instructions.
- If the machine has been out of use for more than 6 months, the oil in the assemblies such as axles, transmission(s), etc. must be changed.
- If hydraulic oil filters such as suction and return filters as well as breathers have been out of use for more than 6 months, they must be replaced.
- Lubricate the machine in compliance with the lubrication plan.

8 Trouble-Shooting

8.1 General

Operating problems are often the result of incorrect handling of the machine, the use of unsuitable materials or irregular maintenance.

The following table presents a summary of a range of problems and their probable causes.

If a problem can only be eliminated through repair, then the responsible Service Agent must be called in.

8.2 Engine

All faults in the diesel engine must be examined as described in their specific engine operating instructions.

During the warranty period, malfunctions must be dealt with by the responsible Service Agent or a specialist workshop.

<i>Fault</i>	<i>Possible cause</i>	<i>Remedy</i>
8.3 No steering movement		
1	Oil supply to pump interrupted	Check and repair suction line
2	Hydraulic pump damaged	Repair or replace
3	Priority valve damaged	Remedy fault (call Service Agent)
4	Steering control unit damaged	Remedy fault (call Service Agent)
5	Steering cylinders damaged	Repair
6	Mechanical fault	Repair
8.4 Insufficient performance of service brake		
1	Wear of drum brake	Adjust or repair (call Service Agent)
2	Master brake cylinder damaged	Repair or replace (call Service Agent)
3	Mechanical fault	Repair (call Service Agent)
8.5 Insufficient performance of parking brake		
1	Wear of drum brake	Adjust or repair
2	Mechanical fault in brake actuation	Repair and/ or re-adjust
8.6 Hydrostatic travel drive has no neutral position		
1	Switch for direction of travel damaged	Repair or replace
2	Solenoids of valve damaged	Repair or replace
3	Neutral position has shifted	Check, re-calibrate (call Service Agent)
4	Internal damage to travel pump	Replace travel pump
5	Excessive engine idling	Adjust

8 Trouble-Shooting

<i>Fault</i>	<i>Possible cause</i>	<i>Remedy</i>
8.7 Hydraulic oil exceeds max. admissible temperature		
1	Thermo switch damaged	Replace
2	Oil level too low	Top up oil to mark on dipstick
3	Oil cooler clogged or faulty	Clean, check, replace if necessary
4	Suction filter clogged	Replace
5	High-pressure valves do not respond all the time or too early	Check high-pressure valves, re-adjust or replace if necessary
6	Flushing circulation does not function	Check pressure of flushing and filling pump, possible back pressure in cooling circuit, check housing pressure
7	Travel pump or travel motor damaged (worn)	Replace
8	Charge pump worn	Replace
9	Main relief valve damaged	Replace
8.8 Sluggish acceleration and deceleration, too little propulsive power		
1	Insufficient engine power	Check diesel engine
2	A brake has got stuck	Check, remedy damage
3	No tank pressurization	Check ventilation filters and breathers, replace
4	Suction filter clogged	Replace filter
5	Fast/ slow-gear does not shift electrically or mechanically	Check power supply and solenoid valve, repair and replace if necessary. Check travel motor
6	Fault in brake inching device	Check, adjust, replace
7	Filling pump sucks up air	Check, eliminate leakage
8	Travel pump mis-adjusted	Re-adjust travel pump
9	Filling or supply pressure too low	Check pressure, adjust
10	Pressure relief valve of filling circuit clogged or faulty	Check, re-adjust or replace
11	High-pressure too low	Check high-pressure (pressure cut-off), and re-adjust high-pressure valves or replace if necessary
12	Travel pump does not open fully, pilot pressure too low	Nozzles clogged, check, repair
13	Internal damage to travel pump or travel motor	Replace units
14	Travel motor mis-adjusted	Re-adjust travel motor

<i>Fault</i>	<i>Possible cause</i>	<i>Remedy</i>
8.9 Transmission works in one direction only		
1	Switch for direction of travel damaged	Repair or replace if necessary
2	Solenoid valve sticks or is damaged	Repair or replace if necessary
3	Power supply towards switch for direction of travel or solenoid valve interrupted	Check and repair (incl. ground connection)
4	Pilot pressure too low on one side	Nozzles clogged, check, clean
5	High-pressure relief valve is faulty or incorrectly set	Swap valves around. If machine now travels in the other direction, examine valve, clean and replace if necessary
8.10 Transmission works in neither direction		
1	Too little hydraulic oil in tank	Top up to mark on dipstick
2	Mechanical connection to diesel engine faulty	Check, repair
3	Filling pump damaged, no filling pressure	Remove pump and examine, install new pump if necessary
4	Switch for direction of travel damaged	Repair and replace if necessary
5	Solenoid valve for direction of travel damaged	Repair and replace if necessary
6	Suction filter clogged	Replace filter
7	Suction line between tank and pump kinked	Check and eliminate kink
8	Power supply to switch for direction of travel and solenoid valve interrupted	Remedy cause of interruption
9	Internal damage to travel pump or travel motor	Replace units completely
10	Mechanical connection between travel motor and axle interrupted	Check, repair
8.11 Loader installation is not working		
1	Oil supply to pump interrupted	Check suction line and repair if necessary
2	Main relief valve damaged	Check and replace if necessary
3	Hydraulic pump damaged	Check, repair or replace
4	Hydraulic pump drive mechanically interrupted	Check and repair


8 Trouble-Shooting

<i>Fault</i>	<i>Possible cause</i>	<i>Remedy</i>
8.12 Decrease in machine's performance (loader installation)		
1	Insufficient engine power	Check diesel engine and adjust if necessary
2	Hydraulic oil level too low	Top up hydraulic oil to the mark on the dipstick
3	Pump is sucking up air	Tighten hose connections. Replace O-ring or seals
4	Insufficient operating pressure	Re-adjust main relief valve, replace if necessary
5	Wear of pump	Replace pump
6	Incorrect hydraulic oil	Quality of hydraulic oil must conform to our recommendation
8.13 Working cylinders are not working satisfactorily		
1	Seals in cylinders worn	Re-seal cylinders
2	Secondary valves faulty	Check secondary valves and replace completely if necessary
8.14 Trouble in the electrical system		
1	Outside and/or internal lighting damaged	Check cables, connections, bulbs and fuses
2	Windshield wiper does not work	Check cables, connections and fuses. Examine windshield wiper for mechanical damage. Replace complete wiper if necessary
3	Horn does not work	Check cables, connections and fuses. Replace complete horn
4	Control organs are imprecise	Determine the fault or source of the problem, call Service Agent if necessary
5	Starting system does not work satisfactorily	Check charge capacity of battery. Test starter function. Check connection and condition of power and battery ground cables. Check function of ignition lock, replace if necessary.

9 Appendix

9.1 Electrical system

Fuse box — Assignment diagram



D = K3 (turn-signal flasher relay) below instrument panel

A			B		
Position	Ampere	assigned to	Position	Ampere	assigned to
F 1	15	Heater fan	F 1	15	Working floodlight, front
F 2	15	Wash/wipe, front	F 2	15	Working floodlight, rear
F 3	15	Wash/wipe, rear	F 3	10	Turn signal
F 4	10	Rotating beacon; interior light	F 4	10	Hazard warning switch
F 5	15	Travel, forward/reverse	F 5	15	Socket; radio
F 6	10	Reserve	F 6	15	Reserve
F 7	10	Reserve	F 7	10	Horn
F 8	10	E-module inputs	F 8	10	High beam
F 9	10	Instruments	F 9	10	Low beam
F 10	10	Radio	F 10	10	Side marker light, left
F 11	15	Reserve	F 11	10	Side marker light, right
C / D					
F 01	50	Series fuse	K 1		Start relay
F 02	80	Starting system	K 2		Pre-heat relay
F 03	30	Control module power supply	K 3		Turn-signal flasher relay

Colors of fuses


10 A	red	15 A	blue	30 A	rose	50 A	red	80 A	white
------	-----	------	------	------	------	------	-----	------	-------

Cable and plug colors

bg	beige	dgr	dark gray	hbr	light brown	rt	red
bl	blue	ge	yellow	hgr	light gray	sw	black
br	brown	gn	green	hr	light red	vi	violet
dbl	dark blue	gr	grey	nt	nature	ws	white
dbr	dark brown	hbl	light blue	or	orange		


9 Appendix

Start-up	Pre-heat	Shut-off	Heating	Air conditioning
----------	----------	----------	---------	------------------



Path	Designation	Device	Path	Designation	Device
	ZSML	Central control module	1.4	K2	Pre-heat relay
1.1	F01	Flat-type fuse	1.5	R1	Glow plug
1.1	G1	Generator	1.5	Y1	Engine shutoff
1.1	F02	Flat-type fuse	1.7	FA1	Fuse
1.2	F03	Flat-type fuse	1.7	S2	Heater switch
1.2	Y29	Excess fuel for starting (turbocharged engine only)	1.7	M3	Heating
1.2	G2	Battery 12 V	1.8	S13	Air conditioning temperat. switch
1.3	K1	Start relay	1.8	S30	Air conditioning pressure switch
1.3	M1	Starter	1.8	Y30	Air conditioning relay
1.4	S1	Glow-plug and starter switch			

Wash/wipe system, front	Wash/wipe system, rear
--------------------------------	-------------------------------




L824-E04

Path	Designation	Device	Path	Designation	Device
	ZSML	Central control module	1.11	S20	Washer switch front/rear
	SK030	Instrument panel	1.13	M5	Washer pump rear
1.9	FA2	Fuse	1.14	S22	Wiper switch rear
1.9	M4	Washer pump front	1.14	M7	Wiper rear
1.10	S21	Wiper switch front	1.16	FA3	Fuse
1.10	M6	Wiper front			

9 Appendix


Monitoring



L824-E05

Path	Designation	Device	Path	Designation	Device
2.1	FA8	Fuse	2.4	R2	Tank sensor
2.1	R3	Engine temperature sensor	2.5	R4	Hydraulic oil temperature sensor
2.2	P1	Engine temperature indicator	2.5	S28	Air filter maintenance switch
2.2	S33	Transmission position	2.6	S27	Oil pressure switch
2.3	B9	Speed	2.7	S26	Hydrostatic brake switch
2.3	P2	Fuel tank indicator			

Monitoring




L824-E06

Path	Designation	Device	Path	Designation	Device
2.8	FA11	Reserve fuse	2.15	FA6	Reserve fuse
2.14	FA7	Reserve fuse			

9 Appendix


"Travel" fuse	Travel	Float position	Additional control circuit
---------------	--------	----------------	----------------------------



L824-E07

Path	Designation	Device	Path	Designation	Device
3.1	FA5	Fuse	3.5	S21/2	Float position switch
3.2	Y4	Travel, forward	3.5	Y7	Float position
3.2	S21/1	Switch for travel, forward/reverse	3.7	S10	Float position switch
3.3	Y3	Travel, reverse	3.8	Y8	Additional control circuit 1
3.3	H16	Travel motion alarm	3.8	S21/3	Additional control circuit switch
3.4	S16	Switch for travel, forward/reverse	3.8	Y9	Additional control circuit 2
3.4	Y2	Travel direction recognition	3.9	S9	Additional control circuit


Travel speed	Ride control system	4 th control circuit	Working hydraulics	Manual transmission
--------------	---------------------	---------------------------------	--------------------	---------------------



Path	Designation	Device	Path	Designation	Device
3.10	S13	Travel, SLOW	3.13	S11	4 th control circuit
3.10	Y6	Travel, SLOW	3.14	Y5	Working hydraulics
3.12	S12	Ride control system switch	3.14	S15	Working hydraulics
3.12	Y11	Ride control system 1	3.15	S14	Manual transmission
3.12	Y15	Ride control system 2	3.15	Y12	Manual transmission 1
3.13	Y16	Ride control system 3	3.16	Y13	Manual transmission 2


9 Appendix

Lighting and signaling



Path	Designation	Device	Path	Designation	Device
4.1	E8	Interior light	4.4	E1	Lighting front left
4.1	FB4	Fuse	4.5	S12	Light switch
4.2	FB3	Fuse	4.5	E3	Lighting rear left
4.2	S4	Direction indicator switch, hazard warning switch	4.6	FB10	Fuse
4.2	K3	Flasher transmitter	4.6	FB11	Fuse
4.3	FB7	Fuse	4.6	E2	Lighting front right
4.3	B5	Horn	4.6	S25	Brake light switch
4.4	FB8	Fuse	4.7	E4	Lighting rear right
4.4	FB9	Fuse	4.7	S23	Hand brake switch
			4.8	E14	License-plate illumination


Rotating beacon	Working floodlights	Instrument panel	Radio	Socket
-----------------	---------------------	------------------	-------	--------




Path	Designation	Device	Path	Designation	Device
4.9	FA4	Fuse	4.12	E6	Working floodlight rear
4.9	S3	Rotating beacon switch	4.12	FA9	Fuse
4.9	E7	Rotating beacon	4.13	U1	Instrument panel
4.10	FB1	Fuse	4.13	FA10	Fuse
4.10	S5	Working floodlight front	4.15	B4	Loudspeaker
4.10	E3	Working floodlight front	4.15	B2	Radio
4.11	E4	Working floodlight front	4.15	FB6	Fuse
4.11	FB2	Fuse	4.15	B3	Loudspeaker
4.11	S6	Working floodlight rear	4.16	FB5	Fuse
4.11	E5	Working floodlight rear	4.16	XSD	Socket

9 Appendix

Central control module (ZSML)




X60	Signal inputs "engine monitoring"
1	Power supply Terminal 15 output
2	Central mass Terminal 31
3	Charge control generator D+
4	Air filter maintenance switch signal
5	Oil pressure switch signal
6	Hydrostatic brake pressure switch signal
7	Transmission switch signal
8	Tank sensor signal
9	Engine temperature sensor signal
10	Hydraulic oil temperature sensor signal
11	Speed signal generator "W" signal
12	--
13	--
13	--
15	--
16	--
17	--
18	Speedometer signal sensor
X30	Signal inputs "Lighting"
1	Power supply Terminal 15 output
2	--
3	Parking light Terminal 15 input
4	High beam signal
5	Direction indicator control signal
6	Reserve -
7	Reserve +
8	Reserve +
9	Reference voltage
10	Reserve - Analog
11	Reserve - Analog
12	Reserve - Analog
X80	Coordinate lever
1	Power supply Terminal 15 output
2	Central mass Terminal 31
3	Travel forward signal
4	Travel reverse signal
5	Float position signal
6	Additional control circuit signal
7	Additional control circuit signal
8	Reserve - Analog
9	Reserve - Analog




X40	CAN-BUS (Option)
1	Power supply Terminal 15 output
2	Central mass Terminal 31
3	CAN/Hi
4	R1
5	R2
6	CAN/Lo
X10	Control panel
1	--
2	Central mass Terminal 31
3	CAN/Hi
4	--
5	--
6	CAN/Lo
X90	Programming connection
X91	Immobilizer (Option)
1	Power supply Terminal 15 output
2	Central mass Terminal 31
3	TXD
4	RXD
5	CTS
6	RTS

9 Appendix



X31	Module power supply, working floodlights, rotating beacon, wiper
1	--
2	--
3	Reserve digital output
4	Relay K11:87a N.C. contact output
5	Relay K11:87 N.O. contact output
6	Reserve digital output
7	Relay K12:87 N.O. contact output
8	Relay K12 power supply Terminal 15 input
9	Relay K12:87a N.C. contact Output
10	Power supply Terminal 15 input working floodlight front
11	Relay K11 power supply Terminal 15 input
12	Reserve PWM output
13	Power supply Terminal 15 input working floodlight rear
14	Reserve PWM output
15	Reserve PWM output
16	Power supply Terminal 30 input rotating beacon
17	Reserve Digital output
18	Reserve PWM output
19	Power supply Terminal 15 input wash/wipe rear
20	Power supply Terminal 15 input travel
21	Power supply Terminal 15 input wash/wipe rear
X70	Working floodlights, Wipers
1	Brake light switch Terminal 15 output
2	--
3	Working floodlight front output
4	Working floodlight rear output
5	Rotating beacon output
6	Wiper Terminal 53b 2 nd setting output
7	Washer pump front output
8	Wiper Terminal 31b output
9	Interior lamp Terminal 30 output
10	Wiper Terminal 53 output
11	Wiper Terminal 53a output
12	Hand brake switch signal input
13	Washer pump rear output
14	Rear wiper Terminal 53a output
15	--
16	Rear wiper Terminal 31b output
17	Rear wiper Terminal output
18	Brake light switch signal input




X61	X61 <i>ab</i> 824/0213	Rear end
1	1	--
2	2	--
3	3	Starting Terminal 50a output
4	4	Pre-heat output
5	5	Engine shutdown output
6	6	Brake light output
7	7	Travel, direction recognition output
8	8	Travel, FAST-SLOW output
9	9	Transmission 1 output
10	21	Travel forward output
11	11	Transmission 2 output
12	12	Working hydraulics output
13	16	Travel reverse output
14	15	Back-up lamp output
15	10	Travel motion alarm output
16	14	Ride control system 3 output
17	17	Float position output
18	18	Additional control circuit output
19	19	Additional control circuit output
20	20	Ride control system 1,2 output
21	13	Rear fog lamp output
X20		Panel, right
1		Power supply Terminal 15 output
2		--
3		Starting Terminal 50a signal
4		Pre-heat signal
5		Engine shutdown signal
6		Ride control system signal
7		Additional control circuit signal
8		Additional control circuit signal
9		Float position 1 signal
10		Float position 2 signal
11		4 th control circuit signal
12		4 th control circuit signal
13		Rotating beacon signal
14		Working floodlight front signal
15		Working floodlight rear signal
X5		Power supply

9 Appendix

9.2 Hydraulic system

(Hydraulic system includes options)



L834-H01
03-09-30

Fig. H01 Hydraulic system

	<i>Description of hydraulic system</i>
1	Steering cylinder
2	Steering orbit
3	Priority valve
4	Steering pump / charge pump
5	Hydraulic oil tank
6	Hydraulic oil cooler
7	Hydraulic oil temperature control
8	Combined hydraulic oil filter
9	Breather
10	Travel motor
11	Travel pump
12	Master brake cylinder
13	Brake – front axle

9 Appendix




Fig. H02 Hydraulic system

	Description of hydraulic system
5	Hydraulic oil tank
14	Loader control lever
15	Pilot control unit
16	Control valve
17	Additional control circuit connection; hydraulic quick-attach system
18	Hydraulic cylinder — lift frame
19	Hydraulic cylinder — bucket tilt
20	Load retaining valves
21	Vibration damping
22	Release valve (only if Pos. 20 & Pos. 21 installed)
23	Transmission (high-speed version)
24	Valve
25	Open return
26	Distributor for hand-held hammer
27	4th control circuit
28	Control unit

9.3 Equipment options

Ride control system (LSD)

Depending on the operating weight, roadway conditions and speed, there may be wheel loader bouncing whilst driving.

The ride control system reduces possible machine bouncing resulting in the following advantages:

- higher transport speed
- improved material-handling performance
- more stable steering
- shorter braking distance
- increased operator comfort



Load-retaining valves (option) are without function as long as LSD is activated!

Operation

- Switch on the ride control system (80/11) - green indicator lamp is ON.
- The ride control system is automatically activated as soon as travel speed is at least 6 km/h (high-speed version).
- 20 km/h-version: The ride control system must be switched on.



The bucket tilt cylinder must not be at a cylinder stop (bucket not completely tilted back) as otherwise free oscillation is not possible.

Repair



Before working on the loader hydraulic system, the accumulator pressure of the ride control system must be let off. To do so, proceed as follows:

- Stop the machine in the proper manner.
- Switch off the ride control system (80/11).
- Remove the front-end cover.
- Open ball valve (81/1).




Bild 80 Operation




Fig. 81 Ball valve

DELIVERY AND HANDING-OVER INSTRUCTIONS

The following checklist is to be followed when handing over the machine to the customer:

1. Operating instructions

The operating instructions should be read side by side, and be explained in detail through practical training on the machine.

The following items are essential:

- Accident Prevention Regulations published by the employer's liability insurance associations in the user's country
- Technical data
- Operator controls, indicating and warning elements
- Checks before putting the machine into operation
- Specifications for diesel engine start-up
- Starting and switching off the diesel engine
- Explanation of hydrostatic travel drive
- Driving, speed ranges and notes for driving on roads
- Recovery and transport of the machine
- Operation of all functions
- Actuation of the quick-attach system
- Explanation of maintenance and inspection intervals in compliance with Maintenance and Inspection Plan by demonstrating maintenance points on machine
- Lubrication intervals and points of lubrication in compliance with lubrication chart and demonstration of these points on the machine
- Handing over the diesel engine operating instructions

2. Spare parts list

- Structure of spare parts list, of Figure s and the respective descriptions
- Instructions for ordering spare parts: always state the type of machine, the vehicle identity number (Fz-Id.Nr.), parts designation, complete spare part number, piece number, delivery address, etc.

3. Warranty

- Explanation of warranty covered by manufacturer
- Explanation of inspection cards and note on maintenance and inspection plan
- The warranty/ handing-over card must be filled out correctly and returned



Wheel Loader SKL 824

Maintenance and Inspection Plan

The careful performance of all prescribed inspections is the best prerequisite for the machine's continuous readiness for operation.

All maintenance work mentioned should therefore be performed in the prescribed sequence with the machine being in warm condition.



The inspections are obligatory.


If omitted, this may affect the warranty covered by us.

The machine must be thoroughly cleaned before inspection takes place.

Inspection plan

To be carried out by trained specialist dealer personnel.

O = Checking, maintenance X = Replacement		Operating hours				min. 2x yearly	min. 1x yearly
		after 100	every 500	every 1000	every 2000		
Perform work with machine at operating temperature		after 100	every 500	every 1000	every 2000	yearly	yearly
1	Check whether machine-specific instruction book is in the machine	O	O				
2	Change engine oil			X			X
3	Change engine oil filter			X			X
4	Drain water from fuel tank	O	O			O	
5	Change fuel filter			X			X
6	Clean fuel pump and screen filter			O			
7	Check air intake	O	O				
8	Change air filter - main cartridge	to service indicator					X
9	Change air filter - safety cartridge	as required ¹⁾					
10	Clean cooling fins of hydraulic oil cooler  <i>In case of high exposure to dust, shorten the cleaning intervals.</i>	O	O			O	
11	Clean cooling fins of engine oil cooler  <i>In case of high exposure to dust, shorten the cleaning intervals</i>	O	O			O	
12	Check V-belt tension	O		O			
13	Check engine mounts and pump attachments	O	O				
14	Check engine speed adjustment, top-end and low idle speed	O	O				
15	Check valve lash of engine and adjust if necessary			O			
16	Check injection valves				O		
17	Check fuel leak-oil pipe and replace if necessary			O	X ¹⁾		
18	Replace toothed belt ³⁾						
19	Check crankcase breather in valve cover				O		
20	Check acid level and battery connections	O	O				
21	Check condition of tires, tire pressure and tightness of wheel nuts	O	O				
22	Check secure fastening of axles and propeller shaft	O	O				
23	Check bearing bushings and bolts of work equipment and replace if necessary	O	O				
24	Check bushings and bolts of the articulation and the articulated steering and replace if necessary.	O	O				
25	Check that door catches function perfectly, and replace if necessary	O	O				

O = Checking, maintenance X = Replacement		Operating hours				min. 2x yearly	min. 1x yearly
		after 100	every 500	every 1000	every 2000		
Perform work with machine at operating temperature		after 100	every 500	every 1000	every 2000	yearly	yearly
26	Clean or replace the dust filter for cab ventilation	O		X			X
27	Check electrical indicating and warning elements, and lighting system	O	O				
28	Check smooth running of operator controls and adjust if necessary	O	O				
29	Check tightness of all pipes, hoses, control valve, hydraulic pumps, cylinders, etc.	O	O				
	 <i>When tightening hose and pipe connections, screw-in couplings must be locked to prevent rotation</i>						
30	Check or change hydraulic oil	O	O	X ²⁾			X
31	Replace insert of hydraulic oil return suction filter	X	X			X	
32	Replace breather			X			X
33	Check function of brakes and replace brake oil	O	O		X		X
34	Bleed brake	O	O				
35	Rear axle differential with transmission / option: manual transmission: oil check or oil change	X	O	X			X
36	Front axle differential - oil check or oil change	X	O	X			X
37	Wheel hubs of front and rear axles: oil check or oil change	X	O	X			X
38	Grease machine in compliance with overview of lubricating points	O	O				
39	Check function, condition and completeness of safety equipment	O	O				
40	Hydraulic function check with pressure function test	O	O				
41	Test run and test work	O	O				
42	Initial inspection cards and return to manufacturer	O	O ⁴⁾				

1) at least every 2 years

2) Extension of oil change intervals in compliance with oil sample analysis and lab report.
For further information see Chapter 7.3

3) Every 5 years or 5,000 operating hours respectively

4) within warranty