



TEREX
LIGHT CONSTRUCTION

SERIES AL4000D1
LIGHT TOWER
OPERATION/SERVICE
& PARTS MANUAL

After Serial Number:

FKF-13923

PART NUMBER SFMAL4D1
REVISION B
SEPTEMBER 2006

Discount Equipment

Discount-Equipment.com is your online resource for commercial and industrial quality parts and equipment sales.

Locations:

Florida (West Palm Beach): [561-964-4949](tel:561-964-4949)

Outside Florida TOLL FREE: [877-690-3101](tel:877-690-3101)

Need parts? Check out our website at www.discount-equipment.com

Can't find what you need?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and fill out the request form.

Please have the machine model and serial number available in order to help us get you the correct parts. One of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mayco, Toro/Stone, Diamond Products, Magnum, Airman, Mustang, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand Brothers, Essick, Miller Spreader, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna/Target, Whiteman-Concrete/Mortar, Stow-Concrete/Mortar, Baldor, Wacker, Sakai, Snorkel, Upright, Mi-T-M, Sullair, Neal, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Blaw-Knox, Himoina, Best, Buddy, Crown, Edco, Wyco, Bomag, Laymor, Terremite, Barreto, EZ Trench, Takeuchi, Basic, Bil-Jax, Curtis, Gehl, Heli, Honda, ICS/PowerGrit, Puckett, Waldon, ASV, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, Gorman Rupp, CH&E, Cat Pumps, Comet, General Pump, Giant, AMida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, Small Line, Wanco, Yanmar

TABLE OF CONTENTS

Receiving and Set-up

Safety Alert Symbols.....	3
General Safety.....	4-8
Check Out on Receipt/Delivery.....	11
Serial Number Register.....	12
TEREX Amida Light Tower Model Coding System	13
Recommended Engine Oil and Fuel	14

Operating Instructions

Light Tower Operating Instructions	15-19
Engine (see manufacturer's handbook)	
Generator (see manufacturer's handbook)	

Parts Identification Drawings

Trailer and Fuel Tank	41-42
Axle and Wheels	43
Cabinet and Attachments	44-46
Tower and Related Parts	47-56
Engine and Generator	57-61
Electrical Box	62
Floodlight Fixtures / Ballasts	63-64
Hitches	65
Options	66-77

Wiring Diagrams

Fixture with Joy Connector (MH or TH)	33
Metal Halide Ballast with Connector	34
High Pressure Sodium Ballast with Connector	35
Wiring	36-40

Troubleshooting Guide

Specifications, Routine Maintenance, Wind Loading, Torque Specs	24-27
Criteria for Replacement of Wire Rope	28
Broken Cable Replacement Procedure	29-32
Light Fixture Troubleshooting	20-22
TEREX Amida Numbered Wiring System	23
Engine (refer to manufacturer's handbook)	
Generator (refer to manufacturer's handbook)	

Warranty Information

Warranty Procedure.....	10
Warranty.....	9

SAFETY ALERT SYMBOLS



**MEANS:
ATTENTION! BE ALERT!
YOUR SAFETY IS INVOLVED**

THIS SAFETY SYMBOL IS USED FOR IMPORTANT SAFETY MESSAGES. WHEN YOU SEE THIS SYMBOL, FOLLOW THE SAFETY MESSAGE TO AVOID PERSONAL INJURY OR PROPERTY DAMAGE.

UNDERSTANDING SIGNAL WORDS

A signal word - **DANGER**, **WARNING** or **CAUTION** is used with the safety alert symbol.



DANGER Identifies the hazard or unsafe practice that will result in severe injury or death.



WARNING Identifies the hazard or unsafe practice that could result in severe injury or death.



CAUTION Identifies the hazard or unsafe practice that could result in minor injury or property damage.



NOTICE Identifies important installation, operation or maintenance information.


GENERAL SAFETY

⚠ WARNING DO NOT OPERATE THE AL4000 LIGHT TOWER WITHOUT READING THIS OPERATOR'S MANUAL.



SAFETY ALERT SYMBOL

Stop and take time to read ALL Safety alert messages. Follow the safety messages to avoid personal injury or property damage.



ACCIDENT PREVENTION

Use protective clothing and safety equipment. Always wear approved safety equipment such as gloves, safety boots, safety hard hat, goggles, ear protection, and dust masks when necessary.

Wear protective clothing that is snug and belted where required.



UNAUTHORIZED WELDING

⚠ WARNING UNAUTHORIZED WELDING CAN CAUSE STRUCTURAL FAILURE OR PERSONAL INJURY.

DO NOT weld on any structural member.

Any unauthorized welding or repair procedure will void the warranty.

GENERAL SAFETY



⚠ WARNING FUELING

ALWAYS handle fuel with care. It is highly flammable.

ALWAYS stop engine before refueling. Fill fuel tank outdoors.

Be sure the fuel supply has a positive shut-off valve.

DO NOT replace fuel lines with materials different from those supplied as original equipment.

⚠ WARNING FIRES CAN CAUSE SEVERE PERSONAL INJURY OR MACHINE DAMAGE.

Prevent fires by keeping the light tower and its surrounding area clean.


DO NOT refuel while smoking or when near open flame or sparks.

DO NOT refuel the engine when it is hot. Allow to cool for several minutes before refueling.

DO NOT spill fuel inside the engine compartment.

If fuel has leaked, wipe it up and have leak repaired before next use.

Have a fire extinguisher nearby. Be sure the extinguisher is properly maintained and be familiar with its use. Extinguishers rated ABC by the NFPA are appropriate for all applications.



GENERAL SAFETY

⚠ WARNING

Guard Against Electrical Shock

Equipment produces high voltage electricity (up to 480 volts) that can produce a fatal shock to a person who accidentally places their self in the electrical circuit. Use every precaution to avoid contact with the high voltage electrical circuit.

Beware of a cut or damaged power cord. Have a qualified electrician replace immediately.

Take extra precautions when troubleshooting electrical problems. When troubleshooting indicates a malfunction in the high voltage AC system, pass the troubleshooting task on to a qualified and trained electrician.

Disconnect electrical power and turn off engine before removing protective covers on high voltage enclosures.

Understand that the electrical circuits in this light tower complete their paths back to the generator within the equipment. The neutral conductor at the generator is bonded to the equipment frame.

Ground wires within the system are also bonded to the equipment frame.

Only use a multimeter (or voltmeter) with two well-insulated probes rated for 750 volts each.

Keep one hand in your pocket when touching the multimeter probe to hot conductors. This will prevent electricity from passing into one hand and out the other, a path that takes the electricity across the heart.

Always disconnect power from the circuit being measured before connecting test leads to high voltage points.

Do not try to position both probes at once. Instead, clamp the common insulated alligator clip to a neutral wire and then probe for voltages with the other probe.

Never clamp to a hot wire since a severe shock could be received by contact with the other probe.

Inspect the ground cable between the generator set and the frame. If damaged, replace immediately.

Treat all conductors as potentially hot, especially when troubleshooting malfunctioning equipment. Jewelry should be removed before working around live conductors.

Proceed through the circuitry systematically, operating only one section at a time.

Use tools with insulated handles when working within the reach of live conductors.

Maintain a good footing. If you slip, or a tool drops, do not grab for it if live conductors are within reach.

Concentrate on the task until the danger from high voltage is removed.

⚠ WARNING

Guard Against Battery Hazards

Lead acid batteries can be dangerous. The sulfuric acid in the battery can cause severe skin and eye burns. The hydrogen gas emitted during charging can explode if an arc or flame is present near the battery. Use precautions to prevent acid burns or explosive conditions.

Do not smoke while servicing batteries.

Do not allow tools to touch battery terminals and create an arc. Do not test battery voltage by setting up a brief arc at the terminals. Use a multimeter instead.

Disconnect the negative terminal of the battery when working on the engine or other parts to prevent accidental arcing. Disconnect the negative cable at the end away from the battery.

Always wear eye protection when servicing the battery.

When charging the battery, do not remove the vent caps.

If acid does get on skin or in eyes, immediately flush under running water, and then obtain medical help as soon as possible.

⚠ WARNING

Guard Against Fire Hazard

Use caution with diesel fuel and motor oil because of fire hazards.

Do not fill fuel tank while engine is running.

Do not smoke or use open flame near the unit or the fuel tank.

Be sure the fuel supply has a positive shut-off valve.

Do not replace fuel lines with materials different from those supplied as original equipment.

⚠ WARNING

Protect The Environment And Practice Good Industrial Hygiene

Exhaust Gases Are Toxic. Do not use indoors unless properly ventilated. Provide an adequate exhaust system to properly expel discharged gases. Check exhaust system regularly for leaks. Ensure periodically that the exhaust manifolds are secure and not warped. Make sure the unit is well ventilated.

Prevent pollution by catching used oil in a container for proper disposal.

Wash hands to remove oil and fuel. Practice good industrial hygiene.

⚠ CAUTION

Do Not Touch Hot Parts

The exhaust manifold and tailpipe are very hot. Parts of the engine are also hot. Avoid touching hot parts of the engine or tailpipe. Use protective gloves when handling hot parts.

⚠ WARNING

Be Alert And Attentive To The Task

Read the safety instructions and operating procedures before attempting to troubleshoot or work on this unit. Also read the engine manual, which is a separate booklet that is provided with this manual.

Do not work on this equipment when mentally or physically fatigued.

Do not work on this equipment when under the influence of performance impairing drugs or alcohol.

If this manual becomes lost, order a new one from TEREX-Amida so future operation and maintenance personnel may read these instructions.

⚠ CAUTION

Beware of Moving Parts

Avoid being hit or pinched by the moving parts of this unit.

Loose jackets, shirts, neckties, or sleeves should not be worn while working on or running a unit.

Only remove guards or protective devices from unit temporarily to gain access for maintenance. Always replace guards and protective devices promptly (Prior to Operation).

Keep your hands away from moving parts. Particularly, be sure to keep hands clear of the blower and alternator belts when the engine is running.

⚠ WARNING

Beware of Traffic Hazards

Stand clear of traffic when starting or checking the unit along the road.

Check the fuel tank, oil pan, and fuel and oil lines for leaks that would spill fuel or oil on the road.

Check fasteners and mounting brackets periodically to ensure all are tight and nothing is in danger of falling off during transit.

NOTICE

Use Only Equal Replacement Parts

When a part fails and needs to be replaced only use equivalent size, length, thread, grade, and material. Replace stainless steel fasteners with stainless steel fasteners. The engine may use metric or SAE bolts, but all other bolts are generally SAE thread. Be sure to use Grade 8 bolts and nuts to mount the genset to the trailer.

Replace the fuel and oil hoses with items of equal material, diameter and length.

Contact the manufacturer, TEREX Light Construction, regarding replacement parts to ensure a correct repair.

⚠ CAUTION

Use Caution Working Near Lamps

Metal halide lamps produce short wave ultra-violet radiation and **can cause serious skin burn, or eye inflammation if the outer envelope of the lamp is broken or punctured.** Do not use where people will remain for more than a few minutes unless adequate shielding or other safety precautions are used.

TEREX-AMIDA, INC.

CHECK OUT ON RECEIPT OF DELIVERY:

The tower will be serviced, tested and ready for operation when received except for export units and skid mount units which are knocked down for shipping (export units are sometimes shipped with dry batteries). TEREX-Amida recommends the following checks:

- A. **INSURE THERE IS NO FREIGHT HANDLING DAMAGE** which should be charged against the carrier.

- B. **INSURE THE MANUALS ARE IN THE POCKET PROVIDED INSIDE THE UNIT.**

- C. **REVIEW THE MANUALS FOR SAFETY AND OPERATING PROCEDURES.**

- D. **CHECK THE ENGINE OIL, COOLANT (IF LIQUID COOLED) AND FUEL LEVELS.**

- E. **OPERATE THE TOWER IN ACCORDANCE WITH OPERATING INSTRUCTIONS.**

EXPORT: Assemble according to the instructions enclosed.

TEREX LIGHT CONSTRUCTION
PORTABLE LIGHT TOWER
OPERATION AND SERVICE MANUAL

This Operation and Service Manual contains information pertaining to the operation and maintenance of your Terex Light Tower. We suggest that you read this manual carefully prior to operating the tower. This manual should be retained and referred to for operation, maintenance, and ordering parts. When ordering parts, **PLEASE INCLUDE THE MODEL AND SERIAL NUMBER** located on the nameplate of the tower.

For major repair and service or other information, contact:



www.discount-equipment.com

Terex Model Number _____	Serial Number _____
Engine Model Number _____	Serial Number _____
Generator Model Number _____	Serial Number _____
Sold to: _____	Ship to: _____
_____	_____
_____	_____
Options: _____	Production Date: _____
_____	Work Order Number _____
_____	Shipping Date _____
_____	In Service Date _____

When this unit left the factory the engine was filled with engine oil grade _____

IMPORTANT

WHEN REQUESTING TECHNICAL HELP AND ORDERING REPLACEMENT PARTS THE MODEL AND SERIAL NUMBER ARE NECESSARY.

REFER TO THE TEREX SERIAL NUMBER TAG ON THE UNIT FOR CORRECT MODEL NUMBER AND SERIAL NUMBER.

MODEL NUMBER IDENTIFICATION

Sample:

Light Tower Product Line AL4 080 D 4 MH CE

Tower Series _____

AL4000 (AL4) = 30 Foot Basic Tower with winch in cabinet

AL5000 (AL5) = 30 Foot Basic Tower with in-cabinet light storage and door insulation

LT7000 (LT7) = 30 Foot Deluxe Hydraulic Tower w/optional Acoustic Enclosure and Complete Instrumentation

kW Rating _____
(080 is 8.0 kW)

Diesel (D) _____

Number of Lights _____

Type of Lights _____

- ◆ HPS = High Pressure Sodium
- MH = Metal Halide
- TH = Tungsten Halogen

European Version (AL4000 Only) _____

RECOMMENDED ENGINE OIL & FUEL

KUBOTA D905 DIESEL ENGINE

Engine oil should be MIL-L-2104C or have properties of API classification of CD grades or higher.

Change the type of engine oil according to the ambient operating temperature:

Above 77°F (25°C)	SAE 30
32°F to 77°F (0 to 25°C)	SAE 20
Below 32°F (0°)	SAE 10W SAE 10W-30

Use #2 diesel fuel.

NOTES:

1. The temperatures in the table are the ambient temperatures at the time when the engine is started. If the running ambient temperatures are much higher than the starting temperatures, a compromise must be struck and a higher viscosity oil used. Multi-grade oils overcome the problem, provided they possess a suitable specification.
2. MIL-L-2104B or MIL-L-2104C or API CD must also be used if the sulfur content of the fuel exceeds 0.5%.
3. Always use a reputable brand of diesel fuel. The sulfur content should be below 0.5% (higher sulfur content would require more frequent oil changes). Observe strict cleanliness when filling the fuel tank.
4. Check the engine oil level before starting the engine or more than five minutes after it has been stopped. Remove the dipstick, wipe clean, reinsert it, take it out again, and check the oil level. If the oil level is too low, remove the oil filler cap and add new oil until the FULL line on the dipstick is reached.

MODEL AL4000

OPERATING INSTRUCTIONS

⚠ WARNING

READ ALL DIRECTIONS IN MANUAL CAREFULLY BEFORE OPERATING EQUIPMENT

⚠ WARNING

DO NOT RAISE TOWER IN THE VICINITY OF OVERHEAD POWER LINES!

OPERATING INSTRUCTIONS

I. MOVE LIGHT TOWER TO DESIRED LOCATION KEEPING THE FOLLOWING IN MIND:

- A. The light tower should not be placed where those working under the light are either:
 - 1) Forced to look into the light regularly.
 - 2) Forced to work with their backs to the light (shadows will block the light from the work area).
- B. The area where the tower is positioned should be relatively level.
- C. The light tower should be located on the same level or on ground higher than the area being lighted (higher light mounting heights reduce the shadow length).
- D. Unit should be level to ensure smooth trouble-free tower telescoping. Tower may not telescope down properly when unit is not level.

II. UNHITCH FROM THE TOWING VEHICLE AS FOLLOWS:

- A. Engage the trailer braking system, especially if trailer is not on level ground. **CAUTION:** If electrical or manual braking system is not supplied, chock the wheels instead.
- B. Swing the tongue jack into position and raise the tongue off the towing vehicle.


III. LEVEL THE TRAILER, USING THE JACKS AS FOLLOWS:

- A. Extend the rear outriggers until the springs lock into place. Swing the jack on each outrigger into vertical position.
- B. Start at the highest jack position. Rotate the jack handle until the jack foot touches the ground.
- C. Raise the other jacks to level trailer... **⚠ WARNING** ...insure that the rear jacks are down to prevent the tower from tipping over backwards when raised.

IV. DRIVE GROUNDING ROD INTO EARTH

V. INSTALL THE FLOODLIGHTS ON THE CROSSBEAM

- A. Remove the light fixtures from the tower by removing detent pin and rotating the clamp to free the lights. Install them on the cross arm studs with the lens facing the ground.
- B. The cord on the fixture should be on the side closest to the trailer so the cord entry is beneath the fixture when the tower is raised (this reduces moisture problems and ensures the water weep hole in the fixture is down).
- C. Set the vertical aim for each light fixture by adjusting the light fixtures and tightening the lower bolt.
- D. Set the spread between the light fixtures horizontal aiming by adjusting the fixtures and tightening the wing nut.
- E. The unit may be transported with the light fixtures mounted on the cross-arm if they are pointed toward the ground.




VI. RAISING THE TOWER (refer to drawing above)

- A. Remove the tower travel-locking pin from the cradle at the rear of the cabinet.
- B. Aim the fixture, both horizontally and vertically, to the estimated angles that will light the work area.
- C. Using the winch, raise the tower to the vertical position. The tower-locking pin at the base of the pivot post will lock automatically and you will hear it “snap” into place. Insert manual pin into locking device.
- D. Release the tension on the cable by backing the winch off slightly and pull the telescoping locking pin on the galvanized tower section. Hold this out while turning the winch to raise the tower. After the tower has telescoped slightly, the locking pin can be released. Raise the tower to the desired height.

⚠ CAUTION DO NOT ATTEMPT TO LEAN THE TOWER DOWN BELOW 45° WHEN IT IS EXTENDED-SERIOUS DAMAGE MAY OCCUR!

VII. START THE ENGINE / GENERATOR SET

- A. **CAUTION** Ensure the circuit breakers are turned “OFF”. This prevents the engine from starting under load and prevents electrical equipment from being subjected to improper voltage and frequency.
- B. Check the oil, fuel, and coolant (if liquid cooled) levels. If the fuel tank is empty, it may be necessary to bleed the fuel line after filling the tank (see engine instruction book for procedure).
- C. Turn the ignition switch to the “ACC” position (see diagram below). Press the preheat push-button for a **maximum of 20 SECONDS**. Do not engage the preheat button longer than the time specified or damage may occur.



- D. Turn the ignition switch to the “START” position to engage the engine. After the engine starts, release the switch so that it returns to the “RUN” position. Let the engine come up to speed and stabilize (review the engine operating procedures in the manufacturers handbook). Note: If engine will not start, leave switch in run position for additional 10-20 seconds to completely prime the fuel system. Then repeat step “C” and start engine.
- E. Turn on the main circuit breaker.

VIII. TURN ON THE FLOODLIGHTS

- A. Turn the circuit breakers “ON” and check to ensure that all lamps come on. Allow a minimum of two (2) minutes for lamps to reach full luminance.
- B. If required, rotate the tower to aim the lights as desired. Tighten the tower rotating locking bolt.
- C. Adjust the tower vertically and adjust lighting direction of individual fixtures if required.

IX. TURN OFF THE FLOODLIGHTS

- A. If operating, turn light circuit breakers off.
- B. Turn engine switch to “OFF” to shut down the engine.

CAUTION Do not shut down engine prior to turning lights off.

- C. **CAUTION** Allow lamps to cool at least ten (10) minutes before moving the tower to avoid breaking lamps.

X. LOWERING THE TOWER TO TRAVELING POSITION

- A. Using the winch, telescope the tower down to its fully retracted position until the telescoping locking pin snaps into place.
- B. **▲CAUTION** Ensure that the telescoping locking pin locks before pulling the vertical lock pin at the bottom of the pivot post. This ensures the tower is completely lowered and cannot be damaged by telescoping out while in the travel position.
- C. Loosen rotating lock.
- D. Rotate the tower so that the groove in the galvanized ring at the pivot is pointing to the rear of the trailer to enable the tower to be lowered into the travel position.
- E. Tighten rotating lock.
- F. Pull the vertical locking-pin at the base of the pivot post (the kick-out spring should provide sufficient pressure to start the tower pivoting over).
- G. Let out on the winch cable to lower the tower into the cradle.
- H. Insert the rear tower horizontal travel-locking pin into the cradle.

XI. RELOCATING LIGHT TOWER TO NEW LOCATION

- A. Insure that tower has been properly lowered (see section VII) and locking pins are engaged.
- B. Insure all fixtures are pointed toward the ground, or mounted on the fixture storage brackets on the lower tower section.
- C. **▲CAUTION** All jacks must be raised and all outriggers locked into travel position.
- D. Insure that the coupler is properly secured to the towing vehicle and safety chains are attached (if supplied). Release any manual braking mechanism (if supplied).
- E. Do not tow at excessive speeds (60 mph – 100-kmh maximum) as the weight of the light tower can cause loss of vehicle control, especially under emergency stopping conditions. The standard trailer has no towing brakes; therefore allow extra distance for stopping.

XII. USE OF LIGHT TOWER AUXILIARY POWER

- A. One (1) 30amp/240v Twist-Lock and (1) 15 amp/120v receptacles are provided for auxiliary power.
- B. Total auxiliary power cannot exceed main circuit breaker rating. Each lamp operating consumes 10 amps of current @ 120 vac.
- C. Before plugging in auxiliary power cords, feed them up through the trailer frame and attach to receptacles. Close the cabinet doors to protect control panel and other components from weather (see Miscellaneous Specifications and Routine Maintenance section for power control details).

LIGHT FIXTURE TROUBLESHOOTING

⚠ DANGER Do not open fixtures while light circuit breaker is “ON”. Allow lamp to cool before touching.

****TAKE EXTRA PRECAUTIONS WHEN TROUBLESHOOTING ELECTRICAL PROBLEMS****

- A. Only use a voltmeter with two well-insulated pin probes rated for 600 volts.
- B. Treat all conductors as potentially hot.
- C. Proceed through circuits systematically, operating only one section at a time.
- D. Before disconnecting ballast, turn off circuit breaker and wait 30 seconds for capacitor to discharge.
- E. If all the lights are out and all the ballasts are receiving power, suspect burned out power cable.

<u>SYMPTOM</u>	<u>CAUSES</u>	<u>CORRECTIVE ACTION</u>
LAMP WILL NOT START	Check Ballast Status Light	<ul style="list-style-type: none"> a. Input lights should be on. This confirms power is going to the ballast. b. Output lights should be on. This confirms power is coming from ballasts. c. Output lights should be normal brightness. If one or more of the output lights stay extra-bright, then the lamp is not striking. d. Use this knowledge to diagnose problem. e. If ballast status light is out, but the floodlight lamp is working, suspect burned out ballast status lamp and replace.
	Lamp loose in socket	Inspect lamp base to see if there is arcing at center contact button. Tighten lamp snugly. Check socket for damage. Replace if defective.
	Floodlight Plugs not tight	Check plug and receptacle. Tighten if loose.
	Defective Ballast	Interchange ballast plugs in generator enclosure. If lamp starts, replace ballast. Check ballast wiring diagram. Check for swollen capacitors, charred wiring, core and coil, or other signs of excessive heat.
	Low Voltage	Check line voltage at ballast input. Voltage should be within 10% of nameplate rating when operating at normal load. Increase supply voltage or remove external load.
	Improper ballast	Proper HID lamps will perform erratically or fail to start on an improper ballast. The ballast nameplate data should agree with the line voltage and lamp used. Improper ballast will cause lamp to fail.
	Improper lamp operating position	Operating position should agree with lamp etch. A BUHOR lamp can be operated base up vertical to and including the horizontal and BD can be operated base down and vertical to, approaching, but not including the horizontal. A lamp operated beyond the specified position may not start.
	Lamp has been operating; cool down time insufficient	HID lamps require 4 to 8 minutes cool-down time before restarting. Switch off breaker and allow lamp to cool.

LIGHT FIXTURE TROUBLESHOOTING (cont'd)

<u>SYMPTOM</u>	<u>CAUSES</u>	<u>CORRECTIVE ACTION</u>
LAMP STARTS SLOWLY (ARC DOES NOT STRIKE WHEN SWITCH IS FIRST TURNED ON)	Defective Lamp	Lamp may glow for extended period of time. Replace after checking voltage and ballast.
CIRCUIT BREAKER TRIPS ON LAMP START-UP	Short circuit	Checking wiring against diagram. Check for shorts.
LAMP LIGHT OUTPUT LOW	Normal lamp depreciation	Replace lamp
	Dirty lamp or fixture	Clean lamp and fixture (Let cool sufficiently before cleaning)
	Defective ballast	Interchange ballast plugs in generator enclosure. If lamp returns to normal light output, replace ballast. Check for swollen capacitors, charred wiring, core and coil, or other signs of excessive heat.
	Wrong Voltage	Check voltage at ballast input. Voltage should be within 10% of nameplate rating. Check wiring connections for voltage loss. Check socket contact point.
	Improper ballast	Check ballast nameplate against lamp data.
LAMP COLORS DIFFERENT	Normal lamp depreciation	Lamp color and brightness decreases and colors change slightly as lamps age. Spot replacement with new lamps may cause noticeable differences in lamp colors. Group replacement minimizes color differences.
	Dirty fixture	Dirty fixtures will cause lamps to appear different in color. Clean fixture.
	Wrong lamp	Check data on lamps, which appear different in color. Replace with correct color lamp.
ARC TUBE DISCOLORED OR SWOLLEN	Over voltage from power supply	Check voltage at ballast. Check for current or voltage surges. Check for shorted capacitors and replace if defective.
	Improper ballast	Lamp operated on ballast designed for higher wattage lamp. Check ballast nameplate against lamp data.

LIGHT FIXTURE TROUBLESHOOTING (cont'd)

<u>SYMPTOM</u>	<u>CAUSES</u>	<u>CORRECTIVE ACTIONS</u>
SHORT LAMP LIFE	Lamp damaged	Check for outer bulb cracks. If air enters outer bulb, arc tube may continue to burn for 100 hours before failure. Check for bulb cracks where glass meets the base due to tightening lamp too firmly in socket. Look for broken arc tube or loose metal parts. Replace lamp.
	Improper ballast	Ballast nameplate data should agree with lamp line voltage and lamp use. If improper ballast is used, the lamp life will be shortened. A mismatch may also cause the ballast to fail.
LAMP FLICKERS AND GOES OUT INTERMITTET	Improper ballast	Improper ballasting can cause flickering or erratic operation. In the start-up period the lamp may ignite, start to warm-up and then extinguish (cycle).
	New lamp	Under certain conditions new lamps may "cycle". Usually after three (3) tries to start at 30 to 60 second intervals, lamps will stabilize and operate satisfactorily.
	Defective lamp	Replace lamp.
	High spike ballast	Ballast produce high spike current. Measure with oscilloscope. Replace ballast as required.

TRACEABLE NUMBERED WIRING SYSTEM


(Using plug in ballasts to troubleshoot)

When troubleshooting the preceding problems, minimize down time by following the traceable numbered wiring system, always follow these steps:

STEP1: Insure all ballasts, which are numbered, are plugged into lead wires with corresponding numbers.

STEP2: Looking at the lights from the glass side and following the diagram below, plug each fixture into the appropriately numbered plug at the top of the tower.

By adhering to the traceable numbered wiring system, troubleshooting, fixture aiming, and fixture control will follow a standard predictable pattern.



**TEREX Amida Model AL4000
Light Tower – General Specifications
And Routine Maintenance**

TEREX Amida model AL4000 series light tower provides mobile; trailer mounted floodlighting for nighttime maintenance, construction, mining, and emergency work. It consists of a trailer with a diesel powered 6 kW 60Hz (50 Hz units available) generator, and a 30 foot cable actuated tower with four (4) 1000 watt floodlight fixtures. It is ideally suited for heavy-duty use and is built to meet the following specification:

DIMENSIONS

Overall length, travel position w/fixtures & tongue	179"	(4547 mm)
Overall length, tower vertical w/tongue & jacks	124"	(3150 mm)
Trailer frame length	70"	(1778 mm)
Overall height, floodlighting position	30'	(9.14 mm)
Overall height, travel position	68"	(1727 mm)
Overall width with fenders	61"	(1549 mm)
Overall width with outriggers pulled out	102"	(2591 mm)
Trailer frame width	41"	(1041 mm)
Tongue length	44"	(1118 mm)
Wheel size	15"	(381mm)
Axle Rating	3500 lb.	(1588 kg)
Tongue weight travel position	100 lb.	(45.4 kg)
Total weight no fuel	2050 lb.	(930 kg)
Fuel Capacity	30 gal.	(114 l)
Unit weight with full fuel tank	2250 lb.	(1020 kg)

This section details specifications and maintenance not covered in the operators and trouble-shooting sections of this manual and the AL4000 specification sheets.

OIL / AIR SERVICE

The engine oil should initially be changed after the first 50 hours of use and then every 200 hours thereafter. The oil filter should be replaced after every 400 hours of use. The air filter element should be replaced once every year, or after six cleanings (see manufacturer's operation manual for details).

BRAKE SYSTEM

Electrical or mechanical brakes are not standard equipment on the AL4000. Contact your dealer or the factory for option information.

MANUAL WINCH

Maintain a light film of automotive-type grease on the pinion, drum gear, and the O.D. of the drum bearing at all times. Keep the ratchet pawl pivot, pinion shaft bushings, and pinion threads lubricated with automotive engine oil at all times. Before each use, check the brake friction discs for wear. If less than 1/16" thick, cracked, or broken, replace **IMMEDIATELY**. Ratchet pawl should "click" when tower is raised, and not when it is lowered. Always be alert for any fraying of cables, and replace any damaged cables **IMMEDIATELY**. Never stand under any object lifted by the winch.

ELECTRIC WINCH

The electric winch is permanently sealed and does not need any periodic lubrication. Always be alert for any fraying of cables, and replace any damaged cables **IMMEDIATELY**. Never stand under any object lifted by the winch.

RECEPTACLE POWER TABLE

METAL HALIDE/ HIGH PRESSURE SODIUM

STATUS	RECEPTACLE POWER AVAILABLE 120/240 VAC	
LIGHTS ON	DUPLEX W/FI	240V- 30A REC.
ALL OFF	15 AMPS*	30 AMPS*
1 OR 3	15 AMPS*	16.6 AMPS
2 OR 4	15 AMPS*	16.6 AMPS
1 AND 3	15 AMPS*	8.3 AMPS
2 AND 4	8.3 AMPS	8.3 AMPS

TUNGSTEN HALOGEN

STATUS	RECEPTACLE POWER AVAILABLE 120/240 VAC	
LIGHTS ON	DUPLEX W/FI	240V- 30A REC.
ALL OFF	15 AMPS*	30 AMPS*
1 OR 3	15 AMPS*	17 AMPS
2 OR 4	15 AMPS*	17 AMPS
1 AND 3	15 AMPS*	10 AMPS
2 AND 4	15 AMPS*	10 AMPS

- There is more current available than listed. The rating of the duplex receptacle is 15 amps.

NOISE LEVEL

Mean SPL (sound pressure level) hemispherically at 7 meters:

62.01dBA

Sound Power Level (62.01dBA + 20 log d + 7.8):

90.0 LWA re 1 pW

D = 7 meters

MISCELLANEOUS SPECIFICATIONS

The Amida AL4000 light tower is built to NEC standards.

FASTENER TORQUE SPECIFICATIONS

All fasteners should be torqued to the following specifications in lb-ft (lb-in):


FASTENER SIZE UNF & UNC	STAINLESS STEEL *	STAINLESS STEEL* NYLOK NUT	SAE GRADE 5 PLATED (METRIC 8.8)	SAE GRADE 5 PLATED NYLOK NUT	SAE GRADE 8 PLATED (METRIC 10.9)	SAE GRADE 8 PLATED NYLOK NUT
#6	(10-12)	(8.5-10)	(14-16)			
#8	(20-22)	(17-19)	(25-28)			
#10	(26-32)	(22-27)	(40-45)			
1/4"	(75-94)	(64-80)	7-9		12-14	
5/16"	12-Nov	14-Dec	15-17		23-26	
3/8"	20-22	22-24	28-34		45-50	
7/16"	31-33	32-35	40-45		70-75	
1/2"	43-45	45-50	75-85	70-80	100-110	95-105
9/16"	57-63	60-65	80-100	75-95	145-160	135-150
5/8"	92-104	100-105	130-170	125-165	175-205	165-195
3/4"	128-135	140-150	220-240	205-225	380-420	365-405
4mm	(22-26)	(19-22)	(23-27)			
6mm	(45-50)	(38-43)	(72-78)			
8mm	12-Nov	9-10	14-16			
10mm	18-20	15-17	45-50	40-45	70-75	
12mm	42-44	36-38	56-60	50-55	95-105	
16mm			140-148			
18mm			185-200			
20mm			280-290			

* An anti-seize lubricant MUST be used on all stainless steel hardware.

WIND LOADING CHARACTERISTICS

All wind load calculations were performed with the tongue at 12 o'clock, the wind coming from the direction shown with the lights flat-facing into the wind.

WIND DIRECTION	SPEED
FROM 12 O'CLOCK	78 MPH
FROM 1 & 11 O'CLOCK	83.8 MPH
FROM 2 & 10 O'CLOCK	92 MPH
FROM 3 & 9 O'CLOCK	66 MPH
FROM 4 & 8 O'CLOCK	62 MPH
FROM 5 & 7 O'CLOCK	84 MPH
FROM 6 O'CLOCK	90 MPH



NOTE:

If optional front outriggers are used, the allowable wind loading in the 3 and 9 o'clock directions is 79 mph. In the 4 and 8 o'clock directions, the allowable wind velocity would be 94 mph.

CRITERIA FOR REPLACEMENT OF WIRE ROPE – TEREX-AMIDA LIGHT TOWERS

The wire ropes used to raise and lower the masts on a TEREX-Amida Light Tower are probably some of the most important mechanical parts used in day-to-day operation of the machinery. It is therefore very important that the cables be inspected on a frequent basis (once a month) for wear and tear, and immediately in the event of possible damage due to operator error in using the winch, or possible damage from other equipment.

NORMAL WEAR AND TEAR

When used properly, the wire ropes should give years of trouble-free service, depending on how often the masts are raised and lowered. The rule of thumb at TEREX-Amida is that if the tower is **raised and lowered an average of once per day**, that the cables **should be replaced every two years of service**.

NORMAL INSPECTION

The wire ropes are constructed of 7 strands of 19 plow steel wires each twisted together, and then the assembly galvanized to resist corrosion. Using a wadded-up cloth or heavy leather gloves (to avoid being pricked by a broken wire), run a hand up and down a length of the cable. If any exterior wires are broken, they will lift up from main body of the cable and become visible. For any given 1 foot of cable length; if there are 4 or more wires each, on any 2 or more strands broken, the suspect rope **should be replaced immediately**.

OPERATOR ERROR – OTHER MACHINERY DAMAGE

One of the most common reasons for failure of a Light Tower wire rope is due to operator error in using the winch, or damage to the cable by tools or other machinery. The most common operator error happens when the mast is telescoping down. **When the upper telescoping lock engages, the operator does not pull the lower pivot lock out (located on the tower base) and keeps on cranking the winch. This results in the cable becoming loose around the drum due to the tower not pivoting down.** This can result in three problems: the loose cable can get trapped underneath itself, resulting in a sudden or partial “drop” of the mast when the loose section releases at a later time, thus damaging the cable; or the cable can jump off the winch drum and be damaged by the gears of the winch. The loose cable can also cause the drum to spin to take up the slack cable. If there is enough friction in the threaded parts of the winch, the drum can cause the crank handle to start spinning. This can cause the tower to “freefall” and the results can be catastrophic for anyone standing underneath the tower. A spinning crank handle can also break bones. Other reasons damage can occur are due to some outside force such as forklift blade nicking or crushing a cable when moving a unit, or an accidental blow or damage by a hand tool, etc.

DAMAGE INSPECTION

If any nicks (partial strand cut through), kinks (permanent bends), or weld spatter on the cable (from field service) are observed, the suspect wire rope **should be changed immediately**. If there is a crushed spot somewhere on the wire rope, it should be **replaced only** if the width of the crushed spot exceeds 1-1/4 times the nominal diameter of the cable (5/16” on a 1/4” cable, and 7/32” on a 3/16” cable), or if there are broken wires at the point of damage.

BROKEN CABLE REPLACEMENT PROCEDURE

1. PREPARATION

- 1.1 Collapse tower to where mast is retracted, then pivot tower to horizontal position.
- 1.2 Remove the tower from the trailer and place it on a work surface such as two saw horses.

2. REMOVING TOP CABLE AND TOP MAST SECTION

- 2.1 Tie middle section and large section together by wrapping band, cable, chain, or rope around the sheave brackets on these two sections. This insures that the middle section stays inside the large section during removal of the small section.
- 2.2 Remove or lock the telescope lock pin open. This is the pin that locks the three sections together during travel.
- 2.3 Drill out the aluminum pop rivets holding the plastic guides at the top of the middle section. Using a screwdriver, remove these guides.
- 2.4 Remove the clevis pin anchoring the cable to the top of the middle section and remove the clevis pin and the sheave from the middle section.
- 2.5 Pass the free end of the cable through the sheave slot between the middle and small section, and out of the top of the tower. Pull the cable and the small section completely out of the middle section together. Be sure to keep the cable tight; if slack accumulates it is most difficult to remove.
- 2.6 Unfasten the cable by removing the bolt at the base of the small section.

3. REINSTALLING THE SMALL SECTION

- 3.1 Fasten new cable to the base of the small section.
- 3.2 Reversing the procedure described in steps 2.1 through 2.5, reinstall the small section.
- 3.3 Reinstall the plastic guides with new pop rivets. New plastic guides should be used, but the old guides can be used if their mounting position is shifted to the point where new holes can be drilled in the tower section to provide a good fit when installing new pop rivets.


4. REMOVING THE LOWER CABLE AND MIDDLE TOWER SECTION


- 4.1 Remove or lock open the telescope lock pin if not previously done in step 2.2.
- 4.2 Drill out the aluminum pop rivets holding the plastic guides at the top of the large section. Using a screwdriver, remove these guides.
- 4.3 Remove the cable from winch drum.
- 4.4 Remove the sheave clevis pin and the sheave from the top of the large section.
- 4.5 If the old cable is not frayed between the winch and the bottom mast pulley, attach a flexible "fish wire" or "snake" (wire, rope cord, etc.) to the end of the cable to be used to thread the new cable through the lower tower and pulleys. This can be done by "untwisting" the cable and inserting the wire or cord into the middle of the cable and thus letting the cable twist back tightly around the fish wire. If the old cable is frayed, cut off the frayed portion and proceed as above and then remove tower and cable as instructed in section 4.6.

- 4.6 Pass the free end of the cable through the sheave slot between the large and middle sections and out of the top of the tower. Pull the cable and the middle section completely out of the large section altogether. Be sure to keep the cable tight, if slack accumulates it is most difficult to remove.
- 4.7 If the fish wire doesn't work, it is necessary to remove the square mast section from the round mast section. Remove the pivot pin from the pivot post and lift the mast from the pivot post and place the assembly on a work surface. Remove the hex nut from the bottom of the round section, remove the "T" bolt at the top of the round section, and pull the square mast assembly out of the round section, and proceed as instructed in section 4.6.
- 4.8 Unfasten the cable by removing the bolt at the base of the middle section.

5. REINSTALLING THE LOWER CABLE AND MIDDLE SECTION


- 5.1 If the "fish wire" worked, attach the cable to the fish wire and pull through the pulleys and the round section.
- 5.2 If the square tower section was removed from the round section, thread the cable through the pulleys at the bottom of the large section and out of the tubular stud. Reinstall the large square section into the round section. Install the "T" locking bolt, and the hex nut on the bottom of the round section. The hex-locking nut should be tightened and then backed off approximately one-half turn or until the tower rotates freely.
- 5.3 Fasten the new cable to the base of the middle section.
- 5.4 Reversing the procedures detailed in sections 4.4 through 4.7, reinstall the middle section.
- 5.5 Fasten the new cable to the winch drum.
- 5.6 Reinstall the plastic shims as described in section 3.3.





SHIM PLACEMENT (as viewed from crossarm end)

PART# WD2985	DWG.# 2985A
ITEM#	PART#
	DESCRIPTION
	#REQ



NOTE:
PIN CONFIGURATION IS THE SAME
FOR TUNGSTEN HALOGEN FIXTURES


A	3/15/00	DATE	ECO #	ADDED EUROPEAN (CE) WIRING DATA
REV.	DATE	ECO #	CHANGE	
TOLERANCES UNLESS OTHERWISE SPECIFIED:				
Fractions ±1/16				
Decimals .XX=±.030 .XXX=±.010				
.XXXX=±.005				
Degrees ±1/2°				
REMOVE ALL BURRS & SHARP EDGES				
MATL.				
WIRING DIAGRAM, MH OR HPS FIXTURE				
W/JOY CONNECTOR				
DR BY				
SCALE				
PLOT 4/30/91				
DATE 4/30/91				
PART# WD2985				
DWG.# 2985A				

DOMESTIC COLOR CODE	EUROPEAN COLOR CODE	CIRCUIT
WHITE	LIGHT BLUE	COMMON FROM BALLAST
BLACK	BROWN	HOT FROM BALLAST (LIVE)
GREEN	GREEN W/YELLOW	GROUND (EARTH)

Terex-amida

Discount-Equipment.com


PART #	WD2986	DWG. #	2986
ITEM #	PART #	DESCRIPTION	#REQ



REV.	DATE	ECO #	CHANGE
TOLERANCES UNLESS OTHERWISE SPECIFIED:			
Fractions $\pm 1/16$			
Decimals $.XX = \pm 0.030$ $.XXX = \pm 0.010$			
$.XXXX = \pm 0.005$			
Degrees $\pm 1/2^\circ$			
REMOVE ALL BURRS & SHARP EDGES			
WIRING DIAGRAM - 1000MH BALLAST			
MATL.		W/JOY CONNECTOR	
MATERIAL		DR BY CNM	
P/N		APP BY	
USAGE		SCALE NONE	
DATE 4/30/91		PART # WD2986	
DATE 4/30/91		DWG. # 2986	

COLOR	CIRCUIT
BLACK	INPUT 120V
WHITE	INPUT COMMON
RED	LAMP HOT
ORANGE	LAMP COMMON
GREEN	GROUND

PART#	WD2987	DWG.#	2987
ITEM#	PART#	DESCRIPTION	#REQ



5-POLE
RECEPTACLE


COLOR	CIRCUIT
BLACK	INPUT 120V
WHITE	INPUT COMMON
RED	LAMP HOT
ORANGE	LAMP COMMON
GREEN	GROUND

REV.	DATE	ECO #	CHANGE
TOLERANCES UNLESS OTHERWISE SPECIFIED: Fractions ±1/16 Decimals .XX=±.030 .XXX=±.010 .XXXX=±.005 Degrees ±1/2°			
REMOVE ALL BURRS & SHARP EDGES			
MATL. MATL		WIRING DIAGRAM - 1000HPS BALLAST	
MAT P/N		W / JOY CONNECTOR	
USAGE		SCALE: NONE	
DATE: 4/30/91		PART# WD2987	
PLOT: 4/30/91		DWG.# 2987	

TereX-amida

Discount-Equipment.com


DRAWING NO.	REV.	DATE	APPROVED
6495	1		
REVISIONS			
FOR	REV.	DESCRIPTION	DATE



PARTS LIST	NOMENCLATURE OR DESCRIPTION	MATERIAL OR NOTE
1	TEREX LIGHT CONSTRUCTION	
2	AC WIRING FOR A LIGHT TOWER	
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		
33		
34		
35		
36		
37		
38		
39		
40		
41		
42		
43		
44		
45		
46		
47		
48		
49		
50		

QTY	PART OR IDENTIFYING NO.	SCALE	DATE	BY
		1		
		2		
		3		
		4		
		5		
		6		
		7		
		8		
		9		
		10		
		11		
		12		
		13		
		14		
		15		
		16		
		17		
		18		
		19		
		20		
		21		
		22		
		23		
		24		
		25		
		26		
		27		
		28		
		29		
		30		
		31		
		32		
		33		
		34		
		35		
		36		
		37		
		38		
		39		
		40		
		41		
		42		
		43		
		44		
		45		
		46		
		47		
		48		
		49		
		50		

ENGINE COMPONENTS



CONTROL BOX

Terex-amida
 590 HUEY Rd, ROCK HILL, S.C.
 Ph. (803) 324-3011 FAX 366-1101
 WD - DC ENGINE WIRING, KUBOTA
 D905, AL4, AL5, TX3 BORDER "B"
 DR BY JCS/APP BY SCALE N/A
 PART# WD4730 DWG.# 4730G

TOLERANCES UNLESS OTHERWISE SPECIFIED:
 Fractions ±1/16
 Decimals .XX±0.030 .XXX±0.010
 .XXXX±.005
 Degrees ±1/2°
 REMOVE ALL BURRS & SHARP EDGES
 MATL. USAGE
 DATE 3/23/00
 DATE 3/23/00
 DATE 3/23/00


REV.	DATE	ECO #	CHANGE
G	12/22/04	-	REVISED TO MATCH PRODUCTION MODELS
F	9/12/02	-	ADDED CIRCUIT AND DIODES FOR NEW KUBOTA SOLENOID
E	1/12/01	-	ADDED DIODE FOR FUEL PUMP/ PRIME

SWITCH POSITION	ACC	IGN	BAT	ST
ACC	●	○	○	○
IGN	○	●	○	○
BAT	○	○	●	○
ST	○	○	○	●



FIGURE NO.	6549	SHEET NO.	1
REV.		REV.	
DESCRIPTION		DATE	APPROVED
EDR	REV		

ENGINE COMPONENTS

CONTROL BOX



SWITCH POSITION	ACC	DIFF	RUN	START
IGN	o	o	o	o
BAT	o	o	o	o
ST	o	o	o	o





END NO.	REV.	PART OR IDENTIFYING NO.	NOMENCLATURE OR DESCRIPTION	MATERIAL SOURCE
1	1			



APPROVED	BLK	06/15/05	SR	6549
DESIGNED	BLK	06/15/05	D	
DRAWN	BLK	06/15/05	D	

SCALE: 1 OF 1

DRAWING NO. 6496 SPECIAL		REV. 1	REV.
REVISIONS			
ECR	REV.	DESCRIPTION	DATE
-	-	ADDED MOUNTING COMPONENTS FOR SPECIAL BUILD	3/23/05
			APPROVED
			JCS




9 CONDUCTOR 14 GAUGE MALE CONNECTOR PLUG W/ PLASTIC THREAD RING CRIMP CONNECTIONS AND MUST BE FIELD INSTALLABLE (DEUTSCH) HD16-9-96S


9 PIN CONNECTOR	
PIN 1	GREEN
PIN 2	EMPTY
PIN 3	BROWN
PIN 4	BLUE
PIN 5	WHITE
PIN 6	RED
PIN 7	BLACK

NOTES:

- FORCE OF EXTENSION: THE FORCE REQUIRED TO EXTEND ASSEMBLY TO ITS MAXIMUM WORKING LENGTH AT -29° ±3°C (-20° ±5°F) SHALL NOT EXCEED 155.7N (35 LBS).
- COIL FLEX LIFE: CABLE MUST BE CAPABLE OF WITHSTANDING A 200,000 CYCLE TEST WITHOUT MECHANICAL OR ELECTRICAL FAILURE. ONE CYCLE CONSISTS OF EXTENDING ASSEMBLY TO ITS MAXIMUM WORKING LENGTH, THEN RETRACTING TO ITS FREE LENGTH.
- CABLE CONSTRUCTION CONFIRMS TO APPLICABLE REQUIREMENTS OR THE FOLLOWING WIRE AND CABLE SPECIFICATIONS:
 - SAE J1067 FOR COLD BEND, INSULATION AND JACKET COMPOUND.
 - SAE J1128 FOR ABRASION RESISTANCE, HIGH TEMPERATURE OIL ABSORPTION AND DIELECTRIC
 - CABLE TO BE SUBJECTED TO A 3000 VOLT, 60 HZ SPARK TEST AS OUTLINED BY UL STANDARD NO. 62 OR EQUIVALENT.
 - CABLE TO BE BOTH UL AND CSA APPROVED
 - APPROVAL CUL AWM STYLE 2516 REQUIRED



PART OF IDENTIFYING NO.		NOMENCLATURE OR DESCRIPTION		MATERIAL OR NOTE	
FIND NO.	QTY REQD.	PARTS LIST			
<p>THIS DRAWING IS THE PROPERTY OF TEREX LIGHT CONSTRUCTION. ANY REPRODUCTION WITHOUT WRITTEN PERMISSION OF TEREX LIGHT CONSTRUCTION, INC. IS PROHIBITED.</p>					
<p>CONSOLIDATED COIL CORD W/PLUG END</p>					
<p>DRAWING NO. 6496 SPECIAL</p>					
<p>SCALE: 1 OF 1</p>					





ENGINE COMPONENTS

CONTROL BOX

SWITCH TERMINAL

ACC	0	0	0	0	0
DEF	0	0	0	0	0
IGN	0	0	0	0	0
START	0	0	0	0	0




VOLTAGE REGULATOR CONNECTOR
(VIEW FROM WIRE ENTRY SIDE)


FORM NO.	65-49	REV.	1
DATE		APPROVED	


REV.	DESCRIPTION	DATE	APPROVED
1			

QTY	PART OR IDENTIFYING NO.	NOMENCLATURE OR DESCRIPTION	MATERIAL OR NOTE
1	100	ALTERNATOR	
1	101	STARTER MOTOR	
1	102	FUEL SOLENOID	
1	103	VOLTAGE REGULATOR	
1	104	RELAY	
1	105	PUSH BUTTON	
1	106	WIRE HARNESS	

APPROVED	BAL	06/15/05	DESIGNED BY	PERKINS
ENGINEER	BAL	06/15/05	DRAWN BY	PERKINS
DRAWN	BAL	06/15/05	CHECKED BY	PERKINS
FORM NO.				65-49
SCALE				1 OF 1











116203-1, Cabinet Assembly Complete












TEREX
LIGHT CONSTRUCTION


Model: AL4000 LIGHT TOWER


Page:


Title: Cabinet Decals

109471
DECAL KIT,
COMPLETE










Orientation of Shims Inside Tube







TEREX
LIGHT CONSTRUCTION


Model: AL4000 LIGHT TOWER


Page:


Title: 2" Section

















850107 SAFETY DECAL










866120, Radiator Cap


865307, Overflow Tank Kit



839131 Guard

866110, Radiator






630930, Generator 6kW (Leroy Somer)

(2) 990200
Lock Nut

189335, Generator
Mounting Bar

(4) 990210, Flat Washer


(2) 990820, Bolt







NOTE:

FOR COMPLETE MH ASSEMBLY
ORDER PART# 41100720



TEREX PART#	#	DESCRIPTION	QTY.
833563	3	SOCKET BRACKET (T&B 057-05-80643)	1
833564	4	SOCKET MOGUL BASE W/ WIRES	1
833565	5	SCREW 8-32 x 3/8" PH PH TT ZC	2
833566	6	TRUNNION FOR GENERATOR	1
833567	7	HOUSING ALUM. CST. FOR GENERATOR	1
990810	8	BOLT 1/2-13 x 1-1/2" HH MS SS	2
833568	9	REFLECTOR 18" ALUM. PEENED	1
833569	10	GASKET HIF (T&B - B61178)	1
833570	11	REINFORCING RING (T&B - B60198)	1
833571	12	SCREW 10-24 x 5/8 HW SL TT	4
833524	13	VULCANIZED GASKET SILICONE - 1/8" LENS COMBINATION	1
833543	15	CLAMP BAND Ø19.5" ALUMINUM	1
833573	17	HANDLE FOR 1/2-13 BOLT (DWG) (OPTIONAL)	1
682470	18	STRAIN RELIEF #2521 T&B	1
833574	19	SCREW 8-32 X 1 HH SL MS SS	1
663850	20	CORD #16-3 SIOW 105°C + 2 TERM. RING	1
833577	23	SCREW 8-32 x 5/8" FH PH MS ZC	2
991650	24	SPLIT WASHER 1/2 SS	2
990675	25	RIVETS Ø1/8" ALUM. 3/16" LENGHT	2
160071	26	LAMP, 1000 WATT METAL HALIDE	1
833578	27	NUTSERT 8-32 x Ø1/4" x 13/32" LENGHT	1
160140	28	LAMP, 1000 WATT HP SODIUM (OPT.)	1
709034	29	EURO CONNECTOR TERMINAL STRIP	2
683950	31	SEAL RING .755" ID - EPDM	1
680020	32	LOCKNUT 1/2	1
833581	36	FIBER WASHER	1
833582	37	FIBERGLASS SLEEVE 2-1/2"	.5
833583	38	LBL WET LOCATION/EXTERIEUR	1
	39		
833584	40	LBL 105C SUPPLY COND.	1
833585	41	LBL FIXTURE CSA - NRTL/C	1
995970	42	WASHER 1/2 EXTER. TOOTH LOCK SS	2








TEREX
LIGHT CONSTRUCTION

Model: AL4000 LIGHT TOWER

Title: Electric Winch, 12V DC

Option
0LTX0690







TEREX
LIGHT CONSTRUCTION

Model: AL4000 LIGHT TOWER

Title: Stop,Tail & Turn Light, Tag Light

Option:
OLTX0080



Discount-Equipment.com



TEREX
LIGHT CONSTRUCTION

Model: AL4000 LIGHT TOWER

Title: 12V DOME LIGHT WITH SWITCH

Option:
OLT X0270

684030
DOME LIGHT
W/SWITCH






TEREX
LIGHT CONSTRUCTION

Model: AL4000 LIGHT TOWER

Title: 7 POLE CONNECTOR FOR LIGHTS

Option:
OLTX0180

663400
PLUG, 7P



663405
GUARD


DiscountEquipment.com



TEREX
LIGHT CONSTRUCTION

Model: AL4000 LIGHT TOWER
Title: FOUR OUTRIGGERS AND JACKS

Option:
OLTX0540






TEREX
LIGHT CONSTRUCTION

Model: AL4000 LIGHT TOWER


Title: SPARE TIRE AND WHEEL

Option: OLTX0261

124310
MOUNT BRK'T



188070
MOUNT CLAMP



841060
TIRE & WHEEL MOUNTED F78x15, LOAD RANGE B


DiscountEquipment.com




TEREX
LIGHT CONSTRUCTION

Model: AL4000 LIGHT TOWER
Title: EXTRA GFI DUPLEX RECEPTACLE

Option:
OLTX0210



684640
RECEPTACLE, 20A, 120V DUPLEX W/ GFI



683970
BREAKER, MINI, IP/20A




TEREX
LIGHT CONSTRUCTION

Model: AL4000 LIGHT TOWER

Title: ELECTRIC TRAILER BRAKES

Option:

OLTY0315





TEREX
LIGHT CONSTRUCTION


Model: AL4000 LIGHT TOWER


Title: AXLE WITH SURGE BRAKES


Option: 0LTY0314/316

NOTE: SEE STANDARD AXLE FOR COMMON PARTS


841480, KIT: BRAKE LINES AND FITTINGS (NOT SHOWN)




 TEREX LIGHT CONSTRUCTION	Model: AL4000 LIGHT TOWER	Option: OLTX0130
	Title: BATTERY BLANKET	



160530
BATTERY BLANKET

 TEREX LIGHT CONSTRUCTION	Model: AL4000 LIGHT TOWER	Option: OLTX0222
	Title: BATTERY 700 AMP	






TEREX
LIGHT CONSTRUCTION

Model: AL4000 LIGHT TOWER

Title: FUEL LINE HEATER

Option: OLTX0140

741690
FUEL LINE HEATER



Discount-Equipment.com