REVISED SERIAL NO. 4550



PARTS LIST MANUAL

Model SK-14



14" MANUAL STREET SAW FOR CONCRETE & ASPHALT



PARTS FINDER Search Website Search Website Search Website Search Website







Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: http://www.discount-equipment.com/category/5443-parts/ and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep,Small Line, Wanco, Yanmar

READ AND UNDERSTAND THE OPERATORS INSTRUCTION MANUAL THOROUGHLY BEFORE ATTEMPTING TO OPERATE THIS EQUIPMENT. Death or serious injury could occur if this machine is used improperly.



SAFETY MESSAGES



The safety instructions are proceeded by a graphic alert message of DANGER, WARNING, or CAUTION.



Indicates an imminent hazard which, if not avoided, will result in death or serious injury.



Indicates an imminent hazard which, if not avoided, can result in death or serious injury.



Indicates hazards which, if not avoided, could result in serious injury and or damage to the equipment.

GASOLINE

Powered Equipment







 Do not operate gasoline powered equipment without adequate ventilation. Carbon monoxide is an invisible, odorless gas that can kill.

ELECTRICAL

Powered Equipment





ELECTRICAL HAZARD - Be sure equipment is properly grounded.
 Failure to comply could kill or result in serious injury.



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

GENERAL INSTRUCTIONS -





- You must read and understand the operators instruction manual and all other manuals associated with this machine. For your safety and the safety of others around you, it is extremely important to fully understand how to operate this machine in the way it was intended. Different model machines or older/newer versions of the same model may have different parts and controls that you need to understand. If instructions are not readable or available DO NOT USE this machine and contact Discount-equipment for a replacement Manual.
- You must be able to physically handle the bulk weight and power of this machine. If not properly controlled this machine can cause death or serious injury.
- Do not operate this machine in an impaired mental state. You must be able to exercise good judgement and reactions to maintain a safe working environment.
- This is a "one person" machine which means only one operator can be operating the machine at any one time. For the safety of others, maintain a safe operating distance to other personnel. Your work area should be defined and appropriately marked so bystanders and coworkers do not stand or walk near this machine and end up seriously injured by flying debris or exposing them to harmful noise or dust.
- This equipment is for Commercial use. Although this is a "one person" machine your work team should understand how to shut this machine off and quickly get medical help if an accident strikes the operator.
- Keep all guards in place during operation. The guards are to provide protection from inadvertent contact with dangerous moving parts, pinch points, or hot surfaces.
- Wear appropriate Personal Protective Equipment (PPE) including safety glasses, safety boots, work gloves, respiratory protection,

- hearing protection, and head protection. Do not wear loose clothing that can get tangled in moving parts. Failure to do so could result in dismemberment or death. Wear an approved respirator when removing hazardous materials or when grinding/cutting dry materials. Some dust particles such as concrete dust can contain silicate particles which can cause silicosis (a very serious lung disease). Contact NIOSH or OSHA for further details. When wet grinding/cutting, avoid contact with the concrete/asphalt slurry which can cause serious skin irritations.
- You must maintain this machine per the maintenance schedule in the operator manual. Remember before adjusting, servicing, or fueling this machine, disconnect the source of power to the machine by disconnecting the spark plug (Gas models), or by unplugging the electrical power cord (electric models) or air hose (Pneumatic models) AT THE MACHINE so you can assure yourself it remains unplugged while you are working on it. Do not modify this machine. Use only genuine EDCO parts and accessories. Repairs and service should be performed by approved EDCO dealers or authorized technicians.
- You should look carefully around the area before you begin work so you can identify potential hazards such as deck inserts, pipes, columns, openings, electrical cords or outlets, or any other objects protruding from the slab surface.
- This machine has no brain so you must use your own. There is no substitute for safety. The safety decals on the machine are to serve as a reminder for information you must already know before you begin using this machine. Take a moment to reread the safety decals each time you use the machine. If your machine is missing any decals, contact Discount-equipment.




PARTS LIST MANUAL EDCO MODEL SK-14

Section	Page Number
Safety Messages / General Instructions. How To Order Replacement Parts Illustration #1: Main Frame Grouping. Parts Listing - Illustration # 1: Main Frame Grouping Illustration # 2: Arbor & Blade Guard Grouping. Parts Listing - Illustration # 2: Arbor & Blade Guard Grouping. Illustration # 3: Engine Grouping. Parts Listing - Illustration # 3: Engine Grouping. Limited Equipment Warranty.	3

	MODEL SK-14 MANUAL STREET SAWS			
	PART#	MODEL#	GASOLINE ENGINE OPTION	
	45400D	SK14-9H	9HP HONDA GX270-QXC9	
	45600D	SK14-11H	11HP HONDA GX340K1-QXC9	
	48100D	SK14-13H	13HP HONDA GX390K1-QXC9	
Coxo	count	Edulle		
=		D.		



ILLUSTRATION #1: MAIN FRAME GROUPING






	PART	S LISTING - ILLUSTRA	ATION	l # 1:	MAIN FI	RAME GROUPING
ITEM#	PART#	DESCRIPTION	QTY.	ITEM#	PART#	DESCRIPTION
1	52060	MAIN FRAME	1	46	10025	WASHER, FLAT 3/8
2	52021	HANDLE BAR	1	47	10011	SPACER, STEEL 5/8 OD x 3/8 ID
3	10029	SCREW, CAP 3/8-24 x 1-3/4	4	48	10004	NUT, LOCK 3/8-24
4	10025	WASHER, FLAT 3/8	8	49	50024	WHEEL, 4 x 1-3/8 x 3/8" BORE
5	10004	NUT, LOCK 3/8-24	4	50	52022	BUMPER, RUBBER
6	79022	GRIP, HAND 1" MODEL RG	2			1" OD x 3/16 ID x 7/16 H
7	80008	HANDWHEEL, SMALL w/ 5/8-11 x 12"		51	52023	RIVET, BLIND 3/16 x .7"L x .375
		ROD	1			
8	10411	SCREW, SKT. HD. CAP 1/2-13 x 4	1			40
9	50550	SLEEVE FOR 1/2" CAPSCREW, TAPERED) 1			
10	14023	KNOB, BALL 1-3/8" DIA. w/ 1/2-13 THD	. 1			4
11	80007	DECAL, "CUT CONTROL" (SMALL)	1			order Je
12	80009	BEARING, BALL 5/8" 2-HOLE FLANGE	1			
13	10412	BOLT, CARRIAGE 1/4-20 x 1	2			40
14	10213	WASHER, FLAT 5/16	2			
15	10602	WASHER, FLAT 1/4	2			
16	10861	NUT, KEPS 1/4-20	2		~ ()	
17	55010	SPACER, HANDWHEEL 5/8' ID x 3/4	1			
18	10046	NUT 5/8-11	1			
19	50010	SWITCH KIT, STOP BUTTON, 7/8 HOLE	1			
20	52016	LINKAGE, CUT CONTROL	1			
21	10321	SCREW, CAP 1/2-20 x 1-1/4	1			
22	10205	NUT, LOCK 1/2-20	1			
23	52061	FORK	1			
24	52010	SPACER, FRONT WHEEL 3/4 ID x 15/16	2			
25 26	52001 10009	WHEEL, ALUM. 4 x 1-1/2 x 3/4" BRG. WASHER, FLAT 3/4	2 2			
27	10306	PIN, COTTER 3/16 x 1-1/4	2			
28	80028	WHEEL 6 x 2 x 3/4" BRG.				
20	00020	(MOUNTED OUTSIDE OF FRAME)	2			
29	52062	AXLE SHAFT 3/4 DIA. x 19-1/4 L	1			
30	10009	WASHER, FLAT 3/4	6			
31	10306	PIN, COTTER 3/16 x 1-1/4	2			
32	52006	COVER, BELT	1			
33	52046	COVER, BELT - INNER PANEL	1			
34		STUD, BELT COVER	3			
	52013	3/8-16 x 5 1/2 (11 & 13HP HONDA)				
	52044	3/8-16 x 6 (9HP HONDA)				
35	52012	SPACER, BELT COVER 3/8 ID x 3-11/16	3			
36	10811	WASHER, LOCK 3/8	3			
37	10437	NUT, ACORN 3/8-16	3			
38	10025	WASHER, FLAT 3/8	9			
39	10404	NUT 3/8-16	3			
40	52045	SPACER, STEEL 5/8 OD x 3/8 ID x 3/4L	1			
		(9HP HONDA ONLY)				
41	52007	GUIDE BAR	1			
42	10309	SCREW, CAP 3/8-24 x 1-1/4	1			
43	10025	WASHER, FLAT 3/8	3			
44	10004	NUT, LOCK 3/8-24	1			
45	10885	SCREW, CAP 3/8-24 x 3	1			

IIEM#	PART#	DESCRIPTION	QIY.
46	10025	WASHER, FLAT 3/8	3
47	10011	SPACER, STEEL 5/8 OD x 3/8 ID x 3/8	/8 1
48	10004	NUT, LOCK 3/8-24	2
49	50024	WHEEL, 4 x 1-3/8 x 3/8" BORE	1
50	52022	BUMPER, RUBBER	
		1" OD x 3/16 ID x 7/16 H	1
51	52023	RIVET, BLIND 3/16 x .7"L x .375 HD	1



ILLUSTRATION #2: ARBOR & BLADE GUARDGROUPING






ITEM#	PART#	DESCRIPTION	QTY.
1	69050A	ARBOR ASSEMBLY COMPLETE (ITEMS 2 -13)	1
2	69050	ARBOR SHAFT 1" DIA. x 19-1/4	1
3	62022	BEARING, BALL 1" 2-HOLE FLANGE	2
4	10961	FITTING, GREASE 1/4-28 x 90°	1
5	10960	FITTING, GREASE 1/4-28 x 45°	11
6	10003	SCREW, CAP 7/16-20 x 1-1/4	4
7	10450	WASHER, LOCK 7/16	4
8	10481	NUT 7/16-20	4
9	10211	PIN, ROLL 5/16 x 2	1
10	56026	ARBOR BACKING PLATE 4" DIA.	1
11	56025	ARBOR BLADE CAP 4" DIA. w/ 1" HOLE	1
12	55009	WASHER, LOCK, INT. TOOTH 1"	1
13	50019	NUT, JAM 1-14	1
14	80027	SHEAVE, 3" OD x 3Gr.A x 1" BORE	1
15	10115	KEY 1/4 SQ. x 2	1
16	52005A	BLADE GUARD ASSEMBLY COMPLETE	
		(ITEMS 17 - 26)	
17	52005	GUARD, BLADE 14"	1
18	40012	FLAP, SPLASH 2-1/2 x 7	1
19	10018	SCREW, CAP 1/4-20 X 3/4	1
20	10602	WASHER, FLAT 1/4	2
21	10015	NUT, LOCK 1/4-20	1
22	81004	NOZZLE, COOLANT 1/8 MPT w/ 4" TUBES	1
23	10724	ELBOW, STREET 1/2 NPT x 90° (BLACK)	1
24	10711	VALVE, BALL 1/2 FPT	1
25	80021	CONN., SWIVEL FEMALE 3/4 HOSE x 1/2 MPT	1
		INCLUDES HOSE WASHER, ITEM # 26	
26	10070	WASHER, HOSE 3/4	1
27	52002	LATCH, FLEXIBLE DRAW w/ T-HANDLE	1
28	10830	SCREW, MACHINE 10-32 x 1/2	1
29	10831	WASHER, LOCK, INT. TOOTH #10	4
30	10832	NUT 10-32	4




ILLUSTRATION # 3: ENGINE GROUPING



		PARTS LISTIN	IG -	ENGIN	E GROU	JPING
ITEM#	PART#	DESCRIPTION	QTY.	ITEM#	PART#	DESC
1		ENGINE,) 1	12	10877	SCREV
	15027	HONDA 9HP GX270-QXC9		13	10982	TIE, CA
	79045	HONDA 11HP GX340 K1-QXC9		14	11565	CLAMF
	15029	HONDA 13HP GX390K1-QXC9		15	10877	SCREV
2	10918	BOLT, CARRIAGE 5/16-18 x 1-3/	4 4	16	11542	BARB,
3	10213	WASHER, FLAT 5/16	4			3/8 HO
4	10801	WASHER, LOCK 5/16	4	17	52063	HOSE,
5	10054	NUT 5/16-18	4	18	11544	BARB,
6	80027	SHEAVE 3" OD x 3Gr.A x 1"				3/8 HO
	•	BORE	1	19	10776	PIPE P
7	10307	KEY 1/4 SQ. x 2-1/4	1	20	36042	CLIP, A
8	10253	BELTAX-27	3			5/8 x 5/
9	52015	BOLT, TAP 3/8-16 x 3-1/2		21	50010	SWITC
*		(FULL THREAD)	1		000.0	HOLE
10	10404	NUT 3/8-16	1	(INCI	UDES SV	
11	40388	CABLE, THROTTLE,		`	CONNEC	
		LEVER-TYPE 24"	1		CONNEC	


Γ	ГЕМ#	PART#	DESCRIPTION (QTY.
	12	10877	SCREW, CAP STSHW 10-24 x 1/2	2 2
	13	10982	TIE, CABLE, BLACK NYLON 11-1	/4 1
	14	11565	CLAMP, LOOM, 5/8" (SAE SIZE 1	0) 1
	15	10877	SCREW, CAP STSHW 10-24 x 1/2	2 1
	16	11542	BARB, PUSH-ON	
			3/8 HOSE x 12mm x 1.5 MALE	1
	17	52063	HOSE, PUSH-ON 3/8" ID x 10-1/2	"L 1
	18	11544	BARB, PUSH-ON	
			3/8 HOSE x 1/4 FPT	1
	19	10776	PIPE PLUG 1/4 NPT (BRASS)	1
	20	36042	CLIP, ADHESIVE BACK CORD	
			5/8 x 5/8	2
	21	50010	SWITCH KIT, STOP BUTTON, 7/8	,
			HOLE	1
	(INCL	UDES SV	/ITCH SUBASSY., WIRES, TERMII	NALS,
	BUTT	CONNEC	CTOR & GROUND HARDWARE)	

ILLUSTRATION # 4: CE BLADE GUARD WITH SAFETY SWITCH



ITEI		RTS LISTI PART#	NG - CE BLADE GUARD WITH SAFETY SWITC DESCRIPTION	CH QTY.
1	5	52005E	GUARD, BLADE 14" CE (REFER TO ILLUS. #2 FOR	
			VALVE, NOZZLE AND FLAP COMPONENTS)	1
2	1	0021	SCREW, CAP 3/8-24 x 1	1
3	1	0014	NUT 3/8-24	1
4	5	52040	SWITCH, WATERPROOF, 2-WIRE N/C	1
5	5	52041	BRACKET, SAFETY SWITCH	1
6		0877	SCREW, CAP STHW 10-24 x 1/2	2
7	5	0084	TERM., RING # 10 16-14 GA. INSULATED	1
8	1	0938	CONNECTOR, BUTT 16-14 GA. INSULATED	1
9	1	0633	SWITCH, TOGGLE SPST	1
1	0 1	1642	TREM., RING #6 16-14 GA. BLUE VINYL INSULATED	2
1	1 1	1560	GROMMET, 7/16ID x 3/16GRV. x 9/16GD.	1
1	2 1	0454	WASHER, LOCK, INT. TOOTH 1/2"	1
1	3 ~	~~~	THIN HEX NUT INCL. w/ TOGGLE SWITCH	1
1	4 1	0674	BOOT, TOGGLE SWITCH	1
1	5 1	0005	PLUG, HOLE 7/8' (CHROME)	1

ILLUSTRATION #5: OPTIONAL WATER TANK ASSEMBLY PART # 52030



ILLUS [*]	TRATION #	5: OPTIONAL WATER TANK ASSEMBLY (PAR	Т # 52030)
ITEM#	PART#	DESCRIPTION	QTY.
1	52031	DRUM, PLASTIC 5 GALLON, 3/4 NPT CAP	10
2	52035	TIE-DOWN STRAP, MOLDED RUBBER 24"	2
3	52036	TRAY, WATER TANK	1
4	52037	MOUNT BRACKET, WATER TANK (RIGHT)	1
5	52038	MOUNT BRACKET, WATER TANK (LEFT)	1
6	10053	SCREW, CAP 5/16-18 x 3/4	4
7	10213	WASHER, FLAT 5/16	8
8	10801	WASHER, LOCK 5/16	4
9	10054	NUT 5/16-18	4
10	10029	SCREW, CAP 3/8-16 x 1-3/4	4
11	10025	WASHER, FLAT 3/8	8
12	10004	NUT, LOCK 3/8-16	4
13	10843	BOLT, SPADE 2- 3/8-16 x 1- 5/8	2
14	10810	NUT, LOCK 3/8-16	4
15	52034	BUSHING, HEX 3/4 x 1/4 NPT (BRASS)	1
16	10799	BARB, ELBOW 90° 3/8 HOSE x 1/4 MPT	1
17	10714	CLAMP, HOSE, SAE #4, ADJ. TO 5/8"	4
18	52028	HOSE, WATER, 3/8 x 1-3/4	1
19	11637	COUPLING, QUICK-DISCONNECT 3/8"	
		(SPECIAL FITTING w/ SHUT-OFF)	1
20	52029	HOSE, WATER, 3/8 x 18-1/2"	1
21	52027	BARB, 3/8 HOSE x 1/2MPT, WHT NYLON	1
22	52026	ADAPTER, 3/4 MGH x 1/2FPT, WHT NYLON	1
23	10031	SCREW, CAP 1/4-20 x 1	2
24	10213	WASHER, FLAT 5/16	2
25	10015	NUT, LOCK 1/4-20	2

PARTS FINDERS Search Website Can't Find







Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: http://www.discount-equipment.com/category/5443-parts/ and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep,Small Line, Wanco, Yanmar