


CUTTER DRUM ASSEMBLY PROCEDURES



EQUIPMENT DEVELOPMENT COMPANY, INC.



PARTS FINDER Search Website Search Website Search Website Search Website







Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: http://www.discount-equipment.com/category/5443-parts/ and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.


We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep,Small Line, Wanco, Yanmar

Table of Contents

	Model CPM-8	Page
	6-Shaft - General Purpose - Carbide Cutters	4
	6-Shaft - Fine - Carbide Cutters	
	6-Shaft - 4" Line Removal - Carbide Cutters	6
	6-Shaft - General Purpose - Pointed Steel Cutters	7
	6-Shaft - Special Milling - Carbide Milling Cutters	8
	Model CPM-8 EDGER Drum Assemblies	\cap
	6-Shaft Edger - General Purpose - Carbide Cutters	9
	6-Shaft Edger - Fine - Carbide Cutters (Model CPM4 or CPM8)	
	6-Shaft Edger - Line Removal - Carbide Cutters	11
	6-Shaft Edger - Fine - Flat-Tip Steel Cutters (Model CPM4 or CPM8).	12
	6-Shaft Edger - Super Fine - Pointed Steel Cutters (Model CPM4 or CPM8)	13
	Model CPL-8 Scari-Lite	
	6-Shaft - General Purpose- Carbide Cutters	14
	6-Shaft - Pointed Steel Cutter	15
	Model CPM-10	
	6-Shaft - General Purpose - Carbide Cutters	16
	6-Shaft - Fine - Carbide Cutters	17
	8-Shaft - General Purpose - Carbide Cutters	18
	6-Shaft - Fine - Pointed Steel Cutters	19
	Model CPU-10FC	
	6-Shaft - General Purpose - Carbide Cutters	20
	4-Shaft - General Purpose - Carbide Cutters	20 21
	6-Shaft - Fine - Carbide Cutters	22
	Model CPU-12	
	6-Shaft- General Purpose - Carbide Cutters	23
	-0	
C.O	Oisco Contraction of the contrac	



CPM-8, 6-Shaft General Purpose **Carbide Cutter Drum Assembly**



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange

Carbide Cutter



CG227 Part# 12230



CP206-T Part# 20156

CPM-8, 6-Shaft Fine Carbide Cutter Drum Assembly



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange



CP206-T Part# 20156

CPM-8, 6-Shaft 4" Line Removal Carbide Cutter Drum Assembly



261 Spacers 54 Cutters

Carbide Cutter



CP206-T Part # 20156

Spacer



CG227 Part # 12230

Instructions: Repeat the same sequence for the other 3 shafts.

- Loose fit
- One Spacer minimum by each flange

Key:

1\$ - 1 Spacer

2 S - 2 Spacers

3 S - 3 Spacers

26 S - 26 Spacers

34 S - 34 Spacers

10 - 1 Cutter

20 - 2 Cutters

50 - 5 Cutters



CPM-8, 6-Shaft General Purpose Pointed Steel Cutter Drum Assembly



132 Spacers 144 Cutters

- 3 Spacers
- 2 Cutters
- 2 Spacers
- 2 Cutters
- 2 Spacers
- 2 Cutters
- 2 Spacers
- 2 Cutters
- 1 Spacer
- 1 Cutter
- 1 Spacer
- 1 Spacer
- 5 Cutters
- 1 Spacer
- 2 Cutters
- 2 Spacer
- 2 Cutters
- 2 Spacers
- 2 Cutters2 Spacers
- 2 Cutters
- 2 Spacers
- 2 Cutters
- 1 Spacer

Spacer



CG227 Part# 12230 Pointed Steel



JRS-501 Part# 12206

Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange



CPM-8, 6-Shaft Special Milling Carbide Milling Cutter Drum Assembly



174 Spacers 48 Cutters

5 Spacers

1 Cutter

4 Spacers

1 Cutter

4 Spacers

1 Cutter

1 Spacer

2 Spacers

2 Cutters

4 Spacers

1 Cutter

4 Spacers

1 Cutter

4 Spacers

1 Cutter

1 Spacer

Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange

Carbide Milling Cutter




Part# 12230



CP207-T Part# 20336



CPM-8 Edger, 6-Shaft General Purpose Carbide Cutter Drum Assembly



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange



CG227 Part# 12230



CP206-T Part# 20156



CPM-4 or CPM-8 Edger Attachment, 6-Shaft Fine Carbide Cutter Drum Assembly



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange

Carbide Cutter







CP206-T Part# 20156



CPM-8 Edger, 6-Shaft Line Removal Carbide Cutter Drum Assembly



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange

Spacer




CG227 Part# 12230

CP206-T Part# 20156



CPM-4 or CPM-8 Edger Attachment, 6-Shaft Fine Flat-Tip Steel Cutter Drum Assembly



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange





CP305 Part# 20206

CPM-4 or CPM-8 Edger Attachment, 6-Shaft Super Fine Pointed Steel Cutter Drum Assembly



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange





JRS-501 Part# 12206



CPL-8, 6-Shaft General Purpose Carbide Cutter Drum Assembly





Loose fit

• One Spacer minimum by each flange

CPL-8, 6-Shaft Pointed Steel Cutter Drum Assembly



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange




CG227 Part# 12230

CP204-P Part# 20236



CPM-10, 6-Shaft General Purpose **Carbide Cutter Drum Assembly**



252 Spacers 102 Cutters

1 Cutter 3 Spacers 1 Cutter

3 Spacers

1 Cutter

3 Spacers

3 Spacers

1 Cutter 3 Spacers

1 Cutter

2 Spacers 1 Cutter

1 Spacer

1 Spacer 1 Cutter 1 Spacer

3 Cutters

3 Spacers

1 Cutter

3 Spacers

1 Cutter

1 Cutter

3 Spacers

1 Cutter

3 Spacers

1 Cutter

3 Spacers

1 Cutter

Carbide Cutter

Spacer



CP403 Part # 20060




CP308-T Part# 20326

Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange

CPM-10, 6-Shaft Fine **Carbide Cutter Drum Assembly**





- Loose fit
- One Spacer minimum by each flange



Part# 20326

CPM-10, 8-Shaft General Purpose **Carbide Cutter Drum Assembly**



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange



CP206-T Part# 20156

CG227

Part# 12230

CPM-10, 6-Shaft Fine **Pointed Steel Cutter Drum Assembly**



240 Spacers 132 Cutters

- 1 Spacer 1 Cutter
- 2 Spacers
- 1 Cutter
- 2 Spacers 1 Cutter
- 2 Spacers
- 1 Cutter
- **Spacers**
- Cutter
- 2 Spacer
- 1 Cutter
- 2 Spacers 1 Cutter
- 2 Spacers
- 1 Cutter
- 2 Spacers 1 Cutter
- 1 Spacer
- 2 Spacers
- 1 Cutter
- 1 Spacer
- 4 Cutters
- 2 Spacers
- 1 Cutter
- 2 Spacers
- 1 Cutter 2 Spacers
- Cutter
- **Spacers**
- 1 Cutter
- 2 Spacers 1 Cutter
- **Spacers**
- 1 Cutter
- Spacers
- 1 Cutter
- 2 Spacer
- 1 Cutter
- 3 Spacers

Pointed Steel Cutter









CP404-P6 Part# 20296

Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange



CPU-10FC, 6-Shaft General Purpose Carbide Cutter Drum Assembly



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange





CP308-T Part# 20326


CPU-10FC, 4-Shaft General Purpose Carbide Cutter Drum Assembly





• One Spacer minimum by each flange

CPU-10FC, 6-Shaft Fine Set-up Carbide Cutter Drum Assembly



Instructions: Repeat this sequence for every other shaft, then rotate the sequence 180° and repeat for the remaining shafts.

- Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange








CP308-T Part# 20326



CPU-12, 6-Shaft General Purpose Carbide Cutter Drum Assembly



300 Spacers 102 Cutters

Carbide Cutter



CP408-TV Part # 20136

Spacer



CP403 Part # 20060

Instructions:
Rotate drum 180°
and Repeat the same
sequence for the
other 3 shafts.

- · Rotationally Balanced
- Loose fit
- One Spacer minimum by each flange

Key:

15 - 1 Spacer

2S - 2 Spacers

3S - 3 Spacers

1C - 1 Cutter

2C - 2 Cutters



PARTS FINDER Search Website Search Website Search Website Search Website







Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: http://www.discount-equipment.com/category/5443-parts/ and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep,Small Line, Wanco, Yanmar