PARTS MANUAL



MODELS MODELS WBH-16EAWD WBH-16EAWDF POWER BUGGY

(B&S VANGUARD 18 HP GASOLINE ELECTRIC START)

Revision #5 (01/25/22)



THIS MANUAL MUST ACCOMPANY THE EQUIPMENT AT ALL TIMES.

PARTS FINDERS Search Website Can't Find







Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: http://www.discount-equipment.com/category/5443-parts/ and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep,Small Line, Wanco, Yanmar

WBH-16EAWD Power Buggy

Explanation of Code in Remarks Column	4
Suggested Spare Parts	5

Component Drawings

Nameplate and Decals Assembly	6–7
Hydraulic Drive Assembly	8–9
Hydraulic Pump Assembly	10–11
Hydraulic Dump Assembly	12–13
Manifold Assembly	14–15
Pump and Coupling Assembly	16–17
Tub Assembly	18–19
Panel Assembly	20–21
Brake Assembly	22–23
Steering and Controls Assembly	24–25
Chassis Assembly	26–27
Handle/Foot Dump Controls Assembly	28–29
Hydraulic Oil Tank Assembly	30–31
Battery Assembly	32–33
Fuel Tank Assembly (Steel)	34–35
Fuel Tank Assembly (Plastic)	36–37
Engine Mounting Assembly	38–39
Engine Service Parts	40–41

NOTICE

Specifications and part numbers are subject to change without notice.

EXPLANATION OF CODE IN REMARKS COLUMN

The following section explains the different symbols and remarks used in the Parts section of this manual. Use the help numbers found on the back page of the manual if there are any questions.

NOTICE

The contents and part numbers listed in the parts section are subject to change **without notice**. Multiquip does not guarantee the availability of the parts listed.

SAMPLE PARTS LIST

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	12345	BOLT	1	INCLUDES ITEMS W/%
2%		WASHER, 1/4 IN	۱	NOT SOLD SEPARATELY
2%	12347	WASHER, 3/8 IN	N1	MQ-45T ONLY
3	12348	HOSE	A/R	MAKE LOCALLY
4	12349	BEARING	1	S/N 2345B AND ABOVE

NO. Column

Unique Symbols — All items with same unique symbol (@, #, +, %, or >) in the number column belong to the same assembly or kit, which is indicated by a note in the "Remarks" column.

Duplicate Item Numbers — Duplicate numbers indicate multiple part numbers, which are in effect for the same general item, such as different size saw blade guards in use or a part that has been updated on newer versions of the same machine.

NOTICE

When ordering a part that has more than one item number listed, check the remarks column for help in determining the proper part to order.

PART NO. Column

Numbers Used — Part numbers can be indicated by a number, a blank entry, or TBD.

TBD (To Be Determined) is generally used to show a part that has not been assigned a formal part number at the time of publication.

A blank entry generally indicates that the item is not sold separately or is not sold by Multiquip. Other entries will be clarified in the "Remarks" Column.

QTY. Column

Numbers Used — Item quantity can be indicated by a number, a blank entry, or A/R.

A/R (As Required) is generally used for hoses or other parts that are sold in bulk and cut to length.

A blank entry generally indicates that the item is not sold separately. Other entries will be clarified in the "Remarks" Column.

REMARKS Column

Some of the most common notes found in the "Remarks" Column are listed below. Other additional notes needed to describe the item can also be shown.

Assembly/Kit — All items on the parts list with the same unique symbol will be included when this item is purchased.

Indicated by:

"INCLUDES ITEMS W/(unique symbol)"

Serial Number Break — Used to list an effective serial number range where a particular part is used.

Indicated by:

"S/N XXXXX AND BELOW"

"S/N XXXX AND ABOVE"

"S/N XXXX TO S/N XXX"

Specific Model Number Use — Indicates that the part is used only with the specific model number or model number variant listed. It can also be used to show a part is NOT used on a specific model or model number variant.

Indicated by:

"XXXXX ONLY"

"NOT USED ON XXXX"

"Make/Obtain Locally" — Indicates that the part can be purchased at any hardware shop or made out of available items. Examples include battery cables, shims, and certain washers and nuts.

"Not Sold Separately" — Indicates that an item cannot be purchased as a separate item and is either part of an assembly/kit that can be purchased, or is not available for sale through Multiquip.

SUGGESTED SPARE PARTS

WBH16EAWD POWER BUGGY

1 to 3 units

Qty.	P/N	Description
1	508667	. FILTER, HYDRAULIC OIL
1	EM16477	. CAP, HYDRAULIC OIL TANK
1	18035	. PUMP, HYDRAULIC
1	18051	. COUPLING, ENGINE SHAFT
2	512881	. BRAKE BAND ASSY.
1	18145	. ROD, BRAKE CONTROL
		. CAP, FUEL (NON EPA, 2-IN)
1	520820	.CAP, FUEL (EPA, 2-IN)
5	845125	. FILTER, IN-LINE FUEL
	18043	
1	18133	.CABLE, THROTTLE
1	18132	.LEVER,THROTTLE
1	18029	. WHEEL, DRIVE, PNEUMATIC
		.WHEEL, DRIVE, FOAM
1	18082	. WHEEL, STEERING, PNEUMATIC
		. WHEEL, STEERING, FOAM
		.CABLE, PARKING BRAKE
1	18044	. SWITCH, TRACTION ASSIST
1	EM16754	. SWITCH, 2WD/AWD TOGGLE

NOTICE


Part numbers on this Suggested Spare Parts list may supersede/replace the part numbers shown in the following parts lists.

B&S VANGUARD 18 HP GASOLINE ENGINE

1 to 3 units

Qty.	P/N	Description
3	496018S	SPARK PLUG
3	691959	KEY, IGNITION
3	808167	GRIP, STARTER
1	66574	ROPE, STARTER
		AIR FILTER
3	272490S	PRE-CLEANER
3	842921	OIL FILTER
3	845125	IN-LINE FLIEL FILTER


NAMEPLATE AND DECALS ASSY.



NAMEPLATE AND DECALS ASSY.

<u>NO.</u>	PART NO.	PART NAME	QTY.	<u>REMARKS</u>
1 2	18247	DECAL, CRUSH WARNING DECAL, TRAVEL LEVER DIRECTION	1 1	MOLDED INTO FLIEL TANK COVER
3		PLATE, SERIAL NUMBER	1 1	CONTACT MQ PARTS DEPT.
4	491757	RIVET, I.D. PLATE	2	A CONTRACTOR OF THE CONTRACTOR
5	18248	DECAL, HOT SURFACE WARNING	1	
6 7	512446 18252	DECAL, WBH-16 AWD DECAL, MQ WHITEMAN	2	.00
8	18245	DECAL, MQ WITTEMAN DECAL, FORKLIFT LIFTING	6	
9	513608	DECAL, LIFTING HOOK	3	
10		DECAL, GASOLINE ONLY	1	MOLDED INTO FUEL TANK COVER
11 12		DECAL, WHITEMAN SAFETY INSTRUCTIONS DECAL, BUCKET DUMP LEVER		
13	EM985	DECAL, HYDRAULIC OIL	1 1	WOLDED INTO TOLE TANK GOVER
14	520935	DECAL, SAFETY INSTRUCTIONS	1	., 0
15	518524	DECAL, ISO 9001:2008	1	
16	35137	DECAL, READ MANUAL, ASK FOR TRAINING	1	
		X		
	C	Q		
	1.65			
×				
o `				
O'				
0				
0				
0				
0				
0			REV. #	5 (01/25/22) — PAGE 7
0		H-16EAWD POWER BUGGY • PARTS MANUAL	— REV. #	5 (01/25/22) — PAGE 7


HYDRAULIC DRIVE ASSY.



HYDRAULIC DRIVE ASSY.

<u>NO.</u>	<u>PART NO.</u> 513598	PART NAME HOSE, MANIFOLD	<u>QTY.</u>	<u>REMARKS</u>
2	18265M	HOSE, MANIFOLD	1	
3	513606	HOSE, RH HYDRAULIC MOTOR	1	
4	513000	ADAPTER, ELBOW	2	×
5	513605	HOSE, LH HYDRAULIC MOTOR	1	
6	512189	ADAPTER, T-CONNECTOR	1	
7	492527	NUT, HEX 1/2"-20	Ω	
8	18029	WHEEL	4	PNEUMATIC TIRE
8A	18029 18029F	WHEEL, DRIVE ASSY. FRONT		FOAM FILLED TIRE
9@	511692	FLANGE, HUB	2	I OAWIT ILLED TITLE
10@	18237	LUG BOLT/HUB FLANGE	8	
11	492584	NUT, HEX 1/2"-13 NYLON	8	
12	18190	SCREW, HUB STUD 1/2"-20 X 2-3/4"	8	
13	491689	KEY, COTTER 1/8" X 2		.0
14	PT018038	NUT, CASTLE 1-1/8"-18	2 2 2	
15	803281	HUB, DRIVE	2	
16	3365	ADAPTER, STRAIGHT	4	
17	505718	SCREW, HHC 1/2"-13 X 2-3/4"	8	
18	18011	MOTOR, HYDRAULIC DRIVE	2	
19	PE449105	KEY, WOODRUFF 1-1/4" 32 MM	2	
20	492600	WASHER, FLAT 1/2"	8	
21	492584	NUT, NYLOC 1/2"-13	8	
22	18027	HOSE, DRIVER MOTOR CROSSOVER	1	
23	513602	HOSE, MANIFOLD	1	
24	513547	ADAPTER, ELBOW	1	
25	513601	HOSE, MANIFOLD	1	
26	513603	HOSE, MANIFOLD	1	
28	513607	HOSE, HYDRAULIC	1	
29	516528	FLANGE HUB, ASSY	1	INCLUDES ITEMS W/@
30	512201	ADAPTER ELBOW	1	
31	18011SK	SEAL KIT, DRIVE MOTOR	1	


HYDRAULIC PUMP ASSY.



HYDRAULIC PUMP ASSY.

1 18035 PUMP, HYDRAULIC 1 2 511808 ADAPTER, STRAIGHT 2 3 3365 ADAPTER, STRAIGHT 2 4 18256M HOSE, PUMP TO DUMP VALVE 1 5 18258M HOSE, FILTER TO PUMP 1 6 18261M HOSE, PUMP TO TANK 1 7 513599 HOSE, PUMP TO DIRECTION VALVE 1 8 512190 ADAPTER, STRAIGHT 2 9 18257M HOSE, FILTER TO DUMP VALVE 1 10 508667 FILTER, HYDRAULIC OIL 1 11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 14 18058 VALVE, DIRECTION CONTROL 1 14A 18058SK SEAL KIT 1					
2 511808 ADAPTER, STRAIGHT 2 3 3365 ADAPTER, STRAIGHT 2 4 18256M HOSE, PUMP TO DUMP VALVE 1 5 18258M HOSE, PUMP TO TANK 1 7 513599 HOSE, PUMP TO DIRECTION VALVE 1 8 512190 ADAPTER, STRAIGHT 2 9 18257M HOSE, FILTER TO DUMP VALVE 1 10 508667 FILTER, HYDRAULIC OIL 1 11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 144 18058S VALVE, DIRECTION CONTROL 1 15 18262M HOSE, PUMP TO DIRECTION VALVE 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW 2. REPLACES P/N 492373 18 0166 A WASHER, LOCK 3/8"	<u>NO.</u>				<u>REMARKS</u>
4 18256M HOSE, PLMP TO DUMP VALVE 1 5 18258M HOSE, FILTER TO PUMP 1 6 18261M HOSE, PUMP TO TANK 1 7 513599 HOSE, PUMP TO DIRECTION VALVE 1 8 512190 ADAPTER, STRAIGHT 2 9 18257M HOSE, FILTER TO DUMP VALVE 1 10 508667 FILTER, HYDRAULIC OIL 1 11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, STRAIGHT 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 144 180585 VALVE, DIRECTION CONTROL 1 14A 180585 VALVE, DIRECTION CONTROL 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW 2 REPLACES P/N 492673 18 0166 A WASHER, LOCK 3/8" REPLACES P/N 492624	=		•		
4 18256M HOSE, PLMP TO DUMP VALVE 1 5 18258M HOSE, FILTER TO PUMP 1 6 18261M HOSE, PUMP TO TANK 1 7 513599 HOSE, PUMP TO DIRECTION VALVE 1 8 512190 ADAPTER, STRAIGHT 2 9 18257M HOSE, FILTER TO DUMP VALVE 1 10 508667 FILTER, HYDRAULIC OIL 1 11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, STRAIGHT 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 144 180585 VALVE, DIRECTION CONTROL 1 14A 180585 VALVE, DIRECTION CONTROL 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW 2 REPLACES P/N 492673 18 0166 A WASHER, LOCK 3/8" REPLACES P/N 492624				2	
5 18288M HOSE, FILTER TO PUMP 1 6 18261M HOSE, PUMP TO TANK 1 7 513599 HOSE, PUMP TO DIRECTION VALVE 1 8 512190 ADAPTER, STRAIGHT 2 9 18257M HOSE, FILTER TO DUMP VALVE 1 10 508667 FILTER, HYDRAULIC OIL 1 11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 14 18058 VALVE, DIRECTION CONTROL 1 14 18058SK SEAL KIT 1 15 18262M HOSE, PUMP TO DIRECTION VALVE 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW 2. REPLACES P/N 492373 18 0166 A WASHER, LOCK 3/8° . REPLACES P/N 492624			,	1	×
6 18261M HOSE, PUMP TO TANK 1 7 513599 HOSE, PUMP TO DIRECTION VALVE 1 8 512190 ADAPTER, STRAIGHT 2 9 18257M HOSE, FILTER TO DUMP VALVE 1 10 508667 FILTER, HYDRAULIC OIL 1 11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 14 18058 VALVE, DIRECTION CONTROL 1 14A 18058K SEAL KIT 1 15 18262M HOSE, PUMP TO DIRECTION VALVE 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW			· · · · · · · · · · · · · · · · · · ·	1	
7 513599 HOSE, PUMP TO DIRECTION VALVE 1 8 512190 ADAPTER, STRAIGHT 2 9 18257M HOSE, FILTER TO DUMP VALVE 1 10 508667 FILTER, HYDRAULIC OIL 1 11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 144 18058 VALVE, DIRECTION CONTROL 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW 2	6		· · · · · · · · · · · · · · · · · · ·	1	
9 18257M HOSE, FILTER TO DUMP VALVE 1 10 508667 FILTER, HYDRAULIC OIL 1 11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 14 18058 VALVE, DIRECTION CONTROL 1 14A 18058SK SEAL KIT 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, TANK TO PUMP 1 16 18266M HOSE, TANK TO PUMP 2 17 EM963055 HEX HEAD CAP SCREW	7	513599	HOSE, PUMP TO DIRECTION VALVE	1	
10 508667 FILTER, HYDRAULIC OIL 1 11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 14 18058 VALVE, DIRECTION CONTROL 1 14A 18058SK SEAL KIT 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW	8		·	2	
11 508664 SUPPORT, FILTER 1 12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 14 18058 VALVE, DIRECTION CONTROL 1 14A 18058SK SEAL KIT 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW			· · · · · · · · · · · · · · · · · · ·	1	O ,
12 511799 ADAPTER, ELBOW 2 13 3322 ADAPTER, ELBOW 6 14 18058 VALVE, DIRECTION CONTROL 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW				1	
13 3322 ADAPTER, ELBOW 6 14 18058 VALVE, DIRECTION CONTROL 1 14A 18058SK SEAL KIT 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW				2	
14 18058 VALVE, DIRECTION CONTROL 1 14A 18058SK SEAL KIT 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW 2 REPLACES P/N 492373 18 0166 A WASHER, LOCK 3/8" 2 REPLACES P/N 492624			·		
14A 18058SK SEAL KIT 1 15 18262M HOSE, TANK TO PUMP 1 16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW	14			1	
16 18266M HOSE, PUMP TO DIRECTION VALVE 1 17 EM963055 HEX HEAD CAP SCREW	14A	18058SK		1	
17 EM963055 HEX HEAD CAP SCREW	15		•	1	
18 0166 A WASHER, LOCK 3/8"				x 10	DEDI ACEO D/N. 400070
to Discount. Edin Prent. con.				2	REPLACES P/N 4923/3
		Ois C	Junit Folijohnel.		
	0				
		WBH-16	6EAWD POWER BUGGY • PARTS MANUAL	— REV. #5 (I	01/25/22) — PAGE 11
				•	,

HYDRAULIC DUMP ASSY.



NOTES:



REFERENCE HYDRAULIC PUMP ASSEMBLY ITEM 4 FOR HOSE PART NUMBER.


REFERENCE HYDRAULIC PUMP ASSEMBLY ITEM 9 FOR HOSE PART NUMBER.

REFERENCE HANDLE/FOOT DUMP CONTROLS
ASSEMBLY ITEM 8 FOR DUMP VALVE
PART NUMBER.

HYDRAULIC DUMP ASSY.

1A 2 3 4 5 6 7 8	PART NO. 18022 18022SK 491705 511803 18020 511804 512234 511806 506191	PART NAME CYLINDER, HYDRAULIC DUMP SEAL KIT, DUMP CYLINDER ZERK FITTING ADAPTER, ELBOW HOSE, DUMP VALVE TO HYD. PISTON ADAPTER, ELBOW MALE ADAPTER, ELBOW ADAPTER, STRAIGHT ADAPTER, ELBOW	QTY. 1 2 2 2 1 1 1	REMARKS
				order 40
			7,0	
		aliphent.com		
		int. Folling		
	Oisco			
,O X				


MANIFOLD ASSY.



MANIFOLD ASSY.


1\$ 2 3 4\$ 6 7\$ 8\$ 9\$ 10\$ 12\$ 12A 13\$	PART NO. 18045 3322 3365 509103 513548 18159 18147 18161 25539 18134 18174 18174SK 18034	PART NAME MANIFOLD BLOCK ADAPTER, ELBOW ADAPTER, STRAIGHT ADAPTER ORIFICE SOLENOID, CARTRIDGE SEAL KIT, SOLENOID, CARTRIDG	QTY. 1 3 3 1 1 2 2 2 2 1 E 1 3	REMARKS
14\$ 14A 15\$ 15A\$ 16	18093KIT 18093SK 507785 18095 18127	CARTRIDGE VALVE ASSY. W/ 12V SEAL KIT, SOLENOID, CTRL., CAF COIL, SOLENOID COIL, SOLENOID MANIFOLD ASSEMBLY	COIL 2	INCLUDES ITEMS W/\$
			coll.	
		Jilomerne		
		JUNI-E CHIPMEN		
	Oisc	SUNTEROLINA		
	Disc	Junit. L. Culil Pine 1		

PUMP AND COUPLING ASSY.




PUMP AND COUPLING ASSY.

4.0	PART NO.	PART NAME	QTY.	<u>REMARKS</u>
1#	492472	SCREW, ALLEN HEAD 3/8"-16 X 3/4"	2	
2	18051	COUPLING, ENGINE SHAFT		INCLUDES ITEM W/#
2A	18051RS	SPIDER, URETHANE	1	
2B 2C	492356 492622	SCREW, 1/4" X 3/4" GRD 5 WASHER, LOCK 1/4"	1	
20 2D	EM923057	WASHER, FLAT 3/4"	1	DEDI ACES D/N 50445
4	18112	FAN		nerlaces r/in 30443
6	EM923057	WASHER, FLAT 1/4"	2	DEDLACES D/N 40050
7	492355	SCREW, HHC 1/4"-20 X 1/2"	2 2	
11	506250	KEY, WOODRUFF	1	.00
20	513761	FAN GUARD, AWD	1	
21	510701	BRACKET, LONG	1	
22	512737	BRACKET, SHORT	1	
23	EM963055	BOLT, HHCS 3/8" NC X 3/4" GRD 5	1	REPLACES P/N 49237
24	0166A	WASHER, LOCK 3/8"		
25	512367	BOLT, C/H 3/16" NC X 1/2" GRD 2	4	TIET E/(OEOT/IN +0202
26	492595	WASHER, FLAT 3/16"	4	
27	492621	WASHER, LOCK 3/16"	4	
28	492438	BOLT, C/H 5/16" NF X 1" GRD 5	\sim 1	
29	492623	WASHER, LOCK 5/16"	i	
30	802442	LOCK COLLAR	i	
31	803009	BUSHING, HYDRAULIC PUMP.	1	
×	Olis			
0				




TUB ASSY.

5 6 7 9	18130 18129	PIN, HYD. PISTON CROSS		
10 11 12	0202 492597 492583 492582	PIN, TUB FRAME CROSS SCREW, HHC 5/16"-18 X 1" ZINC WASHER, FLAT 9.5 X 22.2 NUT, NYLOC 3/8"-16 NUT, NYLOC 5/16"-18	2 1 4 8 9	REPLACES P/N 492364
13 14 14 15	512279 18099 522262 EM916019	SUPPORT, BUM STOP FRAME, TUB MOUNT, 16 CU. FT FRAME, TUB MOUNT, 16 CU. FT GREASE FITTING	1	
			in to)
		ent.c) ,	
		JUIPME		
	Ois Co			
×(°				
2				



PANEL ASSY.


NO. 1 2	PART NO. 503978 511474	PART NAME POP RIVET AM-56 FASTENER, ACCESS DOOR	<u>QTY.</u> 1 1	<u>REMARKS</u>
3 4	18008 492355	DOOR, ACCESS SCREW, 1/4" NC X 1/2" GRD 5	1 2	
5 6	492597 18141	WASHER, FLAT 3/8" COVER, RIGHT/SIDE ENGINE	32 1	
7 8	492364 492582	SCREW, HHC 5/16"-18 X 1" NUT, NYLOC 5/16"-18	6 9	1.
9 10	801026 492623	COVER, LEFT/SIDE ENGINE WASHER, LOCK 5/16"	1 4	
12	492363	SCREW, HHC 5/16" NC X 3/4" GRD 5	10	. 3
13 14	23297 EM923057	MANUAL HOLDER WASHER, 1/4"	4	REPLACES P/N 492596
15	EM16754	2WD/AWD TOGGLE SWITCH	1	10
			~O	
		iiQ.		
	c,C			
	AIS .			
X	,			
\mathcal{O}				
				_
-		_		
	WBH-16	BEAWD POWER BUGGY • PARTS MANUA	L — REV. #5 (01/25/22) — PAGE 21



BRAKE ASSY.


1 2 3	511762	PART NAME	<u>QTY.</u>	<u>REMARKS</u>
3	00=	SCREW, HHC 1/2"-13 X 8"	1	
	511698	CLEVIS, ASSY. BRAKE	2	
	492574	NUT, HEX 3/8"-24 NF	2	
4	18111	PEDAL, BRAKE	1	
5	621	WASHER, FLAT 1/2"	1	
6	492584	NUT, NYLOC 1/2"-13	10	
7	18167	SPRING, BRAKE PEDAL	1	
8	18307	SPRING, BRAKE	2	
9\$		BAND, BRAKE	2	NOT SOLD SEPARATELY
10\$		LINING, BRAKE	2	NOT SOLD SEPARATELY
11\$	503723	RIVET, BRAKE LINING	56	
12	18303	SHAFT, CRANK PIN	2	()
13	492395	SCREW, HHC 1/2"-13 X 1-3/4"	1	
14	512602	BRAKE LEVER, LEFT	1	
14A	512601	BRAKE LEVER, RIGHT	1	
15	18032	LINKAGE, RIGHT BRAKE	i	3 '
16	18314	LINKAGE, LEFT BRAKE	, io	
17	492582	NUT, NYLOC 5/16"	3	
18	492365	SCREW, HHC 5/16" NC X 1-1/4" GRD		
19	505170	CLIP. PARK CABLE	1	
20	18016	CABLE, PARK BRAKE	1	
21	492367	SCREW, HHC 5/16"-18 X 1-3/4"	3	
22	18057	LEVER, ASSY. PARK BRAKE	1	
23	492597	WASHER, FLAT 3/8"	6	
23 24	18145	ROD, BRAKE CONTROL	1	
25	512881	BRAKE BAND ASSY	2	INCLUDES ITEMS W/\$
26	6109170	WASHER, FLAT 1/2"		
		SURILIFOUNIA		

STEERING AND CONTROLS ASSY.



STEERING AND CONTROLS ASSY.


<u>NO.</u>	PART NO.	PART NAME	QTY.	<u>REMARKS</u>
1	506088	SCREW, HHC 1/4"-20 X 3/8"	1	
2	492369	SCREW, HHC 5/16"-18 X 2-1/4"	1	
3	18183	ROD-END, THROTTLE CABLE	2	
4	492582	NUT, NYLOC 5/16"-18	1	X
5	EM504505	WRAP, TIEHANDLE BAR	2	REPLACES P/N 504505
6	18242	HANDLE BAR	1	REPLACES P/N 18282
7	18044	SWITCH, TRACTION ASSIST	1	
8	15081	GRIP, HANDLE	2	REPLACES P/N 511432
9	505304	COVER, WIRE (LOOM)	1	1PC=1FT
10	18133	CABLE, THROTTLE	1	10
11	18043	SWITCH, KILL	1	
12	492465	SCREW, ALLEN HEAD 1/4"-20 X 3/8"	1	
13	492581	NUT, NYLOC 1/4"-20	2	70,
14	509161	WASHER, FLAT 5/16"	2	*O
15	18132	LEVER, THROTTLE	1	
16	18182	BUSHING, CABLE	1	
17	18176	SPRING	_1	
18	18181	BUSHING, CABLE	1	
19	18061	LEVER, CONTROL	1	
20	492357	SCREW, HHC 1/4"-20 X 1	1	
21	511717	KEY, WOODRUFF 1/8" X 5/8"	1	
22	492584	NUT, NYLOC 1/2"-13	1	
23	18177	SPRING	1	
24	492583	NUT, NYLOC 3/8"	2	
25	492598	WASHER, FLAT 3/8"	2	
26	491723	PIN, STEERING SHAFT	1	
27	18255	STEERING COLUMN	1	
28	18238	BEARING, STEERING SHAFT	1	
29	512186	PIN, STEERING SHAFT	1	
30	491689	COTTER PIN, 1/8" X 2"	1	
31	3311	KEY, WOODRUFF 1-1/4" 32 MM	2	REPLACES P/N PE449105
32	513611	HOSE, HYDRAULIC MOTOR	1	
33	513610	HOSE, HYDRAULIC MOTOR	1	
34	512201	ADAPTER, ELBOW	2	
35	18011	MOTOR, HYDRAULIC DRIVE	1	
36	492584	NUT, NYLOC 1/2"	4	
37	492600	WASHER, FLAT 1/2"	4	
38	PT018038	NUT, CASTLE 1-1/8"	1	
39	492399	BOLT 1/2" X 3"	4	
40	18207	HUB, DRIVE	1	
41	18082	WHEEL, STEERING REAR		
41A	18082F	WHEEL, STEERING REAR	1	FOAM FILLED TIRE
42	18083	CONE BOLT 1/2" X 1-1/2"	4	
43	512200	BUSHING, BRONZE	2	



CHASSIS ASSY.

2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 18 19 20 21 22 23 24 27	492583 492598 492313 503112 492375 492356 492622 512196 18146 505069 18198 505976 506185 492623 492623 492366 18047 492586 492597	NUT, NYLOC 3/8" WASHER, FLAT 3/8" SCREW, HHC 3/8"-16 X 1-1/2" SCREW, HHC 3/8"-16 X 2-3/4" SCREW, HHC 3/8"-16 X 12 SCREW, HHC 1/4" NC X 3/4" GRD 5 WASHER, LOCK 1/4" BRACKET, HYD. PUMP MOUNTING MOUNT, OIL FILTER NUT, NYLOC 3/4"-10 ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	QTY. 10 18 3 4 2 2 2 1 1 1 2 5 2	rder your or
3 4 5 6 7 8 9 10 11 12 13 14 15 16 18 19 20 21 22 23 24 27	492313 503112 492375 492356 492622 512196 18146 505069 18198 505976 506185 492623 492366 18047 492586	SCREW, HHC 3/8"-16 X 1-1/2" SCREW, HHC 3/8"-16 X 2-3/4" SCREW, HHC 3/8"-16 X 12 SCREW, HHC 1/4" NC X 3/4" GRD 5 WASHER, LOCK 1/4" BRACKET, HYD. PUMP MOUNTING MOUNT, OIL FILTER NUT, NYLOC 3/4"-10 ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	3 4 2 2 1 1 1 2 2 5	rder your pa
4 5 6 7 8 9 10 11 12 13 14 15 16 18 19 20 21 22 23 24 27	503112 492375 492356 492622 512196 18146 505069 18198 505976 506185 492623 492366 18047 492586	SCREW, HHC 3/8"-16 X 2-3/4" SCREW, HHC 3/8"-16 X 12 SCREW, HHC 1/4" NC X 3/4" GRD 5 WASHER, LOCK 1/4" BRACKET, HYD. PUMP MOUNTING MOUNT, OIL FILTER NUT, NYLOC 3/4"-10 ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	4 2 2 1 1 1 2 2 5	rder your pa
5 6 7 8 9 10 11 12 13 14 15 16 18 19 20 21 22 23 24 27	492375 492356 492622 512196 18146 505069 18198 505976 506185 492623 492366 18047 492586	SCREW, HHC 3/8"-16 X 12 SCREW, HHC 1/4" NC X 3/4" GRD 5 WASHER, LOCK 1/4" BRACKET, HYD. PUMP MOUNTING MOUNT, OIL FILTER NUT, NYLOC 3/4"-10 ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	2 2 1 1 1 2 2 5	rder your pa
6 7 8 9 10 11 12 13 14 15 16 18 19 20 21 22 23 24 27	492356 492622 512196 18146 505069 18198 505976 506185 492623 492366 18047 492586	SCREW, HHC 1/4" NC X 3/4" GRD 5 WASHER, LOCK 1/4" BRACKET, HYD. PUMP MOUNTING MOUNT, OIL FILTER NUT, NYLOC 3/4"-10 ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	2 1 1 1 2 2 5	rder your pa
7 8 9 10 11 12 13 14 15 16 18 19 20 21 22 23 24 27	492622 512196 18146 505069 18198 505976 506185 492623 492366 18047 492586	WASHER, LOCK 1/4" BRACKET, HYD. PUMP MOUNTING MOUNT, OIL FILTER NUT, NYLOC 3/4"-10 ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	2 1 1 1 2 2 5	rder your po
8 9 10 11 12 13 14 15 16 18 19 20 21 22 23 24 27	512196 18146 505069 18198 505976 506185 492623 492366 18047 492586	BRACKET, HYD. PUMP MOUNTING MOUNT, OIL FILTER NUT, NYLOC 3/4"-10 ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	1 1 1 2 2 5	rder your P
9 10 11 12 13 14 15 16 18 19 20 21 22 23 24 27	18146 505069 18198 505976 506185 492623 492366 18047 492586	MOUNT, OIL FILTER NUT, NYLOC 3/4"-10 ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	2 5	rder your
10 11 12 13 14 15 16 18 19 20 21 22 23 24 27	505069 18198 505976 506185 492623 492366 18047 492586	NUT, NYLOC 3/4"-10 ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	2 5	rder you.
11 12 13 14 15 16 18 19 20 21 22 23 24 27	18198 505976 506185 492623 492366 18047 492586	ROD, TUB PROP CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	2 5	rder you
12 13 14 15 16 18 19 20 21 22 23 24 27	505976 506185 492623 492366 18047 492586	CLAMP, BRACKET CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	2 5	rder y
13 14 15 16 18 19 20 21 22 23 24 27	506185 492623 492366 18047 492586	CLAMP, BRACKET WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	2 5	rger,
14 15 16 18 19 20 21 22 23 24 27	492623 492366 18047 492586	WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	2 5 2	'9°.
15 16 18 19 20 21 22 23 24 27	492366 18047 492586	SCREW, HHC 5/16"-18 X 1-1/2" CHASSIS	5 2	(0)
16 18 19 20 21 22 23 24 27	18047 492586	CHASSIS	2	
18 19 20 21 22 23 24 27	492586			
19 20 21 22 23 24 27		NULT NIVLOCEOU 11	1	
20 21 22 23 24 27	492597	NUT, NYLOC 5/8"-11	2	
21 22 23 24 27		WASHER, FLAT 9.5 X 22.2	3	
22 23 24 27	18162	PANEL, REAR WHEEL COVER	1	
23 24 27	18222	PLATFORM, OPERATOR	1	
24 27	492313	SCREW, HHC 3/8"-16 X 1-1/2"	1	
27	492406	SCREW, HHC 5/8"-11 X 1-1/2"	2	
	492363	SCREW, HHC 5/16"-18 X 3/4"	3	
28	492553	NUT, HEX 5/16"-18	3	
	18173	LATCH, PLATFORM	1	
*C	Oisco)	JINI LECULIA DE LA COMPANSIONE DEL COMPANSIONE DE LA COMPANSIONE D		
9				

HANDLE/FOOT DUMP CONTROLS ASSY.




REFERENCE HYDRAULIC DUMP ASSY.

HANDLE/FOOT DUMP CONTROLS ASSY.


<u>NO.</u>	PART NO.	PART NAME	QTY.	<u>REMARKS</u>
1	492401	SCREW, HHC 1/2"-13 X 4	1	
2	503119	NUT, NYLOC 3/16"]	
3	18121	KNOB, LEVER	1	
4	18065	LEVER, DUMP VALVE	1	
5	512185	SCREW, HHC 1/4"-20 X 1-3/4"	2	
6	492622	WASHER, FLAT 1/4"	4	
7	512183	SCREW, HHC 3/16"-24 X 1-1/4"	1	
8	18064	VALVE, DUMP	1	INCLUDES ITEMS W/\$
8A	18064SK	SEAL KIT, DUMP VALVE	1	
9\$		PIN, DUMP VALVE CROSS	1	NOT SOLD SEPARATELY
10	492596	WASHER, FLAT 1/4"	1	
11	492581	NUT, NYLOC 1/4"-20	1	
12	492584	NUT, NYLOC 1/2"-13	2	70,
13	492600	WASHER, FLAT 1/2"	1	
14	18152	PEDAL, DUMP VALVE	1	
15	18123	CLEVIS, ASSY. DUMP VALVE	2	J
16	492574	NUT, HEX 3/8"	2	
17	18153	ROD, DUMP VALVE	1	
18	492400	SCREW, HHC 1/2"-13 X 3-1/2"	1	
19	18122	BELL CRANK, DUMP VALVE	1	
20	512200	BUSHING, BRONZE	2	
21	803151	STOP, STEERING	1	
22	492467	SET SCREW, 5/16" X 3/8" NC	2	
23	503901	ZERK FITTING 1/4"-28	1	
	Oisc			
X	O T			

HYDRAULIC OIL TANK ASSY.



HYDRAULIC OIL TANK ASSY.


2 3	PART NO. 520461 801791 520460	PART NAME RETAINER O-RING COVER	QTY. 1 1	<u>REMARKS</u>
4 5 6 7 8 9	520343 510717 EM16477 18125 492376 492598	O-RING BOLT, 1/2" NC X 1-3/4" CAP, HYDRAULIC OIL TANK TANK, HYDRAULIC OIL SCREW, HHC 3/8" X 1-1/4" WASHER, FLAT 3/8"	1 1 1 3 6	OUT
10 11 12% 13 14 15	18229 492583 18052 491213 506094	SCREEN, OIL RESERVOIR NUT, NYLOC 3/8"-16 SCREW,SIGHT GAUGE, HYD. OIL TANKPLUG, HYD. OIL TANK 1/2" NPT PLUG, HYD. OIL TANK 1/2" NPT	1 3 2 1 1	NOT SOLD SEPARATELYINCLUDES ITEM W/%
			,0'	
		ant.c),	
		dilphne		
	. 60			
×				
,O*(



BATTERY ASSY.


4 6	PART NO. 505500 512557 511250	PART NAME WINGNUT BATTERY CABLE, NEGATIVE BATTERY CABLE, POSITIVE	QTY. 2 1 1	REMARKS
8 10 12 16 18 20 22 24	512555 EM923057 2101402 508480 492357 503119 512585 4671	BATTERY SUPPORT BRACKET WASHER, FLAT 1/4" WASHER, LOCK 1/4" BATTERY SUPPORT PLATFORM BOLT 3/16" X 1" NUT 3/16" SUPPORT BRACKET BOLT BATTERY	1 2 1 2 2 2 2	REPLACES P/N 492596 REPLACES P/N 492622
	1071		×O	olge,
		Colilpino		
×	Oisco C			

FUEL TANK ASSY. (STEEL)




FUEL TANK ASSY. (STEEL)

NO.	PART NO.	PART NAME	QTY.	REMARKS
1	520820	CAP, FUEL (EPA) 2" DIA.	1	
2	802006	FUEL TANK NECK SEAL	1	
3	800845	COVER, FUEL TANK, FRONT, PLASTIC	1	
4	521392	COVER, FUEL TANK, REAR, PLASTIC	1	X
5	492356	SCREW, 1/4" X 3/4" GRD 5	4	
6	492622	WASHER, LOCK 1/4"	4	
7	509161	WASHER, FLAT 5/16""	4	. 0
8	EM202772	VENT VALVE, EPA	1	
9	EM203403	GROMMET, VENT VALVE	1	
10	802498	TENSION CLAMP	1	10
11	60004	HOSE, FUEL, Ø.1875, LOW PERM 50PSI 41	" 1	
12	802573	TENSION CLAMP	1	<i>*</i> ,
13	845125	FILTER, IN-LINE FUEL	1	70,
15	520611	HOSE, FUEL, 1/4" EPA 3.1 FT. (.95 M)	4	1PC=1FT
16	22081	VALVE, FUEL SHUT-OFF	1	
17	802574	TENSION CLAMP	1 0	
18	506208	CLAMP, FUEL HOSE	3	
19	492581	NUT, NYLOC 1/4"	2	
20	492595	WASHER, FLAT 1/4"	2 3	
21	801130	CLAMP, RUBBER COATED	3	
22	511807	CLAMP, NYLON 5/8"	1	
23	492355	SCREW, 1/4" NC X 1/2" GRD 5	1	
24	800056	BOLT, HHCS 1/4" NC X 3/4" GRD 5	2	
25	800841	TANK, FUEL, STEEL	1	
26	802498	TENSION CLAMP	3	
27	520833	HOSE, AIR FILTER 3/16" X 5-1/2" (.14M), EP	Ά1	1PC=1FT
28	802405	REDUCER, HOSE 1/4" TO 3/16"	1	
29	23505	CANISTER, CHARCOAL, 390CC (EPA)	1	
30	510725	CLAMP	2	
31	492363	SCREW, 5/16" X 3/4" GRD 5	6	
32	EM923343	WASHER, LOCK 5/16"	8	REPLACES P/N 492623
33	EM923023	WASHER, FLAT 5/16"	8	REPLACES P/N 492597
34	491030	PLASTIC TIE WRAP	1	




FUEL TANK ASSY. (PLASTIC)

7 506208 CLAMP, FUEL HOSE 4 9 19633 SEAL, FUEL TANK GROMMET 1 10 20795 VALVE, FUEL SHUT-OFF 1 11 512192 HOSE, FUEL 1 12 EM20763 FILTER, FUEL 2 13 512191 HOSE, FUEL 1 14 511807 STRAP, NYLON 5/8" 1 15 515386 COVER, FUEL TANK	2 3 5	PART NO. EM923343 EM492299 EM923023 18166	PART NAME WASHER, LOCK 5/16" SCREW, HHC 5/16"-18 X 1/2" WASHER, FLAT 5/16" CAP, FUEL 4" DIA.	QTY. 4 4 4 1	<u>REMARKS</u>
15 515386 COVER, FUEL TANK	7 9 10 11 12 13	506208 19633 20795 512192 EM20763 512191	CLAMP, FUEL HOSE SEAL, FUEL TANK GROMMET VALVE, FUEL SHUT-OFF HOSE, FUEL FILTER, FUEL HOSE, FUEL	1 1 1	JOUN P
Oiscount. Equipment. con.	15	515386	COVER, FUEL TANK		REPLACES P/N 18103
Oiscount: Faliph Oiscount - Faliph			aent.c	on	
Oiscoulla de la companya de la comp			dilpi		
	, X	o Disco			



ENGINE MOUNTING ASSY.

^	<u>PART NO.</u> 3564470394G1	PART NAME ENGINE, B&S 18HP VANGUARD	QTY. 1	<u>REMARKS</u>
2 3 4 5	492581 EM923023 513593 513594	NUT, NYLOC 5/16" WASHER, FLAT 3/8"90° FITTING ADAPTER PLUG	4 1 1	REPLACES P/N 505679
6 7	492368 2105162	SCREW, 5/16" NC X 2" GRD 5 SCREW, 5/16" NC X 1-3/4" GRD 5	1 3	GROUND CONNECTIONREPLACES P/N 492367
				10111
				261
			(or or
			10	
		Ment. C	20.	
		Hill		
	aisco!			
	Oisco!			
~,O	Ojiscoj			
30 X	o oiscol			
-,O	Ojiscoj			



ENGINE SERVICE PARTS

NO. 1 2 3 4 5 6 7 9 10	PART NO. 394018S 272490S 692318 691959 845125 496018S 66574 808167 842921	PART NAME AIR FILTER PRE-CLEANER IGNITION SWITCH, W/KEY IGNITION KEY SET IN-LINE FUEL FILTER SPARK PLUG, CHAMPION ROPE, STARTER GRIP, STARTER OIL FILTER	QTY. 1 1 2 1 2 1 1 1	REMARKS
		Coliloment	COULTO	
		Junit: Folilomel.		
COX				
	WBH-1	6EAWD POWER BUGGY • PARTS MA	NUAL — REV. #5 (0	1/25/22) — PAGE 41

PARTS FINDERS Search Website Can't Find







Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: http://www.discount-equipment.com/category/5443-parts/ and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep,Small Line, Wanco, Yanmar