

AIRMAN

PC

PARTS CATALOG

SCREW COMPRESSOR

PDS185L-5E1

**Discount
Equipment**

www.discount-equipment.com

HOKUETSU INDUSTRIES CO., LTD.

PARTS FINDER

**Search Website
by Part Number**



**Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote**

Search Manuals

Enter part number or description to find parts manual or lookup part numbers.

* Part #

* Model

Serial

Part Number

Submit

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form

Please fill in the following information to request help.

Manufacturer

Model

Description

Part Number

Quantity

Price

Comments

Submit

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar


適用型式
FOR MODEL

型 式 MODEL	適用号機 SER. NO.
PDS185L-5E1	B4-7E10051~

原動機型式 ENGINE MODEL	YANMAR 4TNV88C-DHKS1
-----------------------	----------------------

STANDARD PAINTING

標準塗装色



NOTICE

1. This parts catalog contains all the parts and assemblies of "AIRMAN" brand products. The complete unit is divided into several parts groups, the details of which are clearly illustrated, and completely listed. So desired part number, name and quantity can be easily determined referring to Ref.No.
2. When you place order for service parts, please be sure to advise us of the following information.
 - (1) Part number.
 - (2) Quantity required.
 - (3) Part name.
 - (4) Model name and Serial number.
3. How to read parts catalog.

				(8) 備考		S:STD. SC:w. AFTER COOLER SD:DRY AIR	
52 - 00 LINING				(5)		(6)	(7)
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
見出番号	部 品 番 号	互換性 Inter- change ability	部 品 名 称	数量	適用号機範囲 Applicable Ser. No.	変更	備 考
Ref.NO.	Part NO.		Part Name	Q'ty		C/H	Remarks
	52900 04921		URETHANE FOAM KIT				S SC SD
	52900 05121		URETHANE FOAM KIT				◎
			(Const. No. 1~21)				◎
	52900 06121		URETHANE FOAM KIT				◎
			(Const. No. 1~9 & 11~24)				
1	52959 71350	Lining	ライニング	1			
2	52959 97640	Lining	ライニング	1			
3	52959 80220	Lining	ライニング	1			
4	52959 71450	Lining	ライニング	1			
5	52959 71550	Lining	ライニング	1			
6	52959 30940	Lining	ライニング	1			
7	52959 71650	Lining	ライニング	2			

(1) Ref.No.

Reference number (Ref.No.) is to be used for locating the part number and name from the illustrations. (However some parts such as bolts and nuts etc., are not illustrated but their reference numbers only listed.)

Ref.No.1, 1-1, 1-2,..... shows history of part modifications.

[These reference numbers mean 1: primary period, 1-1: first alteration, 1-2: second alteration and 1-3.....follows]

(2) Part No.

Every part has its own proper number. Even if a part has the same shape as an other part and if its number different, it is not interchangeable at all in many cases.

(3) Interchangeability

A, B, C, D, E, Q, X, Y and Z in column "Interchangeability" show the following.

A: A new part can replace an old part, but an old part cannot replace a new part.

B: Not interchangeable.

C: Disused.

D: Newly added.

E: Compatible with eachother.

Q: Quantity per unit changed.

X: Included in this set of parts, this part is not used for this model.

Y: Part to be selected.

Z: This part can not be supplied as an individual part.

(4) Part name

Every part has its own proper name.

(5) Q'ty

The number shown in the column of Q'TY indicates the quantity of parts used per one unit machine.

(6) Applicable Ser.No. (Serial Number)

Ser.No. shows the machine number to which the part is applicable.

Month and year stated in column "Ser.No." show the month and year from which the part is applicable.

(7) Change column

M1, M2, Mn mentioned in the column indicate the change of part number and the serial number of the unit, the part of which was modified.

(8) Remarks

This column "Remarks" mentions in mark or signal the specifications of each part, original part number of manufacturer, model name of the part for which is used and etc.

[Example. SC:w. AFTER COOLER]

4. Abbreviations used in this catalog.

ass'y	assembly	L	Length
C/H	Change column	o & p	overrun & parking brake
Comp.	Compressor	OPT.	Option
Const.	Consisting of	Press.	Pressure
Cont.	Control	SPC/S.	Special specifications
Cyl.	Cylinder	STD.	Standards
Eng.	Engine	T or t	Thickness
EXP.	Export	w.	with
Incl.	Including	w/o	without

NOTE : We are always engaged in improving our products. So there may be some changes of the product which are not yet mentioned in this parts catalog. Therefore, in necessary case, we issue a revision in which such changes are added. When you have any question on the parts catalog, please ask your nearest dealer or directly us.

目 次 CONTENTS

図 番 号 FIG. NO.	図 名 称 FIG. NAME	頁 PAGE
—COMPRESSOR PARTS—		
21 - 00	AIR END	エア エンド 21 - 1
31 - 00	MOUNTING & INTAKE	マウンティング, インテーク 31 - 1
33 - 00	RECEIVER, SEPARATOR & SERVICE HEADER	レシーバ, セパレータ, サービス ヘッダ 33 - 1
36 - 00	AIR LINE	エア ライン 36 - 1
37 - 00	OIL LINE	オイル ライン 37 - 1
38 - 00	COOLING	クーリング 38 - 1
39 - 00	NAME PLATE	ネーム プレート 39 - 1
41 - 00	ENGINE & EXHAUST	エンジン, エキゾースト 41 - 1
43 - 00	FUEL LINE	フュエル ライン 43 - 1
44 - 00	ELECTRIC	エレクトリック 44 - 1
51 - 00	FRAME & BONNET	フレーム, ボンネット 51 - 1
52 - 00	LINING	ライニング 52 - 1
—ENGINE PARTS—		
Fig. 1.	CYLINDER BLOCK	シリンダ ブロック Fig. 1.
Fig. 2.	GEAR HOUSING	ギヤ ケース Fig. 2.
Fig. 3.	FLYWHEEL HOUSING & OIL SUMP	フライホイールハウジング, オイルパン Fig. 3.
Fig. 4.	CYLINDER HEAD & BONNET	シリンダ ヘッド, ボンネット Fig. 4.
Fig. 5.	SUCTION MANIFOLD	吸気 マニホールド Fig. 5.
Fig. 6.	EXHAUST MANIFOLD	排気 マニホールド Fig. 6.
Fig. 7.	DIESEL PARTICULATE FILTER (DPF)	排気微粒子除去装置 (DPF) Fig. 7.
Fig. 8.	CAMSHAFT & DRIVING GEAR	カムシャフト, 駆動ギヤ Fig. 8.
Fig. 9.	CRANKSHAFT & PISTON	クランクシャフト, ピストン Fig. 9.
Fig. 10.	LUB. OIL SYSTEM	潤滑油 システム Fig. 10.
Fig. 11.	COOLING WATER SYSTEM	冷却水 システム Fig. 11.
Fig. 12.	FUEL SUPPLY PUMP	燃料 サプライ ポンプ Fig. 12.
Fig. 13.	FUEL INJECTION VALVE	燃料噴射弁 Fig. 13.
Fig. 14.	FUEL PIPE	燃料パイプ Fig. 14.
Fig. 15.	STARTING MOTOR	スタータ モータ Fig. 15.
Fig. 16.	GENERATOR	ゼネレータ Fig. 16.
Fig. 17.	ELECTRONIC CONTROL UNIT (ECU)	電子制御ユニット (ECU) Fig. 17.
Fig. 18.	ELECTRIC PARTS	電装品 Fig. 18.
Fig. 19.	ACCESSORY	付属品 Fig. 19.
Fig. 20.	GASKET SET	パッキン セット Fig. 20.

型 式 名 の 見 方 HOW TO READ MODELS

P D S 185 L - 5 E 1
① ② ③ ④ ⑤ ⑥ ⑦

- ① PD : PORTABLE DIESEL ENGINE
- ② S : SCREW(OIL-INJECTION)
- ③ 185 : Free air delivery(cfm)
- ④ L : LEAK GUARD TYPE
- ⑤ 5 : BOX
- ⑥ MODEL CHANGE MARK
- ⑦ VARIATION MARK

- ① PD : 可搬式、ディーゼルエンジン
- ② S : スクリュー(オイルインジェクション)
- ③ 185 : 吐出空気量(cfm)
- ④ L : リークガード型
- ⑤ 5 : ボックス
- ⑥ モデルチェンジ記号
- ⑦ バリエーション記号

Go to Discount-Equipment.com to order your parts

21 - 00 AIR END

見出番号	部 品 番 号	互換性 Inter- change- ability	部 品 名 称	数量	適用号機範囲 Applicable Ser. No.	変更	備 考
Ref. NO.	Part NO.		Part Name	Q'ty	5E1	-	Remarks
	21000 33711		COMPRESSION GROUP	コンプレッション グループ			
1	21201 44701		Cylinder, 1st	シリンダ	1		
2	21212 19300		Cover, oil seal	オイル シール カバー	1		
3	22123 03600		Orifice	オリフィス	1		
4	21211 13001		Oil seal	オイル シール	1		
5	21465 06600		Collar	カラー	1		
6	03402 15080		O-ring	O-リング	1		
7	21217 34501		Casing, discharge	デイスチャージ ケーシング	1		
8	03316 14028		Pin	ピン	2		
9	21221 04100		O-ring	O-リング	1		
10	03620 60001		Plug	プラグ	5		
11	03620 60002		Plug	プラグ	1		
12	03620 60003		Plug	プラグ	1		
13	21218 35601		End cover	エンド カバー	1		
14	03402 15095		O-ring	O-リング	1		
15	02280 10040		Socket bolt	ソケット ボルト	2		
16	02280 10030		Socket bolt	ソケット ボルト	9		
17	03115 40010		Spring washer	スプリング ワッシャ	3		
18	21218 35700		End cover	エンド カバー	1		
19	22314 02101		O-ring	O-リング	1		
20	21461 35500		Rotor, male	オス ロータ	1		
21	21462 27600		Rotor, female	メス ロータ	1		
	A pair of rotor (male & female) should be ordered. / ロータは、オス・メス一対でご注文下さい						
22	21406 42400		Bearing, rotor	ロータ ベアリング	1		
23	21470 14000		Bearing, complete	ベアリング コンプリート	1		
24	21468 06501		Plate	プレート	1		
25	02280 08025		Socket bolt	ソケット ボルト	3		
26	02280 08030		Socket bolt	ソケット ボルト	5		
27	03115 40008		Spring washer	スプリング ワッシャ	6		
28	03115 30008		Lock washer	ロック ワッシャ	2		
29	21406 42300		Bearing, rotor	ロータ ベアリング	1		
30	21470 14300		Bearing, complete	ベアリング コンプリート	1		
31	21468 02700		Plate	プレート	1		
32	02280 10030		Socket bolt	ソケット ボルト	1		
33	03115 30010		Lock washer	ロック ワッシャ	1		
	22 - 00		VALVE GROUP	バルブ グループ			
71	22100 41205		Unloader ass'y	アンローダ	1 ~0156		
	(Const. No. 72~98)						
71 -1	22100 54000	A	Unloader ass'y	アンローダ	1 0157~	M648	
	(Const. No. 72~98, See page 36-1 No. 15, 22, 23 & See page 37-1 No. 31)						
72	22111 28201		Body, unloader	アンローダ ボディ	1		
73	22115 12703		Cover, unloader	アンローダ カバー	1		
74	03402 10125		O-ring	O-リング	1		
75	03620 60002		Plug	プラグ	2		
76	03890 20020		Nylon tube	ナイロンチューブ	2		
77	22115 11300		Cover, unloader	アンローダ カバー	1		
78	02282 08025		Socket bolt	ソケット ボルト	3		
79	03402 10070		O-ring	O-リング	1		
80	22150 13801		Valve	バルブ	1		

21 - 00 AIR END

見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name	数量 Q'ty	適用号機範囲 Applicable Ser. No.		変更 C/H	備 考 Remarks
					5E1	-		


81	22130 09500		Piston, unloader	アンローダ ピストン	1			
82	21441 04800		O-ring	O-リング	1			
83	21441 04900		O-ring	O-リング	1			
84	22144 16700		Spring	スプリング	1			
85	22144 16600		Spring	スプリング	1			
86	23124 15600		Bushing	ブッシング	1			
87	22144 10600		Spring	スプリング	2			
88	36429 01600		Needle valve	ニードルバルブ	2			
89	36428 01100		Valve seat	バルブシート	2			
90	03402 25008		O-ring	O-リング	2			
91	36623 00900		Piston, auto-relief	ピストン	2			
92	03402 25021		O-ring	O-リング	2			
93	36621 01900		Cover, auto-relief	カバー	2			
94	02270 04012		Socket bolt, w/w	ワッシャ付ソケットボルト	8			
95	21221 02100		O-ring	O-リング	2			
96	36349 22800		Pipe	パイプ	1			
97	03734 53021		Nipple elbow	ニッフルエルボ	2			
98	03734 65020		Nipple elbow	ニッフルエルボ	4			
99	03402 10125		O-ring	O-リング	1			
100	02280 10075		Socket bolt	ソケットボルト	4			
101	03115 30010		Lock washer	ロックワッシャ	4			

61 - 00

COUPLING GROUP


カップリンググループ

131	21425 04801		Coupling, complete	カップリング, コンプリート	1			
132	03306 14036		Key	キー	1			
133	21468 04400		Plate	プレート	1			
134	02282 10030		Socket bolt	ソケットボルト	1			
135	03115 30010		Lock washer	ロックワッシャ	1			
136	02283 08020		Socket bolt	ソケットボルト	8			
137	03115 42008		Spring washer	スプリングワッシャ	8			
138	02238 10030		Bolt, w/w	ワッシャ付ボルト	8			
139	03316 08014		Pin	ピン	2			



31 - 00 MOUNTING & INTAKE

見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name	数量 Q'ty	適用号機範囲 Applicable Ser. No.	変更 C/H	備 考 Remarks
	31 - 00		MOUNTING GROUP	マウンティング グループ			
1	31110 05710		Bracket	ブ ラケット	1		
2	31110 25510		Bracket	ブ ラケット	1		
3	02135 10020		Bolt	ボ ルト	8		
4	03115 02010		Spring washer	ス プリング ワッシャ	8		
5	31130 28100		Vibration isolator ass'y	防振ゴ ム	2		
6	02915 20010		Nut, w/w	ワッシャ付ナット	4		
7	31130 20500		Vibration isolator ass'y	防振ゴ ム	2		
8	02915 20012		Nut, w/w	ワッシャ付ナット	2		
9	31110 15110		Bracket	ブ ラケット	1		
10	02201 08020		Flange bolt	フランジ 付ボ ルト	4		
11	31120 08900		Shim	シム	2		
	32 - 00		INTAKE GROUP	インテーク グループ			
31	32100 44900		Air filter ass'y	エア フィルタ	2		Const. No. 32~35
32	32143 11800		Element	エレメント	2		
33	32142 11300		Cup	カップ	2		
34	32147 03600		O-ring	O-リング	2		
35	32151 01600		Vacuator valve	バ キュエータ バ ルブ	2		
36	32148 03000		Filter service indicator	インジ ケータ	2		
37	02201 08012		Flange bolt	フランジ 付ボ ルト	4		
38	32240 51900		Bracket	ブ ラケット	2		
39	02915 00008		Hexagon flange nuts	フランジ 付ナット	8		
40	32331 99000		Hose	ホース	1		
41	03511 20090		Hose clip	ホース クリップ	2		
42	32331 98901		Hose	ホース	1		
43	03511 20100		Hose clip	ホース クリップ	2		



33 - 00 RECEIVER, SEPARATOR & SERVICE HEADER

見出番号	部 品 番 号	互換性 Inter- change ability	部 品 名 称	数量	適用号機範囲 Applicable Ser. No.	変更	備 考
Ref. NO.	Part NO.		Part Name	Q'ty	5E1	-	Remarks

33 - 00 RECEIVER GROUP レシーバ グループ

1	33100 00721		Oil separator	オイル セパレータ	1 ~0195		ASME
1 -1	33100 03420	B	Oil separator	オイル セパレータ	1 -	M632	ASME
1 -2	33100 06820	B	Oil separator	オイル セパレータ	1 0196~	M701	ASME
(Receiver tank) (Incl. No. 2)							
2	33231 04000		Cap	キャップ	1		ASME
3	03402 25030		O-ring	O-リング	1		
4	03841 30018		Nylon tube, w/n	ナット付ナイロンチューブ	1		
5	03734 21030		Nipple elbow	ニップル エルボ	2		
6	33260 10400		Bracket	ブラケット	1		
7	02201 08012		Flange bolt	フランジ 付ボルト	4		
8	39701 04600		Plate	プレート	2		
9	02201 08020		Flange bolt	フランジ 付ボルト	8		
10	35200 23800		Safety valve ass'y	安全弁	1 ~0130		(145PSI)
10 -1	35200 23900	B	Safety valve ass'y	安全弁	1 0131~	M 8	(150PSI)
11	37740 01400		Elbow	エルボ	1		
12	37160 90121		Pipe	パイプ	1		
13	03734 85140		Nipple	ニップル	1		Incl. No. 14
14	03402 25044		O-ring	O-リング	1		
15	38466 09800		Pipe	パイプ	1 ~0143		
15 -1	37110 01900	B	Hose	ホース	1 ~0156	M11	
15 -2	37110 07900	B	Hose	ホース	1 0157~	M13	
16	03734 53040		Nipple elbow	ニップル エルボ	1 ~0143		
16 -1	03734 43040	B	Nipple	ニップル	1 0144~	M11	
17	03734 52040	C	Nipple elbow	ニップル エルボ	1 0144~	M11	
18	03735 13004		Valve	バルブ	1		
19	33238 03000		Plug	プラグ	1		
20	37170 29600	D	Joint	ジョイント	1 0144~0156	M11	
20 -1	37170 31000	B	Joint	ジョイント	1 0157~	M13	
21	52728 61710	D	Cushion rubber	クッション ラバー	1 0144~	M11	
22	02136 06025	D	Bolt	ボルト	2 0144~	M11	
23	03116 15006	D	Plain washer	プレーン ワッシャ	2 0144~	M11	
24	52744 01100	D	Washer	ワッシャ	2 0144~	M11	
25	03425 00005	D	Vinyl clip	ビニール クリップ	2 0144~	M11	
26	03734 45004	D	Nipple elbow	ニップルエルボ	1 0157~	M13	

34 - 00 SEPARATOR GROUP セパレータ グループ




51	34210 33800		Casing, separator	セパレータ ケーシング	1		
52	03620 60001		Plug	プラグ	2		
53	03620 60003		Plug	プラグ	1		
54	33238 01800		Plug	プラグ	1		Incl. No. 55
55	03402 25011		O-ring	O-リング	1		
56	03402 25145		O-ring	O-リング	1		
57	02283 10030		Socket bolt	ソケット ボルト	4		
58	34224 03000		Element	エレメント	1		
59	03729 12140		Gas pipe	ガス パイプ	1		
60	34250 30503		Cover, separator	セパレータ カバー	1		
61	03402 15145		O-ring	O-リング	1		
62	02283 10035		Socket bolt	ソケット ボルト	4		
63	03115 31010		Lock washer	ロック ワッシャ	8		

33 - 00 RECEIVER, SEPARATOR & SERVICE HEADER

見出番号	部 品 番 号	互換性 Inter- change ability	部 品 名 称	数量	適用号機範囲 Applicable Ser. No.		変更	備 考
					5E1	-		
Ref. NO.	Part NO.		Part Name	Q'ty	5E1	-	C/H	Remarks


35 - 00 SERVICE HEADER GROUP サービス ヘッダ グループ

101	35100 60501		Air manifold	エア マニホルド	1			
102	52728 57410		Cushion rubber	クッション ラバー	2			
103	35410 07000		Bracket	ブラケット	1 ~0091			
103 -1	35410 07100	B	Bracket	ブラケット	1 0092~		M 4	
104	02246 08025		Bolt, w/w	ワッシャ付ボルト	4			
105	37110 03400		Hose	ホース	1 ~0091			
105 -1	37110 18000	B	Hose	ホース	1 0092~		M 4	
106	03734 85120		Nipple elbow	ニップル エルボ	1			
107	03734 44012		Nipple elbow	ニップル エルボ	1			
108	35301 20200		Body	ボディ	1			
109	03402 15075		O-ring	Oリング	1			
110	03402 25032		O-ring	Oリング	1			
111	22144 07700		Spring	スプリング	1			
112	35303 08400		Piston	ピストン	1			
113	35303 03300		Piston	ピストン	1			
114	35301 22200		Body	ボディ	1			
115	03620 60002		Plug	プラグ	3			
116	03620 60001		Plug	プラグ	1			
117	02283 10090		Socket bolt	ソケット ボルト	2			
118	02283 10030		Socket bolt	ソケット ボルト	2			
119	03115 31010		Lock washer	ロック ワッシャ	4			
120	03402 15050		O-ring	Oリング	1			
121	35421 00105		Air valve	エア バルブ	2			
122	35470 54200		Bracket	ブラケット	2			
123	02246 06016		Bolt, w/w	ワッシャ付ボルト	4			




36 - 00 AIR LINE

見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name		数量	適用号機範囲 Applicable Ser. No.		変更 C/H	備 考 Remarks
					Q'ty	5E1	-		
36 - 00 CONTROL GROUP コントロール グループ									
1	36141 18600		Gauge, air press.	圧力計	1	(PSI)			
2	36131 03100		Cushion rubber	クッション ラバー	1				
3	03840 15105		Nylon tube, w/n	ナット付ナイロンチューブ	1	~0156			
3 -1	03840 15080	B	Nylon tube, w/n	ナット付ナイロンチューブ	1	0157~		M14	
4	06540 07095		Corrugated tube	コルゲート チューブ	1	~0156			
4 -1	06540 07070	B	Corrugated tube	コルゲート チューブ	1	0157~		M14	
5	03734 21151		Nipple elbow	ニップル エルボ	1				
6	03734 20015		Nipple	ニップル	1				
7	36400 19000		Regulator ass'y	レギュレータ	1				
8	37189 38500		Bushing	ブッシング	1				
9	86183 01500		Joint	ジョイント	1				
10	03734 44002		Nipple elbow	ニップル エルボ	1				
11	37189 33500		Bushing	ブッシング	1				
12	37189 08100		Bushing	ブッシング	1				
13	03732 00602		Bush	ブッシュ	1				
14	03731 44002		Nipple	ニップル	1				
15	37189 39400		Bushing	ブッシング	1				
16	03840 20030		Nylon tube, w/n	ナット付ナイロンチューブ	1				
17	03840 20044		Nylon tube, w/n	ナット付ナイロンチューブ	1				
18	03840 20021		Nylon tube, w/n	ナット付ナイロンチューブ	1				
19	03840 20029		Nylon tube, w/n	ナット付ナイロンチューブ	1				
20	03734 20020		Nipple	ニップル	2				
21	03734 21020		Nipple elbow	ニップル エルボ	1				
22	03734 20020		Nipple	ニップル	3				
23	03734 21020		Nipple elbow	ニップル エルボ	2				
















37 - 00 OIL LINE

見出番号	部 品 番 号	互換性 Inter- change ability	部 品 名 称	数量	適用号機範囲 Applicable Ser. No.	変更	備 考
Ref. NO.	Part NO.		Part Name	Q'ty	5E1	-	Remarks
	37 - 00		OIL LINE GROUP				オイル ライン グループ
1	37200 11502		By-pass valve ass'y	1			Incl. Pellet &
	37231 02100		Pellet ass'y	1			0-ring
	03402 25045		O-ring	1			
2	03402 15025		O-ring	1			
3	03402 15045		O-ring	1			
4	02136 08035		Bolt	2			
5	02136 08090		Bolt	2			
6	03115 06008		Spring washer	4			
7	03116 15008		Plain washer	4			
8	37111 29900		Pipe	1			
9	37145 04700		Pipe	1			
10	37110 17400		Hose	1	~0156		
10 -1	37110 18900	A	Hose	1	0157~	M12	
11	03734 76060		Nipple	2			Incl. No. 16
12	03734 75060		Nipple	1			Incl. No. 16
13	37731 11300		Nipple	1			
14	03734 85060		Nipple	1			Incl. No. 16
15	37731 06400		Nipple	1			Incl. No. 16
16	03402 25024		O-ring	6			
17	03830 06007		U-bolt	1			
18	02915 20006		Nut, w/w	2			
19	03116 12006		Plain washer	2			
20	37411 07501		Body	1	~0130		
20 -1	37411 08100	B	Body	1	0131~	M579	
21	37438 08900		Filter cartridge	1			
22	37510 38700		Bracket	1			
23	02201 08012		Flange bolt	1			
24	02201 10020		Flange bolt	1			
25	03847 20048		Nylon tube, w/n	1			
26	06540 07038		Corrugated tube	1			
27	37189 36600		Bushing	1			
28	03402 25011		O-ring	1			
29	37580 01900		Strainer	1			
30	03734 21020		Nipple elbow	1			
31	03734 20020		Nipple	1			
32	33238 03700	D	Plug	1	0131~	M579	Incl. No. 33
33	03402 25008	D	O-ring	1	0131~	M579	



38 - 00 COOLING

見出番号	部 品 番 号	互換性 Inter- change ability	部 品 名 称	数量	適用号機範囲 Applicable Ser. No.	変更	備 考
Ref. NO.	Part NO.		Part Name	Q'ty	5E1	-	Remarks
	38 - 00		COOLING GROUP	クーリング グループ			
1	38100 47900		Radiator	ラジエータ	1		(90kPa)
2	38420 10311		Bracket	ブラケット	1		
3	38200 49800		Oil cooler	オイルクーラ	1		
4	52728 63110		Cushion rubber	クッション ラバー	2	~0053	
4 -1	52728 63111	A	Cushion rubber	クッション ラバー	1	0054~	M 2
5	38420 09711		Bracket	ブラケット	1		
6	03407 64632		Seal rubber	シール ラバー	2		
7	02915 00008		Hexagon flange nuts	フランジ 付ナット	4		
8	38524 80101		Hose	ホース	1		(upper)
9	38524 80001		Hose	ホース	1		(lower)
10	03511 20040		Hose clip	ホース クリップ	1		
11	03511 20045		Hose clip	ホース クリップ	3		
12	03424 80069		Clip	クリップ	2		
13	38440 24010		Shroud, fan	ファン シュラウド	1		
14	38440 24110		Shroud, fan	ファン シュラウド	1		
15	02915 00006		Hexagon flange nuts	フランジ 付ナット	16		
16	38441 41110		Plate	プレート	2		
17	38450 07410		Guard, fan	ファン ガード	1		
18	38450 07510		Guard, fan	ファン ガード	1		
19	03570 08157		Hose	ホース	1		
20	03511 20016		Hose clip	ホース クリップ	2	~0156	
20 -1	03511 40021	A	Hose clip	ホース クリップ	2	0157~	M620
21	37170 12200		Joint	ジョイント	1		
22	37110 17300		Hose	ホース	1		
23	03734 43030		Nipple	ニップル	1		
24	37170 29500		Joint	ジョイント	1		
25	52728 61810		Cushion rubber	クッション ラバー	1		
26	02136 06025		Bolt	ボルト	5		
27	03116 15006		Plain washer	プレーン ワッシャ	5		
28	52744 01100		Washer	ワッシャ	5		
29	35421 06900		Air valve	エア バルブ	1		
30	33238 02700		Plug	プラグ	1		
31	35421 06800		Air valve	エア バルブ	1		
32	33238 02800		Plug	プラグ	1		
33	38590 01400		Reserve tank ass'y	リザーブ タンク	1		
34	38591 00400		Bracket	ブラケット	1		
35	02201 06016		Flange bolt	フランジ 付ボルト	25		
36	38594 02400		Hose	ホース	1		
37	03511 40016		Hose clip	ホース クリップ	2		
38	52350 52030		Cover	カバー	1		
39	02201 08020		Flange bolt	フランジ 付ボルト	6		
40	03403 00512		Grommet	グロメット	2		
41	03403 00703		Grommet	グロメット	1		
42	52728 62910		Cushion rubber	クッション ラバー	1		
43	52728 63010		Cushion rubber	クッション ラバー	1		
44	03407 66811		Seal rubber	シール ラバー	1		
45	03407 66861		Seal rubber	シール ラバー	1		
46	03407 66871		Seal rubber	シール ラバー	2		
47	03407 67415		Seal rubber	シール ラバー	2		
48	03407 67401		Seal rubber	シール ラバー	2		
49	03425 00001		Clip	クリップ	10		




39 - 00 NAME PLATE

見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name	数量 Q'ty	適用号機範囲 Applicable Ser. No.		変更 C/H	備 考 Remarks
					5E1	-		
	39 - 00		ACCESSORY GROUP	アクセサリ グループ				
	39600 51641		Instruction manual	取扱説明書	~0156			
	39600 57150	B	Instruction manual	取扱説明書	0157~		M14	
1	39170 02000		Mark (AIRMAN)	マーク	1			
2	39103 10811		Plate (SER. NO.)	プレート	1			
3	03260 03010		Blind rivet	リベット	4			
4	39178 23930		Plate (AIRMAN)	プレート	2			
5	39178 06840		Plate (AIRMAN)	プレート	1			
6	39178 02950		Plate (PDS185LS)	プレート	2			
7	39178 04150		Plate (PDS185LS T4)	プレート	2			
8	39178 05250		Plate (LEAK GUARD)	プレート	1			
9	39178 93240		Plate (mark)	プレート	2			
10	39178 67840		Plate (california)	プレート	1			
11	39178 03050		Plate (in-pane)	プレート	1	~0156		
11 -1	39178 67851	B	Plate (in-pane)	プレート	1	0157~	M14	
12	39153 70500		Plate (start-stop)	プレート	1	~0156		
12 -1	39153 78900	B	Plate (start-stop)	プレート	1	0157~	M14	
13	39178 00310		Plate (LLC)	プレート	1			
14	39176 69300		Plate (lift position)	プレート	1			
15	39176 50000		Plate (danger, battery)	プレート	1			
16	39176 07510		Plate (strainer)	プレート	1			
17	39179 01700		Plate (genuine oil)	プレート	1			
18	39178 22031		Plate (FLAMMABLES)	プレート	1			
19	39173 04200		Plate, complete	プレート(1セット)	1			Const. No. 20~28
20	* * *	Z	Plate	プレート	1			(39173 04200)
			(caution, high temp.)					
21	* * *	Z	Plate	プレート	1			(39173 04200)
			(caution, radiator cap)					
22	* * *	Z	Plate (caution, fire)	プレート	1			(39173 04200)
23	* * *	Z	Plate	プレート	1			(39173 04200)
			(warning, compressed air)					
24	* * *	Z	Plate	プレート	1			(39173 04200)
			(warning, exhaust gases)					
25	* * *	Z	Plate	プレート	1			(39173 04200)
			(warning, compressed air)					
26	* * *	Z	Plate	プレート	1			(39173 04200)
			(danger, compressed air)					
27	* * *	Z	Plate	プレート	1			(39173 04200)
			(warning, cooling fan)					
28	* * *	Z	Plate (warning, V-belt)	プレート	1			(39173 04200)
29	39173 03300		Plate, complete	プレート(1セット)	1			Const. No. 30~33
30	* * *	Z	Plate (fuel drain)	プレート	1			(39173 03300)
31	* * *	Z	Plate (radiator drain)	プレート	1			(39173 03300)
32	* * *	Z	Plate (eng. oil drain)	プレート	1			(39173 03300)
33	* * *	Z	Plate (oil fence drain)	プレート	1			(39173 03300)
34	39173 03400		Plate, complete	プレート(1セット)	1			Const. No. 35~36
35	* * *	Z	Plate (oil cooler drain)	プレート	1			(39173 03400)
36	* * *	Z	Plate (receiver tank drain)	プレート	1			(39173 03400)
37	39176 92600		Plate, complete	プレート(1セット)	1			Const. No. 38
38	* * *	Z	Plate (refueling drain)	プレート	1			(39173 92600)

39 - 00 NAME PLATE

見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name	数量 Q' ty	適用号機範囲 Applicable Ser. No.		変更 C/H	備 考 Remarks
					5E1	-		
39	39178 47611		Plate (EMERGENCY STOP) プレート	1				
40	39178 20450		Plate (oil level gauge) プレート	1				
41	39178 59540		Plate (OPEN-CLOSE) プレート	1				
42	39178 59640		Plate (OPEN-CLOSE) プレート	1				
43	39178 38151	D	Plate (QR CODE) プレート	1	0157~		M625	
44	39178 62751	D	Plate (air pressure) プレート	1	0157~		M14	




41 - 00 ENGINE & EXHAUST

見出番号	部 品 番 号	互換性 Inter- change ability	部 品 名 称	数量	適用号機範囲 Applicable Ser. No.	変更	備 考
Ref. NO.	Part NO.		Part Name	Q'ty	5E1	-	Remarks
	41 - 00		ENGINE GROUP	エンジン グループ			
1	37411 07300		Body	ボデー	1		
2	02201 08012		Flange bolt	フランジ 付ボルト	2		
3	41290 01200		Filter ass'y	エンジンオイルフィルター	1		See Engine parts Fig. 10.
4	43534 01702		Ring connector	リング コネクタ	1		(Nipple)
5	43532 05201		Nipple	ニップル	1 ~0156		(Bolt)
5 -1	43532 10200	A	Nipple	ニップル	1 0157~	M626	
6	03407 16022		Gasket	ガスケット	1		
7	41330 00700		Gasket	ガスケット	1		
8	03580 19090		Hose	ホース	1		
9	03511 20035		Hose clip	ホース クリップ	2		
10	37181 07100		Clip	クリップ	2		
11	02201 06016		Flange bolt	フランジ 付ボルト	2		
	02915 00006	D	Hexagon flange nuts	フランジ 付ナット	2 0131~	M10	
12	37170 02900		Joint	ジョイント	1		
13	86183 01900		Joint	ジョイント	2		
14	37160 87220		Pipe	パイプ	1		
15	33200 05200		Gauge ass'y	エンジンオイルレベルゲージ	1		
16	41250 06800		Bracket	ブラケット	1		
17	03830 06007		U-bolt	U-ボルト	1		
18	02915 20006		Nut, w/w	ワッシャ付ナット	2		
19	37170 29600		Joint	ジョイント	1		
20	52728 61710		Cushion rubber	クッション ラバー	1		
21	02136 06025		Bolt	ボルト	2		
22	03116 15006		Plain washer	プレーン ワッシャ	2		
23	52744 01100		Washer	ワッシャ	2		
24	03735 13004		Valve	バルブ	1		
25	33238 03000		Plug	プラグ	1		
26	37731 16100		Nipple	ニップル	1		
27	03402 25028		O-ring	O-リング	1		
28	37170 29700		Joint	ジョイント	2		
29	03570 08143		Hose	ホース	1		
30	03511 20016		Hose clip	ホース クリップ	2		
31	03734 43040		Nipple	ニップル	2		
32	37110 17500		Hose	ホース	1 ~0156		
32 -1	37110 19000	A	Hose	ホース	1 0157~	M12	
33	37110 17600		Hose	ホース	1 ~0156		
33 -1	37110 19100	A	Hose	ホース	1 0157~	M12	
34	37170 28600		Joint	ジョイント	1		
35	02201 06016		Flange bolt	フランジ 付ボルト	4		
36	37160 87020		Pipe	パイプ	1		
37	37160 87120		Pipe	パイプ	1		
38	03734 76040		Nipple elbow	ニップル エルボ	1		Incl. No. 40
39	03734 75040		Nipple	ニップル	1		Incl. No. 40
40	03402 25018		O-ring	O-リング	2		
41	41250 07100		Bracket	ブラケット	1		
42	02201 08020		Flange bolt	フランジ 付ボルト	2		
43	37160 89520		Pipe	パイプ	1		
44	03734 52022		Nipple	ニップル	2		


41 - 00 ENGINE & EXHAUST

見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name	数量 Q'ty	適用号機範囲 Applicable Ser. No.		変更 C/H	備 考 Remarks
					5E1	-		
45	33238 03500		Plug	プラグ	1			See Engine parts Fig. 19.
46	21221 06800		O-ring	O-リング	1			See Engine parts Fig. 19.
47	03425 00001		Vinyl clip	ビニール クリップ	5			
48	41330 01000	D	Gasket	ガスケット	1	0157~	M626	
42 - 00 EXHAUST GROUP エキゾースト グループ								
81	42180 00200		Exhaust filter	エキゾースト フィルタ	1			See Engine parts Fig. 7.
82	42310 04110		Pipe, exhaust	エキゾースト パイプ	1			
83	42324 16200		Gasket	ガスケット	1			See Engine parts Fig. 19.
84	02915 01010		Hexagon flange nuts	フランジ 付ナット	4			
85	42324 14900		Gasket	ガスケット	1			See Engine parts Fig. 7.
86	02135 08035		Bolt	ボルト	4			
87	42410 03600		Insulating cover	断熱カバー	1			
88	03511 30125		Hose clip	ホース クリップ	3			
89	42240 39700		Bracket	ブラケット	1			
90	03830 08009		U-bolt	U-ボルト	1			
91	02915 00008		Hexagon flange nuts	フランジ 付ナット	2			
92	42240 31700		Bracket	ブラケット	1			
93	42240 31800		Bracket	ブラケット	1			
94	02201 08020		Flange bolt	フランジ 付ボルト	8			
95	02136 08030		Bolt	ボルト	2			
96	03116 15008		Plain washer	プレーン ワッシャ	8			
97	03115 06008		Spring washer	スプリング ワッシャ	8			
98	02912 06008		Nut	ナット	10			
99	42310 16410		Pipe, exhaust	テール パイプ	1			
100	42230 20900		Belt	ベルト	1			See Engine parts Fig. 19.



43 - 00 FUEL LINE

見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name	数量 Q'ty	適用号機範囲 Applicable Ser. No.		変更 C/H	備 考 Remarks
					5E1	-		
	43 - 00		FUEL GROUP	フュエル グループ				
1	43100 02613		Fuel tank	フュエル タンク	1			
2	43220 03400		Cap	キャップ	1			Incl. Strainer
3	43310 42000		Belt	ベルト	2			
4	02201 42700		Belt	ベルト	2			
5	02246 08025		Bolt, w/w	ワッシャ付ボルト	2			
6	02915 00008		Hexagon flange nuts	フランジ 付ナット	4			
7	38465 23500		Cushion rubber	クッション ラバー	4			
8	38465 23400		Cushion rubber	クッション ラバー	4			
9	37170 12200		Joint	ジョイント	1			
10	03570 08044		Hose	ホース	1			
11	03511 20020		Hose clip	ホース クリップ	2			
12	37170 29400		Joint	ジョイント	1			
13	52728 61710		Cushion rubber	クッション ラバー	1			
14	02136 06025		Bolt	ボルト	2			
15	03116 15006		Plain washer	プレーン ワッシャ	2			
16	52744 01100		Washer	ワッシャ	2			
17	35421 06900		Air valve	エア バルブ	1			
18	33238 02700		Plug	プラグ	1			
19	43650 02700		Fuel pump	フュエル ポンプ	1			
20	02201 06016		Flange bolt	フランジ 付ボルト	2			
21	43540 08800		Fuel filter (pre)	フュエル フィルタ (プレ)	1			See Engine parts Fig. 19.
22	43456 01900		Bolt	ボルト	2			See Engine parts Fig. 19.
23	37181 07700		Clip	クリップ	1			
24	37181 04200		Clip	クリップ	5			
25	43540 09800		Fuel filter (main)	フュエル フィルタ (メイン)	1			See Engine parts Fig. 19.
26	43340 41600		Bracket	ブラケット	1			
27	02201 08020		Flange bolt	フランジ 付ボルト	6			
28	44290 68300		Guide	ガイド	1			
29	02248 08016		Bolt, w/w	ワッシャ付ボルト	2			
30	02248 08025		Bolt, w/w	ワッシャ付ボルト	1			
31	43526 09800		Hose	ホース	1			
32	43526 09700		Hose	ホース	1			
33	43526 09600		Hose	ホース	1			
34	43526 10100		Hose	ホース	1			
35	43526 10000		Hose	ホース	1			
36	43526 09900		Hose	ホース	1			
37	03511 40018		Hose clip	ホース クリップ	10			
38	43660 00500		Clip	クリップ	2			
39	03425 00001		Vinyl clip	ビニール クリップ	20			
40	02201 08030		Flange bolt	フランジ 付ボルト	2			




44 - 00 ELECTRIC

見出番号	部 品 番 号	互換性 Inter- change ability	部 品 名 称	数量	適用号機範囲 Applicable Ser. No.	変更	備 考
Ref. NO.	Part NO.		Part Name	Q'ty	5E1	-	Remarks
44 - 00 ELECTRIC GROUP エレクトリック グループ							
1	44210 06700	Y	Battery	ハッテリ	1		(95D31R)
1	44210 08500	Y	Battery	ハッテリ	1		(95D31R)
2	44100 12201		Battery box	ハッテリ ホックス	1		
3	44220 19800		Cover	カバー	1		
4	44243 02600		Holder	ホルダー	2		
5	02915 20006		Nut, w/w	ワッシャ付ナット	2		
6	03116 12006		Plain washer	プレーン ワッシャ	2		
7	44364 08200		Thermo sensor	サーモ センサ	2		(dis. air/water)
8	06540 07020		Corrugated tube	コルゲート チューブ	2		
9	36331 15500		Nipple	ニップル	1		
10	03407 20016		Gasket	ガスケット	1		
11	44250 87710		Bracket	ブラケット	1		
12	03407 64759		Seal rubber	シール ラバー	1		
13	03403 00362		Grommet	グロメット	1		
14	02915 00006		Hexagon flange nuts	フランジ 付ナット	3		
15	44250 88310		Bracket	ブラケット	1 ~0143		
15 -1	44250 01720	B	Bracket	ブラケット	1 0144~	M11	
16	44250 88010		Bracket	ブラケット	1		
17	03403 00703		Grommet	グロメット	1		
18	46870 64400		Controller	コントローラ	1		(YANMAR 1R1797-00101)
19	02138 06030		Bolt	ボルト	4		
	03115 02006		Spring washer	スプリング ワッシャ	4		
	03116 12006		Plain washer	プレーン ワッシャ	4		
20	44346 17100		Relay (EGR)	リレー (EGR)	1		(YANMAR 172802-17150)
21	44346 16600		Relay (starter)	リレー (スタータ)	1		(YANMAR 129927-77920)
22	44346 16600		Relay (glow)	リレー (グロー)	1		(YANMAR 129927-77920)
23	44250 41710		Bracket	ブラケット	2		
24	44250 32110		Bracket	ブラケット	1		
25	44470 01600		Fuse box	ヒューズ ホックス	1		
	46934 03200		Fuse	ヒューズ	1		(10A)
26	44470 01700		Fuse box	ヒューズ ホックス	1		
	46934 03300		Fuse	ヒューズ	1		(20A)
27	44470 03000		Fuse box	ヒューズ ホックス	1		(80A)
28	02345 66008		Screw	スクリュー	2		
	03115 02006		Spring washer	スプリング ワッシャ	2		
	03116 12006		Plain washer	プレーン ワッシャ	2		
29	44461 22600		Connector	コネクタ	1		
30	44470 02900		Fuse box	ヒューズ ホックス	1		(50A)
31	44250 87810		Bracket	ブラケット	1 ~0156		
31 -1	44250 11020	B	Bracket	ブラケット	1 0157~	M14	
32	02401 66020		Screw	スクリュー	4		
33	45214 01400		Washer	ワッシャ	4		
34	44322 07300		Starter switch	スタータ スイッチ	1 ~0156		
	52739 00600	C	Key	キー	1 0157~	M14	
34 -1	46167 07000	B	Select switch	電源スイッチ	1 0157~	M14	
	45214 03300	D	Washer	ワッシャ	1 0157~	M14	
35	46870 64003		Controller	コントローラ	1 ~0156		(emergency)
35 -1	46870 00711	B	Controller	コントローラ	1 0157~	M14	(emergency)
36	05085 21074		Cable	ケーブル	1		(battery~starter)
37	06540 10074		Corrugated tube	コルゲート チューブ	1		

44 - 00 ELECTRIC

見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name	数量 Q'ty	適用号機範囲 Applicable Ser. No.		変更 C/H	備 考 Remarks
					5E1	-		
38	05625 00018		Terminal	ターミナル	1			
39	44462 06700		Insulator	インシュレータ	1			(battery "+")
40	44462 00800		Insulator	インシュレータ	1			(starter)
41	07888 51050		Cable	ケーブル	1			(earth)
42	05068 23050		Cable	ケーブル	1			(earth)
43	02248 10020		Bolt, w/w	ワッシャ付ボルト	4			
44	36159 04500		Sending unit	センディング ユニット	1			Incl. No. 45
45	36153 01600		Gasket	ガスケット	1			
46	02415 65012		Screw, w/w	ワッシャ付スクリュー	5			
47	44336 03801		Botton switch (Incl. Cap)	非常停止ボタン	1			(emergency stop)
	44382 01301		Cap	キャップ	1			
48	44328 20600		Pressure switch	圧力スイッチ	3			
49	44490 27051		Wiring harness	ワイヤハーネス	1	~0156		
49 -1	44490 77950	B	Wiring harness	ワイヤハーネス	1	0157~	M14	
50	44290 70700		Guide	ガイド	1			
51	02201 06016		Flange bolt	フランジ付ボルト	8			
52	44290 68600		Guide	ガイド	1			
53	02248 08016		Bolt, w/w	ワッシャ付ボルト	1			
54	44290 70600		Guide	ガイド	1			
55	02201 08020		Flange bolt	フランジ付ボルト	8			
56	02915 00008		Hexagon flange nuts	フランジ付ナット	3			
57	02248 06016		Bolt, w/w	ワッシャ付ボルト	5			
58	46811 30000		Solenoid valve	電磁弁	1			
59	06540 07025		Corrugated tube	コルゲートチューブ	1			
60	37181 07700		Clip	クリップ	14			
60 -1	37181 07700	Q	Clip	クリップ	10			
61	37181 04200		Clip	クリップ	2			
62	03425 00005		Vinyl clip	ビニール クリップ	10			
63	03425 00003		Vinyl clip	ビニール クリップ	2			
64	03425 00001		Vinyl clip	ビニール クリップ	22			
65	46242 23400	D	Push button switch	始動ボタン	1	0157~	M14	
66	46921 02300	D	Silicon rectifier	整流器	1	0157~	M14	



51 - 00 FRAME & BONNET

見出番号	部 品 番 号	互換性 Inter- change ability	部 品 名 称	数量	適用号機範囲 Applicable Ser. No.	変更	備 考
Ref. NO.	Part NO.		Part Name	Q'ty	5E1	-	Remarks
51 - 00 FRAME GROUP フレーム グループ							
1	51100 10450		Frame	フレーム	1 ~0078		
1 -1	51100 10850	B	Frame	フレーム	1 ~0091	M 2	
1 -2	51100 11050	B	Frame	フレーム	1 ~0130	M 4	
1 -3	51100 12950	B	Frame	フレーム	1 ~0143	M10	
1 -4	51100 14450	B	Frame	フレーム	1 0144~	M11	
2	03403 10017		Grommet	グロメット	4		
3	52350 52230		Cover	カバー	1		
4	02201 06016		Flange bolt	フランジ 付ボルト	5		
5	03735 13006		Valve	バルブ	1		
52 - 00 BONNET GROUP ホンネット グループ							
31	52100 87330		Cover	カバー	1		
32	52100 87430		Cover	カバー	1		
33	52100 87530		Cover	カバー	1		
34	52100 88630		Cover	カバー	1 ~0091		
34 -1	52100 01040	B	Cover	カバー	1 ~0156	M 4	
34 -2	52100 12640	B	Cover	カバー	1 0157~	M14	
35	52800 35210		Duct	ダクト	1		
36	03407 66850		Seal rubber	シール ラバー	2		
37	03407 66821		Seal rubber	シール ラバー	1		
38	03407 66940		Seal rubber	シール ラバー	2		
39	03407 66916		Seal rubber	シール ラバー	1		
40	03407 68065		Seal rubber	シール ラバー	1 ~0091		
40 -1	03407 68066	B	Seal rubber	シール ラバー	1 0092~	M 4	
41	52100 88930		Cover	カバー	1		
42	52100 89030		Cover	カバー	1 ~0078		
42 -1	52100 00940	B	Cover	カバー	1 0079~	M 2	
43	52300 80620		Top cover	トップ カバー	1		
44	52728 62710		Cushion rubber	クッション ラバー	1		
45	52728 62810		Cushion rubber	クッション ラバー	1		
46	52450 03340		Door	ドア	1		
47	03407 64746		Seal rubber	シール ラバー	1		
48	52480 14400		Hinge	ヒンジ	2		
49	02136 08016		Bolt	ボルト	8		
50	52710 03601		Latch ass'y	ラッチ	1		key type
	52739 03400		Key	キー	1		(No. 0200)
51	52728 14810		Cushion rubber	クッション ラバー	1		
52	03407 68076		Seal rubber	シール ラバー	1		
53	02246 08025		Bolt, w/w	ワッシャ付ボルト	22		
54	03403 10010		Grommet	グロメット	4		
55	52350 52830		Cover	カバー	1		
56	03407 68076		Seal rubber	シール ラバー	1		
57	02136 06025		Bolt	ボルト	4		
58	03116 15006		Plain washer	プレーン ワッシャ	4		
59	52744 01100		Washer	ワッシャ	4		
60	52350 89010		Cover	カバー	1		
61	02246 08016		Bolt, w/w	ワッシャ付ボルト	2		
62	52800 35410		Duct	ダクト	1		
63	03407 67232		Seal rubber	シール ラバー	1		

51 - 00 FRAME & BONNET


見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name	数量 Q'ty	適用号機範囲 Applicable Ser. No.		変更 C/H	備 考 Remarks
					5E1	-		
64	52450 02840		Door	ドア	1	~0156		
64 -1	52450 27440	B	Door	ドア	1	0157~	M14	
65	52723 00900		Lock	ロック	1			
66	52746 04100		Cap	キャップ	2			
67	52480 14700		Hinge	ヒンジ	2			
68	03266 05012		Blind rivet	リベット	6			
69	02401 46012		Screw	スクリュー	4			
70	52450 03740		Door	ドア	1			
71	03407 64753		Seal rubber	シール ラバー	1			
72	03407 68083		Seal rubber	シール ラバー	1			
73	03407 68065		Seal rubber	シール ラバー	1			
74	52350 52530		Cover	カバー	1			
75	52800 35611		Duct	ダクト	1			
76	52800 35510		Duct	ダクト	1			
77	52450 03440		Door	ドア	1			
78	03407 64733		Seal rubber	シール ラバー	1			
79	03407 68090		Seal rubber	シール ラバー	1			
80	52710 07900		Latch ass'y	ラッチ	1			
81	52710 07200		Latch ass'y	ラッチ	1			
82	52746 01900		Cap	キャップ	2			
83	52800 35310		Duct	ダクト	1			
84	02915 00006		Hexagon flange nuts	フランジ 付ナット	52			
85	02246 06016		Bolt, w/w	ワッシャ付ボルト	11			
86	52620 56500		Lifting bail	リフティング ベール	1			
87	52620 56601		Lifting bail	リフティング ベール	1			
88	02135 12040		Bolt	ボルト	6			
89	03115 02012		Spring washer	スプリング ワッシャ	4			
90	03116 12012		Plain washer	プレーン ワッシャ	4			
91	02912 06012		Nut	ナット	2			
92	02246 08050		Bolt, w/w	ワッシャ付ボルト	10			
93	31131 04100		Rubber, vibration isolator	ラバー	1			
94	03115 06012		Spring washer	スプリング ワッシャ	4			(SUS)
95	03116 15012		Plain washer	プレーン ワッシャ	4			(SUS)
96	03407 67301		Seal rubber	シール ラバー	1			
97	33238 02900	D	Plug	プラグ	1	0196~	M711	

39 - 00

ACCESSORY GROUP

アクセサリ グループ

151	39200 04302		Tool box	ツール ボックス	1			
152	02915 00006		Hexagon flange nuts	フランジ 付ナット	4			



52 - 00 LINING

見出番号 Ref. NO.	部 品 番 号 Part NO.	互換性 Inter- change ability	部 品 名 称 Part Name	数量 Q'ty	適用号機範囲 Applicable Ser. No.		変更 C/H	備 考 Remarks
					5E1	-		
	52900 76220		URETHANE FOAM KIT ウレタン フォーム キット					
1	52959 57040		Lining ライニング*	1				
2	52959 16640		Lining ライニング*	1				
3	52959 59260		Lining ライニング*	1				
4	52931 48130		Lining ライニング*	1				
5	52931 48230		Lining ライニング*	1				
6	52959 59360		Lining ライニング*	1				
7	52919 34630		Lining ライニング*	2				
8	52977 49510		Lining ライニング*	2				
9	52977 49610		Lining ライニング*	1				
10	52931 48330		Lining ライニング*	1				
11	52931 48530		Lining ライニング*	1				
12	52978 77701		Lining ライニング*	1				
13	52978 77801		Lining ライニング*	1				
14	52977 51400		Lining ライニング*	1				
15	52977 49710		Lining ライニング*	1				
16	52977 49810		Lining ライニング*	2				
17	52978 77600		Lining ライニング*	1				
18	52977 49910		Lining ライニング*	1				
19	52977 68200		Lining ライニング*	1				
20	52939 25540		Lining ライニング*	1				
21	52919 09610		Lining ライニング*	1				
22	52931 48430		Lining ライニング*	1				
23	52978 77901		Lining ライニング*	1				
24	52977 50010		Lining ライニング*	1				
25	52978 78001		Lining ライニング*	1				
26	52977 50210		Lining ライニング*	2				
27	52939 25640		Lining ライニング*	1				
28	52939 25740		Lining ライニング*	1				
29	52939 25840		Lining ライニング*	1				

エンジン パーツ
ENGINE PARTS

原動機型式 ENGINE MODEL	YANMAR 4TNV88C-DHKS1
-----------------------	----------------------

Directions for the Parts Catalog.

1. This Parts Catalog shows both standard and optional parts.
2. Parts may change without prior notice.
3. The following is an example of the Parts Catalog format.

OCF10-G21601 29. FUEL INJECTION PUMP(W/BOOST)

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	729595-51390	FUEL INJECTION PUMP	1	1	1	1	1			1
1-1	1	729595-51391	FUEL INJECTION PUMP	1	1	1	1	1		N	1
		(A=E00185) (B=E00200)									
3	2	26022-060162	SCREW M 6X 16	9	9	9	9	9			
3-1	2	26022-060162	SCREW M 6X 16	4	4	4	4	4		K	
		(A=E00156) (B=E00156) (C=E00156) (D=E00156) (E=E00156)									
4	2	129470-51040	CAMSHAFT	1	1	1	1	1			
5	2	122710-51050	BEARING, ROLLER	2	2	2	2	2			
6	2	129470-51060	RETAINER	1	1	1	1	1			

Remarks

(1) BOOST COMPENSATOR TYPE. OPTIONAL PART, TO E00155, (4JH-DT, 4JH-DTZ)

① Ref. No.

The Ref. No. listed may not be in accordance with the illustration Ref. No.

(Ex.) Illustration No.

List Ref No.

1

1

(Before change)

1-1

(After change)

For interchangeable symbols N, R and K, illustrations for new parts may be abbreviated.

② Lev. (Level)

Level indication

The numbers below indicate the level of relativity towards the main part.

1 ----- Main parts (Assembly parts)

2 ----- Sub component included in " 1 ".

3 ----- Sub component included in " 2 ".

Note) Parts that are not for sale are partially illustrated but not listed.

③ Interchangeability Symbol

When a part change takes place, one of the following interchangeability symbols is indicated beside the part.

Symbol	Interchangeability	Contents note
N	Old $\xleftrightarrow{\text{Yes}} \text{New}$ No	New Part is interchangeable for Old Part but Old Part is not interchangeable for New Part.
Q	Old $\xleftrightarrow{\text{No}} \text{New}$ Yes	New Part is not interchangeable for Old Part but Old Part is interchangeable for New Part.
R	Old $\xleftrightarrow{\text{Yes}} \text{New}$ Yes	New/ Old Parts are both interchangeable.
S	Old $\xleftrightarrow{\text{No}} \text{New}$ No	New/ Old Parts are both not interchangeable.
W		Part newly added.
Z		Part discontinued.
F		Not interchangeable by a single part but interchangeable together with related parts.
K		Changes only for used parts quantities.

④ Effective Machine No.

When a part changes, the effective Machine No. will be indicated in the (A)-(F) column.

Product Symbol	Product No.	Product Symbol	Product No.
C	Clutch No. Compressor No.	F	Machine No. (Agricultural Equip.)
D	Drive No.	M	Machine No.
E	Engine No.		

Note 1) A date may follow the symbol. (Ex.) 1996.01

Note 2) "XXXXX" and "ZZZZZ" are for parts that could not be predicted or for engine models that could not be identified.

Note 3) (A=E00185) is the E (Engine Serial Number) for the column (A) model (in this case 4JH-DT) after the parts design change.

⑤ Remarks


Figures or alphabets (symbols) are entered in the remarks column.

The comments (remarks) on parts that are indicated at the bottom of the illustration are the same symbols as those stated above.

Fig.1. CYLINDER BLOCK


(A)=4TNV88C-DHKS1
(B)=
(C)=

(D)=
(E)=
(F)=




No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129C00-01560	BLOCK ASSY, CYLINDER	1							
4	2	129001-01250	PLUG, 50	1							
5	2	171051-01921	PLUG, NPTF1	1							
6	2	129150-02020	BOLT, METAL CAP	10							
9	2	129795-02412	BUSH, CAMSHAFT	1							
10	2	27241-300000	PLUG(30	8							
11	2	124060-01050	PLUG, PT1/8	1							
12	2	124160-01910	PLUG, PT1/4	2							
13	2	124160-01910	PLUG, PT1/4	1							
14	2	27241-120000	PLUG, 12	1							
24	2	129150-02931	METAL ASSY, THRUST	2							
27	1	129150-01200	BOLT, CYLINDER HEAD	18							
28	1	129685-01350	GASKET, HEAD	1							
29	1	129001-02931	METAL ASSY, MAIN	5							1
32	1	129150-02871	METAL ASSY, MAIN .25	5							2
35	1	129150-02941	METAL ASSY, 0.25 OS	1							3

Remarks
(1)Spare parts.
(2)Under-sized(U.S.=0.25) parts.
(3)Over-sized(O.S.=0.25) parts.




No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129A00-01500	CASE, GEAR	1							
2	1	129100-01580	PIN, PARALLEL 8X16	2							
3	1	124160-01751	CAP, FILLER	1							
4	1	129795-01950	PIPE, KNOCK L=18	2							
5	1	119609-32040	O-RING, P16	2							
6	1	119624-32040	O-RING, P12.0	1							
7	1	24311-000320	O-RING, 1AP32.0	1							
8	1	26106-080162	BOLT, M8X 16 PLATED	3							
9	1	171031-11741	PIPE, FILLER	1							
10	1	24311-000320	O-RING, 1AP32.0	1							
11	1	129A00-01550	COVER ASSY, CASE	1							
13	2	119934-01800	SEAL, OIL	1							
14	1	124240-01871	COVER, HYDRAULIC PUMP	1							
15	1	22190-080002	WASHER, SEAL 8	1							
16	1	26106-080162	BOLT, M8X 16 PLATED	4							
17	1	26106-080352	BOLT, M8X 35 PLATED	1							
18	1	26106-080402	BOLT, M8X 40 PLATED	7							
19	1	26106-080602	BOLT, M8X 60 PLATED	3							
20	1	26106-080852	BOLT, M8X 85 PLATED	4							



No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129100-01580	PIN, PARALLEL 8X16	2							
2	1	129A00-01602	HOUSING, FLYWHEEL	1							
3	1	119620-01750	CAP, WHEEL COVER	1							
4	1	26206-100252	BOLT, M10X 25 PLATED	6							
5	1	26206-100302	BOLT, M10X 30 PLATED	4							
6	1	129400-01730	SPACER, OIL PAN	1							
7	1	129688-01780	OIL PAN ASSY	1							
8	2	119640-01640	PLUG, DRAIN M22	1							
10	2	22190-220002	WASHER, SEAL 22	1							
11	1	26106-080162	BOLT, M8X 16 PLATED	4							
12	1	26106-080252	BOLT, M8X 25 PLATED	2							
13	1	26106-080452	BOLT, M8X 45 PLATED	20							
14	1	26106-080502	BOLT, M8X 50 PLATED	4							
15	1	129100-01580	PIN, PARALLEL 8X16	2							
16	1	129648-01600	CASE ASSY, OIL SEAL	1							
18	2	129648-01780	SEAL, OIL	1							
19	1	129486-01670	BOLT, M8X30	6							
20	1	26106-080352	BOLT, M8X 35 PLATED	3							
21	1	129A00-21710	SENSOR, FLYWHEEL	1							1
22	1	26450-060162	BOLT, M6X 16	1							

(1) When replacing this part, it is necessary to update the software of the ECU using the designated service tool. Please refer to the Service Manual for details.

N:Old $\xrightarrow[\text{No}]{\text{Yes}}$ New, Q:Old $\xrightarrow[\text{Yes}]{\text{No}}$ New, R:Old $\xrightarrow[\text{Yes}]{\text{Yes}}$ New, S:Old $\xrightarrow[\text{No}]{\text{No}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change
Copyright (C) 2020 YANMAR GLOBAL CS CO., LTD. All Rights Reserved.




No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129601-11241	SHAFT ASSY, ROCKER	1							
2	2	129601-11251	SHAFT, ROCKER ARM	1							
4	2	119802-11260	SUPPORT, ROCKER ARM	2							
5	2	119802-11270	SUPPORT, ROCKER ARM	3							
6	2	129150-11280	SPRING, SHAFT	4							
7	2	129004-11650	ARM ASSY, ROCKER	8							
8	3	129150-11230	SCREW, VALVE ADJUST	8							
10	3	129150-11750	NUT, M8XP1.0	8							
11	2	26226-080182	STUD, M8X 18	3							
12	1	129150-11370	CAP, VALVE	8							
13	1	129C20-11700	HEAD ASSY, CYLINDER	1							
20	2	27241-400000	PLUG, 40	2							
21	2	129005-11100	VALVE, INTAKE	4							
22	2	129100-11112	VALVE, EXHAUST	4							
23	2	129795-11120	SPRING, VALVE	8							
24	2	129795-11180	RETAINER, SPRING	8							
25	2	124460-11340	SEAL, VALVE STEM	4							
26	2	129A00-11340	SEAL, VALVE STEM	4							
27	2	27310-080001	COTTER, 8	8							
29	1	129978-11871	GASKET, INJECTOR	4							
30	1	129A00-11900	RETAINER, INJECTOR	4							
31	1	120270-54410	WASHER, INJECTOR	4							
32	1	22351-060012	PIN, SPRING 6.0X12	2							
33	1	26106-080252	BOLT, M8X 25 PLATED	3							
34	1	26106-080352	BOLT, M8X 35 PLATED	4							
35	1	26106-080502	BOLT, M8X 50 PLATED	7							
36	1	124160-01751	CAP, FILLER	1							
37	1	124160-11360	KNOB, BONNET	3							
38	1	129C00-11360	BONNET ASSY, HEAD	1							
39	2	129004-03010	PLATE, BAFFLE	1							
40	1	119802-03070	BAFFLE, BREATHER	1							
41	2	129150-03070	BAFFLE, BREATHER	1							
42	2	123907-03100	DIAPHRAGM, BREATHER	1							
43	2	123907-03110	PLATE, CENTER	1							
44	2	123907-03120	PLATE, BREATHER	1							
45	2	123907-03140	SPRING, DIAPHRAGM	1							
47	2	129C00-11310	GASKET, BONNET	1							
48	2	129A00-11330	JOINT	1							
49	2	129978-12700	SENSOR, PRESSURE	1							1
50	3	129A00-12780	O-RING, EGR SENSOR	2							
51	2	129A00-13360	HOSE ASSY, PRESSURE	1							
53	3	129A00-13380	CLIP, HOSE 14	2							
54	2	119640-61400	PLUG	1							
56	2	22857-500100	SCREW, 5X10	4							
57	2	22857-500100	SCREW, 5X10	6							
58	2	26450-060162	BOLT, M6X 16	2							
59	1	24311-000120	O-RING, 1AP12.0	3							
60	1	24311-000320	O-RING, 1AP32.0	1							
61	1	129900-07900	LIFTER, ENGINE	1							
62	1	129900-07920	LIFTER, ENGINE	1							
63	1	26106-080162	BOLT, M8X 16 PLATED	4							

(1) When replacing this part, it is necessary to update the software of the ECU using the designated service tool. Please refer to the Service Manual for details.

N:Old $\xleftrightarrow{\text{Yes}}$ New Q:Old $\xleftrightarrow{\text{No}}$ New R:Old $\xleftrightarrow{\text{Yes}}$ New S:Old $\xleftrightarrow{\text{No}}$ New W:Add Z:Discontinued F:Interchangeable by set K:Q'ty Change

Copyright (C) 2020 YANMAR GLOBAL CS CO., LTD. All Rights Reserved.




No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
64	1	119803-77830	HARNESS, WIRE	1							
65	1	129008-77800	PLUG, GLOW	4							
66	1	129C00-77820	CONNECTOR, GLOW PLUG	1							
67	1	120130-11860	GUIDE, VALVE	4							2
68	1	129150-11810	GUIDE, VALVE	4							2

(1) When replacing this part, it is necessary to update the software of the ECU using the designated service tool. Please refer to the Service Manual for details.

N:Old $\xleftrightarrow[\text{No}]{\text{Yes}}$ New, Q:Old $\xleftrightarrow[\text{Yes}]{\text{No}}$ New, R:Old $\xleftrightarrow[\text{Yes}]{\text{Yes}}$ New, S:Old $\xleftrightarrow[\text{No}]{\text{No}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


Copyright (C) 2020 YANMAR GLOBAL CS CO., LTD. All Rights Reserved.



No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129005-03080	HOSE ASSY, BREATHER	1							
2	2	129410-03990	CLAMP, HOSE 21.5	2							
3	1	129C00-12110	GASKET, MANIFOLD	1							
4	1	129C00-12150	MANIFOLD ASSY,INTAKE	1							
5	2	129C00-12100	MANIFOLD, INTAKE	1							
6	2	26216-060202	STUD, M6X 20	4							
7	1	129A00-12721	SENSOR,AIR TEMP	1							1
8	1	26106-080502	BOLT, M8X 50 PLATED	5							
9	1	129A00-12810	GASKET, COLLECTOR	1							
10	1	129A00-12851	COLLECTOR ASSY	1							
11	2	119660-01570	STUD, M6X12	1							
12	2	129A00-12711	SENSOR, TEMPERATURE	1							
13	3	129A00-12790	O-RING, TEMP SENSOR	1							
14	2	129A00-12830	COLLECTOR, INTAKE	1							
15	2	129A00-59110	JOINT, HOSE M14	1							
16	2	129A00-59120	JOINT, HOSE 14	1							
17	2	22190-140002	WASHER, SEAL 14	2							
18	2	26216-080302	STUD, M8X 30	2							
19	2	26716-060002	NUT, M6	1							
20	1	26106-080502	BOLT, M8X 50 PLATED	1							
21	1	26106-080752	BOLT, M8X 75 PLATED	1							
22	1	26216-081052	STUD, M8X105	3							
23	1	26306-080002	NUT, M8	3							
24	1	129A00-12820	BEND, INTAKE	1							
25	1	129A00-12900	THROTTLE, INTAKE	1							1
26	1	129A00-12910	GASKET, THROTTLE	2							
27	1	26106-060202	BOLT, M6X 20 PLATED	2							
28	1	26106-060402	BOLT, M6X 40 PLATED	4							
29	1	26106-060902	BOLT, M6X 90 PLATED	2							

(1) When replacing this part, it is necessary to update the software of the ECU using the designated service tool. Please refer to the Service Manual for details.


N:Old $\xrightarrow[\text{No}]{\text{Yes}}$ New, Q:Old $\xrightarrow[\text{Yes}]{\text{No}}$ New, R:Old $\xrightarrow[\text{Yes}]{\text{Yes}}$ New, S:Old $\xrightarrow[\text{No}]{\text{No}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change
Copyright (C) 2020 YANMAR GLOBAL CS CO., LTD. All Rights Reserved.



No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129C00-13100	MANIFOLD, EXHAUST	1							
2	1	129C00-13110	GASKET, MANIFOLD	1							
3	1	123900-13130	STUD, M10X22	4							
4	1	129A01-13601	BOLT, M10X50 10.9T	1							
5	1	129F01-13630	BOLT, M10X80 10.9T	5							
6	1	129A01-13700	STUD, 10X80 10.9	2							
7	1	129A00-13770	SENSOR, TEMPERATURE	1							1
8	2	129A00-91200	CLIP, BAND	1							
9	1	26306-100002	NUT, M10	2							
10	1	129A00-13300	PIPE ASSY, PRESSURE	1							
11	2	23297-080061	CLAMP, A8X 6	2							
12	1	129A00-13350	BOLT, PIPE JOINT	1							
13	1	23414-120000	GASKET, 12X1.0	2							
14	1	26106-060122	BOLT, M6X 12 PLATED	2							
15	1	129A00-13400	COOLER, EGR	1							
16	1	129A00-13410	GASKET, EGR COOLER	2							
17	1	129F01-13600	BOLT, M10X90 10.9T	1							
18	1	129E00-13620	BOLT, M8X40 10.9	2							
19	1	129A00-13851	PIPE, EGR OUTLET	1							
20	2	129A00-13861	PIPE, EGR OUTLET	1							
21	2	129418-18320	STUD, M8X20	2							
22	1	26106-080502	BOLT, M8X 50 PLATED	2							
23	1	129A00-13752	SENSOR,EGR GAS TEMP	1							1
24	1	129C00-13800	PIPE, EGR	1							
25	1	129927-13810	GASKET, EGR PIPE	1							
26	1	26106-080252	BOLT, M8X 25 PLATED	2							
27	1	26306-080002	NUT, M8	2							
28	1	129C00-13901	VALVE, EGR	1							1
29	1	129A00-13910	GASKET, EGR-V INLET	1							
30	1	129A00-13920	GASKET, EGR-V OUTLET	1							
31	1	26306-080002	NUT, M8	2							

(1) When replacing this part, it is necessary to update the software of the ECU using the designated service tool.
Please refer to the Service Manual for details.

N:Old $\xleftrightarrow[\text{No}]{\text{Yes}}$ New, Q:Old $\xleftrightarrow[\text{Yes}]{\text{No}}$ New, R:Old $\xleftrightarrow[\text{Yes}]{\text{No}}$ New, S:Old $\xleftrightarrow[\text{No}]{\text{Yes}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change
Copyright (C) 2020 YANMAR GLOBAL CS CO., LTD. All Rights Reserved.




No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129930-13201	GASKET, SILENCER	1							
3	1	129C00-13870	SENSOR, ATD TEMP.DS+	1							1
4	1	129C00-13880	SENSOR, ATD TEMP.DS+	1							1
5	1	129C20-16090	DPF ASSY	1							1
6	2	129C20-16290	CASE, DOC	1							1
11	2	129C00-16400	CASE, SOOT FILTER	1							1
13	2	129C22-16500	SILENCER, DPF	1							
14	2	129A00-16600	GASKET, DPF	2							
15	2	129A00-16610	BOLT, M8X28 10.9T	16							
16	2	129C01-16690	LIFTER, DPF	1							
17	2	129A00-16700	STIFFENER, DPF A	5							
18	2	129C20-16700	STIFFENER, DPF B	1							
19	2	129A00-16730	STIFFENER, DPF C	1							
20	2	129A00-16740	STIFFENER, DPF C	1							
21	2	26106-080142	BOLT, M8X 14 PLATED	2							
22	2	26306-080002	NUT, M8	16							
24	1	129A00-13350	BOLT, PIPE JOINT	2							
25	1	129A00-17300	PIPE, SENSOR	1							
26	1	129A00-17311	GASKET, SENSOR	4							
27	1	129A00-17350	PIPE, SENSOR	1							
29	1	129C00-17500	HOSE,PRES EXH	1							
30	1	129A00-17520	CLIP, HOSE	2							
32	1	129A00-17551	HOSE, PRESSURE	1							
33	1	129A00-17570	CLIP, HOSE	2							
34	1	129978-17700	SENSOR, PRESSURE	1							1
35	1	129A00-17760	BRACKET, SENSOR	1							
36	1	26106-060162	BOLT, M6X 16 PLATED	2							
37	1	26106-080202	BOLT, M8X 20 PLATED	2							
38	1	129A00-91200	CLIP, BAND	1							
39	1	129C00-91200	BAND	1							
40	1	129A00-91430	CLIP, CONNECTOR	2							

(1) When replacing this part, it is necessary to update the software of the ECU using the designated service tool. Please refer to the Service Manual for details.

N:Old $\xrightarrow[\text{No}]{\text{Yes}}$ New, Q:Old $\xrightarrow[\text{Yes}]{\text{No}}$ New, R:Old $\xrightarrow[\text{Yes}]{\text{Yes}}$ New, S:Old $\xrightarrow[\text{No}]{\text{No}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change
Copyright (C) 2020 YANMAR GLOBAL CS CO., LTD. All Rights Reserved.


Fig.8. CAMSHAFT & DRIVING GEAR



							0CD50-M06560 Fig.8					
							(A)=4TNV88C-DHKS1		(D)=			
							(B)=		(E)=			
							(C)=		(F)=			
No.	Lev.	Parts No.	Description	Q'ty						I	R	
				(A)	(B)	(C)	(D)	(E)	(F)			
1	1	129150-14200	TAPPET	8								
2	1	129150-14400	ROD, PUSH L=178	8								
3	1	129C00-14580	CAMSHAFT ASSY	1								
4	2	129150-02450	METAL, THRUST	1								
6	2	129A00-14100	GEAR, CAMSHAFT	1								
7	2	22512-070140	KEY, 7X 14	1								
8	1	129A00-14701	PULSER, CAMSHAFT	1								
9	1	26106-060102	BOLT, M6X 10 PLATED	3								
10	1	26106-080142	BOLT, M8X 14 PLATED	2								
11	1	129A00-14710	SENSOR, ROTATION	1								
12	1	26450-060162	BOLT, M6X 16	1								
13	1	129A00-25050	SHAFT, IDLE GEAR A	1								
14	1	129A00-25110	GEAR ASSY, IDLE A	1								
17	1	26106-080452	BOLT, M8X 45 PLATED	3								
18	1	129A00-25900	GEAR, SUPPLY PUMP	1								
19	1	22217-180000	WASHER, SPRING 18	1								
20	1	26776-180002	NUT, LOCK M18	1								
21	1	129A00-25060	SHAFT, IDLE GEAR B	1								
22	1	129A00-25120	GEAR ASSY, IDLE B	1								
25	1	129A00-25200	PLATE, IDLE SHAFT B	1								
26	1	129A00-25210	GASKET, IDLE SHAFT B	1								
27	1	26106-080402	BOLT, M8X 40 PLATED	2								
28	1	119802-25071	BUSH, IDLE GEAR	1							1	
29	1	129A00-25080	BUSH, IDLE GEAR B	1							1	

Remarks
(1)Spare parts.


Fig.9. CRANKSHAFT & PISTON



Remarks
(1)Spare parts.
(2)Under-sized(U.S.=0.25) parts.
(3)Over-sized(O.S.=0.25) parts.

				0CD50-M06560 Fig.9							
				(A)=4TNV88C-DHKS1				(D)=			
				(B)=				(E)=			
				(C)=				(F)=			
No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129604-21000	CRANKSHAFT ASSY	1							
2	2	129100-01580	PIN, PARALLEL 8X16	1							
4	2	119803-21200	GEAR, CRANKSHAFT	1							
5	2	22512-070140	KEY, 7X 14	1							
7	1	22351-030010	PIN, SPRING 3.0X10	1							
8	1	119802-21650	V-PULLEY, CRANKSHAFT	1							
9	1	129795-21661	WASHER, 14	1							
10	1	121850-21680	BOLT, V-PULLEY	1							
11	1	121111-21501	BOLT, FLYWHEEL	6							
12	1	129C20-21560	FLYWHEEL ASSY	1							
14	2	119865-21600	GEAR, RING Z=116	1							
16	1	129C00-22080	PISTON ASSY	4							
18	2	129A00-22500	RING SET, PISTON	4							
24	1	129202-22300	PIN, PISTON D26 L70	4							
25	1	22252-000260	RING, 26	8							
26	1	729402-23100	ROD ASSY, CONNECTING	4							
30	2	121550-23200	BOLT, CONNECTING ROD	8							
31	2	129150-23601	METAL ASSY,CRANK PIN	4							
33	1	129100-23910	METAL, PISTON PIN	4							1
34	1	129150-23611	METAL, CRANK PIN .25	4							2
36	1	129C00-22900	PISTON ASSY, 0.25 OS	4							3
38	2	129A00-22950	RING SET, PISTON .25	4							3

Fig.10. LUB. OIL SYSTEM




							OCD50-M06560 Fig.10					
							(A)=4TNV88C-DHKS1			(D)=		
							(B)=			(E)=		
							(C)=			(F)=		
No.	Lev.	Parts No.	Description	Q'ty						I	R	
				(A)	(B)	(C)	(D)	(E)	(F)			
1	1	129C00-32000	PUMP ASSY, OIL	1								
13	1	129486-32020	GASKET, PUMP	1								
14	1	26450-060252	BOLT, M6X 25	4								
15	1	129004-34802	DIPSTICK, OIL	1								
16	1	121520-34810	GUIDE, DIPSTICK	1								
17	1	129150-35042	GASKET, INLET PIPE	1								
18	1	129436-35070	PIPE ASSY, OIL INLET	1								
19	1	26106-080552	BOLT, M8X 55 PLATED	2								
20	1	129067-33011	COOLER ASSY, OIL	1								
21	2	129508-33050	O-RING	1								
22	1	129417-33111	NUT, OIL COOLER	1								
23	1	129103-35122	GASKET, BRACKET	1								
25	1	129688-35170	BRACKET ASSY, FILTER	1								
27	2	129417-35150	STUD, M20X67	1								
28	2	129553-35500	VALVE ASSY, BYPASS	1								
30	3	129553-35520	SPRING, VALVE	1								
31	3	129553-35530	RETAINER, SPRING	1								
32	3	24190-130002	BALL, STEEL 13/32	1								
33	2	23875-040000	PLUG, R04	2								
34	1	129006-44480	JOINT, R02	1								
35	1	129467-49040	HOSE ASSY, WATER	1								
37	2	129165-49060	TUBE, CORRUGATED	1								
38	1	129615-49050	PIPE, COOLER INLET	1								
39	1	23000-022000	CLAMP, 22	4								
40	1	26106-080252	BOLT, M8X 25 PLATED	3								
41	1	119761-39450	SWITCH, HYDRAULIC	1								
42	1	129150-35153	FILTER ASSY, D80X80L	1								

1

Remarks
(1)Spare parts.


Fig.11. COOLING WATER SYSTEM



Remarks
(1)When replacing this part, it is necessary to update the software of the ECU using the designated service tool.
Please refer to the Service Manual for details.

No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129A01-42001	PUMP ASSY, CW	1							
4	2	129100-42051	GASKET, WATER PUMP	1							
12	2	129103-49301	ELBOW, PT1/4	1							
13	2	129928-49420	JOINT	1							
15	1	129486-42021	GASKET, WATER PUMP	1							
16	1	129004-42040	JOINT, WATER PIPE	1							
17	1	129486-42140	O-RING, G30	1							
18	1	124395-49840	GASKET, THERMOSTAT	1							
19	1	23414-080000	GASKET, 8X1.0	1							
20	1	26106-080122	BOLT, M8X 12 PLATED	1							
21	1	26106-080162	BOLT, M8X 16 PLATED	3							
22	1	26106-080452	BOLT, M8X 45 PLATED	1							
23	1	26106-080602	BOLT, M8X 60 PLATED	3							
24	1	129550-42350	V-PULLEY, PUMP	1							
25	1	129612-42350	V-BELT, A38	1							
26	1	129916-44740	FAN, COOLING D=430	1							
27	1	129648-44771	SPACER, FAN 18MM	1							
28	1	26106-060222	BOLT, M6X 22 PLATED	4							
29	1	26106-080162	BOLT, M8X 16 PLATED	4							
30	1	129155-49801	THERMOSTAT, 71C	1							
31	1	129150-49811	GASKET, THERMOSTAT	1							
32	1	129350-49530	COVER, THERMOSTAT	1							
33	1	129795-49551	GASKET, COVER	1							
34	1	26106-080222	BOLT, M8X 22 PLATED	2							
35	1	119620-49290	COCK ASSY, 1/4	1							
39	1	121450-42450	PLUG, M16	1							
40	1	129927-44900	SENSOR, TEMPERATURE	1							1
41	1	124465-44950	GASKET, 16	1							
42	1	22190-120002	WASHER, SEAL 12	1							
43	1	129928-49420	JOINT	1							
44	1	129A00-49610	PIPE ASSY, EGR-C IN	1							
46	2	129960-03990	CLAMP, HOSE 19.8	2							
48	1	129C00-49610	PIPE ASSY, OUTLET A	1							
49	2	129960-03990	CLAMP, HOSE 19.8	2							
51	1	129C00-49620	PIPE ASSY, OUTLET B	1							
52	2	129960-03990	CLAMP, HOSE 19.8	2							
55	1	129C23-49700	PIPE ASSY, WATER	1							
56	1	26106-080162	BOLT, M8X 16 PLATED	2							

Fig.12. FUEL SUPPLY PUMP




(A)=4TNV88C-DHKS1
(B)=
(C)=

OCD50-M06560 Fig.12
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129C28-51000	PUMP ASSY, FUEL	1							1
2	2	129A00-51100	VALVE ASSY	1							1
3	3	129A00-51110	RING, SEAL	1							
4	3	129A00-51120	O-RING, MPROP	1							
5	2	129A00-51130	BOLT, MPROP	2							
6	2	129A00-51200	SENSOR, TEMPERATURE	1							1
7	2	129A00-51900	O-RING, FUEL PUMP	1							
8	1	26106-080302	BOLT, M8X 30 PLATED	3							

Remarks
(1)When replacing this part, it is necessary to update the software of the ECU using the designated service tool.
Please refer to the Service Manual for details.

Fig.13. FUEL INJECTION VALVE



No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129A00-53100	INJECTOR, CR	4							1
4	2	129A00-53200	RING, RETAINING	4							
6	2	129C28-53300	O-RING	4							
7	1	129C00-57000	COMMON RAIL ASSY	1							1
8	2	129A00-57100	SENSOR, PRESSURE	1							1
9	2	129A00-57200	VALVE ASSY, PLV4	1							1
10	3	129A00-57210	O-RING, PLV4	1							
11	1	26106-080252	BOLT, M8X 25 PLATED	2							
12	1	122780-59100	RETAINER, PIPE	4							
14	1	129A00-59700	PIPE ASSY, RAIL IN	1							
17	1	129C00-59810	PIPE ASSY, INJECTION	1							
19	1	129A00-59820	PIPE ASSY, INJECTION	1							
21	1	129C00-59820	PIPE ASSY, INJECTION	1							
23	1	129A00-59830	PIPE ASSY, INJECTION	1							
25	1	26366-060002	NUT, M6	4							

Remarks
(1)When replacing this part, it is necessary to update the software of the ECU using the designated service tool.
Please refer to the Service Manual for details.

(A)=4TNV88C-DHKS1
(B)=
(C)=

(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129677-59501	PIPE ASSY, RETURN	1							
3	2	23080-007000	CLAMP, 7	1							
4	1	129A00-59020	PIPE ASSY, RETURN	1							
7	2	23080-015000	CLAMP, 15	2							
8	1	129C00-59030	PIPE ASSY, RETURN	1							
9	2	114270-59010	CLAMP, HOSE 12	2							
12	2	129A00-91200	CLIP, BAND	1							






Fig.15. STARTER MOTOR




No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129242-77010	STARTER, 1.7	1							
2	2	129698-77020	SWITCH ASSY, MAGNET	1							
3	2	129242-77100	ARMATURE ASSY	1							
4	2	129242-77110	YOKE ASSY	1							
5	2	129242-77120	HOLDER ASSY, BRUSH	1							
6	3	129242-77130	BRUSH, -	2							
7	3	129242-77140	BRUSH SET	1							
8	3	129242-77150	SPRING, BRUSH	4							
9	2	129242-77160	COVER ASSY, STARTER	1							
10	3	129242-77170	METAL, REAR COVER	1							
11	2	118400-77170	GEAR, PLANETARY	3							
12	2	129242-77180	BRACKET, CENTER P	1							
13	3	129698-77190	BRACKET, CENTER	1							
14	2	129698-77200	GEAR, INTERNAL	1							
15	2	129242-77210	BRACKET, CENTER A	1							
16	2	129698-77220	PINION ASSY	1							
17	2	129698-77230	SHAFT, PINION	1							
18	2	129698-77250	WASHER SET	1							
19	2	129242-77260	CASE ASSY, GEAR	1							
20	3	X2114535200	METAL, STARTER	1							
21	2	129242-77270	LEVER SET, SHIFT	1							
22	2	129242-77280	COVER KIT, DUST	1							
23	2	124195-77770	BOLT, THROUGH	2							
24	1	26106-120252	BOLT, M12X 25 PLATED	2							



No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129423-77210	ALTERNATOR, 12V-40A	1							
2	2	129240-79310	NUT	1							
3	2	119620-77380	ROTOR ASSY	1							
4	3	123501-79240	BEARING, BALL	1							
5	3	119620-79250	COVER, BEARING	1							
6	2	119620-77421	FRAME ASSY, DRIVE	1							
7	3	119620-79200	BEARING, BALL	1							
8	3	119620-79210	PLATE, RETAINER	1							
9	3	119620-79220	SCREW	4							
10	3	119620-79230	STUD	2							
11	2	119620-77440	FRAME ASSY, REAR	1							
12	2	119620-77461	PULLEY, GENERATOR	1							
13	2	119620-77471	NUT	1							
14	2	119620-77490	COLLAR	1							
15	2	129423-77730	REGULATOR ASSY	1							
16	2	119620-79260	HOLDER ASSY	1							
17	2	129052-79270	HOLDER ASSY, BRUSH	1							
18	3	119620-77480	BRUSH ASSY, SUB	2							
19	3	119620-79280	SPRING	2							
20	2	119620-79290	SCREW	6							
21	2	119620-79300	SCREW	1							
22	2	129240-79300	COVER	1							
23	2	119620-79310	BOLT	3							
24	2	119620-79320	SCREW, W/WASHER	2							
25	2	119620-79330	BOLT	2							
26	2	119620-79340	BUSH, INSULATION	1							
27	2	119620-79350	NUT	2							
28	2	119620-79360	WASHER, THRUST	1							
29	1	129795-01900	BOLT, M10X33	1							
30	1	26306-100002	NUT, M10	1							
31	1	119940-77270	SPACER, GENERATOR	1							
32	1	119802-77330	ADJUSTER, BELT	1							
33	1	129972-77341	BOLT, ADJUSTER L=50	1							
34	1	26106-080452	BOLT, M8X 45 PLATED	1							


No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129C20-75061	ECU ASSY,4-88C-DHKS	1							1
12	1	129A00-75910	ECU ASSY,SERVICE YMR	1							2



Please refer to the Service Manual for details.

N:Old $\xrightarrow[\text{No}]{\text{Yes}}$ New, Q:Old $\xrightarrow[\text{Yes}]{\text{No}}$ New, R:Old $\xrightarrow[\text{Yes}]{\text{Yes}}$ New, S:Old $\xrightarrow[\text{No}]{\text{No}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change
Copyright (C) 2020 YANMAR GLOBAL CS CO., LTD. All Rights Reserved.


Fig.18. ELECTRIC PARTS



(A)=4TNV88C-DHKS1
(B)=
(C)=

(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129A00-77930	BRACKET, CONNECTOR	1							
3	1	129928-79700	CLAMP, 150-M8	1							
4	1	129C00-91223	HARNESS, B T4	1							
14	1	129C00-91232	HARNESS, C T4	1							
19	1	129A00-91451	BOOT, CAP TYPE	1							
20	1	129A00-91600	BRACKET, HARNESS	1							
21	1	26106-080122	BOLT, M8X 12 PLATED	2							
22	1	26106-080122	BOLT, M8X 12 PLATED	1							
23	1	26106-080122	BOLT, M8X 12 PLATED	2							
24	1	29621-100000	BAND, TR100	1							
25	1	29621-200000	BAND	1							




(A)=4TNV88C-DHKS1
(B)=
(C)=

(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	128300-13230	GASKET, SILENCER	1							
2	1	129640-13590	CLAMP ASSY	1							
3	2	129640-13580	CLAMP	1							
4	2	22117-100000	WASHER, 10	1							
5	2	22217-100000	WASHER, SPRING 10	1							
6	2	26106-100652	BOLT, M10X 65 PLATED	1							
7	2	26706-100002	NUT, M10	1							
8	1	172B02-17150	RELAY, CA TYPE C	1							
9	1	129238-35111	PLUG	1							
11	1	129150-35153	FILTER ASSY, D80X80L	1							
12	1	720445-44200	TANK ASSY, SUB	1							
14	2	120445-44540	BRACKET, SUB TANK	1							
15	1	129612-52100	PUMP, FUEL FEED	1							
16	1	129A00-55600	FILTER ASSY, FUEL	1							
17	2	129A00-55610	BRACKET ASSY, FILTER	1							
18	2	129A00-55800	FILTER, FUEL	1							
19	1	129E22-55700	FILTER ASSY, FUEL PRE	1							
20	2	129E00-55710	BODY ASSY	1							
21	3	129A00-55751	PLUG, AIR VENT	1							
22	3	129A00-55760	O-RING	1							
24	2	129A00-55720	CUP, CLEAR	1							
25	2	129A00-55730	ELEMENT, FUEL FILTER	1							
26	2	129242-55740	PLUG, DRAIN	1							
27	2	129A00-55740	O-RING	1							
28	2	129A00-55770	FLOAT	1							
29	1	129C21-59010	HOSE ASSY, FUEL	1							
30	2	114270-59010	CLAMP, HOSE 12	2							
33	1	129C21-59020	HOSE ASSY, FUEL	1							
34	2	114270-59010	CLAMP, HOSE 12	2							
37	1	129C21-59030	HOSE ASSY, FUEL	1							
38	2	114270-59010	CLAMP, HOSE 12	2							
41	1	129C21-59040	HOSE ASSY, FUEL	1							
42	2	114270-59010	CLAMP, HOSE 12	2							
45	1	129C21-59050	HOSE ASSY, FUEL	1							
46	2	114270-59010	CLAMP, HOSE 12	2							
49	1	129C21-59060	HOSE ASSY, FUEL	1							
52	2	23080-015000	CLAMP, 15	2							
53	1	129927-77910	BRACKET, CONNECTOR	2							
54	1	129927-77920	RELAY, ISO 70A	2							
55	1	129115-91250	SWITCH ASSY, STARTER	1							
57	2	129115-91270	KEY ASSY	1							
58	1	24321-000600	O-RING, 1AG60.0	1							
59	1	26106-080952	BOLT, M8X 95 PLATED	2							

Remarks
(1)Optional parts.

Fig.20. GASKET SET



(A)=4TNV88C-DHKS1
(B)=
(C)=

(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty						I	R
				(A)	(B)	(C)	(D)	(E)	(F)		
1	1	129C20-92620	GASKET SET	1							1
2	2	129685-01350	GASKET, HEAD	1							
3	2	129C00-11310	GASKET, BONNET	1							
4	2	124460-11340	SEAL, VALVE STEM	4							
5	2	129A00-11340	SEAL, VALVE STEM	4							
6	2	129978-11871	GASKET, INJECTOR	4							
7	2	129C00-12110	GASKET, MANIFOLD	1							
8	2	129A00-12780	O-RING, EGR SENSOR	2							
9	2	129A00-12790	O-RING, TEMP SENSOR	1							
10	2	129A00-12810	GASKET, COLLECTOR	1							
11	2	129A00-12910	GASKET, THROTTLE	2							
12	2	129C00-13110	GASKET, MANIFOLD	1							
13	2	129930-13201	GASKET, SILENCER	1							
14	2	128300-13230	GASKET, SILENCER	1							
15	2	129A00-13410	GASKET, EGR COOLER	2							
16	2	129927-13810	GASKET, EGR PIPE	1							
17	2	129A00-13910	GASKET, EGR-V INLET	1							
18	2	129A00-13920	GASKET, EGR-V OUTLET	1							
19	2	129A00-16600	GASKET, DPF	2							
20	2	129A00-17311	GASKET, SENSOR	4							
21	2	129A00-25210	GASKET, IDLE SHAFT B	1							
22	2	129486-32020	GASKET, PUMP	1							
23	2	119609-32040	O-RING, P16	2							
24	2	119624-32040	O-RING, P12.0	1							
25	2	129150-35042	GASKET, INLET PIPE	1							
26	2	129150-35111	GASKET, BRACKET	1							
27	2	129486-42021	GASKET, WATER PUMP	1							
28	2	129486-42140	O-RING, G30	1							
29	2	124465-44950	GASKET, 16	1							
30	2	129795-49551	GASKET, COVER	1							
31	2	129150-49811	GASKET, THERMOSTAT	1							
32	2	124395-49840	GASKET, THERMOSTAT	1							
33	2	129A00-51900	O-RING, FUEL PUMP	1							
34	2	22190-080002	WASHER, SEAL 8	1							
35	2	22190-120002	WASHER, SEAL 12	1							
36	2	22190-140002	WASHER, SEAL 14	2							
37	2	22190-220002	WASHER, SEAL 22	1							
38	2	23414-080000	GASKET, 8X1.0	1							
39	2	23414-120000	GASKET, 12X1.0	2							
40	2	24311-000120	O-RING, 1AP12.0	3							
41	2	24311-000320	O-RING, 1AP32.0	3							

Remarks
(1)Optional parts.

2020年 12月 24日 初版

2024年 8月 20日 改訂

発行 **北越工業株式会社**

新潟本社・工場
新潟県燕市下粟生津3074

HOKUETSU INDUSTRIES CO., LTD.

Copyright (C) 2020 HOKUETSU INDUSTRIES CO., LTD. All Rights Reserved.

2408-04
CAT. NO. 39520 87000

PARTS FINDER

Search Website by Part Number

**Discount
Equipment**



***Search Manual
Library For Parts
Manual & Lookup Part
Numbers – Purchase
or Request Quote***

Search Manuals

How many search results do you want to get displayed? (Set 0 to return all results)

* **Find**

* **Find**

Sort

Rank: Search Ranking

File Names

Rank: Full Text Search (required)

Descriptions

Rank: Description Rank (You Are Looking For)

Submit

**Can't Find Part or
Manual? Request Help
by Manufacturer,
Model & Description**

Parts Order Form	
Product Name:	
Required Part:	
Quantity:	
Ordered By:	
Name:	
Company:	
Address:	
City:	
State/Region:	
Zip Code:	
Phone:	
E-mail:	
Comments:	
Date:	
Order #:	
Part Number:	

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: 561-964-4949 Outside Florida TOLL FREE: 877-690-3101

Need parts?

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment ,Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar



www.discount-equipment.com

Go to Discount-Equipment.com to order your parts

AIRMAN
HOKUETSU INDUSTRIES CO., LTD.