



# 11304 "BRUTE" HAMMER

Pos.	Part Number	Description {Qty.}	F/C	Pos.	Part Number	Description {Qty.}	F/C
2	1 614 220 157	Field 120V	22	68	1 613 465 001	Handle Bumper {2}	9
4	1 615 805 068	Bearing Housing	73	69	1 615 700 042	Intermediate Plate	38
5	1 610 900 015	Ball Bearing	60	70	1 615 132 011	Handle	74
6	1 615 500 214	Retaining Nut	85	71	1 611 11A 004	Name Plate	9
7	1 615 108 104	Field Housing	9	73	1 603 435 019	Screw {2}	89
8	1 616 610 091	Fan	23	74	2 916 160 009	Spring Washer {3}	74
9	1 613 313 000	Nut	89	75	3 614 640 501	Spring {3}	27
11	1 610 108 013	Felt Seal	77	76	3 611 034 500	Cord Clamp	89
12	1 610 102 616	Washer	65	84	1 611 099 003	Mounting Plate	9
15	1 610 910 091	Needle Bearing	51	85	1 614 336 045	Brush Holder	25
19	1 616 110 033	Eccentric Shaft	53			w/pos. 96, 879 - 883	
21	1 616 318 009	Eccentric Gear	34	86	1 610 300 033	Pin	54
22	1 616 328 036	Intermediate Gear	31	87	1 610 900 027	Ball Bearing	56
23	1 610 913 005	Needle Bearing {2}	56	88	1 610 283 016	Oil Seal	77
24	1 615 500 323	Gear Housing Cover	70	89	1 610 009 008	Insulating Plate	9
25	1 612 001 027	Connecting Rod	57	94	1 611 015 021	Gasket	79
26	1 610 910 092	Needle Bearing	56	95	1 614 431 030	Cable	10
27	1 610 210 033	O-Ring {2}	78	96	1 614 448 037	Cable {2}	10
28	1 618 700 043	Piston	47	97	2 915 011 007	Nut {2}	89
30	1 614 601 039	Retainer	89	99	3 613 313 500	Nut {2}	89
32	1 900 210 156	O-Ring {2}	78	102	2 910 211 025	Screw {2}	89
33	3 613 101 500	Wrist Pin	47	104	2 910 141 201	Screw {4}	89
34	1 618 710 039	Striker	44	105	2 914 551 188	Screw {4}	89
36	1 900 210 166	O-Ring	78	106	2 914 551 189	Screw {4}	89
37	1 615 806 029	Guide Tube	43	107	2 910 141 242	Screw {4}	89
38	1 610 220 009	Ring	49	108	2 914 201 707	Screw {4}	89
39	1 614 619 005	Spring	49	109	2 910 141 248	Screw {9}	89
40	1 615 700 017	Flange	38	110	2 910 141 356	Screw {4}	89
41	1 610 210 008	O-Ring {2}	86	111	3 613 450 500	Hex Bolt {3}	89
42	1 613 123 003	Impact Bolt	45	112	2 910 211 236	Screw {2}	89
44	1 618 045 018	Locking Lever	86	114	2 917 721 034	Pin {2}	89
45	1 613 103 004	Locking Bolt	86	119	1 601 110 058	Label	9
46	2 917 760 187	Roll Pin {2}	86	131	1 601 110 618	Label	9
47	1 900 210 172	O-Ring	78	801	1 617 000 851	Motor Housing Assembly	71
48	1 610 516 007	Eccentric Cover	9			w/pos. 11, 12, 15, 67, 71,	
49	1 610 707 000	Sleeve	9			86, 87, 88, 114, 813	
50	3 600 421 500	Brass Bushing	82	803	1 614 011 092	Armature 120V	AW
51	1 610 703 019	Strain Relief	11	813	1 610 910 035	Needle Bearing	61
52	1 615 500 324	Slide Housing Cover	70	843	1 617 000 428	Tool Holder Assembly	84
53	1 615 500 325	Top Housing Cover	70			w/pos. 32	
55	3 604 460 507	Cord 115V	11	854	3 607 000 509	Switch Housing Assembly	74
55/1	1 900 452 003	Terminal Sleeve {2}	11			w/pos. 108, 112	
56	1 610 703 011	Strain Relief	11	858	1 610 591 001	Switch Button	9
57	1 615 500 212	Switch Cover	9	859	2 910 091 118	Switch Screw {6}	89
58	1 617 200 015	Switch	15	861	1 617 000 429	Mounting Plate Assembly	9
59	1 615 700 041	Intermediate Plate	38	879	1 614 652 001	Brush Spring {2}	27
60	1 615 500 211	Switch Flange	9	881	1 613 490 005	Screw {2}	89
62	1 612 026 011	Switch Lever	63	882	2 916 699 130	Lock Washer {2}	65
63	1 615 132 010	Switch Handle	74	883	1 617 000 425	Brush Set	26
64	1 616 334 000	Handle Buffer {2}	9	895	1 615 430 016	Grease 1000ml	1
65	1 613 060 005	Shaft	54	897	1 617 000 426	Service Pack	78
67	2 916 660 023	Retaining Ring	89	898	1 615 430 015	Grease 225ml	1

## Service Notes:

Use 1 981 000 975 Spanner Wrench for removal/installation of 1 615 500 214 (Pos. 6) Retaining Nut.