

Item	Description	Part No.	Part No.
		TT55G	TT90G
1	Compressor w/flywheel	PV02A	PT03A
2	Pressure Gauge	PG200-2.5SI1/4	PG200-2.5SI1/4
3	Regulator Assembly	R202-1/4	R202-1/4
4	Air Receiver	10TT41X5-B	10TT41X5-B
5	Drain Cock	DC1/4	DC1/4
6	V-Belt	A49	A54
7	Belt Guard	TT-GUARD	TT-GUARD
8	Engine -Honda	GX160K1QX6	GX270A6
9	Pilot Unloader Valve & Check Valve	LMV100F	LMV100F
10	Pulley - Engine	MAL37	MAL37
11	Safety Valve	PSV1/4-150	PSV1/4-150
12	Engine Control w/Cable	TCP-48	TCLP-48
13	Handle Grip	TT-GRIP (2)	TT-GRIP (2)
14	Vibration Damper	TT-FOOT (4)	TT-FOOT (4)
15	Pneumatic Wheel	TT-WHEEL	TT-WHEEL
16	Quick Coupler	CPL-DUO	CPL-TRI
17	Hose Assembly - Regulator	TT-HOSE	TT-HOSE
18	Gauge, Regulator	PT0160	PT0160
19	Discharge Tube	TU-1/2-CU (3')	TU-1/2-CU (3')
	Eagle Compressor Oil		

Item	Description	Part No.
		TT90GE
1	Compressor w/flywheel	PT03A
2	Pressure Gauge	PG200-2.5SI1/4
3	Regulator Assembly	R202-1/4
4	Air Receiver	10TT41X5-B
5	Drain Cock	DC1/4
6	V-Belt	A54
7	Belt Guard	TT-GUARD
8	Engine -Honda	GX270QAE
9	Pilot Unloader Valve & Check Valve	LMV100F
10	Pulley - Engine	MA38X1
11	Safety Valve	PSV1/4-150
12	Engine Control w/Cable	TCLP-48
13	Handle Grip	TT-GRIP (2)
14	Vibration Damper	TT-FOOT (4)
15	Pneumatic Wheel	TT-WHEEL
16	Quick Coupler	CPL-TRI
17	Hose Assembly - Regulator	TT-HOSE
18	Gauge, Regulator	PT0160
19	Discharge Tube	TU-1/2-CU (3')
	Eagle Compressor Oil	EAOIL10

