


LS600 PUMP — WIRING DIAGRAM (ENGINE START/SHUTDOWN RELAY)

CONTROL BOX INTERIOR
ENGINE START/SHUTDOWN RELAY



Engine Start/Shutdown Relay

MAYCO LS600 PUMP

www.discount-equipment.com