



**PARTS LIST MANUAL**

**VAC-200**



**200 CFM HEPA 2.0 VACUUM**

PART #	MODEL #	POWER OPTION
ED33125HCONK	WNS2220	DUAL MOTORS, 3.2 HP 120V

**READ AND UNDERSTAND THE OPERATOR'S SAFETY MANUAL THOROUGHLY BEFORE ATTEMPTING TO OPERATE THIS EQUIPMENT.**



Death or serious injury could occur if this machine is used improperly.  
Machine specific Operator's Instruction Manuals are offered at <https://discount-equipment.com>



# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

**Search Manuals**

Enter your information to help us find the right parts manual for your machine.

\* Brand:

\* Model:

\* Serial:

\* Part Number:

SEARCH

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

**Parts Order Form**

Please fill in the following information to help us find the right part for your machine.

Manufacturer:	<input type="text"/>
Model:	<input type="text"/>
Description:	<input type="text"/>
Part Number:	<input type="text"/>
Quantity:	<input type="text"/>
Notes:	<input type="text"/>

Submit

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar

**SAFETY INFORMATION****SAFETY MESSAGES**

• Safety Instructions are preceded by a graphic alert symbol of DANGER, WARNING, or CAUTION.

**DANGER**

Indicates an imminent hazard which, if not avoided, will result in death or serious injury.

**WARNING**

Indicates an imminent hazard which, if not avoided, can result in death or serious injury.

**CAUTION**

Indicates hazards which, if not avoided, could result in serious injury and or damage to the equipment.

**GASOLINE / PROPANE POWERED EQUIPMENT****WARNING**

• Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

**WARNING**

• Tilting a gasoline powered machine fitted with an EPA approved vented charcoal filter gas cap, beyond 20° can cause fuel leakage. If a leak occurs, do not start or run the engine until the leak is fixed. Eliminate all other ignition sources in the immediate area (no smoking, flares, sparks or flames). Use approved gasoline absorbing material to contain the fuel leakage. Then use clean, non-sparking tools to collect absorbed materials then dispose of these contaminants properly.



• Gasoline is extremely flammable and poisonous. It should only be dispensed in well ventilated areas, and with a cool engine.

• Small gasoline engines produce high concentrations of carbon monoxide (CO) example: a 5 HP 4 cycle engine operation in an enclosed 100,000 cu. ft. area with only one change of air per hour is capable of providing deadly concentrations of CO in less than fifteen minutes. Five changes of air in the same area will produce noxious fumes in less than 30 minutes. Gasoline powered equipment should not be used in enclosed or partially enclosed areas. Symptoms of CO poisoning include, head-ache, nausea, weakness, dizziness, visual problems and loss of consciousness. If symptoms occur - get into fresh air and seek medical attention immediately.

- Never refuel a hot engine or an engine while it is running.
- Engines are shipped from factory without fuel/oil.



• Propane is extremely flammable and is heavier than air and tends to settle in low areas where a spark or flame could ignite gas. DO NOT start or operate this propane engine in a poorly ventilated area where leaking propane gas could accumulate and endanger safety of persons in area. If headache develops, shut off machine. Have it checked for carbon monoxide emissions by a qualified technician before using it again. To ensure personal safety, installation and repair of propane fuel supply systems must be performed only by qualified technicians. Carbon monoxide emissions from this machine are greatly increased due to a dirty combustion air cleaner.

**ELECTRICAL POWERED EQUIPMENT**

Extreme care must be taken when operating electric models with water present: Ensure power cord is properly grounded, is attached to a Ground-Fault-Interrupter (GFI) outlet, and is undamaged.

- Check all electrical cables - be sure connections are tight and cable is continuous and in good condition. Be sure cable is correctly rated for both the operating current and voltage of this equipment.
- Improper connection of the equipment grounding conductor can result in a risk of electric shock. Check with qualified electrician or service person if there is any doubt as to whether the outlet is properly grounded. Adhere to all local codes and ordinances.
- NOTE: In the event of a malfunction or breakdown, grounding provides a path of least resistance for the electric current to dissipate. The motor is equipped with a grounded plug and must be connected to an outlet that is properly installed and properly grounded. DO NOT modify the plug provided on the motor. If the plug does not fit the outlet have a qualified electrician install the proper receptacle.

**ELECTRICAL POWERED EQUIPMENT CONTINUED**

- Do not disconnect power by pulling cord. To disconnect, grasp the plug, not the cord.
- Unplug power cord at the machine when not in use and before servicing.
- Switch motor OFF before disconnecting power.
- Never use frayed, damaged, taped or under rated extension cords. Electrical shock could result in death or serious injury to the operator and damage to the equipment.
- Assure you are using the proper extension cord length.

**GENERAL INSTRUCTIONS**

- Equipment should only be operated by trained personnel in good physical condition and mental health (not fatigued). The operator and maintenance personnel must be physically able to handle the bulk weight and power of this equipment.
- This is a one person tool. Maintain a safe operating distance to other personnel. It is the operators' responsibility to keep other people (workers, pedestrians, bystanders, etc.) away during operation. Block off the work area in all directions with roping, safety netting, etc. Failure to do so may result in others being injured by flying debris or exposing them to harmful dust and noise.
- This equipment is intended for commercial use only.
- For the operator's safety and the safety of others, always keep all guards in place during operation.
- Never let equipment run unattended.



- Personal Protection Equipment and proper safety attire must be worn when operating this machinery. The operator must wear approved safety equipment appropriate for the job such as hard hat and safety shoes when conditions require. Hearing protection MUST be used when operational noise levels of this equipment may exceed 85db. Eye protection MUST be worn at all times.



Keep body parts, loose clothing and accessories away from moving parts. Failure to do so could result in dismemberment or death.

- Do not modify the machine.
- Stop motor/engine when adjusting or servicing this equipment. Maintain a safe operating distance from flammable materials. Sparks from the cutting-action of this machine can ignite flammable materials or vapors.

**DUST WARNING**

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to cause cancer, birth defects, or other reproductive harm. Materials being removed can be toxic or hazardous. A breathing respirator is required to help protect the operator.

Some examples of these chemicals are:

- Lead from lead-based paints.
- Crystalline silica from bricks, concrete and other masonry products. Your risk of exposure to these chemicals varies depending on how often you do this type of work. To reduce your risk: work in a well ventilated area, use a dust control system, such as an industrial-style vacuum, and wear approved personal safety equipment, such as a dust/particle respirator designed to filter out microscopic particles.
- See more on the importance of dust prevention and silica warnings at: [osha.gov/silica](http://osha.gov/silica)

# PARTS LIST MANUAL


## VAC-200

### 200 CFM HEPA 2.0 VACUUM

#### TABLE OF CONTENTS


<u>Section</u>	<u>Page Number</u>
Safety Information .....	2
How To Order Replacement Parts .....	3
Illustration 1: Base Assembly .....	4, 5
Illustration 2: Dustpan Lever Assembly .....	6
Illustration 3: 50mm Inlet Assembly .....	7
Illustration 4: 1.2M Filter & Manual Shaker Assembly .....	8, 9
Illustration 5: Motor Deck Assembly .....	10, 11
Illustration 6: Motor Head Assembly, 120V, 1200 Watt .....	12, 13
Illustration 7: HEPA 2.0 Filter Assembly .....	14
Illustration 8: Hose, Wand and Floor Tool .....	15
Illustration 9: Optional Accessories .....	16
Illustration 10: Floor Tool Sweep Mount .....	17
Decal Sheet .....	18
Limited Equipment Warranty of Sale - Terms & Conditions .....	19
STOP - Before Using This Product .....	20

**ILLUSTRATION 1:  
BASE ASSEMBLY**




<b>PARTS LISTING - ILLUSTRATION 1: BASE ASSEMBLY</b>			
ITEM #	PART #	DESCRIPTION	QTY.
1	ED34808002	LOWER HOUSING, D1, 50MM, RED	1
2	ED25080	PUSH HANDLE, D1, W2	1
3	ED32039R	HANDLE SUPPORT, PLASTIC	2
4	ED34813	DUSTPAN WITH GASKET, RED	1
	ED2509865	DUST PAN REPLACEMENT GASKET	1
5	ED20070	GASKET, DUST PAN/LOWER HOUSING	1
6	ED25085	CASTER, DUAL, FIXED, 75MM, W/BRAKE	2
7	ED34882	WASHER, FLAT/THIN M8 ZINC	2
8	ED25037	WASHER, EXT. STAR M8 ZINC	4
9	ED25054	BOLT, HEX, M8 X 25, ZINC	2
10	ED22120	PLUG, 8MM, BLACK	4
11	ED25038	BOLT, HEX, M8 X 20, DIN 933, ZINC	2
12	ED200190	WASHER, M8 BLK NYLON	6
13	ED32927	NUT, ACORN M8	2
14	ED34810	BOLT, HEX M8 X 50	2
15	ED20050	WASHER, SPLIT LOCK M8	2
16	ED25061	WASHER, FLAT, M8, DIN125, ZINC	2
17	ED25060	KNOB, BLACK, 8MM	2
18	ED20010A	DUST PAN LEVER ASSY., DS1/WS (REFER TO ILLUS. 2 FOR BREAKDOWN)	1
19	ED2509862	GASKET, 10MM, 62IN	1
20	ED25084	CASTER, DUAL, SWIVEL, 75MM	2
21	ED20006A	INLET KIT, 50MM, ALUMINUM (REFER TO ILLUS. 3 FOR BREAKDOWN)	1



**ILLUSTRATION 2: DUSTPAN LEVER ASSEMBLY**

ITEM #	PART #	DESCRIPTION	QTY.
1	ED20010	FOOT LEVER, D1	1
2	ED34812	SPACER FOR FOOT LEVER	2
3	ED20044	NUT, HEX M8-8, DIN 934, ZINC	4
4	ED34882	WASHER, FLAT/THIN M8 ZINC	6
5	ED25061	WASHER, FLAT, M8, DIN125, ZINC	6
6	ED30029	NUT, LOCK, M8, ZINC	4
7	ED34921	PIN, D6X15MM	2
8	ED20027	FLAT STEEL PIVOT	2
9	ED25067	WASHER, FLAT, M6, DIN 125, ZINC	4
10	ED34923	C SPRING CLIP, ZINC	4
11	ED34922	PIN, D6 X 19MM	2
12	ED34852*	TENSION LEVER, DUSTPAN (*USE ED34852A FOR KIT)	2
12-13	ED34852A	TENSION LEVER W/ BEARING, DUSTPAN	2
13	ED34853*	BEARING, DUSTPAN LEVER (*USE ED34852A FOR KIT)	2
14	ED34811	BOLT, HEX M8 X 55, DIN 933, ZINC	2
15	ED25037	WASHER, EXT. STAR, M8, ZINC	2
16	ED25053	BOLT, CARRAIGE M8 X 35	2



**ILLUSTRATION 3: 50mm INLET ASSEMBLY**



ITEM #	PART #	DESCRIPTION	QTY.
1	ED20006	INLET, 50MM, ALUMINUM	1
2	ED34870	GASKET 50MM INLET	1
3	ED20021	DEFLECTOR, 50MM, ALUMINUM	1
4	ED32870	SCREW, SOC HD CAP M4 X 25 ZINC	3
5	ED328667	WASHER, FLAT, M4, DIN 125, ZINC	3
6	ED25057	SCREW, SOC HD CAP M4 X 20 ZINC	1
7	ED32867	WASHER, EXT. STAR, M5, ZINC	1




# ILLUSTRATION 4: 1.2M FILTER & MANUAL SHAKER ASSEMBLY



<b>PARTS LISTING - ILLUSTRATION 4: 1.2M FILTER ASSEMBLY &amp; MANUAL SHAKER</b>			
<b>ITEM #</b>	<b>PART #</b>	<b>DESCRIPTION</b>	<b>QTY.</b>
1	ED34823002	HOUSING SPACER, PORT, SMALL, RED	1
2	ED34815	SCREW, SOC FH CAP M6 X 30	4
3	ED34806	SHAKER ROD MOUNTING SUPPORT	2
4	ED34805	HOSE, 3/4 ID CLEAR	2
5	ED34802	SLIDE ASSEMBLY, W/ HOOK	2
6	ED25047	CLEVIS, DIN 71752G, STEEL	1
7	ED22565	SHAKER BAR W/ SWIVEL HANDLE	1
8	ED34879	SPRING CLIP, 6 X 12, CLEVIS YOKE	1
9	ED34804	SLIDE BAR, FILTER MANUAL SHAKER	1
10	ED25056	FILTER SUPPORT WELDMENT, 1.2M	1
11	ED34871	PLASTIC PLUG 4.5/13	4
12	ED20040	NUT, HEX, M6-8, DIN 934, ZINC	4
13	ED20039	WASHER, SPLIT LOCK, M6 DIN 7980	4
14	ED34998	GROUND CONNECTION, FOR BOLT	2
15	ED34876	NUT, LOCK M6 ZINC	7
16	ED20045	NUT, SQUARE, M8, ZINC	2
17	ED25038	BOLT, HEX, M8 X 20, DIN 933, ZINC	2
18	ED20050	WASHER, SPLIT LOCK, M8	2
19	ED34868	GROUND WIRE, FILTER TO DEFLECTOR	1
20	ED20091F	FILTER INSERT, 1.2M	8
21	ED20091	FILTER, 13 SQ/FT, 1.2M	1
22	ED20044	NUT, HEX M8-8, DIN 934, ZINC	1
23	ED3137766	GASKET, NITRILE SPONGE FOR D1	1
24	ED3481701	SCREW, BH SOC, FLANGED, M6 X 25	6
25	ED34817A	M6 BLIND PEM	2
26	ED25000	WASHER, EXT. STAR 1/4"	2
27	ED34819	WASHER, FENDER, M6	4
28	ED30095	FILTER BAR SUPPORT, DS1/W2	1
29	ED34817	SCREW, SOC BH, ULS, M6 X 20	2

**ILLUSTRATION 5: MOTOR DECK ASSEMBLY**




- NOTES:  
 1. PEM INSTALLATION INSTRUCTIONS  
 1. DRILL INTO LOWER HOUSING W/ 6MM BIT  
 2. REMOVE UPPER HOUSING, BORE OUT W/ 8MM BIT  
 3. INSERT PEM INTO LOWER HOUSING W/ PEM GUN




<b>PARTS LISTING - ILLUSTRATION 5: MOTOR DECK ASSEMBLY</b>			
ITEM #	PART #	DESCRIPTION	QTY.
1	ED20020	MOTOR HOLD DOWN BRACKET	4
2	ED32999	JUNCTION BOX, ELECTRICAL, GREY	1
3	ED25210	FEMALE IEC PLUG W/12" WIRE	2
4	ED2005531	POWER CORD, 12/3 SJO W/MOLDED PLUG	1
5	ED27001A	MOTOR HEAD, COMPLETE (REFER TO ILLUS. 6 FOR BREAKDOWN)	2
6	ED21092-1	INSULATOR, GAS EX, BRASS	3
7	ED90223WNS	MOTOR DECK, RED, DS1	1
8	ED21092	WIRE NUT, GAS EX, CRIMP ON	3
9	ED26603	KNOB FOR MOTOR HOLD DOWN, M6	4
10	ED34817A	M6 BLIND PEM	6
11	ED34817	SCREW, SOC BH, ULS, M6 X 20	2
12	ED34876	NUT, LOCK M6 ZINC	2
13	ED25000	WASHER, EXT. STAR 1/4"	2
14	ED34819	WASHER, FENDER, M6	2
15	ED3481701	SCREW, BH SOC, FLANGED, M6 X 25	2
16	ED34960	PG 09 CABLE GRIP	2
17	ED34961	STRAIN RELIEF, 90, 1/2", BLACK	1
18	ED270179KIT-WNS	GROUND, PART OF WIRE KIT FOR WNS	1
19	ED31376002	GASKET, NEOPRENE, .188", 5.4FT LG	1

**ILLUSTRATION 6: MOTOR HEAD ASSEMBLY, 120V, 1200 WATT**



PARTS LISTING - ILLUSTRATION 6: MOTOR HEAD ASSEMBLY, 120V, 1000 WATT			
ITEM #	PART #	DESCRIPTION	QTY.
1	ED27015	HOUSING COVER, SINGLE MOTOR	1
2	ED27014	MOTOR HOUSING, SINGLE MOTOR	1
3	ED8004	SUPPORT RING, SINGLE MOTOR	1
4	ED27002	MOTOR, 120V, 1200 WATT	1
	ED33327	REPLACEMENT BRUSHES: BRUSH SET, ELECTRO MOTOR	1
	ED33326	BRUSH SET, AMETEK MOTOR	1
5	ED27007	SEPARATOR PLATE, WNS MOTOR HEAD	1
6	ED2509811R	MOTOR HEAD GASKET	1
7	ED27001	MOTOR HEAD, ALUMINUM	1
8	ED27004	GASKET FOR MOTOR HEAD, WNS	1
9	ED27012	SCREW #8 X 1/2" PHIL PAN HEAD, ZINC	3
10	ED27017	SWITCH, ROCKER, 1000/1200W	1
11	ED25211	MALE IEC PLUG	1
12	ED27003	SCREW #8 X 2" PHIL PAN HEAD, ZINC	6
13	ED32989	HEX WASHER TEX SCREW, #10-16, .625LG	1
14	ED27011	SCREW, #6 X 0.5	2
15	ED31715	TERMINAL, 90 DEG, 16-14 GA. BLUE	2
16	ED8021	PROTECTION SCREEN, MOTOR HEAD	1
17	ED25064	SCREW PHIL PH #8 X 5/8" ZINC	2




## WIRE DIAGRAM







**ILLUSTRATION 7: HEPA 2.0 FILTER MODULE**

SILICA COMPLIANT

*Meets and Exceeds OSHA Respiratory Standards*




INSTALLED



ITEM #	PART #	DESCRIPTION	QTY.
1-10	ED35192CON	HEPA 2.0 FIELD UPGRADE KIT (INCLUDES ITEMS 1 THRU 10)	1
1	ED34823004	SMALL SPACER RING, HEPA 2.0	1
2	ED3481701	SCREW, BH SOC, FLANGED, M6 X 25	2
3	ED25000	WASHER, EXT. STAR 1/4"	2
4	ED3137766	GASKET, NITRILE SPONGE FOR D1	1
5	ED34817A	M6 BLIND PEM	2
6	ED35211CON	HEPA FILTER 2.0	2
7	ED3519201	HEPA RETAINING BRACKET, CONTRACTOR	2
8	ED20031	WASHER, FENDER, 1/4 X 1-1/4	2
9	ED250025	NUT, 1/4-20, ZINC	2
10	ED25001	NUT, LOCK 1/4-20, ZINC	2

**ILLUSTRATION 8:  
HOSE, WAND AND FLOOR TOOL**




ITEM #	PART #	DESCRIPTION	QTY.
1	ED5220-BL	HOSE CONNECTOR 2"BL TO 2" HOSE	1
2	ED501425 ED5014B	HOSE, 2" X 25', PLASTIC CRUSH-PROOF (WITH CUFFS) REPLACEMENT 2" HOSE CUFF ONLY	1 2
3	ED5004	WAND, 2" X 45", DOUBLE BEND, CHROME 1.5" TOOL COUPLING	1
4	ED3512N	FLOOR TOOL W/ NYLON BRISTLES 14"	1
5	ED3512NA	REPLACEMENT NYLON BRISTLES 14"	1

**ILLUSTRATION 9: OPTIONAL ACCESSORIES**



**PART # ED5018**  
**FLOOR SWEEP KIT 32"**  
INCLUDES ALL MOUNTING  
BRACKETS AND HARDWARE.

**PART # ED5018DA**  
**REPLACEMENT SQUEEGEE**



**PART # ED5003K PRO WAND KIT**  
INCLUDES PART # ED5003 WAND  
& PART # ED5060 FLOOR TOOL




**PART # ED5060 FLOOR TOOL, 20" W/ ROLLERS**

**PART # ED5060A REPLACEMENT SQUEEGEE**  
(500mm RUBBER STRIP)

**PART # ED5003 WAND 45", SINGLE BEND**

**ILLUSTRATION 10: FLOOR TOOL MOUNT BRACKET**



ITEM #	PART #	DESCRIPTION	QTY.
1-5	ED9703KIT	MOUNTING BRKT FOR VAC. FLOOR SWEEP (INCLUDES ITEMS 1 THRU 5)	1
1	ED9703	MOUNTING BRACKET, FLOOR TOOL, D1	1
2	ED34818	BOLT, CARRIAGE M6 X 30, ZINC	4
3	ED20040	NUT, HEX, M6-8, DIN 934, ZINC	4
4	ED20039	WASHER, SPLIT LOCK, M6 DIN 7980	4
5	ED34819	WASHER, FENDER M6	4

# PARTS FINDER

**Search Website  
by Part Number**



**Search Manual  
Library For Parts  
Manual & Lookup Part  
Numbers – Purchase  
or Request Quote**

**Search Manuals**

Enter your information to help us find the right parts manual for your machine.

\* Brand:

\* Model:

\* Serial:

\* Part Number:

SEARCH

**Can't Find Part or  
Manual? Request Help  
by Manufacturer,  
Model & Description**

**Parts Order Form**

Please fill in the following information to help us find the right part for your machine.

Manufacturer:	<input type="text"/>
Model:	<input type="text"/>
Description:	<input type="text"/>
Part Number:	<input type="text"/>
Quantity:	<input type="text"/>
Notes:	<input type="text"/>

Submit

Discount-Equipment.com is your online resource for quality parts & equipment.

Florida: **561-964-4949** Outside Florida TOLL FREE: **877-690-3101**

**Need parts?**

Click on this link: <http://www.discount-equipment.com/category/5443-parts/> and choose one of the options to help get the right parts and equipment you are looking for. Please have the machine model and serial number available in order to help us get you the correct parts. If you don't find the part on the website or on one of the online manuals, please fill out the request form and one of our experienced staff members will get back to you with a quote for the right part that your machine needs.

We sell worldwide for the brands: Genie, Terex, JLG, MultiQuip, Mikasa, Essick, Whiteman, Mayco, Toro Stone, Diamond Products, Generac Magnum, Airman, Haulotte, Barreto, Power Blanket, Nifty Lift, Atlas Copco, Chicago Pneumatic, Allmand, Miller Curber, Skyjack, Lull, Skytrak, Tsurumi, Husquvarna Target, Stow, Wacker, Sakai, Mi-T-M, Sullair, Basic, Dynapac, MBW, Weber, Bartell, Bennar Newman, Haulotte, Ditch Runner, Menegotti, Morrison, Contec, Buddy, Crown, Edco, Wyco, Bomag, Laymor, EZ Trench, Bil-Jax, F.S. Curtis, Gehl Pavers, Heli, Honda, ICS/PowerGrit, IHI, Partner, Imer, Clipper, MMD, Koshin, Rice, CH&E, General Equipment, Amida, Coleman, NAC, Gradall, Square Shooter, Kent, Stanley, Tamco, Toku, Hatz, Kohler, Robin, Wisconsin, Northrock, Oztec, Toker TK, Rol-Air, APT, Wylie, Ingersoll Rand / Doosan, Innovatech, Con X, Ammann, Mecalac, Makinex, Smith Surface Prep, Small Line, Wanco, Yanmar